

# How to Use This Manual

---

We want to help you get the most driving pleasure from your vehicle. Your owner's manual, when read from cover to cover, can do that in many ways.

Illustrations complement the words of the manual to best explain how to enjoy your Mazda. By reading your manual, you can find out about the features, important safety information, and driving under various road conditions.



The above symbol in this manual means "Do not do this " or "Do not let this happen".

**Index:** A good place to start is the Index, an alphabetical listing of all information in your manual.

You'll find several **WARNINGS**, **CAUTIONS**, and **NOTES** in the manual.

## **WARNING**

*A **WARNING** indicates a situation in which serious injury or death could result if the warning is ignored.*

## **CAUTION**

A **CAUTION** indicates a situation in which bodily injury or damage to your vehicle, or both, could result if the caution is ignored.

## **NOTE**

A **NOTE** provides information and sometimes suggests how to make better use of your vehicle.



The above symbol, located on some parts of the vehicle, indicates that this manual contains information related to the part. Please refer to the manual for a detailed explanation.

# A Word to Mazda Owners

---

Thank you for choosing a Mazda. We at Mazda design and build vehicles with complete customer satisfaction in mind.

To help ensure enjoyable and trouble-free operation of your Mazda, read this manual carefully and follow its recommendations.

An Authorized Mazda Dealer knows your vehicle best. So when maintenance or service is necessary, that's the place to go.

Our nationwide network of Mazda professionals is dedicated to providing you with the best possible service.

We assure you that all of us at Mazda have an ongoing interest in your motoring pleasure and in your full satisfaction with your Mazda product.

**Mazda Motor Corporation**  
HIROSHIMA, JAPAN

## **Important Notes About This Manual**

Keep this manual in the glove box as a handy reference for the safe and enjoyable use of your Mazda. Should you resell the vehicle, leave this manual with it for the next owner.

All specifications and descriptions are accurate at the time of printing. Because improvement is a constant goal at Mazda, we reserve the right to make changes in specifications at any time without notice and without obligation.

## **Air Conditioning and the Environment**

Your Mazda's genuine air conditioner is filled with HFC134a (R134a), a refrigerant that has been found not to damage the earth's ozone layer. If the air conditioner does not operate properly, consult an Authorized Mazda Dealer.

**Please be aware that this manual applies to all models, equipment and options. As a result, you may find some explanations for equipment not installed on your vehicle.**

©2002 Mazda Motor Corporation  
Printed in Japan Sep. 2002(Print2)

# Table of Contents

|                                                                                                                                            |           |
|--------------------------------------------------------------------------------------------------------------------------------------------|-----------|
| <b>Your Vehicle at a Glance</b><br>Interior, exterior views and part identification of your Mazda.                                         | <b>1</b>  |
| <b>Essential Safety Equipment</b><br>Use of safety equipment, including seats, seat belt system, SRS air bags and child-restraint systems. | <b>2</b>  |
| <b>Knowing Your Mazda</b><br>Explanation of basic operations and controls; opening/closing and adjustment of various parts.                | <b>3</b>  |
| <b>Before Driving Your Mazda</b><br>Important information about driving your Mazda.                                                        | <b>4</b>  |
| <b>Driving Your Mazda</b><br>Explanation of instruments and controls.                                                                      | <b>5</b>  |
| <b>Interior Comfort</b><br>Use of various features for drive comfort, including climate control and audio system.                          | <b>6</b>  |
| <b>In Case of an Emergency</b><br>Helpful information on what to do in an emergency.                                                       | <b>7</b>  |
| <b>Maintenance and Care</b><br>How to keep your Mazda in top condition.                                                                    | <b>8</b>  |
| <b>Customer Information</b><br>Important consumer information including warranties and add-on equipment.                                   | <b>9</b>  |
| <b>Specifications</b><br>Technical information about your Mazda.                                                                           | <b>10</b> |
| <b>Index</b>                                                                                                                               | <b>11</b> |




# 1

## Your Vehicle at a Glance


Interior, exterior views and part identification of your Mazda.

|                                 |            |
|---------------------------------|------------|
| <b>Dashboard Overview .....</b> | <b>1-2</b> |
| <b>Interior Overview .....</b>  | <b>1-3</b> |
| <b>Exterior Overview .....</b>  | <b>1-4</b> |


# Dashboard Overview





## Interior Overview



# Exterior Overview



## Exterior Overview





# 2

## Essential Safety Equipment

Use of safety equipment, including seats, seat belt system, SRS air bags and child-restraint systems.

|                                                              |      |
|--------------------------------------------------------------|------|
| <b>Seats</b> .....                                           | 2-2  |
| Front Seats .....                                            | 2-2  |
| Rear Seat .....                                              | 2-5  |
| <b>Seat Belt Systems</b> .....                               | 2-11 |
| Seat Belt Precautions .....                                  | 2-11 |
| 3-Point Type Seat Belt .....                                 | 2-14 |
| Front Seat Belt Pretensioner and Load Limiting Systems ..... | 2-16 |
| Rear Center Position Seat Belt .....                         | 2-18 |
| Seat Belt Extender .....                                     | 2-20 |
| Seat Belt Warning Light .....                                | 2-21 |
| Seat Belt Warning Beep .....                                 | 2-21 |
| <b>Child Restraint</b> .....                                 | 2-22 |
| Child Restraint Precautions .....                            | 2-22 |
| Installing Child-Restraint Systems .....                     | 2-25 |
| LATCH Child-Restraint Systems .....                          | 2-31 |
| <b>SRS Air Bags</b> .....                                    | 2-36 |
| Supplemental Restraint Systems (SRS) Precautions .....       | 2-36 |
| Air Bag System Description .....                             | 2-40 |

## Seats

### Front Seats

#### **WARNING**

##### **Securing the Seats:**

*Adjustable seats and seatbacks that are not securely locked are dangerous. In a sudden stop or collision, the seat or seatback could move, causing injury. Make sure the adjustable components of the seat are locked in place by attempting to slide the seat forward and backward and rocking the seatback.*


#### ▼ Seat Slide

#### **WARNING**

##### **Driver's Seat Adjustment:**

*Adjusting the driver's seat while the vehicle is moving is dangerous. The driver could lose control of the vehicle and have an accident. Adjust the driver's seat only when the vehicle is stopped.*

To move a seat forward or backward, raise the lever and slide the seat to the desired position and release the lever.



Make sure the lever returns to its original position and the seat is locked in place by attempting to push it forward and backward.


**▼ Seat Recline****⚠ WARNING****Reclining:**

*Sitting in a reclined position while the vehicle is moving is dangerous because you don't get the full protection from seat belts. During sudden braking or a collision, you can slide under the lap belt and suffer serious internal injuries. For maximum protection, sit well back and upright.*

**Unlocked Seatback:**

*A seatback plays an important role in your protection in a vehicle. Leaving the seatback unlocked is dangerous as it can allow passengers to be ejected or thrown around and baggage to strike occupants in a sudden stop or collision, resulting in severe injury. After adjusting the seatback at any time, even when there are no other passengers, rock the seatback to make sure it is locked in place.*

To change the seatback angle, lean forward slightly while raising the lever. Then lean back to the desired position and release the lever.



Make sure the lever returns to its original position and the seatback is locked in place by attempting to push it forward and backward.



**⚠ CAUTION**

When returning a rear-reclined seatback to its upright position, make sure you support the seatback while operating the seatback lever. If the seatback is not supported, it will flip forward suddenly and could cause injury.

## Seats

### ▼ Seat Tilt (Driver's Seat)

The seat-bottom angle can be adjusted by rotating the dial.



### ▼ Head Restraint


#### **WARNING**

**Head Restraints Adjustment:**  
*Driving with the head restraints adjusted too low or removed is dangerous. With no support behind your head, your neck could be seriously injured in a collision. Always drive with the head restraints inserted when seats are being used and make sure they are properly adjusted.*

#### **Height adjustment**

To raise a head restraint, pull it up to the desired position.

To lower the head restraint, press the stop-catch release, then push the head restraint down.



Adjust the head restraint so that the top is parallel with the top of the passenger's ears, never the passenger's neck.

## Rear Seat

### **WARNING**

#### Stacking Cargo:

Stacking luggage or other cargo higher than the seatbacks, and putting things on the rear package tray or on the luggage compartment cover is dangerous. During sudden braking or a collision, objects can become projectiles that may hit and injure passengers. Don't stack things higher than the seatbacks or put things on the rear package tray or on the luggage compartment cover.

#### Securing Seats:

Adjustable seats and seatbacks that are not securely locked are dangerous. In a sudden stop or collision, the seat or seatback could move, causing injury. Make sure the adjustable components of the seat are locked in place by attempting to slide the seat forward and backward and rocking the seatback.

#### Unlocked Seatback:

A seatback plays an important role in your protection in a vehicle. Leaving the seatback unlocked is dangerous as it can allow passengers to be ejected or thrown around and baggage to strike occupants in a sudden stop or collision, resulting in severe injury. After adjusting the seatback at any time, even when there are no other passengers, rock the seatback to make sure it is locked in place.

### **WARNING**

#### Passenger on the Folded Seatback:

Driving with a passenger on the folded seatback is dangerous. Allowing a child to sit up on the folded seatback while the vehicle is moving is particularly dangerous. In a sudden stop or even a minor collision, a child not in a proper seat or child-restraint system and seat belt could be thrown forward, back or even out of the car resulting in serious injuries or death. The child or other objects in the baggage area could be thrown into other occupants and cause serious injury. Never allow a passenger to sit or stand on the folded seatback while the vehicle is moving.

#### Children and the Folding Rear Seats:

Playing with the folding rear seats is dangerous. Once the seats are back up, a child in the trunk would not be able to get out the way they had entered. If you have small children, keep the seatbacks locked (sedan). Do not give the car keys to children and do not allow them to play in the vehicle.

### **NOTE**

When returning a rear seat to its original position, also replace the seat belt to its normal position. Verify that the seat belt pulls and retracts.

## Seats

### ▼ Split-Folding Rear Seatback


To provide more space in the luggage compartment.

1. Unfasten the lap portion of the rear-center seat belt (page 2-19).

#### ⚠ CAUTION

Always unfasten the lap portion of the belt before folding the rear-left seatback. Leaving the lap portion of the belt fastened could cause damage to the seat belt, buckle and seatback.


2. Pull the lock release up and fold the seatback forward.



To return the seatback to its original position, reverse the procedure.

### ▼ Rear Seatback Lock (Sedan)

To lock or unlock a seatback, move the lever.



#### NOTE

The seatback locks are part of the trunk security system (page 3-11).

### ▼ Folding the Rear Seats Flat (Hatchback)


The seatbacks can be folded after setting up the seat bottoms.

1. Unfasten the lap portion of the rear-center seat belt (page 2-19).


#### ⚠ CAUTION

Always unfasten the lap portion of the belt before folding the rear-left seatback. Leaving the lap portion of the belt fastened could cause damage to the seat belt, buckle and seatback.

2. Remove the head restraints (page 2-9).




3. Pull the strap and lift the end of each seat bottom up and forward.




#### **NOTE**

When raising the seat bottom, hold the seat belt and clear it from the seat bottom's housing space.

4. Lift the rear of the seat bottoms forward.



5. Pull the lock release up and fold each seatback forward.



To return the rear seat to its original position, reverse the procedure.

## Seats

### ⚠ CAUTION


- Putting your fingers between the seat bottom and floor is dangerous. You could injure your fingers. When replacing the seat bottom, be careful not to catch your fingers between the seat bottom and floor.
- After replacing the seat bottom to its original position, make sure all seat belt buckles are on top of the seat bottom and the seat belts are not twisted. Twisting or placing the seat belts under the seat bottom could damage the seat belts.

### ▼ Removing the Seat Bottoms (Hatchback)

When flat folding the rear seats, the seat bottoms can be removed for more room.

#### To remove


1. Pull the strap and lift the end of each seat bottom up and forward.




### NOTE

When raising the seat bottom, hold the seat belt and clear it from the seat bottom's housing space.

2. Lift the rear of the seat bottoms forward.



3. Pull the retaining clip to release the lever. Remove the seat bottom.




**⚠ WARNING****Riding in Area with Rear Seat Bottom Removed:**

*Riding in the area where a rear seat bottom has been removed is dangerous. Sudden braking or a collision could cause serious injury. Do not sit or lie in the area where a rear seat bottom has been removed while the vehicle is moving. Never ride in a vehicle where you can't sit in the seat and wear the seat belt.*

**To install**

1. Insert the ends of the seat bottom lever into the holders.



2. Return the seat bottom to its original position.

**⚠ CAUTION**

- Putting your fingers between the seat bottom and floor is dangerous. You could injure your fingers. When replacing the seat bottom, be careful not to catch your fingers between the seat bottom and floor.
- After replacing the seat bottom to its original position, make sure all seat belt buckles are on top of the seat bottom and the seat belts are not twisted. Twisting or placing the seat belts under the seat bottom could damage the seat belts.

**▼ Head Restraint****⚠ WARNING****Head Restraints Adjustment:**

*Driving with the head restraints adjusted too low or removed is dangerous. With no support behind your head, your neck could be seriously injured in a collision. Always drive with the head restraints inserted when seats are being used and make sure they are properly adjusted.*


## Seats

---

### Height adjustment

To raise a head restraint, pull it up to the desired position.


To lower the head restraint, press the stop-catch release, then push the head restraint down.



Adjust the head restraint so that the top is parallel with the top of the passenger's ears, never the passenger's neck.

### Removal

To remove the head restraint, press the stop-catch release, then pull up on the head restraint.



## Seat Belt Precautions

Seat belts help to decrease the possibility of severe injury during accidents and sudden stops. Mazda recommends that the driver and all passengers always wear seat belts.

All of the seat belt retractors are designed to keep the lap/shoulder belts out of the way when not in use.

The driver's seat belt has no provisions for child-restraint systems and has only an emergency locking mode. The driver may wear it comfortably, and it will lock during a collision.

However, the front passenger's seat and rear lap/shoulder belt retractors operate in two modes: emergency locking mode, and for child-restraint systems, automatic locking mode.

### **WARNING**

#### **Not Wearing Seat Belts:**

*Not wearing a seat belt is extremely dangerous. During a collision, occupants not wearing seat belts could hit someone or things inside the vehicle or even be thrown out of the vehicle. They could be seriously injured or even killed. In the same collision, occupants wearing seat belts would be much safer. Always wear your seat belt and make sure all occupants are properly restrained.*

#### **Seat Belt Damaged During an Accident:**

*Using a damaged seat belt is dangerous. An accident could damage the belt webbing of the seat belt in use. A damaged seat belt cannot provide adequate protection in a collision. Have an Authorized Mazda Dealer inspect all seat belt systems in use during an accident before they are used again.*

#### **Twisted Seat Belts:**

*Twisted seat belts are dangerous. In a collision, the full width of the belt isn't available to absorb the impact. This puts more force on the bones beneath the belt, which could break them or cause other serious injury or death. Don't wear twisted seat belts.*

# Seat Belt Systems


## ⚠ WARNING

### One Belt, One Passenger:

*Using one seat belt for more than one person at a time is dangerous. A seat belt used in this way can't spread the impact forces properly and the two passengers could be crushed together and seriously injured or even killed. Never use one belt for more than one person at a time.*

## ⚠ CAUTION

Belt retraction may become difficult if the belts and rings are soiled, so try to keep them clean.



## ▼ Pregnant Women and Persons with Serious Medical Conditions

Pregnant women should wear seat belts. Ask your doctor for specific recommendations. The lap belt should be worn **SNUGLY AND AS LOW AS POSSIBLE OVER THE HIPS**. The shoulder belt should be worn across your shoulder properly, but never across the stomach area.

Persons with serious medical conditions also should wear seat belts. Check with your doctor for any special instructions regarding specific medical conditions.



**▼ Emergency Locking Mode**

If the belt has fully retracted, it will always be in the emergency locking mode until you move it into automatic locking mode by pulling the belt all the way out to its full length. In the emergency locking mode, the belt remains comfortable on the occupant and the retractor will lock in position during a collision.

If the belt feels tight and hinders comfortable movement while the vehicle is stopped or in motion, you may be in the automatic locking mode because you have pulled the belt too far out. To return to the more comfortable emergency locking mode, wait until you can stop the vehicle in a safe area, retract the belt fully to convert it back to emergency locking mode and then again extend it around you.

**▼ Automatic Locking Mode**

Always use the automatic locking mode to keep the child-restraint system from shifting to an unsafe position in the event of an accident. To get the seat belt into the automatic locking mode, pull it all the way out and connect it as instructed on the child-restraint system. It will retract down to the child-restraint system and stay locked on it. See the section on child restraint (page 2-22).

## Seat Belt Systems


### 3-Point Type Seat Belt

#### NOTE


When using the rear center seat belt, refer to "Rear Center Position Seat Belt" (page 2-18).

#### ▼ Fastening the Seat Belts

1. Grasp the buckle and tongue.
2. Slowly pull out the lap/shoulder belt.



3. Insert the tongue into the buckle until you hear a click.




#### ! WARNING

##### Positioning the Shoulder Portion of the Seat Belt:

*Improper positioning of the shoulder portion of the seat belt is dangerous. An improperly positioned belt will provide little or no protection in a collision. Always make sure the shoulder portion of the seat belt is positioned across your shoulder and near your neck, but never under your arm, on your neck, or on your upper arm.*

4. Make sure the shoulder belt is snugly fitted against your body.



#### ! WARNING


##### Positioning the Lap Portion of the Seat Belt:

*The lap portion of the seat belt worn too high is dangerous. In a collision, this would concentrate the impact force directly on the abdominal area, causing serious injury. Wear the lap portion of the belt snugly and as low as possible.*

# Seat Belt Systems

## ▼ Unfastening the Seat Belts

Depress the button on the buckle.




### NOTE

If a belt does not fully retract, inspect it for kinks and twists.

## ▼ Shoulder Belt Adjuster

Adjust the height of the shoulder belt if the seat belt touches your neck, or if it crosses your arm instead of your shoulder. To raise the shoulder belt adjuster, push the adjuster up. To lower the shoulder belt adjuster, push the button and slide it down. Make sure the adjuster is locked.



## ⚠ WARNING

### **Positioning the Shoulder Portion of the Seat Belt:**

***Improper positioning of the shoulder portion of the seat belt is dangerous. An improperly positioned belt will provide little or no protection in a collision. Always make sure the shoulder portion of the seat belt is positioned across your shoulder and near your neck, but never under your arm, on your neck, or on your upper arm.***

## Seat Belt Systems

### Front Seat Belt Pretensioner and Load Limiting Systems

For optimum protection, the driver and front passenger seat belts are equipped with pretensioner and load limiting systems.

In moderate or greater frontal or near-frontal accidents, the front air bag and pretensioner systems deploy simultaneously. The pretensioners take up slack in the front seat belts as the air bags are expanding. The load limiting system releases belt webbing in a controlled manner to reduce belt force on the occupant's chest.

#### **WARNING**

##### **Incorrect Positioning of the Driver and Front Passenger Seat Belts:**

*Incorrect positioning of the driver and passenger seat belts is dangerous. Without proper positioning, the pretensioner and load limiting systems cannot provide adequate protection in an accident and this could result in serious injury. Wear seat belts only as recommended in this owner's manual.*

#### **WARNING**

##### **Expendable Seat Belt Pretensioners:**

*Use of front seat belts with the pretensioner system expended is dangerous.*

*The seat belt pretensioners will only function once. After they are expended, they will not work again and must be replaced immediately, even if there was no front seat occupant seated at the time.*

*If the seat belt pretensioners are not replaced, the risk of injury in a collision will increase.*

*Always have an Authorized Mazda Dealer inspect and replace the seat belt pretensioners after a collision.*

##### **Modification or Testing of the Pretensioner System:**

*Modifying the components or wiring of the pretensioner system, including the use of electronic testing devices is dangerous. You could accidentally activate it or make it inoperable which would prevent it from activating in an accident. The occupants could be seriously injured. Never modify the components or wiring, or use electronic testing devices on the pretensioner system.*

##### **Pretensioner System Disposal:**

*Improper disposal of the pretensioner system or a vehicle with non-deactivated pretensioners is dangerous. Unless all safety procedures are followed, injury could result. Ask an Authorized Mazda Dealer how to safely dispose of the pretensioner system or how to scrap a pretensioner-equipped vehicle.*

## Seat Belt Systems

### NOTE

- The pretensioner system will only activate in a moderate or greater frontal or near-frontal collision. It will not activate in side or rear impacts.
- Some smoke (non-toxic gas) will be released when the air bags and pretensioners deploy. This does not indicate a fire. This gas normally has no effect on occupants, however, those with sensitive skin may experience light skin irritation. If residue from the deployment of the air bags or the front pretensioner system gets on the skin or in the eyes, wash it off as soon as possible.

### ▼ Air Bag/Front Seat Belt Pretensioner Systems Warning Light



If the air bag/front seat belt pretensioner system is OK, the warning light comes on when the ignition switch is turned to the ON position or after the engine is cranked. After about 6 seconds it goes out.

A system malfunction is indicated when the warning light constantly flashes, stays on or doesn't come on at all. If any of these occur, consult an Authorized Mazda Dealer as soon as possible. The system may not work in an accident.

### **WARNING**


#### **Self-Servicing the Air Bag/ Pretensioner Systems:**

***Self-servicing or tampering with the systems is dangerous. An air bag/pretensioner could accidentally activate or become disabled. This could cause serious injuries. Never tamper with the systems and always have an Authorized Mazda Dealer perform all servicing and repairs.***

## Seat Belt Systems


### Rear Center Position Seat Belt

Before using the rear-center lap/shoulder belt make sure tongue (A) and anchor buckle (B) are fastened.



#### ▼ Fastening the Seat Belt

1. Grasp the buckle (D) and tongue (C).
2. Slowly pull out the lap/shoulder belt.
3. Insert the tongue (C) into the buckle (D) until you hear a click.



### **WARNING**

#### **Fastening the Rear-Center Seat Belt with Only One Buckle:**

*Fastening the rear-center seat belt with only one buckle is dangerous. If only one pair of seat belt tongue and buckle, either tongue (A) and anchor buckle (B) or tongue (C) and anchor buckle (D), is fastened, the seat belt cannot provide full protection. In a sudden stop or collision, the user could slide under the belt and suffer serious injuries. Always make sure that both pairs of seat belt tongues and buckles are fastened properly.*

#### **Positioning the Shoulder Portion of the Seat Belt:**

*Improper positioning of the shoulder portion of the seat belt is dangerous. An improperly positioned belt will provide little or no protection in a collision. Always make sure the shoulder portion of the seat belt is positioned across your shoulder and near your neck, but never under your arm, on your neck, or on your upper arm.*

4. Make sure the shoulder belt is snugly fitted against your body.

# Seat Belt Systems


## ⚠ WARNING

### Positioning the Lap Portion of the Seat Belt:

*The lap portion of the seat belt worn too high is dangerous. In a collision, this would concentrate the impact force directly on the abdominal area, causing serious injury. Wear the lap portion of the belt snugly and as low as possible.*


### ▼ Unfastening the Seat Belt

Depress the button on the buckle.



### ▼ Unfastening the Lap Portion of the Seat Belt

Insert a small object in the anchor buckle (B) slot, such as a key.



## ⚠ CAUTION

Always unfasten the lap portion of the belt before folding the rear-left seatback. Leaving the lap portion of the belt fastened could cause damage to the seat belt, buckle and seatback.

### ▼ Fastening the Lap Portion of the Seat Belt

Grasp tongue (A) and insert it into the anchor buckle (B) until you hear a click. It is now secure for passenger use.

### NOTE

After returning the rear-left seatback to its upright position, fasten the lap portion of the belt.

## Seat Belt Systems

### Seat Belt Extender

If your seat belt is not long enough, even when fully extended, a seat belt extender may be available to you at no charge from your Authorized Mazda Dealer.

This extender will be only for you and for the particular vehicle and seat. Even if it plugs into other seat belts, it may not hold in the critical moment of a crash.

When ordering an extender, only order one that provides the necessary additional length to fasten the seat belt properly.

Please contact your Authorized Mazda Dealer for more information.

### **WARNING**

#### **Unnecessary Use of an Extender:**

*Using a seat belt extender when not necessary is dangerous. The seat belt will be too long and not fit properly. In an accident, the seat belt will not provide adequate protection and you could be seriously injured. Only use the extender when it is required to fasten the seat belt properly.*

#### **Using an Improper Extender:**

*Using a seat belt extender that is for another person or a different vehicle or seat is dangerous. The seat belt will not provide adequate protection and the user could be seriously injured in an accident. Only use the extender provided for you and for the particular vehicle and seat. NEVER use the extender in a different vehicle or seat.*

#### **Using an Extender That is Too Long:**

*Using an extender that is too long is dangerous. The seat belt will not fit properly. In an accident, the seat belt will not provide adequate protection and you could be seriously injured. Don't use the extender or choose one shorter in length if the distance between the extender's buckle and the center of the user's body is less than 15cm (6 in).*

## Seat Belt Systems

---

### Seat Belt Warning Light



If the driver's seat belt is not fastened when the ignition switch is turned to the ON position, the seat belt warning light will remain on until the belt is fastened. If the system does not operate correctly, consult an Authorized Mazda Dealer.

### Seat Belt Warning Beep

If the driver's seat belt is not fastened when the ignition switch is turned to the ON position, a beep will sound for about 6 seconds.

## Child Restraint

---

### Child Restraint Precautions

Mazda strongly urges the use of child-restraint systems for children small enough to use them.

You are required by law to use a child-restraint system for children in the U.S. and Canada. Check your local and state or provincial laws for specific requirements regarding the safety of children riding in your vehicle.

Whatever child-restraint system you consider, please pick the appropriate one for the age and size of the child, obey the law and follow the instructions that come with the individual child-restraint system.

A child who has outgrown child-restraint systems should sit in the rear and use seat belts, both lap and shoulder. If the shoulder belt crosses the neck or face, move the child closer to the center of the vehicle in the outboard seats, and towards the buckle on the right if the child is seated in the center seat.

Statistics confirm that the rear seat is the best place for all children up to 12 years of age—the more so with a supplemental restraint system (air bags).

A rear-facing child-restraint system should **NEVER** be used in the front seat because it would be too close to the air bag. The front passenger's seat is also the least preferred seat for other child-restraint systems.

## **WARNING**

### **Proper Size of Child-Restraint System:**

*For effective protection in vehicle accidents and sudden stops, a child must be properly restrained using a seat belt or child-restraint system depending on age and size. If not, the child could be seriously injured or even killed in an accident.*

### **Follow the Manufacturer's Instructions and Always Keep the Child-Restraint System Buckled Down:**

*An unsecured child-restraint system is dangerous. In a sudden stop or a collision it could move causing serious injury or death to the child or other occupants. Make sure the child-restraint system is properly secured in place according to the child-restraint system manufacturer's instructions. When not in use, remove it from the vehicle or fasten it with a seat belt, or latch it down to BOTH LATCH lower anchors.*


### **Holding a Child While the Vehicle is Moving:**

*Holding a child in your arms while the vehicle is moving is extremely dangerous. No matter how strong the person may be, he or she cannot hold onto a child in a sudden stop or collision and it could result in serious injury or death to the child or other occupants. Even in a moderate accident, the child may be exposed to air bag forces that could result in serious injury or death to the child, or the child may be slammed into the adult, injuring the adult. Always secure a child in a proper child-restraint system.*

### **Rear-Facing Child-Restraint System:**

*Rear-facing child-restraint systems on the front seat are particularly dangerous. The child-restraint system can be hit by a deploying air bag and moved violently backward resulting in serious injury or death to the child. NEVER use a rear-facing child-restraint system in the front seat with an air bag that could deploy.*

Deploying air bag



## Child Restraint

### **WARNING**

#### **Children and Seating Position with Side Air Bag:**

*Allowing anyone to lean over or against the front door is dangerous. If the vehicle is equipped with side air bags, the impact of an inflating side air bag could cause serious injury or death to the person. Children are more likely to sleep in the vehicle; when they do, they are more at risk in the front passenger's seat that has a side air bag because they may slump over into the path of the seatback-mounted air bag.*

*Furthermore, leaning over or against the doors could block the side air bag and eliminate the advantages of supplemental protection. With the front air bag and the additional side air bag that comes out of the front seat, the rear seat is always a better location for children who are prone to sleeping. If a child can't be seated in the rear, do not allow the child to lean over or against the front door, even if the child is seated in a child-restraint system.*

#### **One Belt, One Passenger:**

*Using one seat belt for more than one person at a time is dangerous. A seat belt used in this way can't spread the impact forces properly and the two passengers could be crushed together and seriously injured or even killed. Never use one belt for more than one person at a time.*

### **CAUTION**

A seat belt or child-restraint system can become very hot in a closed vehicle during warm weather. To avoid burning yourself or a child, check them before you or your child touches them.

### **NOTE**

Your Mazda is equipped with LATCH lower anchors for attachment of specially designed LATCH child-restraint systems in the rear seats. When using these anchors to secure a child-restraint system, refer to "LATCH Child-Restraint Systems" (page 2-31).

## Installing Child-Restraint Systems

Accident statistics reveal that a child is safer in the rear seat. The front passenger's seat is clearly the worst choice for any child under 12, and with rear-facing child-restraint systems it is clearly unsafe due to air bags.

Some child-restraint systems now come with tethers and therefore must be installed on the seats that take tethers to be effective. In your Mazda, tethered child-restraint systems can only be accommodated in the three positions on the rear seat.

Some child-restraint systems also employ specially designed LATCH attachments; refer to "LATCH Child-Restraint Systems" (page 2-31).

### **WARNING**

#### **Tethered Child-Restraint Systems Work Only on Rear Seat:**

*Installation of a tether equipped child-restraint system in the front passenger's seat defeats the safety design of the system and will result in an increased chance of serious injury if the child-restraint system goes forward without benefit of being tethered.*

*Place tether equipped child-restraint systems where there are tether anchors.*


## ▼ Rear Seat Child-Restraint System Installation

Follow these instructions when using a child-restraint system, unless you are attaching a LATCH-equipped child-restraint system to the rear LATCH lower anchors. Refer to "LATCH Child-Restraint Systems" (page 2-31).

### **NOTE**


Follow the child-restraint system manufacturer's instructions carefully. If you are not sure whether you have a LATCH system or tether, check in the child-restraint system manufacturer's instructions and follow them accordingly. Depending on the type of child-restraint system, it may not employ seat belts which are in automatic locking mode.

1. Secure the child-restraint system with the lap portion of the lap/shoulder belt. See the instructions on the child-restraint system for belt routing instructions.
2. To get the retractor into the automatic locking mode, pull the shoulder belt portion of the seat belt until the entire length of the belt is out of the retractor.



# Child Restraint




3. Push the child-restraint system firmly into the vehicle seat. Be sure the belt retracts as snugly as possible. Clicking from the retractor will be heard during retraction if the system is in the automatic locking mode. If the belt does not lock the seat down tight, repeat this step.



## NOTE


Inspect this function before each use of the child-restraint system. You should not be able to pull the shoulder belt out of the retractor while the system is in the automatic locking mode. When you remove the child-restraint system, be sure the belt fully retracts to return the system to emergency locking mode before occupants use the seat belts.

4. If your child-restraint system requires the use of a tether strap, hook and tighten the tether strap by following the manufacturer's instructions.




# Child Restraint


**Hatchback  
(Outboard position)**



**Hatchback  
(Center position)**



**Hatchback  
(Center position)**



## **⚠ WARNING**

### **Child-Restraint Tether Usage:**

*Using the tether to secure anything but a child-restraint system is dangerous. This could weaken or damage the tether or tether anchor and result in injury. Use the tether and tether anchor only for a child-restraint system.*

### **Incorrect Positioning of the Tether Strap (Hatchback):**

*Positioning the tether strap on top of the head restraint is dangerous. In a collision, the head restraint could bend or break. This will cause the strap to loosen. The child-restraint system could move and injure the child or someone else. Always position the tether strap between the head restraint and the seatback.*

# Child Restraint

## ▼ If You Must Use the Front Seat for Children

If you cannot put all children in the rear seat, at least put the smallest in the rear and be sure the largest child up front uses the shoulder belt over the shoulder. Do not put rear-facing child-restraint systems on the front passenger's seat. This seat is also not set up for tethered child-restraint systems, put them in one of the three rear seat positions set up with tether anchors. Don't allow anyone to sleep against the right front door if you have an optional side air bag, it could cause serious injuries to an out of position occupant. As children more often sleep in cars, it is better to put them in the rear seat. If installing the child-restraint system on the front seat is unavoidable, follow these instructions when using a front-facing child-restraint system in the front passenger's seat.

### NOTE

To check if your Mazda front seats have side air bags:  
Every Mazda side air bag will have a "SRS-Air Bag" label on the outboard shoulder of the front seats.

## WARNING

**Front Passenger's Seat Position:**  
*As your vehicle has front air bags and doubly so because your vehicle has side air bags, a front-facing child-restraint system should be put on the front seat only when it is unavoidable. Always move the seat as far back as possible, because the force of a deploying air bag could cause serious injury or death to the child.*

**Rear-Facing Child-Restraint System:**  
*Rear-facing child-restraint systems on the front seat are particularly dangerous. The child-restraint system can be hit by a deploying air bag and moved violently backward resulting in serious injury or death to the child. NEVER use a rear-facing child-restraint system in the front seat with an air bag that could deploy.*

# Child Restraint


## ! WARNING

### Children and Seating Position with Side Air Bag:

*Allowing anyone to lean over or against the front door is dangerous. If the vehicle is equipped with side air bags, the impact of an inflating side air bag could cause serious injury or death to the person. Children are more likely to sleep in the vehicle; when they do, they are more at risk in the front passenger's seat that has a side air bag because they may slump over into the path of the seatback-mounted air bag. Furthermore, leaning over or against the doors could block the side air bag and eliminate the advantages of supplemental protection. With the front air bag and the additional side air bag that comes out of the front seat, the rear seat is always a better location for children who are prone to sleeping. If a child can't be seated in the rear, do not allow the child to lean over or against the front door, even if the child is seated in a child-restraint system.*

## ▼ Front Passenger's Seat Child-Restraint System Installation

1. Slide the seat as far back as possible.



2. Secure the child-restraint system with the lap portion of the lap/shoulder belt. See the instructions on the child-restraint system for belt routing instructions.
3. To get the retractor into the automatic locking mode, pull the shoulder belt portion of the seat belt until the entire length of the belt is out of the retractor.
4. Push the child-restraint system firmly into the vehicle seat. Be sure the belt retracts as snugly as possible. Clicking from the retractor will be heard during retraction if the system is in automatic locking mode. If the belt does not lock the seat down tight, repeat this step.

# Child Restraint

---

**NOTE**

- Inspect this function before each use of the child-restraint system. You should not be able to pull the shoulder belt out of the retractor while the system is in the automatic locking mode. When you remove the child-restraint system, be sure the belt fully retracts to return the system to emergency locking mode before occupants use the seat belts.
- Follow the child-restraint system manufacturer’s instruction carefully. Depending on the type of child-restraint system, it may not employ seat belts which are in automatic locking mode.

## **LATCH Child-Restraint Systems**

Your Mazda is equipped with LATCH lower anchors for attachment of specially designed LATCH child-restraint systems in the rear seat. Both anchors must be used, otherwise the seat will bounce around and put the child in danger. Some LATCH child-restraint systems must also be used in conjunction with a tether to be effective. If they have a tether you must use it to better assure your child's safety.

### **WARNING**

#### **Manufacturer's Instructions for Child-Restraint System:**

*An unsecured child-restraint system is dangerous. In a sudden stop or a collision it could move causing serious injury or death to the child or other occupants. Make sure the child-restraint system is properly secured in place according to the child-restraint system manufacturer's instructions.*

#### **Attaching Two Child-Restraint Systems to the Same LATCH Lower Anchor:**

*Attaching two child-restraint systems to the same LATCH lower anchor is dangerous. In a collision, one anchor may not be strong enough to hold two child-restraint system attachments and may break, causing serious injury or death. If you use the seat position for another child-restraint system when an outboard LATCH position is occupied, use the center seat belts instead, and the tether if tether-equipped.*

#### **Unsecured Child-Restraint System:**

*An unsecured child-restraint system is dangerous. In a sudden stop or a collision it could move causing serious injury or death to the child or other occupants. Follow the child-restraint system manufacturer's instructions on belt routing to secure the seat just as you would with a child in it so that nobody is tempted to put a child in an improperly secured seat later on. When not in use, remove it from the vehicle or fasten it with a seat belt, or latch it down to **BOTH** LATCH lower anchors.*


#### **LATCH Child-Restraint Systems:**

*Not following the child-restraint system manufacturer's instructions when installing the child-restraint system is dangerous. If seat belts or a foreign object prevent the child-restraint system from being securely attached to the LATCH lower anchors and the child-restraint system is installed improperly, the child-restraint system could move in a sudden stop or collision causing serious injury or death to the child or other occupants. When installing the child-restraint system, make sure there are no seat belts or foreign objects near or around the LATCH lower anchors. Always follow the child-restraint system manufacturer's instructions.*

# Child Restraint

## ▼ Child-Restraint System Installation Procedure (Rear Outboard Seats)

1. Expand the area between the seat bottom and the seatback slightly to verify the locations of the LATCH lower anchors.






### NOTE

The markings above the LATCH lower anchors indicate the locations of LATCH lower anchors for the attachment of a child-restraint system.


2. Secure the child-restraint system using BOTH LATCH lower anchors, following the child-restraint system manufacturer's instruction.

3. If your child-restraint system came equipped with a tether, that probably means it is very important to properly secure the tether for child safety, please carefully follow the child-restraint system manufacturer's instructions when installing tethers.



# Child Restraint

## Hatchback (Outboard position)



### **WARNING**

#### **Child-Restraint Tether Usage:**

*Using the tether to secure anything but a child-restraint system is dangerous. This could weaken or damage the tether or tether anchor and result in injury. Use the tether and tether anchor only for a child-restraint system.*

#### **Incorrect Positioning of the Tether Strap (Hatchback):**


*Positioning the tether strap on top of the head restraint is dangerous. In a collision, the head restraint could bend or break. This will cause the strap to loosen. The child-restraint system could move and injure the child or someone else. Always position the tether strap between the head restraint and the seatback.*

## ▼ Child-Restraint System Installation Procedure (Rear Center Seat)

The LATCH lower anchors at the center of the rear seat are much further apart than the sets of LATCH lower anchors for child-restraint system installation at other seating positions. Child-restraint systems with rigid LATCH attachments cannot be installed on the center seating position. Some LATCH equipped child-restraint systems can be placed in the center position and will reach the nearest LATCH lower anchors which are 400 mm (15.75 in) apart. LATCH compatible child-restraint systems (with attachments on belt webbing) can be used at this seating position only if the child-restraint system instructions state that the child-restraint system can be installed to LATCH lower anchors that are 400 mm (15.75 in) apart. Do not attach two child-restraint systems to the same LATCH lower anchor. If any child-restraint system has a tether, it must be used also for your child's optimum safety.

# Child Restraint

- 1. Expand the area between the seat bottom and the seatback slightly to verify the locations of the LATCH lower anchors.




**NOTE**

The markings above the LATCH lower anchors indicate the locations of LATCH lower anchors for the attachment of a child-restraint system.


- 2. Secure the child-restraint system using BOTH LATCH lower anchors, following the child-restraint system manufacturer's instructions.

- 3. If your child-restraint system came equipped with a tether, that probably means it is very important to properly secure the tether for child safety, please carefully follow the child-restraint system manufacturer's instructions when installing tethers.


**Sedan**




**Sedan**



**Hatchback  
(Center position)**



Hatchback  
(Center position)



**⚠ WARNING**

**Child-Restraint Tether Usage:**  
*Using the tether to secure anything but a child-restraint system is dangerous. This could weaken or damage the tether or tether anchor and result in injury. Use the tether and tether anchor only for a child-restraint system.*

## SRS Air Bags

---

### Supplemental Restraint Systems (SRS) Precautions

Read this owner's manual carefully to verify what air bags (driver-side air bag, passenger-side air bag, side air bags) are equipped in your vehicle.

The front and side supplemental restraint systems (SRS) include 4 air bags (verify "SRS AIR BAG" location indicator marks).

They are located in:

- The steering wheel hub
- The passenger side dashboard
- The outboard sides of the front seatbacks

These systems operate independently depending on the type of accident encountered; if you have side air bags, the side air bags are not likely to deploy on both sides in the same accident because a vehicle is not often hit from both sides. The side air bags work together but they and the frontal air bag system will not normally deploy during the same type of accident unless a combination of frontal and side impacts occur.

The air bag supplemental restraint systems are designed to provide only supplemental protection only in the front seats in a few modes, so seat belts become important in the following ways:

Without seat belt usage, the air bags cannot provide adequate protection during an accident. Seat belt usage is necessary to:

- Keep the passenger away from an inflating air bag.
- Reduce the possibility of injuries during an accident that is not designed for air bag inflation, such as roll-over or rear impact.
- Reduce the possibility of injuries in frontal or side collisions that are not severe enough to activate the air bags.
- Reduce the possibility of being thrown from your vehicle.
- Reduce the possibility of injuries to lower body and legs during an accident because the air bags provide no protection to these parts.
- Hold the driver in a position which allows better control of the vehicle.

Small children, those under 18 kg (40 lb), should be protected by a child-restraint system (page 2-22).

Carefully consider which child-restraint system is necessary for your child and follow the installation directions in this Owner's Manual as well as the child-restraint system manufacturer's instructions.

## **WARNING**

### **Air Bags without Seat Belts:**

*Depending only on the air bags for protection during an accident is dangerous. Alone, air bags may not prevent serious injuries. The appropriate air bags can be expected to inflate only in collisions with frontal, near frontal or side forces that are at least moderate. Vehicle occupants should always wear seat belts.*


### **Child in the Front Seat:**

*Placing a child, 12 years or under, in the front seat is dangerous. The child could be hit by a deploying air bag and be seriously injured or even killed. A sleeping child is more likely to lean against the door and be hit by the side air bag in a moderate, right-side collision. Whenever possible, always secure a child 12 years and under on the rear seat with an appropriate child-restraint system for the child's age and size.*

### **Rear-Facing Child-Restraint System:**

*Rear-facing child-restraint systems on the front seat are particularly dangerous. The child-restraint system can be hit by a deploying air bag and moved violently backward resulting in serious injury or death to the child. NEVER use a rear-facing child-restraint system in the front seat with an air bag that could deploy.*

Deploying air bag



### **Seating Position with Front Air Bags:**

*Sitting too close to the air bag storage compartments or placing hands or feet on them is extremely dangerous. Front Air bags inflate with great force and speed. Serious injuries could occur if someone is too close. The driver should always hold onto only the rim of the steering wheel. The front seat passenger should keep both feet on the floor. Front seat occupants should adjust their seats as far back as possible and always sit upright against the seatbacks with seat belts worn properly.*

## SRS Air Bags

---

### **WARNING**

#### **Seating Position with Side Air Bags:**

*Sitting too close to the side air bag storage compartments or placing hands on them is extremely dangerous. A side air bag inflates with great force and speed directly out of the outboard shoulder of the front seat and expands along the front door on the side the car is hit.*

*Serious injury could occur if someone is sitting too close to the door or leaning against a window in the front seats or if rear seat occupants grab the sides of the front seatbacks. Furthermore, sleeping up against the door or hanging out the driver's-side window while driving could block the side air bag and eliminate the advantages of supplemental protection. Give the side airbags room to work by sitting in the center of the seat while the vehicle is moving with seat belts worn properly.*

#### **Front Air Bag Storage Areas:**

*Attaching an object to a front air bag storage area or placing something in front of it is dangerous. In an accident, the object could interfere with front air bag inflation and injure the occupants.*

*Always keep the front air bag storage areas free of objects.*

#### **Side Air Bag Storage Areas:**

*Attaching things to the front seat in such a way as to cover the outboard side of the seat in any way is dangerous. In an accident the object could interfere with the side air bag, which inflates from the outboard side of the front seats, impeding the added protection of the side air bag system or redirecting the air bag in a way that is dangerous. Furthermore, the bag could be cut open spewing exhaust.*

*Do not hang net bags, map pouches or back pads with side straps on the front seats. Never use seat covers on the front seats. Always keep the side air bag storage areas in your front seats free to deploy in the event of a side collision.*

#### **Hot Air Bag Inflators:**

*Hot air bag inflators are dangerous. Immediately after inflation, the inflators in the steering wheel, dashboard or the seatbacks are very hot. You could get burned. Don't touch the internal components of the air bag storage areas after the bags have inflated.*

 **WARNING****Installation of Front-End Equipment:**

*Installation of front-end equipment, such as frontal protection bar (kangaroo bar, bull bar, push bar, etc.), snowplow, or winches, is dangerous. The air bag crash sensor system could be affected. This could cause air bags to inflate unexpectedly, or it could prevent the air bags from inflating during an accident. Front occupants could be seriously injured. Never install any front-end equipment to your vehicle.*

**Suspension Adjustment:**

*Adjusting the vehicle suspension is dangerous. If the vehicle's height or the suspension is changed, the vehicle will be unable to accurately detect a collision resulting in incorrect or unexpected air bag deployment and the possibility of serious injuries.*

**Modification of the Supplemental Restraint System:**

*Modifying the components or wiring of the supplemental restraint system is dangerous. You could accidentally activate it or make it inoperable. Don't make any modifications to the supplemental restraint system. This includes installing trim, badges, or anything else over the air bag storage areas. It also includes installing extra electric equipment on or near system components or wiring. An Authorized Mazda Dealer can provide the special care needed in the removal and installation of front seats. It is important to protect the side air bag wiring and connections to assure that the bags do not accidentally deploy and that the seats retain an undamaged air bag connection.*

 **CAUTION**

To prevent damage to the side air bag wiring, don't place luggage or other objects under the front seats.

**NOTE**

- When an air bag deploys, a loud inflation noise can be heard and some smoke will be released. Neither is likely to cause injury, however, the texture of the air bags may cause light skin injuries on body parts not covered with clothing through friction.
- Should you sell your Mazda, we urge you to tell the new owner of its air bag systems and that familiarization with all instructions about them, from the Owner's Manual, is important.


## SRS Air Bags

### Air Bag System Description

The supplemental restraint systems (SRS) have two basic subsystems:

- The air bag system with inflators and air bags.
- The electric system with crash sensors and diagnostic module.

The air bags are mounted in the following locations: the center of the steering wheel, the passenger-side of the dashboard, and in the outboard sides of the front seatbacks. They are out of sight until activated.




### ▼ How the Air Bags Work

When air bag crash sensors detect a frontal or side impact of greater than moderate force, an electrical current is sent to the inflators.

Gases are produced to inflate the air bags and after the inflation, the air bags quickly deflate.

The air bags will function only once. After that, **the air bags will not work again and must be replaced.**

Only an Authorized Mazda Dealer can replace the systems.




## ▼ Air Bag Activation/Deactivation


### Front air bag activation

A greater than moderate impact will cause the front air bags to inflate in the following cases:


Hitting a solid wall straight on at greater than about 22 km/h (14 mph).




Frontal impact within about a 30 degree range from head-on to the vehicle.




Hitting a curb, pavement edge or hard object.



Driving into a big hole or hitting the far side of a hole.



Landing hard or the vehicle falling.




# SRS Air Bags


## Limitations to front air bag activation

Depending on the severity of impact, the front air bags may not inflate in the following cases:


Impacts involving trees or poles cause severe cosmetic damage but may not have enough impact to activate the air bag.



Frontal offset impact to the vehicle may not provide the stopping force necessary for air bag deployment.




Rear-ending or running under a truck's tail gate may not provide the stopping force necessary for air bag deployment.




## Non-activation of front air bags

Front air bags will not normally inflate in the following cases:


Collision from the rear.



Impact to the side, but it may deploy a side air bag.




Vehicle roll-over, may deploy the side air bag(s) but not the front air bags.




**Side air bag activation**

Greater than moderate impact to one side of the vehicle (driver or passenger side areas) will cause a side air bag to inflate, but it will not normally deploy the front air bags.


**Limitations to side air bag activation**

Depending on the severity of impact, a side air bag may not inflate in the following cases:


Frontal offset impact may not provide enough side impact to deploy a side air bag.



Side impacts involving trees or poles can cause severe cosmetic damage but may not have enough impact force to activate a side air bag.



Vehicle roll-over may not provide enough side force to deploy the side air bags.



Side impacts with two-wheeled vehicles may not provide enough force to deploy a side air bag.




# SRS Air Bags

---


## Non-activation of side air bag

A side air bag will not normally inflate in the following cases:

Collision from the rear.



Collision from the front, but it may deploy the front air bags.



**▼ Constant Monitoring**

The following components of the air bag systems are monitored by a diagnostic system:

- SAS unit
- Air bag modules
- Side air bag crash sensor
- Front seat belt pretensioners
- Related wiring

A diagnostic module continuously monitors the systems' readiness. This begins when the ignition switch is turned to the ON position and continues while the vehicle is being driven.

**▼ Air Bag/Front Seat Belt Pretensioner Systems Warning Light**

If the air bag/front seat belt pretensioner system is OK, the warning light comes on when the ignition switch is turned to the ON position or after the engine is cranked. After about 6 seconds it goes out.

A system malfunction is indicated when the warning light constantly flashes, stays on or doesn't come on at all. If any of these occur, consult an Authorized Mazda Dealer as soon as possible. The system may not work in an accident.

**⚠ WARNING****Self-Servicing the Air Bag/  
Pretensioner Systems:**

*Self-servicing or tampering with the systems is dangerous. An air bag/pretensioner could accidentally activate or become disabled. This could cause serious injuries. Never tamper with the systems and always have an Authorized Mazda Dealer perform all servicing and repairs.*

**▼ Maintenance**

The air bag systems do not require regular maintenance. But if any of the following occurs, take your vehicle to an Authorized Mazda Dealer as soon as possible:

- The air bag system warning light flashes.
- The air bag system warning light stays on.
- The air bag system warning light stays off when the ignition switch is turned to the ON position.
- The air bags inflate.

## SRS Air Bags

---

### **WARNING**

#### **Damaged Air Bag Sensors:**

*Driving with damaged air bag sensors is dangerous. A collision, even one not strong enough to inflate the air bags, could damage the sensors. If there was a subsequent collision, a damaged sensor would not inflate the air bags. Always have an Authorized Mazda Dealer inspect the air bag systems after a collision.*

#### **Removing Interior Parts:**

*Removing any components such as the front seat, front dashboard, the steering wheel or parts containing air bag parts or sensors is dangerous. These parts contain essential air bag parts. The air bag could accidentally activate and cause serious injuries. Always have an Authorized Mazda Dealer remove these parts.*

#### **Air Bag Disposal:**

*Improper disposal of an air bag or a vehicle with live air bags in it can be extremely dangerous. Unless all safety procedures are followed, injury can result. Ask an Authorized Mazda Dealer how to safely dispose of an air bag or how to scrap an air bag equipped vehicle.*

Explanation of basic operations and controls; opening/closing and adjustment of various parts.

|                                             |          |
|---------------------------------------------|----------|
| <b>Doors and Locks</b> .....                | 3-2      |
| Keys .....                                  | 3-2      |
| Keyless Entry System .....                  | 3-2      |
| Door Locks .....                            | 3-6      |
| Liftgate (Hatchback) .....                  | 3-9      |
| Trunk Lid (Sedan) .....                     | 3-11     |
| Trunk Release Handle (Sedan) .....          | 3-12     |
| Power Windows .....                         | 3-14     |
| Fuel-Filler Lid and Cap .....               | 3-16     |
| Hood .....                                  | 3-18     |
| Sunroof .....                               | 3-19     |
| Roof Rack .....                             | 3-21     |
| <br><b>Steering Wheel and Mirrors</b> ..... | <br>3-23 |
| Steering Wheel .....                        | 3-23     |
| Mirrors .....                               | 3-23     |

# Doors and Locks


## Keys

### **WARNING**

**Keys and Children:**

*Leaving children in a vehicle with the ignition key is dangerous. This could result in someone being badly injured or even killed. They could play with power windows or other controls, or even make the vehicle move. Don't leave the keys in your vehicle with children.*

The keys operate all locks.



 — Key code number plate

A code number is stamped on the plate attached to the key set; detach this plate and store it in a safe place (not in the vehicle) for use if you need to make a replacement key.

Also write down the code number and keep it in another safe and handy place, but not in the vehicle.

If your key is lost, consult your Authorized Mazda Dealer with the code number ready.

## Keyless Entry System

This system locks and unlocks the doors and the liftgate.

It can also help you signal for attention in an emergency.

Press the button slowly and accurately.

### **CAUTION**

To avoid damage to the transmitter, do not:


- Drop it.
- Get it wet.
- Disassemble it.
- Expose it to heat or sunlight.

## Doors and Locks

### NOTE

- The keyless entry system is designed to operate up to about 2.5 m (8 ft) from the center of the vehicle, but this may vary because of local conditions.
- The system doesn't operate when the ignition switch is in the ON position.
- If the transmitter does not operate when pressing a button or the operation range becomes too small, the battery may be dead. To install a new battery, refer to Maintenance (page 3-4).
- Additional transmitters can be obtained at an Authorized Mazda Dealer. Up to 3 transmitters can be used with the keyless entry system per vehicle. Bring all transmitters to an Authorized Mazda Dealer when the electronic codes need to be reset.

### ▼ Transmitter



### NOTE

This device complies with part 15 of the FCC Rules and with RSS-210 of Industry Canada. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. (Outside transmissions may momentarily interfere with the device's operation.)

### Lock button

To lock the doors and the liftgate, press the LOCK button and the hazard warning lights will flash once.

To confirm that all the doors and the liftgate have been locked, press the LOCK button again within 5 seconds. If they are closed and locked, the horn will sound and the hazard warning lights will flash once.

### NOTE

Confirm that all the doors and the liftgate are locked visually or aurally by use of the double click.

# Doors and Locks

## Unlock button

To unlock the driver’s door, press the UNLOCK button and the hazard warning lights will flash twice.

To unlock all the doors and the liftgate, press the UNLOCK button again within 5 seconds and the hazard warning lights will flash twice.

|                                                                                                                                                                     |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>NOTE</b>                                                                                                                                                         |
| After unlocking with the transmitter, all doors and the liftgate will automatically lock if one of the doors or the liftgate is not opened within about 30 seconds. |

## !Panic button

You can use the ! button to turn on the alarm, which allows you to signal for attention in an emergency.

|                                                                         |
|-------------------------------------------------------------------------|
| <b>NOTE</b>                                                             |
| The alarm will work whether any door or the liftgate is open or closed. |

## Turning on the alarm

Pressing the ! button once will trigger the alarm for about 2 minutes and 30 seconds, and do the following:

- The horn sounds intermittently.
- The hazard warning lights flash.

## Turning off the alarm

Press any button on the transmitter.


|                                                                                                             |
|-------------------------------------------------------------------------------------------------------------|
| <b>NOTE</b>                                                                                                 |
| If the LOCK and UNLOCK button are pressed sequentially, the hazard warning flasher may not flash correctly. |

## ▼ Transmitter Maintenance


|                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <b>CAUTION</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| <ul style="list-style-type: none"><li>• Make sure the battery is installed with the correct pole facing upward. Battery leakage could occur if it is not installed correctly.</li><li>• When replacing the battery, be careful not to bend the electrical terminals or get oil on them. Also be careful not to get dirt in the transmitter as it could damage it.</li><li>• Danger of explosion if battery is incorrectly replaced.</li><li>• Replace only with the same type battery (CR2025 or the equivalent).</li><li>• Dispose of used batteries according to the following instructions.<ul style="list-style-type: none"><li>• Insulate the plus and minus terminals of the battery using cellophane or equivalent tape.</li><li>• Never disassemble.</li><li>• Never throw the battery into fire and/or water.</li><li>• Never deform or crush.</li></ul></li></ul> |

## **Replacing the transmitter battery**


1. Insert a small screwdriver into the slot and gently pry open the transmitter.



2. Press the portion of the battery indicated by A and remove the battery.



3. Install a new battery (CR2025 or the equivalent) into the front portion of the holder with the positive pole (+) facing up. Press on the B portion of the battery to set the battery.



## **⚠ CAUTION**

Do not press any buttons when replacing the battery. The electronic code could be altered and cause the keyless entry system to malfunction. If the keyless entry system fails to operate, contact an Authorized Mazda Dealer.

4. Align the front and back covers and snap the transmitter shut.

# Doors and Locks

## ▼ Service

If you have a problem with the keyless entry system, consult an Authorized Mazda Dealer.

If your transmitter is lost or stolen, bring all remaining transmitters to an Authorized Mazda Dealer as soon as possible for a replacement and to make the lost or stolen transmitter inoperative.

### CAUTION

- Changes or modifications could void your right to operate the keyless entry system.
- Damage to your keyless entry system will affect the vehicle warranty coverage.

## Door Locks

### WARNING

**Unattended Children and Pets:**  
*Leaving a child or an animal unattended in a parked vehicle is dangerous. In hot weather, temperatures inside a vehicle can become high enough to cause brain damage or even death. Always take all children and animals with you or leave a responsible person with them.*

**Keys and Children:**  
*Leaving children in a vehicle with the ignition key is dangerous. This could result in someone being badly injured or even killed. They could play with power windows or other controls, or even make the vehicle move. Don't leave the keys in your vehicle with children.*


**Unlocked Doors:**  
*Unlocked doors in a moving vehicle are dangerous. Passengers can fall out if a door is accidentally opened and can more easily be thrown out in an accident. So keep all doors locked when driving.*

### NOTE

Always remove the key from the ignition switch, close all windows, and lock all doors when leaving your vehicle unattended. This discourages intruders and thieves.

### ▼ Locking, Unlocking with Key

Either front door can be locked or unlocked with a key.  
Turn the key toward the front to unlock,  
toward the back to lock.




### ▼ Locking, Unlocking with Transmitter


The doors can be locked/unlocked by operating the keyless entry system transmitter, refer to keyless entry system (page 3-2).

### ▼ Locking, Unlocking with Door-Lock Button

To lock any door from the inside, push down its door-lock button.  
To unlock, pull it up.



To lock any door with the door-lock button from the outside, push down its door-lock button and close the door.



#### NOTE


When locking the doors this way, be careful not to leave the key inside the vehicle.

## Doors and Locks

### ▼ Power Door Locks

#### Locking, unlocking with key

All doors and the liftgate lock automatically when any door is locked with a key. All doors and the liftgate unlock when the driver's door is unlocked and the key is held in the unlock position a second longer. Also, all doors and the liftgate unlock when the passenger's door is unlocked.




#### NOTE

Holding the key in the unlocked position in the driver's door lock for about a second unlocks all doors and the liftgate. To unlock only the driver's door, insert a key into the driver's door lock and turn the key briefly to the unlock position and then immediately return it to the center position.

#### Locking, unlocking with door-lock switch


All doors and the liftgate lock automatically when LOCK is pushed. They all unlock when the unmarked part of the door-lock switch is pushed.



### ▼ Rear Door Child Safety Locks

These locks are intended to help prevent children from accidentally opening the rear doors. Use them both whenever a child rides in the vehicle.

If you slide the child safety lock to the lock position before closing that door, the door cannot be opened from the inside. The door can be opened only by lifting the outside handle.



## Liftgate (Hatchback)


### **WARNING**

#### Open Liftgate:

*An open liftgate in a moving vehicle will cause exhaust gas to be drawn into the cabin. This gas contains CO (carbon monoxide), which is colorless, odorless, and highly poisonous, and it can cause loss of consciousness and death. Moreover, an open liftgate could cause occupants to fall out in accident. Do not drive with the liftgate open.*

### ▼ Locking, Unlocking with Key

To lock the liftgate with the key, insert the key and turn it counterclockwise.



To unlock the liftgate with the key, insert the key and turn it clockwise.

The liftgate can be locked/unlocked by inserting the key into the key slot of any door, refer to Power Door Locks (page 3-8).

### ▼ Locking, Unlocking with Transmitter


The liftgate can be locked/unlocked by operating the keyless entry system transmitter, refer to Keyless Entry System (page 3-2).

### ▼ Locking, Unlocking with Door-Lock Switch

The liftgate can be locked/unlocked by operating the door-lock switch, refer to Power Door Locks (page 3-8).

### ▼ Opening and Closing the Liftgate

To open the liftgate, pull up on the handle.



To close, use both hands to push the liftgate down until the lock snaps shut. Do not slam it. Pull up on the liftgate to make sure it is secure.

## Doors and Locks

### ▼ Luggage Compartment


#### **WARNING**

##### Placing Cargo on the Cover:

*Placing luggage or other cargo on top of the luggage compartment cover is dangerous. During sudden braking or a collision, the cargo could become a projectile that could hit and injure someone. Don't place anything on top of the cover.*


#### Luggage strap

The luggage compartment can be accessed by opening the liftgate when the straps are attached to the sides of the liftgate.



#### Luggage compartment cover

This cover can be removed for more room. To do this, just unfasten the straps; then lift and pull it out.




#### Luggage compartment cover hook

#### **CAUTION**

Remove luggage or other cargo from the trunk mat before lifting the mat to avoid damaging the trunk mat or the luggage compartment cover.

Use the hook under the luggage compartment cover to temporarily hold the trunk mat.



# Doors and Locks

## Trunk Lid (Sedan)


### **WARNING**

**Open Trunk and Exhaust Gas:**  
Exhaust gas in the cabin of a vehicle is dangerous. This gas contains CO (carbon monoxide), which is colorless, odorless, and highly poisonous. If inhaled, it can cause loss of consciousness and death. Because exhaust gas can get into the cabin through an open trunk, keep the trunk closed when driving.

### ▼ Opening and Closing the Trunk


#### **Opening the trunk lid with the key**

Insert the key into the slot and turn it clockwise.



#### **Opening the trunk lid with the remote release lever**

Pull up the release lever next to the driver's seat.



#### **Closing the trunk lid**

Use both hands to push the trunk lid down until the lock snaps shut. Do not slam it. Pull up on the trunk lid to make sure it is secure.

### ▼ Trunk Security


In some situations you may want to prevent the trunk from being opened with the remote trunk lid release lever.

Give your key only to someone you trust.

To secure the trunk lid, lock the rear seatbacks (page 2-6) , push the trunk lock lever up, and close the trunk.


# Doors and Locks

To cancel the security feature, insert the key into the lock, turn the key clockwise, and push the trunk lock lever down.



## ▼ Trunk Light

The trunk light is on when the lid is open and off when it's closed.



### NOTE

To prevent the battery from being discharged, do not leave the trunk open for a long period when the engine is not running.

## Trunk Release Handle (Sedan)

Your vehicle is equipped with a trunk release handle that provides a means of escape for children and adults in the event they become locked inside the trunk.

No matter how careful adults might be with keys and locking their cars, parents should be aware that children may be tempted to play around vehicles and use the trunk as a hiding place.

Adults are advised to familiarize themselves with the operation and location of the release handle so that all children can be told about it in an appropriate way, keeping in mind that most vehicles don't have such handles.

## ! WARNING

### **Open Trunk Lid and Children:**

*Leaving the trunk lid open or leaving children in the vehicle with the keys is dangerous. Children could open the trunk lid and climb inside resulting in possible injury or death from heat exposure. Close the trunk lid, lock the rear seatbacks and do not allow children to play inside the vehicle.*


### **Unattended Children and Pets:**

*Leaving children or animals unattended in a parked vehicle is dangerous. Babies left sleeping and kids who lock themselves in cars or trunks can die very quickly from heat prostration. Don't leave your children or pets alone in a car at any time. Don't leave the car, the rear folding seats or the trunk unlocked. Always keep the car from being a tempting place to play by locking rear seats, doors and the trunk, and keeping the keys where children won't play with them.*

## ▼ Opening the Trunk Lid from the Inside

Pull the illuminated "T" shaped handle. The handle is made of material that will glow for hours in the darkness of the trunk following a brief exposure to ambient light.


The "T" shaped handle is located on the inside of the trunk lid.



## Doors and Locks

### ⚠ CAUTION

Always keep the handle firmly attached to the holder and in the recessed position. Not securing the handle this way could allow it to snag luggage in the trunk and open the trunk lid.



## Power Windows

The ignition switch must be in the ON position for the power windows to operate.

### ⚠ WARNING

**Closing Power Windows:**  
*Closing power windows are dangerous. A person's hands, head, or even neck could be caught by the window and result in serious injury or even death.*  
*This warning applies especially to children. Make sure the opening is clear before closing a window.*


### ⚠ CAUTION

To prevent burning out the fuse and damaging the power window system, don't open or close more than two windows at once.

### ▼ Operating the Driver's Side Power Window

To open the window, push down the switch.

To close the window, pull up the switch.



## Doors and Locks

### **Auto-opening**


To fully open the window automatically, push the switch completely down.

To stop the window partway, pull up the switch and then release it.

### **▼ Operating the Passenger Power Windows**

The power windows may be operated when the power window lock switch is in the unlock position.


The passenger windows may be opened or closed by the power window master control switches on the driver's door.



### **Front passenger-side power window**

To open the window, push down the switch.


To close the window, pull up the switch.



### **Rear power windows**

To open a window, push the lower part of the switch.

To close, push the upper part of the switch.




## Doors and Locks

### ▼ Power Window Lock Switch

With the lock switch in the unlocked position, all power windows on each door can be operated.

With the lock switch in the locked position, only the driver's side power window can be operated.



### **⚠ WARNING**

**Unintentional Window Operation:**  
*Unintentional window operation is dangerous. A person's hands, head, or neck could be caught by the window and result in serious injury. Unless a passenger needs to operate a window, keep the power window lock switch in the locked position.*

## Fuel-Filler Lid and Cap

### **⚠ WARNING**

#### **Fuel Spray:**

*Fuel spray is dangerous. Fuel can burn skin and eyes and cause illness when ingested. Fuel spray is released when there is pressure in the fuel tank and the fuel cap is removed too quickly. When removing the fuel cap, loosen the cap slightly and wait for any hissing to stop. Then remove it.*

#### **Fuel Vapor:**



*Fuel vapor is dangerous. It could be ignited by sparks or flames causing serious burns and injuries. Before refueling, stop the engine, and always keep sparks and flames away from the filler neck.*

### **⚠ CAUTION**

Always use only a genuine Mazda fuel cap or an approved equivalent, available at Authorized Mazda Dealers. The wrong cap can result in a serious malfunction of the fuel and emission control systems. It may also cause the check engine light in the instrument cluster to illuminate.


**▼ Fuel-Filler Lid**

To open, pull up the remote fuel-filler lid release.

**▼ Fuel-Filler Cap**

To remove the filler cap, turn it counterclockwise.

To replace the filler cap, turn it clockwise until it clicks.

**⚠ CAUTION**


Make sure the fuel-filler cap is tightened securely. The check engine light comes on when the cap isn't tightened securely. If the light remains on (even after you have tightened the cap securely, driven, and restarted the engine several times), it may indicate a different problem. Contact an Authorized Mazda Dealer as soon as possible.

## Doors and Locks


### Hood

#### ▼ Opening the Hood


1. With the vehicle parked, pull the release handle to unlock the hood.



2. Pull the safety catch up and lift the hood.



3. Use the support rod to hold the hood open.




#### ▼ Closing the Hood

1. Check under the hood area to make certain all filler caps are in place and all loose items (e.g. tools, oil containers, etc.) have been removed.
2. Secure the rod in its clip.
3. Close the hood so that it locks securely.

## Sunroof

The sunroof can be opened or closed electrically only when the ignition switch is in the ON position.



## ! WARNING

### Extending the Head or Arms Through the Sunroof:

*Extending the head, arms, or other parts of the body through the sunroof is dangerous. The head or arms could hit something while the vehicle is moving. This could cause death or serious injury. Don't let passengers stand up or extend anything through the open sunroof while the vehicle is moving.*

### Closing the Sunroof:

*A closing sunroof is dangerous. The hands, head, or even neck of a person—especially a child—could be caught in it as it closes, causing serious injury or even death. Make sure the opening is clear before closing the sunroof.*

## NOTE


After washing your Mazda or after a rain, wipe the water off the sunroof before operating it.

## ▼ Tilt Operation

The rear of the sunroof can be tilted open to provide more ventilation.

To tilt, push the rear of the tilt switch.

To close, push the front of the tilt switch.




# Doors and Locks

## ▼ Slide Operation

To open to any position, press the rear of the slide switch.


To close, press the front of the slide switch.



## ▼ Sunshade

The sunshade can be opened and closed by hand.

The sunshade opens automatically when the sunroof is opened, but must be closed by hand.




 **CAUTION**

The sunshade doesn't tilt. To avoid damaging the sunshade, don't push up on it.

## Doors and Locks

### Roof Rack

The front cross bar is fixed in place. The rear cross bar can be adjusted by sliding it.



### CAUTION

- The roof rack is not designed for direct placement of objects or loads. A special attachment kit is necessary. Consult an Authorized Mazda Dealer.
- The maximum load on the roof rack is 75 kg (165 lb). Do not overload.
- Because the bolts and screws may loosen initially, retighten them. Periodically check bolts for looseness approximately every 100 km (62 miles).
- Avoid turning sharply and jamming on the brakes while the roof rack installed. Doing so may cause an accident or the luggage may fall off.
- Road conditions (especially steep curves or rough roads) and weather changes (strong cross wind, head wind, rain, snow, or fog) can change vehicle operating characteristics greatly when the vehicle is equipped with the roof rack. To cope with these conditions, drive at a slower speed.
- When driving in a tunnel or parking garage or any place with height restrictions with the roof rack installed, be aware that the roof rack will raise the total clearance of the vehicle.
- If the vehicle is washed in an automatic car wash with the roof rack installed, the roof rack or the roof of the vehicle can be damaged. Before washing the vehicle in an automatic car wash, always remove the roof rack.


## Doors and Locks

### NOTE


Roof racks increase wind turbulence which can result in noise. This does not indicate an abnormality. The roof rack can be removed when it is not needed.

### ▼ Roof Rack Adjustment


1. Loosen the screw at both ends of the rear cross bar, then remove the rear cross bar covers.



2. Loosen the bolt at both ends of the rear cross bar, then slide the rear cross bar to the desired position.




3. Tighten the bolt at both ends of the rear cross bar alternately and evenly.



### NOTE

- If only one bolt is tightened, the cross bar will lean to one side.
- Tighten the bolts with tightening torque of 11—12 N•m { 110—120 kgf•cm }.

4. Install the rear cross bar cover by inserting the clips into the square hole of the rear cross bar until they click, then tighten the screw.



# Steering Wheel and Mirrors


## Steering Wheel

### **WARNING**

**Adjusting the Steering Wheel:**  
*Adjusting the steering wheel while the vehicle is moving is dangerous. Moving it can very easily cause the driver to abruptly turn to the left or right. This can lead to loss of control or an accident. Never adjust the steering wheel while the vehicle is moving.*

### ▼ **Tilt Steering Wheel**

To change the angle of the steering wheel, stop the vehicle, pull the tilt wheel release lever under the steering column down, adjust the wheel, then push the release lever up to lock the column.



After adjusting, push the wheel up and down to be certain it's locked before driving.

## Mirrors

### ▼ **Outside Mirrors**


Check the mirrors' angles before driving.

### **WARNING**

**Convex Mirror (Passenger Side):**  
*Changing lanes without taking into account the actual distance of the vehicle in the convex mirror is dangerous. You could have a serious accident. What you see in the convex mirror is closer than it appears. Be sure to look over your shoulder or to check your inside mirror before changing lanes.*

### **Manual control mirror**

To adjust, move the mirror's control lever, just inside the door.




## Steering Wheel and Mirrors

### Power control mirror

The ignition switch must be in the ACC or ON position.

To adjust:


1. Move the selector switch to the left or right to choose the mirror.
2. Depress the perimeter switch in the appropriate direction.



After adjusting the mirror, lock the control by moving the selector switch to the middle position.

### Folding the mirror

Fold the outside mirror rearward until it is flush with the vehicle.



## **WARNING**


**Driving with Mirrors Folded In:**  
*Driving with the outside mirrors folded in is dangerous. Your rear view will be restricted, and you could have an accident. Always return the outside mirrors to the driving position before you start driving.*

### ▼ **Rearview Mirror (With Day/ Night Function)**

Before driving, adjust the rearview mirror to center on the scene through the rear window.

Do this with the day/night lever in the day position.

Push the lever forward for day driving. Pull it back to reduce glare from headlights.



## Steering Wheel and Mirrors

---



### **WARNING**

**Blocked View:**

*Cargo stacked higher than the seatbacks is dangerous. It can block your view in the rearview mirror, which might cause you to hit another car when changing lanes. Don't stack things higher than the seatbacks.*



Important information about driving your Mazda.

|                                                                        |             |
|------------------------------------------------------------------------|-------------|
| <b>Fuel and Engine Exhaust Precautions .....</b>                       | <b>4-2</b>  |
| Fuel Requirements .....                                                | 4-2         |
| Emission Control System .....                                          | 4-3         |
| Engine Exhaust (Carbon Monoxide) .....                                 | 4-4         |
| <b>Before Starting the Engine .....</b>                                | <b>4-5</b>  |
| Before Getting In .....                                                | 4-5         |
| After Getting In .....                                                 | 4-5         |
| <b>Driving Tips .....</b>                                              | <b>4-6</b>  |
| Break-In Period .....                                                  | 4-6         |
| Money-Saving Suggestions .....                                         | 4-6         |
| Hazardous Driving .....                                                | 4-7         |
| Rocking the Vehicle .....                                              | 4-7         |
| Winter Driving .....                                                   | 4-8         |
| Driving In Flooded Area .....                                          | 4-10        |
| Overloading .....                                                      | 4-10        |
| Operating Tips for Turbocharged Vehicles (MAZDASPEED<br>Protegé) ..... | 4-11        |
| <b>Towing .....</b>                                                    | <b>4-12</b> |
| Trailer Towing .....                                                   | 4-12        |

# Fuel and Engine Exhaust Precautions

## Fuel Requirements

Vehicles with catalytic converters or oxygen sensors must use **ONLY UNLEADED FUEL**, which will reduce exhaust emissions and keep spark plug fouling to a minimum.

Fuel with a lower rating could cause the emission control system to lose effectiveness. It could also cause engine knocking and serious engine damage.

Your Mazda will perform best with fuel listed in the table.

| Fuel                  | Octane Rating* (Anti-knock index)               |
|-----------------------|-------------------------------------------------|
| Regular unleaded fuel | 87 [ (R+M)/2 method] or above (91 RON or above) |

\*U.S. federal law requires that octane ratings be posted on gasoline station pumps.

### MAZDASPEED Protégé

Use only premium unleaded fuel:91 [ (R+M)/2 method] or above (96 RON or above)

⚠ CAUTION

- **USE ONLY UNLEADED FUEL.**  
Leaded fuel is harmful to the catalytic converter or the oxygen sensor. The lead will accumulate on the oxygen sensor and the catalyst inside the converter. This will result in a malfunction of the emission control system, causing poor performance.
- Your vehicle can only use oxygenated fuels containing no more than 10% ethanol by volume. Damage to your vehicle may occur when ethanol exceeds this recommendation, or if the gasoline contains any methanol. Stop using gasohol of any kind if your vehicle engine is performing poorly.
- Never add fuel system additives. Never add cleaning agents other than those specified by Mazda. Other cleaning agents and additives may damage the system. Consult an Authorized Mazda Dealer.

Gasoline blended with oxygenates such as alcohol or ether compounds are generally referred to as oxygenated fuels. The common gasoline blend that can be used with your vehicle is ethanol blended at no more than 10%. Gasoline containing alcohol, such as ethanol or methanol, may be marketed under the name "Gasohol".

Vehicle damage and drivability problems resulting from the use of the following may not be covered by the Mazda warranty.

- Gasohol containing more than 10% ethanol.
- Gasoline or gasohol containing methanol.
- Leaded fuel or leaded gasohol.

## Fuel and Engine Exhaust Precautions

### Emission Control System

Your vehicle is equipped with an emission control system (the catalytic converter is part of this system) that enables your vehicle to comply with existing exhaust emissions requirements.

#### **WARNING**

**Parking Over Things That Burn:**

*Parking over or near anything inflammable, such as dry grass, is dangerous. Even with the engine turned off, the exhaust system could ignite it because the exhaust system gets very hot during normal use. A resulting fire could cause serious injury or death. Never park over or near anything inflammable.*

#### **CAUTION**

Ignoring the following precautions could cause lead to accumulate on the catalyst inside the converter or cause the converter to get very hot. Either condition will damage the converter and cause poor performance.

- **USE ONLY UNLEADED FUEL.**
- Don't drive your Mazda with any sign of engine malfunction.
- Don't coast with the ignition switch turned off.
- Don't descend steep grades in gear with the ignition switch turned off.
- Don't operate the engine at high idle for more than 5 minutes.
- Don't tamper with the emission control system. All inspections and adjustments must be made by a qualified technician.
- Don't try to push-start or pull-start your vehicle.

#### **NOTE**

Under U.S. federal law, any modification to the original-equipment emission control system before the first sale and registration of a vehicle is subject to penalties. In some states, such modification made on a used vehicle is also subject to penalties.

## Fuel and Engine Exhaust Precautions

---

### Engine Exhaust (Carbon Monoxide)

#### **WARNING**

##### **Carbon Monoxide:**

*Engine exhaust gas is dangerous. This gas contains carbon monoxide (CO), which is colorless, odorless, and poisonous. When inhaled, it can cause loss of consciousness and death. If you smell exhaust gas inside your vehicle, keep all windows fully open and contact an Authorized Mazda Dealer immediately.*

##### **Exhaust Gas in Enclosed Area:**

*Running the engine inside an enclosed area, such as a garage, is dangerous. Exhaust gas, which contains poisonous carbon monoxide, could easily enter the cabin. Loss of consciousness or even death could occur. Don't run the engine when inside an enclosed area.*

##### **Idling with the Windows Closed:**

*Exhaust gas is dangerous. When your vehicle is stopped with the windows closed and the engine running for a long time in an open area, exhaust gas, which contains poisonous carbon monoxide, could enter the cabin. Loss of consciousness or even death could occur. Open the windows or adjust the heating or cooling system to draw fresh air.*

##### **Snow Blocking the Exhaust Gas:**

*Running the engine when a vehicle is stopped in deep snow is dangerous. The exhaust pipe could be blocked by the snow, allowing exhaust gas to enter the cabin. Because exhaust gas contains poisonous carbon monoxide, anyone in the cabin could be injured or killed. Clear the snow from underneath and around your vehicle before starting the engine.*

## Before Starting the Engine

### Before Getting In

- Be sure the windows, outside mirror (s), and outside lights are clean.
- Inspect inflation pressures and condition of tires.
- Look under the vehicle for any sign of a leak.
- If you plan to back up, make sure nothing will be in your way.

#### NOTE

Engine oil, engine coolant, brake/clutch fluid, washer fluid, and other fluid levels should be inspected daily, weekly, or at refueling, depending on the fluid. See Maintenance, Section 8.

### After Getting In

- Are all doors closed and locked?
- Are the inside and outside mirrors adjusted?
- Is everyone's seat belt fastened?
- Do all the lights work?
- Check all gauges.
- Check all warning lights when the ignition switch is turned to the ON position.
- Release the parking brake and make sure the parking brake warning light goes off.

Always be thoroughly familiar with your Mazda.

## Driving Tips

---

### Break-In Period

No special break-in is necessary, but a few precautions in the first 1,000 km (600 miles) may add to the performance, economy, and life of your Mazda.

- Don't race the engine.
- Don't maintain one constant speed for long.
- Don't drive constantly at full-throttle or high engine rpm for extended periods of time.
- Avoid unnecessary hard stops.
- Avoid full-throttle starts.

### Money-Saving Suggestions

How you operate your Mazda determines how far it will travel on a tank of fuel. Use these suggestions to help save money on fuel and repairs.

- Avoid long warm-ups. Once the engine runs smoothly, begin driving.
- Avoid fast starts.
- Keep the engine tuned. Follow the maintenance schedule (page 8-3) and have an Authorized Mazda Dealer perform inspections and servicing.
- Use the air conditioner only when necessary.
- Slow down on rough roads.
- Keep the tires properly inflated.
- Don't carry unnecessary weight.
- Don't rest your foot on the brake pedal while driving.
- Keep the wheels in correct alignment.
- Keep windows closed at high speeds.
- Slow down when driving in crosswinds and headwinds.

### **WARNING**

#### **Coasting:**

***Turning off the engine to coast down a hill is dangerous. This causes the loss of power steering and power brake control. Any loss of steering or braking control could cause an accident. Never turn off the engine and coast down a hill.***

## Hazardous Driving

### WARNING

***Downshifting on Slippery Surfaces:***  
Downshifting into lower gear while driving on slippery surfaces is dangerous. The sudden change in tire speed could cause the tires to skid. This could lead to loss of vehicle control and an accident. If it is necessary to downshift on slippery surfaces, be very careful.

When driving on ice or in water, snow, mud, sand, or similar hazard:

- Be cautious and allow extra distance for braking.
- Avoid sudden braking and quick steering.
- If your vehicle is not equipped with ABS, brake with the pedal by using a light up-down motion. Don't hold the pedal down constantly. If your vehicle is equipped with ABS, don't pump the brakes. Continue to press down on the brake pedal.
- If you get stuck, shift to 1 or 2 and accelerate slowly. Don't spin the front wheels.
- For more traction in starting, use sand, rock salt, chains, carpeting, or other nonslip material under the front wheels.

### NOTE

Use snow chains only on the front wheels.

## Rocking the Vehicle

### WARNING

***Spinning the Wheels:***  
When the vehicle is stuck, spinning the wheels at high speed is dangerous. The spinning tire could overheat and explode. This could cause serious injuries. Don't spin the wheels at more than 56 km/h (35 mph), and don't allow anyone to stand behind a wheel when pushing the vehicle.

### CAUTION

Too much rocking may cause engine overheating, transaxle failure, and tire damage.

If you must rock the vehicle to free it from snow, sand, or mud, depress the accelerator slightly and slowly move the shift lever from 1 (D) to R.

## Driving Tips

### Winter Driving

- Carry emergency gear, including tire chains, window scraper, flares, a small shovel, jumper cables, and a small bag of sand or salt.

Ask a Mazda dealer to perform the following precautions:

- Have the proper ratio of antifreeze in the radiator.
- Inspect the battery and its cables. Cold reduces battery capacity.
- Use only cold-weather engine oil (page 8-13).
- Inspect the ignition system for damage and loose connections.
- Use washer fluid made with antifreeze—but don't use engine coolant antifreeze for washer fluid (page 8-22).
- Don't use the parking brake in freezing weather as the parking brake may freeze. Instead, shift to P with an automatic transaxle and to 1 or R with a manual transaxle. Block the rear wheels.

### ▼ Snow Tires

#### **WARNING**

##### Mixing Tire Types:

*Using tires different in size or type is dangerous. Your vehicle's handling could be greatly affected and result in an accident. Use only the same size and type tires (snow, radial, or non-radial) on all four wheels.*

#### **CAUTION**

Check local regulations before using studded tires.

##### Use snow tires on all four wheels

Your vehicle is originally equipped with all season radials designed to be used all year around. In some extreme climates you may find it necessary to replace them with snow tires during the winter months to further improve traction on snow and ice covered roads.

Don't go faster than 120 km/h (75 mph). Inflate snow tires 30 kPa (0.3 kgf/cm<sup>2</sup>, 4.3 psi) more than recommended on the tire pressure label (driver's door), but never more than the maximum cold-tire pressure shown on the tires.

**▼ Tire Chains****⚠ CAUTION**

- Chains may scratch or chip aluminum wheels. Install tire chains on steel wheels only.
- Chains may affect handling.
- Don't go faster than 50 km/h (30 mph) or the chain manufacturer's recommended limit, whichever is lower.
- Drive carefully and avoid bumps, holes, and sharp turns.
- Avoid locked-wheel braking.
- Don't use chains on the temporary tire; it may result in damage to the vehicle and to the tire.
- Don't use chains on roads that are free of snow or ice. The tires and chains could be damaged.

**NOTE****(MAZDASPEED Protégé)**

Use of tire chains on a vehicle equipped with 215/45ZR17 specification tires and rim could cause interference with the vehicle body and scratching. If tire chains are to be used, replace both front and rear tires with P195/50R16 tires. Please consult an Authorized Mazda Dealer.

Check local regulations before using tire chains.

Install the chains on the front tires.

Don't use chains on the rear tires.

Use only SAE Class "S" chains, and make sure they fit.

**Installing the chains**

1. Remove the wheel covers, or the chain bands will scratch them.
2. Secure the chains on the front tires as tightly as possible. Always follow the chain manufacturer's instructions.
3. Retighten the chains after driving 1/2—1 km (1/4—1/2 mile).

## Driving Tips

---

### Driving In Flooded Area

#### **WARNING**

**Driving with Wet Brakes:**

*Driving with wet brakes is dangerous. Increased stopping distance or the vehicle pulling to one side when braking could result in a serious accident. Light braking will indicate whether the brakes have been affected. Dry the brakes by driving very slowly and applying the brakes lightly until brake performance returns to normal.*

#### **CAUTION**

Make sure water does not enter the vehicle interior or the engine area. The vehicle interior could become wet or the engine could be damaged.

### Overloading

#### **WARNING**

**Vehicle Load Weight:**

*The gross axle weight rating (GAWR) and the gross vehicle weight rating (GVWR) of your vehicle are on the Motor Vehicle Safety Standard Label on the driver's door frame. Exceeding these ratings can cause an accident or vehicle damage. You can estimate the weight of your load by weighing the items (or people) before putting them in the vehicle. Be careful not to overload your vehicle.*

## **Operating Tips for Turbocharged Vehicles (MAZDASPEED Protégé)**

MAZDASPEED Protégé's turbocharger greatly enhances engine power. Its advanced design provides better operation and requires minimum additional maintenance. To get maximum performance from your turbocharged engine, take note of the following tips:

- The turbocharged engine is designed for optimal operation with premium unleaded gasoline. Do not use fuel with a lower octane rating. Extra fuel additives are NOT recommended.
- Change the engine oil and filter using the turbo engine interval outlined the maintenance schedule (for your driving condition).
- Use engine oil with API SL or ILSAC GF-III service grade (or higher). Extra oil additives are NOT recommended.
- After driving at freeway speeds or up a long hill, idle the engine at least 30 seconds to cool the turbo. Avoid simply shutting the engine off abruptly after a hard or long drive. Damage to the turbocharger may result.
- Don't race or over-rev the engine when starting. This should not be done with ANY engine, especially not with one that's turbocharged.
- Do not add any aftermarket devices to alter the engine's ignition timing, fuel delivery, or turbo boost pressure. This may lead to serious engine damage and may void your warranty.

# Towing

---

## Trailer Towing

Never tow a trailer with your Mazda.


Explanation of instruments and controls.

|                                                     |      |
|-----------------------------------------------------|------|
| <b>Starting and Driving</b> .....                   | 5-2  |
| Ignition Switch .....                               | 5-2  |
| Starting the Engine .....                           | 5-3  |
| Brake System .....                                  | 5-4  |
| Manual Transaxle Operation .....                    | 5-8  |
| Automatic Transaxle Controls .....                  | 5-10 |
| Automatic Transaxle Controls (Sport AT) .....       | 5-13 |
| Power Steering .....                                | 5-19 |
| Cruise Control .....                                | 5-19 |
| <br><b>Instrument Cluster and Indicators</b> .....  | 5-23 |
| Meters and Gauges .....                             | 5-23 |
| <br><b>Warning/Indicator Lights and Beeps</b> ..... | 5-27 |
| Warning/Indicator Lights .....                      | 5-27 |
| Beeps .....                                         | 5-35 |
| <br><b>Switches and Controls</b> .....              | 5-36 |
| Lighting Control .....                              | 5-36 |
| Turn and Lane-Change Signals .....                  | 5-37 |
| Fog Lights .....                                    | 5-37 |
| Daytime Running Lights .....                        | 5-38 |
| Windshield Wipers and Washer .....                  | 5-38 |
| Rear Window Wiper and Washer (Hatchback) .....      | 5-40 |
| Rear Window Defroster .....                         | 5-40 |
| Horn .....                                          | 5-41 |
| Hazard Warning Flasher .....                        | 5-41 |

# Starting and Driving

## Ignition Switch

### ▼ Ignition Switch Positions




### LOCK

The steering wheel locks to protect against theft. Only in this position can the key be removed.


### Manual transaxle

When turning the ignition switch to the LOCK position, push the key in at the ACC position.



### Automatic transaxle

When turning the ignition switch to the LOCK position, keep the shift lever in P.



## ! WARNING

### Removing the Key:

*It's dangerous to remove the key from the ignition switch while the vehicle is moving. Removing the key allows the steering wheel to lock. You will lose steering control and a serious accident could occur.*

*Remove the key only when the vehicle is parked.*

### Not Setting the Parking Brake:

*Leaving the driver's seat without setting the parking brake is dangerous. Unexpected vehicle movement could occur if the parking brake is not set. This could cause an accident. Before leaving the driver's seat, always set the parking brake and make sure the shift lever is in P with an automatic transaxle or in 1 or R with a manual transaxle.*

# Starting and Driving

## NOTE

If turning the key is difficult, jiggle the steering wheel from side to side.

## ACC (Accessory)

The steering wheel unlocks and some electrical accessories will operate.

## ON

This is the normal running position after the engine is started. The warning lights (except brakes) should be inspected before the engine is started (page 5-27).

## START

The engine is started in this position. It will crank until you release the key; then it returns to the ON position. The brake warning light can be checked after the engine is started (page 5-27).

## ▼ Ignition Key Reminder

If the ignition switch is in the LOCK or ACC position, a beep will sound when any door is opened.

## Starting the Engine

## NOTE

Engine-starting is controlled by the spark ignition system. This system meets all Canadian Interference-Causing Equipment Standard requirements regulating the impulse electrical field strength of radio noise.

1. Occupants should fasten their seat belts.
2. Make sure the parking brake is on.
3. Depress the brake pedal.
4. **(Manual transaxle)**  
Depress the clutch pedal all the way and shift into neutral.  
Keep the pedal depressed while cranking the engine.

## NOTE

The starter will not operate if the clutch pedal is **not** pushed down all the way.

## **(Automatic transaxle)**

Put the vehicle in park (P). If you must restart the engine while the vehicle is moving, shift into neutral (N).

## NOTE

The starter will not operate if the shift lever is **not** in P or N.

## Starting and Driving

5. Turn the ignition switch to the START position and hold (up to 10 seconds at a time) until the engine starts.

### CAUTION

Don't try the starter for more than 10 seconds at a time. If the engine stalls or fails to start, wait 10 seconds before trying again. Otherwise, you may damage the starter and drain the battery.

6. After starting the engine, let it idle for about 10 seconds.

### NOTE

- In extremely cold weather, below  $-18^{\circ}\text{C}$  ( $0^{\circ}\text{F}$ ), or after the vehicle has stood idle several days, let the engine warm up without operating the accelerator.
- Whether cold or warm, the engine should be started without use of the accelerator.

## Brake System

### ▼ Foot Brake

Your Mazda has power-assisted brakes that adjust automatically through normal use.

Should power-assist fail, you can stop by applying greater force than normal to the brake pedal. But the distance required to stop will be greater than usual.

### WARNING

**Driving with the Engine Off:**  
*Continuing to drive when the engine is stalled or turned off is dangerous. Braking will require more effort, and the brake's power-assist could be depleted if you pump the brake. This will cause longer stopping distances or even an accident. Don't continue driving when the engine is stalled or turned off, find a safe place to stop.*

**Riding the Brakes:**  
*Driving with your foot continuously on the brake pedal or steadily applying the brakes for long distances is dangerous. This causes overheated brakes, resulting in longer stopping distances or even total brake failure. This could cause loss of vehicle control and a serious accident. Avoid continuous application of the brakes. Shift to a lower gear when going down steep hills.*

# Starting and Driving

## ⚠ WARNING

**Driving with Wet Brakes:**  
*Driving with wet brakes is dangerous. Increased stopping distance or the vehicle pulling to one side when braking could result in a serious accident. Light braking will indicate whether the brakes have been affected. Dry the brakes by driving very slowly and applying the brakes lightly until brake performance is normal.*


### ▼ Parking Brake

## ⚠ CAUTION

Driving with the parking brake on will cause excessive wear of the brake linings or pads.


### Setting the parking brake

Depress the brake pedal, then pull the brake handle fully upward.



### Releasing the parking brake

Depress the brake pedal, then pull the handle up and press the button. Lower the handle to the release position while holding in the button.



### ▼ Brake System Warning Light



This warning has the following functions:

#### Parking brake warning

The light comes on when the parking brake is applied with the ignition switch in the START or ON position. It goes off when the parking brake is fully released.

#### Low brake fluid level warning/ Electronic brake force distribution system warning

If the light stays on after the parking brake is fully released, you may have a brake problem.

Drive to the side of the road and park off the right-of-way.

## Starting and Driving

---

### Low brake fluid level warning

You may notice that the pedal is harder to push or that it may go closer to the floor. In either case, it will take longer to stop the vehicle.

1. With the engine stopped, check the brake fluid level immediately and add fluid as required (page 8-18).
2. After adding fluid, check the light again.

If the warning light remains on, or if the brakes do not operate properly, do not drive the vehicle. Have it towed to an Authorized Mazda Dealer.

Even if the light goes off, have your brake system inspected as soon as possible.

### Electronic brake force distribution system warning

If the electronic brake force distribution control unit determines that some components are operating incorrectly, the control unit may turn the brake system warning light on.

In this case, the ABS warning light comes on at the same time (page 5-32).

## **WARNING**

### **Brake Warning Light:**

*Driving with the brake system warning light on is dangerous. It indicates that your brakes may not work at all or that they could completely fail at any time. If this light remains on, have the brakes inspected immediately. Don't drive with this light on, and contact an Authorized Mazda Dealer to have the brakes inspected as soon as possible.*

### **ABS Warning Light and Brake Warning Light on at the Same Time:**

*Driving when the brake system warning light and ABS warning light are on at the same time is dangerous. When both lights are on, the rear wheels could lock more quickly in an emergency stop than under normal circumstances.*

*Don't drive with both lights on, and contact an Authorized Mazda Dealer to have the brakes inspected as soon as possible.*

# Starting and Driving

## ▼ Anti-Lock Brake System (ABS)

The ABS control unit continuously monitors the speed of each wheel. If one is about to lock up, the ABS responds by automatically releasing and reapplying that wheel's brake.

The driver will feel a slight vibration in the brake pedal and may hear a chattering noise from the brake system. This is normal when the ABS operates. Don't pump the brakes, continue to press down on the brake pedal.

### **WARNING**

#### **ABS:**

*The ABS cannot compensate for unsafe and reckless driving, excessive speed, tailgating (following another vehicle too closely), and hydroplaning (reduced tire friction and road contact because of water on the road surface). You can still have an accident. So don't rely on ABS as a substitute for safe driving.*

#### **NOTE**

Braking distances may be longer on loose surfaces (snow or gravel, for example) which usually have a hard foundation. A vehicle with a normal braking system may require less distance to stop under these conditions because the tires will build up a wedge of surface layer when the wheels skid.

## ▼ ABS Warning Light



The warning light stays on for a few seconds when the ignition switch is turned to the ON position.

If the ABS warning light stays on while you're driving, the ABS control unit has detected a system malfunction. If this occurs, your brakes will function normally as if the vehicle had no ABS. Should this happen, consult an Authorized Mazda Dealer as soon as possible.

### **WARNING**

**ABS Warning Light and Brake Warning Light on at the Same Time:**  
*Driving when the brake system warning light and ABS warning light are on at the same time is dangerous. When both lights are on, the rear wheels could lock more quickly in an emergency stop than under normal circumstances. Don't drive with both lights on, and contact an Authorized Mazda Dealer to have the brakes inspected as soon as possible.*


## Starting and Driving

### NOTE

When the engine is jump-started to charge the battery, uneven rpm occurs and the ABS warning light comes on. This is due to a weak battery, not a malfunction. Recharge the battery.

### ▼ Brake Pad Wear Indicator

When the disc brake pads become worn, the built-in wear indicators contact the disc plates. This causes a screeching noise to warn that the pads should be replaced.




When you hear this noise, consult an Authorized Mazda Dealer as soon as possible.

### ! WARNING

***Driving with Worn Disc Pads:***  
*Driving with worn disc pads is dangerous. The brakes could fail and cause a serious accident. As soon as you hear a screeching noise consult an Authorized Mazda Dealer.*

## Manual Transaxle Operation

### ▼ Manual Transaxle Shift Pattern



The shift pattern of the transaxle is conventional, as shown.

Press the clutch pedal all the way down while shifting; then release it slowly.

A safety feature prevents accidental shifting from 5 to reverse. The shift lever must be put in neutral before being shifted to reverse.

### ! WARNING

#### **Sudden Engine-Braking:**

*Shifting down while driving on wet, snowy, or frozen roads, or driving at high speeds causes sudden engine braking, which is dangerous. The sudden change in tire speed could cause the tires to skid. This could lead to loss of vehicle control and an accident. Do not cause sudden engine braking on slippery road surfaces or at high speeds.*

# Starting and Driving

## ⚠ CAUTION

- Keep your foot off the clutch pedal except when shifting gears. Also, don't use the clutch to hold the vehicle on an upgrade. This will avoid needless clutch wear and damage.
- Make sure the vehicle comes to a complete stop before shifting to reverse. Shifting to reverse while the vehicle is still moving may damage the transaxle.

## NOTE

If shifting to reverse is difficult, shift into neutral, release the clutch pedal, and try again.

## ▼ Recommendations for Shifting

### Upshifting

#### 1.6-liter engine

For normal acceleration, we recommend these shift points.

|        |                  |
|--------|------------------|
| 1 to 2 | 26 km/h (16 mph) |
| 2 to 3 | 45 km/h (28 mph) |
| 3 to 4 | 56 km/h (35 mph) |
| 4 to 5 | 73 km/h (45 mph) |

For cruising

|        |                  |
|--------|------------------|
| 1 to 2 | 16 km/h (10 mph) |
| 2 to 3 | 31 km/h (19 mph) |
| 3 to 4 | 48 km/h (30 mph) |
| 4 to 5 | 66 km/h (41 mph) |

#### 2.0-liter engine

For normal acceleration, we recommend these shift points.

|        |                  |
|--------|------------------|
| 1 to 2 | 21 km/h (13 mph) |
| 2 to 3 | 39 km/h (24 mph) |
| 3 to 4 | 55 km/h (34 mph) |
| 4 to 5 | 79 km/h (49 mph) |

For cruising

|        |                  |
|--------|------------------|
| 1 to 2 | 18 km/h (11 mph) |
| 2 to 3 | 29 km/h (18 mph) |
| 3 to 4 | 47 km/h (29 mph) |
| 4 to 5 | 68 km/h (42 mph) |

### MAZDASPEED Protégé

For normal acceleration and cruising, we recommend these shift points.

|        |                  |
|--------|------------------|
| 1 to 2 | 24 km/h (15 mph) |
| 2 to 3 | 40 km/h (25 mph) |
| 3 to 4 | 65 km/h (40 mph) |
| 4 to 5 | 73 km/h (45 mph) |


### Downshifting

When you must slow down in heavy traffic or on a steep **upgrade**, downshift before the engine starts to overwork. This reduces the chance of stalling and gives better acceleration when you need more speed.

On a steep **downgrade**, downshifting helps maintain safe speed and prolongs brake life.

# Starting and Driving

## Automatic Transaxle Controls



### Various Lockouts:

|                                                                                    |                                                                                                                                                       |
|------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | Indicates that you must depress the brake pedal and hold in the lock-release button to shift (The ignition switch must be in the ACC or ON position). |
|  | Indicates the shift lever can be shifted freely into any position.                                                                                    |
|  | Indicates that you must hold in the lock-release button to shift.                                                                                     |

### ▼ Transaxle Ranges

The shift lever must be in P or N to operate the starter.

#### P (Park)

P locks the transaxle and prevents the front wheels from rotating.

### WARNING

**Holding the Vehicle with P:**  
*Setting the shift lever to the P position without using the parking brake to hold the vehicle is dangerous. If P fails to hold, the vehicle could move and cause an accident. To hold the vehicle, set the shift lever to P AND set the parking brake.*

### CAUTION

- Shifting into P, N or R while the vehicle is moving can damage your transaxle.
- Shifting into a driving gear or reverse when the engine is running faster than idle can damage the transaxle.

#### R (Reverse)

In position R, the vehicle moves only backward. You must be at a complete stop before shifting to or from R, except as explained under Rocking the Vehicle (page 4-7).

#### N (Neutral)

In N, the wheels and transaxle are not locked. The vehicle will roll freely even on the slightest incline unless the parking brake or brakes are on.

# Starting and Driving

## **WARNING**

### Shifting from N or P:

*It's dangerous to shift from N or P into a driving gear when the engine is running faster than idle. If this is done, the vehicle could move suddenly, causing an accident or serious injury. If the engine is running faster than idle, don't shift from N or P into a driving gear.*

### Shifting into N while Driving:

*Shifting into N while driving is dangerous. Engine braking cannot be applied when decelerating which could lead to an accident or serious injury. Do not shift into N when driving the vehicle.*

## **D (Drive)**

D is the normal driving position. From a stop, the transaxle will automatically shift through a 4-gear sequence.

## **2 (Second)**

The 2 position is helpful when driving in heavy, slow-moving traffic and climbing hills, for engine braking assist when going down hills, or for starting on slick surfaces and other situations where gentle acceleration may be necessary. Do not exceed 108 km/h (67 mph) in the 2 position.

## **1 (Low)**

Use the 1 position for maximum power in hard-pulling situations, or for climbing and descending very steep grades. Do not exceed 57 km/h (35 mph) in the 1 position.

## **WARNING**

### Sudden Engine-Braking:

*Shifting down while driving on wet, snowy, or frozen roads, or driving at high speeds causes sudden engine braking, which is dangerous. The sudden change in tire speed could cause the tires to skid. This could lead to loss of vehicle control and an accident. Do not cause sudden engine braking on slippery road surfaces or at high speeds.*

## ▼ **Shift-Lock System**

The shift-lock system prevents shifting out of P unless the brake pedal is depressed.

To shift from P:

1. Depress and hold the brake pedal.
2. Start the engine.
3. Push and hold the lock-release button.
4. Move the shift lever.

## **NOTE**

- When the ignition switch is in the LOCK position, the transaxle cannot be shifted from P.
- To be sure the vehicle is in park, **the ignition key cannot be removed unless the shift lever is in P.**


## Starting and Driving

### ▼ Overdrive

#### Overdrive operation

In D, the transaxle automatically shifts to overdrive, which improves fuel economy and reduces noise.

To allow engine braking when going down a steep grade, make sure the overdrive button is in the off position.



And for a smoother ride with less shifting, don't use it when:

- Going up a steep grade.
- Driving in stop-and-go traffic.
- Pulling heavy loads.

**To turn off the overdrive, push the button.**

The transaxle will then shift through a three-gear sequence in D.

Shift patterns without overdrive:

D = 1st, 2nd, 3rd

2 = 2nd

1 = 1st

**To turn it on, push the button again.**

Shift patterns with overdrive:

D = 1st, 2nd, 3rd, 4th

2 = 2nd

1 = 1st

#### O/D OFF indicator light

**O/D  
OFF**

This light comes on when the overdrive has been turned off.

#### **⚠ CAUTION**

If the overdrive-off indicator light flashes, the transaxle has an electrical problem. Continuing to drive your Mazda in this condition could cause damage to your transaxle. Consult an Authorized Mazda Dealer as soon as possible.

### ▼ Driving Tips

#### Passing

For extra power when passing another vehicle or climbing steep grades, depress the accelerator fully. The transaxle will shift to a lower gear, depending on vehicle speed.

#### Climbing steep grades from a stop

To climb a steep grade from a stopped position:


1. Depress the brake pedal.
2. Shift to D or 1, depending on the load weight and grade steepness.
3. Release all brakes while gradually accelerating.

# Starting and Driving

## Descending steep grades

When descending a steep grade, shift to 2 or 1, depending on load weight and grade steepness. Descend slowly, using the brakes only occasionally to prevent them from overheating.

## Automatic Transaxle Controls (Sport AT)



### Various Lockouts:

|                                                                                     |                                                                                                            |
|-------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------|
|   | Indicates that you must depress the brake pedal to shift (The ignition switch must be in the ON position). |
|  | Indicates the shift lever can be shifted freely into any position.                                         |

# Starting and Driving

## ▼ Transaxle Ranges

The shift lever must be in P or N to operate the starter.

### P (Park)

P locks the transaxle and prevents the front wheels from rotating.

 **WARNING**

**Holding the Vehicle with P:**  
*Setting the shift lever to the P position without using the parking brake to hold the vehicle is dangerous. If P fails to hold, the vehicle could move and cause an accident. To hold the vehicle, set the shift lever to P AND set the parking brake.*

 **CAUTION**

- Shifting into P, N or R while the vehicle is moving can damage your transaxle.
- Shifting into a driving gear or reverse when the engine is running faster than idle can damage the transaxle.

### R (Reverse)

In position R, the vehicle moves only backward. You must be at a complete stop before shifting to or from R, except as explained under Rocking the Vehicle (page 4-7).

### N (Neutral)

In N, the wheels and transaxle are not locked. The vehicle will roll freely even on the slightest incline unless the parking brake or brakes are on.

 **WARNING**

**Shifting from N or P:**  
*It's dangerous to shift from N or P into a driving gear when the engine is running faster than idle. If this is done, the vehicle could move suddenly, causing an accident or serious injury. If the engine is running faster than idle, don't shift from N or P into a driving gear.*

**Shifting into N while Driving:**  
*Shifting into N while driving is dangerous. Engine braking cannot be applied when decelerating which could lead to an accident or serious injury. Do not shift into N when driving the vehicle.*

### D (Drive)

D is the normal driving position. From a stop, the transaxle will automatically shift through a 4-gear sequence.

### M (Manual)

M is the manual shift mode position. Gears can be shifted up or down by tapping the shift lever back or forward from this position.

# Starting and Driving

## ▼ Shift-Lock System

The shift-lock system prevents shifting out of P unless the brake pedal is depressed.

To shift from P:

1. Depress and hold the brake pedal.
2. Start the engine.
3. Move the shift lever.


### NOTE

- When the ignition switch is in the ACC or LOCK position, the transaxle cannot be shifted from P.
- To be sure the vehicle is in park, **the ignition key cannot be removed unless the shift lever is in P.**

## ▼ Shift-Lock Override

If the shift lever won't move from P with the brake pedal depressed, continue to hold down the pedal.

1. Remove the shift-lock override cover with a screwdriver.
2. Insert a screwdriver and push it down.




3. Move the shift lever.

4. Take the vehicle to an Authorized Mazda Dealer to have the system checked.

## ▼ Manual Shift Mode

This mode gives you the feel of driving a manual transaxle vehicle by tapping the shift lever forward and back while in this mode.

To change to manual shift mode, shift the lever from D to M.



To return to automatic shift mode, shift the lever from M to D.

### NOTE

- If you change to manual shift mode when the vehicle is stopped, the gear will shift to M1.
- If you tap the shift lever back when the vehicle is stopped and the gear is at M1, the gear will shift to M2. M2 is helpful for starting on slippery surfaces.

## Starting and Driving


### ▼ Indicators

#### Shift position indicator

In manual shift mode, the "M" of the shift position indicator in the instrument panel illuminates.

#### Gear position indicator

In manual shift mode, the numeral for the selected gear illuminates below the shift position indicator.



#### **NOTE**


If the gears cannot be shifted down when driving at higher speeds, the shift position and gear position indicators will flash twice to signal that the gears cannot be shifted down (page 5-17).

### ▼ Shifting

#### Shifting up

(M1→M2→M3→M4)

To shift up to a higher gear, tap the shift lever back (+) once.



#### **NOTE**


- When driving slowly, the gears may not shift up depending on vehicle speed (page 5-17).
- In manual shift mode, gears do not shift up automatically. Don't run the engine with the tachometer needle in the RED ZONE. If the tachometer needle enters the RED ZONE, you may feel engine-braking because the fuel delivery will be stopped to protect the engine. However, this does not indicate an abnormality.
- Gears may not be shifted from M1 to M2 right after shifting the lever from D to M. Wait a few seconds and then shift up to M2.

# Starting and Driving

## Shifting down

(M4→M3→M2→M1)

To shift down to a lower gear, tap the shift lever forward (–) once.



## **WARNING**

### **Sudden Engine-Braking:**

*Shifting down while driving on wet, snowy, or frozen roads, or driving at high speeds causes sudden engine braking, which is dangerous. The sudden change in tire speed could cause the tires to skid. This could lead to loss of vehicle control and an accident. Do not cause sudden engine braking on slippery road surfaces or at high speeds.*

## **NOTE**

- When driving at high speeds, the gear may not shift down depending on vehicle speed (page 5-17).
- During deceleration, the gear may automatically shift down depending on vehicle speed (page 5-17).

## ▼ **Shifting Specification**

### **Shifting up**

If the vehicle speed is lower than the speed specified for each gear, the gear cannot be shifted up to a higher gear.

| Gear  | Vehicle speed                                                    |
|-------|------------------------------------------------------------------|
| M1→M2 | You can shift up to M2 whether the vehicle is stopped or moving. |
| M2→M3 | 20 km/h (12 mph)                                                 |
| M3→M4 | 38 km/h (24 mph)                                                 |

### **Shifting down**

If the vehicle speed is higher than the speed specified for each gear, the gear cannot be shifted down to a lower gear.

| Gear  | Vehicle speed      |
|-------|--------------------|
| M4→M3 | 161 km/h (100 mph) |
| M3→M2 | 100 km/h (62 mph)  |
| M2→M1 | 45 km/h (28 mph)   |

During deceleration, the gears shift down automatically when speed is reduced to the following:

| Gear        | Vehicle speed    |
|-------------|------------------|
| M4→M3       | 36 km/h (22 mph) |
| M3 or M2→M1 | 9 km/h (6 mph)   |

# Starting and Driving

---

## ▼ Recommendations for Shifting

### Upshifting

For normal acceleration and cruising, we recommend these shift points.

|          |                  |
|----------|------------------|
| M1 to M2 | 24 km/h (15 mph) |
| M2 to M3 | 40 km/h (25 mph) |
| M3 to M4 | 65 km/h (40 mph) |

### Downshifting

When you must slow down in heavy traffic or on a steep **upgrade**, downshift before the engine starts to overwork. This gives better acceleration when you need more speed.

On a steep **downgrade**, downshifting helps maintain safe speed and prolongs brake life.

## ▼ Driving Tips

### Passing

For extra power when passing another vehicle or climbing steep grades, depress the accelerator fully (D range). The transaxle will shift to a lower gear, depending on vehicle speed.

### Climbing steep grades from a stop

To climb a steep grade from a stopped position:

1. Depress the brake pedal.
2. Shift to D or M1, depending on the load weight and grade steepness.
3. Release all brakes while gradually accelerating.

### Descending steep grades

When descending a steep grade, shift to lower gears, depending on load weight and grade steepness. Descend slowly, using the brakes only occasionally to prevent them from overheating.

# Starting and Driving

## Power Steering

Power steering is only operable when the engine is running. If the engine is off or if the power steering system is inoperable, you can still steer, but it requires more physical effort.

If the steering feels rigid during normal driving, consult an Authorized Mazda Dealer.

### CAUTION

Never hold the steering wheel to the extreme left or right for more than five seconds with the engine running. This could damage the power steering system.

## Cruise Control

With cruise control, you can set and automatically maintain any speed of more than about 40 km/h (25 mph).

### WARNING

#### **Cruise Control Use:**

*Using cruise control in the following conditions could cause you to lose control of the vehicle:*

- *Heavy or unsteady traffic*
- *Slippery or winding roads*
- *Similar restrictions that require inconsistent speed*

*Don't use cruise control in these situations.*

### ▼ Cruise Set Indicator Light

# CRUISE


This light comes on when a cruising speed is set.

## Starting and Driving

### ▼ Activation/Deactivation

To activate the system, press the cruise main switch.

To deactivate the system, press the switch again.




### WARNING

#### **Cruise Main Switch:**

***Leaving the cruise main switch on when not using the cruise control is dangerous as it may be switched on accidentally. This could result in loss of vehicle control. Keep the cruise main switch off when cruise control is not in use.***

### ▼ To Set Speed

1. Activate the cruise control system.
2. Accelerate to the desired speed, which must be more than 40 km/h (25 mph).
3. Press the SET/COAST button and release it at the speed you want. Release the accelerator at the same time.



Don't continue to hold in the button. Until you release it, speed will continue to drop (unless you continue to accelerate) and you'll miss the desired speed.

### NOTE


- The SET function can't be activated until about 2 seconds after the cruise main switch has been engaged.
- On a steep grade, the vehicle may momentarily slow down going up or speed up while going down.

# Starting and Driving

## ▼ To Increase Cruising Speed


Follow either of these procedures.

- Press the RESUME/ACCEL button and hold it. Your vehicle will accelerate.  
Release the button at the speed you want.



Your vehicle has a tap-up feature that allows you to increase your current speed in increments of 1.6 km/h (1 mph) by a momentary tap of the RESUME/ACCEL button. Multiple taps will increase your vehicle speed 1.6 km/h (1 mph) for each tap.

- Accelerate to the desired speed. Press the SET/COAST button and release it immediately.




## NOTE

Accelerate if you want to speed up temporarily when the cruise control is on. Greater speed will not interfere with it or change the set speed. Take your foot off the accelerator to return to the set speed.

## ▼ To Decrease Cruising Speed

Press the SET/COAST button and hold it. The vehicle will gradually slow. Release the button at the speed you want.




Your vehicle has a tap-down feature that allows you to decrease your current speed in decrements of 1.6 km/h (1 mph) by a momentary tap of the SET/COAST button. Multiple taps will decrease your vehicle speed 1.6 km/h (1 mph) for each tap.

## Starting and Driving

### ▼ To Resume Cruising Speed at More Than 40 km/h (25 mph)

If some other method besides the cruise main switch was used to cancel cruising speed and the system is still activated, the most recent set speed will automatically resume when the RESUME/ACCEL button is pressed.


If vehicle speed is below 40 km/h (25 mph), increase the vehicle speed up to 40 km/h (25 mph) and press the RESUME/ACCEL button.



### ▼ To Cancel

To turn off the system, use **one** of these methods:

- Press the cruise main switch.
- Slightly depress the brake pedal.
- Press the CANCEL button.



- **(Manual transaxle)**  
Depress the clutch pedal.

The system is off when the ignition is off.


#### NOTE

Cruise control will cancel at about 15 km/h (9 mph) below the preset speed or below 40 km/h (25 mph).


# Instrument Cluster and Indicators

## Meters and Gauges

### With tachometer



### Without tachometer



|                                         |      |
|-----------------------------------------|------|
| ① Speedometer .....                     | 5-24 |
| ② Odometer and Trip Meter .....         | 5-24 |
| ③ Tachometer .....                      | 5-25 |
| ④ Engine Coolant Temperature Gauge..... | 5-25 |
| ⑤ Fuel Gauge.....                       | 5-26 |



# Instrument Cluster and Indicators

## ▼ Speedometer

The speedometer indicates the speed of the vehicle.

## ▼ Odometer and Trip Meter

The display mode can be changed from odometer to trip meter A to trip meter B and then back to odometer by pressing the selector while they are displayed. The selected mode will be displayed.



### NOTE

The odometer and trip meter can be displayed as follows even when the ignition switch is in the ACC or LOCK position:

- Displays for about 10 minutes after the ignition switch is turned to the ACC or LOCK position from the ON position.
- Displays for about 10 minutes after any door is opened.

### (Sport AT model)

The headlight switch must be in the  or  position to see the odometer and trip meter display when the ignition switch is in the LOCK position.

## Odometer

When this mode is selected, ODO will be displayed.

The odometer records the total distance the vehicle has been driven.

## Trip meter

The trip meter can record the total distance of two trips. One is recorded in trip meter A, and the other is recorded in trip meter B.

For instance, trip meter A can record the distance from the point of origin, and trip meter B can record the distance from where the fuel tank is filled.

When trip meter A is selected, pressing the selector again within one second will change to trip meter B mode.

## Instrument Cluster and Indicators

When trip meter A is selected, TRIP A will be displayed. When trip meter B is selected, TRIP B will be displayed.


The trip meter records the total distance the vehicle is driven until the meter is again reset. Return it to "0.0" by holding the selector depressed for more than 1 second. Use this meter to measure trip distances and to compute fuel consumption.

### NOTE

- Only the trip meters record tenths of kilometers (miles).
- The trip record will be erased when;
  - The power supply is interrupted (blown fuse or the battery is disconnected).
  - The vehicle is driven over 999.9 km (mile).

### ▼ Tachometer

The tachometer shows engine speed in thousands of revolutions per minute (rpm).




### ⚠ CAUTION

Don't run the engine with the tachometer needle in the RED ZONE. This may cause severe engine damage.

### ▼ Engine Coolant Temperature Gauge

The engine coolant temperature gauge shows the temperature of the engine coolant.



If the needle exceeds normal range toward H, it indicates overheating.

### ⚠ CAUTION


Driving with an overheated engine can cause serious engine damage (page 7-14).

## Instrument Cluster and Indicators

---


### ▼ Fuel Gauge

The fuel gauge shows approximately how much fuel is in the tank. We recommend keeping the tank over 1/4 full. When the low fuel warning light illuminates or when the needle is near E, refuel as soon as possible.




### ▼ Dashboard Illumination

When the headlight switch is in the  or  position, rotate the thumb-wheel to adjust the brightness of the dashboard lights.



# Warning/Indicator Lights and Beeps

## Warning/Indicator Lights



Warning/Indicator lights will appear in any of the highlighted areas

| Signal                                                                              | Warning/Indicator Lights                                  | Page |
|-------------------------------------------------------------------------------------|-----------------------------------------------------------|------|
|   | Brake System Warning Light                                | 5-29 |
|  | Charging System Warning Light                             | 5-30 |
|  | Engine Oil Pressure Warning Light                         | 5-31 |
|  | Check Engine Light                                        | 5-31 |
|  | ABS Warning Light                                         | 5-32 |
|  | Air Bag/Front Seat Belt Pretensioner System Warning Light | 5-32 |
|  | Low Fuel Warning Light                                    | 5-33 |

# Warning/Indicator Lights and Beeps

---

| Signal                                                                           | Warning/Indicator Lights             | Page |
|----------------------------------------------------------------------------------|--------------------------------------|------|
|  | Seat Belt Warning Light              | 5-33 |
|  | Door-Ajar Warning Light              | 5-33 |
|  | Low Washer Fluid Level Warning Light | 5-33 |
| <b>AT</b>                                                                        | Automatic Transaxle Warning Light    | 5-33 |
|  | Headlight High-Beam Indicator Light  | 5-34 |
| <b>O/D<br/>OFF</b>                                                               | O/D OFF Indicator Light              | 5-34 |
| <b><i>PRNDM</i></b>                                                              | Shift Position Indicator Light       | 5-34 |
| <b>CRUISE</b>                                                                    | Cruise Set Indicator Light           | 5-35 |

## Warning/Indicator Lights and Beeps

### ▼ Brake System Warning Light



This warning has the following functions:

#### **Parking brake warning**

The light comes on when the parking brake is applied with the ignition switch in the START or ON position. It goes off when the parking brake is fully released.

#### **Low brake fluid level warning/ Electronic brake force distribution system warning**

If the light stays on after the parking brake is fully released, you may have a brake problem.

Drive to the side of the road and park off the right-of-way.

#### **Low brake fluid level warning**

You may notice that the pedal is harder to push or that it may go closer to the floor. In either case, it will take longer to stop the vehicle.

1. With the engine stopped, check the brake fluid level immediately and add fluid as required (page 8-18).
2. After adding fluid, check the light again.

If the warning light remains on, or if the brakes do not operate properly, do not drive the vehicle. Have it towed to an Authorized Mazda Dealer.

Even if the light goes off, have your brake system inspected as soon as possible.

#### **Electronic brake force distribution system warning**

If the electronic brake force distribution control unit determines that some components are operating incorrectly, the control unit may turn the brake system warning light on.

In this case, the ABS warning light comes on at the same time (page 5-32).

## Warning/Indicator Lights and Beeps

---

### **WARNING**

#### **Brake Warning Light:**

*Driving with the brake system warning light on is dangerous. It indicates that your brakes may not work at all or that they could completely fail at any time. If this light remains on, have the brakes inspected immediately. Don't drive with this light on, and contact an Authorized Mazda Dealer to have the brakes inspected as soon as possible.*

#### **ABS Warning Light and Brake Warning Light on at the Same Time:**

*Driving when the brake system warning light and ABS warning light are on at the same time is dangerous. When both lights are on, the rear wheels could lock more quickly in an emergency stop than under normal circumstances.*

*Don't drive with both lights on, and contact an Authorized Mazda Dealer to have the brakes inspected as soon as possible.*

### ▼ **Charging System Warning Light**



This warning light comes on when the ignition switch is turned to the ON position and goes off when the engine is started.

If the warning light comes on while driving, it indicates a malfunction of the alternator or of the charging system. Drive to the side of the road and park off the right-of-way. Consult an Authorized Mazda Dealer.

### **CAUTION**

Don't continue driving when the charging system warning light is illuminated.

# Warning/Indicator Lights and Beeps

## ▼ Engine Oil Pressure Warning Light



This warning light indicates low engine oil pressure.

If the light comes on while driving:


1. Drive to the side of the road and park off the right-of-way.
2. Turn off the engine and inspect the engine oil level (page 8-13). If it's low, add oil.
3. Check the light.

If the light remains on even after you add oil, have your vehicle towed to the nearest service station or to an Authorized Mazda Dealer.

### CAUTION

Don't run the engine if oil pressure is low. It could result in extensive engine damage.

## ▼ Check Engine Light



If this light comes on while driving, the vehicle may have a problem. It is important to note the driving conditions when the light came on and consult an Authorized Mazda Dealer.

The check engine light may come on in the following cases:

- The fuel tank level being very low or approaching empty.
- The engine's electrical system has a problem.
- The emission control system has a problem.
- The fuel-filler cap is missing or not tightened securely.

If the check engine light flashes continuously, decrease your speed and consult an Authorized Mazda Dealer as soon as possible.

## Warning/Indicator Lights and Beeps

### ▼ ABS Warning Light



The warning light stays on for a few seconds when the ignition switch is turned to the ON position.

If the ABS warning light stays on while you're driving, the ABS control unit has detected a system malfunction. If this occurs, your brakes will function normally as if the vehicle had no ABS. Should this happen, consult an Authorized Mazda Dealer as soon as possible.

### **WARNING**

**ABS Warning Light and Brake Warning Light on at the Same Time:**  
*Driving when the brake system warning light and ABS warning light are on at the same time is dangerous. When both lights are on, the rear wheels could lock more quickly in an emergency stop than under normal circumstances.  
Don't drive with both lights on, and contact an Authorized Mazda Dealer to have the brakes inspected as soon as possible.*

### NOTE

When the engine is jump-started to charge the battery, uneven rpm occurs and the ABS warning light comes on. This is due to a weak battery, not a malfunction.  
Recharge the battery.

### ▼ Air Bag/Front Seat Belt Pretensioner System Warning Light



If the air bag/front seat belt pretensioner system is OK, the warning light comes on when the ignition switch is turned to the ON position or after the engine is cranked. After about 6 seconds it goes out.

A system malfunction is indicated when the warning light constantly flashes, stays on or doesn't come on at all. If any of these occur, consult an Authorized Mazda Dealer as soon as possible. The system may not work in an accident.

# Warning/Indicator Lights and Beeps

## **WARNING**

### Self-Servicing the Air Bag/ Pretensioner Systems:

*Self-servicing or tampering with the systems is dangerous. An air bag/pretensioner could accidentally activate or become disabled. This could cause serious injuries. Never tamper with the systems and always have an Authorized Mazda Dealer perform all servicing and repairs.*

### ▼ Low Fuel Warning Light



This warning light in the fuel gauge signals that the fuel tank will soon be empty.

Get fuel as soon as possible.

### ▼ Seat Belt Warning Light



If the driver's seat belt is not fastened when the ignition switch is turned to the ON position, the seat belt warning light will remain on until the belt is fastened. If the system does not operate correctly, consult an Authorized Mazda Dealer.

### ▼ Door-Ajar Warning Light



This warning light comes on when any door isn't securely closed.

### ▼ Low Washer Fluid Level Warning Light



This warning light reveals that little windshield washer fluid remains. Add fluid (page 8-22).

### ▼ Automatic Transaxle Warning Light

# AT

This warning light stays on for a few seconds when the ignition switch is turned to the ON position. The light flashes when the transaxle has a problem.

## Warning/Indicator Lights and Beeps

### CAUTION

If the automatic transaxle warning light flashes, the transaxle has an electrical problem. Continuing to drive your Mazda in this condition could cause damage to your transaxle. Consult an Authorized Mazda Dealer as soon as possible.

### ▼ Headlight High-Beam Indicator Light



This light indicates one of two things:

- The high-beam headlights are on.
- The turn signal lever is in the flash-to-pass position.

### ▼ O/D OFF Indicator Light



This light comes on when the overdrive has been turned off.

### CAUTION

If the overdrive-off indicator light flashes, the transaxle has an electrical problem. Continuing to drive your Mazda in this condition could cause damage to your transaxle. Consult an Authorized Mazda Dealer as soon as possible.

### ▼ Shift Position Indicator Light

This indicates the selected shift position when the ignition switch is in the ACC or ON position.



Gear position indicator

In manual mode, the "M" of the shift position indicator illuminates and the numeral for the selected gear illuminates in the gear position indicator.

## Warning/Indicator Lights and Beeps

---

### ▼ Cruise Set Indicator Light

# CRUISE

This light comes on when a cruising speed is set.

## Beeps

### ▼ Seat Belt Warning Beep

If the driver's seat belt is not fastened when the ignition switch is turned to the ON position, a beep will sound for about 6 seconds.

### ▼ Ignition Key Reminder


If the ignition switch is in the LOCK or ACC position, a beep will sound when any door is opened.

### ▼ Lights-On Reminder

If lights are on and the key is removed from the ignition switch, a beep will sound when any door is opened.

# Switches and Controls

## Lighting Control



### ▼ Headlights

To turn on the lights, turn the knob on the end of the control lever.

| Lever Position     | OFF |     |    |
|--------------------|-----|-----|----|
| Headlights         | Off | Off | On |
| Taillights         |     |     |    |
| Parking lights     |     |     |    |
| License lights     | Off | On  | On |
| Side-marker lights |     |     |    |

### NOTE


To prevent discharging the battery, don't leave the lights on while the engine is off.

### ▼ Lights-On Reminder

If lights are on and the key is removed from the ignition switch, a beep will sound when any door is opened.


### ▼ Headlight High-Low Beams

Push the lever forward for high beams. Pull it back for low.



### ▼ Flashing the Headlights

To flash the headlights, pull the lever fully toward you. The headlight switch need not be on, and the lever will return to the normal position when released.




## Switches and Controls

### Turn and Lane-Change Signals

#### ▼ Turn Signal

Move the signal lever down (for a left turn) or up (for a right turn) to the stop position. The signal will self-cancel after the turn is completed.

If the indicator light continues to flash after a turn, manually return the lever to its original position.



Green indicators on the dashboard show which signal is working.

#### Lane-change signals


Move the lever slightly toward the direction of the change—until the indicator flashes—and hold it there. It will return to the off position when released.

#### NOTE

If an indicator light stays on without flashing or if it flashes abnormally, the turn signal bulb may be burned out.

### Fog Lights

Use this switch to turn on the fog lights. They help you to see as well as to be seen.



To turn on the fog lights, first turn on the headlight switch. Then press the fog light switch.

To turn the fog lights off, press the fog light switch again or turn the headlight switch off.

## Switches and Controls

---

### Daytime Running Lights

In Canada, vehicles must be driven with the headlights on during daytime operation.

For that reason, the daytime running lights automatically turn on when the ignition switch is turned to the ON position.

#### NOTE

The running lights go off when the parking brake is applied.

### Windshield Wipers and Washer

The ignition switch must be in the ON position.

#### **WARNING**

##### **Frozen Washer Fluid:**

*Using windshield washer fluid in freezing temperatures is dangerous. The washer fluid could freeze on the windshield and block your vision. You could have an accident. Don't use the washer without first warming the windshield.*

#### NOTE


Because heavy ice and snow can jam the wiper blades, the wiper motor is protected by a circuit breaker. This mechanism will automatically stop operation of the blades, but only for about 5 minutes.

If this happens, turn off the wiper switch and park off the right-of-way, and remove the snow and ice.

After 5 minutes, turn on the switch and the blades should operate normally. If they don't resume functioning, consult an Authorized Mazda Dealer as soon as possible.

## Switches and Controls

### ▼ Windshield Wipers



Turn the wipers on by pulling the lever down.


**INT** — Intermittent

**1** — Normal

**2** — Fast


#### One-touch wipers

For a single wiping cycle, push the lever up to **MIST**.



### ▼ Windshield Washer

Pull the lever toward you and hold it to spray washer fluid.



#### **NOTE**

In the OFF or INT position, the wipers will be activated until the lever is released.


If the washer doesn't work, inspect the fluid level (page 8-22). If it's OK, consult an Authorized Mazda Dealer.

## Switches and Controls

### Rear Window Wiper and Washer (Hatchback)

The ignition switch must be in the ON position.

#### ▼ Rear Window Wiper



Turn the wiper on by turning the knob.

**ON** — Normal

**INT** — Intermittent

#### ▼ Rear Window Washer

To spray washer fluid, turn the knob to the  position. After the knob is released, the washer will stop.

#### NOTE

There are two washer positions: up and down. In the down washer position, the wiper will not be activated.

If the washer doesn't work, inspect the fluid level (page 8-22). If it's OK and the washer still doesn't work, consult an Authorized Mazda Dealer.


### Rear Window Defroster

The rear defroster clears frost, fog, and thin ice from the rear window.

The ignition switch must be in the ON position.

Push the switch to turn on the rear window defroster; the indicator light will come on.

Push the switch again to turn it off.



#### ⚠ CAUTION

Don't use sharp instruments or window cleaners with abrasives to clean the inside of the rear window surface. They may damage the defroster grid inside the window.

#### NOTE

This defroster is not designed for melting snow. If there is an accumulation of snow on the rear window, brush it off before using the defroster.

## Switches and Controls

### Horn

To sound the horn, press around the  mark of the steering wheel.

### Hazard Warning Flasher

The hazard warning lights should always be used when you stop on or near a roadway.

The hazard warning lights warn other drivers that your vehicle is a traffic hazard and that they must take extreme caution when near it.



Depress the hazard warning switch and all four turn signals will flash at once.

#### NOTE

- The turn signals don't work when the hazard warning lights are on.
- Check local regulations about the use of hazard warning lights while the vehicle is being towed. They may forbid it.



Use of various features for drive comfort, including climate control and audio system.

|                                           |      |
|-------------------------------------------|------|
| <b>Climate Control System</b> .....       | 6-2  |
| Operating Tips .....                      | 6-2  |
| Vent Operation .....                      | 6-3  |
| Manual Type .....                         | 6-5  |
| <b>Audio System</b> .....                 | 6-10 |
| Audio System for MAZDASPEED Protégé ..... | 6-10 |
| Antenna .....                             | 6-10 |
| Operating Tips for Audio System .....     | 6-11 |
| Audio Set .....                           | 6-17 |
| Safety Certification .....                | 6-34 |
| <b>Interior Equipment</b> .....           | 6-35 |
| Sunvisors .....                           | 6-35 |
| Interior Lights .....                     | 6-35 |
| Lighter .....                             | 6-37 |
| Ashtray .....                             | 6-38 |
| Cup Holder .....                          | 6-38 |
| Storage Compartments .....                | 6-39 |

## Climate Control System

---

### Operating Tips

#### ▼ Operating the Climate Control System

Operate the climate control system with the engine running.

#### ▼ Clearing the Air Inlet

Clear all obstructions like leaves, snow and ice from the hood and the air inlet in the cowl grille to improve the system efficiency.

#### ▼ Foggy Windows

The windows may fog up easily in humid weather. Use the climate control system to defog the windows.

To help defog the windows, operate the air conditioner to dehumidify the air.

#### ▼ Outside/Recirculated Air Position

Use the outside air position in normal conditions. The recirculated air position can be used temporarily when driving on dusty roads or for quick cooling of the interior.

#### ▼ Parking in Direct Sunlight

If the vehicle has been parked in direct sunlight during hot weather, open the windows to let warm air escape, then run the climate control system.

#### ▼ Not Using for a Long Period


Run the air conditioner at least once a month to keep internal parts lubricated.

#### ▼ Check the Refrigerant before Weather Gets Hot

Have the air conditioner checked before the weather gets hot. Lack of refrigerant may make the air conditioner less efficient. Consult an Authorized Mazda Dealer for refrigerant inspection.

The optional air conditioner is filled with HFC134a (R134a), a refrigerant that will not damage the ozone layer. If the air conditioner is low on refrigerant or has a malfunction, consult an Authorized Mazda Dealer.

## Vent Operation



\* Depending on the model some vents may not be available.

### ▼ Adjusting the Vents

#### Directing airflow

You can direct air flow by moving the adjustment knob.

#### Adjusting the amount of airflow


These vents can be opened and closed with wheel.

#### **NOTE**


When using the air conditioner, mist may come out from the vents. This is not a sign of trouble but a result of humid air being suddenly cooled.

▼ Selecting the Airflow Mode


**Dashboard Vents**




**Defroster and Floor Vents**




**Dashboard and Floor Vents**



**Defroster Vents**




**Floor Vents**




# Climate Control System

## Manual Type




### ▼ Control Switches

#### Temperature control dial



This dial controls temperature. Turn it clockwise for hot and counterclockwise for cold.

#### Fan control dial



This dial allows variable fan speeds.

0—Fan off

1—Low speed


2—Medium low speed

3—Medium high speed

4—High speed

# Climate Control System

## Mode selector dial



Turn the mode selector dial to select airflow mode (page 6-4).

## A/C switch




Push the switch to turn the air conditioner on. An indicator light on the switch will illuminate when the fan control dial is on.

Push the switch once again to turn the air conditioner off.

### NOTE

The air conditioner may not function when the outside temperature approaches 0 °C (32 °F).

## Air intake selector



This switch controls the source of air entering the vehicle.

Press the switch to alternate between the  and  positions. The indicator light for the selected mode will illuminate.

It is recommended that under normal conditions the switch be kept in the outside air position.

## Outside air position ( )

Outside air is taken into the vehicle. Use this position for normal ventilation and heating.

# Climate Control System

## Recirculated air position ( )

Outside air is shut off. Air within the vehicle is recirculated.


This position can be used when driving on a dusty road or in similar conditions. It also helps to provide quicker cooling of the interior.

### **WARNING**

#### **The Recirculated Air Position:**

*Using the  position in cold or rainy weather will cause the glass to fog up. Your vision will be hampered, which could lead to a serious accident. Do not use the  position in cold or rainy weather.*

## ▼ Heating




1. Set the mode selector dial to the  position.
2. Set the temperature control dial to the hot position.
3. Set the fan control dial to the desired speed.

## NOTE

- If the windshield fogs up easily, set the mode selector dial to the  position.
- If cooler air is desired at face level, set the mode selector dial at the  position and adjust the temperature control dial to maintain maximum comfort.
- The air to the floor is warmer than air to the face (except when the temperature control dial is set at the extreme hot or cold position).
- In the  position, the outside air is automatically selected.

## ▼ Cooling (With Air Conditioner)



1. Set the mode selector dial to the  position.
2. Set the temperature control dial to the desired position.
3. Set the fan control dial to the desired speed.
4. Turn on the air conditioner.

# Climate Control System

- Adjust the fan control dial and temperature control dial to maintain maximum comfort.

## ⚠ CAUTION


When using the air conditioner while driving up long hills or in heavy traffic, closely monitor the temperature gauge (page 5-25).

The air conditioner may cause engine overheating. If the gauge indicates overheating, turn the air conditioner off.

## NOTE


- When maximum cooling is desired, set the temperature control dial to the extreme cold position and set the air intake selector to the  position, then set the fan control dial to the position 4.
- If warmer air is desired at floor level, set the mode selector dial at the  position and adjust the temperature control dial to maintain maximum comfort.
- The air to the floor is warmer than air to the face (except when the temperature control dial is set at the extreme hot or cold position).

## ▼ Ventilation



- Set the mode selector dial to the  position.
- Set the air intake selector to the  position.
- Set the temperature control dial to the desired position.
- Set the fan control dial to the desired speed.

## ▼ Windshield Defrosting and Defogging



- Set the mode selector dial to the  position.
- Set the temperature control dial to the desired position.

# Climate Control System

- Set the fan control dial to the desired speed.

## ⚠ WARNING


### ***Foggy Windshield:***

*Using the ☼ position with the temperature control set to the cold position will cause the outside of the glass to fog up. Your vision will be hampered, which could lead to a serious accident. Set the temperature control to the hot or warm position when using the ☼ position.*

## NOTE

- For maximum defrosting, set the temperature control dial to the extreme hot position and the fan control dial to position 4.
- If warm air is desired at the floor, set the mode selector dial to the ☼ position.
- In the ☼ or ☼ position, outside air is automatically selected. The air intake selector cannot be changed to the 🚗 position.

## ▼ Dehumidifying (With Air Conditioner)



Operate the air conditioner in cool or cold weather to help defog the windshield and side windows.

- Set the mode selector dial to the desired position.
- Set the air intake selector to the 🚗 position.
- Set the temperature control dial to the desired position.
- Set the fan control dial to the desired speed.
- Turn on the air conditioner.

## Audio System

### Audio System for MAZDASPEED Protégé

Your MAZDASPEED Protégé is upgraded with a high-performance audio system from Kenwood Car Audio. This system features a special head unit capable of playing back an MP3 encoded compact disc. In addition, the system is equipped with a dedicated amplifier to power the trunk-mounted subwoofer. Please refer to additional reference guides supplied by Kenwood regarding the operation of this audio system.

#### ▼ Rear Window Antenna

The rear window antenna receives both AM and FM signals.


#### ⚠ CAUTION

When washing the inside rear window, use a soft cloth dampened in lukewarm water, gently wiping the antenna lines. Use of glass cleaning products could damage the antenna.

### Antenna

#### ▼ Manual Type

The manual antenna must be raised and lowered by hand.




#### ⚠ CAUTION

To prevent from damaging the antenna, retract it before entering a car wash facility or passing beneath a low overhead clearance.

#### ▼ Detachable Type

To remove the antenna, turn it counterclockwise.  
To install the antenna, turn it clockwise.  
Make sure the antenna is security installed.



**⚠ CAUTION**


To prevent damage to the antenna, remove it before entering a car wash facility or passing beneath a low overhead clearance.

**NOTE**


When leaving your vehicle unattended, we recommend that you remove the antenna and store it inside the vehicle.

**Operating Tips for Audio System****▼ Radio Reception****AM characteristics**

AM signals bend around such things as buildings or mountains and bounce off the ionosphere. Therefore, they can reach longer distances than FM signals. Because of this, two stations may sometimes be picked up on the same frequency at the same time.


**FM characteristics**

An FM broadcast range is usually about 40—50 km (25—30 miles) from the source. Because of extra coding needed to break the sound into two channels, stereo FM has even less range than monaural (non-stereo) FM.



# Audio System


Signals from an FM transmitter are similar to beams of light because they do not bend around corners, but they do reflect. Unlike AM signals, FM signals cannot travel beyond the horizon. Therefore, FM stations cannot be received at the great distances possible with AM reception.



Atmospheric conditions can also affect FM reception. High humidity will cause poor reception. However, cloudy days may provide better reception than clear days.


## Multipath noise

Since FM signals can be reflected by obstructions, it is possible to receive both the direct signal and the reflected signal at the same time. This causes a slight delay in reception and may be heard as a broken sound or a distortion. This problem may also be encountered when in close proximity to the transmitter.




## Flutter/Skip noise

Signals from an FM transmitter move in straight lines and become weak in valleys between tall buildings, mountains, and other obstacles. When a vehicle passes through such an area, the reception conditions may change suddenly, resulting in annoying noise.




## Weak signal noise

In suburban areas, broadcast signals become weak because of distance from the transmitter. Reception in such fringe areas is characterized by sound breakup.




**Strong signal noise**

This occurs very close to a transmitter tower. The broadcast signals are extremely strong, so the result is noise and sound breakup at the radio receiver.

**Station drift noise**

When a vehicle reaches the area of two strong stations broadcasting at similar frequencies, the original station may be temporarily lost and the second station picked up. At this time there will be some noise from this disturbance.

**▼ Operating Tips for Cassette Tape Player****Cleaning the cassette tape player**


The tape head, capstans, and pinch rollers will gather oxide residue from cassette tapes. This can cause weak or wavering sounds and damage to the cassette tapes and player. Use a good quality head-cleaning tape or a liquid cleaner cassette tape to remove it.

Should the unit not operate normally, consult an Authorized Mazda Dealer. Never attempt to repair it or insert a screwdriver or anything else.


**Handling the cassette tape player**

The following precautions should be observed.

- Do not spill any liquid on the audio system.




- Do not insert any objects, other than cassette tape, into the slot.



## Audio System

---

- If the cassette tape is loose, it may produce poor sound or performance during playback. Use a pencil or something similar to remove any slack.




- Only cassette tapes that play no longer than 90 minutes should be used. Cassette tape exceeding 90 minutes are thin and may easily break.
- Do not leave a cassette tape in the tape player slot when not in use. Remove it completely to permit the slot door to close and to protect the mechanism from dust.
- Store cassette tapes away from extreme heat, magnetic fields, and direct sunlight. Protect the exposed cassette tape from dirt and damage. Store cassette tapes in their original cases or other protective cases.
- Insert only cassette tapes into the slot. If objects other than cassette tapes are inserted, they may damage the player.

### ▼ Operating Tips for Mini Disc (MD) Player


- The MD player has been designed to play MDs bearing the identification logo as shown. No other MDs can be played.



- When inserting the MD, make sure the MD label is facing up, and the MD is oriented to the insertion slot in the direction of the arrow. If not inserted correctly, the MD will be ejected, or may remain stuck in the MD deck.



- Do not touch the internal part of the MD. If the MD shutter is slid open for no reason, it may be broken.



- Store MDs in their cases and away from direct sunlight.
- Do not insert fingers or foreign objects in the MD insertion slot as it could damage the MD deck.

### ▼ Operating Tips for CD Player/In-Dash CD Changer


#### Condensation phenomenon

Immediately after turning on the heater when the vehicle is cold, the CD or optical components (prism and lens) in the CD player/changer may become clouded with condensation. At this time, the CD will eject immediately when placed in the unit. A clouded CD can be corrected simply by wiping it with a soft cloth. Clouded optical components will clear naturally in about an hour. Wait for normal operation to return before attempting to use the unit.


#### Handling the CD player/In-dash CD changer

The following precautions should be observed.


- Do not spill any liquid on the audio system.




- Do not insert any objects, other than CDs, into the slot.



- The CD revolves at high speed within the unit. Defective (cracked or badly bent) CDs should never be used.




- Do not use non-conventional discs such as heart-shaped, octagonal discs, etc. The CD player/changer could be damaged.




## Audio System

- A new CD may have rough edges on its inner and outer perimeters. If a disc with rough edges is used, proper setting will not be possible and the CD player/changer will not play the CD. Remove the rough edges in advance by using a ball-point pen or pencil as shown below. To remove the rough edges, rub the side of the pen or pencil against the inner and outer perimeter of the CD.




- When driving over uneven surfaces, the sound will jump.



- The CD player/changer has been designed to play CDs bearing the identification logo as shown. No other discs can be played.



- Be sure never to touch the signal surface when handling the CDs. Pick up a CD by grasping the outer edge or the edge of the hole and the outer edge.



- Do not stick paper or tape on the CD. Avoid scratching the reverse side (the side without a label).
- Dust, finger smudges, and dirt can decrease the amount of light reflected from the signal surface, thus affecting sound quality. If the CD should become soiled, gently wipe it with a soft cloth from the center of the CD to the edge.
- Do not use record sprays, antistatic agents, or household spray cleaners. Volatile chemicals such as benzine and thinner can also damage the surface of the CD and must not be used. Anything that can damage, warp, or fog plastic should never be used to clean CDs.
- CDs, like traditional audio records, are made of plastic. To avoid warping, keep the CDs in their cases and do not store them where they will be exposed to direct sunlight.
- The CD player/changer ejects the CD if the CD is inserted upside down. Also dirty and/or defective CDs may be ejected.
- 8 cm (3 in) CDs and CD accessories (e.g. 8 cm disc adapter) cannot be used in the CD player/changer.
- Do not insert cleaning discs in the CD player/changer.
- Do not insert any disc with a peel-off or seal on it.

**Audio Set**




Illustration is of a representative audio unit.

Power/Volume/Sound Controls .....6-18

Clock .....6-20

Operating the Radio .....6-22

Operating the Cassette Tape Player .....6-24

Operating the Mini Disc (MD) Player .....6-26


Operating the Compact Disc (CD) Player .....6-28

Operating the In-Dash CD Changer .....6-30

Error Indications .....6-33

# Audio System

## ▼ Power/Volume/Sound Controls



### Power ON/OFF

Turn the ignition switch to the ACC or ON position.

Press the power/volume knob to turn the audio system on.

Press the power/volume knob again to turn the audio system off.

#### NOTE

To prevent the battery from being discharged, do not leave the audio system on for a long period when the engine is not running.


### Volume adjustment

To adjust the volume, turn the power/volume knob.

Turn the power/volume knob to the right to increase volume, to the left to decrease it.

**Audio sound adjustment**

1. Press the audio control knob to select bass, mid-range, treble, fade or balance control. The selected function will be indicated.



\* If your vehicle is not equipped with rear speakers, adjust the power/volume knob so level is even.

2. Turn the audio control knob to adjust the selected functions as follows:


| Indication  | Turn Left                    | Turn Right                   |
|-------------|------------------------------|------------------------------|
| <b>BASS</b> | Decrease bass                | Increase bass                |
| <b>MID</b>  | Decrease mid-range           | Increase mid-range           |
| <b>TREB</b> | Decrease treble              | Increase treble              |
| <b>FADE</b> | Shift the sound to the front | Shift the sound to the rear  |
| <b>BAL</b>  | Shift the sound to the left  | Shift the sound to the right |

**NOTE**

About 5 seconds after selecting any mode, the volume function will be automatically selected. To reset bass, mid-range, treble, fade, and balance, press the audio control knob for 2 seconds. The unit will beep and "CL" will be displayed.

# Audio System

## ▼ Clock



### Setting the time

The clock can be set at any time when the ignition switch is in the ACC or ON position.

1. To adjust the time, press the clock button ( **CLOCK** ) for about 2 seconds until a beep is heard.  
The clock's current time will flash.
2. To advance the hours, press the hour set button ( **H** ). To advance the minutes, press the minute set button ( **M** ) while the time is flashing.
3. Press the clock button ( **CLOCK** ) again to start the clock.

### Exact hour adjustment

1. To set the exact hour, press the clock button ( **CLOCK** ) for about 2 seconds until a beep is heard.  
The clock's current time will flash.
2. Press the clock button ( **CLOCK** ) again and the time will be adjusted as follows:  
(Example)  
12:01—12:29→12:00  
12:30—12:59→1:00

#### **NOTE**

If the power supply to the unit is interrupted (if the fuse blows or the vehicle's battery is disconnected), the clock will need to be reset.


### **Changing the display mode**

The display on the unit can be changed by pressing the clock button ( **CLOCK** ). This alternates the display between time and audio. When the clock mode has been selected, the time will be displayed.

|                                                                                                                                                                     |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>NOTE</b>                                                                                                                                                         |
| If audio operation is selected while the time mode is on, the selected audio mode will be displayed for ten seconds, then the display will revert to the time mode. |

# Audio System

## ▼ Operating the Radio



### Radio ON

Press a band selector button (**AM** or **FM1/2**) to turn the radio on.

### Band selection

Choose AM by pressing the AM button (**AM**) and FM by pressing the FM1/2 button (**FM1/2**).

The selected mode will be indicated. If FM stereo is being received, "ST" will be displayed.

#### **NOTE**

If the FM broadcast signal becomes weak, reception automatically changes from STEREO to MONO for reduced noise, and the "ST" indicator will go out.

### Tuning

The radio has the following tuning methods: Manual, Seek, Scan, Preset channel, and Auto memory tuning. The easiest way to tune stations is to set them on preset channels.

#### **NOTE**

If the power supply is interrupted (fuse blows or the battery is disconnected), the preset channels will be canceled.

### Manual tuning

Turning the manual tuning knob will change the frequency higher or lower.

### Seek tuning

Pressing the seek tuning button (  ,  ) will cause the tuner to seek a higher or lower frequency automatically.

#### NOTE

If you continue to press and hold the button, the frequency will continue changing without stopping.

### Scan tuning

Press the scan button ( **SCAN** ) to automatically sample strong stations. Scanning stops at each station for about 5 seconds. To hold a station, merely press the scan button ( **SCAN** ) again during this interval.

### Preset channel tuning

The six preset channels can be used to store 6 AM and 12 FM stations.

1. To set a channel first select AM, FM1, or FM2. Tune to the station you want.
2. Depress a channel preset button for about 2 seconds until a beep is heard. The preset channel number and station frequency will be displayed. The station is now held in the memory.
3. Repeat this operation for the other stations and bands you want to store. To tune one in the memory, select AM, FM1, or FM2 and then press its channel preset button. The station frequency and the channel number will be displayed.

#### NOTE

If the power supply is interrupted (fuse blows or the battery is disconnected), the preset channels will be canceled.

### Auto memory tuning

This is especially useful when driving in an area where the local stations are not known. Additional AM/FM stations can be stored without disturbing the previously set channels.

Press and hold the auto memory button ( **AUTO-M** ) for about 2 seconds until a beep is heard; the system will automatically scan and temporarily store up to 6 stations with the strongest frequencies in each selected band in that area.

After scanning is completed, the station with the strongest frequency will be tuned and its frequency displayed.


Press and release the auto memory button ( **AUTO-M** ) to recall stations from the auto-stored stations. One stored station will be selected each time; its frequency and channel number will be displayed.

#### NOTE

If no stations can be tuned after scanning operations, "A" will be displayed.

# Audio System

## ▼ Operating the Cassette Tape Player



### Cassette tape insert

Insert the cassette tape into the slot, open edge to the right and cassette tape will begin play and "TAPE" will be displayed. At the end of the cassette tape, the unit automatically reverses cassette tape play. When ▲ is lit, the cassette tape's top side is playing. When ▼ is lit, the bottom side is on.

#### NOTE

When a metal tape is inserted, the player will automatically compensate for it and "MTL" will be displayed.

### Playing

Press the cassette tape play button (**MD/TAPE**) to start playing when a cassette tape is in the unit. If there isn't a cassette tape in the unit when the cassette tape play button (**MD/TAPE**) is pressed, "NO TAPE" will flash on and off in sequence.

### Dolby noise reduction

When using a tape with Dolby NR\*, push the Dolby NR button (**DO**). The **DO** symbol will be displayed. To play a tape without Dolby NR, push the button once again.

\* Noise reduction system manufactured under license from Dolby Laboratories Licensing Corporation.

Dolby and the double-D symbol  are trademarks of Dolby Laboratories Licensing Corporation.

### **Ejecting the cassette tape**

Press the cassette tape eject button () to eject the cassette tape.

#### **NOTE**

The cassette tape can be ejected when the ignition switch is in the OFF position.

### **Fast forward/Rewind**

Press the fast-forward button () to fast-forward.

Press the rewind button () to rewind. To stop this operation and play the cassette tape, press the button again.

#### **NOTE**

When the cassette tape ends during fast forward or rewind, it automatically stops and starts playing.

### **Reversing**

Press the program button (**PROG**) to change cassette tape-playing direction.

#### **NOTE**

When the cassette tape ends, the unit automatically reverses play.

### **Automatic program control (APC)**

APC is used to find the beginning of either the next program or the one being played.

Press the APC button () to the beginning of the next selection. Press the APC button () to the beginning of the one being played. To stop this operation and play the cassette tape, press the button again.

If APC detects 15 seconds of blank space it will automatically advance the tape to the next selection.

#### **NOTE**

APC may not operate properly if

- A tape was recorded at a low level.
- A tape has long, silent intervals.
- A tape is a live recording.
- A tape has very short intervals of less than 3 seconds.

### **Repeat play**

This operation makes it possible to listen to a selection repeatedly.

Press the repeat button (**RPT**) during play. The current selection playing will be repeated ("RPT" will be displayed). Press the repeat button (**RPT**) once again to cancel repeat play.


#### **NOTE**

RPT may not operate properly if

- A tape was recorded at a low level.
- A tape has long, silent intervals.
- A tape is a live recording.
- A tape has very short intervals of less than 3 seconds.

# Audio System

## ▼ Operating the Mini Disc (MD) Player



### Inserting the MD

Insert the MD, label-side up with the arrow pointed to the slot. The auto-loading mechanism will set the MD and begin play. There will be a short lapse before play begins while the player reads the digital signals on the MD.

### Playing

Press the MD play button (**MD/TAPE**) to start playing when a MD is in the unit.

### Ejecting the MD

Press the MD eject button (**▲**) to eject the MD.

### Fast-forward/Reverse

Press and hold the fast-forward button (**▶▶**) to advance through a track at high speed.

Press and hold the reverse button (**<<**) to reverse through a track at high speed.

### Track search

Press the track up button (**^**) once to skip forward to the beginning of the next track.

Press the track down button (**v**) once to skip back to the beginning of the current track.

### Music scan

This feature helps to find a program by playing about the first 10 seconds of each track.

Press the scan button (**SCAN**) during play to start scan play operation (the track number will flash).

Press the scan button (**SCAN**) once again to cancel scan play.

**NOTE**

If the unit is left in scan, normal play will resume where scan was selected.

**Repeat play**

This feature makes it possible to listen to a selection repeatedly.

Press the repeat button (**RPT**) during play. The current selection will be repeated ("RPT" will be displayed). Press the repeat button (**RPT**) once again to cancel repeat play.

**Random play**

This feature allows the MD player to randomly select the order of the songs.

Press the random button (**RDM**) during play. The next selection will be randomly selected ("RDM" will be displayed). Press the random button (**RDM**) once again to cancel random play.

**Changing the MD display**

To change the MD display during MD play, press and hold the display button (**DISP**) for about half a second to advance through each of the following displays:

→Song title → Disc title → No display →

**NOTE**


If there is no song or disc title recorded on the MD, "NO TITLE" will be displayed.

**Long disc or song titles**

When disc or song titles exceed 10 letters or numerals, press the display button (**DISP**) to display the remaining part of the title.

# Audio System

## ▼ Operating the Compact Disc (CD) Player



### Inserting the CD

Insert the CD into the slot, label-side up. The auto-loading mechanism will set the CD and begin play. There will be a short lapse before play begins while the player reads the digital signals on the CD. The disc-in indicator will illuminate and the track number will be displayed.

### Playing

Press the CD play button (CD) to start playing when a CD is in the unit.

### Ejecting the CD

Press the CD eject button (▲) to eject the CD.

### Fast-forward/Reverse

Press and hold the fast-forward button (▶▶) to advance through a track at high speed.

Press and hold the reverse button (◀◀) to reverse through a track at high speed.

### Track search

Press the track up button (∧) once to skip forward to the beginning of the next track.

Press the track down button (∨) once to skip back to the beginning of the current track.

### Music scan

This feature helps to find a program by playing about the first 10 seconds of each track.

Press the scan button (**SCAN**) during play to start scan play operation (the track number will flash).

Press the scan button (**SCAN**) once again to cancel scan play.

|                                                                               |
|-------------------------------------------------------------------------------|
| <b>NOTE</b>                                                                   |
| If the unit is left in scan, normal play will resume where scan was selected. |

### **Repeat play**

This feature makes it possible to listen to a selection repeatedly.

Press the repeat button (**RPT**) during play. The current selection will be repeated ("RPT" will be displayed).

Press the repeat button (**RPT**) once again to cancel repeat play.

### **Random play**


This feature allows the CD player to randomly select the order of the songs.

Press the random button (**RDM**) during play. The next selection will be randomly selected ("RDM" will be displayed).

Press the random button (**RDM**) once again to cancel random play.

# Audio System

## ▼ Operating the In-Dash CD Changer



### Inserting the CD

The CD must be label-side up when inserting. The auto-loading mechanism will set the CD and begin play. There will be a short lapse before play begins while the player reads the digital signals on the CD.

The disc number and the track number will be displayed.

#### **NOTE**

A CD cannot be inserted while the display reads "WAIT". A beeping sound can be heard during this waiting time. Simultaneously pressing the power/volume knob and the load button (LOAD) for about 2 seconds will turn this beeping sound ON or OFF.

### **Normal insertion**

1. Press the load button (LOAD).
2. When "In" is displayed, insert the CD.

### **Inserting CDs into desired tray number**

1. Press and hold the load button (LOAD) for about 2 seconds until a beep is heard.
2. Press the channel preset button for the desired tray number within 5 seconds after the beep is heard.
3. When "In" is displayed, insert the CD.

#### **NOTE**

The CD cannot be inserted to the desired tray number if the number is already occupied.

**Multiple insertion**

1. Press and hold the load button (**LOAD**) for about 2 seconds until a beep is heard.
2. When "In" is displayed, insert the CD.
3. When "In" is displayed again, insert the next CD.

**NOTE**

The first-inserted CD will be played automatically when:

- No CD is inserted within 15 seconds after "In" is displayed.
- The CD trays are full.

**Ejecting the CD****Normal ejection**

1. Press the CD eject button (**▲**). The disc number and "OUT" will be displayed.
2. Pull out the CD.

**NOTE**

When the CD is ejected during play, the next CD will be played automatically.

**Ejecting CDs from desired tray number**

1. Press and hold the CD eject button (**▲**) for about 2 seconds until a beep is heard.
2. Press the channel preset button for the desired CD number within 5 seconds after the beep is heard.
3. Pull out the CD.

**Multiple ejection**

1. Press and hold the CD eject button (**▲**) for about 2 seconds until a beep is heard.
2. Wait 5 seconds or press the CD eject button (**▲**) again within 5 seconds after the beep is heard.
3. Pull out the CD, then the next CD will be ejected.

**NOTE**

- CDs will be ejected starting with the one with the lowest number.
- All CDs in the tray will be ejected continuously.
- CDs can be ejected when the ignition switch is off. Press and hold the CD eject button (**▲**) for about 2 seconds and all CDs will eject.

**Playing**

Press the CD play button (**CD**) to start playing when a CD is in the unit.

**Fast-forward/Reverse**

Press and hold the fast-forward button (**▶▶**) to advance through a track at high speed.

Press and hold the reverse button (**◀◀**) to reverse through a track at high speed.

**Track search**

Press the track up button (**∧**) once to skip forward to the beginning of the next track.

Press the track down button (**∨**) once to skip back to the beginning of the current track.

## Audio System

---

### Disc search

Press the disc up button (**DISC▲**) to skip forward to the beginning of the next CD.

Press the disc down button (**DISC▼**) to skip back to the beginning of the previous CD.

### Music scan

This feature helps to find a program by playing about the first 10 seconds of each track.

Press the scan button (**SCAN**) during play to start scan play operation (the track number will flash).

Press the scan button (**SCAN**) once again to cancel scan play.

|                                                                               |
|-------------------------------------------------------------------------------|
| <b>NOTE</b>                                                                   |
| If the unit is left in scan, normal play will resume where scan was selected. |

### Repeat play

This feature makes it possible to listen to a selection repeatedly.

Press the repeat button (**RPT**) during play. The current selection will be repeated ("RPT" will be displayed).

Press the repeat button (**RPT**) once again to cancel repeat play.

### Random play

This feature allows the CD player to randomly select the order of the songs.

Press the random button (**RDM**) during play. The next selection will be randomly selected ("RDM" will be displayed).

Press the random button (**RDM**) once again to cancel random play.

**▼ Error Indications**

If you see an error indication on the display, find the cause in the chart. If you cannot clear the error indication, take the vehicle to an Authorized Mazda Dealer.

| Indication | Cause                      | Solution                                                                                                   |
|------------|----------------------------|------------------------------------------------------------------------------------------------------------|
| CHECK MD   | MD is inserted upside down | Insert the MD properly. If the error indication does not disappear, consult an Authorized Mazda Dealer     |
| CHECK MD   | MD is defective            | Insert another MD properly. If the error indication does not disappear, consult an Authorized Mazda Dealer |
| CHECK CD   | CD is inserted upside down | Insert the CD properly. If the error indication does not disappear, consult an Authorized Mazda Dealer     |
| CHECK CD   | CD is defective            | Check the CD for scratches or soiling                                                                      |

# Audio System

---

## Safety Certification

This CD player is made and tested to meet exacting safety standards. It meets FCC requirements and complies with safety performance standards of the U.S. Department of Health and Human Services.

### CAUTION

- This CD player should not be adjusted or repaired by anyone except qualified service personnel.  
If servicing is required, contact an Authorized Mazda dealer.
- Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous laser exposure. Never operate the CD player with the top case of the unit removed.
- Changes or modifications not expressly approved by Mazda may void the user's authority to operate this equipment.

### NOTE


For CD player section:  
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

## Sunvisors

When you need a sunvisor, lower it for use in front or swing it to the side.



## ▼ Vanity Mirrors

To use the vanity mirror, lower the sunvisor.

## Interior Lights

### ▼ Illuminated Entry System

When the switch is in the DOOR position, the overhead light comes on for:

- about 30 seconds after the driver's door is unlocked and the ignition key is removed.
- about 15 seconds after all doors are closed.
- about 15 seconds after the key is removed from the ignition.

The light also goes out when:

- the ignition switch is turned to the ON position and all doors are closed.
- the driver's door is locked.


### NOTE

If any door is left opened, the light goes out after about 5 minutes. The light turns on again when the ignition switch is turned to the ON position, or when any door is opened after all doors have been closed.


# Interior Equipment

## ▼ Overhead Lights

With sunroof



Without sunroof




|      |                                                                                                                                                    |
|------|----------------------------------------------------------------------------------------------------------------------------------------------------|
| OFF  | Light off                                                                                                                                          |
| DOOR | <ul style="list-style-type: none"><li>• Light on when any door is open</li><li>• Light on or off when the illuminated entry system is on</li></ul> |
| ON   | Light on                                                                                                                                           |


## ▼ Map Lights

The map lights are switched on or off by pressing the switches.

With sunroof




Without sunroof



## Interior Equipment

### ▼ Luggage Compartment Light




|     |                                    |
|-----|------------------------------------|
| OFF | Light off                          |
| ON  | Light on when the liftgate is open |

### Lighter

The ignition switch must be in the ACC or ON position.

Press the lighter in and release it. When ready for use, it automatically pops out.



### ⚠ CAUTION

- Don't touch the metal part of the lighter, you may burn yourself.
- Don't hold the lighter in because it will overheat.
- Don't use the lighter socket for plug-in accessories such as shavers and coffee pots. They may damage it or cause electrical failure. Use only a genuine Mazda lighter or the equivalent.
- If the lighter doesn't pop out within 30 seconds, remove it to prevent overheating.


## Interior Equipment

### Ashtray

#### ⚠ CAUTION

Don't use the ashtray for trash. You might start a fire.

To remove, open and push down on the lock spring.



### Cup Holder

#### ⚠ WARNING

##### Using Cup Holder:


*Using a cup holder to hold hot liquids while the vehicle is moving is dangerous. If the contents spill, you could be scalded. Never use a cup holder to hold hot liquids while the vehicle is moving.*

##### Don't Put Anything Other Than Cups or Drink-cans in Cup Holder:

*Putting objects other than cups or drink-cans in a cup holder is dangerous.*

*During sudden braking or maneuvering, occupants could be hit and injured, or objects could be thrown around the vehicle, causing interference with the driver and the possibility of an accident. Only use a cup holder for cups or drink-cans.*

The cup holder is in the center console.



## Storage Compartments

### ⚠ WARNING

#### Open Storage Boxes:

*Driving with the storage boxes open is dangerous. To reduce the possibility of injury in an accident or a sudden stop, keep the storage boxes closed when driving.*


### ⚠ CAUTION

In hot weather, don't leave combustible materials or objects which will deform in extreme heat such as lighters and glasses in the vehicle.

### ▼ Glove Box


To open the glove box, pull the latch toward you.

The door has a lock, insert the key and turn it clockwise to lock, counterclockwise to unlock.



### ▼ Center Console

To open, pull the release catch.




### ▼ Cargo Securing Loops

### ⚠ WARNING

#### Not Securing Cargo:

*Not securing cargo while driving is dangerous. The cargo could move or be crushed in sudden braking or a collision and cause injury. Make sure the luggage is secured before driving.*

Use the loops in the luggage compartment to secure cargo with a rope or net. The tensile strength of the loops is 196 N (20 kgf, 44.1 lbf). Do not apply excessive force to the loops as it will damage them.





Helpful information on what to do in an emergency.

|                                      |      |
|--------------------------------------|------|
| <b>Parking in an Emergency</b> ..... | 7-2  |
| Parking in an Emergency .....        | 7-2  |
| <b>Flat Tire</b> .....               | 7-3  |
| Spare Tire and Tool Storage .....    | 7-3  |
| Changing a Flat Tire .....           | 7-7  |
| <b>Overheating</b> .....             | 7-14 |
| Overheating .....                    | 7-14 |
| <b>Emergency Starting</b> .....      | 7-16 |
| Starting a Flooded Engine .....      | 7-16 |
| Jump-Starting .....                  | 7-16 |
| Push-Starting .....                  | 7-18 |
| <b>Emergency Towing</b> .....        | 7-19 |
| Towing Description .....             | 7-19 |
| Towing/Tiedown Hooks .....           | 7-20 |
| Recreational Towing .....            | 7-21 |

## Parking in an Emergency

---

### Parking in an Emergency

The hazard warning lights should always be used when you stop on or near a roadway.

The hazard warning lights warn other drivers that your vehicle is a traffic hazard and that they must take extreme caution when near it.



Depress the hazard warning switch and all four turn signals will flash at once.


#### NOTE

- The turn signals don't work when the hazard warning lights are on.
- Check local regulations about the use of hazard warning lights while the vehicle is being towed. They may forbid it.

**Spare Tire and Tool Storage**

Spare tire and tools are stored in the locations illustrated in the diagram.



**Sedan**




# Flat Tire

---

Hatchback




Lug wrench




Conventional tire hold-down bolt

**▼ Jack****To remove the jack****(Sedan)**


1. Remove the jack container lid.




2. Turn the wing bolt counterclockwise.

**(Hatchback)**

1. Remove the cover.



2. Turn the wing bolt counterclockwise.

**To secure the jack**

Perform the removal procedure in reverse.

## Flat Tire

### ▼ Spare Tire

Your Mazda has a temporary spare tire. The temporary spare tire is lighter and smaller than a conventional tire, and is designed only for emergency use and should be used only for VERY short periods. Temporary spares should NEVER be used for long drives or extended periods.

#### (MAZDASPEED Protégé)

Your Mazda is equipped with a limited-slip differential for the front drive axles and is designed to operate optimally when both front tires are of equal diameter. However, the diameter of the temporary spare tire is smaller than the conventional tires. Due to this, mounting the spare tire to any front axle positions should be avoided, whenever possible and safe.

### WARNING

#### **Driving with a Temporary Spare Tire on Ice or Snow:**

***Driving with a spare tire on the front (driving) wheels on ice or snow is dangerous. Handling will be affected. You could lose control of the vehicle and have an accident. Put the spare tire on the rear axle and move a regular tire to the front.***

### CAUTION

To avoid damage to the temporary spare or to the vehicle, observe the following precautions:

- Don't exceed 80 km/h (50 mph).
- Avoid driving over obstacles. Also, don't drive through an automatic car wash. This tire's diameter is smaller than a conventional tire's, so the ground clearance is reduced about 25 mm (1 in).
- Don't use a tire chain on this tire because it won't fit properly.
- Don't use your temporary spare on any other vehicle; it has been designed only for your Mazda.
- Use only one temporary spare tire on your vehicle at the same time.

#### (MAZDASPEED Protégé)


This temporary spare tire's diameter is smaller than the conventional tire. Avoid mounting this spare tire to any front axle positions, whenever possible and safe.

Due to the special limited-slip front differential, this temporary spare is recommended to be used in the rear axle positions only. Prolonged driving with the temporary spare tire in any front axle positions may cause possible damage to the limited-slip differential assembly.


# Flat Tire

## To remove the spare tire


Turn the tire hold-down bolt counterclockwise with the lug wrench.



## **Except MAZDASPEED Protégé**



## **MAZDASPEED Protégé**



## Changing a Flat Tire

### NOTE

If the following occurs while driving, it could indicate a flat tire.

- Steering becomes difficult.
- The vehicle begins to vibrate excessively.
- The vehicle pulls in one direction.

If you have a flat tire, drive slowly to a level spot that is well off the road and out of the way of traffic to change the tire. Stopping in traffic or on the shoulder of a busy road is dangerous.

## **⚠ WARNING**

### Jacking a Vehicle:

*Changing a tire is dangerous if not done properly. The vehicle can slip off the jack and seriously injure someone.*

*Be sure to follow the directions for changing a tire, and never get under a vehicle that is supported only by a jack.*

### Passenger in Vehicle Supported by a Jack:


*Allowing someone to remain in a vehicle supported by a jack is dangerous. The occupant could cause the vehicle to fall resulting in serious injury. Never allow anyone inside a vehicle supported by a jack.*

# Flat Tire

**NOTE**


Make sure the jack is well lubricated before using it.

- 1. Park on a level surface off the right-of-way and firmly set the parking brake.
- 2. Put a vehicle with an automatic transaxle in Park (P), a manual transaxle in Reverse (R) or 1, and turn off the engine.
- 3. Turn on the hazard warning flasher.
- 4. Have everyone get out of the vehicle and away from the vehicle and traffic.
- 5. Remove the jack, tool, and spare tire (page 7-3).
- 6. Block the wheel diagonally opposite the flat tire. When blocking a front wheel, place the block both in front and behind the tire. When blocking a rear wheel, place the block both in front and behind the tire.



**▼ Removing a Flat Tire**

- 1. Pry off the wheel cover with the beveled end of the lug wrench.




**NOTE**

Force the end of the wrench firmly between wheel and cover, or removal will be difficult.

**⚠ CAUTION**


Align the notch on the wheel cover with the valve stem when installing it.




Damage could occur during installation if the wheel cover is not properly aligned.

# Flat Tire

- Loosen the lug nuts by turning them counterclockwise one turn each, but don't remove any until the tire has been raised off the ground.



- Place the jack under the jacking position closest to the tire being changed.



## **WARNING**

### **Incorrect Jacking Position:**

*Attempting to jack the vehicle in positions other than those recommended in this manual is dangerous. The vehicle could slip off the jack and seriously injure or even kill someone. Use only the front and rear jacking positions recommended in this manual.*

### **Improper Jack:**

*Using a jack that isn't designed for your Mazda is dangerous. The vehicle could slip off the jack and seriously injure someone. Use only the jack provided with your Mazda.*

### **Placing Objects Under the Jack:**


*Jacking the vehicle with an object under the jack is dangerous. The jack could slip and someone could be seriously injured by the jack or the falling vehicle. Never place objects under the jack.*

- Insert the jack handle into the jack.

## Flat Tire

---


5. Turn the jack handle clockwise and raise the vehicle high enough so that the spare tire can be installed. Before removing the lug nuts, make sure your Mazda is firmly in position and that it cannot slip or move.



6. Remove the lug nuts by turning them counterclockwise; then remove the wheel.

### ▼ Locking Lug Nuts

If your vehicle has optional anti-theft wheel lug nuts, one on each wheel will lock the tires and you must use a special key to unlock them. This key is attached to the lug wrench and is stored with the spare tire. Register them with the lock manufacturer by filling out the card provided in the glove box and mailing it in the accompanying envelope. If you lose your key, consult an Authorized Mazda Dealer or use the lock manufacturer's order form, which is with the registration card.



### To remove an anti-theft lug nut

1. Get the key for the locking lug nut.
2. Place it on top of the nut, and be sure to hold the key square to it. If you hold the key at an angle, you may damage both key and nut. Don't use a power impact wrench.
3. Place the lug wrench on top of the key and apply pressure. Turn the wrench counterclockwise.


### To replace the nut

1. Place the key on top of the nut.
2. Place the lug wrench on top of the key, apply pressure, and turn it clockwise.

# Flat Tire

## ▼ Mounting the Spare Tire

1. Remove dirt and grime from the mounting surfaces of the wheel and hub, including the hub bolts, with a cloth.




### ⚠ WARNING

#### Removing Dirt and Grime from Wheels, Hubs and Hub Bolts:

*When changing or replacing a tire, not removing dirt and grime from the mounting surfaces of the wheel, hub and hub bolts is dangerous. The lug nuts could loosen while driving and cause the tire to come off, resulting in an accident. Make sure the mounting surfaces of the wheel, hub and lug nuts are clean before changing or replacing tires.*

2. Mount the spare tire.

3. Install the lug nuts with the beveled edge inward; tighten them by hand.



### ⚠ WARNING


#### Applying Oil and Grease to Lug Nuts, Bolts:

*Applying oil or grease to lug nuts and bolts is dangerous. The lug nuts could loosen while driving and cause the tire to come off, resulting in an accident. In addition, lug nuts and bolts could be damaged if tightened more than necessary. Do not apply oil or grease to lug nuts and bolts and do not tighten the lug nuts beyond the recommended tightening torque.*


## Flat Tire

4. Turn the jack handle counterclockwise and lower the vehicle. Use the lug wrench to tighten the nuts in the order shown.

4-nut models



5-nut models



If you're unsure of how tight the nuts should be, have them inspected at a service station.

### Nut tightening torque:

|                     |                      |
|---------------------|----------------------|
| N·m (kgf·m, ft·lbf) | 90—120 (9—12, 65—87) |
|---------------------|----------------------|

## WARNING

### Loose Lug Nuts:

*Improperly or loosely tightened lug nuts are dangerous. The wheel could wobble or come off. This could result in loss of vehicle control and cause a serious accident. Always securely and correctly tighten the lug nuts.*


### Metric Studs and Lug Nuts:

*Because the wheel studs and lug nuts on your Mazda have metric threads, using a non-metric nut is dangerous. On a metric stud, it would not secure the wheel and would damage the stud, which could cause the wheel to slip off and cause an accident. Be sure to reinstall the same nuts you removed or replace them with metric nuts of the same configuration.*

### Incorrect Tire Air Pressure:

*Driving on tires with incorrect air pressure is dangerous. Tires with incorrect pressure could affect handling and result in an accident. Don't drive with any tires that have incorrect air pressure. When you check the regular tires' air pressure, check the spare tire, too.*

5. Store the damaged tire, using the conventional tire hold-down bolt supplied in the tool bag to hold it in place. Have the damaged tire repaired as soon as possible.

**NOTE**

To prevent the jack and tool from rattling, store them properly.

## Overheating

### Overheating

If the temperature gauge indicates overheating, the vehicle loses power, or you hear a loud knocking or pinging noise, the engine is probably too hot.

If this happens:

1. Drive safely to the side of the road and park off the right-of-way.
2. Put a vehicle with an automatic transaxle in park (P), a manual transaxle in neutral.  
Apply the parking brake.
3. Turn off the air conditioner.

### **WARNING**

**Steam from Overheated Engine:**  
*Steam from an overheated engine is dangerous. The escaping steam could seriously burn you. Open the hood ONLY after steam is no longer escaping from the engine.*

4. Check whether coolant or steam is escaping from under the hood or from the engine compartment.

#### **If steam is coming from the engine compartment:**


Don't go near the front of the vehicle. Stop the engine. Then turn the ignition switch to the ON position without starting the engine.

The radiator cooling fans will start to cool the engine.

#### **If neither coolant nor steam is escaping:**

Open the hood and idle the engine until it cools. If this doesn't lower the temperature, stop the engine and let it cool.

5. Check the coolant level.  
If it's low, look for leaks in the radiator hoses and connections, heater hoses and connections, radiator, and water pump.  
If you find a leak or other damage, or if coolant is still leaking, stop the engine and call an Authorized Mazda Dealer.



If you find no problems, the engine is cool, and no leaks are obvious, carefully add coolant as required (page 8-16).

## **WARNING**

### Cooling System Caps:

*When the engine and radiator are hot, scalding coolant and steam may shoot out under pressure and cause serious injury. Don't remove either cooling system cap when the engine and radiator are hot.*

## **CAUTION**

If the engine continues to overheat or frequently overheats, have the cooling system inspected. The engine could be seriously damaged unless repairs are made.

## Emergency Starting

---

### Starting a Flooded Engine

If the engine fails to start, it may be flooded (excessive fuel in the engine).

Follow this procedure:

1. Depress the accelerator all the way and hold it there.
2. Turn the ignition switch to the START position and hold it there—for up to 10 seconds. If the engine starts, release the key and accelerator immediately because the engine will suddenly rev up.
3. If the engine fails to start, crank it without using the accelerator—for up to 10 seconds.

### Jump-Starting

Jump-starting is dangerous if done incorrectly. So follow the procedure carefully. If you feel unsure about jump-starting, we strongly recommend that you have a competent service technician do the work.

#### **WARNING**

**Battery-Related Explosion:**  
*Flames and sparks near open battery cells are dangerous. Hydrogen gas, produced during normal battery operation, could ignite and cause the battery to explode. An exploding battery can cause serious burns and injuries. Keep all flames, including cigarettes, and sparks away from open battery cells.*


**Low Fluid Level or Frozen Battery:**  
*Jump-starting a frozen battery or one with a low fluid level is dangerous. It may rupture or explode, causing serious injury. Don't jump-start a frozen battery or one with a low fluid level.*

#### **CAUTION**

Use only a 12 V booster system. You can damage a 12 V starter, ignition system, and other electrical parts beyond repair with a 24 V power supply (two 12 V batteries in series or a 24 V motor generator set).

# Emergency Starting

1. Make sure the booster battery is 12 V and that its negative terminal is grounded.
2. If the booster battery is in another vehicle, don't allow the vehicles to touch. Turn off the engine of the vehicle with the booster battery and all unnecessary electrical loads in both vehicles.
3. Connect the jumper cables in the exact sequence as in the illustration.
  - Connect one end of a cable to the positive terminal on the discharged battery (1).
  - Attach the other end to the positive terminal on the booster battery (2).
  - Connect one end of the other cable to the negative terminal of the booster battery (3).
  - Connect the other end to a solid, stationary, exposed metallic point (for example, the engine hanger) away from the discharged battery (4).



## **⚠ WARNING**

**Connecting to Negative Terminal:**  
*Connecting the end of the second cable to the negative (–) terminal of the discharged battery is dangerous. A spark could cause the gas around the battery to explode and injure someone. Connect the cable to a point away from the battery.*

**Connecting Jumper Cable to a Moving Part:**  
*Connecting a jumper cable near or to a moving parts (cooling fans, belts) is dangerous. The cable could get caught when the engine starts and cause serious injury. Never connect a jumper cable to or near any part that moves.*

4. Start the engine of the booster vehicle and run it a few minutes. Then start the engine of the other vehicle.
5. When finished, carefully disconnect the cables in the reverse order described in Step 3.

# Emergency Starting

---

## Push-Starting

### **WARNING**

**Towing a Vehicle to Start It:**  
*Towing a vehicle to start it is dangerous. The vehicle being towed could surge forward when its engine starts, causing the two vehicles to collide. The occupants could be injured. Never tow a vehicle to start it.*

You can't start a vehicle with an automatic transaxle by pushing it.

### **CAUTION**

You shouldn't push-start a vehicle that has a manual transaxle. It can damage the emission control system.




## Emergency Towing

### Towing Description

We recommend that towing be done only by an Authorized Mazda Dealer or a commercial tow-truck service.

Proper lifting and towing are necessary to prevent damage to the vehicle. Government and local laws must be followed.


A towed vehicle usually should have its front wheels off the ground. If excessive damage or other conditions prevent this, use wheel dollies.



When towing with the rear wheels on the ground, release the parking brake.


### ⚠ CAUTION

Don't tow the vehicle pointed backward with driving wheels on the ground. This may cause internal damage to the transaxle.



### ⚠ CAUTION

Don't tow with sling-type equipment. This could damage your vehicle. Use wheel-lift or flatbed equipment.



## Emergency Towing


### Towing/Tiedown Hooks

#### ⚠ CAUTION


- The towing hook should be used only in an emergency (to get the vehicle out of a ditch or a snow bank, for example).
- When using the towing hook, always pull the cable or chain in a straight direction with respect to the hook. Apply no sideways force.
- Don't use the tiedown hooks under the front and rear for towing. They are designed ONLY for tying down the vehicle when it's being transported. Using them for towing will damage the bumper.

#### ▼ Towing Hook-Rear


Sedan



Hatchback




#### ▼ Tiedown Hooks-Front




# Emergency Towing

## ▼ Tiedown Hooks-Rear

Sedan



Hatchback



## Recreational Towing

An example of “recreational towing” is towing your vehicle behind a motorhome. The transaxle is not designed for towing this vehicle on all 4 wheels.

When doing recreational towing refer to “Towing Description” (page 7-19) and “Towing/Tiedown Hooks” (page 7-20) and carefully follow the instructions.



How to keep your Mazda in top condition.

|                                                         |      |
|---------------------------------------------------------|------|
| <b>Introduction</b> .....                               | 8-2  |
| Introduction .....                                      | 8-2  |
| <b>Scheduled Maintenance</b> .....                      | 8-3  |
| Scheduled Maintenance (Except MAZDASPEED Protégé) ..... | 8-3  |
| Scheduled Maintenance (MAZDASPEED Protégé) .....        | 8-6  |
| <b>Owner Maintenance</b> .....                          | 8-10 |
| Owner Maintenance Schedule .....                        | 8-10 |
| Owner Maintenance Precautions .....                     | 8-11 |
| Engine Compartment Overview .....                       | 8-12 |
| Engine Oil .....                                        | 8-13 |
| Engine Coolant .....                                    | 8-16 |
| Brake/Clutch Fluid .....                                | 8-18 |
| Power Steering Fluid .....                              | 8-20 |
| Automatic Transaxle Fluid (ATF) .....                   | 8-20 |
| Washer Fluid .....                                      | 8-22 |
| Body Lubrication .....                                  | 8-23 |
| Air Filter .....                                        | 8-23 |
| Wiper Blades .....                                      | 8-24 |
| Battery .....                                           | 8-27 |
| Tires .....                                             | 8-28 |
| Light Bulbs .....                                       | 8-33 |
| Fuses .....                                             | 8-42 |
| <b>Appearance Care</b> .....                            | 8-46 |
| How to Minimize Environmental Paint Damage .....        | 8-46 |
| Exterior Care .....                                     | 8-48 |
| Interior Care .....                                     | 8-51 |

## Introduction

---

### Introduction

Be extremely careful and prevent injury to yourself and others or damage to your vehicle when using this manual for inspection and maintenance.

If you're unsure about any procedure it describes, we strongly urge you to have a reliable and qualified service shop perform the work, preferably an Authorized Mazda Dealer.

Factory-trained Mazda technicians and genuine Mazda parts are best for your vehicle. Without this expertise and the parts that have been designed and made especially for your Mazda, inadequate, incomplete, and insufficient servicing may result in problems. This could lead to vehicle damage or an accident and injuries.

For expert advice and quality service, consult an Authorized Mazda Dealer.

The owner should retain evidence that proper maintenance has been performed as prescribed.

Claims against the warranty resulting from lack of maintenance, as opposed to defective materials or authorized Mazda workmanship, will not be honored.

Any auto repair shop using parts equivalent to your Mazda's original equipment may perform maintenance. **But we recommend that it always be done by an Authorized Mazda Dealer using genuine Mazda parts.**

## Scheduled Maintenance

---

### Scheduled Maintenance (Except MAZDASPEED Protégé)

Follow Schedule 1 if the vehicle is operated mainly where none of the following conditions apply.

If any do apply, follow Schedule 2 (Canada and Puerto Rico residents follow Schedule 2).

- Repeated short-distance driving
- Driving in dusty conditions
- Driving with extended use of brakes
- Driving in areas where salt or other corrosive materials are being used
- Driving on rough or muddy roads
- Extended periods of idling or low-speed operation
- Driving for long periods in cold temperatures or extremely humid climates

|                                                                                                         |
|---------------------------------------------------------------------------------------------------------|
| <b>NOTE</b>                                                                                             |
| After the prescribed period, continue to follow the described maintenance at the recommended intervals. |

# Scheduled Maintenance

## ▼ Schedule 1

**I** : Inspect and repair, clean, adjust, or replace if necessary.  
(Oil-permeated air filter cannot be cleaned using the air-blow method.)

**R** : Replace

**L** : Lubricate

| Maintenance Interval<br>(Number of months or<br>kilometers (miles),<br>whichever comes first) | Months      | 6   | 12 | 18   | 24 | 30   | 36 | 42   | 48 |
|-----------------------------------------------------------------------------------------------|-------------|-----|----|------|----|------|----|------|----|
|                                                                                               | ×1000 km    | 12  | 24 | 36   | 48 | 60   | 72 | 84   | 96 |
|                                                                                               | ×1000 miles | 7.5 | 15 | 22.5 | 30 | 37.5 | 45 | 52.5 | 60 |

### ENGINE

|                        |                                                                                |   |   |   |   |   |   |   |   |
|------------------------|--------------------------------------------------------------------------------|---|---|---|---|---|---|---|---|
| Engine valve clearance |                                                                                |   |   |   |   |   |   |   | I |
| Engine timing belt     | Inspect at 96,000km (60,000 miles)<br>Replace every 168,000 km (105,000 miles) |   |   |   |   |   |   |   |   |
| Drive belts (tension)  |                                                                                |   |   |   | I |   |   |   | I |
| Engine oil             | R                                                                              | R | R | R | R | R | R | R | R |
| Engine oil filter      | R                                                                              | R | R | R | R | R | R | R | R |

### COOLING SYSTEM

|                |                                                                                                                     |  |  |   |  |  |  |  |   |
|----------------|---------------------------------------------------------------------------------------------------------------------|--|--|---|--|--|--|--|---|
| Cooling system |                                                                                                                     |  |  | I |  |  |  |  | I |
| Engine coolant | Replace at first 72,000 km (45,000 miles) or 36 months ;<br>after that, every 48,000 km (30,000 miles) or 24 months |  |  |   |  |  |  |  |   |

### FUEL SYSTEM

|                                 |  |  |  |   |  |  |  |  |   |
|---------------------------------|--|--|--|---|--|--|--|--|---|
| Idle speed                      |  |  |  | I |  |  |  |  | I |
| Air filter                      |  |  |  | R |  |  |  |  | R |
| Fuel lines and hoses *1         |  |  |  | I |  |  |  |  | I |
| Hoses and tubes for emission *1 |  |  |  |   |  |  |  |  | I |

### IGNITION SYSTEM

|             |  |  |  |   |  |  |  |  |   |
|-------------|--|--|--|---|--|--|--|--|---|
| Spark plugs |  |  |  | R |  |  |  |  | R |
|-------------|--|--|--|---|--|--|--|--|---|

### CHASSIS and BODY

|                                    |   |   |   |   |   |   |   |   |   |
|------------------------------------|---|---|---|---|---|---|---|---|---|
| Brake lines, hoses and connections |   |   |   | I |   |   |   |   | I |
| Disc brakes                        |   |   |   | I |   |   |   |   | I |
| Drum brakes                        |   |   |   | I |   |   |   |   | I |
| Steering operation and linkages    |   |   |   | I |   |   |   |   | I |
| Front suspension ball joints       |   |   |   | I |   |   |   |   | I |
| Driveshaft dust boots              |   |   |   | I |   |   |   |   | I |
| Bolts and nuts on chassis and body |   |   |   | I |   |   |   |   | I |
| Exhaust system heat shields        |   |   |   | I |   |   |   |   | I |
| All locks and hinges               | L | L | L | L | L | L | L | L | L |

### AIR CONDITIONER SYSTEM (if equipped)

|                      |  |   |  |   |  |   |  |   |
|----------------------|--|---|--|---|--|---|--|---|
| Refrigerant amount   |  | I |  | I |  | I |  | I |
| Compressor operation |  | I |  | I |  | I |  | I |

\*1 According to state and federal regulations, failure to perform maintenance on these items will not void your emissions warranties. However, Mazda recommends that all maintenance services be performed at the recommended time or mileage period to ensure long-term reliability.

# Scheduled Maintenance

## ▼ Schedule 2

**I** : Inspect and repair, clean, adjust, or replace if necessary.  
(Oil-permeated air filter cannot be cleaned using the air-blow method.)  
**R** : Replace  
**L** : Lubricate

| Maintenance Interval<br>(Number of months or<br>kilometers (miles),<br>whichever comes first) | Months      | 4 | 8  | 12 | 16 | 20 | 24 | 28 | 32 | 36 | 40 | 44 | 48 |
|-----------------------------------------------------------------------------------------------|-------------|---|----|----|----|----|----|----|----|----|----|----|----|
|                                                                                               | ×1000 km    | 8 | 16 | 24 | 32 | 40 | 48 | 56 | 64 | 72 | 80 | 88 | 96 |
|                                                                                               | ×1000 miles | 5 | 10 | 15 | 20 | 25 | 30 | 35 | 40 | 45 | 50 | 55 | 60 |

### ENGINE

|                        |                                                                                 |                                                  |   |   |   |   |   |   |   |   |   |   |   |
|------------------------|---------------------------------------------------------------------------------|--------------------------------------------------|---|---|---|---|---|---|---|---|---|---|---|
| Engine valve clearance |                                                                                 |                                                  |   |   |   |   |   |   |   |   |   |   | I |
| Engine timing belt *2  | Inspect at 96,000 km (60,000 miles)<br>Replace every 168,000 km (105,000 miles) |                                                  |   |   |   |   |   |   |   |   |   |   |   |
| Drive belts (tension)  |                                                                                 |                                                  |   |   |   |   | I |   |   |   |   |   | I |
| Engine oil             | Puerto Rico                                                                     | Replace every 5,000 km (3,000 miles) or 3 months |   |   |   |   |   |   |   |   |   |   |   |
|                        | Others                                                                          | R                                                | R | R | R | R | R | R | R | R | R | R | R |
| Engine oil filter      |                                                                                 | R                                                | R | R | R | R | R | R | R | R | R | R | R |

### COOLING SYSTEM

|                      |                                                                                                                     |   |   |   |   |   |   |   |   |   |   |   |   |
|----------------------|---------------------------------------------------------------------------------------------------------------------|---|---|---|---|---|---|---|---|---|---|---|---|
| Cooling system       |                                                                                                                     |   |   |   |   | I |   |   |   |   |   |   | I |
| Engine coolant       | Replace at first 72,000 km (45,000 miles) or 36 months ;<br>after that, every 48,000 km (30,000 miles) or 24 months |   |   |   |   |   |   |   |   |   |   |   |   |
| Engine coolant level | I                                                                                                                   | I | I | I | I | I | I | I | I | I | I | I | I |

### FUEL SYSTEM

|                                 |  |  |     |  |  |   |  |  |     |  |  |  |   |
|---------------------------------|--|--|-----|--|--|---|--|--|-----|--|--|--|---|
| Idle speed                      |  |  |     |  |  | I |  |  |     |  |  |  | I |
| Air filter                      |  |  | I*1 |  |  | R |  |  | I*1 |  |  |  | R |
| Fuel lines and hoses *1         |  |  |     |  |  | I |  |  |     |  |  |  | I |
| Hoses and tubes for emission *1 |  |  |     |  |  |   |  |  |     |  |  |  | I |

### IGNITION SYSTEM

|             |  |  |  |  |  |   |  |  |  |  |  |  |   |
|-------------|--|--|--|--|--|---|--|--|--|--|--|--|---|
| Spark plugs |  |  |  |  |  | R |  |  |  |  |  |  | R |
|-------------|--|--|--|--|--|---|--|--|--|--|--|--|---|

### ELECTRICAL SYSTEM

|                        |   |   |   |   |   |   |   |   |   |   |   |   |   |
|------------------------|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Function of all lights | I | I | I | I | I | I | I | I | I | I | I | I | I |
|------------------------|---|---|---|---|---|---|---|---|---|---|---|---|---|

### CHASSIS and BODY

|                                       |   |   |   |   |   |   |   |   |   |   |   |   |   |
|---------------------------------------|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Brake lines, hoses and connections    |   |   |   |   |   | I |   |   |   |   |   |   | I |
| Brake and clutch fluid level          | I | I | I | I | I | I | I | I | I | I | I | I | I |
| Disc brakes                           |   |   | I |   |   | I |   |   | I |   |   |   | I |
| Drum brakes                           |   |   |   |   |   | I |   |   |   |   |   |   | I |
| Tire inflation pressure and tire wear | I | I | I | I | I | I | I | I | I | I | I | I | I |
| Steering operation and linkages       |   |   |   |   |   | I |   |   |   |   |   |   | I |
| Power steering fluid level            | I | I | I | I | I | I | I | I | I | I | I | I | I |
| Front suspension ball joints          |   |   |   |   |   | I |   |   |   |   |   |   | I |
| Driveshaft dust boots                 |   |   |   |   |   | I |   |   |   |   |   |   | I |
| Bolts and nuts on chassis and body    |   |   | I |   |   |   |   |   | I |   |   |   | I |
| Exhaust system heat shields           |   |   |   |   |   | I |   |   |   |   |   |   | I |
| All locks and hinges                  | L | L | L | L | L | L | L | L | L | L | L | L | L |
| Washer fluid level                    | I | I | I | I | I | I | I | I | I | I | I | I | I |

### AIR CONDITIONER SYSTEM (if equipped)

|                      |  |  |   |  |  |   |  |  |   |  |  |  |   |
|----------------------|--|--|---|--|--|---|--|--|---|--|--|--|---|
| Refrigerant amount   |  |  | I |  |  | I |  |  | I |  |  |  | I |
| Compressor operation |  |  | I |  |  | I |  |  | I |  |  |  | I |

\*1 According to state and federal regulations, failure to perform maintenance on these items will not void your emissions warranties. However, Mazda recommends that all maintenance services be performed at the recommended time or mileage period to ensure long-term reliability

\*2 If the vehicle is operated in cold districts { below -18 degrees C (0 degrees F) }, replace the timing belt at 96,000 km (60,000 miles).

# Scheduled Maintenance

---

## Scheduled Maintenance (MAZDASPEED Protégé)

Follow Schedule 1 if the vehicle is operated in the USA where none of the following conditions mainly apply.

If any do apply, follow Schedule 2 (Canadian residents follow Schedule 2 in all conditions).

- Repeated short-distance driving
- Driving in dusty conditions
- Driving with extended use of brakes
- Driving in areas where salt or other corrosive materials are used
- Driving on rough or muddy roads
- Extended periods of idling or low-speed operation
- Driving for long periods in cold temperatures or extremely humid climates

|                                                                                                         |
|---------------------------------------------------------------------------------------------------------|
| <b>NOTE</b>                                                                                             |
| After the prescribed period, continue to follow the described maintenance at the recommended intervals. |

# Scheduled Maintenance

## ▼ Schedule 1

- I** : Inspect and repair, clean, adjust, or replace if necessary.  
 (Oil-permeated air filter cannot be cleaned using the air-blow method.)  
**R** : Replace  
**L** : Lubricate

| Maintenance Interval<br>(Number of months or kilometers<br>(miles), whichever comes first) | Months      | 6   | 12 | 18   | 24 | 30   | 36 | 42   | 48 |
|--------------------------------------------------------------------------------------------|-------------|-----|----|------|----|------|----|------|----|
|                                                                                            | ×1000 km    | 12  | 24 | 36   | 48 | 60   | 72 | 84   | 96 |
|                                                                                            | ×1000 miles | 7.5 | 15 | 22.5 | 30 | 37.5 | 45 | 52.5 | 60 |

### ENGINE

|                          |              |                                                                                |  |  |   |  |  |  |   |
|--------------------------|--------------|--------------------------------------------------------------------------------|--|--|---|--|--|--|---|
| Engine valve clearance   |              |                                                                                |  |  |   |  |  |  | I |
| Engine timing belt       |              | Inspect at 96,000km (60,000 miles)<br>Replace every 168,000 km (105,000 miles) |  |  |   |  |  |  |   |
| Drive belts (tension)    |              |                                                                                |  |  | I |  |  |  | I |
| Engine oil <sup>*3</sup> | Turbo engine | Replace every 8,000 km (5,000 miles) or 5 months                               |  |  |   |  |  |  |   |
| Oil filter               | Turbo engine | Replace every 8,000 km (5,000 miles) or 5 months                               |  |  |   |  |  |  |   |

### COOLING SYSTEM

|                |  |                                                                                                                       |  |  |   |  |  |  |   |
|----------------|--|-----------------------------------------------------------------------------------------------------------------------|--|--|---|--|--|--|---|
| Cooling system |  |                                                                                                                       |  |  | I |  |  |  | I |
| Engine coolant |  | Replace at first 72,000 km (45,000 miles) or<br>36 months ; every 48,000 km (30,000 miles) or<br>24 months thereafter |  |  |   |  |  |  |   |

### FUEL SYSTEM

|                                            |  |  |  |  |   |  |  |  |   |
|--------------------------------------------|--|--|--|--|---|--|--|--|---|
| Idle speed                                 |  |  |  |  | I |  |  |  | I |
| Air filter                                 |  |  |  |  | R |  |  |  | R |
| Fuel lines and hoses <sup>*1</sup>         |  |  |  |  | I |  |  |  | I |
| Hoses and tubes for emission <sup>*1</sup> |  |  |  |  |   |  |  |  | I |

### IGNITION SYSTEM

|             |  |  |  |  |   |  |  |  |   |
|-------------|--|--|--|--|---|--|--|--|---|
| Spark plugs |  |  |  |  | R |  |  |  | R |
|-------------|--|--|--|--|---|--|--|--|---|

### CHASSIS and BODY

|                                    |  |   |   |   |   |   |   |   |   |
|------------------------------------|--|---|---|---|---|---|---|---|---|
| Brake lines, hoses and connections |  |   |   |   | I |   |   |   | I |
| Disc brakes                        |  |   |   |   | I |   |   |   | I |
| Steering operation and linkages    |  |   |   |   | I |   |   |   | I |
| Front suspension ball joints       |  |   |   |   | I |   |   |   | I |
| Driveshaft dust boots              |  |   |   |   | I |   |   |   | I |
| Bolts and nuts on chassis and body |  |   |   |   | I |   |   |   | I |
| Exhaust system heat shields        |  |   |   |   | I |   |   |   | I |
| All locks and hinges               |  | L | L | L | L | L | L | L | L |

### AIR CONDITIONER SYSTEM (if equipped)

|                      |  |  |   |  |   |  |   |  |   |
|----------------------|--|--|---|--|---|--|---|--|---|
| Refrigerant amount   |  |  | I |  | I |  | I |  | I |
| Compressor operation |  |  | I |  | I |  | I |  | I |

<sup>\*1</sup> According to state / provincial and federal regulations, failure to perform maintenance on these items will not void your emissions warranties. However, Mazda recommends that all maintenance services be performed at the recommended time or mileage / kilometer period to ensure long-term reliability.

<sup>\*3</sup> Use only engine oils with API SL or ILSAC GF-III service grade (or higher). Recommended viscosity index is 5W-30 or 10W-30 (depending on climate conditions).

# Scheduled Maintenance

## ▼ Schedule 2

**I** : Inspect and repair, clean, adjust, or replace if necessary.  
(Oil-permeated air filter cannot be cleaned using the air-blow method.)  
**R** : Replace

| Maintenance Interval<br>(Number of months or<br>kilometers (miles),<br>whichever comes first) | Months      | 4 | 8  | 12 | 16 | 20 | 24 | 28 | 32 | 36 | 40 | 44 | 48 |
|-----------------------------------------------------------------------------------------------|-------------|---|----|----|----|----|----|----|----|----|----|----|----|
|                                                                                               | ×1000 km    | 8 | 16 | 24 | 32 | 40 | 48 | 56 | 64 | 72 | 80 | 88 | 96 |
|                                                                                               | ×1000 miles | 5 | 10 | 15 | 20 | 25 | 30 | 35 | 40 | 45 | 50 | 55 | 60 |

### ENGINE

|                        |              |                                                                                 |  |  |  |  |          |  |  |  |  |  |          |
|------------------------|--------------|---------------------------------------------------------------------------------|--|--|--|--|----------|--|--|--|--|--|----------|
| Engine valve clearance |              |                                                                                 |  |  |  |  |          |  |  |  |  |  | <b>I</b> |
| Engine timing belt*2   |              | Inspect at 96,000 km (60,000 miles)<br>Replace every 168,000 km (105,000 miles) |  |  |  |  |          |  |  |  |  |  |          |
| Drive belts (tension)  |              |                                                                                 |  |  |  |  | <b>I</b> |  |  |  |  |  | <b>I</b> |
| Engine oil*3           | Turbo engine | Replace every 5,000 km (3,000 miles) or 3 months                                |  |  |  |  |          |  |  |  |  |  |          |
| Oil filter             | Turbo engine | Replace every 5,000 km (3,000 miles) or 3 months                                |  |  |  |  |          |  |  |  |  |  |          |

### COOLING SYSTEM

|                      |  |                                                                                                                         |          |          |          |          |          |          |          |          |          |          |          |
|----------------------|--|-------------------------------------------------------------------------------------------------------------------------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|
| Cooling system       |  |                                                                                                                         |          |          |          |          | <b>I</b> |          |          |          |          |          | <b>I</b> |
| Engine coolant       |  | Replace at first 72,000 km (45,000 miles) or 36 months ;<br>and every 48,000 km (30,000 miles) or 24 months, thereafter |          |          |          |          |          |          |          |          |          |          |          |
| Engine coolant level |  | <b>I</b>                                                                                                                | <b>I</b> | <b>I</b> | <b>I</b> | <b>I</b> | <b>I</b> | <b>I</b> | <b>I</b> | <b>I</b> | <b>I</b> | <b>I</b> | <b>I</b> |

### FUEL SYSTEM

|                                |  |  |  |             |  |  |          |  |  |             |  |  |          |
|--------------------------------|--|--|--|-------------|--|--|----------|--|--|-------------|--|--|----------|
| Idle speed                     |  |  |  |             |  |  | <b>I</b> |  |  |             |  |  | <b>I</b> |
| Air filter                     |  |  |  | <b>I</b> *1 |  |  | <b>R</b> |  |  | <b>I</b> *1 |  |  | <b>R</b> |
| Fuel lines and hoses*1         |  |  |  |             |  |  | <b>I</b> |  |  |             |  |  | <b>I</b> |
| Hoses and tubes for emission*1 |  |  |  |             |  |  |          |  |  |             |  |  | <b>I</b> |

### IGNITION SYSTEM

|             |  |  |  |  |  |  |          |  |  |  |  |  |          |
|-------------|--|--|--|--|--|--|----------|--|--|--|--|--|----------|
| Spark plugs |  |  |  |  |  |  | <b>R</b> |  |  |  |  |  | <b>R</b> |
|-------------|--|--|--|--|--|--|----------|--|--|--|--|--|----------|

### ELECTRICAL SYSTEM

|                        |  |          |          |          |          |          |          |          |          |          |          |          |          |
|------------------------|--|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|
| Function of all lights |  | <b>I</b> | <b>I</b> | <b>I</b> | <b>I</b> | <b>I</b> | <b>I</b> | <b>I</b> | <b>I</b> | <b>I</b> | <b>I</b> | <b>I</b> | <b>I</b> |
|------------------------|--|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|

\*1 According to state / provincial and federal regulations, failure to perform maintenance on these items will not void your emissions warranties. However, Mazda recommends that all maintenance services be performed at the recommended time or mileage / kilometer period to ensure long-term reliability.

\*2 If the vehicle is operated in cold districts { below -18 degrees C (0 degrees F) }, replace the timing belt at 96,000 km (60,000 miles).

\*3 Use only engine oils with API SL or ILSAC GF-III service grade (or higher). Recommended viscosity index is 5W-30 or 10W-30 (depending on climate conditions).

## Scheduled Maintenance

**I** : Inspect and repair, clean, adjust, or replace if necessary.  
(Oil-permeated air filter cannot be cleaned using the air-blow method.)

**L** : Lubricate

| Maintenance Interval<br>(Number of months or<br>kilometers (miles),<br>whichever comes first) | Months      | 4 | 8  | 12 | 16 | 20 | 24 | 28 | 32 | 36 | 40 | 44 | 48 |
|-----------------------------------------------------------------------------------------------|-------------|---|----|----|----|----|----|----|----|----|----|----|----|
|                                                                                               | ×1000 km    | 8 | 16 | 24 | 32 | 40 | 48 | 56 | 64 | 72 | 80 | 88 | 96 |
|                                                                                               | ×1000 miles | 5 | 10 | 15 | 20 | 25 | 30 | 35 | 40 | 45 | 50 | 55 | 60 |

### CHASSIS and BODY

|                                       |   |   |   |   |   |   |   |   |   |   |   |   |   |
|---------------------------------------|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Brake lines, hoses and connections    |   |   |   |   |   |   | I |   |   |   |   |   | I |
| Brake and clutch fluid level          | I | I | I | I | I | I | I | I | I | I | I | I | I |
| Disc brakes                           |   |   | I |   |   |   | I |   |   | I |   |   | I |
| Tire inflation pressure and tire wear | I | I | I | I | I | I | I | I | I | I | I | I | I |
| Steering operation and linkages       |   |   |   |   |   |   | I |   |   |   |   |   | I |
| Power steering fluid level            | I | I | I | I | I | I | I | I | I | I | I | I | I |
| Front suspension ball joints          |   |   |   |   |   |   | I |   |   |   |   |   | I |
| Driveshaft dust boots                 |   |   |   |   |   |   | I |   |   |   |   |   | I |
| Bolts and nuts on chassis and body    |   |   |   | I |   |   | I |   |   | I |   |   | I |
| Exhaust system heat shields           |   |   |   |   |   |   | I |   |   |   |   |   | I |
| All locks and hinges                  | L | L | L | L | L | L | L | L | L | L | L | L | L |
| Washer fluid level                    | I | I | I | I | I | I | I | I | I | I | I | I | I |

### AIR CONDITIONER SYSTEM (if equipped)

|                      |  |  |   |  |  |  |   |  |  |   |  |  |   |
|----------------------|--|--|---|--|--|--|---|--|--|---|--|--|---|
| Refrigerant amount   |  |  | I |  |  |  | I |  |  | I |  |  | I |
| Compressor operation |  |  | I |  |  |  | I |  |  | I |  |  | I |

## Owner Maintenance

---

### Owner Maintenance Schedule

The owner or a qualified service technician should make these vehicle inspections at the indicated intervals to ensure safe and dependable operation.

Bring any problem to the attention of an Authorized Mazda Dealer or qualified service technician as soon as possible.

#### ▼ When Refueling

- Brake and clutch fluid level (page 8-18)
- Engine coolant level (page 8-16)
- Engine oil level (page 8-13)
- Washer fluid level (page 8-22)

#### ▼ At Least Monthly

- Tire inflation pressures (page 8-29)

#### ▼ At Least Twice a Year (For Example, Every Spring and Fall)

- Automatic transaxle fluid level (page 8-20)
- Power steering fluid level (page 8-20)

You can do the following scheduled maintenance items if you have some mechanical ability and a few basic tools and if you closely follow the directions in this manual.

- Air filter (page 8-23)
- Engine coolant (page 8-16)
- Engine oil (page 8-14)

## Owner Maintenance Precautions

Improper or incomplete service may result in problems. This section gives instructions only for items easy to perform.

As explained in the Introduction (page 8-2), several procedure can be done only by a qualified service technician with special tools.

Improper owner maintenance during the warranty period may affect warranty coverage. For details, read the separate Mazda Warranty statement provided with the vehicle. If you're unsure about any servicing or maintenance procedure, have it done by an Authorized Mazda Dealer.

There are strict environmental laws regarding the disposal of waste oil and fluids. Please dispose of your waste carefully and with due regard to the environment.

We recommend that you entrust the oil and fluid changes of your vehicle to an Authorized Mazda Dealer.

### **WARNING**

#### **Maintenance Procedures:**

*Performing maintenance work on a vehicle is dangerous if not done properly. You can be seriously injured while performing some maintenance procedure. If you lack sufficient knowledge and experience or the proper tools and equipment to do the work, have it done by a qualified technician.*

#### **Running the Engine:**

*Working under the hood with the engine running is dangerous. It becomes even more dangerous when you wear jewelry or loose clothing.*

*Either can become entangled in moving parts and result in injury.*

*Therefore, if you must run the engine while working under the hood, make certain that you remove all jewelry (especially rings, bracelets, watches, and necklaces) and all neckties, scarves, and similar loose clothing before getting near the engine or cooling fan.*


#### **Electrical Fan and Engine Inspection:**

*Inspecting the engine with the ignition switch in the ON position is dangerous. The cooling fan could come on unexpectedly even when the engine isn't running. You could be seriously injured by the fan. Turn the ignition switch off and remove the key from the ignition switch when you inspect the engine.*


# Owner Maintenance

## Engine Compartment Overview

### 1.6-liter engine



### 2.0-liter engine



# Owner Maintenance

## Engine Oil

### ▼ Recommended Oil

Oil container labels provide important information.



(ILSAC)

**(Except MAZDASPEED Protégé)**


The quality designation **SG, SH, SJ, SL**, or **ILSAC** must be on the label.

**(MAZDASPEED Protégé)**

The quality designation **SL** or **ILSAC** must be on the label.

Engine oil viscosity, or thickness, has an effect on fuel economy and cold-weather operation (starting and oil flow). Low-viscosity engine oils can provide improved fuel economy and cold-weather performance.

But high-temperature weather conditions require higher-viscosity engine oils for satisfactory lubrication.



5W-30

10W-30

When choosing an oil, consider the temperature range your vehicle will operate in before the next oil change. Then select the recommended viscosity from this chart.

### ⚠ CAUTION


Using oils of viscosity besides those recommended for specific temperature ranges could result in engine damage.

Energy conserving oils are recommended. A chief contribution they make to fuel economy is reducing the amount of fuel necessary to overcome engine friction.

### ▼ Inspecting Engine Oil Level


1. Be sure the vehicle is on a level surface.
2. Warm up the engine to normal operating temperature.
3. Turn it off and wait 5 minutes for the oil to return to the oil pan.
4. Pull out the dipstick, wipe it clean, and reinsert it fully.

#### 1.6-liter engine



# Owner Maintenance

## 2.0-liter engine



5. Pull it out again and examine the level. It's OK between L and F. But if it's near at or below L, add enough oil to bring the level to F.

### ⚠ CAUTION

Don't add engine oil over F. This may cause engine damage.

6. Make sure the O-ring is positioned properly before reinserting the dipstick.

The distance between L and F on the dipstick represents the following:

|                   |                  |
|-------------------|------------------|
| L (US qt, Imp qt) | 1.0 (1.05, 0.87) |
|-------------------|------------------|

## ▼ Changing Engine Oil and Filter

Change engine oil and filter according to Scheduled Maintenance (page 8-3).

Please act responsibly—protect the environment and take used oil to a recycling facility. Ask your dealer or a service station for information.

### ⚠ WARNING


**Handling Used Engine Oil:**  
Continuous contact with used engine oil is dangerous. It could cause skin cancer. Always wash with soap and water immediately after changing oil and filter.

### Changing engine oil

### ⚠ WARNING


**Checking or Changing Engine Oil:**  
Hot engine oil is dangerous. If the engine has been running, the engine oil becomes very hot. You could be seriously burned. Don't check or change the engine oil when the engine is hot.

## 1.6-liter engine



# Owner Maintenance

## 2.0-liter engine



1. Warm up the engine for a few minutes and turn it off. Remove the oil-filler cap.
2. Remove the drain plug and drain the oil into a suitable container.
3. Replace the plug tightly after the oil has thoroughly drained.
4. Fill the engine with new oil to the F mark on the dipstick.
5. Securely replace the oil-filler cap.
6. Start the engine and inspect around the drain plug for leaks.
7. Turn it off and wait 5 minutes for the oil to return to the oil pan.

Check the oil level and fill to the F mark if necessary.

**Oil capacity (General reference only, refer to Specifications section for capacities.)**

### NOTE

- The indicated engine oil capacities are for general reference purposes only. When adding or changing oil, verify the engine oil level with the oil dipstick.
- Use only specified engine oil (page 10-5).

### Changing oil filter

Because you need a special tool to retighten the filter, an Authorized Mazda Dealer should do the work.

## Owner Maintenance

### Engine Coolant

#### ▼ Inspecting Coolant Level

#### **WARNING**


##### **Hot Engine:**

*A hot engine is dangerous. If the engine has been running, parts of the engine compartment can become very hot. You could be burned. Don't inspect the coolant system or add coolant when the engine is hot.*

Inspect the antifreeze protection and coolant level in the coolant reservoir at least once a year—at the beginning of the winter season—and before traveling where temperatures may drop below freezing.

Inspect the condition and connections of all cooling system and heater hoses. Replace any that are swollen or deteriorated.

The coolant should be at full in the radiator and between the FULL and LOW marks on the coolant reservoir when the engine is cool.



If it's at or near LOW, add enough coolant to the coolant reservoir to provide freezing and corrosion protection and to bring the level to FULL.

#### **CAUTION**

Radiator coolant will damage paint. Rinse it off quickly.

#### **Do not overfill.**

If new coolant is required frequently, consult an Authorized Mazda Dealer.

#### ▼ Changing Coolant

Change coolant according to Scheduled Maintenance (page 8-3).

#### **CAUTION**

- Use only soft (demineralized) water in the coolant mixture. Water that contains minerals will cut down on the coolant's effectiveness.
- Don't add only water. Always add a proper coolant mixture.
- The engine has aluminum parts and must be protected by an ethylene-glycol-based coolant to prevent corrosion and freezing.
- DO NOT USE alcohol or methanol antifreeze. DO NOT MIX alcohol or methanol with the coolant. This could damage the cooling system.
- Don't use a solution that contains more than 60 % antifreeze. This would reduce effectiveness.

# Owner Maintenance

For mixture percentage:

| Protection                                            | Volume              |       |
|-------------------------------------------------------|---------------------|-------|
|                                                       | Antifreeze solution | Water |
| Above $-16^{\circ}\text{C}$ ( $3^{\circ}\text{F}$ )   | 35%                 | 65%   |
| Above $-26^{\circ}\text{C}$ ( $-15^{\circ}\text{F}$ ) | 45                  | 55    |
| Above $-40^{\circ}\text{C}$ ( $-40^{\circ}\text{F}$ ) | 55                  | 45    |


## To change coolant

### **WARNING**

**Removing the Cooling System Cap:** Removing the cooling system cap or drain plug while the engine is running or hot is dangerous. This might lead to cooling system and engine damage and could result in serious injury from escaping hot coolant or steam. Turn off the engine and wait until it's cool. Even then, be very careful when removing the cap or drain plug. Wrap a thick cloth around it and slowly turn it counterclockwise to the first stop. Step back while the pressure escapes. When you're sure all the pressure is gone, press down on the cap — still using a cloth — turn the cap, and remove it.

## Manual transaxle

1. Remove the cooling system cap.




2. Only when the engine is cool, loosen the radiator drain plug and drain the coolant into a suitable container.
3. With the drain plug loose but not fully removed, flush out the system with running water.
4. Drain the system completely and retighten the plug. Add as much ethylene-glycol-based coolant and water as necessary to provide freezing and corrosion protection.
5. In extremely cold climates, add the amount recommended in the coolant manufacturer's instructions.
6. Run the engine at idle with the cooling system cap off. Slowly add additional coolant if necessary.
7. At this point, wait until the engine reaches normal operating temperature; then depress the accelerator two or three times. Add more coolant, if necessary, until the system is full.
8. Install the cooling system cap. Inspect all connections for leaks. Inspect the level in the coolant reservoir one more time.

## Owner Maintenance

### Automatic transaxle

1. Remove the cooling system cap.



2. Only when the engine is cool, remove the radiator drain plug and drain the coolant into a suitable container.
3. Flush out the system with running water.
4. Drain the system completely. Insert and tighten the plug. Add as much ethylene-glycol-based coolant and water as necessary to provide freezing and corrosion protection.
5. In extremely cold climates, add the amount recommended in the coolant manufacturer's instructions.
6. Run the engine at idle with the cooling system cap off. Slowly add additional coolant if necessary.
7. At this point, wait until the engine reaches normal operating temperature; then depress the accelerator two or three times. Add more coolant, if necessary, until the system is full.
8. Install the cooling system cap. Inspect all connections for leaks. Inspect the level in the coolant reservoir one more time.


### Brake/Clutch Fluid

#### ▼ Inspecting Brake/Clutch Fluid Level

The brakes and clutch draw fluid from the same reservoir.

Inspect the fluid level in the reservoir regularly. It should be kept at MAX.

The level normally drops with accumulated distance, a condition associated with wear of brake and clutch linings. If it is excessively low, have the brake/clutch system inspected by an Authorized Mazda Dealer.



**▼ Adding Brake/Clutch Fluid**** WARNING****Spilled Brake Fluid:**

*Spilled brake fluid is dangerous. If it gets in your eyes, they could be seriously injured. If this happens, immediately flush your eyes with water and get medical attention. Brake fluid spilled on a hot engine could cause a fire. Be careful not to spill brake fluid on yourself or on the engine.*

**Low Brake/Clutch Fluid Levels:**

*Low brake/clutch fluid levels are dangerous. Low levels could signal brake lining wear or a brake system leak. Your brakes could fail and cause an accident. If you find a low fluid level, have the brakes and clutch inspected.*

If the fluid level is low, add fluid until it reaches MAX.

Before adding fluid, thoroughly clean the area around the cap.

** CAUTION**

- Brake and clutch fluid will damage painted surfaces. If brake or clutch fluid does get on a painted surface, wipe it off immediately.
- Using nonspecified brake and clutch fluids (page 10-5) will damage the systems. Mixing different fluids will also damage them.  
If the brake/clutch system frequently requires new fluid, consult an Authorized Mazda Dealer.

## Owner Maintenance

### Power Steering Fluid

#### ▼ Inspecting Power Steering Fluid Level


##### ⚠ CAUTION

To avoid damage to the power steering pump, don't operate the vehicle for long periods when the power steering fluid level is low.

##### NOTE

Use specified power steering fluid (page 10-5).

Inspect the fluid level in the reservoir at each engine oil change with the engine off and cold. Add fluid if necessary; it does not require periodic changing.



The level must be kept between MIN and MAX.

Visually examine the lines and hoses for leaks and damage.

If new fluid is required frequently, consult an Authorized Mazda Dealer.

### Automatic Transaxle Fluid (ATF)

#### ▼ Inspecting Automatic Transaxle Fluid Level

The automatic transaxle fluid level should be inspected regularly. Measure it as described below.

The volume of fluid changes with the temperature. Fluid must be checked at idle without driving at normal operating temperature.

##### ⚠ CAUTION

- Low fluid level causes transaxle slippage. Overfilling can cause foaming, loss of fluid, and transaxle malfunction.
- Use specified fluid (page 10-5). A nonspecified fluid could result in transaxle malfunction and failure.


1. Park on a level surface and set the parking brake firmly.
2. Idle the engine about two minutes. Push down on the brake pedal.
3. Move the shift lever through all ranges and set it at P.

# Owner Maintenance

## ! WARNING

**Sudden Vehicle Movement:**  
*Shifting the shift lever without first depressing the brake pedal is dangerous. The vehicle could move suddenly and cause an accident. Make sure the brake pedal is applied before shifting the shift lever.*

4. With the engine still idling, pull out the dipstick, wipe it clean, and put it back.
5. Pull it out again.  
 The proper fluid level is marked on the dipstick as follows.



### **Fluid hot scale A**

When the vehicle has been driven and the fluid is at normal operating temperature, about 65°C (150°F), the level must be between Full and Low.

### **Fluid cold scale B**

When the engine has not been running and the outside temperature is about 20°C (70°F), the level must be between Full and Low.

## ! CAUTION

- Use the cold scale only as a reference.
- If outside temperature is lower than about 20°C (70°F), start the engine and inspect the fluid level after the engine reaches operating temperature.
- If the vehicle has been driven for an extended period at high speeds or in city traffic in hot weather, inspect the level only after stopping the engine and allowing the fluid to cool for 30 minutes.

Fully insert the dipstick. When adding fluid, inspect with the dipstick to make sure it doesn't pass full.

## NOTE

Inspect both sides of the dipstick for accurate reading.

## Owner Maintenance

### Washer Fluid

#### ▼ Inspecting Washer Fluid Level


#### **WARNING**

##### Substitute Washer Fluid:

*Using radiator antifreeze as washer fluid is dangerous. If sprayed on the windshield, it will dirty the windshield, affect your visibility, and could result in an accident. Use only windshield washer fluid or plain water in the reservoir.*

Inspect fluid level in the washer fluid reservoir; add fluid if necessary.

##### Sedan




The top of the float should be between FULL and LOW.

Use plain water if washer fluid is unavailable.

But use only washer fluid in cold weather to prevent it from freezing.

##### Hatchback



To inspect the washer fluid level in the front reservoir, pull off the cap. Then, holding your thumb over the hole in the center of the cap, lift it straight up. There should be fluid in the straw. Add fluid if necessary.

Use plain water if washer fluid is unavailable. But use only washer fluid in cold weather to prevent it from freezing.

## Owner Maintenance

### Body Lubrication

All moving points of the body, such as door and hood hinges and locks, should be lubricated each time the engine oil is changed. Use a nonfreezing lubricant on locks during cold weather.

Make sure the engine hood's secondary latch keeps the hood from opening when the primary latch is released.

### Air Filter

#### CAUTION

Don't drive without an air filter. This could result in excessive engine wear.


A viscous paper air filter fits inside the air cleaner housing, as shown. It's been specially treated and should not be cleaned and reused. Replace it when necessary.

#### ▼ Replacing the Air Filter

#### NOTE


If the vehicle is operated in very dusty or sandy areas, replace the filter more often than recommended intervals.

1. Unfasten the clamps.



## Owner Maintenance

2. Lift off the air filter cover and remove the filter.



3. Wipe inside the air cleaner housing with a damp cloth.
4. Replace the filter.
5. Install in the reverse order of removal.

Replace the filter according to Scheduled Maintenance (page 8-3).

## Wiper Blades

### ⚠ CAUTION

Hot waxes applied by automatic car washes have been known to affect the cleanability of windows.

Contamination of either the windshield or the blades with foreign matter can reduce wiper effectiveness. Common sources are insects, tree sap, and hot wax treatments used by some commercial car washes.

If the blades are not wiping properly, clean the window and blades with a good cleaner or mild detergent; then rinse thoroughly with clean water. Repeat if necessary.

### ⚠ CAUTION

To prevent damage to the wiper blades, don't use gasoline, kerosene, paint thinner, or other solvents on or near them.

### ▼ Replacing Windshield Wiper Blades


When the wipers no longer clean well, the blades are probably worn or cracked. Replace them.

### ⚠ CAUTION

To prevent damage to the wiper arms and other components, don't move the wipers by hand.

# Owner Maintenance


1. Raise the wiper arm and turn the blade assembly to expose the plastic locking clip. Compress the clip and slide the assembly downward; then lift it off the arm.




## ⚠ CAUTION

To prevent damage to the windshield, don't let the wiper arm fall on it.

2. Hold the end of the rubber and pull until the tabs are free of the metal support.



3. Remove the metal stiffeners from the blade rubber and install them in new blades.




## ⚠ CAUTION

- Don't bend the stiffeners. You need to use them again.
- If the metal stiffeners are switched, the blade's wiping efficiency could be reduced. So don't use the driver's side metal stiffeners on the passenger's side, or vice versa.
- Be sure to reinstall the metal stiffeners in the new blade rubber so that the curve is the same as it was in the old blade rubber.

# Owner Maintenance

4. Carefully insert the new blade rubber. Then install the blade assembly in the reverse order of removal.



**NOTE**

Install the blade so that the tabs are toward the bottom of the wiper arm.


**▼ Replacing Rear Window Wiper Blade (Hatchback)**

When the wiper no longer cleans well, the blade is probably worn or cracked. Replace it.

**! CAUTION**

To prevent damage to the wiper arm and other components, don't move the wiper by hand.


1. Raise the wiper arm and turn the blade assembly to expose the plastic locking clip. Compress the clip and slide the assembly downward; then lift it off the arm.



**! CAUTION**


To prevent damage to the rear window, don't let the wiper arm fall on it.

2. Pull down the blade rubber and slide it out of the blade holder.



# Owner Maintenance


3. Remove the metal stiffeners from the blade rubber and install them in new blades.



## ⚠ CAUTION

Don't bend the stiffeners. You need to use them again.

4. Carefully insert the new blade rubber. Then install the blade assembly in the reverse order of removal.



## Battery

### ⚠ WARNING

**Battery-Related Lead Materials:**  
 Battery posts, terminals and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm.  
 Wash hands after handling.


**Spilled Battery Fluid:**  
 Spilled battery fluid is dangerous. Battery fluid contains **SULFURIC ACID** which could cause serious injuries, if it gets in your eyes or on your skin. If this happens, immediately flush your eyes with water for 15 minutes or wash your skin thoroughly and get medical attention. Be careful not to get battery fluid on yourself.

**Battery-Related Explosion:**  
 Flames and sparks near open battery cells are dangerous. Hydrogen gas, produced during normal battery operation, could ignite and cause the battery to explode. An exploding battery can cause serious burns and injuries. Keep all flames, including cigarettes, and sparks away from open battery cells.

**Children and Batteries:**  
 Allowing children to play near batteries is dangerous. Battery fluid could cause serious injuries if it gets in the eyes or on the skin. Always keep batteries out of the reach of children.

## Owner Maintenance

### ▼ Battery Maintenance



To get the best service from a battery:

- Keep it securely mounted.
- Keep the top clean and dry.
- Keep terminals and connections clean, tight, and coated with petroleum jelly or terminal grease.
- Rinse off spilled electrolyte immediately with a solution of water and baking soda.
- If the vehicle will not be used for an extended time, disconnect the battery cables.

### Tires

For reasons of proper performance, safety, and better fuel economy, always maintain recommended tire inflation pressures and stay within the recommended load limits and weight distribution.

#### **WARNING**

##### **Using Different Tire Types:**

*Driving your vehicle with different types of tires is dangerous. It could cause poor handling and poor braking; leading to loss of control. Except when using the temporary spare tire, use only the same type tires (radial, bias-belted, bias-type) on all four wheels.*

##### **Using Wrong-Sized Tires:**

*Using any other tire size than what is specified for your Mazda (page 10-8) is dangerous. It could seriously affect ride, handling, ground clearance, tire clearance, and speedometer calibration. This could cause you to have an accident. Use only tires that are the correct size specified for your Mazda.*


# Owner Maintenance

## ▼ Tire Inflation Pressure

### **WARNING**

**Incorrect Tire Inflation:**  
*Overinflation or underinflation of tires is dangerous. Adverse handling or unexpected tire failure could result in a serious accident. Always inflate the tires to the correct pressure (page 10-8).*

Inspect all tire pressures monthly (including the spare) when the tires are cold. Maintain recommended pressures for the best ride, top handling, and minimum tire wear.



Refer to the specification charts (page 10-8).

### NOTE

- Warm tires normally exceed recommended pressures. Don't release air from warm tires to adjust the pressure.
- Underinflation can cause reduced fuel economy and poor sealing of the tire bead, which will deform the wheel and cause separation of tire from rim.
- Overinflation can produce a harsh ride and a greater possibility of damage from road hazards. Keep your tire pressure at the correct levels. If one frequently needs inflating, have it inspected.

## ▼ Unidirectional Tire Information (MAZDASPEED Protégé)

Your Mazda is originally equipped with unidirectional tires. The direction of tire rotation, which is determined by the directional tread pattern, affects the tire's performance, such as in wet conditions. Unidirectional tires must be installed according to the rolling direction marks. These marks are molded into the side wall of the tires.


### **CAUTION**

Unidirectional tires cannot be rotated side to side (such as right side of the vehicle to the left, or vice versa), or tire performance may be reduced in wet conditions. Rotate unidirectional tires only from front to rear.

# Owner Maintenance

## ▼ Tire Rotation

To equalize tread wear, rotate the tires every 12,000 km (7,500 miles) or sooner if irregular wear develops. During rotation, inspect them for correct balance.



Do not include (TEMPORARY USE ONLY) spare tire in rotation.

Also, inspect them for uneven wear and damage. Abnormal wear is usually caused by one or a combination of the following:

- Incorrect tire pressure
- Improper wheel alignment
- Out-of-balance wheel
- Severe braking

After rotation, inflate all tire pressures to specification (page 10-8) and inspect the lug nuts for tightness.

### ⚠ CAUTION

Rotate unidirectional tires and radial tires that have an asymmetrical tread pattern or studs only from front to rear, not from side to side. Tire performance will be weakened if rotated from side to side.

### ⚠ CAUTION

Limited-Slip Differential system; don't use the following:

- Tires not of the designated size
- Tires of different sizes or types at the same time
- Tires not sufficiently inflated

If these instructions aren't followed, the rotation of the left and right wheels will be different and will thus apply a constant load on the limited-slip differential.

This will cause a malfunction.


## ▼ Replacing a Tire

### ⚠ WARNING

#### **Worn Tires:**


***Driving with worn tires is dangerous. Reduced braking, steering, and traction could result in an accident. Always use tires that are in good condition.***

If a tire wears evenly, a wear indicator will appear as a solid band across the tread. Replace the tire when this happens.



New tread

Tread wear indicator



Worn tread

You may need to replace it before the band is across the entire tread.

## ▼ Temporary Spare Tire

Inspect the temporary spare tire at least monthly to make sure it's properly inflated and stored.

The temporary spare tire is easier to handle because of its construction. It is lighter and smaller than a conventional tire and should be used only for an emergency and only for a short distance.

Use the temporary only until the conventional tire is repaired, which should be as soon as possible.

Maintain its pressure at 420 kPa (4.2 kgf/cm<sup>2</sup> or bar, 60 psi).

## ⚠ CAUTION

- Don't use your temporary spare tire rim with a snow tire or a conventional tire. Neither will properly fit and could damage both tire and rim.
- The temporary spare tire has a tread life of up to 5,000 km (3,000 miles), depending on road conditions and driving habits.
- When the tread wear solid-band indicator appears, replace the tire with the same type of temporary spare (page 8-30).

## ▼ Replacing a Wheel

When replacing a wheel, make sure the new one is the same as the original factory wheel in diameter, rim width, and offset.

Proper tire balancing provides the best riding comfort and helps reduce tread wear. Out-of-balance tires can cause vibration and uneven wear, such as cupping and flat spots.

## ⚠ WARNING

### Using a Wrong-Sized Wheel:

*Using a wrong-sized wheel is dangerous. Braking and handling could be affected, leading to loss of control and an accident. Always use wheels of the correct size on your vehicle.*

# Owner Maintenance

---

|                                                                                                  |
|--------------------------------------------------------------------------------------------------|
|  <b>CAUTION</b> |
|--------------------------------------------------------------------------------------------------|


A wrong-sized wheel may adversely affect

- Tire fit
- Wheel and bearing life
- Ground clearance
- Snow-chain clearance
- Speedometer calibration
- Headlight aim
- Bumper height

**Light Bulbs****Sedan**

Overhead lights/Map lights

Headlights


Front turn signal lights/  
Parking lights

Side turn signal lights

Front side-marker lights

Brake lights/Taillights

Rear side-marker lights



Reverse lights

Taillights

High-mount brake light

Trunk light

Rear turn signal lights

License plate lights

# Owner Maintenance


---

## Hatchback

Overhead lights/Map lights

Headlights

Front turn signal lights/  
Parking lights




Side turn signal lights

Front side-marker lights

Reverse lights

Rear turn signal lights

Brake lights/Taillights



License plate lights

# Owner Maintenance


Your Mazda's headlights have replaceable halogen bulbs.

## ⚠ WARNING


### Handling Halogen Bulbs:

*When a halogen bulb breaks, it is dangerous. These bulbs contain pressurized gas. If one is broken, it will explode and serious injuries could be caused by the flying glass. If the glass portion is touched with bare hands, body oil could cause the bulb to overheat and explode when lit. Never touch the glass portion of the bulb with your bare hands and always wear eye protection when handling or working around halogen bulbs.*

#### Sedan



#### Hatchback



Headlight low beam      Headlight main beam


### Children and Halogen Bulbs:

*Playing with a halogen bulb is dangerous. Serious injuries could be caused by dropping a halogen bulb or breaking it some other way. Always keep halogen bulbs out of the reach of children.*


## ▼ Replacing a Headlight Bulb

### Sedan

1. Make sure the headlight switch is off.
2. Lift the hood and find the bulb in the rear of the headlight body.
3. Detach the electrical connector from the bulb by pulling it to the rear.



4. Pull off the sealing cover.
5. Unhook the bulb retaining spring.



6. Swing the retaining spring out and away to free the headlight bulb.
7. Carefully remove the headlight bulb from the socket by pulling it straight back.
8. Replace the bulb.

# Owner Maintenance

9. Install in the reverse order of removal.

## NOTE


- When reinstalling the sealing cover, make sure ↑ faces up.
- Use the protective cover and carton to dispose of the old bulb promptly out of the reach of children.

## Hatchback

1. Make sure the headlight switch is off.
2. Lift the hood and find the bulbs in the rear of the headlight body.


### (Low beam bulb)

3. Detach the electrical connector from the bulb by pulling it to the rear.



4. Pull off the sealing cover.

5. Unhook the bulb retaining spring.



6. Swing the retaining spring out and away to free the headlight bulb.
7. Carefully remove the headlight bulb from the socket by pulling it straight back.
8. Replace the bulb.
9. Install in the reverse order of removal.


## NOTE

- When reinstalling the sealing cover, make sure ↑ faces up.
- Use the protective cover and carton to dispose of the old bulb promptly out of the reach of children.

### (High beam bulb)

10. Turn the socket and bulb assembly counterclockwise and remove it. Carefully remove the headlight bulb from its socket in the reflector by gently pulling it straight backward out of the socket.

11. Remove the bulb from the electrical connector by pressing the tab on the connector with your finger and pulling the bulb upward.



12. Install the new bulb in the reverse order of removal.

**NOTE**

Use the protective cover and carton to dispose of the old bulb promptly out of the reach of children.


# Owner Maintenance

---


## ▼ Replacing a Bulb (Front)

To replace the fog light bulbs, contact an Authorized Mazda Dealer.  
To replace the front side-marker light bulbs (Hatchback), contact an Authorized Mazda Dealer.


Front turn signal lights/Parking lights



Front side-marker lights




Side turn signal lights




## ▼ Replacing a Bulb (Interior)

① Overhead light (Type B)


② Map lights (Type B)




Overhead light (Type A)



Map lights (Type A)



Luggage compartment light  
(Hatchback)



## Owner Maintenance


### ▼ Replacing a Bulb (Rear)

#### Rear bulb access


(Sedan)

To replace the turn signal light, brake light/taillight, side-marker light or reverse light bulb, the trunk end trim must be removed and the inside cover must be partially opened.

1. Pull the center section of the plastic retainer and remove the retainers and the trunk end trim.




2. Remove the inside cover's plastic retainers and partially open the inside cover.



#### (Hatchback)


To replace the turn signal light, brake light/taillight or reverse light bulb, remove the caps and the cover.




# Owner Maintenance

- ① Brake lights/Taillights
- ② Rear side-marker lights
- ③ Reverse lights
- ④ Taillights

## Sedan




## Rear turn signal lights Sedan




- ① Brake lights/Taillights
- ② Rear turn signal lights
- ③ Reverse lights

## Hatchback




## License plate lights


### Sedan




### Hatchback



## High-mount brake light (Sedan)



## Trunk light (Sedan)



# Owner Maintenance

## Fuses

Your vehicle's electrical system is protected by fuses.


If any lights, accessories, or controls don't work, inspect the appropriate circuit protector. If a fuse has blown, the inside element will be melted.

If the same fuse blows again, avoid using that system and consult an Authorized Mazda Dealer as soon as possible.


### ▼ Fuse Replacement

If the electrical system doesn't work, first inspect fuses on the driver's side.


1. Turn off the ignition switch and other switches.
2. Open the fuse panel cover.



3. Pull the fuse straight out with the fuse puller provided on the fuse panel.



4. Inspect it and replace if it's blown.



Normal



Blown

5. Push in a new fuse of the same rating, and make sure it fits tightly. If it doesn't, have an Authorized Mazda Dealer install it.


If you have no spare fuses, borrow one of the same rating from a circuit not essential to vehicle operation, such as the RADIO circuit.

### ⚠ CAUTION


Always replace a fuse with one of the same rating. Otherwise you may damage the electric system.

If the headlights or other electrical components don't work and the fuses in the cabin are OK, inspect the fuse block under the hood. If a fuse is blown, it must be replaced. Follow these steps:


1. Turn off the ignition switch and all other switches.
2. Remove the fuse block cover.



3. If a fuse is blown, replace it with a new one **of the same rating**.



Normal



Blown


**NOTE**

To replace the MAIN fuse, contact an Authorized Mazda Dealer (page 8-44).

# Owner Maintenance

## ▼ Fuse Panel Description


### Fuse block (Engine compartment)



| DESCRIPTION |             | FUSE RATING | PROTECTED COMPONENT                                       |
|-------------|-------------|-------------|-----------------------------------------------------------|
| 1           | HEATER      | 40 A        | Heater                                                    |
| 2           | ABS         | 60 A        | Antilock brake system, For protection of various circuits |
| 3           | IG KEY      | 60 A        | For protection of various circuits                        |
| 4           | PTC         | 30 A        | —                                                         |
| 5           | GLOW        | 40 A        | —                                                         |
| 6           | —           | —           | —                                                         |
| 7           | COOLING FAN | 30 A        | Cooling fan                                               |
| 8           | BTN         | 40 A        | Interior lights, Power door lock                          |
| 9           | AD FAN      | 30 A        | Additional cooling fan for air conditioner                |
| 10          | INJ OR FIP  | 30 A        | Engine control unit                                       |
| 11          | A/C         | 10 A        | Air conditioner                                           |

| DESCRIPTION |          | FUSE RATING | PROTECTED COMPONENT                |
|-------------|----------|-------------|------------------------------------|
| 12          | ST.SIG   | 10 A        | Starter signal                     |
| 13          | HORN     | 15 A        | Horn                               |
| 14          | HAZARD   | 15 A        | Hazard warning flashers            |
| 15          | TAIL     | 15 A        | Taillights                         |
| 16          | HEAD C/U | 7.5 A       | For protection of various circuits |
| 17          | FOG      | 15 A        | —                                  |
| 18          | FOG      | 15 A        | Fog lights                         |
| 19          | STOP     | 15 A        | Brake lights                       |
| 20          | HEAD-R   | 15 A        | Headlight-right                    |
| 21          | HEAD-L   | 15 A        | Headlight-left                     |
| 22          | —        | —           | —                                  |
| 23          | HEAD HI  | 15 A        | —                                  |
| 24          | MAIN     | 100 A       | For protection of all circuits     |

Fuse panel (Driver's side)



| DESCRIPTION |           | FUSE RATING | PROTECTED COMPONENT                                     |
|-------------|-----------|-------------|---------------------------------------------------------|
| 1           | S/WRM     | 15 A        | For protection of various circuits                      |
| 2           | H/CLN     | 20 A        | For protection of various circuits                      |
| 3           | RADIO     | 15 A        | Audio system                                            |
| 4           | A/C       | 15 A        | Air conditioner                                         |
| 5           | R.WIPER   | 10 A        | For protection of various circuits                      |
| 6           | —         | —           | —                                                       |
| 7           | —         | —           | —                                                       |
| 8           | ROOM      | 10 A        | Interior lights, Trunk light, Luggage compartment light |
| 9           | MIRR DEF  | 10 A        | —                                                       |
| 10          | —         | —           | —                                                       |
| 11          | DOOR LOCK | 30 A        | Power door lock                                         |
| 12          | P/WIND    | 30 A        | —                                                       |

| DESCRIPTION |        | FUSE RATING | PROTECTED COMPONENT         |
|-------------|--------|-------------|-----------------------------|
| 13          | WIPER  | 20 A        | Windshield wiper and washer |
| 14          | ENGINE | 10 A        | Engine control unit         |
| 15          | METER  | 10 A        | Instrument cluster          |
| 16          | —      | —           | —                           |
| 17          | P/WIND | 30 A        | Power windows               |

## Appearance Care

---

### How to Minimize Environmental Paint Damage

The paintwork on your Mazda represents the latest technical developments in composition and methods of application.

Environmental hazards, however, can harm the paint's protective properties, if proper care is not taken.

Here are some examples of possible damage, with tips on how to prevent them.

#### ▼ Etching Caused by Acid Rain or Industrial Fallout

##### Occurrence

Industrial pollutants and vehicle emissions drift into the air and mix with rain or dew to form acids. These acids can settle on a vehicle's finish. As the water evaporates, the acid becomes concentrated and can damage the finish.

And the longer the acid remains on the surface, the greater the chance is for damage.

##### Prevention

It is necessary to wash and wax your vehicle to preserve its finish according to the instructions in this section. These steps should be taken immediately after you suspect that acid rain has settled on your vehicle's finish.

#### ▼ Damage Caused by Bird Dropping, Insects, or Tree Sap

##### Occurrence

Bird droppings contain acids. If these aren't removed they can eat away the clear and color base coat of the vehicle's paintwork.

When insects stick to the paint surface and decompose, corrosive compounds form. These can erode the clear and color base coat of the vehicle's paintwork if they are not removed.

Tree sap will harden and adhere permanently to the paint finish. If you scratch the sap off while it is hard, some vehicle paint could come off with it.

##### Prevention

It is necessary to have your Mazda washed and waxed to preserve its finish according to the instructions in this section. This should be done as soon as possible.

Bird droppings can be removed with a soft sponge and water. If you are traveling and these are not available, a moistened tissue may also take care of the problem. The cleaned area should be waxed according to the instructions in this section.

Insects and tree sap are best removed with a soft sponge and water or a commercially available chemical cleaner.

Another method is to cover the affected area with dampened newspaper for one to two hours. After removing the newspaper, rinse off the loosened debris with water.

## ▼ Water Marks

### Occurrence

Rain, fog, dew, and even tap water can contain harmful minerals such as salt and lime. If moisture containing these minerals settles on the vehicle and evaporates, the minerals will concentrate and harden to form white rings. The rings can damage your vehicle's finish.

### Prevention

It is necessary to wash and wax your vehicle to preserve its finish according to the instructions in this section. These steps should be taken immediately after you find water marks on your vehicle's finish.

## ▼ Paint Chipping

### Occurrence

Paint chipping occurs when gravel thrown in the air by another vehicle's tires hits your vehicle.

### How to avoid paint chipping

Keeping a safe distance between you and the vehicle ahead reduces the chances of having your paint chipped by flying gravel.

### NOTE

- The paint chipping zone varies with the speed of the vehicle. For example, when traveling at 90 km/h (56 mph), the paint chipping zone is 50 m (164 ft).
- In low temperatures a vehicle's finish hardens. This increases the chance of paint chipping.
- Chipped paint can lead to rust forming on your Mazda. Before this happens, repair the damage by using Mazda touch-up paint according to the instructions in this section. Failure to repair the affected area could lead to serious rusting and expensive repairs.

## Appearance Care

### Exterior Care

Follow **all** label and container directions when using a chemical cleaner or polish. Read all warnings and cautions.

#### ▼ Maintaining the Finish

##### Washing

To help protect the finish from rust and deterioration, wash your Mazda thoroughly and frequently, at least once a month, with lukewarm or cold water.

If the vehicle is washed improperly, the paint surface could be scratched. Here are some examples of how scratching could occur.

Scratches occur on the paint surface when:

- The vehicle is washed without first rinsing off dirt and other foreign matter.
- The vehicle is washed with a rough, dry, or dirty cloth.
- The vehicle is washed at a car wash that uses brushes that are dirty or too stiff.
- Cleansers or wax containing abrasives are used.

##### **NOTE**

- Mazda is not responsible for scratches caused by automatic car washes or improper washing.
- Scratches are more noticeable on vehicles with darker paint finishes.

To minimize scratches on the vehicle's paint finish:

- Rinse off any dirt or other foreign matter using lukewarm or cold water before washing.
- Use plenty of lukewarm or cold water and a soft cloth when washing the vehicle. Do not use a nylon cloth.
- Rub gently when washing or drying the vehicle.
- Take your vehicle only to a car wash that keeps its brushes well maintained.
- Don't use abrasive cleansers or wax that contain abrasives.

### CAUTION

- Don't use steel wool, abrasive cleaners, or strong detergents containing highly alkaline or caustic agents on chrome-plated or anodized aluminum parts. This may damage the protective coating; also, cleaners and detergents may discolor or deteriorate the paint.
- To prevent damaging the antenna, retract it before entering a car wash facility or passing beneath a low overhead clearance.

Pay special attention to removing salt, dirt, mud, and other foreign material from the underside of the wings, and make sure the drain holes in the lower edges of the doors and rocker panels are clean.

## Appearance Care

Insects, tar, tree sap, bird droppings, industrial fallout, and similar deposits can damage the finish if not removed immediately. When prompt washing with plain water is ineffective, use a mild soap made for use on vehicles.

Thoroughly rinse off all soap with lukewarm or cold water. Don't allow soap to dry on the finish.

After washing the vehicle, dry it with a clean chamois to prevent water spots from forming.

### **WARNING**

***Driving with Wet Brakes:***  
*Driving with wet brakes is dangerous. Increased stopping distance or the vehicle pulling to one side when braking could result in a serious accident. Light braking will indicate whether the brakes have been affected. Dry the brakes by driving very slowly and applying the brakes lightly until brake performance is normal.*

### **Waxing**

Your vehicle needs to be waxed when water no longer beads on the finish. Always wash and dry the vehicle before waxing it. In addition to the vehicle body, wax the metal trim to maintain its luster.

1. Use wax which contains no abrasives. Waxes containing abrasive will remove paint and could damage bright metal parts.
2. Use a good grade of natural wax for metallic, mica, and solid colors.

3. When waxing, coat evenly with the sponge supplied or a soft cloth.

4. Wipe off the wax with a soft cloth.

### **NOTE**

A spot remover to remove oil, tar, and similar materials will usually also take off the wax. Rewax these areas even if the rest of the vehicle doesn't need it.

### ▼ **Repairing Damage to the Finish**

Deep scratches or chips on the finish should be repaired promptly. Exposed metal quickly rusts and can lead to major repairs.

### **CAUTION**

If your Mazda is damaged and needs metal parts repaired or replaced, make sure the body shop applies anti-corrosion materials to all parts, both repaired and new. This will prevent them from rusting.

### ▼ **Bright-Metal Maintenance**

- Use tar remover to remove road tar and insects. Never do this with a knife or similar tool.
- To prevent corrosion on bright-metal surfaces, apply wax or chrome preservative and rub it to a high luster.
- During cold weather or in coastal areas, cover bright-metal parts with a coating of wax or preservative heavier than usual. It would also help to coat them with noncorrosive petroleum jelly or some other protective compound.

## Appearance Care

---

### CAUTION

Don't use steel wool, abrasive cleaners, or strong detergents containing highly alkaline or caustic agents on chrome-plated or anodized aluminum parts. This may result in damage to the protective coating and cause discoloration or paint deterioration.

### ▼ Underbody Maintenance

Road chemicals and salt used for ice and snow removal and solvents used for dust control may collect on the underbody. If not removed, they will speed up rusting and deterioration of such underbody parts as fuel lines, frame, floor pan, and exhaust system, even though these parts may be coated with anti-corrosive material.

Thoroughly flush the underbody and wheel housings with lukewarm or cold water at the end of each winter. Try also to do this every month.

Pay special attention to these areas because they easily hide mud and dirt. **It will do more harm than good to wet down the road grime without removing it.**

The lower edges of doors, rocker panels, and frame members have drain holes that should not be clogged. Water trapped there will cause rusting.

### WARNING

***Driving with Wet Brakes:***  
***Driving with wet brakes is dangerous. Increased stopping distance or the vehicle pulling to one side when braking could result in a serious accident. Light braking will indicate whether the brakes have been affected. Dry the brakes by driving very slowly and applying the brakes lightly until brake performance is normal.***

### ▼ Aluminum Wheel Maintenance

A protective coating is provided over the aluminum wheels. Special care is needed to protect this coating.

#### NOTE

- Don't use a wire brush or any abrasive cleaner, polishing compound, or solvent on aluminum wheels. They may damage the coating.
- Only use a mild soap or neutral detergent and always use a sponge or soft cloth to clean the wheels. Rinse thoroughly with lukewarm or cold water. Also, be sure to clean the wheels after driving on dusty or salted roads. This helps prevent corrosion.
- Avoid washing your vehicle in an automatic car wash that uses high-speed or hard brushes.
- If your aluminum wheels lose luster, wax the wheels.

## Appearance Care

### Interior Care

#### ▼ Dashboard Precautions

Prevent caustic solutions such as perfume and cosmetic oils from contacting the dashboard. They'll damage and discolor it. If these solutions get on the dashboard, wipe them off immediately.

#### CAUTION

Do not use glazing agents. Glazing agents contain ingredients which may cause discoloration, wrinkling, cracks and peeling.

#### ▼ Cleaning the Upholstery and Interior Trim

##### Vinyl

Remove dust and loose dirt from vinyl with a whisk broom or vacuum cleaner. Clean vinyl with a leather-and-vinyl cleaner.

##### Leather

Real leather isn't uniform and may have scars, scratches, and wrinkles. Clean it with a leather cleaner or mild soap.

Wipe it with a **damp** soft cloth; then dry and buff it with a **dry** soft cloth.

#### Fabric

Remove dust and loose dirt from fabric with a whisk broom or vacuum cleaner. Clean it with a mild soap solution good for upholstery and carpets. Remove fresh spots immediately with a fabric spot cleaner.

To keep the fabric looking clean and fresh, take care of it. Otherwise its color will be affected, it can be stained easily, and its fire-resistance may be reduced.

#### CAUTION

Use only recommended cleaners and procedures. Others may affect appearance and fire-resistance.

#### ▼ Cleaning the Lap/Shoulder Belt Webbing

Clean the webbing with a mild soap solution recommended for upholstery or carpets. Follow instructions. Don't bleach or dye the webbing; this may weaken it.

After cleaning the belts, thoroughly dry the belt webbing and make sure there is no remaining moisture before retracting them.

#### WARNING

##### **Damaged Seat Belt:**

*Using damaged seat belts is dangerous. In a collision, damaged belts cannot provide adequate protection. Have your Authorized Mazda Dealer replace damaged belts immediately.*

# Appearance Care

---

## ▼ Cleaning the Window Interiors

If the windows become covered with an oily, greasy, or waxy film, clean them with glass cleaner. Follow the directions on the container.

|                                                                                                       |
|-------------------------------------------------------------------------------------------------------|
|  <b>CAUTION</b>      |
| Don't scrape or scratch the inside of the rear window. You may damage the rear window defroster grid. |

Important consumer information including warranties and add-on equipment.

|                                                          |      |
|----------------------------------------------------------|------|
| <b>Customer Assistance</b> .....                         | 9-2  |
| Customer Assistance (U.S.A.) .....                       | 9-2  |
| Customer Assistance (Canada) .....                       | 9-3  |
| Customer Assistance (Puerto Rico) .....                  | 9-6  |
| <b>Mazda Importer/Distributors</b> .....                 | 9-7  |
| Importer/Distributor .....                               | 9-7  |
| Distributor in Each Area .....                           | 9-7  |
| <b>Warranty</b> .....                                    | 9-8  |
| Warranties for Your Mazda .....                          | 9-8  |
| Outside the United States and Canada .....               | 9-9  |
| Add-On Non-Genuine Parts and Accessories .....           | 9-10 |
| <b>Cell Phones</b> .....                                 | 9-11 |
| Cell Phones Warning .....                                | 9-11 |
| <b>Uniform Tire Quality Grading System (UTQGS)</b> ..... | 9-12 |
| Uniform Tire Quality Grading System (UTQGS) .....        | 9-12 |
| <b>Reporting Safety Defects</b> .....                    | 9-14 |
| Reporting Safety Defects .....                           | 9-14 |
| <b>Service Publications</b> .....                        | 9-15 |
| Service Publications .....                               | 9-15 |

# Customer Assistance

## Customer Assistance (U.S.A.)

Your complete and permanent satisfaction is our business. We are here to serve you. All Authorized Mazda Dealers have the knowledge and the tools to keep your Mazda vehicle in top condition.

If you have any questions or recommendations for improvement regarding the service of your Mazda vehicle or servicing by Mazda Dealer personnel, we recommend that you take the following steps:

### ▼ STEP 1: Contact Your Mazda Dealer

Discuss the matter with an Authorized Mazda Dealer. This is the quickest and best way to address the issue. If your concern has not been resolved by the CUSTOMER RELATIONS, SALES, SERVICE, or PARTS MANAGER, then please contact the GENERAL MANAGER of the dealership or the OWNER.

### ▼ STEP 2: Call the Mazda National Customer Assistance Center #800

If for any reason you feel the need for further assistance after contacting your dealership management, call Mazda North American Operations' Customer Assistance Center toll-free at: **1 (800) 222-5500**.

In order to serve you efficiently and effectively, please help us by providing the following information:

1. Your name, address, and telephone number
2. Year and model of vehicle
3. Vehicle Identification Number (17 digits, noted on your registration or title or located on the upper driver's side corner of the dash)
4. Purchase date and current mileage
5. Your dealer's name and location
6. Your question(s)

If you would like to write a letter, please address it to the following, Attn: Customer Assistance, which corresponds with your state:

| REGIONAL OFFICE                                                                                                                 | AREAS COVERED |
|---------------------------------------------------------------------------------------------------------------------------------|---------------|
| Mazda North American Operations<br>7755 Irvine Center Drive<br>Irvine, CA 92618-2922<br>P.O. Box 19734<br>Irvine, CA 92623-9734 | All states    |

This way, we can be sure to respond to you as efficiently as possible. That is our goal. If you live outside the U.S.A., please contact your nearest Mazda Distributor.

## **Customer Assistance (Canada)**

### **▼ Satisfaction Review Process**

Your complete and permanent satisfaction is of primary concern to Mazda. All Authorized Mazda Dealers have both the knowledge and tools to keep your Mazda in top condition. In our experience, any questions, problems, or complaints regarding the operation of your Mazda or any other general service transactions are most effectively resolved by your dealer. If the cause of your dissatisfaction cannot adequately be addressed by normal dealership procedures, we recommend that you take the following steps:

### **▼ STEP 1: Contact the Mazda Dealer**

Discuss the matter with a member of dealership management. If the Service Manager has already reviewed your concerns, contact the owner of the dealership or its General Manager.

### **▼ STEP 2: Contact the Mazda Regional Office**

If you feel that you still require assistance, ask the dealer Service Manager to arrange for you to meet the local Mazda Service Representative. If more expedient, contact Mazda Canada Inc. Regional Office nearest you for such arrangements. Regional Office address and phone numbers are shown (page 9-5).

### **▼ STEP 3: Contact the Mazda Customer Relations Department**

If still not substantially satisfied, contact the Customer Relations Department, Mazda Canada Inc., 305 Milner Avenue, Suite 400 Scarborough, Ontario M1B 3V4 Canada  
TEL:1 (800) 263-4680.

Provide the Department with the following information:

1. Your name, address and telephone number
2. Year and model of vehicle
3. Vehicle Identification Number (VIN). Refer to the "Vehicle Identification Labels" page of section 10 of this manual for the location of the VIN.
4. Purchase date
5. Present odometer reading
6. Your dealer's name and location
7. The nature of your problem and/or cause of dissatisfaction

The Department, in cooperation with the local Mazda Service Representative, will review the case to determine if everything possible has been done to ensure your satisfaction.

## Customer Assistance

---

Please recognize that the resolution of service problems in most cases requires the use of your Mazda dealer's service facilities, personnel and equipment. We urge you to follow the above three steps in sequence therefore for most effective results.

### ▼ Mediation/Arbitration Program

Occasionally a customer concern cannot be resolved through Mazda's Customer Satisfaction Program. If after exhausting the procedures in this manual your concern is still not resolved, you have another option.

Mazda Canada Inc. participates in an arbitration program administered by the Canadian Motor Vehicle Arbitration Plan (CAMVAP). CAMVAP will advise you about how your concern may be reviewed and resolved by an independent third party through binding arbitration.

Your complete satisfaction is the goal of Mazda Canada Inc. and our dealers. Mazda's participation in CAMVAP makes a valuable contribution to our achieving that goal. There is no charge for using CAMVAP. CAMVAP results are fast, fair and final as the award is binding on both you and Mazda Canada Inc.

### ▼ Canadian Motor Vehicle Arbitration Plan (CAMVAP)

If a specific item of concern arises, where a solution cannot be reached between an owner, Mazda, and/or one of its dealers (that all parties cannot agree upon), the owner may wish to use the services offered by the Canadian Motor Vehicle Arbitration Plan (CAMVAP).

CAMVAP uses the services of Provincial Administrators to assist consumers in scheduling and preparing for their arbitration hearings. However, before you can proceed with CAMVAP you must follow your Mazda dispute resolution process as outlined previously.

CAMVAP is fully implemented in all provinces and territories. Consumers wishing to obtain further information about the Program can obtain an information booklet from your dealer, the Provincial Administrator or the Canadian Motor Vehicle Arbitration Plan Office at the following address or telephone number.

Canadian Motor Vehicle Arbitration Office  
235 Yorkland Boulevard, suite 300  
North York, Ontario  
M2J 4Y8  
1 (800) 207-0685

Customer Assistance

Provincial Administrators may be reached locally as listed below:

| Province/Territory                   | CAMVAP Number  |
|--------------------------------------|----------------|
| British Columbia & Yukon Territories | (604) 681-0312 |
| Alberta & Northwest Territories      | (403) 426-0650 |
| Saskatchewan                         | (306) 352-9259 |
| Manitoba                             | (204) 942-7166 |
| Ontario                              | (416) 596-8824 |
| Atlantic Canada                      | (902) 422-5413 |
| Quebec                               | (418) 649-1330 |

▼ Regional Offices

| REGIONAL OFFICES                                                                                                                      | AREAS COVERED                                                                       |
|---------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|
| MAZDA CANADA INC.<br>WESTERN REGION<br>8171 ACKROYD ROAD<br>SUITE 2000<br>RICHMOND B.C.<br>V6X 3K1<br>(604) 303-5670                  | ALBERTA,<br>BRITISH COLUMBIA,<br>MANITOBA,<br>SASKATCHEWAN,<br>YUKON                |
| MAZDA CANADA INC.<br>CENTRAL/ATLANTIC REGION<br>305 MILNER AVENUE<br>SUITE 400<br>SCARBOROUGH, ONTARIO<br>M1B 3V4<br>1 (800) 263-4680 | ONTARIO,<br>NEW BRUNSWICK,<br>NOVA SCOTIA,<br>PRINCE EDWARD ISLAND,<br>NEWFOUNDLAND |
| MAZDA CANADA INC.<br>QUEBEC REGION<br>6111 ROUTE TRANS<br>CANADIENNE<br>POINTE CLAIRE, QUEBEC<br>H9R 5A5<br>(514) 694-6390            | QUEBEC                                                                              |

# Customer Assistance

---

## Customer Assistance (Puerto Rico)

Your complete and permanent satisfaction is our business. That is why all Authorized Mazda Dealers have the knowledge and the tools to keep your Mazda vehicle in top condition.

If you have any questions or recommendations for improvement regarding the service of your Mazda vehicle or servicing by Mazda Dealer personnel, we recommend that you take the following steps:

### ▼ STEP 1

Discuss the matter with an Authorized Mazda Dealer. This is the quickest and best way to address the issue. If your concern has not been resolved by the CUSTOMER RELATIONS, SALES, SERVICE, or PARTS MANAGER, then please contact the GENERAL MANAGER of the dealership or the OWNER.

### ▼ STEP 2

If, after following STEP 1, you feel the need for further assistance, please contact your area's Mazda representative (Indicated on the next page).

Please help us by providing the following information:

1. Your name, address, and telephone number
2. Year and model of vehicle
3. Vehicle Identification Number (17 digits, noted on your registration or title or located on the upper driver's side corner of the dash)
4. Purchase date and current mileage
5. Your dealer's name and location
6. Your question(s)

# Mazda Importer/Distributors

---

## Importer/Distributor

### ▼ U.S.A.

#### **Mazda North American Operations**

7755 Irvine Center Drive

Irvine, CA 92618-2922 U.S.A.

P.O. Box 19734

Irvine, CA 92623-9734 U.S.A.

TEL: 1 (800) 222-5500 (in U.S.A.)

(949) 727-1990 (outside U.S.A.)

## Distributor in Each Area

### ▼ CANADA

#### **Mazda Canada Inc.**

305 Milner Avenue, Suite 400

Scarborough, Ontario M1B 3V4 Canada

TEL: 1 (800) 263-4680 (in Canada)

(416) 609-9909 (outside Canada)

### ▼ PUERTO RICO

#### **Plaza Motors Corp. (Mazda de Puerto Rico)**

P.O. Box 362722, San Juan, Puerto Rico

00936-2722

TEL: (787) 788-9300

### ▼ GUAM

#### **Triple J Motors**

157 South Marine Drive, Tamuning,

GUAM 96911 USA

P.O. Box 6066 Tamuning, Guam 96931

TEL: (671) 649-6555

### ▼ SAIPAN

#### **Pacific International Marianas, Inc. (d.b.a. Midway Motors)**

P.O. Box 887 Saipan, MP 96950

TEL: (670) 234-7524

#### **Triple J Saipan, Inc.**

(d.b.a. Triple J Motors)

P.O. Box 500487 Saipan, MP 96950-0487

TEL: (670) 234-7133/3051

### ▼ AMERICAN SAMOA

#### **Polynesia Motors, Inc.**

P.O. Box 1120, Pago Pago, American  
Samoa 96799

TEL: (684) 699-9347

# Warranty

---

## Warranties for Your Mazda

- New Vehicle Limited Warranty
- Distributor Major Component Limited Warranty (Canada only)
- Safety Restraint System Limited Warranty
- Anti-perforation Limited Warranty
- Federal Emission Control Warranty (U.S.A. only)
  - Emission Defect Warranty
  - Emission Performance Warranty
- California Emission Control Warranty (U.S.A. only)
- Emission Control Warranty (Canada only)
- Replacement Parts and Accessories Limited Warranty
- Tire Warranty

|                                                            |
|------------------------------------------------------------|
| <b>NOTE</b>                                                |
| Detailed warranty information is provided with your Mazda. |

## **Outside the United States and Canada**

Government regulations in the United States and Canada require that automobiles meet specific emission regulations and safety standards. Therefore, vehicles built for use in the United States, its territories, and Canada may differ from those sold in other countries.

The differences may make it difficult or even impossible for your vehicle to receive satisfactory servicing in other countries. We strongly recommend that you **NOT** take your Mazda outside these areas.

You may have these problems if you do:

- Recommended fuel may be unavailable. Any kind of leaded fuel or low-octane fuel will affect vehicle performance and damage the emission controls and engine.
- Proper repair facilities, tools, testing equipment, and replacement parts may not be available.

The Mazda warranty applies only to Mazda vehicles registered and normally operated in the United States, its territories, and Canada.

## Warranty

---

### Add-On Non-Genuine Parts and Accessories

Non-genuine parts and accessories for Mazda vehicles can be found in stores. These may fit your vehicle, but they are not approved by Mazda for use with Mazda vehicles. When you install non-genuine parts or accessories, they could affect your vehicle's performance or safety system; the Mazda warranty doesn't cover this. Before you install any non-genuine parts or accessories, consult an Authorized Mazda Dealer.

#### **WARNING**

**Installation of Non-Genuine Parts or Accessories:**

*Installation of non-genuine parts or accessories is dangerous. Improperly designed parts or accessories could seriously affect your vehicle's performance or safety system. This could cause you to have an accident or increase your chances of injuries in an accident. Always consult an Authorized Mazda Dealer before you install non-genuine parts or accessories.*

**Add-On Electrical and Electronic Equipment:**

*Incorrectly choosing or installing improper add-on equipment or choosing an improper installer is dangerous. Essential systems could be damaged, causing engine stalling, air-bag (SRS) activation, ABS inactivation, or a fire in the vehicle. Be very careful in choosing and installing add-on electrical equipment, such as mobile telephones, two-way radios, stereo systems, and car alarm systems.*

Mazda assumes no responsibility for death, injury, or expenses that may result from the installation of add-on non-genuine parts or accessories.

**Cell Phones Warning** **WARNING****Use of Cell Phones and Other Devices by Driver:**

*Although not Mazda products, use of any electrical devices such as cell phones, computers, portable radios, vehicle navigation or other devices by the driver while the vehicle is moving is dangerous. Dialing a number on a cell phone while driving also ties-up the driver's hands. Use of these devices will cause the driver to be distracted and could lead to a serious accident. If a passenger is unable to use the device, pull off the right-of-way to a safe area before use. If use of a cell phone is necessary despite this warning, use a hands-free system to at least leave the hands free to drive the vehicle. Never use a cell phone or other electrical device while the vehicle is moving and, instead, concentrate on the full-time job of driving.*

*Please comply to the legal regulations concerning the use of communication equipment in vehicles in your country.*

## Uniform Tire Quality Grading System (UTQGS)

---

### Uniform Tire Quality Grading System (UTQGS)

This information relates to the tire grading system developed by the U.S. National Highway Traffic Safety Administration for grading tires by tread wear, traction, and temperature performance.

#### ▼ Tread Wear

The tread wear grade is a comparative rating based on the wear rate of the tire when tested under controlled conditions on a specified government test course.

For example, a tire graded 150 would wear one-and-a-half times as well on the government course as a tire graded 100.

The relative performance of tires depends upon the actual conditions of their use, however, and may depart significantly from the norm because of variations in driving habits, service practices and differences in road characteristics and climate.

#### ▼ Traction-AA, A, B, C

The traction grades, from highest to lowest, are AA, A, B, and C. These grades represent the tire's ability to stop on wet pavement as measured under controlled conditions on specified government test surfaces of asphalt and concrete. A tire marked C may have poor traction performance.

### **WARNING**

*The traction grade assigned to this tire is based on braking (straight ahead) traction tests and does not include acceleration cornering (turning), hydroplaning, or peak traction characteristics.*

#### ▼ Temperature-A, B, C

The temperature grades are A (the highest), B, and C, represent the tire's resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on a specified indoor laboratory test wheel.

Sustained high temperature can cause the material of the tire to degenerate and reduce tire life, and excessive temperatures can lead to sudden tire failure.

Grade C corresponds to a level of performance which all passenger vehicle tires must meet under the Federal Motor Vehicle Safety Standard No. 109. Grades B and A represent higher levels of performance on the laboratory test wheel than the minimum required by law.

# Uniform Tire Quality Grading System (UTQGS)

## **WARNING**

*The temperature grade for this tire is established for a tire that is properly inflated and not overloaded. Excessive speed, underinflation, or excessive loading, either separately or in combination, can cause heat buildup and possible tire failure.*

These grades will be added to the sidewalls of passenger vehicle tires over the next several years according to a schedule established by the NHTSA and the tire manufacturers.

The grade of tires available as standard or optional equipment on Mazda vehicle may vary with respect to grade.

**ALL PASSENGER VEHICLE TIRES MUST CONFORM TO THESE GRADES AND TO ALL OTHER FEDERAL TIRE-SAFETY REQUIREMENTS.**


### ▼ Uniform Tire Quality Grading

Quality grades can be found where applicable on the tire sidewall between tread shoulder and maximum section width.

For example:

**Treadwear 200 Traction AA Temperature A**

**UTQGS MARK (example)**



# Reporting Safety Defects

---

## Reporting Safety Defects

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying Mazda Motor Corporation (Your Mazda Importer/Distributor).

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or Mazda Motor Corporation (Your Mazda Importer/Distributor).

To contact NHTSA, you may either call the Auto Safety Hotline toll-free at 1 (800) 424-9393 (or 366-0123 in Washington, D.C. area) or write to: NHTSA, U.S. Department of Transportation, Washington, D.C. 20590. You can also obtain other information about motor vehicle safety from the Hotline.

|                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p><b>NOTE</b></p> <p>If you live in the U.S.A., all correspondence to Mazda Motor Corporation should be forwarded to:</p> <p>Mazda North American Operations<br/>7755, Irvine Center Drive<br/>Irvine, California 92618-2922<br/>P.O. Box 19734<br/>Irvine, CA 92623-9734<br/>Customer Assistance Center or toll free at 1 (800) 222-5500</p> <p>If you live outside of the U.S.A., please contact the nearest Mazda Distributor shown (page 9-7) in this booklet.</p> |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

## Service Publications

Factory-authorized Mazda service publications are available for owners who wish to do some of their own maintenance and repair.

When requesting any of our publications through an Authorized Mazda Dealer, refer to the chart below.

If they don't have what you need in stock, they can order it for you.

| PUBLICATION ORDER NUMBER           | PUBLICATION DESCRIPTION        |
|------------------------------------|--------------------------------|
| 9999 95 017B 03                    | 2003 WORKSHOP MANUAL (English) |
| 9999 95 019G 03                    | 2003 WIRING DIAGRAM (English)  |
| 9999 95 038C 03 (U.S.A. only)      | 2003 OWNER'S MANUAL            |
| 9999 EC 038C 03 (Canada only)      | 2003 OWNER'S MANUAL            |
| 9999 PR 038C 03 (Puerto Rico only) | 2003 OWNER'S MANUAL            |

### ▼ WORKSHOP MANUAL:

Covers recommended maintenance and repair procedures of the drive train, body and chassis.

### ▼ WIRING DIAGRAM:

Provides electrical schematics as well as component location for the entire electrical system.

### ▼ OWNER'S MANUAL:

This booklet contains information regarding the proper care and operation of your vehicle. This is not a technician's manual.



---

# 10

## Specifications

Technical information about your Mazda.


|                                     |      |
|-------------------------------------|------|
| <b>Identification Numbers</b> ..... | 10-2 |
| Vehicle Information Labels .....    | 10-2 |
| <b>Specifications</b> .....         | 10-4 |
| Specifications .....                | 10-4 |

# Identification Numbers


## Vehicle Information Labels

### ▼ Vehicle Identification Number


The vehicle identification number legally identifies your vehicle. The number is on a plate attached to the left top side of the dashboard. This plate can easily be seen through the windshield.




### ▼ Motor Vehicle Safety Standard Label




### ▼ Chassis Number



### ▼ Vehicle Emission Control Information Label




### ▼ Tire Pressure Label




## ▼ Engine Number

1.6-liter engine



2.0-liter engine



# Specifications

## Specifications

### ▼ Engine

| Item              | Model                           |                                  |
|-------------------|---------------------------------|----------------------------------|
|                   | 1.6-liter engine                | 2.0-liter engine                 |
| Type              | DOHC-16V in-line, 4-cylinder    |                                  |
| Bore×Stroke       | 78.0 × 83.6 mm (3.07 × 3.29 in) | 83.0 × 92.0 mm (3.27 × 3.62 in)  |
| Displacement      | 1,598 ml (1,598 cc, 97.5 cu in) | 1,991 ml (1,991 cc, 121.5 cu in) |
| Compression ratio | 9.0                             | 9.1                              |

### ▼ Electrical System

| Item              |          | Model                                                     |                              |
|-------------------|----------|-----------------------------------------------------------|------------------------------|
|                   |          | 1.6-liter engine                                          | 2.0-liter engine             |
| Battery           |          | 12V-40AH/5HR                                              | 12V-40AH/5HR<br>12V-52AH/5HR |
| Alternator        |          | 12 V-70 A                                                 | 12 V-80 A                    |
| Starter           |          | 12 V - 1.0 kW                                             | 12 V - 1.0 kW                |
| Spark-plug number | MAZDA    | —                                                         | BP13 18 110, BP14 18 110     |
|                   | NGK      | ZFR5F-11, ZFR6F-11                                        | BKR5E-11, BKR6E-11, PZFR6F*  |
|                   | DENSO    | KJ16CR11, KJ20CR11                                        | K16PR-U11, K20PR-U11         |
|                   | CHAMPION | —                                                         | RC8YC4, RC10YC4              |
| Spark-plug gap    |          | 1.0—1.1 mm (0.040—0.043 in), 0.7—0.8 mm (0.028—0.031 in)* |                              |

\*Only for MAZDASPEED Protégé

## ▼ Lubricant Quality

(Except MAZDASPEED Protégé)

| Lubricant   | Classification            |        |
|-------------|---------------------------|--------|
|             | API Service               | ILSAC  |
| Engine oil* | SG (Energy Conserving II) | —      |
|             | SH (Energy Conserving II) | GF-I   |
|             | SJ                        | GF-II  |
|             | SL                        | GF-III |

\*Refer to the recommended SAE viscosity numbers on page 8-13.

(MAZDASPEED Protégé)

| Lubricant   | Classification |        |
|-------------|----------------|--------|
|             | API Service    | ILSAC  |
| Engine oil* | SL             | GF-III |

\*Refer to the recommended SAE viscosity numbers on page 8-13.

| Lubricant                 | Classification                             |             |              |
|---------------------------|--------------------------------------------|-------------|--------------|
| Manual transaxle oil      | Any temperature                            | API Service | GL-4 or GL-5 |
|                           |                                            | SAE         | 75W-90       |
|                           | Above 10°C (50°F)                          | API Service | GL-4 or GL-5 |
|                           |                                            | SAE         | 80W-90       |
| Automatic transaxle fluid | ATF M-V                                    |             |              |
| Power steering fluid      | ATF M-III or equivalent (e.g. Dexron® III) |             |              |
| Brake/Clutch fluid        | SAEJ1703 or FMVSS116 DOT-3                 |             |              |

## ▼ Capacities

(Approximate Quantities)

| Item          |                     |                                | Unit |               |                |
|---------------|---------------------|--------------------------------|------|---------------|----------------|
|               |                     |                                | L    | US qt         | Imp qt         |
| Engine oil    | 1.6-liter engine    | With oil filter replacement    | 3.2  | 3.4           | 2.8            |
|               |                     | Without oil filter replacement | 3.0  | 3.2           | 2.6            |
|               | 2.0-liter engine    | With oil filter replacement    | 3.5  | 3.7           | 3.1            |
|               |                     | Without oil filter replacement | 3.3  | 3.5           | 2.9            |
| Coolant       | 1.6-liter engine    | With heater                    | 6.0  | 6.3           | 5.3            |
|               |                     | Without heater                 | 5.5  | 5.8           | 4.8            |
|               | 2.0-liter engine    | With heater                    | 7.5  | 7.9           | 6.6            |
|               |                     | Without heater                 | 6.9  | 7.3           | 6.1            |
| Transaxle oil | Manual transaxle    |                                | 2.7  | 2.9           | 2.4            |
|               | Automatic transaxle |                                | 7.2  | 7.6           | 6.3            |
| Fuel tank     | 1.6-liter engine    |                                | 50   | 13.2 (US gal) | 11.0 (Imp gal) |
|               | 2.0-liter engine    |                                | 55   | 14.5 (US gal) | 12.1 (Imp gal) |

Check oil and fluid levels with dipsticks or reservoir gauges.

# Specifications

## ▼ Dimensions

| Item           | Model                                     |                     |
|----------------|-------------------------------------------|---------------------|
|                | Sedan                                     | Hatchback           |
| Overall length | 4,450 mm (175.2 in), 4,445 mm* (175.0 in) | 4,331 mm (170.5 in) |
| Overall width  | 1,705 mm (67.1 in)                        | 1,705 mm (67.1 in)  |
| Overall height | 1,410 mm (55.5 in)                        | 1,410 mm (55.5 in)  |
| Front tread    | 1,470 mm (57.9 in), 1,455 mm* (57.2 in)   | 1,465 mm (57.7 in)  |
| Rear tread     | 1,470 mm (57.9 in), 1,460 mm* (57.4 in)   | 1,470 mm (57.9 in)  |
| Wheelbase      | 2,610 mm (102.8 in)                       | 2,610 mm (102.8 in) |

\* Only for MAZDASPEED Protegé

## ▼ Weights

### Sedan

| Item                               |       | Weight              |                                              |
|------------------------------------|-------|---------------------|----------------------------------------------|
|                                    |       | 1.6-liter engine    | 2.0-liter engine                             |
| GVWR (Gross Vehicle Weight Rating) |       | 1,600 kg (3,527 lb) | 1,653 kg (3,644 lb),<br>1,674 kg* (3,691 lb) |
| GAWR (Gross Axle Weight Rating)    | Front | 850 kg (1,874 lb)   | 883 kg (1,947 lb),<br>889 kg* (1,960 lb)     |
|                                    | Rear  | 760 kg (1,675 lb)   | 780 kg (1,720 lb),<br>785 kg* (1,731 lb)     |
| CW (Curb Weight)*                  |       | —                   | 1,273 kg (2,807 lb)                          |

\* Only for MAZDASPEED Protegé

### Hatchback

| Item                               |                     |                     | Weight              |
|------------------------------------|---------------------|---------------------|---------------------|
| GVWR (Gross Vehicle Weight Rating) | Manual transaxle    |                     | 1,638 kg (3,611 lb) |
|                                    | Automatic transaxle |                     | 1,662 kg (3,664 lb) |
| GAWR (Gross Axle Weight Rating)    | Front               | Manual transaxle    | 863 kg (1,903 lb)   |
|                                    |                     | Automatic transaxle | 887 kg (1,955 lb)   |
|                                    | Rear                |                     | 780 kg (1,720 lb)   |
| CW (Curb Weight)                   | Manual transaxle    |                     | 1,232 kg (2,716 lb) |
|                                    | Automatic transaxle |                     | 1,247 kg (2,749 lb) |

## ▼ Air Conditioner

| Gas complies with SAE J639 | Maximum operating charge |
|----------------------------|--------------------------|
| HFC134a (R-134a)           | 0.525 kg (18.55 oz)      |

## ▼ Light Bulbs

| Light bulb                            |           |        | Wattage |
|---------------------------------------|-----------|--------|---------|
| Headlights                            | Sedan     |        | 60/55   |
|                                       | Hatchback | Hi     | 60      |
|                                       |           | Lo     | 55      |
| Front turn signal/Parking lights      |           |        | 27/8    |
| Side turn signal lights               |           |        | 5       |
| Fog lights                            |           |        | 55      |
| Rear turn signal lights               |           |        | 21      |
| Front side-marker lights              |           |        | 5       |
| Rear side-marker lights (Sedan)       |           |        | 3.8     |
| Taillights (Sedan)                    |           |        | 3.8     |
| Brake lights/Taillights               |           |        | 21/5    |
| High-mount brake light                | Sedan     | Type A | 21      |
|                                       |           | Type B | 5.8     |
|                                       | Hatchback |        | 5.8     |
| Reverse lights                        |           |        | 21      |
| License plate lights                  |           |        | 5       |
| Trunk light (Sedan)                   |           |        | 5       |
| Luggage compartment light (Hatchback) |           |        | 5       |
| Overhead light                        | Type A    |        | 10      |
|                                       | Type B    |        | 8       |
| Map lights                            |           |        | 5       |

# Specifications

---

## ▼ Tires

Check the tire pressure label for tire size and inflation pressure. Refer to Tire Inflation Pressure on page 8-29.

### Standard tire

| Tire size       | Inflation pressure                                                |                                                                   |
|-----------------|-------------------------------------------------------------------|-------------------------------------------------------------------|
|                 | Front                                                             | Rear                                                              |
| P185/65R14 85S  | 220 kPa (2.2 kgf/cm <sup>2</sup> , 32 psi or lb/po <sup>2</sup> ) | 220 kPa (2.2 kgf/cm <sup>2</sup> , 32 psi or lb/po <sup>2</sup> ) |
| 185/65R14 86T   | 210 kPa (2.1 kgf/cm <sup>2</sup> , 30 psi or lb/po <sup>2</sup> ) | 210 kPa (2.1 kgf/cm <sup>2</sup> , 30 psi or lb/po <sup>2</sup> ) |
| P195/55R15 84V  | 220 kPa (2.2 kgf/cm <sup>2</sup> , 32 psi or lb/po <sup>2</sup> ) | 220 kPa (2.2 kgf/cm <sup>2</sup> , 32 psi or lb/po <sup>2</sup> ) |
| 195/55R15 85V   | 210 kPa (2.1 kgf/cm <sup>2</sup> , 30 psi or lb/po <sup>2</sup> ) | 210 kPa (2.1 kgf/cm <sup>2</sup> , 30 psi or lb/po <sup>2</sup> ) |
| P195/50R16 83V  | 220 kPa (2.2 kgf/cm <sup>2</sup> , 32 psi or lb/po <sup>2</sup> ) | 220 kPa (2.2 kgf/cm <sup>2</sup> , 32 psi or lb/po <sup>2</sup> ) |
| 215/45ZR17 88W* |                                                                   |                                                                   |

\* Only for MAZDASPEED Protégé

### Temporary spare tire

| Tire size    | Inflation pressure |
|--------------|--------------------|
| T125/70 D14  | 420 kPa (60 psi)   |
| T115/70 D15  | 420 kPa (60 psi)   |
| T135/70 D15* | 420 kPa (60 psi)   |

\* Only for MAZDASPEED Protégé

## ▼ Fuses

Refer to the fuse rating on page 8-42.



# Index

---

## A

|                                                |      |
|------------------------------------------------|------|
| Add-On Non-Genuine Parts and Accessories ..... | 9-10 |
| Air Bag Systems .....                          | 2-36 |
| Air Filter .....                               | 8-23 |
| Antenna .....                                  | 6-10 |
| Anti-Lock Brake System (ABS) .....             | 5-7  |
| Warning light .....                            | 5-7  |
| Appearance Care .....                          | 8-46 |
| Ashtray .....                                  | 6-38 |
| Audio System .....                             | 6-10 |
| Audio set .....                                | 6-17 |
| Operating tips for audio system .....          | 6-11 |
| Safety certification .....                     | 6-34 |
| Automatic Transaxle .....                      |      |
| Driving tips .....                             | 5-12 |
| Fluid .....                                    | 8-20 |
| Overdrive .....                                | 5-12 |
| Shift-lock system .....                        | 5-11 |
| Transaxle ranges .....                         | 5-10 |
| Automatic Transaxle (Sport AT) .....           |      |
| Driving tips .....                             | 5-18 |
| Indicators .....                               | 5-16 |
| Manual shift mode .....                        | 5-15 |
| Recommendations for shifting .....             | 5-18 |
| Shifting .....                                 | 5-16 |
| Shifting specification .....                   | 5-17 |
| Shift-lock override .....                      | 5-15 |
| Shift-lock system .....                        | 5-15 |
| Transaxle ranges .....                         | 5-14 |

## B

|                      |      |
|----------------------|------|
| Battery .....        |      |
| Maintenance .....    | 8-27 |
| Specifications ..... | 10-4 |

## B

|                                   |      |
|-----------------------------------|------|
| Beeps .....                       |      |
| Ignition key reminder .....       | 5-35 |
| Lights-on reminder .....          | 5-35 |
| Seat belt warning beep .....      | 5-35 |
| Before Starting the Engine .....  | 4-5  |
| After getting in .....            | 4-5  |
| Before getting in .....           | 4-5  |
| Body Lubrication .....            | 8-23 |
| Brake/Clutch .....                |      |
| Fluid .....                       | 8-18 |
| Brakes .....                      |      |
| Anti-lock brake system (ABS) .... | 5-7  |
| Foot brake .....                  | 5-4  |
| Pad wear indicator .....          | 5-8  |
| Parking brake .....               | 5-5  |
| Warning light .....               | 5-5  |
| Break-In Period .....             | 4-6  |
| Bulb Replacement .....            | 8-33 |

## C

|                                          |      |
|------------------------------------------|------|
| Capacities .....                         | 10-5 |
| Carbon Monoxide .....                    | 4-4  |
| Cargo Securing Loops .....               | 6-39 |
| Catalytic Converter .....                | 4-3  |
| Cell Phones .....                        | 9-11 |
| Center Console .....                     | 6-39 |
| Child Restraint .....                    |      |
| Child restraint precautions .....        | 2-22 |
| Installing child-restraint systems ..... | 2-25 |
| LATCH child-restraint systems .....      | 2-31 |
| Child Safety Locks for Rear Door ....    | 3-8  |
| Cigarette Lighter .....                  | 6-37 |
| Climate Control System .....             | 6-2  |
| Gas specifications .....                 | 10-6 |
| Cruise Control .....                     | 5-19 |

## C

- Cup Holder .....6-38
- Customer Assistance .....9-2

## D

- Dashboard Illumination .....5-26
- Daytime Running Lights .....5-38
- Defroster
  - Rear window .....5-40
- Dimensions .....10-6
- Door Locks .....3-6
- Driving In Flooded Area .....4-10
- Driving Tips .....4-6
  - Automatic transaxle .....5-12
  - Automatic transaxle (Sport AT) .....5-18
  - Break-in period .....4-6
  - Driving in flooded area .....4-10
  - Hazardous driving .....4-7
  - Money-saving suggestions .....4-6
  - Rocking the vehicle .....4-7
  - Trailer towing .....4-12
  - Turbocharged vehicles .....4-11
  - Winter driving .....4-8

## E

- Emergency Starting .....7-16
  - Flooded engine .....7-16
  - Jump-starting .....7-16
  - Push-starting .....7-18
- Emergency Towing .....7-19
- Emission Control System .....4-3
- Engine
  - Coolant .....8-16
  - Exhaust gas .....4-4
  - Hood release .....3-18
  - Oil .....8-13

## E

- Overheating .....7-14
- Starting .....5-3
- Engine Compartment Overview .....8-12
- Engine Coolant
  - Overheating .....7-14
- Engine Coolant Temperature
  - Gauge .....5-25
- Exhaust Gas .....4-4
- Exterior Care .....8-48

## F

- Flasher
  - Hazard warning .....5-41
  - Headlights .....5-36
- Flat Tire .....7-3
  - Changing .....7-7
  - Spare tire and tool storage .....7-3
- Fluids
  - Classification .....10-5
  - Owner maintenance .....8-10
- Fog Lights .....5-37
- Foot Brake .....5-4
- Front Seats .....2-2
- Fuel
  - Filler lid and cap .....3-16
  - Gauge .....5-26
  - Requirements .....4-2
  - Tank capacity .....10-5
- Fuses .....8-42
  - Panel description .....8-44
  - Replacement .....8-42

## G

- Gauges .....5-23
- Glove Box .....6-39

# Index

---

## H

|                              |      |
|------------------------------|------|
| Hazard Warning Flasher ..... | 5-41 |
| Hazardous Driving .....      | 4-7  |
| Headlights                   |      |
| Control .....                | 5-36 |
| Flashing .....               | 5-36 |
| High-low beams .....         | 5-36 |
| On reminder .....            | 5-36 |
| Hood Release .....           | 3-18 |
| Horn .....                   | 5-41 |

## I

|                                |      |
|--------------------------------|------|
| Ignition                       |      |
| Keys .....                     | 3-2  |
| Switch .....                   | 5-2  |
| Illuminated Entry System ..... | 6-35 |
| Indicator Lights .....         | 5-27 |
| Cruise set .....               | 5-35 |
| Headlight high-beam .....      | 5-34 |
| O/D OFF .....                  | 5-34 |
| Shift position .....           | 5-34 |
| Instrument Cluster .....       | 5-23 |
| Interior Care .....            | 8-51 |
| Interior Lights .....          | 6-35 |

## J

|                     |      |
|---------------------|------|
| Jump-Starting ..... | 7-16 |
|---------------------|------|

## K

|                            |     |
|----------------------------|-----|
| Keyless Entry System ..... | 3-2 |
| Keys .....                 | 3-2 |

## L

|                                 |      |
|---------------------------------|------|
| Label Information .....         | 10-2 |
| Lane-Change Signals .....       | 5-37 |
| Liftgate .....                  | 3-9  |
| Light Bulbs                     |      |
| Replacement .....               | 8-33 |
| Specifications .....            | 10-7 |
| Lighter .....                   | 6-37 |
| Lighting Control .....          | 5-36 |
| Lubricant Quality .....         | 10-5 |
| Luggage Compartment .....       | 3-10 |
| Luggage Compartment Light ..... | 6-37 |

## M

|                                     |      |
|-------------------------------------|------|
| Maintenance .....                   | 8-1  |
| Introduction .....                  | 8-2  |
| Owner maintenance precautions ..... | 8-11 |
| Owner maintenance schedule .....    | 8-10 |
| Scheduled .....                     | 8-3  |
| Manual Transaxle Operation .....    | 5-8  |
| Recommendations for shifting .....  | 5-9  |
| Map Lights .....                    | 6-36 |
| Meters and Gauges .....             | 5-23 |
| Mirrors                             |      |
| Outside mirrors .....               | 3-23 |
| Rearview mirror .....               | 3-24 |
| Money-Saving Suggestions .....      | 4-6  |

## O

|                               |      |
|-------------------------------|------|
| Odometer and Trip Meter ..... | 5-24 |
| Outside Mirrors .....         | 3-23 |
| Overhead Lights .....         | 6-36 |
| Overheating .....             | 7-14 |
| Overloading .....             | 4-10 |

## P

|                               |      |
|-------------------------------|------|
| Paint Damage .....            | 8-46 |
| Parking Brake .....           | 5-5  |
| Parking in an Emergency ..... | 7-2  |
| Power Door Locks .....        | 3-8  |
| Power Steering .....          | 5-19 |
| Fluid .....                   | 8-20 |
| Power Windows .....           | 3-14 |
| Push-Starting .....           | 7-18 |

## R

|                                    |      |
|------------------------------------|------|
| Rear Door Child Safety Locks ..... | 3-8  |
| Rear Seat .....                    | 2-5  |
| Rear Window Defroster .....        | 5-40 |
| Rear Window Washer .....           | 5-40 |
| Rear Window Wiper .....            | 5-40 |
| Rearview Mirror .....              | 3-24 |
| Recreational Towing .....          | 7-21 |
| Rocking the Vehicle .....          | 4-7  |
| Roof Rack .....                    | 3-21 |

## S

|                                      |      |
|--------------------------------------|------|
| Safety Defects, Reporting .....      | 9-14 |
| Seat Belt System                     |      |
| 3-point type .....                   | 2-14 |
| Extender .....                       | 2-20 |
| Pregnant women .....                 | 2-12 |
| Pretensioner and load limiting ..... | 2-16 |
| Rear-center lap/shoulder .....       | 2-18 |
| Seat belt precautions .....          | 2-11 |
| Warning beep .....                   | 2-21 |
| Warning light .....                  | 2-21 |
| Seats                                |      |
| Front seats .....                    | 2-2  |
| Rear seat .....                      | 2-5  |
| Service Publications .....           | 9-14 |
| Spare Tire and Tool Storage .....    | 7-3  |

## S

|                                  |      |
|----------------------------------|------|
| Specifications .....             | 10-4 |
| Speedometer .....                | 5-24 |
| SRS Air Bags                     |      |
| Air bag system description ..... | 2-40 |
| Supplemental restraint systems   |      |
| precautions .....                | 2-36 |
| Warning light .....              | 2-45 |
| Starting the Engine .....        | 5-3  |
| Steering Wheel .....             | 3-23 |
| Horn .....                       | 5-41 |
| Storage Compartments .....       | 6-39 |
| Cargo securing loops .....       | 6-39 |
| Center console .....             | 6-39 |
| Glove box .....                  | 6-39 |
| Sunroof .....                    | 3-19 |
| Sunshade .....                   | 3-20 |
| Sunvisors .....                  | 6-35 |

## T

|                                   |      |
|-----------------------------------|------|
| Tachometer .....                  | 5-25 |
| Temporary Spare Tire .....        | 8-31 |
| Tiedown                           |      |
| Hook .....                        | 7-20 |
| Tires                             |      |
| Flat tire .....                   | 7-3  |
| Inflation pressure .....          | 8-29 |
| Replacement .....                 | 8-30 |
| Rotation .....                    | 8-30 |
| Snow tires .....                  | 4-8  |
| Spare tire and tool storage ..... | 7-3  |
| Specifications .....              | 10-8 |
| Tire chains .....                 | 4-9  |
| Uniform tire quality grading      |      |
| system (UTQGS) .....              | 9-12 |
| Tool .....                        | 7-3  |

# Index

---

## T

|                                    |      |
|------------------------------------|------|
| Towing                             |      |
| Description .....                  | 7-19 |
| Emergency towing .....             | 7-19 |
| Hook .....                         | 7-20 |
| Recreational towing .....          | 7-21 |
| Trailer towing .....               | 4-12 |
| Trailer Towing .....               | 4-12 |
| Trip Meter .....                   | 5-24 |
| Trunk Lid .....                    | 3-11 |
| Trunk Light .....                  | 3-12 |
| Trunk Release Handle .....         | 3-12 |
| Turn and Lane-Change Signals ..... | 5-37 |

## V

|                                  |      |
|----------------------------------|------|
| Vanity Mirrors .....             | 6-35 |
| Vehicle Information Labels ..... | 10-2 |

## W

|                              |      |
|------------------------------|------|
| Warning Lights .....         | 5-27 |
| Air bag system .....         | 5-32 |
| Anti-lock brake system       |      |
| (ABS) .....                  | 5-32 |
| Automatic transaxle .....    | 5-33 |
| Brake system .....           | 5-29 |
| Charging system .....        | 5-30 |
| Check engine .....           | 5-31 |
| Door-ajar .....              | 5-33 |
| Engine oil pressure .....    | 5-31 |
| Front seat belt pretensioner |      |
| system .....                 | 5-32 |
| Low fuel .....               | 5-33 |
| Low washer fluid level ..... | 5-33 |
| Seat belt .....              | 5-33 |
| Warranty .....               | 9-8  |
| Washer Fluid .....           | 8-22 |
| Weights .....                | 10-6 |

## W

|                          |      |
|--------------------------|------|
| Wheel Replacement .....  | 8-31 |
| Windows                  |      |
| Power windows .....      | 3-14 |
| Windshield Washer .....  | 5-39 |
| Windshield Wipers .....  | 5-39 |
| Blades replacement ..... | 8-24 |
| Winter Driving .....     | 4-8  |