

# FORTE

## Features & Functions Guide



**Delivery First**  
The priority that delivers more

# GETTING TO KNOW YOUR **FORTE**

## **Congratulations on Your New Kia Purchase!**

Your new Kia vehicle has been designed, engineered and manufactured to provide you with years of comfortable and dependable driving. Kia is committed to quality, innovation, safety and — above all — your satisfaction.

## **Using This Guide**

The information contained in this guide is a brief overview that will help you become familiar with the operation and features of your new Kia vehicle. The flipbook format facilitates information access, while the detailed illustrations help to ensure the instructions are easy to follow.

This **Features & Functions Guide**, and the specific operational and safety information it provides, is not a substitute for your Owner's Manual. In the interest of your safety and that of your family, and to help you avoid risks that may result in death or serious injury, Kia reminds you to carefully read your Owner's Manual in order to fully familiarize yourself with the important information it contains.

While the information contained in this guide is accurate at the time of printing, Kia may change vehicle specifications without notice in advance or after the fact, and assumes no liability in connection with such changes.

[www.kia.com](http://www.kia.com)

Consumer - Roadside Assistance  
1-800-333-4KIA (4542)

See Back Pages for Vehicle Maintenance Schedule

*Always check the Owner's Manual for complete operating information and safety warnings.*

## ESSENTIAL FEATURES

|                                                                           |    |
|---------------------------------------------------------------------------|----|
| Active ECO System (ECO Mode)* . . . . .                                   | 08 |
| Air Conditioning / Climate Control* . . . . .                             | 26 |
| Audio System — Standard Audio Systems* . . . . .                          | 20 |
| Audio System — UVO eServices System* . . . . .                            | 23 |
| Audio System — UVO eServices with Premium<br>Navigation System* . . . . . | 24 |
| Aux/USB/iPod® Port & Power Outlets . . . . .                              | 25 |
| <b>Bluetooth®</b> Wireless Technology . . . . .                           | 18 |
| Cruise Control . . . . .                                                  | 17 |
| Digital Clock . . . . .                                                   | 25 |
| Folding Rear Seats . . . . .                                              | 32 |
| Fuel Economy . . . . .                                                    | 07 |
| Manual Gear Shift* . . . . .                                              | 29 |
| Passenger Airbag Off Indicator . . . . .                                  | 40 |
| Rear-Camera Display* . . . . .                                            | 39 |
| Smart Key* . . . . .                                                      | 35 |
| Tire Pressure Monitoring System (TPMS) . . . . .                          | 07 |
| Windshield Wipers & Washers . . . . .                                     | 15 |

*Driving while distracted can result in a loss of vehicle control that may lead to an accident, severe personal injury and death. The driver's primary responsibility is in the safe and legal operation of a vehicle, and use of any handheld devices, other equipment or vehicle systems which take the driver's eyes, attention and focus away from the safe operation of a vehicle or that are not permissible by law should never be used during operation of the vehicle.*



**FORTE** FEATURES & FUNCTIONS GUIDE

|                                        |    |
|----------------------------------------|----|
| <b>VIDEOS &amp; QR CODES</b> . . . . . | 02 |
|----------------------------------------|----|

## INSTRUMENT CLUSTER

|                                                  |    |
|--------------------------------------------------|----|
| Instrument Cluster Overview . . . . .            | 03 |
| Indicators & Warning Lights . . . . .            | 04 |
| LCD Instrument Cluster Modes* . . . . .          | 05 |
| Trip Computer / Tripmeter . . . . .              | 05 |
| User Setting Mode* . . . . .                     | 06 |
| Service Mode . . . . .                           | 06 |
| Fuel Economy . . . . .                           | 07 |
| Tire Pressure Monitoring System (TPMS) . . . . . | 07 |
| Drive Mode Integrated Control System . . . . .   | 08 |
| Active ECO System (ECO Mode)* . . . . .          | 08 |

## DRIVER'S PANEL

|                                                                                        |    |
|----------------------------------------------------------------------------------------|----|
| Electronic Stability Control (ESC) . . . . .                                           | 09 |
| Heated Steering Wheel* . . . . .                                                       | 09 |
| Instrument Panel Dimmer . . . . .                                                      | 09 |
| Hill-start Assist Control (HAC)* . . . . .                                             | 09 |
| Blind Spot Detection (BSD) System . . . . .                                            | 10 |
| Lane Keeping Assist System (LKAS) /<br>Lane Departure Warning System (LDWS)* . . . . . | 11 |
| Autonomous Emergency Braking (AEB) /<br>Front Collision Warning System* . . . . .      | 11 |
| Engine Start/Stop Button* . . . . .                                                    | 12 |
| Power Windows, Window Lock & Central Door Lock . . . . .                               | 13 |
| Power/Folding Mirrors* . . . . .                                                       | 13 |
| Power/Heated Outside Mirrors . . . . .                                                 | 13 |
| Automatic Door Lock/Unlock . . . . .                                                   | 13 |

## STEERING WHEEL CONTROLS

|                                                 |    |
|-------------------------------------------------|----|
| Headlights & High Beams . . . . .               | 14 |
| Turn Signals & Fog Lights* . . . . .            | 14 |
| Windshield Wipers & Washers . . . . .           | 15 |
| Rear Wiper & Washer* . . . . .                  | 15 |
| Tilt/Telescoping Steering Wheel . . . . .       | 16 |
| FlexSteer™ Steering Wheel Mode* . . . . .       | 16 |
| Audio Controls . . . . .                        | 17 |
| Cruise Control* . . . . .                       | 17 |
| <b>Bluetooth®</b> Wireless Technology . . . . . | 18 |

## AUDIO SYSTEMS

|                                           |    |
|-------------------------------------------|----|
| Standard Audio System (Type A)* . . . . . | 20 |
| Standard Audio System (Type B)* . . . . . | 21 |

|                                                         |    |
|---------------------------------------------------------|----|
| UVO eServices Setup* . . . . .                          | 22 |
| UVO eServices System* . . . . .                         | 23 |
| UVO eServices with Premium Navigation System* . . . . . | 24 |

## CENTER PANEL

|                                                           |    |
|-----------------------------------------------------------|----|
| Digital Clock . . . . .                                   | 25 |
| Aux/USB/iPod® Port & Power Outlets . . . . .              | 25 |
| Automatic Climate Control* . . . . .                      | 26 |
| Manual Climate Control* . . . . .                         | 27 |
| Automatic Gear Shift with Sportmatic® Shifting* . . . . . | 28 |
| Manual Gear Shift* . . . . .                              | 29 |

## SEATING

|                                                  |    |
|--------------------------------------------------|----|
| 6-Way Manual Adjustable Driver's Seat* . . . . . | 30 |
| Seat Warmers / Ventilated Seats* . . . . .       | 30 |
| 10-way Power Adjustable Driver's Seat* . . . . . | 31 |
| Driver Position Memory System* . . . . .         | 31 |
| Front Seat Headrest Adjustment . . . . .         | 31 |
| Folding Rear Seats . . . . .                     | 32 |

## OTHER KEY FEATURES

|                                                                 |    |
|-----------------------------------------------------------------|----|
| Sunroof Operation* . . . . .                                    | 33 |
| Map/Room Lamps* . . . . .                                       | 33 |
| Remote Keyless Entry (Folding Key)* . . . . .                   | 34 |
| Double-Turn Lock / Unlock All . . . . .                         | 34 |
| Smart Key . . . . .                                             | 35 |
| Power Trunk / Smart Trunk* . . . . .                            | 36 |
| Hood Release Lever and Latch . . . . .                          | 37 |
| Sunvisor . . . . .                                              | 37 |
| Trunk Release Button . . . . .                                  | 37 |
| HomeLink® / Auto-Dimming Rearview Mirror* . . . . .             | 38 |
| Rear-Camera Display* . . . . .                                  | 39 |
| Fuel Cap / Malfunction Indicator (Check Engine Light) . . . . . | 39 |
| Child Safety Locks . . . . .                                    | 39 |

## SAFETY FEATURES

|                                                                               |    |
|-------------------------------------------------------------------------------|----|
| Seat Belts . . . . .                                                          | 40 |
| Seat Belts Retractor Locks . . . . .                                          | 40 |
| Occupant Detection System (ODS) /<br>Passenger Airbag Off Indicator . . . . . | 40 |

## NORMAL MAINTENANCE SCHEDULE . . . . . 41

## LEGAL DISCLAIMERS . . . . . See Back Inside Cover Page

\*IF EQUIPPED

Kia provides a number of video resources at your disposal to assist you with becoming familiar with the features and functions found in your Kia vehicle. You can access these resources by snapping the QR Codes with your smartphone/tablet (mobile devices) or by visiting the following website: [www.KuTechVideos.com/yd13/2017](http://www.KuTechVideos.com/yd13/2017). Continue reading for a more in-depth look at QR Codes and for instructions on how to use them.

### What are QR Codes?

A QR Code is a square, 2-dimensional barcode that can be read by mobile devices loaded with an appropriate barcode or QR Code Reader App. The app reads the barcode image and then launches/uploads the specific information the code contains, such as URLs, text, photos, videos and so much more.

### How to Use QR Codes

If you have a mobile device with a QR Code Reader App, you can snap the code with your phone and you'll be provided a video with additional information pertaining to the topic. For example, in the Fuel Cap section, if you would like additional information, just snap the code with your mobile device to view the selected Kia Features & Functions Video.

### How to snap a QR Code

1. With your mobile device, download a QR Code Reader App. With many devices, you can do this through an app store or marketplace
2. Open the QR Code Reader App on your mobile device
3. The app will utilize your device's camera. Center the code in the camera viewing area:
  - With some apps, as soon as the app recognizes the code, it will launch the corresponding video
  - With other apps, you will have to snap or take a picture of the code. The app will then launch the corresponding video
  - For operation specifics, refer to the instructions that come with the QR Code Reader App

### QR CODE

#### One Click Fuel Cap Video

To view a video on your mobile device, snap this QR Code or visit the listed website.



[www.KuTechVideos.com/yd13/2017](http://www.KuTechVideos.com/yd13/2017)

**REMINDER:** When accessing videos on your mobile device, standard cellular data rates may apply.


### QUICK TIPS

1. If you're having trouble scanning codes, check the following:
  - The code should be centered and focused in your mobile device's camera screen
  - Consider moving your device closer to or farther away from the code
  - The code should be well lit, without significant shadow
  - Avoid scanning from a significant angle
  - Confirm that the device's app supports 2D QR Code scanning.
  - Try another QR Code Reader app; not all apps are created equal
2. After scanning, if a "connecting" message appears and then nothing happens or there's a "connection error" message, this typically indicates that your device is having trouble connecting to the Internet


## Instrument Cluster Overview

- A** Tachometer
- B** Speedometer
- C** Turn Signal Indicators
- D** LCD Screen/Odometer/Tripmeter\*
- E** Gear Shift Position Indicator\*
- F** Fuel Gauge
- G** Engine Coolant Temperature Gauge

Your vehicle's instrument cluster & indicator light locations may differ from those in the illustrations. For more information on the instrument cluster, the LCD Warning Messages and the function of all indicator and warning lights, please refer to the Owner's Manual.



# Indicators & Warning Lights



Your vehicle's instrument cluster & indicator light locations may differ from those in the illustrations. For more information on the instrument cluster and the function of all indicator and warning lights, please refer to the Owner's Manual.

Low Tire Pressure Indicator / TPMS Malfunction Indicator

Electronic Stability Control OFF Indicator

**ECO** ECOMINDER™ (ECO) Indicator\*

Anti-Lock Brake System (ABS) Indicator

Trunk/Hatch Open Indicator

Immobilizer Indicator

Electronic Stability Control Indicator

**KEY OUT** KEY OUT Indicator

Malfunction Indicator\*

Light on Indicator

Fog Lights Indicator\*

Electronic Power Steering (EPS) Warning Indicator\*

Engine Oil Pressure Warning Indicator

Safety Belt Warning Indicator

Door Ajar Warning Indicator

Electronic Brake Force (EBD) System Warning Light

Parking Brake / Brake Fluid Warning Indicator

Airbag Warning Indicator

Charging System Warning Indicator

High Beam Indicator

Low Fuel Level Warning Indicator

**CRUISE** Cruise Control ON Indicator\*

**SET** Cruise Control Set Indicator\*

Washer Fluid Level Warning Indicator

## LCD Instrument Cluster Modes\*

Press Mode button **A** to scroll through the different LCD modes:



**Trip Computer Mode:** Displays driving information for tripmeter, fuel economy, etc.



**A/V Mode\*:** Displays the state of the A/V System




**Turn-by-Turn Mode\*:** Displays the state of the navigation



**User Settings Mode:** Change settings of the doors, lamps and other features




**Information Mode:** Informs on service intervals and pressure status of each tire and other features




## Trip Computer / Tripmeter


The Trip Computer is a driver information system that displays information related to driving on the display when the ignition switch or the ENGINE START/STOP button\* is in the ON position.



**Instrument Cluster Type A** – To toggle through the different Trip Computer modes, press the Trip button **B**. When in Tripmeter, press the Trip button **B** again to select Trip A or Trip B. Press and hold the Reset button **C** to reset the Tripmeter to zero.



**Instrument Cluster Type B/C** – To scroll through the different LCD Instrument Cluster modes, press the Mode button **D**. To display the Tripmeter, press the Mode button **D** and select Trip Computer . Then press the Next button **E** to scroll to the Trip A/B screens. Press and hold the Select/Reset button **F** to reset the Tripmeter to zero.



### REMINDERS:


- Appearance of Tripmeter display may differ as equipped
- All stored driving information (except Odometer and Range) is reset if the battery is disconnected

## User Settings Mode\*

(Type B/C settings)

To enter the User Settings mode on the LCD\* screen, press the Mode button **A** when the vehicle is at a standstill and with the ignition or the ENGINE START/STOP button\* in the ON position and select User Settings .

You can navigate the selections on the display by pressing the Next button **B**, and then selecting the item by pressing the Select/Reset button **C**.



### User Settings Menu:

#### Driving Assist\*:

- Lane Keeping Assist System (LKAS)\*
- Autonomous Emergency Braking (AEB)\*
- Forward Collision Warning\*
- Rear Collision Warning\*

#### Doors:

- Auto Door Lock\*
- Auto Door Unlock\*
- Two Press Unlock\*
- Horn Feedback\*
- Smart Trunk\*

#### Lights:

- One-Touch Turn Lamp\*
- Headlamp Delay\*
- Welcome Light\*

#### Sound:

- Cluster Voice Guidance
- Blind Spot Detection Sound\*
- Welcome Sound\*

#### Convenience:

- Easy Seat Access\*

#### Service Interval:

- Service Interval On/Off

## Service Mode\*




(Type B/C settings)

To enter Service Mode, press the Mode button **A**, scroll to the Service mode  and press Next button **B**. System will display number of miles remaining until next service is due, and type of service.

When service is required, the following screen will be displayed: **Service Required**.

To reset the Service Mode system, press and hold the Next button **B** for more than 1 second.

To turn Service In OFF, go to User Settings.



### Service Interval Setting:

To set the service interval when in User Settings mode:

- Press the Next button **B** and scroll to Service Interval. Press the Select/Reset button **C** to enter
- Press the Next button **B** and toggle to ON, then press the Select/Reset button **C**. Then press the Next button **B** to scroll and select the desired miles or months for your next service
- Press the Select/Reset button **C** to enter

## QR CODE

To view these videos on your mobile device, snap these QR Codes or visit the listed website.

Refer to page 2 for more information.

### LCD Display Video



[www.KuTechVideos.com/yd13/2017](http://www.KuTechVideos.com/yd13/2017)

### LCD Display: Maintenance Video



[www.KuTechVideos.com/yd13/2017](http://www.KuTechVideos.com/yd13/2017)

## Fuel Economy

Several factors contribute to your vehicle's fuel economy, including maintenance of your vehicle, driving style, environmental conditions, vehicle weight and vehicle aerodynamics. Below are tips on how to improve fuel economy:

- Keep your vehicle in good condition with regular maintenance
- Don't let the engine idle longer than necessary
- Drive at a moderate speed, accelerating smoothly and at a moderate rate
- Keep tires inflated to the recommended pressure
- Travel lightly, without carrying unnecessary weight in your vehicle
- Avoid placing large or heavy items on roof racks
- Avoid hilly, winding or poorly maintained roads

**REMINDER:** Driving range can vary depending on your vehicle's fuel tank size, e.g. 12-gal. vs. 24-gal., even though the MPG may be the same

For more information on Fuel Economy, you can snap the QR code above to view a video or refer to the brochure "GETTING MORE OUT OF EVERY GALLON, FUEL-SAVING TIPS TO DRIVE BY" available at your local dealership.

## Tire Pressure Monitoring System (TPMS)



The indicator  functions as both Low Tire Pressure Light and TPMS Malfunction Indicator.

The TPMS indicator will illuminate if one or more tires is significantly underinflated, the vehicle has a spare tire without TPMS installed or the outside temperature becomes significantly colder.

- Inflate tire(s) to specifications to turn off Low Tire Pressure Light  using an accurate digital tire pressure gauge. See front driver's door jamb for PSI specification
- When there is a problem with the TPMS, the TPMS Malfunction Indicator  will blink for approximately one minute and then illuminate - See dealer for service

**REMINDER:** Consult your dealer for service if Low Tire Pressure Light remains illuminated after inflating your tire(s).

### QUICK TIPS

- Even with TPMS, tire pressure should be checked manually at least once a month. Only adjust tire pressure on "cold tires"
- For proper maintenance and optimal fuel economy, maintain recommended tire inflation pressures and stay within the load limits and weight distribution recommended for your vehicle
- In winter or cold weather, the TPMS light may illuminate if the tire pressure was adjusted to the recommended tire inflation pressure during warm weather

### QR CODES

To view these videos on your mobile device, snap these QR Codes or visit the listed website.

Refer to page 2 for more information.

#### Fuel Economy Video



[www.KuTechVideos.com/yl13/2017](http://www.KuTechVideos.com/yl13/2017)

#### TPMS Video



[www.KuTechVideos.com/yl13/2017](http://www.KuTechVideos.com/yl13/2017)



## Drive Mode Integrated Control System

The Drive Mode may be selected depending on driver's preferences and road conditions.

To cycle through the different Drive Modes **A**, press the DRIVE MODE button **B**. The Instrument Cluster will display SPORT or ECO when selected. When in Normal mode, it will not display in the Instrument Cluster.

### REMINDERS:

- The system is turned ON and in Normal mode when ignition is in the ON position
- When ECO mode is selected, the indicator will display and system remains on, even when ignition is cycled
- Steering effort may be slightly increased in Sport mode



(Located on Center Panel next to Gear Shift)\*

## Active ECO System (ECO Mode)\*

The Active ECO system helps improve fuel economy by controlling several vehicle components. When activated, it optimizes drivetrain operations such as engine power and transmission to help improve fuel economy.

To turn ON, press the DRIVE MODE button **B**. The ECO mode indicator in the instrument cluster will illuminate, indicating that the vehicle is in ECO mode and Active ECO is operating. The Active ECO system will remain on even when the ignition is cycled.

To turn the Active ECO system OFF, press the DRIVE MODE button **B** again.

### QUICK TIPS

To help improve your fuel economy:

- Drive at a moderate speed, accelerating smoothly and at a moderate rate
- Keep tires inflated to the recommended pressure
- Be sure the wheels are properly aligned

*For more information on Active ECO, refer to your Owner's Manual or contact your local dealership.*

### QR CODE

#### Active Eco System Video

To view a video on your mobile device, snap this QR Code or visit the listed QR Code or visit the listed website.

Refer to page 2 for more information.



[www.KuTechVideos.com/yd13/2017](http://www.KuTechVideos.com/yd13/2017)

## Electronic Stability Control (ESC)


The ESC system is designed to help stabilize the vehicle during cornering maneuvers. It is a good idea to keep the ESC turned on for daily driving whenever possible. Press ESC button **A** to turn ESC OFF/ON.

### REMINDERS:

- ESC is turned ON by default at vehicle start-up. When ignition is cycled, ESC will turn ON again
- The ESC Indicator Light  In the instrument cluster will be lit momentarily whenever the ESC is active

## Heated Steering Wheel\*

Press button **B** to turn ON/OFF Steering Wheel Heater, while the Engine Start/Stop Button is in the ON position. Steering Wheel Heater will turn OFF automatically in 30 minutes or when button is pressed again to deactivate.



(Located left of steering wheel)

For more information on Electronic Stability Control (ESC) and its specific features and operations, please refer to your Owner's Manual

### QUICK TIPS

- If ignition is turned OFF, then ON again within 30 minutes of Steering Wheel Heater being turned ON, the system will remain in the ON position
- System does NOT turn off when ignition is cycled. To turn off system, press the Steering Wheel Heater button

## Instrument Panel Dimmer

With parking lights/headlights ON, toggle switch **C** (+) or (-) to adjust the brightness of the instrument panel illumination.

### REMINDERS:

- Door Mood Lamp is a fixed brightness and cannot be adjusted (not to be confused with Advanced Mood Lighting Speaker)
- The Instrument Panel Dimmer does not adjust brightness on the Navigation System screen. Use Navigation setup to adjust brightness on the Navigation System

## Hill-start Assist Control (HAC)

HAC helps prevent the vehicle from rolling backwards when accelerating from a stop while on a steep incline. The HAC automatically activates whether the ESC is OFF or ON but does NOT activate when the ESC has malfunctioned.

**REMANDER:** The HAC does not operate when the gear shift is in the P (Park) or the N (Neutral) position.

### QUICK TIPS

- When HAC is active (e.g., during initial acceleration from a stop on an incline), you may notice that the brakes will momentarily remain engaged after you depress the accelerator
- HAC provides a 2-second delay before the vehicle may start rolling backwards

## Blind Spot Detection (BSD) System\*

The BSD system uses radar sensors to help alert the driver before changing lanes. The light on the BSD button **A** will illuminate when turned ON. The outside rearview mirror warning lights will also illuminate for 3 seconds.

The system will become active when the vehicle is traveling more than 18 mph and will alert the driver if another vehicle is detected by the radar sensor.

### Blind Spot Detection (BSD) / Lane Change Assist (LCA)

**1st-stage alert:** When another vehicle is detected within the BSD System boundary **B**, or vehicle in the LCA boundary **C** approaches at a high speed, a yellow indicator will illuminate on the outside rearview mirrors.

**2nd-stage alert:** When 1st-stage alert is on and the driver activates a turn signal, a flashing yellow indicator will illuminate on the outside rearview mirrors and the system will sound an alert.


### RCTA (Rear Cross Traffic Alert)

If the RCTA system sensors detect approaching vehicles from the left or right side **D**, the system will sound an audible alert, the warning indicators on the outside rearview mirror will illuminate and a message will appear on the LCD screen, when these conditions are met:


- The gear shift is in Reverse
- The vehicle moves in reverse
- The vehicle is moving less than 6 mph
- The RCTA can be set to on/off in User Settings from the LCD Instrument Cluster modes

#### REMINDERS:

- When the BSD is ON and the vehicle power is cycled to OFF then ON again, the BSD system returns to ON
- The RCTA feature can be turned OFF/ON in User Settings. When vehicle power is cycled, the RCTA will remain in the previous state



(Located left of steering wheel)



#### QR CODE

#### Blind Spot Detection (BSD) with RCTA Video

To view a video on your mobile device, snap this QR Code or visit the listed website.

Refer to page 2 for more information.



[www.KuTechVideos.com/yt13/2017](http://www.KuTechVideos.com/yt13/2017)

For more information on the above systems, please refer to the Owner's Manual.

## Lane Keeping Assist System (LKAS) / Lane Departure Warning System (LDWS)\*

With the ENGINE START/STOP button in the ON position, press the LKAS/LDWS button **E** to turn system ON. The instrument cluster indicator  will illuminate.

If the LKAS detects that you are veering outside of your lane, the system may issue a warning on the LCD screen and an alert may sound, while applying a slight adjustment to the steering, trying to prevent the vehicle from moving outside its lane.

Standard LKAS is the operating mode by default when the button is depressed to ON. To switch to Active LKAS mode or LDWS mode, go to User Settings in the Instrument Cluster.

If the LDWS detects that you are veering outside of your lane, the system may issue a warning on the LCD screen and an alert may sound.

All systems will operate under the following conditions:

- The vehicle exceeds approximately 55 mph
- The LKAS/LDWS system recognizes the lane the vehicle is traveling in
- LKAS/LDWS will stay on when the ignition is cycled

**REMINDER:** LKAS/LDWS will not issue a warning if the turn signal is activated.




When the LKAS sensor detects the lane traveling in, both lanes are illuminated



When the LKAS sensor does not detect the lane traveling in the lanes are not illuminated



When the LKAS sensor detects the vehicle veering outside of the lane traveling in, a yellow indicator will illuminate either on the left or right lane (shown in both images above)



### QR CODE

#### Lane Departure Warning System Video

To view a video on your mobile device, snap this QR Code or visit the listed website.

Refer to page 2 for more information.



[www.KuTechVideos.com/yd13/2017](http://www.KuTechVideos.com/yd13/2017)

## Autonomous (Assist) Emergency Braking (AEB) / Forward Collision Warning (FCW)\*

The AEB helps to alert the driver when rapidly approaching a vehicle that is slowing down, braking or stopped **F**. A warning message will appear on the LCD screen and a chime will sound. The AEB will become active when the vehicle is traveling more than 6 mph.

To turn the AEB off, go to User Settings in the LCD Instrument Cluster modes.

**REMINDER:** The AEB will be activated by default when vehicle power is cycled on, even when previously set to off

*Autonomous (Assist) Emergency Braking is not a substitute for safe driving, and may not detect all objects in front of vehicle. Always drive safely and use caution.*



## Engine Start/Stop Button\*

### To start the engine:



1. Depress the brake pedal
2. Press the ENGINE START/STOP button while the gear shift is in Park (or while in Neutral for Manual Gear Shift)

To turn the vehicle OFF, press the ENGINE START/STOP button.

To use the ENGINE START/STOP button, you must have the Smart Key fob on your person or in the vehicle.

### REMINDERS:

- In an emergency situation while the vehicle is in motion, you are able to turn the engine off and to the ACC position by pressing the ENGINE START/STOP button for more than 2 seconds or 3 times successively within 3 seconds
- If Smart Key fob Battery is dead, hold the fob up against the Engine Start/Stop button and press



### QR CODE

#### Engine Start/Stop Button & Smart Key Video

To view a video on your mobile device, snap this QR Code or visit the listed website.

Refer to page 2 for more information.



[www.KuTechVideos.com/yt13/2017](http://www.KuTechVideos.com/yt13/2017)

### QUICK TIPS

To use electrical accessories:

#### ACC position

- When in the OFF position and without depressing the brake pedal, press the ENGINE START/STOP button once (orange light **A**)

#### ON position

- When already in the ACC position (orange light **A**) and without depressing the brake pedal, press the ENGINE START/STOP button again (green light **B**)
- When in the OFF position and without depressing the brake pedal, press the ENGINE START/STOP button twice (green light **B**)

Keeping the vehicle in ACC or the ON position without turning engine on may discharge the vehicle's battery.

## Power Windows, Window Lock & Central Door Lock

**A** Pull/Press to operate Driver's & Passenger's Window Auto Up/Down\*

**B** Press to Unlock/Lock All Doors

**C** Press to disable Rear Passenger Windows

**REMINDER:** When pressed **C** window controls for the Rear Passenger Windows are disabled, including from the driver's controls.

*Button configuration may vary depending on vehicle model.*

### QUICK TIPS

- Auto Door Lock/Unlock\* will engage when gear shift is moved in to or out of the P (Park) position
- To turn Auto Door Lock/Unlock\* OFF, go to User Settings\* in the LCD Instrument Cluster Modes

## Power/Folding Mirrors\*

Toggle **D** left or right to select mirror. Then press one of the points to adjust mirror position.

Toggle button **E** left/right to unfold/fold the outside rearview mirrors.

Toggle to center of button **E** to fold/unfold mirrors automatically when:

- The key fob or Smart Key\* Lock/Unlock buttons are pressed
- The door lock/unlock button is pressed (Smart Key\* only)

The mirrors will automatically unfold when the Smart Key\* is within close proximity to the vehicle.


**REMINDER:** To lock position of mirrors, toggle switch **D** to the neutral (center) position.

## Power/Heated Outside Mirrors

Mirror heaters automatically turn ON/OFF at the same time the Rear Window Defroster is turned ON/OFF. Rear Window Defroster button\* is located on climate control system panel.

## Automatic Door Lock/Unlock


When the gear shift is moved into or out of P (PARK), all doors will Lock/Unlock. Refer to the User Settings on how to turn Auto Door Lock/Unlock ON/OFF.



## Headlights & High Beams

### To operate:

- Rotate switch to change the Headlight function
- Push lever to turn High Beams ON
- Pull lever to flash Headlights/High Beams



**AUTO Light\* function** — When the light switch is in the AUTO Light position, the tail lights and headlights will turn ON/OFF automatically depending on the amount of light outside the vehicle.

**Adaptive Front Lighting System (AFLS)\*** — The Adaptive Front Lighting System helps improve visibility during nighttime driving by aiming the low beam headlights in the direction the vehicle is moving. AFLS controls the aiming direction based on steering angle and speed.

When the headlight switch is in the AUTO Light position, the AFLS will activate.

**REMINDER:** When the AFLS indicator illuminates on the instrument cluster, the AFLS is not working properly. See authorized Kia dealer for service.


## Turn Signals & Fog Lights\*

### To operate:

- Move lever Up/Down for Right/Left Turn Signal
- Slightly move lever up/down to activate One-Touch Lane Change Signal
- Rotate switch to turn Fog Lights ON/OFF

**REMINDER:** Headlights must be ON for Fog Light operation.

For more information on the User Settings Mode, please refer to your Owner's Manual.



**One-Touch Lane Change Signal** is activated by moving the Turn Signal Lever slightly for less than 1 second and then releasing. The lane change signal will blink 3-7 times.

To change how many times the Lane Change Signal blinks (3/5/7), go to User Settings Mode in the LCD Instrument Cluster modes.

For more information on the User Settings Mode, please refer to your Owner's Manual.


## Windshield Wipers & Washers

### To operate:

- Move lever Up/Down to change Wiper modes
- Rotate INT switch to adjust Intermittent Wipe Speed
- Pull lever to spray and wipe

### QUICK TIP

Rotating INT switch up increases Intermittent wipe frequency and wipe speed. Rotating INT switch down decreases frequency of wipes.



**MIST:** Single wipe

**OFF:** Wiper off

**INT:** Intermittent wipe

**LO:** Slow wipe

**HI:** Fast wipe


## Rear Wiper & Washer\* (5-door model)

### To operate:

- Rotate REAR switch to change wiper modes
- Push lever for brief wipe

### QUICK TIP

On Rear Wipers, intermittent wipe function is not adjustable.



**ON:** Normal wipe

**INT:** Intermittent wipe\*

**OFF:** Wiper off


## Tilt/Telescoping Steering Wheel

To adjust the Steering Wheel, push down the Lock-Release Lever **A** and adjust to desired angle **B** and distance **C**.

When finished, pull up the Lock-Release Lever **A** to lock Steering Wheel in place.

### QUICK TIP



It may be helpful to pull/push bottom of Steering Wheel towards/away from you to adjust desired distance.



## FlexSteer™ Steering Wheel Mode\*

Select the desired steering mode by toggling through the steering modes.

- Press FlexSteer™ Steering Wheel Mode button **D** to display the steering mode on the LCD display\*
- Then press the button **D** again within 4 seconds to switch modes



Your vehicle's steering wheel buttons may differ from those in the illustrations. See your Owner's Manual for more details.

### QR CODE

#### FlexSteer™ Steering Wheel Mode Video


To view a video on your mobile device, snap this QR Code or visit the listed website.

Refer to page 2 for more information.



[www.KuTechVideos.com/yl13/2017](http://www.KuTechVideos.com/yl13/2017)

## Audio Controls



**A Audio MODE button:** Press to cycle through FM 1-2/AM/SAT 1-3/USB/Aux/iPod®

**B Seek/Preset button:**  
*Radio Mode* - Press to advance through the Preset Stations. Press and hold to Auto Seek  
*USB/Aux/iPod® Mode* - Press to move track up/down. Press & hold to fast forward/rewind

**C Volume button:** Press up/down to raise/lower volume

**D MUTE button:** Press to mute all audio

### QUICK TIP

Pressing the Audio Mode button for more than 1 second will turn Audio Mode ON/OFF.

*Driving while distracted is dangerous and should be avoided. Drivers should remain attentive to driving and always exercise caution when using the steering-wheel-mounted controls while driving.*

*For further audio system operations, refer to pages 20-24.*

## Cruise Control\*

**E CRUISE Control ON/OFF button:** Press to turn the Cruise Control ON/OFF

**F Resume Cruising Speed button:** Press up to resume or increase Cruising Speed

**G Set Cruising Speed button:** Press down to set or decrease Cruising Speed


**H Cruise Control Cancel button:** To cancel Cruise Control, do one of the following:

- Press the brake pedal
- Press the CANCEL button

### QUICK TIPS

- Cruise Control is designed to function above 25 mph
- The Cruise Control system will not activate until the brake pedal has been depressed at least once after ignition ON or engine start

*Your vehicle's steering wheel buttons may differ from those in the illustrations. See your Owner's Manual for more details.*

**Bluetooth® Wireless Technology**

**A Volume button:** Press up/down to raise/lower speaker volume

**B Mute button:** Press to mute the microphone during a call

**C Talk button:** Press to activate voice recognition/bring up menus/place calls with minimal voice command prompts from the system

**QUICK TIP**

When using the voice command feature, wait for the system BEEP before speaking the command.

**D Receive/Place Call button:** Press to receive/place/transfer calls.  
Press to place a call using voice command prompts from the system, or to answer an incoming call

**E End Call button:** Press to end a call or cancel a function

**QUICK TIPS**

- Phonebook transfer upload time varies by phone model and with number of phonebook entries
- Because of differences in phone quality, service providers and **Bluetooth®** Wireless Technology chip programming, functionality may differ from one phone to another
- Changing language setting may delete paired phones

*Your vehicle's steering wheel buttons may differ from those in the illustrations. See your Owner's Manual for more details.*

*Driving while distracted is dangerous and should be avoided. Drivers should remain attentive to driving and always exercise caution when using the steering-wheel-mounted controls while driving*

For more information, if equipped, refer to the Car Multimedia System User's Manual or the UVO System User's Manual. For **Bluetooth®** Wireless Technology FAQs, go to [www.kia.com](http://www.kia.com), Owners section, or call Consumer Information for **Bluetooth®** Technology at (800) 333-4KIA. Refer to your Owner's Manual for more specific **Bluetooth®** Wireless Technology phone pairing and operation instructions.

## Bluetooth® Wireless Technology

### Pairing a Phone

For instructions on how to pair a phone, refer to the audio system's user's guide or your vehicle's Quick Start Guide.

#### QUICK TIP

During the pairing process, be sure to accept the connection requests on the phone for phonebook download and to allow acceptance of all future **Bluetooth®** connection requests.

### How to Place a Call

When using the voice command feature, wait for the system BEEP before speaking the command.

There are two options for placing a call when using the Steering Wheel Controls:

#### Standard Audio Systems\*

- Option 1: Press the Receive/Place Call button **D** (system will prompt you through call process)
- Option 2: Press the Talk button **C** (system will BEEP to indicate it is ready for call placement). Then say the command "Call {name}" or "Dial {number}"

#### UVO eServices System\*/UVO eServices with Navigation\*

- Option 1: Press the Receive/Place Call button **D** (displays the phone screen with number keypad)
- Option 2: Press the Talk button **C**. Then say the command "Call {name}" or "Dial {number}"

## Voice Recognition and Phone Contact Tips

The Kia Voice Recognition System may have difficulty understanding some accents or uncommon names. When using Voice Recognition to place a call, speak in a moderate tone, with clear pronunciation.

Help your **Bluetooth®** Wireless Technology Voice Recognition performance by making a few simple changes to your phone contacts:

- Use full names vs. short or single syllable names ("John Smith" vs. "Dad", "Smith Residence" vs. "Home")
- Avoid using special characters or hyphens (@, &, #, /, -, \*, +, etc.)
- Avoid using acronyms ("In Case of Emergency" vs. "ICE")
- Spell words completely, no abbreviations ("Doctor Goodman" vs. "Dr. Goodman")

## QR CODE

### Voice Recognition Tips Video

To view a video on your mobile device, snap this QR Code or visit the listed website.


Refer to page 2 for more information.



[www.KuTechVideos.com/yd13/2017](http://www.KuTechVideos.com/yd13/2017)

## Standard Audio System (Type A)\*

– FM/AM/Sirius®/Media (CD, USB, iPod®, Aux, My Music, *Bluetooth®* Audio)



## QR CODE

### Standard Audio System Videos

To view a video on your mobile device, snap this QR Code or visit the listed website.

Refer to page 2 for more information.



[www.KuTechVideos.com/audio/base\\_system](http://www.KuTechVideos.com/audio/base_system)

## Audio System Setup Options

Press the SETUP key, then using the touchscreen, press the menu item to enter (Display, Sound, Phone, System). Adjust the available settings for each equipped audio system setup option by pressing the onscreen buttons/arrows. Audio system setup options may include the following:


- **Display settings** - Mode Popup, Media Display
- **Sound settings** - Sound Settings, Speed Dependent Volume Control, Voice Recognition Volume, Touchscreen Beep
- **Phone settings** - Pair Phone, Phone List, Pairing a New Device, Viewed Paired Phone List, Downloading Contacts, Outgoing Volume, Bluetooth Off/On
- **System settings** - Memory Information, Prompt Feedback, Language

**To adjust the Sound settings** (bass, middle, treble, fader, balance) – When in the SETUP menu, select Sound and then Sound Setting. Adjust the settings by pressing the onscreen arrows and then return  to exit.

*Your vehicle's audio system may differ from that in the illustration. For further audio system operations, refer to pages 21-24. See your Owner's Manual for more details.*

## Standard Audio System (Type B)

– FM/AM/Sirius®/Media (CD, MP3, USB, iPod, AUX, My Music, *Bluetooth*® Audio)



## Audio System Setup Options

Press the SETUP key, then using the touchscreen, press the menu item to enter (Display, Sound, Clock/Calendar, Phone, System). Adjust the available settings for each equipped audio system setup option by pressing the onscreen buttons/arrows. Audio system setup options may include the following:

- **Display settings** - Adjusting the Brightness, Mode Popup, MP3 Information Display
- **Sound settings** - Sound Settings, Speed Dependent Volume Control, Voice Recognition Volume, Touchscreen Beep
- **System settings** - Memory Information, Prompt Feedback, Language

**To adjust the Sound settings** (bass, middle, treble, fader, balance) – When in the SETUP menu, select Sound and then Sound Setting. Adjust the settings by pressing the onscreen arrows and then return  to exit.

*Your vehicle's audio system may differ from that in the illustration. For further audio system operations, refer to pages 20-24. See your Owner's Manual for more details.*

## UVO eServices Setup\*

### UVO eServices Registration/Activation – To use UVO eServices:

1. Register through your UVO eServices app or at MyUVO.com
2. On your Smartphone, go to an app store or marketplace to download the UVO eServices app and log in to the app using your MyUVO.com account credentials
3. Follow the app's phone pairing and activation steps

### Android Auto\*

Setting up Android Auto:

1. From an Android Auto compatible device, download the Android Auto app from the Google Play™ Store
2. Open the Android Auto app and proceed with the on-screen instructions to complete setup on the mobile device.

How to start Android Auto:

1. Press the SETUP hard key
2. Press the Connectivity icon
3. Check the box for Android Auto to enable Android Auto
4. Connect the Android™ device with the vehicle using a factory USB cable
5. From the vehicle's home screen, press the Android Auto icon to launch Android Auto

### Apple CarPlay®\*

Setting up and starting Apple CarPlay®:


1. From an Apple CarPlay® compatible device, plug your phone into the vehicle's USB port using the connector provided with your phone
2. On the UVO eServices System audio control unit, press the SETUP button, then CONNECTIVITY on the screen
3. Select ENABLE APPLE CARPLAY. Go back to the HOME screen, then select the APPLE CARPLAY, where you'll see all the Apple CarPlay® supported apps

#### QUICK TIP

- At any time, you can interrupt UVO eServices System Command Feedback by pressing the TALK button on the steering wheel
- Prolonged use of the UVO eServices system in ACC mode may drain the vehicle's battery

## UVO eServices System\*

– FM/AM/SiriusXM®/Media (USB, iPod®, Aux, *Bluetooth*® Audio, My Music)



### Sound Settings

To adjust the UVO eServices System sound settings:

1. Press the **SETUP** key on the audio control unit
2. Select the on-screen **SOUND** button
3. Select the menu item (Position, Tone, Advanced, Default)
4. Use the onscreen buttons to adjust settings
5. Press the return button to save settings


### QUICK TIPS

- When using the voice command feature, wait for the system BEEP before speaking the command
- At any time, you can interrupt UVO eServices System Command Feedback by pressing the **TALK** button on the steering wheel
- Prolonged use of the UVO eServices system in ACC mode may drain the vehicle's battery

*Your vehicle's audio system may differ from that in the illustration. For further UVO eServices System operations, refer to the Car Multimedia System User's Manual. For other audio system information, see page 20-24.*

## UVO eServices with Premium Navigation\*

– FM/AM/SiriusXM®/Media (USB, iPod®, Aux, *Bluetooth*® Audio, My Music)



### QR CODE

#### UVO eServices with Premium Navigation System Videos

To view these videos on your mobile device, snap this QR Code or visit the listed website. Refer to page 2 for more information.



[www.KuTechVideos.com/audio/avn4](http://www.KuTechVideos.com/audio/avn4)

### Sound Settings

To adjust the UVO eServices System sound settings:

1. Press the SETUP button on the Audio Control Unit
2. Select the on-screen SOUND button
3. Select the menu item to change settings
4. Use the on-screen buttons to adjust settings
5. Press the return button to save settings

### QUICK TIPS

- When using the voice command feature, wait for the system BEEP before speaking the command
- At any time, you can interrupt UVO eServices System Command Feedback by pressing the TALK button on the steering wheel


- Prolonged use of the UVO eServices with Premium Navigation system in ACC mode may drain the vehicle's battery. A warning screen may appear periodically to remind users that the navigation system should be operated when the engine is running to prevent battery discharge

Your vehicle's audio system may differ from that in the illustration. For further UVO eServices with Premium Navigation System operations, refer to the Car Multimedia System User's Manual. For other audio system information, see page 20-23.

## Digital Clock

### Center Panel Clock and Outside Temperature Setup\*:

Press the H button **A** to advance the time by one hour. Press the M button **B** to advance the time by one minute.



Press and hold both buttons for more than 4 seconds to switch from 12- to 24-hour formats


Press and hold both buttons for 1-2 seconds to switch temperature modes (Fahrenheit/Celsius)

### UVO eServices System/ UVO eServices with Navigation System\* Clock Setup:

Press the SETUP key, then the CLOCK button to display the Clock setting screen. Then use the on-screen buttons to adjust time.

**REMINDER:** The Center Panel Digital Clock and Navigation System Clock are not synchronized and may differ slightly.

## Aux/USB/iPod® Port & Power Outlets



### Aux/USB/iPod® Port

Use the Aux port to connect audio devices and the USB port to connect USB audio devices and an iPod® device

### Power Outlets


#### QUICK TIP

The power outlets are inactive when ignition is in the OFF position.

**REMINDER:** Using the power outlet (accessory plug) for prolonged periods of time with the engine off could cause the battery to discharge.

*For more information on the Aux/USB/iPod® Port & Power Outlets, refer to the Owner's Manual.*

# Automatic Climate Control\*



## Air Flow Modes

To select Air Flow modes, press the MODE selection button:



## Climate Control Auto Function:

1. Press AUTO to select Full Auto Operation - The Auto setting automatically controls the airflow modes, fan speeds, air intake and air conditioning according to the temperature setting selected
2. Set desired Temperature
3. Press SYNC to select Dual Temperature Control Operation

## Defrost Outside Windshield:

1. Set Fan Speed to the highest position
2. Set desired Temperature
3. Press the Defrost button

## Defog Inside Windshield:

1. Set Fan Speed to desired position
2. Set desired Temperature
3. Press the Defrost button

## REMINDERS:


- Warm air may flow in through vents if Recirculated Air button is not pressed ON (LED lit)
- Pressing any button during AUTO operation will deactivate the AUTO function and switch to manual mode, except for Temperature Control or SYNC Temperature Control
- When in AUTO mode, Air Flow Mode and Fan Speed do not display on the Climate Control Display

## QUICK TIPS

- Defrost Mode activates A/C and opens Fresh Air Vent to help dehumidify the air and improve Defroster performance
- During Auto Operation the A/C indicator will NOT illuminate. The fan speed, air intake, airflow and air conditioning may automatically be engaged at any time to reach desired temperature and reduce humidity
- Keep inside glass as clean as possible to reduce window fogging

*Your Automatic Climate Control system may differ from those in the illustrations. See your Owner's Manual for more details*

# Manual Climate Control\*



## Air Flow Modes

To select Air Flow modes, press the MODE selection button:



Face-Level



Bi-Level



Floor-Level



Floor/Defrost-Level



Defrost/Defrost-Level

## Defrost Outside Windshield:

1. Set Fan Speed to the highest position
2. Set desired Temperature
3. Select Defrost mode

## Defog Inside Windshield:

1. Set Fan Speed to desired position
2. Set desired Temperature
3. Select Defog mode

**REMINDER:** Warm air may flow in through vents if Recirculated Air button is not pressed ON (LED lit)

### QUICK TIPS

- Defrost Mode activates A/C and opens Fresh Air Vent
- MAX A/C Mode automatically engages Recirculated Air
- Keep inside glass as clean as possible to reduce window fogging

*Your Manual Climate Control system may differ from those in the illustrations. See your Owner's Manual for more details*

# Automatic Gear Shift with Sportmatic® Shifting\*

**P:** Park

**R:** Reverse

**N:** Neutral

**D:** Drive

**[+]:** Sport Mode Upshift

**[-]:** Sport Mode Downshift


**Sport Mode:** To enter Sport Mode, move shift lever from D to left gate.

To shift while in Sport Mode, move shift lever up [+ ] to upshift or down [- ] to downshift.


**Paddle Shifters:** To use Paddle Shifters, move shift lever in the D position or in Sport Mode, then pull the [+ ] or [- ] paddle shifters once to upshift or downshift one gear.

## REMINDERS:

- The Paddle Shifters can be operated when the vehicle speed is more than 6 mph
- When in Sport Mode, pulling the left and right paddle shifters at the same time will NOT shift gears



## Paddle Shifters\*



## QUICK TIPS

- Press brake pedal and depress release button to move gearshift from N to P, N to R or from P to any gear
- Sport Mode downshifts are made automatically when the vehicle slows down. When the vehicle stops, 1st gear is automatically selected

## QR CODES

To view these videos on your mobile device, snap these QR Codes or visit the listed website.

Refer to page 2 for more information.

### Sportmatic Shifting Video



[www.KuTechVideos.com/yd13/2017](http://www.KuTechVideos.com/yd13/2017)

### Paddle Shifters Video





[www.KuTechVideos.com/yd13/2017](http://www.KuTechVideos.com/yd13/2017)

## Manual Gear Shift\*



### Starting the Engine

1. Apply Parking Brake **A**
2. Depress Clutch fully **B**
3. Shift into Neutral **C**
4. Turn Ignition to Start




### Shifting into Reverse

1. Depress Clutch fully **B**
2. Shift into Neutral **C**
3. Press Shift Lever button **D** up
4. Shift into Reverse **E**



### QUICK TIP

When shifting into gears 1-6, the Shift Lever can be moved without pulling the Shift Lever Knob.



## 6-Way Manual Adjustable Driver's Seat\*


Pull lever **A** to slide Seat forward/backward.

Pull/press lever **B** to adjust Seat Cushion Height.

Pull lever **C** to adjust Seatback Recline.

### QUICK TIP

When adjusting seat forward or backwards, ensure seat clicks or locks into place before driving the vehicle.




### QUICK TIPS

- With the seat warmer switch in the ON position, the heating system in the seat turns OFF or ON automatically depending on the seat temperature
- System turns OFF when the ignition is cycled


## Seat Warmers / Ventilated Seats\*

**Seat Warmers button** - Press button once for high setting (3 LEDs lit). Press button twice for medium setting (2 LEDs lit). Press button a third time for low setting (1 LED lit) and again to turn OFF.



(Buttons located near Gear Shift Lever)

**Seat Warmers / Ventilated Seats\* button** - Press top/bottom of button once for high setting (3 LEDs lit). Press button twice for medium setting (2 LEDs lit). Press a third time for low setting (1 LED lit) and again to turn OFF.



(Buttons located near Gear Shift Lever)

### QR CODE

#### Heated and Ventilated Seats Video

To view a video on your mobile device, snap this QR Code or visit the listed website.



Refer to page 2 for more information.



[www.KuTechVideos.com/1d13/2017](http://www.KuTechVideos.com/1d13/2017)

## 10-way Power Adjustable Driver's Seat\*

Move/Press controls to adjust Seat forward/backward, Seat Cushion height, Seatback recline and Lumbar support\*.




Seat forward/  
backward

Seat Cushion

Seatback

Lumbar

## Driver Position Memory System\*




To store a seating position into memory, first move the gear shift into P (Park) while the ignition is ON. Then:

1. Adjust the Driver's Seat
2. Press the SET button **D** on the control panel. System will beep once
3. Press one of the memory buttons **E** within 5 seconds. The system will beep twice when memory has been stored

## Front Seat Headrest Adjustment

**To raise Headrest:** Pull Headrest up.



**To lower Headrest:** Press lock, then press the Headrest down.



## Folding Rear Seats



### 2- and 4-door model

1. Lower Rear Headrests to the lowest position
2. Ensure the Rear Seatbelt is secured into the guide
3. Pull Seatback Lock Release Lever **A** to release Rear Seatback (Lever located in trunk)
4. Fold Seatback **B** down



### 5-door model

1. Lower the headrest **C** to the farthest position
2. Pull the Lock Release Lever **D**, located on Seatback shoulder
3. Fold the Seatback **E** forward



#### QUICK TIP

It may be necessary to adjust the front Seatbacks, by sliding forward, to fully lower rear Seatbacks.

## Sunroof Operation\*

The Sunroof and Sunshade operation is controlled through a multi-directional switch/lever, and the ignition needs to be in the ON position to operate the Sunroof/Sunshade.

### Slide the Sunshade and Sunroof:


- Auto Open: Slide lever **A** backward to the farthest position and release.
- Auto Close (Sunroof only): Slide the lever **A** forward to the farthest position and release.

### Slide the Sunroof (with Sunshade open):

- Open: Slide the lever **A** backward and release.
- Close: Slide the lever **A** partially forward to the first detent position or pull the lever downward.

### Tilt the Sunroof:

- Raise: Push lever **A** upward.
- Lower: Pull lever **A** downward.



**REMINDER:** Sunshade needs to remain OPEN while Sunroof is open and vehicle is moving.

### QUICK TIP

To stop the Sunroof/Sunshade at any position, push or pull the Sunroof control lever in any direction.

## Map/Room Lamps\*

### Map/Personal Lamp

Push the lens **B** to turn the map/personal lamp ON/OFF. This light produces a spot beam for convenient use as a map lamp or as a personal lamp for the driver or the front passenger.

### Map/Personal Lamp switch **C**

**DOOR** – In the DOOR position, the lamp turns on when any door is opened.

**ON** – In the ON position, the lamps stay on continuously.

**OFF** – In the OFF position, the lamp is off even if the door is opened.

### Room Lamp switch **D**

Press the switch to turn Room Lamp ON/OFF.

If vehicle is not equipped with Map Lamp, the Room Lamp will operate as follows:

- The lamp turns ON when any door is opened, and turns OFF after 30 seconds
- The lamp turns ON, when doors are unlocked with a key fob or Smart Key
- The lamp stays ON continuously when the ignition is in the ON position and a door is open
- The lamp stays ON for about 20 minutes when the ignition is in the ACC or LOCK/OFF position and a door is open

### QUICK TIPS


- If your vehicle is equipped with the theft alarm system, the interior lights automatically turn off approximately 3 seconds after the system is in armed stage
- Using interior lights for an extended period of time may cause battery discharge

## Remote Keyless Entry (Folding Key)\*

(Type A)


- A** Press the release button to unfold the key
- B** Lock All Doors
- C** To unlock Driver's Door, press once. Press twice in 4 seconds to unlock All Doors
- D** Press and hold more than 1 second to unlock Trunk / Rear Hatch\*
- E** Press and hold more than 1 second for Panic Alarm\*. To turn off Alarm, press any button

**REMINDER:** Remote button configuration may vary depending on vehicle options.



## Double-Turn Lock/Unlock All

- Turn clockwise once to unlock Driver's Door
- Turn clockwise again within 4 seconds to unlock All Doors
- Turn counterclockwise once to Lock All Doors



## OTHER KEY FEATURES

### Smart Key\*

#### Smart Key Fob:

- A** Press to lock All Doors
- B** Press to unlock Driver's Door. Press twice in 4 seconds to unlock All Doors

- C** Press and hold to unlock Trunk/Hatch and manually open

**REMINDER:** The Trunk/Hatch unlocks when the Smart Key fob is within close proximity of the vehicle.

- D** Press and hold more than 1 second for Panic Alarm. To turn off Alarm, press any button

- E** Press to release Mechanical Key (Button on reverse side of fob)


#### Driver's Door Lock/Unlock button **F**:

- Press button once to unlock Driver's Door
- Press again within 4 seconds to unlock All Doors
- Press again to lock All Doors

**REMINDER:** Remote button configuration may vary depending on vehicle options.

#### Mechanical Key **G**:

- Use to unlock Driver's Door
- Use to turn Child Safety Locks



## QR CODE

### Engine Start/Stop Button & Smart Key Video

To view a video on your mobile device, snap this QR Code or visit the listed website.

Refer to page 2 for more information.



[www.KuTechVideos.com/yd13/2017](http://www.KuTechVideos.com/yd13/2017)

## QUICK TIPS

- If the Smart Key battery is weak or not working properly, hold the Smart Key fob up to the Engine Start/Stop button (Lock button side closest) and press to start engine
- The Smart Key's signal can be blocked by the normal operation of a cellular phone or smartphone. To help prevent this, store each device separately

## Power Trunk / Smart Trunk\*

### Smart Key:


To open the Power Trunk, press and hold the Trunk button **D** until the Trunk begins opening. Press again to cancel.

**REMINDER:** Pulling the Trunk upward by the handle or pressing the button a second time will interrupt the automatic opening of the Power Trunk.



### Outside the Vehicle:

To open Power Trunk automatically, press the Trunk Release button **B**.



### Smart Trunk\*

When the Smart Key fob is on your person and you are near the back of the vehicle, within close proximity, the hazard lights will blink and a chime will sound for about 3 seconds as an alert that the Power Trunk is about to open. Then the alert system will blink and chime two additional times before opening the Power Trunk.

The Smart Trunk feature is off by default. To enable the Smart Trunk, go to User Settings in the LCD Instrument Cluster modes.

### QUICK TIP

During the Smart Trunk alert, the Smart Trunk can be deactivated with the Smart Key by pressing any button on the key fob.

### REMINDERS:


- All doors are closed and locked after about 15 seconds
- If the POWER DOOR OFF button is depressed, the Smart Trunk will not operate.
- The Smart Trunk feature will not operate when:
  - The doors are recently closed and locked, and the Smart Key is still detected after 15 seconds near the vehicle or within 60 inches of the door handles
  - A door is not locked or closed
  - The Smart Key is in the vehicle

*For more information on the Smart Trunk operation, please refer to the Owner's Manual.*

## Hood Release Lever and Latch

### Opening the Hood:

1. Pull the Hood Release Lever **A** to unlatch the Hood
2. In the front of the vehicle, lift the Hood slightly, pull the secondary Latch **B** inside of the Hood's center and lift the Hood




### Closing the Hood:

Lower the Hood and then press down to securely lock in place.

## Sunvisor

Use the Sunvisor to shield direct light through the front or side windows.




### REMINDERS:

- Sunvisor may not shield all direct light
- Do not operate the vehicle if Sunvisor is impairing your visibility
- Be aware of seating position when adjusting or swinging Sunvisor around to or from the front or side windows.

## Trunk Release Button

Located underneath the Trunk lid. With Trunk unlocked, press the Trunk Release Button and pull the Trunk up by the handle to open.




### QUICK TIPS

- The Trunk must be unlocked before it can be opened by the Trunk Release Button
- Smart Key\* - The Trunk unlocks automatically, and can then be opened manually, when the Smart Key fob\* is within close proximity to the vehicle

## HomeLink® with Auto-Dimming Rearview Mirror\*

- |                           |                                 |
|---------------------------|---------------------------------|
| <b>A</b> HomeLink® button | <b>E</b> Glare detection sensor |
| <b>B</b> HomeLink® button | <b>F</b> Automatic dimming ON   |
| <b>C</b> Indicator light  | <b>G</b> Automatic dimming OFF  |
| <b>D</b> HomeLink® button |                                 |



The HomeLink® / Auto-Dimming Rearview Mirror\* is designed to reduce glare from a vehicle's headlights located in the rear and also connect up to three electronic transmitters into one location.

- To turn automatic dimming ON, press **I** button **F**
- To turn automatic dimming OFF, press **O** button **G**

**REMINDER:** Mirror indicator light **C** will illuminate when automatic dimming is ON.

### QUICK TIPS

- You can reprogram a single HomeLink® button by repeating Step 2
- Erasing programmed buttons will delete all trained transmitters

## How to Sync Transmitter with HomeLink®\*

If programming for the first time, begin with Step 1 (repeating this step will delete all information).

To program non-rolling and rolling code garage door openers and other devices:

1. Press and hold the left **A** and center **D** buttons simultaneously until the indicator light **C** begins to flash (to reprogram buttons, skip this step)
2. Press and hold the desired button **A**, **B** or **D** and hold the button on the transmitter while it is approximately 1 to 3 inches away from the mirror. The HomeLink® Indicator light **C** will flash rapidly once the frequency signal has been successfully programmed

To finish programming rolling code garage door openers, complete these steps:

3. Locate the “learn” or “smart” button on the garage door’s motor head unit. Press and release the button and complete Step 4 within 30 seconds
4. Firmly press and release the programmed HomeLink® button up to three times

## Operating HomeLink®:

Press one of the programmed HomeLink® buttons.

## Erasing programmed buttons:

Press and hold the left **A** and center **D** buttons simultaneously for approximately 20 seconds, and then release both buttons within 30 seconds



*If your garage door opener was manufactured in 2011 or later, and you're unable to program your vehicle's HomeLink® system, you may need to purchase a HomeLink® Repeater Kit. For more information, go to [www.HomeLink.com](http://www.HomeLink.com) or call (800) 355-3515.*

## Rear-Camera Display\*

The Rear-Camera Display system is not a safety device. It is a supplemental system that displays the view behind the vehicle through the Standard Audio System (Type B)\*, UVO Audio System\*, UVO eServices System\* or the UVO eServices with Navigation System\* screens while the vehicle is in Reverse.

The Rear-Camera Display activates when the:

1. Engine Start/Stop\* button is in the ON position (green light)
2. Gear Shift Lever is in the R (Reverse) position



### REMINDERS:


- Standard Audio System (Type B) / UVO eServices System - While camera is active, only the volume controls on the Audio System can be operated
- UVO eServices with Navigation System - While camera is active, only the Audio System can be operated on the Steering Wheel and Audio Control Unit. Navigation features are disabled

*The Rear-Camera Display is not a substitute for proper and safe backing-up procedures. Always drive safely and use caution when backing up. The Rear-Camera Display may not detect every object behind the vehicle.*

## Fuel Cap / Malfunction Indicator (Check Engine Light)


Tighten for ONE CLICK to prevent Malfunction Indicator  from illuminating.

**REMANDER:** The Fuel Filler Door Release lever is located on the lower part of the driver's door sill.



## Child Safety Locks

Locate these locks on the rear edge of the rear passenger doors. Turn the safety lock to the LOCK position to disable the inner door handles from opening the rear doors.



**REMANDER:** Child Safety Lock is located on rear passenger door jamb.

## QR CODE

### One Click Fuel Cap Video

To view a video on your mobile device, snap this QR Code or visit the listed website.

Refer to page 2 for more information.




[www.KuTechVideos.com/yd13/2017](http://www.KuTechVideos.com/yd13/2017)

## Seat Belts

To properly fasten your Seat Belts:

1. Insert the belt tongue plate **A** into the buckle **B** until it clicks
2. Position the lap portion of the belt across your lap as **LOW ON THE HIPS** as possible **C**. Adjust the belt to a **SNUG FIT** by pulling up on the shoulder portion **D**



### QUICK TIP

The Seat Belt warning chime operates for driver's seat only.

**REMINDER:** For maximum protection, always wear your seatbelt.

## Seat Belt Retractor Locks

Retractor locks allow lap/shoulder seat belts to remain unlocked during normal vehicle operation for freedom of movement and increased comfort.

During a **STRONG STOP, SUDDEN TURN OR CERTAIN COLLISIONS**, seat belt retractors will automatically lock the belts to reduce the risk of injury.

## Occupant Detection System (ODS) / Passenger Airbag Off Indicator

ODS detects the presence of the front passenger.

Depending on the situation and type of accident, the system may:

- Deploy airbag (Adult)
- Not deploy the airbag (Unoccupied)

If the system determines that the airbag should not be deployed, the Passenger Airbag Off light will illuminate.

**PASS  
AIR BAG**

**OFF**

## Normal Maintenance Schedule

When your vehicle requires service, remember that your dealer knows your vehicle best. Your dealer has factory-trained technicians, recommended special tools, genuine Kia replacement parts, and is dedicated to your complete satisfaction. For expert advice and quality service, see your authorized Kia dealer.

### 7,500 miles

#### PERFORM

- Add fuel additive<sup>1</sup> (Every 7,500 miles)
- Rotate tires (Every 7,500 miles)

#### REPLACE

- Engine oil and filter (MPI/GDI Engine - Every 7,500 miles; Turbo GDI Engine - Every 6,500 miles)

#### INSPECT\*

- Air cleaner filter
- Battery condition
- Intercooler, in/out hose, air intake hose – Turbo GDI (Every 7,500 miles)
- Vacuum hose

\*And, if necessary, adjust, correct, clean, or replace

1. If TOP TIER detergent gasoline is not available, one bottle of additive is recommended. Additives are available from your authorized Kia dealer along with information on how to use them. Do not mix other additives.

### 15,000 miles

#### PERFORM

- Add fuel additive<sup>1</sup> (Every 7,500 miles)
- Rotate tires (Every 7,500 miles)

#### REPLACE

- Climate control air filter (for evaporator and blower unit)
- Engine oil and filter (MPI/GDI Engine - Every 7,500 miles; Turbo GDI Engine - Every 6,500 miles)

#### INSPECT\*

- Air cleaner filter
- Battery condition
- Vacuum hose
- Air conditioning refrigerant
- Drive shaft and boots
- Brake hoses and lines
- Intercooler, in/out hose. Air intake hose (Turbo GDI – Every 7,500 miles)

- Front disc brake/pads, calipers and rotors
- Exhaust pipe and muffler
- Steering gear box, linkage & boots/lower arm ball joint, upper arm ball joint
- Suspension mounting bolts
- Rear disc brake/pads, parking brake

\*And, if necessary, adjust, correct, clean, or replace

1. If TOP TIER detergent gasoline is not available, one bottle of additive is recommended. Additives are available from your authorized Kia dealer along with information on how to use them. Do not mix other additives.

### QUICK TIP

Check your Maintenance Schedule or schedule an appointment with a dealer using your UVO eServices account by logging into your UVO App or your account on MyUVO.com (Vehicles equipped with UVO eServices only - See page 22 for setup).

## Normal Maintenance Schedule (Continued)

### 22,500 miles

#### PERFORM

- Add fuel additive<sup>1</sup> (Every 7,500 miles)
- Rotate (Every 7,500 miles)

#### REPLACE

- Engine oil and filter (MPI/GDI Engine - Every 7,500 miles; Turbo GDI Engine - Every 6,500 miles)

#### INSPECT\*

- Air cleaner filter
- Battery condition
- Vacuum hose
- Intercooler, in/out hose. Air intake hose (Turbo GDI – Every 7,500 miles)

\*And, if necessary, adjust, correct, clean, or replace

1. If TOP TIER detergent gasoline is not available, one bottle of additive is recommended. Additives are available from your authorized Kia dealer along with information on how to use them. Do not mix other additives.

### 30,000 miles

#### PERFORM

- Add fuel additive<sup>1</sup> (Every 7,500 miles)
- Rotate tires (Every 7,500 miles)

#### REPLACE

- Air cleaner filter
- Climate control air filter\*\*
- Engine oil and filter (GDI Engine - Every 7,500 miles; Turbo GDI Engine - Every 6,500 miles)

#### INSPECT\*

- Air conditioning refrigerant
- Battery condition
- Brake hoses and lines
- Drive shafts and boots
- Exhaust pipe and muffler
- Front disc brake/pads, calipers and rotors
- Steering gear box, linkage & boots/lower arm ball joint, upper arm ball joint
- Suspension mounting bolts
- Brake/clutch\*\* fluid
- Fuel Filter
- Fuel lines, fuel hoses and connections
- Fuel tank air filter\*\*<sup>2</sup>
- Vacuum hose
- Intercooler, in/out hose. Air intake hose (Turbo GDI – Every 7,500 miles)
- Rear disc brake/pads, parking brake
- Vapor hose and fuel filler cap, fuel tank

\*And, if necessary, adjust, correct, clean, or replace \*\*If equipped

1. If TOP TIER detergent gasoline is not available, one bottle of additive is recommended. Additives are available from your authorized Kia dealer along with information on how to use them. Do not mix other additives. 2. Fuel filter & fuel tank air filter are considered to be maintenance free but periodic inspection is recommended for this maintenance schedule depends on fuel quality. If there are some important safety matters like fuel flow restriction, surging, loss of power, hard starting problem etc., replace the fuel filter immediately regardless of maintenance schedule and consult an authorized Kia dealer for details.

## Normal Maintenance Schedule (Continued)

### 37,500 miles

#### PERFORM

- Add fuel additive<sup>1</sup> (Every 7,500 miles)
- Rotate tires - including tire pressure and tread wear (Every 7,500 miles)

#### REPLACE

- Engine oil and filter (MPI/GDI Engine - Every 7,500 miles; Turbo GDI Engine - Every 6,500 miles)

#### INSPECT\*

- Air cleaner filter
- Battery condition
- Vacuum hose
- Intercooler, in/out hose. Air intake hose (Turbo GDI – Every 7,500 miles)
- Manual transaxle fluid\*\*

\*And, if necessary, adjust, correct, clean, or replace \*\*If equipped

1. If TOP TIER detergent gasoline is not available, one bottle of additive is recommended. Additives are available from your authorized Kia dealer along with information on how to use them. Do not mix other additives.

### 45,000 miles

#### PERFORM

- Add fuel additive<sup>1</sup> (Every 7,500 miles)
- Rotate tires (Every 7,500 miles)

#### REPLACE

- Climate control air filter (for evaporator and blower unit)
- Spark plugs (iridium coated; Turbo GDI)
- Engine oil and filter (MPI/GDI Engine - Every 7,500 miles; Turbo GDI Engine - Every 6,500 miles)
- Spark plugs (iridium coated; T-GDI engine)

#### INSPECT\*

- Air cleaner filter
- Air conditioning refrigerant
- Battery condition
- Brake hoses and lines
- Exhaust pipe and muffler
- Front disc brake/pads, calipers and rotors
- Steering gear box, linkage & boots/lower arm ball joint, upper arm ball joint
- Suspension mounting bolts
- Vacuum hose
- Intercooler, in/out hose. Air intake hose (Turbo GDI – Every 7,500 miles)
- Rear disc brake/pads, parking brake

\*And, if necessary, adjust, correct, clean, or replace

1. If TOP TIER detergent gasoline is not available, one bottle of additive is recommended. Additives are available from your authorized Kia dealer along with information on how to use them. Do not mix other additives.

## Normal Maintenance Schedule (Continued)

### 52,500 miles

#### PERFORM

- Add fuel additive<sup>1</sup> (Every 7,500 miles)
- Rotate tires (Every 7,500 miles)

#### REPLACE

- Engine oil and filter (MPI/GDI Engine - Every 7,500 miles; Turbo GDI Engine - Every 6,500 miles)

#### INSPECT\*

- Air cleaner filter
- Battery condition
- Vacuum hose
- Intercooler, in/out hose. Air intake hose (Turbo GDI – Every 7,500 miles)

\*And, if necessary, adjust, correct, clean, or replace

1. If TOP TIER detergent gasoline is not available, one bottle of additive is recommended. Additives are available from your authorized Kia dealer along with information on how to use them. Do not mix other additives.

### 60,000 miles

#### PERFORM

- Add fuel additive<sup>1</sup> (Every 7,500 miles)
- Rotate tires (Every 7,500 miles)

#### REPLACE

- Air cleaner filter
- Climate control air filter (for evaporator and blower unit)
- Engine oil and filter (MPI/GDI Engine - Every 7,500 miles; Turbo GDI Engine - Every 6,500 miles)

#### INSPECT\*

- Air conditioning refrigerant
- Battery condition
- Brake hoses and lines
- Drive belt<sup>2</sup> (First, 60,000 miles after every 15,000 miles)
- Drive shafts and boots
- Exhaust pipe and muffler
- Front disc brake/pads, calipers and rotors
- Steering gear box, linkage & boots/lower arm ball joint, upper arm ball joint
- Suspension mounting bolts
- Brake/clutch\*\* fluid
- Fuel filter<sup>3</sup>
- Fuel lines, fuel hoses and connections
- Fuel tank air filter<sup>3\*\*</sup>
- Rear disc brake/pads, calipers and rotors
- Vacuum hose
- Intercooler, in/out hose. Air intake hose (Turbo GDI – Every 7,500 miles)
- Vapor hose and fuel filler cap, fuel tank

\*And, if necessary, adjust, correct, clean, or replace \*\*If equipped

1. If TOP TIER detergent gasoline is not available, one bottle of additive is recommended. Additives are available from your authorized Kia dealer along with information on how to use them. Do not mix other additives. 2. The drive belt should be replaced when cracks occur or tension is reduced excessively. 3. Fuel filter & fuel tank air filter are considered to be maintenance free but periodic inspection is recommended for this maintenance schedule depends on fuel quality. If there are some important safety matters like fuel flow restriction, surging, loss of power, hard starting problem etc., replace the fuel filter immediately regardless of maintenance schedule and consult an authorized Kia dealer for details.

# LEGAL DISCLAIMERS

Driving while distracted is dangerous and should be avoided. Drivers should remain attentive to driving and always exercise caution when using the steering-wheel-mounted controls while driving.

Driving while distracted can result in a loss of vehicle control that may lead to an accident, severe personal injury and death. The driver's primary responsibility is in the safe and legal operation of a vehicle, and use of any handheld devices, other equipment or vehicle systems which take the driver's eyes, attention and focus away from the safe operation of a vehicle or that are not permissible by law should never be used during operation of the vehicle.

**Safety Features:** No system, no matter how advanced, can compensate for all driver error and/or driving conditions. Always drive responsibly.

**Airbags:** For maximum protection, always wear your seat belt.

**Android Auto:** Android Auto is a trademark of Google, Inc. Android™ is a registered trademark of Google, Inc. Distracted driving can result in a loss of vehicle control. Never use a handheld device or vehicle system that takes your focus away from safe vehicle operation. Navigation is for information purposes only, and Kia does not make any warranties about the accuracy of the information.

**Apple CarPlay®:** Apple CarPlay® is a registered trademark of Apple Inc. Distracted driving can result in a loss of vehicle control. Never use a handheld device or vehicle system that takes your focus away from safe vehicle operation. Navigation is for information purposes only, and Kia does not make any warranties about the accuracy of the information.

**Apps:** All information contained herein was based upon the latest available information at the time of appstore registration. Descriptions are believed to be correct, and Kia Motors Corporation (KMC) makes every effort to ensure accuracy, however, accuracy cannot be guaranteed. From time to time, KMC may need to update or make changes to the vehicle features and other vehicle information reported in this app. KMC, by the publication and dissemination of this material, does not create any warranties, either express or implied, to any Kia products. Contact your local Kia dealer for the most current information.

**Autonomous Emergency Braking System (AEB) / Forward Collision Warning System:** These systems are not substitutes for safe driving, and may not detect all objects in front of vehicle. Always drive safely and use caution.

**Bluetooth® Wireless Technology:** The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG Inc., and any use of such marks by Kia is pursuant to license. A Bluetooth® enabled cell phone is required to use Bluetooth® wireless technology.

**Driver Assist Features - Blind Spot Detection (BSD) with Lane Change Assist, Rear Cross Traffic Alert (RCTA), Lane Keeping Assist System / Lane Departure Warning System, Rear-Camera Display:** These features are not substitutes for safe driving, and may not detect all objects surrounding vehicle. Always drive safely and use caution.

**Electronic Stability Control (ESC) / Traction Control System (TCS)/Hill-start Assist Control (HAC):** No system, no matter how advanced, can compensate for all driver error and/or driving conditions. Always drive responsibly.

**Engine Start/Stop Button with Smart Key:** Always come to a complete stop before turning the engine on or off. However, if you have an emergency while the vehicle is in motion and must turn the engine off, you can turn the engine off to the ACC position by pressing the Start/Stop button for more than 3 seconds or 3 times in succession. If the vehicle is still moving, you can restart the engine by pressing the Start/Stop button with the shift lever in Neutral (N). With the engine off, hydraulic power assist for steering and braking will be disabled and the vehicle will be more difficult to control.

**Front Seat Headrest Adjustment:** Never attempt to adjust headrests when vehicle is in motion.

**Google Play™ Store** is a trademark of Google, Inc. © 2012 Google Inc. All rights reserved. Google and the Google Logo are registered trademarks of Google Inc.

**HomeLink®:** Homelink® is a registered trademark of Gentex Corporation

**iPod®** is a registered trademark of Apple Inc. iPod® mobile digital device sold separately, and connectivity requires the Kia accessory cable.

**Navigation:** Distracted driving can result in a loss of vehicle control. When operating a vehicle, never use a vehicle system that takes your focus away from safe vehicle operation. Navigation is for information purposes only, and Kia does not make any warranties about the accuracy of the information.

**Occupant Detection System (ODS):** Kia vehicles use a number of different ODS types that vary by model.

**Pandora® internet radio:** Pandora® is a registered trademark of Pandora Media, Inc.

**Roadside Assist:** 24-hour Enhanced Roadside Assistance is a service plan provided by Kia Motors America, Inc. Certain limitations apply. Coverage details are available in the Kia Warranty and Consumer Information Manual. For access to Enhanced Roadside Assistance, a connected mobile phone via Bluetooth® within the cellular service coverage area is required.

**Seat adjustments:** Reclining the passenger seats can reduce the effectiveness of the safety restraint system and may lead to additional injury in an accident.

**Seat belts:** For maximum protection, always wear your seatbelt.

**Seat warmers:** Use extreme caution when using the seat warmers to avoid burns. Refer to the Owner's Manual for more information.

**SiriusXM®:** SiriusXM Satellite Radio, SiriusXM Traffic and SiriusXM Travel Link each require a subscription sold separately, or as a package, by SiriusXM Radio Inc. **If you decide to continue your service at the end of your trial subscription, the plan you choose will automatically renew and bill at then-current rates until you call 1-866-635-2349 to cancel. See SiriusXM Customer Agreement for complete terms at [www.siriusxm.com](http://www.siriusxm.com).** Other fees and taxes will apply. All fees and programming are subject to change. Not all vehicles or devices are capable of receiving all services offered by SiriusXM. Data displays and individual product availability vary by vehicle hardware. Current information and features may not be available in all locations, or on all receivers. Weather Forecast, Current Conditions may not be available in all locations. Images above are for representative purposes only and are not real products. For actual features and images of real products, consult the vehicle manufacturer. SiriusXM is not responsible for any errors or inaccuracies in the data services or their use in the vehicle. Travel Link Stocks displays current price and daily delta of around 7,000 actively reported securities traded on the NYSE®, NASDAQ® and AMEX®. The service is delayed approximately 20 minutes. SiriusXM satellite service is available only to those at least 18 years of age in the 48 contiguous USA, DC, and Puerto Rico (with coverage limitations). SiriusXM Internet Radio service is available throughout our satellite service area and in AK and HI. © 2015 SiriusXM Radio Inc. Sirius, XM and all related marks and logos are trademarks of SiriusXM Radio Inc.

**Power Trunk / Smart Trunk:** Driving with the trunk open may be unlawful and can draw dangerous exhaust fumes into your vehicle; if you choose to do so, keep air vents and all windows open for proper ventilation.

**Sportmatic®** is a registered trademark of Kia Motors America.

**Steering-wheel-mounted controls:** Driving while distracted is dangerous and should be avoided. Remain attentive to driving and be cautious when using steering-wheel-mounted controls while driving.

**Sunvisors:** Sunvisor may not shield all direct light. Do not operate the vehicle if sunvisor is impairing your visibility.

**Tilt/Telescoping Steering Wheel:** Never attempt to adjust steering wheel position when vehicle is in motion.

**Tire Pressure Monitoring System (TPMS):** Even with Tire Pressure Monitoring System, check tire pressure on a regular basis.

**UVO eServices:** Distracted driving can result in a loss of vehicle control. Never use a handheld device or vehicle system that takes your focus away from safe vehicle operation.

**UVO eServices app:** App uses your smartphone data service. Normal cellular service rates will apply.

**UVO eServices with Navigation/Premium Navigation:** Distracted driving can result in a loss of vehicle control. Never use a handheld device or vehicle system that takes your focus away from safe vehicle operation. Navigation is for information purposes only, and Kia does not make any warranties about the accuracy of the information.

**Vehicle Diagnostics:** Vehicle Diagnostics checks powertrain, chassis and air bag systems, and is not a substitute for maintenance. See UVO eServices Maintenance Feature or Owner's Manual for maintenance schedule




## KEY FEATURE WALKTHROUGH

Demonstrate the following with the customer

☐ Standard Audio System\*

(Type A)– page 20


For further operational information, refer to the Owner's Manual.



☐ Standard Audio System\*


(Type B)– page 21

For further operational information, refer to the Owner's Manual.




☐ UVO eServices System\* – page 23

For further operational information, refer to the Car Multimedia System User's Manual. .




☐ UVO eServices with Premium Navigation System\* – page 24

For further operational information, refer to the Car Multimedia System User's Manual.




☐ Cruise Control\* – page 17

Demonstrate operation.



☐ Bluetooth® Wireless Technology\*– page 18

Demonstrate operation.



☐ Tire Pressure Monitoring System (TPMS) – page 7

☐ Active ECO System\* – page 8

☐ Engine Start/Stop Button\* – page 12

☐ Digital Clock – page 25

☐ Aux/USB/iPod® Port – page 25

☐ Seat Warmers / Ventilated Seat\* – page 30

☐ Folding Rear Seats\* – page 32

☐ Sunvisor – page 37

☐ Smart Key\* – page 35

☐ HomeLink® with Auto-Dimming Rearview Mirror\* – page 38

☐ Rear-Camera Display\* – page 39

☐ Passenger Air Bag Off Indicator – page 40

## DURING DELIVERY

\*if equipped

- ☐ Explain first service process and schedule first service appointment
- ☐ Tour Parts & Service departments, introduce staff and explain value of Kia Parts and Service
- ☐ Review recommended maintenance schedule and maintenance requirements to validate warranty
- ☐ Review business hours and Customer 360° Care
- ☐ Review the Kia 10-year/100,000-mile warranty program
- ☐ Ensure 100% satisfaction with sales and delivery process and no problems with the vehicle
- ☐ Confirm time and best contact number for initial dealer follow-up

Sales Consultant: \_\_\_\_\_ Date: \_\_\_\_\_

Sales Manager: \_\_\_\_\_ Date: \_\_\_\_\_

Customer: \_\_\_\_\_ Date: \_\_\_\_\_



## FORTE CUSTOMER DELIVERY CHECKLIST

Owner's Name: \_\_\_\_\_ VIN: \_\_\_\_\_ Mileage: \_\_\_\_\_

Dealership Name: \_\_\_\_\_ Sales Consultant: \_\_\_\_\_ Date: \_\_\_\_\_

### BEFORE DELIVERY


- ☐ Confirm "Good Battery" with Kia GR8-1299 battery tester
- ☐ Verify all tire pressures are to spec (see driver's door label) LF \_\_\_\_\_ LR \_\_\_\_\_ RF \_\_\_\_\_ RR \_\_\_\_\_
- ☐ Verify proper operation of Remote Keyless Entry and Smart Key lock/unlock
- ☐ Ensure floor mats are snapped into place (if applicable)
- ☐ Verify vehicle is clean (interior and exterior), in good condition and free of chips and scratches
- ☐ Ensure all key documents are in the vehicle (Owner's Manual, Warranty and Consumer Information booklet, Tire Warranty booklet and Features & Functions Guide and any supplemental audio user's guides)

### KEY FEATURE WALKTHROUGH


- ☐ Air Conditioning / Climate Control – pages 26-27

Demonstrate Air Flow Modes, Defog and Defrosting Windshield.

Automatic\*




Manual\*



- ☐ Manual Gear Shift\* – page 29


Demonstrate pressing button for reverse gear.



- ☐ Windshield/Rear\* Wipers & Washers - page 15

#### Front Wiper:


Rotate INT switch to adjust Intermittent Wipe Speed.



Pull to spray and wipe.

#### Rear Wiper:

Rotate REAR switch to change wiper modes.



Push lever for brief wipe.

**MIST:** Single wipe  
**OFF:** Wiper off  
**INT:** Intermittent wipe  
**LO:** Slow wipe  
**HI:** Fast wipe

\*IF EQUIPPED



© 2016 Kia Motors America, Inc. All rights reserved.

Part Number: UD170-PS-004

Consumer - Roadside Assistance: 1-800-333-4KIA (4542)