



HIGHLANDER

2 0 1 9



QUICK REFERENCE GUIDE



TOYOTA

2019

HIGHLANDER

This Quick Reference Guide is a summary of basic vehicle operations. It contains brief descriptions of fundamental operations so you can locate and use the vehicle's main equipment quickly and easily.

The Quick Reference Guide is not intended as a substitute for the Owner's Manual located in your vehicle's glove box. We strongly encourage you to review the Owner's Manual and supplementary manuals so you will have a better understanding of your vehicle's capabilities and limitations.

Your dealership and the entire staff of Toyota Motor North America, Inc. wish you many years of satisfied driving in your new Highlander.



A word about safe vehicle operations

This Quick Reference Guide is not a full description of Highlander operations. Every Highlander owner should review the Owner's Manual that accompanies this vehicle.

Pay special attention to the boxed information highlighted in color throughout the Owner's Manual. Each box contains safe operating instructions to help you avoid injury or equipment malfunction.

All information in this Quick Reference Guide is current at the time of printing. Toyota reserves the right to make changes at any time without notice.

OVERVIEW

Engine maintenance	9
Fuel tank door release & cap	8
Hood release	8
Indicator symbols	4-5
Instrument cluster	4
Instrument panel	2-3
Instrument panel light control	8
Keyless entry ^{1,2}	6-7
Smart Key system ^{1,2}	7

FEATURES & OPERATIONS

Air conditioning/heating	22-23
All-wheel drive lock switch	31
Audio	20
Auto lock/unlock ¹	10
Automatic transmission	10
Bird's Eye View Camera	
with Perimeter Scan function	28
Blind Spot Monitor with Rear Cross	
Traffic Alert (BSM w/RCTA)	27
Clock	10
Door locks ^{1,2}	11
Downhill Assist Control system (DAC)	30
Driver Easy Speak	25
Garage door opener (HomeLink®) ³	25
Intelligent parking assist	26
Lights ^{1,2} & turn signals ¹	17
Moonroof ¹	12
Multi-Information Display (MID) ²	18
Panoramic moonroof	12
Parking brake	11
Power Liftgate (back door) ^{1,2}	13
Power outlets-12V DC	21
Power outlets-120V AC	21
Rear seat entertainment system	25
Rear view monitor system	27
Seat adjustments-Front	14
Seat adjustments-Rear	15
Seat heaters/ventilators	24
Seats-Head restraints	15
Seats-Stowing & returning 3rd row seats	15

FEATURES & OPERATIONS (continued)

Snow mode button	31
Steering lock release	11
Steering wheel switches & telephone controls (Bluetooth®)	19
Steering wheel-Hearer	23
Stop & Start Engine System	29
Tilt & telescopic steering wheel	14
USB charge-ports	21
USB media/AUX port	21
Vehicle Stability Control (VSC)/ TRAC OFF switch	30
Windows-Power ¹	18
Windshield wipers & washers ¹	16

TOYOTA SAFETY SENSE™ P (TSS-P)

Automatic High Beams (AHB)	42
Dynamic Radar	
Cruise Control (DRCC)	38-41
Lane Departure Alert with Steering Assist (LDA w/SA)	35-38
Pre-Collision System with Pedestrian Detection (PCS w/PD)	33-35
Quick overview-	
Toyota Safety Sense™ P (TSS-P)	32
Sensors	32



SAFETY & EMERGENCY FEATURES

Floor mat installation	47
Rear door child safety locks	44
Seat belt reminder indicator	43
Seat belts	43
Seat belts-3rd row center	43
Seat belts-Shoulder belt anchor	43
Spare tire & tools	45
Star Safety System™	46-47
Tire Pressure Monitoring (warning) System (TPMS)	44

BLUETOOTH® DEVICE PAIRING SECTION 48-57

¹ Visit your Toyota dealer for information on customizing this feature.
² Programmable by customer. Refer to the Owner's Manual for instructions and more information.
³ HomeLink® is a registered trademark of Gentex Corporation.

Instrument panel




¹ If equipped

² For details, refer to the “Navigation and Multimedia System Owner’s Manual” and “2019 Entune™ Audio Quick Reference Guide.”


Air conditioning controls

Manual



Rear window/ outside rear view mirror defogger

Automatic



Rear window/ outside rear view mirror defogger

Clock Audio/Navigation² system


Power back door main switch¹

VSC OFF switch

“SNOW” switch

“DAC” switch¹

All-wheel drive lock switch¹




Seat heater/ventilator switches¹

Or, seat heater switches¹



Instrument cluster



Indicator symbols

For details, refer to "Indicators and warning lights," Section 2, 2019 Owner's Manual.

	Airbag SRS warning ¹		SET Constant speed cruise control indicator/Constant speed cruise control SET indicator
	Air Bag ON/OFF indicator ¹		Downhill Assist Control indicator ⁴
	All-wheel drive lock indicator ^{1,4}		Driver's and front passenger's seat belt reminder (alarm will sound if speed is over 12 mph)
	Anti-lock Brake (ABS) System warning ¹		SET Dynamic Radar Cruise Control (DRCC)(vehicle-to-vehicle distance control mode) indicator/DRCC SET indicator
	Automatic High Beam (AHB) indicator		Eco driving indicator ¹
	Blind Spot Monitor (BSM) indicator ⁴		Electric power steering system warning ¹
	BSM outside rear view mirror indicator ⁴		
	Brake system warning ¹		



Front Fog light indicator⁴



Fuel tank door position



Headlight low/high beam indicator



Intelligent parking assist indicator⁴



Land Departure Alert with Steering Assist (LDA w/SA) indicator [white/green/amber³ indicator]



Low fuel level warning



Malfunction/Check Engine indicator¹



Master warning^{1,2}



Parking brake warning¹



“PWR MODE” indicator⁴



Pre-Collision System (PCS) warning^{1,2}



Security indicator



Slip indicator^{1,3}



SNOW mode indicator



Stop & Start Engine System indicator^{2,4}



Stop & Start Engine System cancel indicator⁴



Tire Pressure Warning¹



Turn signal indicator



Vehicle Stability Control (VSC) OFF indicator¹



2nd and 3rd row seat belt reminder indicator (warning buzzer)

¹ If the indicator does not turn off within a few seconds of starting the engine, there may be a malfunction. Have the vehicle inspected by your Toyota dealer.

² If the indicator flashes, there may be a malfunction. Refer to the Owner's Manual.


³ If the indicator flashes, it indicates that the system is operating.

⁴ If equipped.

OVERVIEW


Keyless entry

UNLOCKING OPERATION




NOTE: If a door is not opened within 60 seconds of unlocking, all doors will relock for safety.

LOCKING OPERATION




POWER LIFTGATE OPERATION (IF EQUIPPED)




NOTE: Power back door will not open if glass hatch is open.

GLASS HATCH UNLOCK (IF EQUIPPED)



Carry remote to unlock

BACK DOOR LOCK/UNLOCK (IF EQUIPPED)



Carry remote to lock/unlock

* Driver door unlocking function can be programmed to unlock driver door only, or all doors. Grasping passenger door handle will unlock all doors.

NOTE: Doors may also be locked/unlocked using remote.

PANIC BUTTON



Smart Key




HOLD

 Push and hold



Smart Key system


START FUNCTION



NOTE: The Smart Key must be carried to enable the start function. With gear shift lever in Park and the brake pedal depressed, push the “ENGINE START STOP” switch.

POWER (WITHOUT STARTING ENGINE)

Without depressing the brake pedal, pressing the “ENGINE START STOP” switch will change the operation mode in succession from:




Off - All systems OFF. Emergency flashers can be used.

Accessory – Some electrical components can be used.


On - All electrical components can be used.

Fuel tank door release & cap




NOTE: To close, tighten until one click is heard. If the cap is not tightened enough, Check Engine “CHECK” indicator may illuminate.

Hood release




Instrument panel light control




The brightness level of the meters when the surroundings are bright (day mode) and dark (night mode) can be adjusted individually. However, when in day mode, adjusting the brightness level will also change the brightness level of night mode.

Engine maintenance

2.7 L 4-cylinder (1AR-FE) engine



3.5 L V6 (2GR-FKS) engine



NOTE: Regularly scheduled maintenance, including oil changes, will help extend the life of your vehicle and maintain performance. Please refer to the “Warranty & Maintenance Guide.”

FEATURES & OPERATIONS

Auto lock/unlock

Automatic door locks can be programmed to operate in different modes, or turned OFF.

Shift position linked door locking/unlocking function

- Doors lock when shifting from Park.
- Doors unlock when shifting into Park.

Speed linked door locking function


- Doors lock when the vehicle speed goes above approximately 12 mph.

Driver's door linked door unlocking function

- (Without a Smart Key) Doors unlock when the engine switch is set from "ON" to "ACC" or "LOCK" and driver's door is opened.
- (With a Smart Key) Doors unlock when the "ENGINE START STOP" switch is set to OFF and driver's door is opened.

Refer to the Owner's Manual for more details.

Automatic transmission



* The "ENGINE START STOP"/ignition switch must be "ON" and the brake pedal depressed to shift from Park.

"S" (SEQUENTIAL) MODE

Shift the shift lever to "S" position from "D" position.

- + : Upshift (push and release)
- : Downshift (pull and release)


Downshifting increases power going uphill, or provides engine braking downhill. For best fuel economy during normal driving conditions, always drive with the shift lever in the "D" position.

Clock




Press "H" for Hours and "M" for minutes to set or change the time.

Door locks



Steering lock release


With Smart Key system



"Steering Lock active" will be displayed on the multi-information display.

Check that the shift lever is set in P.
Press the engine switch while turning the steering wheel left and right.


Without Smart Key system



When starting the engine, the engine switch may seem stuck in the "LOCK" position. To free it, turn the key while turning the steering wheel slightly left and right.

Parking brake

PARK




Set: Depress
Release: Depress again

FEATURES & OPERATIONS

Moonroof (if equipped)

SLIDING OPERATION


Push once to open partway; again to open completely.



Recommended open position to minimize wind noise.

TILTING OPERATION

Push once to open completely.





Close

Lightly press either side of the moonroof switch while opening/tilting is in progress, the moonroof stops partway.

Panoramic moonroof (if equipped)

SHADE OPERATION



To stop operation partway, quickly slide and release the switch again.



If the moonroof is open, pressing the switch closes it up to the tilt-up position.
If the shade is closed past the half-open position when the switch is pressed, it will open up to the half-open position.


SLIDING OPERATION

The moonroof stops slightly before the fully open position to reduce wind noise and the shade opens fully. Slide the switch again to fully open or close the moonroof.



Power Liftgate (back door) (if equipped)


Instrument panel




Push and hold

Open: Push and hold
Close: Push and hold again

Open only



Open and close



NOTE: If battery is disconnected, the power back door needs to be reinitialized. Refer to the Owner's Manual for more details.

PROGRAMMABLE POWER LIFTGATE


1. When the liftgate reaches the desired height, push the rear liftgate close-button (on the door jam of the liftgate) once. Press and hold the button until the buzzer sounds.
2. To reset the height, with the liftgate open and not moving, press and hold the rear liftgate close-button until it buzzes, and continue to hold until it buzzes again -then let go. Push the same button to close the liftgate. When you next open the liftgate it will open to the maximum height.
3. The height can also be set through the "Setup" screen on the audio display. Setup > Vehicle Customization > Other Vehicle Settings > Power Back Door Opening Adjust. Through this screen, there are 5 height options to choose from.

NOTE: If the liftgate has stopped operating, check inside the glove box, on the left side, to ensure the PWR DOOR OFF button has not been pushed.


For detailed instructions, see Owner's Manual.

FEATURES & OPERATIONS

Tilt & telescopic steering wheel



Lock release lever




Hold wheel, push lever down, set angle and length, and return lever.


NOTE: Do not attempt to adjust while the vehicle is in motion.

Seat adjustments-Front

MANUAL SEAT




POWER SEAT




Seat adjustments-Rear


Second row type 1



Second row type 2




Third row seat




Refer to the Owner's Manual for more details.


Seats-Stowing & returning 3rd row seats



(1) Pull (from outside)




(2) Raise (from inside)




Seats-Head restraints


Front



Second row




Third row




Windshield wipers & washers

FRONT

With intermittent wiper




With AUTO rain-sensing wiper



¹ **Intermittent windshield wiper frequency adjustment** Rotate to increase/decrease wipe frequency.


² **Rain-sensing windshield wipers** Rotate to increase/decrease sensor sensitivity.

REAR



Lights & turn signals

HEADLIGHTS



Daytime Running Light system (DRL) Automatically turns on under certain conditions to make vehicle more visible to other drivers. Not for use at night.


Automatic light cut off system Lights automatically turn off after a delay of 30 seconds, or when lock switch on remote is pushed after all doors are locked.

Automatic High Beam (AHB) system Automatically switches between high and low beams as appropriate to keep the high beam lamps on for as long as possible for enhanced vision at night.

Refer to *Toyota Safety Sense™ P (TSS-P)* in this guide or the *Owner's Manual* for more details on the *Automatic High Beam* feature.


* Operating conditions must be met. Refer to Owner's Manual for details.

FRONT FOG LIGHTS (IF EQUIPPED)





Front fog lights come on only when the headlights are on low beam.

TURN SIGNALS



Multi-Information Display (MID)



Press: Displays the screen registered as the top screen

Press and hold: Registers the currently displayed screen as the top screen

Push MID control switches to view or change information in the following:



Drive information



Navigation system linked display (if equipped)



Audio system-linked display (if equipped)



Driving assist information



Stop & Start Engine System information (if equipped)




Warning messages




Settings display

Windows-Power

DRIVER SIDE



WINDOW LOCK SWITCH




Automatic operation front row or all-position (if equipped) Push the switch completely down or pull it completely up and release to fully open or close. To stop the window partway, operate the switch in the opposite direction.


Window lock switch Deactivates all passenger windows. Driver's window remains operable.

Steering wheel switches & telephone controls (Bluetooth®)

Steering wheel telephone controls



Microphone



Bluetooth® technology allows dialing or receipt of calls without removing your hands from the steering wheel or using a cable to connect the telephone and the system.

* Push and hold to access Mobile Assistant. When a compatible smartphone is Bluetooth® connected push and hold the off hook switch 2-3 seconds to access Siri® Eyes Free.

Refer to the "Navigation and Multimedia System Owner's Manual" for more details.


Refer to the "Bluetooth® Device Pairing Section" in this guide for more information about phone connections and compatibility.

NOTE: Concentrating on the road should always be your first priority while driving. Do not use the hands-free phone system if it will distract you.

FEATURES & OPERATIONS


Audio

ENTUNE™ AUDIO



ENTUNE™ AUDIO PLUS

ENTUNE PREMIUM (JBL®) AUDIO WITH INTEGRATED NAVIGATION AND APP SUITE* *Limited models may be equipped with the JBL upgrade in this unit.*



HOME SCREEN - the home screen offers a two panel and a three panel layout. Information and layout will vary depending on selected set up.

For more information, refer to the "Navigation and Multimedia System Owner's Manual" and "2019 Entune™ Audio Quick Reference Guide."

NOTE: Concentrating on the road should always be your first priority while driving. Do not use the Entune system if it will distract you.


Visually match your vehicle's Entune™ audio system to one featured in this guide for the most accurate information.

* The Entune App Suite may not be pre-installed in your vehicle. In order to activate the Entune App Suite, download and launch the Entune app on your smartphone, connect the phone to the vehicle via Bluetooth®, and open the Entune™ App on the phone and sign in. Press the "Apps" button on the audio unit and accept the prompt to update the Apps. The download process will take up to 15 minutes, and when it is complete, follow the on-screen prompts to complete installation. Once the update is complete, the available Apps will be listed on the Apps menu screen.


** LE models have "SETUP" button while LE Plus models have "APPS" button.

Power outlets- 12V DC


Front



Center console




Power outlets- 120V AC (if equipped)




USB charge-ports (if equipped)

Front




Rear



The "ENGINE START STOP"/ignition switch must be in the ACCESSORY or IGNITION ON/"ACC" or "ON" position to be used.

USB media/AUX port



USB media port

By connecting a USB-compatible portable audio device or USB memory stick into the USB media port, you can listen to music through the vehicle's speaker system.

AUX port


By inserting an AUX cable into the AUX port, you can listen to music from a portable audio device through the vehicle's speaker system while in AUX mode.

FEATURES & OPERATIONS

Air conditioning/heating


FRONT AUTOMATIC AIR CONDITIONING (IF EQUIPPED)

Automatic climate control ON
Adjusting the temperature setting
will cause the airflow vents,
air intake and fan to adjust
automatically.




***Indicator ON:** Synchronize temperature settings for driver and all passengers.
Indicator OFF: Separate temperature settings for driver, front passenger and rear passengers.

FRONT MANUAL AIR CONDITIONING (IF EQUIPPED)




REAR AIR CONDITIONING (IF EQUIPPED)


Automatic



Manual



Steering wheel-Heater (if equipped)




The "ENGINE START STOP"/Ignition switch must be in the ACCESSORY or IGNITION ON/"ACC" or "ON" position to be used.

FEATURES & OPERATIONS


Seat heaters/ventilators

FRONT SEAT HEATERS AND VENTILATORS (IF EQUIPPED)

Seat heaters




Seat heaters/ventilators




Turn the seat heater on and adjust the number, the higher the number, the warmer the seat becomes.

SECOND ROW SEAT HEATERS (IF EQUIPPED)



Rear seat entertainment system (if equipped)




Refer to section 7-1 of the Navigation and Multimedia System Owner's Manual for more information.

Driver Easy Speak (if equipped)

This feature utilizes the vehicle's built-in microphone to amplify the driver's voice through the rear speakers. To activate this feature, select "Driver Easy Speak" from the Apps screen on the audio unit. The feature must be turned on every time you enter the vehicle, and automatically turns off when any door (including the liftgate) is opened. There are 7 volume settings.

Garage door opener (HomeLink®)* (if equipped)




Garage door openers manufactured under license from HomeLink®* can be programmed to operate garage doors, estate gates, security lighting, etc.

Refer to "Garage door opener," Section 6-4 in the Owner's Manual for more details.


For programming assistance, contact HomeLink® at 1-800-355-3515, or visit <http://www.homelink.com>.

* HomeLink® is a registered trademark of Gentex Corporation.

Intelligent parking assist (if equipped)



Multi-Information Display (MID)




The parking assist sonar system operates when the vehicle approaches an obstacle. The distance from your vehicle to nearby obstacles when parallel parking or maneuvering into a garage is measured by sensors and communicated via the Multi-Information Display (MID), the navigation system screen and audible beeps.

When the sensor detects an obstacle, the direction of and the approximate distance to the obstacle are displayed on the MID display or the navigation system screen by illuminating continuously (far) or blinking (near), and beeping sounds will switch from intermittent to continuous as you approach and get closer to a detected obstacle. When the sensors detect two or more obstacles, the audible alerts will respond to the nearest zone.

Always check the surrounding area when using this system.

*Refer to section **Intuitive parking assist** in the **Navigation and Multimedia System Owner's Manual** for more details.*

Blind Spot Monitor with Rear Cross Traffic Alert (BSM w/RCTA) (if equipped)




The Blind Spot Monitor is a system that has two functions:

- The Blind Spot Monitor function (assists the driver in making the decision when changing lanes)
- The Rear Cross Traffic Alert function (assists the driver when backing up)

The system is designed to use radar sensors to detect vehicles traveling in the Highlander's blind spot and advises the driver of the vehicles' presence via the outside rear view mirror indicators.

Refer to the Owner's Manual for limitations and more details on this system before attempting to use it.

Rear view monitor system (if equipped)




The rear view monitor system displays an image of the view from the bumper of the rear area of the vehicle. The camera for the rear view monitor system is located above the license plate.

To adjust the image on the rear view monitor screen, press the "SETUP" button and select "Display" on the "Setup" screen. Select "Camera" to adjust the screen contrast and brightness.

Refer to the Owner's Manual and Navigation and Multimedia System Owner's Manual for limitations and more details on this system.

Bird's Eye View Camera with Perimeter Scan Function (if equipped)




Moving view



Rotation pause switch
See-through view switch

See through view



Rotation pause switch
Moving view switch

The Bird's Eye View Camera with Perimeter Scan function assists the driver in viewing the surroundings, when operating at low speeds or parking, by combining front, side and rear cameras and displaying an overhead image on the Entune™ screen.

To view or turn OFF the screen, press the camera switch when the shift lever is in the "P" position. It will display two angles, the Moving view and the See Through view.


For limitations and more details, refer to section 6-3 in the "Navigation and Multimedia System Owner's Manual."

Stop & Start Engine System (if equipped)

The Stop & Start Engine System stops and restarts the engine according to the brake pedal operation and other operations when the vehicle is stopped.


Stopping the engine

While driving with the shift lever in D, depress the brake pedal, and stop the vehicle.



Disabling the Stop & Start Engine System

Press the Stop & Start Engine System cancel switch to disable the system.




HILL-START ASSIST CONTROL (HAC)

If the engine is stopped by the Stop & Start Engine System when the vehicle is on an incline, brake force is temporarily maintained to prevent rolling backwards until the engine is restarted and drive force is generated. When drive force is generated, the maintained brake force is automatically canceled.

FEATURES & OPERATIONS

Vehicle Stability Control (VSC)/ TRAC OFF switch




The VSC OFF switch can be used to help free a stuck vehicle in surroundings like mud, dirt or snow. While the vehicle is stopped, press switch to disable the TRAC system.

To disable both VSC and TRAC systems, press and hold the switch for at least 3 seconds.

Refer to the Owner's Manual for limitations and more details.

Downhill Assist Control system (DAC) (AWD models)



With the downhill assist control system, the vehicle is able to descend a steep hill, maintaining a constant low speed of about 18 mph (30 km/h) without brake pedal operation.

Press the "DAC" button to activate the system. The slip indicator will flash to indicate that the downhill assist control system is operating.

Refer to the Owner's Manual for more details.


Snow mode button



Use snow mode for accelerating and driving on slippery road surfaces, such as on snow.

Refer to the Owner's Manual for more details.

All-wheel drive lock switch (AWD models)



All-wheel drive lock mode can be used when a large amount of drive power needs to be applied to all the wheels, such as when the vehicle gets stuck in mud and you need to free it.

Refer to the Owner's Manual for more details.

Quick overview-Toyota Safety Sense™ P (TSS-P)

Toyota Safety Sense™ P (TSS-P) is a set of active safety technologies designed to help mitigate or prevent collisions across a wide range of traffic situations, in certain conditions. TSS-P is designed to help support the driver's awareness, decision making and vehicle operation contributing to a safe driving experience.

Refer to the Owner's Manual for operation, setting adjustments, limitations and more details to understand these functions and complete safety precautions. For more information, please go to <http://www.toyota.com/safety-sense>.



Pre-Collision System with Pedestrian Detection (PCS w/PD)

PCS w/PD is designed to provide alert, mitigation, and/or avoidance support in certain conditions, when the system detects a potential collision with a preceding vehicle is likely to occur.

The advanced millimeter-wave radar sensor system is designed to work with the camera sensor to help recognize a preceding pedestrian, and provide an alert, mitigation and/or avoidance support in certain conditions.



Lane Departure Alert with Steering Assist (LDA w/SA)

LDA w/SA is designed to provide notification when the system detects an unintended lane departure.

The Steering Assist function is designed to provide small corrective steering inputs to the steering wheel for a short period of time to help keep the vehicle in its lane.



Dynamic Radar Cruise Control (DRCC)

DRCC is designed to help maintain a pre-set distance to a preceding vehicle when the preceding vehicle is traveling at a lower speed.




Automatic High Beams (AHB)


AHB is designed to detect the headlights of oncoming vehicles and the tail lights of preceding vehicles and switch between high beams and low beams as appropriate.

Sensors

TSS-P combines an in-vehicle camera mounted in front of the inside rear view mirror and a millimeter-wave radar mounted in the front grill. These sensors support the driver assist systems.



Pre-Collision System with Pedestrian Detection (PCS w/PD)



The Pre-Collision System uses a radar sensor and camera sensor to help detect a vehicle or pedestrian in front of your vehicle.

As there is a limit to the degree of recognition accuracy and control performance that this system can provide, do not overly rely on this system. This system will not prevent collisions or lessen collision damage or injury in every situation. Do not use PCS instead of normal braking operations under any circumstances. Do not attempt to test the operation of the pre-collision system yourself, as the system may not operate or engage, possibly leading to an accident. In some situations, such as when driving in inclement weather such as heavy rain, fog, snow or a sandstorm or while driving on a curve and for a few seconds after driving on a curve, a vehicle may not be detected by the radar and camera sensors, preventing the system from operating or engaging properly.

Refer to the Toyota Owner's Manual for a list of additional situations in which the system may not operate properly.

Pre-Collision Warning

When the system determines that the possibility of a frontal collision is high, a buzzer will sound and a warning message will be displayed on the Multi-Information Display (MID) to urge the driver to take evasive action.

Pre-Collision Brake Assist

If the driver notices the hazard and brakes, the system may provide additional braking force using Brake Assist. This system may prime the brakes and may apply greater braking force in relation to how strongly the brake pedal is depressed.


Pre-Collision Braking

If the driver does not brake in a set time and the system determines that the possibility of a frontal collision with a preceding vehicle is extremely high, the system may automatically apply the brakes, reducing speed in order to help the driver reduce the impact and in certain cases avoid the collision.

Refer to the Toyota Owner's Manual for additional information on PCS w/PD operation, settings adjustments, limitations, and precautions before attempting to use it.

PCS PEDESTRIAN DETECTION


Under certain conditions, the PCS system included with the TSS-P package may also help to detect a pedestrian in front of your vehicle using the in-vehicle camera and front-grill mounted millimeter wave radar. The in-vehicle camera of PCS detects a potential pedestrian based on size, profile, and motion of the detected pedestrian. However, a pedestrian may not be detected depending on the conditions, including the surrounding brightness and the motion, posture, size, and angle of the potential detected pedestrian, preventing the system from operating or engaging.



As part of the Pre-Collision System, this function is also designed to first provide an alert and then automatic braking if needed.

Refer to a Toyota Owner's Manual for additional limitations and information.


CHANGING PCS ALERT TIMING



- (1) Press “<>” switches and select  from the Multi-Information Display (MID).
- (2) Press “<>” switches and select  from the MID and then press “.”
- (3) Select “Sensitivity” and then press “.

Each time “” is pressed, the response to the PCS alert timing changes as shown above. You can press “” to go back to the menu.


Note: PCS is enabled each time the engine switch is turned to Ignition On. The system can be disabled/enabled and the alert timing of the system can be changed. (Alert timing only, brake operation remains the same).



- (1) Press “<>” switches and select  from the Multi-Information Display (MID).
- (2) Press “<>” switches and select the  setting function from the MID and then press “○”. The setting screen is displayed.
- (3) Select **PCS** and then press “○.” The Pre-Collision System will be disabled. You can press “<>” to go back to the menu.

Note: The system is enabled each time the engine switch is turned to Ignition On.

Lane Departure Alert with Steering Assist (LDA w/SA)




LDA in TSS-P uses an in-vehicle camera designed to detect visible white and yellow lane markers in front of the vehicle and the vehicle's position on the road. If the system determines that the vehicle is starting to unintentionally deviate from its lane, the system alerts the driver with an audio and visual alert. When the alerts occur, the driver must check the surrounding road situation and carefully operate the steering wheel to move the vehicle back to the center part of their lane.

LDA is designed to function at speeds of approximately 32 MPH or higher on relatively straight roadways.

In addition to the alert function, LDA w/SA also features a steering assist function. When enabled, if the system determines that the vehicle is on a path to unintentionally depart from its lane, the system may provide small corrective steering inputs to the steering wheel for a short period of time to help keep the vehicle in its lane.

TURNING THE LDA SYSTEM ON/OFF




Press the LDA switch to turn the LDA system on. Depress again to turn it off.

Note: The system will continue in the last state it was in (ON or OFF) when the engine is started again.

Refer to the Toyota Owner's Manual for additional information on LDA operation, settings adjustments, limitations, and precautions before attempting to use it.

LANE DEPARTURE ALERT

LDA function display



Lane Departure Alert (LDA) indicator flashes orange when operating



The LDA function  displays when the Multi-Information Display (MID) is switched to the driving assist system information screen.

(1) The system displays solid white lines on the LDA indicator when visible lane markers on the road are detected. A side flashes orange to alert the driver when the vehicle deviates from its lane.

(2) The system displays outlines on the LDA indicator when lane markers on the road are not detected or the function is temporarily cancelled.

Note: When operation conditions are no longer met, a function may be temporarily canceled. However, when the operation conditions are met again, operation of the function is automatically restored. For example, LDA may not function on the side(s) where white/yellow lines are not detectable.

DISABLING STEERING ASSIST

- (1) Press “<>” switches and select  from the Multi-Information Display (MID).
- (2) Press “<” switches and select the  setting function and then press “○”.
- (3) Press “○” each time to change the setting.
- (4) Press “>” to go back to the menu.

Note: Operation of the LDA system and setting adjustments continues in the same condition regardless of ignition cycle until changed by the driver or the system is reset.

ADJUSTING LDA ALERT SENSITIVITY

The driver can adjust the sensitivity of the LDA (warning) function from the Multi-Information Display (MID) customization screen.

High - Is designed to warn approximately before the front tire crosses the lane marker.


Normal - (default) Is designed to warn approximately when the front tire crosses the lane marker.

- (1) Press “<>” switches and select  from the Multi-Information Display (MID).
- (2) Press “<” switches and select the  setting function and then press “○”.
- (3) Press “○” each time to change the setting. Press “>” to go back to the menu.

SWAY WARNING SYSTEM



Continuous lane deviations from swaying.



Gentle swaying from driver's inattentiveness.



Acute steering wheel operation after the number of operations decrease due to driver's inattentiveness.

SWS is a function of LDA and is designed to detect swaying based on the vehicle location in the lane and the driver's steering wheel operation. To help prevent swaying, the system alerts the driver using a buzzer sound and a warning displays in the MID.


DISABLING LDA SWAY WARNING SYSTEM

- (1) Press “◀▶” switches and select  from the Multi-Information Display (MID).
- (2) Press “⏏” switches and select the SWS setting function and then press “○”.
- (3) Press “○” each time to change the setting. Press “▶◀” to go back to the menu.

Note: Operation of the LDA system and setting adjustments continues in the same condition regardless of Ignition cycle until changed by the driver or the system is reset.



Dynamic Radar Cruise Control (DRCC)

DRCC helps maintain a pre-set distance to a preceding vehicle when the preceding vehicle is traveling at a lower speed. This mode is always selected first when the cruise control button is depressed. Constant speed control mode is also available.



TURNING SYSTEM ON/OFF


(1)



Push once: On
Push twice: Off

Refer to page 41 for switching to Constant Speed (Cruise) Control Mode.

ADJUSTING SET SPEED




Vehicle will cruise at a set speed, decelerate to maintain selected distance from a slower vehicle traveling in front and accelerate back up to the selected speed if the vehicle in front changes lanes or speeds up.

- (1) Push the ON-OFF button. The “RADAR READY” or “” indicator will come on.
- (2) Push the lever down to SET speed, push it up to Resume and pull it or depress brake to Cancel.
- (3) Push up to increase the set speed, push down to decrease (1 mph [1.6 km/h] or 1 km/h [0.6 mph] increments).

¹ The set speed may also be cancelled by depressing the brake pedal.

² The set speed may be resumed once vehicle speed exceeds 25 mph.

ADJUSTING DISTANCE




To change the vehicle-to-vehicle distance

Push the “” button to cycle through the settings, which will change progressively.

This mode employs a radar sensor to detect the presence of vehicles up to approximately 320 ft (100 m) ahead, determines the current vehicle-to-vehicle following distance and operates to maintain a preset following distance from the vehicle ahead.

Note: Vehicle-to-vehicle distance will close in when traveling on long downhill slopes.



(1) Constant speed cruising when there are no vehicles ahead

The vehicle travels at the speed set by the driver. The desired vehicle-to-vehicle distance can also be set by operating the vehicle-to-vehicle distance control.

(2) Deceleration cruising and follow-up cruising when a preceding vehicle driving slower than the set speed appears


When a vehicle is detected running ahead of you, the system automatically decelerates your vehicle. When a greater reduction in vehicle speed is necessary, the system applies the brakes (the brake lights will come on at this time). The system will respond to changes in the speed of the vehicle ahead in order to maintain the vehicle-to-vehicle distance set by the driver. A warning tone warns you when the system cannot decelerate sufficiently to prevent your vehicle from closing in on the vehicle ahead.

(3) Acceleration when there are no longer any preceding vehicles driving slower than the set speed

The system accelerates until the set speed is reached. The system then returns to constant speed cruising.

Note: When your vehicle is too close to a vehicle ahead, and sufficient automatic deceleration via the cruise control is not possible, the display will flash and the buzzer will sound to alert the driver. An example of this would be if another driver cuts in front of you while you are following a vehicle. Depress the brake pedal to ensure an appropriate vehicle-to-vehicle distance.


SWITCHING TO CONSTANT SPEED (CRUISE) CONTROL MODE



If you are already using DRCC “

Note: When the engine is turned off, it will automatically default to DRCC.


SETTING CONSTANT SPEED (CRUISE) CONTROL



To adjust speed or cancel, see steps (2) and (3) of ADJUSTING SET SPEED on page 39.

Refer to the Toyota Owner's Manual for additional information on DRCC operation, settings adjustments, limitations, and precautions before attempting to use it.

Automatic High Beams (AHB)



AHB is a safety system designed to help drivers see more of what's ahead at nighttime and reduce glare for oncoming drivers. When enabled, AHB uses an in-vehicle camera to help detect the headlights of oncoming vehicles and tail lights of preceding vehicles, then automatically switches between high and low beams as appropriate to provide the most light possible and enhance forward visibility. By using high beams more frequently, the system may allow earlier detection of pedestrians and obstacles.

Refer to the Toyota Owner's Manual for additional information on AHB operation, settings adjustments, limitations, and precautions before attempting to use it.

ACTIVATING THE AHB SYSTEM

- (1) With the engine switch in IGNITION ON mode and headlight switch turned to "AUTO" or  position, push lever away from you.
- (2) Press the  switch.

The  indicator will come on when the headlights are turned on automatically to indicate that the system is active.

Note: Pull the lever back toward you to turn the AHB system off.

The AHB indicator will turn off. To turn switch to  position and the manual high beam indicator  turns on.

CONDITIONS WHERE AHB WILL TURN ON/OFF AUTOMATICALLY


When all of these conditions are met, high beams will be automatically turned on (after approximately 1 second):

- Vehicle speed is above approximately 21 mph (34 km/h).
- The area ahead of the vehicle is dark.
- There are no oncoming or preceding vehicles with headlights or tail lights turned on.
- There are few street lights on the road ahead.

If any of these conditions occur, the system is designed to automatically turn off high beams:

- Vehicle speed drops below approximately 17 mph (27 km/h).
- The area ahead of the vehicle is not dark.
- Oncoming or preceding vehicles have headlights or tail lights turned on.
- There are many streetlights on the road ahead.


Seat belts




NOTE: If a passenger’s seat belt is fully extended, then retracted even slightly, the Automatic locking retractor (ALR) will prevent it from being re-extended beyond that point, unless fully retracted again. This feature is used to help hold child restraint systems securely.

To find more information about seat belts, and how to install a child restraint system, refer to the Owner’s Manual.

Seat belts-Shoulder belt anchor



Seat belts-3rd row center



Seat belt reminder indicator




A buzzer sounds and an indicator will display as a reminder when a **rear second or third row passenger** is not wearing a seat belt.

SAFETY AND EMERGENCY FEATURES


Rear door child safety locks

Rear door



Moving the lever to the lock position will allow the door to be opened only from the outside.

Tire Pressure Monitoring (warning) System (TPMS)



System reset initialization

1. Push and hold the "SET" button until the indicator blinks three times.
2. Wait a few minutes to allow initialization to complete.

After adjusting tire pressures, or after tires have been rotated or replaced, turn the ignition switch to "ON" and press and hold the "SET" button until indicator blinks three times. Let the vehicle sit for a few minutes to allow initialization to complete.


Refer to the load label on the door jamb or the Owner's Manual for tire inflation specifications.

If the tire pressure indicator flashes for more than 60 seconds and then remains on, take the vehicle to your local Toyota dealer.


NOTE: The warning light may come on due to temperature changes or changes in tire pressure from natural air leakage. If the system has not been initialized recently, setting the tire pressures to factory specifications should turn off the light.

Spare tire & tools


SPARE TIRE, JACK AND TOOL LOCATION




REMOVING THE SPARE TIRE



Remove the cover under the center deck board to find the spare tire clamp bolt.



Assemble the jack handle.



Put the socket adapter on the spare tire clamp bolt. Loosen the bolt by turning it counterclockwise with the jack handle.

Refer to the Owner's Manual for tire changing and jack positioning procedures.

SAFETY AND EMERGENCY FEATURES

Star Safety System™

Your vehicle comes standard with the Star Safety System™, which combines Anti-lock Brake System (ABS), Brake Assist (BA), Electronic Brake-force Distribution (EBD), Smart Stop Technology (SST), Traction Control (TRAC) and Vehicle Stability Control (VSC).

Refer to the Owner's Manual for more details and important information on limitations to these systems.

ANTI-LOCK BRAKE SYSTEM (ABS)

Toyota's ABS sensors detect which wheels are locking up and limits wheel lockup by "pulsing" each wheel's brakes independently. Pulsing releases brake pressure repeatedly for fractions of a second. This helps the tires attain the traction that current road conditions will allow, helping you to stay in directional control.

BRAKE ASSIST (BA)

Brake Assist is designed to detect sudden or "panic" braking, and then add braking pressure to help decrease the vehicle's stopping distance. When there's only a split second to react, Brake Assist can add additional brake pressure more quickly than just the driver alone can.

ELECTRONIC BRAKE FORCE DISTRIBUTION (EBD)

Toyota's ABS technology has Electronic Brake-force Distribution (EBD) to help maintain control and balance when braking. EBD responds to sudden stops by redistributing brake force to enhance the braking effectiveness of all four wheels.

SMART STOP TECHNOLOGY (SST)

Smart Stop Technology automatically reduces engine power when the accelerator and brake pedals are pressed simultaneously under certain conditions.

SST engages when the accelerator is depressed first and the brakes are applied firmly for longer than one-half second at speeds greater than five miles per hour.

SST doesn't engage if the brake pedal is depressed before the accelerator pedal, allowing vehicles to start on a steep hill and safely accelerate without rolling backward.

ENHANCED VEHICLE STABILITY CONTROL (VSC)

Enhanced Vehicle Stability Control provides cooperative control of the ABS, TRAC, VSC and EPS.

Enhanced VSC helps to maintain directional stability when loss of traction occurs during a turn.

TRACTION CONTROL (TRAC)

VSC helps prevent loss of traction during cornering by reducing engine power, and Traction Control helps maintain traction on loose gravel and wet, icy, or uneven surfaces by applying brake force to the spinning wheel(s).



Toyota's TRAC sensors are activated when one of the drive wheels starts to slip. TRAC limits engine output and applies the brakes to the spinning wheel. This transfers power to the wheels that still have traction to help keep you on track.

Floor mat installation

There are two types of Toyota floor mats: carpeted and all-weather. Each vehicle has model-specific floor mats. Installation is easy.

To keep your floor mat properly positioned, follow these steps:

- Only use Toyota floor mats designed for your specific model.
- Use only one floor mat at a time, using the retaining hooks to keep the mat in place.
- Install floor mats right side up.



BLUETOOTH® DEVICE PAIRING SECTION


Do not attempt the Bluetooth® Pairing process while driving.

To begin the Bluetooth® Pairing process, press the HOME button on the faceplate of your Toyota Vehicle Entune™ Multimedia Head Unit.¹


Bluetooth® Pairing for Android phone and Entune™ touch screen system

Pairing your phone is the first step in connecting with your Toyota for hands-free calling and for audio streaming via Bluetooth. This pairing process is quick and easy: all Android mobile digital devices have Bluetooth integrated; all you have to do is setup the phone and multimedia system to “talk” to each other and form a connection.²


Initiate Bluetooth® on your Android®




STEP 1
From your **APPS SCREEN**, select **SETTINGS**.



STEP 2
Select **CONNECTIONS** and select **BLUETOOTH**.



STEP 3
Ensure **BLUETOOTH** is **ON**.



STEP 4
Select **YOUR PHONE DEVICE** to make it discoverable.

Phone will seek out Bluetooth devices while remaining discoverable.



STEP 5
While your Android device is seeking out Bluetooth devices, proceed to your Entune Multimedia Head Unit on your Toyota vehicle.

¹ To determine which head unit is installed in your vehicle, refer to the Audio section in this guide. Entune™ Premium Audio screens are shown in this section. Screens and features may vary by Entune™ system.

² Some Android devices may have slightly different SETTINGS screen layout depending on manufacturer of device and Android OS version.

BLUETOOTH® DEVICE PAIRING

Initiate Bluetooth® on your Entune™ Multimedia Head Unit

Once you have Bluetooth enabled on your phone and ready to pair, you will need to initiate Bluetooth on your Entune head unit. Please follow the instructions below to pair your Bluetooth enabled phone to your Entune system.



STEP 6


On your Toyota Vehicle Entune™ Multimedia Head Unit, Select **SETUP BUTTON** on the Home Screen.



STEP 7


Select **BLUETOOTH**.

Image shown is a sample image, features may vary.



STEP 8


Select **ADD**, to add your phone device.



STEP 9


Back on your smartphone, you can now select your **TOYOTA VEHICLE** in Bluetooth Settings.

You may need to enter the provided Bluetooth PIN on your phone.



STEP 10


Your smartphone is now paired with Entune.



STEP 11

Once paired, Entune will attempt to connect audio and contacts on your phone.


Initiate Bluetooth® on your Entune™ Multimedia Head Unit



STEP 12

Using your smartphone, you will need to allow Entune access to your messaging and contacts.

It is recommended to check the “Don't ask again” box, so as not to have to press OK every time the phone makes a Bluetooth connection with your Toyota.



STEP 13

A confirmation will appear once your phone has been paired and connected.

Additional Resources

If you're having trouble pairing your phone, Toyota has you covered. You can get more information from the following sources:

Online Pairing Guide:

www.toyota.com/connect

Your Toyota Owner's Manual

Located in the vehicle glovebox

Toyota Customer
Experience Center
(800) 331-4331

Disclosures

This brochure is accurate at the time of print; content subject to change based on periodic multimedia software updates.

1. Concentrating on the road should always be your first priority while driving. Do not use the hands-free phone system if it will distract you.
2. The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Toyota is under license. A compatible Bluetooth enabled phone must first be paired. Phone performance depends on software, coverage & carrier.
3. Android is a trademark of Google Inc.
4. Apps/services vary by phone/carrier; functionality depends on many factors. Select apps use large amounts of data; you are responsible for charges. Apps & services subject to change. See Toyota.com/entune for details.

Bluetooth® Pairing for iPhone and Entune™ touch screen system

****Do not attempt the Bluetooth® Pairing process while driving.****


Pairing your phone is the first step in connecting with your Toyota for hands-free calling and for audio streaming via Bluetooth. This pairing process is quick and easy: all iPhone mobile digital devices have Bluetooth integrated; all you have to do is setup the phone and multimedia system to “talk” to each other and form a connection.

Initiate Bluetooth® on your iPhone®




STEP 1

From the **HOME SCREEN**, select **SETTINGS**.




STEP 2

Select **BLUETOOTH**.



STEP 3

Ensure **BLUETOOTH** is **ON**.



STEP 4

Your iPhone will seek out Bluetooth devices while remaining discoverable.



STEP 5

While your iPhone device is seeking out Bluetooth devices, proceed to your Entune Multimedia Head Unit on your Toyota vehicle.

Initiate Bluetooth® on your Entune™ Multimedia Head Unit

Once you have Bluetooth enabled on your phone and ready to pair, you will need to initiate Bluetooth on your Entune head unit. Please follow the instructions below to pair your Bluetooth enabled phone to your Entune system.



STEP 6

On your Toyota Vehicle Entune Multimedia Head Unit, Select **SETUP BUTTON** on the Home Screen.


For Entune™ Audio System, press the **SETUP BUTTON** on the faceplate to access the Setup Screen.



STEP 7


Select **BLUETOOTH**.

Image shown is a sample image, features may vary.



STEP 8


Select **ADD**, to add your phone device.



STEP 9


Back on your smartphone, you can now select your **TOYOTA VEHICLE** in Bluetooth Settings.

You may need to enter the provided Bluetooth PIN on your phone.



STEP 10


Your smartphone is now paired with Entune.



STEP 11

Once paired, Entune will attempt to connect audio and contacts on your phone.


BLUETOOTH® DEVICE PAIRING



STEP 12

Using your smartphone, you may need to allow Entune access to your messaging and contacts.

Only current iPhone text messages can be viewed on the head unit. iPhone does not allow text message reply.



STEP 13

A confirmation will appear once your phone has been paired and connected.

Additional Resources

If you're having trouble pairing your phone, Toyota has you covered. You can get more information from the following sources:

Online Pairing Guide:
www.toyota.com/connect

Your Toyota Owner's Manual
Located in the vehicle glovebox

Toyota Customer
Experience Center
(800) 331-4331

Disclosures

This brochure is accurate at the time of print; content subject to change based on periodic multimedia software updates.


1. Concentrating on the road should always be your first priority while driving. Do not use the hands-free phone system if it will distract you.
2. The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Toyota is under license. A compatible Bluetooth enabled phone must first be paired. Phone performance depends on software, coverage & carrier.
3. Android is a trademark of Google Inc.
4. Apps/services vary by phone/carrier; functionality depends on many factors. Select apps use large amounts of data; you are responsible for charges. Apps & services subject to change. See Toyota.com/entune for details.

Bluetooth® Pairing for Windows Phone and Entune™ touch screen system

****Do not attempt the Bluetooth® Pairing process while driving.****


Pairing your phone is the first step in connecting with your Toyota for hands-free calling and for audio streaming via Bluetooth. This pairing process is quick and easy: all Windows Phone mobile digital devices have Bluetooth integrated; all you have to do is setup the phone and multimedia system to “talk” to each other and form a connection.

Initiate Bluetooth® on your Windows Phone®




STEP 1

From your APP LIST, select **SETTINGS**.



STEP 2

Select **BLUETOOTH**.



STEP 3

Ensure **BLUETOOTH** is **ON**.



STEP 4

Phone will seek out Bluetooth devices while remaining discoverable.



STEP 5

While your iPhone device is seeking out Bluetooth devices, proceed to your Entune Multimedia Head Unit on your Toyota vehicle.

BLUETOOTH® DEVICE PAIRING

Initiate Bluetooth® on your Entune™ Multimedia Head Unit

Once you have Bluetooth® enabled on your phone and ready to pair, you will need to initiate Bluetooth® on your Entune head unit. Please follow the instructions below to pair your Bluetooth enabled phone to your Entune system.



STEP 6

On your Toyota Vehicle Entune Multimedia Head Unit, Select **SETUP BUTTON** on the Home Screen.


For Entune™ Audio System, press the **SETUP BUTTON** on the faceplate to access the Setup Screen.



STEP 7

Select **BLUETOOTH**.

Image shown is a sample image, features may vary.



STEP 8


Select **ADD**, to add your phone device.



STEP 10


Back on your smartphone, you can now select your **TOYOTA VEHICLE** in Bluetooth Settings.

You may need to enter the provided Bluetooth PIN on your phone.



STEP 10


Your smartphone is now paired with Entune.



STEP 11


Once paired, Entune will attempt to connect audio and contacts on your phone.

Initiate Bluetooth® on your Entune™ Multimedia Head Unit



STEP 12

Using your smartphone, you may need to allow Entune access to your contacts.



STEP 13

A confirmation will appear that your phone has been paired and connected.

Additional Resources

If you're having trouble pairing your phone, Toyota has you covered. You can get more information from the following sources:

Online Pairing Guide:
www.toyota.com/connect

Your Toyota Owner's Manual
Located in the vehicle glovebox

Toyota Customer
Experience Center
(800) 331-4331

Disclosures

This brochure is accurate at the time of print; content subject to change based on periodic multimedia software updates.

1. Concentrating on the road should always be your first priority while driving. Do not use the hands-free phone system if it will distract you.
2. The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Toyota is under license. A compatible Bluetooth enabled phone must first be paired. Phone performance depends on software, coverage & carrier.
3. Android is a trademark of Google Inc.
4. Apps/services vary by phone/carrier; functionality depends on many factors. Select apps use large amounts of data; you are responsible for charges. Apps & services subject to change. See Toyota.com/entune for details.



www.toyota.com/owners

CUSTOMER EXPERIENCE CENTER

1-800-331-4331



Printed in U.S.A. 08/18
18-MKG-12086



00505QRG19HIG