



PRIUS PRIME

2 0 1 9



QUICK REFERENCE GUIDE

2019

PRIUS PRIME

This Quick Reference Guide is a summary of basic vehicle operations. It contains brief descriptions of fundamental operations so you can locate and use the vehicle's main equipment quickly and easily.

The Quick Reference Guide is not intended as a substitute for the Owner's Manual located in your vehicle's glove box. We strongly encourage you to review the Owner's Manual and supplementary manuals so you will have a better understanding of your vehicle's capabilities and limitations.

Your dealership and the entire staff of Toyota Motor North America, Inc. wish you many years of satisfied driving in your new Prius Prime.

A word about safe vehicle operations

This Quick Reference Guide is not a full description of Prius Prime operations. Every Prius Prime owner should review the Owner's Manual that accompanies this vehicle.

Pay special attention to the boxed information highlighted in color throughout the Owner's Manual. Each box contains safe operating instructions to help you avoid injury or equipment malfunction.

All information in this Quick Reference Guide is current at the time of printing. Toyota reserves the right to make changes at any time without notice.

INDEX

OVERVIEW

Engine maintenance	9
Fuel tank door release & cap	9
Hood release	8
Indicator symbols	4-5
Instrument cluster	4
Instrument panel	2-3
Instrument panel light control	8
Keyless entry ^{1,2}	6-7
Smart Key System ^{1,2}	7

ELECTRIC VEHICLE SYSTEM

Charging	11-13
Charging equipment	10
Charging system safety functions	17
Electric Vehicle System	10
Charging information	16
Charging schedule ²	14-15
Prime Applications	17

FEATURES & OPERATIONS

Air conditioning/heating	26-27
Audio	30-31
Auto lock/unlock ^{1,2}	18
Blind Spot Monitor with Rear	
Cross Traffic Alert (BSM w/RCTA)	35
Clock	21
Color Dual Multi-Information	
Display (MID)	28
Color Head-up Display (HUD)	29
Door locks	20
Driving mode select switch	19
EV Auto drive mode	20
EV/HV drive mode	19
Garage door opener (HomeLink®) ³	38
Hybrid Synergy Drive System	18
Hybrid transmission	19
Intelligent Clearance Sonar (ICS)	34
Intelligent Parking Assist (IPA)	36-37
Intuitive Parking Assist	33
Lights ¹ & turn signals	23
Parking brake	26
Power outlets-12V DC	32
Qi wireless charger	32

FEATURES & OPERATIONS (continued)

Rear view monitor system	38
Seat adjustments-Front	22
Seat heaters	24
Seats-Folding down rear seats	22
Seats-Head restraints	22
Steering wheel-Heater	25
Steering wheel switches & telephone controls (Bluetooth®)	25
Tilt & telescopic steering wheel	21
USB/AUX port	29
Vehicle Stability Control (VSC)/ TRAC OFF switch	34
Windows-Power	20
Windshield wipers & washers	24

TOYOTA SAFETY SENSE™ P (TSS-P)

Automatic High Beams (AHB)	49
Full-Speed Range Dynamic Radar	
Cruise Control (DRCC)	46-48
Lane Departure Alert with Steering Assist (LDA w/SA)	42-45
Pre-Collision System with Pedestrian Detection (PCS w/PD)	40-42
Quick overview-	
Toyota Safety Sense™ P (TSS-P)	39
Sensors	39

SAFETY & EMERGENCY FEATURES

Floor mat installation	55
Rear door child safety locks	51
Safety Connect	51
Seat belts	50
Seat belts-Shoulder belt anchor	50
Star Safety System™	54-55
Tire Pressure Monitoring (warning) System (TPMS)	52
Tire repair kit & tools	53

BLUETOOTH® DEVICE PAIRING SECTION


56-62

¹ Visit your Toyota dealer for information on customizing this feature.


² Programmable by customer. Refer to the Owner's Manual for instructions and more information.

³ HomeLink® is a registered trademark of Gentex Corporation.

Instrument panel




Steering wheel controls




¹ If equipped.

² For details, refer to the “Navigation System Owner’s Manual and “2019 Prius Prime Entune™ Audio Quick Reference Guide”.



Instrument cluster



○ Service indicators and reminders

Indicator symbols

For details, refer to “Instrument cluster,” Section 3, 2019 Owner’s Manual.



“AIR BAG ON/OFF” indicator¹



Air bag SRS warning¹



Anti-lock Brake System (ABS) warning¹



Automatic High Beam (AHB) indicator



Blind Spot Monitor (BSM) indicator⁴



Brake Override System/Drive-Start Control/Intelligent Clearance Sonar⁴



Brake system warning (yellow indicator) ¹



Brake system warning¹



Charging system warning¹



SET Constant speed cruise control indicator/Constant speed cruise control SET indicator



Driver and front passenger’s seat belt reminder (alarm sounds for speeds over 12 mph)



ECO mode indicator



EV auto mode indicator



EV drive mode indicator



EV indicator



Electric power steering system warning light (red/yellow indicator)¹

Fog light indicator⁴

Fuel tank door position

**SET** Full-Speed Dynamic Radar Cruise Control (DRCC) indicator/DRCC SET indicator Headlight low/high beam indicatorHeated steering wheel indicator⁴High coolant temperature warning¹**CHG MODE** Hybrid battery charge mode indicatorICS OFF indicator^{1,2,4}**P** Intelligent Parking Assist (IPA) indicator^{1,4}**P** Intuitive Parking Assist indicator⁴**LDA** Lane Departure Alert (LDA) indicator**LDA w/SA** Lane Departure Alert with Steering Assist (LDA w/SA) indicatorLow engine oil pressure warning¹

Low fuel level warning

Low Tire Pressure Warning¹**CHECK** Malfunction/Check Engine indicator¹Master warning light¹

Open door warning

**PARK** Parking brake indicator**OFF** Pre-Collision System (PCS) warning^{1,2}**PWR MODE** PWR MODE indicator**READY** "READY" indicator

Rear passengers' seat belt reminder



Security indicator

**R L P N D** Shift position indicators**SA** Slip indicator/Hill-start Assist Control indicator^{1,3}

Smart Key system




Steering control indicator

**← →** Turn signal indicator**OFF** Vehicle Stability Control (VSC) OFF indicator¹¹ If the indicator does not turn off within a few seconds of starting the Hybrid system, there may be a malfunction. Have the vehicle inspected by your Toyota dealer.² If the indicator flashes, there may be a malfunction. Refer to the Owner's Manual.³ If the indicator flashes, it indicates that the system is operating.⁴ If equipped.

OVERVIEW

Keyless entry

UNLOCKING OPERATION




Push
ONCE: Driver door
TWICE: All doors

Carry Smart
Key remote


Front door unlock*

Grasp



NOTE: If a door is not opened within 60 seconds of unlocking, all doors will relock for safety.

LOCKING OPERATION



Push

Carry Smart
Key remote

All-door lock

Touch




PANIC BUTTON



HOLD
Push and hold



BACK DOOR LOCKING/UNLOCKING




Carry Smart
Key remote

* Driver door unlocking function can be programmed to unlock driver door only, or all doors. In some models, grasping front passenger door handle will unlock all doors. *Please refer to the Owner's Manual for more details on how to program the doors.*

NOTE: Doors may also be locked/unlocked using remote.

AIR CONDITIONING REMOTE



**HOLD
A/C**

Push and hold



(1) Press twice to de-activate. System also automatically shuts off after 10 minutes or when a door is opened.

(2) The Remote Air Conditioning System will operate in accordance with the temperature settings of the air conditioning system.

NOTE: Remote Climate system can also be activated via smartphone using Entune Prime Apps (if equipped).

Smart Key system


START FUNCTION




NOTE: The Smart Key must be carried to enable the start function. With gear shift lever in Park and the brake pedal depressed, push the “POWER” switch.

POWER (WITHOUT STARTING HYBRID SYSTEM)


Without depressing the brake pedal, pressing the “POWER” switch will change the operation mode in succession from:



Hood release




Instrument panel light control



Engine maintenance

Engine coolant reservoir

Engine oil filler cap




Engine oil level dipstick

Windshield washer fluid tank

NOTE: Regularly scheduled maintenance, including oil changes, will help extend the life of your vehicle and maintain performance. Please refer to the “**Warranty & Maintenance Guide.**”

Fuel tank door release & cap




The fuel tank door locks/unlocks with the vehicle's doors.

NOTE: Tighten until one click is heard. If the cap is not locked or tightened, Check Engine “” indicator may illuminate.

Electric Vehicle System


The Prius Prime system has features of both electric and hybrid vehicles. Electricity received by charging from an external power source can be used to supplement hybrid energy, and the vehicle can also be driven as an electric vehicle using only the electric motor. The EV driving range can be extended by using regenerative braking to store electricity in the traction battery.

Charging equipment



The charge cable included with the vehicle is designed to be connected only to an AC 120V power source.

Charging connector



Refer to the Owner's Manual for more details.

NOTE: Toyota recommends installing a heavier-duty 15-amp wall receptacle with GFCI (Ground-Fault Circuit-Interrupter).


Charging

The Prius Prime may be charged immediately, or scheduled to charge at a specific time. Before charging, it is recommended that:

- Parking brake is securely set
- All lights are turned off
- The POWER switch is OFF

Refer to “Things to Know Before Charging,” in the Owner’s Manual before attempting to charge the hybrid battery.


START CHARGING



- Make sure to hold the body of the plug and insert it firmly into the outlet.
- Check that the power indicator of the CCID (Charging Circuit Interrupting Device) is illuminated.
- Check the status of the automatic system check that runs before charging to detect electrical leakage. If a malfunction is detected, an error warning indicator flashes.
- The surface of the CCID may become hot, but this does not indicate a malfunction.

Step 1 Plug the charge cable into the outlet of the external power source.

NOTE: Hanging the CCID on a hook is recommended to reduce the strain on the outlet and charge cable plug.




Step 2 Press the charge port lid to open and the charging inlet light will illuminate.

NOTE: For vehicles with smart lid & connector locking system, unlock doors first.


For more information or to change settings for the smart lid and charging connector function, refer to the Owner’s Manual.

ELECTRIC VEHICLE SYSTEM

START CHARGING (CONTINUED)




Step 3 Remove the charge connector cap. Affix the cap to the cable.



- Do not press the latch release button when inserting the connector.
- Align with the guide position shown on underside of the charge connector, and push it in until it clicks.

Step 4 Insert the charge cable connector into the charge inlet.



- Charging will not start if the charging indicator does not illuminate when the charging connector is inserted.

When charge timer function is in use, it will turn off several seconds after illuminating.


- The amount of time until charging is completed can be checked on the energy monitor by turning the POWER switch to ON mode.
- The charging indicator will turn off when charging is completed.

Step 5 Once charging connector is inserted into the inlet and indicator has illuminated, press the connector lock switch before charging.

Refer to the Owner's Manual for limitations and more details.


AFTER CHARGING

Lever raises up when unlocked to release




Step 1 Press the latch release button while pulling toward you to release charging connector.

Note: If smart lid & connector locking system is in use, carry the Smart Key to unlock. (if equipped)




Step 2 Attach cap to charging connector.



Step 3 Attach charging inlet cap and close charging port lid.

Note: For vehicles with smart lid and connector locking system, touching push lifter will activate the locking mechanism of the charging port lid or connector lock. Carry Smart Key to unlock. (if equipped)





Step 4 When the charging equipment will not be used for a prolonged period of time, remove the plug. Hold the body of the plug when removing from the outlet.

Charging schedule

Use of the charge schedule can help reduce electricity costs by making it easy to charge during off-peak hours.

ADD A CHARGING TIME TO THE CHARGE SCHEDULE

7" display




(1) While the vehicle is parked, press the charging timer switch. The Charge Schedule screen displays on the multi-information display.


Use or to navigate through the options and press to select an option. Also, use to return to a previous screen.

Refer to the Owner's Manual for more information.


11.6" display (if equipped)



(1) While the vehicle is parked, press the MENU button to display the menu screen. Then, touch  to select and view the Information screen.




(2) Touch Charge Schedule and the Charge Schedule screen displays.



(3) Create a charge schedule for days and times of the week as reminders. Refer to the Owner's Manual for more information.

Charging Information


Remaining charging time and charging information is displayed on the Multi-Information Display (MID) or 11.6" display (if equipped.)



If the POWER switch is turned to ON mode during charging, the current charging status and the amount of time needed until charging is complete will be displayed on the energy monitor.

After confirming, switch the POWER switch to OFF and turn off the display. The POWER switch will turn off automatically after several tens of seconds.

Charging information and warning messages The first time the POWER switch is turned to ON mode after charging is completed, a message detailing the results of the charge is shown. Also, if an operation was attempted that could not be carried out while charging, a warning message will be shown.



Follow the instructions in the message. The message may not be displayed if the Remote Climate System has been used.

Refer to the Owner's Manual for limitations and more details.

Charging system safety functions

- The Hybrid System will not start while the charging cable is attached to the vehicle, even if the POWER switch is operated.
- If the charge cable is connected while the READY indicator is illuminated, the Hybrid System will stop automatically and driving will not be possible.
- When the charge cable is connected to the vehicle, the shift position cannot be changed from P to another position.
- If the latch release button is pressed, charging will not begin even if the charge cable is connected.
- Charging will stop if the latch release button is pressed and held for several seconds during charging. When restarting charging, reinsert the charge connector after pulling it out, and check that the charging indicator illuminates.

Prime Applications (if equipped)

Prime Applications is a service for Prius Prime vehicles that is added to the Safety Connect® and Entune® products. It provides charge support, comfort support and drive support via the vehicle's navigation system and the owner's smartphone. The Prime Apps include Charge Management, Remote Climate, Charging Station Map, Vehicle Finder and ECO Dashboard.

Both an active Safety Connect® account and an active Entune® account are required for the services.

The following functions of the Prime Applications can be used with the navigation system:

Type A Download of nearby charging stations to the map screen.

Type B View list of nearby charging stations and corresponding charging station information (such as voltage supported).

For details, please refer to <http://www.toyota.com/entune>.

FEATURES & OPERATIONS

Auto lock/unlock

Automatic door locks can be programmed to operate in different modes, or turned OFF.

Shift position linked door locking/unlocking function

- Doors lock when shifting from Park.
- Doors unlock when shifting into Park.

Speed linked door locking function

- Doors lock when the vehicle speed is approximately 12 mph or higher.

Driver's door linked door unlocking function

- Doors unlock when the "POWER" switch is set to OFF and driver's door is opened within approximately 45 seconds.

Refer to the *Owner's Manual* for more details.

Hybrid Synergy Drive System


The Hybrid Synergy Drive System utilizes a computer-controlled gasoline engine and electric motor to provide the most efficient combination of power for the vehicle. To conserve energy, when the brakes are applied the braking force generates electricity which is then sent to the traction battery. In addition, the engine shuts off when the vehicle is stopped. The benefits are better fuel economy, reduced vehicle emissions and improved performance.

NOTE: Fuel consumption and energy information of the Hybrid System are shown on the Multi-Information Display.

TIPS FOR IMPROVED FUEL ECONOMY


- Ensure tire pressures are maintained at levels specified in the Owner's Manual.
- When possible, link trips to reduce engine cold starts.
- Avoid driving at speeds that are higher than necessary, especially on the highway.
- When possible, avoid sudden stops to maximize regenerative braking energy.
- Minimize use of the air conditioning.

STARTING YOUR VEHICLE



- (1) Put the shift lever in "P."
- (2) Depress the brake pedal, and "READY" will be displayed on the Multi-Information Display.
- (3) Press the "POWER" switch briefly and firmly.
- (4) The "READY" light will blink. After a few seconds, when the light remains steady and a beep sounds, you may begin driving.

Hybrid transmission



P	Park button
R	Reverse
N	Neutral
D	Drive
B	Engine brake*


* The engine brake is the equivalent of downshifting. Shift to “B” when engine braking is desired (i.e. downhill driving, coasting to a stop, etc.)

Driving mode select switch

Normal - Suitable for normal driving.


Power mode - Use when a higher level of response is desired, such as when driving in mountainous regions.

ECO drive mode - Helps achieve lower fuel consumption during trips that involve frequent accelerating and braking.



Refer to the Owner's Manual for more details.


EV/HV drive mode



EV Mode allows the electric motor (traction motor), powered by the hybrid battery (traction battery), to be used to drive the vehicle under certain driving conditions. EV Mode is the default Mode upon starting the vehicle if the battery has sufficient charge. You can use the EV/HV button at any time to toggle between EV Mode and hybrid mode.

Refer to the Owner's Manual for more details.


EV Auto drive mode




EV Auto Mode intelligently selects between EV and hybrid driving based on demand and driving conditions to optimize your efficiency.

Refer to the Owner's Manual for more details.


Door locks



Windows-Power



Window lock switch




All window auto up/down Push the switch completely down or pull it completely up and release to fully open or close. To stop the window partway, operate the switch in the opposite direction.


Window lock switch Deactivates all passenger windows. Driver's window remains operable.

Tilt & telescopic steering wheel

Lock release lever



Angle




Hold wheel, push lever down, set angle and length, and return lever.

NOTE: Do not attempt to adjust while the vehicle is in motion.


Clock

Multi-Information Display



To adjust the time, use meter control switches to go to the  screen on the MID for vehicles with the 7" display. Then, select the    option to access the clock setting.

11.6" display (if equipped)




To adjust the time, press  to select . Then select  to access General Settings screen. From here, select "System Time" to access clock setting.


FEATURES & OPERATIONS

Seat adjustments-Front

MANUAL SEAT




POWER SEAT (IF EQUIPPED)*




*Driver's side only

Seats-Head restraints


Front



Rear outboard




Seats-Folding down rear seats





Lights & turn signals

HEADLIGHTS

Type A



Type B



Daytime Running Light system (DRL) Automatically turns on under certain conditions to make vehicle more visible to other drivers. Not for use at night.


Automatic light cutoff system Automatically turns lights off after a delay of 30 seconds, or lock switch on remote is pushed after all doors are locked.

Automatic High Beam (AHB) system Automatically switches between high and low beams as appropriate for enhanced vision at night.

Refer to Toyota Safety Sense™ P (TSS-P) in this guide or the Owner's Manual for more details on the Automatic High Beam feature.


** Operating conditions must be met. Refer to the Owner's Manual for details.

FRONT FOG LIGHTS (IF EQUIPPED)



Front fog lights come on only when the headlights are on low beam.

TURN SIGNALS




FEATURES & OPERATIONS


Windshield wipers & washers

FRONT-INTERMITTENT (IF EQUIPPED)

Type A




Type B




¹ **Intermittent windshield wiper frequency adjustment** Rotate to increase/decrease wipe frequency.

FRONT-AUTO (RAIN-SENSING) (IF EQUIPPED)

Type A




Type B



² **Rain-sensing windshield wipers** Rotate to increase/decrease sensor sensitivity. Refer to the Owner's Manual for more details on customizing AUTO mode operation.


Seat heaters



NOTE: Turn system off when not in use.

The "POWER" switch must be in ACCESSORY or IGNITION ON position to be used.


Steering wheel-Heater (if equipped)



The “POWER” switch must be in ACCESSORY or IGNITION ON position to be used. The heater will be turned off after about 30 minutes.


Steering wheel switches & telephone controls (Bluetooth®)

STEERING WHEEL AUDIO AND TELEPHONE CONTROLS




MICROPHONE

Type A (7" display)



Type B (7" display/11.6" display)



Bluetooth® technology allows dialing or receipt of calls without removing your hands from the steering wheel or using a cable to connect the compatible telephone and the system.


* Push and hold to access Mobile Assistant. When a compatible smartphone is Bluetooth® connected push and hold the off hook switch 2-3 seconds to access Siri® Eyes Free.

Refer to “Bluetooth® Device Pairing Section” in this guide, for more information about phone connections and compatibility.

Refer to the “Navigation System Owner’s manual” for more details.

NOTE: Concentrating on the road should always be your first priority while driving. Do not use the hands-free phone system if it will distract you.

Parking brake




Air conditioning/heating

AUTOMATIC AIR CONDITIONING - 7" DISPLAY

Automatic climate control ON

Adjusting the temperature setting will cause the airflow vents, air intake and fan to adjust automatically.

Smart-flow (S-Flow) mode gives airflow priority to the front seats, reducing the airflow and air conditioning effect on rear seats when there are no passengers.



Controls

Air conditioning temperature control


Windshield defogger

Rear window and outside rear view mirrors defogger




Touch area to display air conditioning control screen (See below)

Air conditioning control screen




FEATURES & OPERATIONS

Color Dual Multi-Information Display (MID)




MAIN DISPLAY

Simple screen




Split screen



The default split screen mode can also be viewed in simple screen mode shown above. The main display shows basic drive information. Push “” to view more info for mileage and average fuel consumption display.

For more details, see the Owner's Manual.

MULTI-INFORMATION DISPLAY (MID)




-  Drive information
-  Navigation system-linked display
-  Audio system-linked display
-  Air conditioning system settings screen
-  Driving assist system information
-  Warning message display
-  Settings display

Push “” to change between the following information screens, “” to select, “” to switch contents and “” to go back:


For more details, see the Owner's Manual.

Color Head-up display (HUD) (if equipped)



The color head-up display can display the current vehicle speed and hybrid system indicator in front of the driver. Also, it can display various types of information to assist the driver.

USB media/AUX port



USB media port

By connecting a USB-compatible portable audio device or USB memory stick into the USB media port, you can listen to music through the vehicle's speaker system.

AUX port


By inserting an AUX cable into the AUX port, you can listen to music from a portable audio device through the vehicle's speaker system while in AUX mode.

FEATURES & OPERATIONS

Audio

ENTUNE™ PREMIUM AUDIO WITH INTEGRATED NAVIGATION

7" Display




HOME SCREEN - the home screen offers a two panel and a three panel layout. Information and layout will vary depending on selected set up.

Refer to the "Navigation System Owner's Manual" and "2019 Prius Prime Entune™ Audio Quick Reference Guide".

NOTE: Concentrating on the road should always be your first priority while driving. Do not use the Entune system if it will distract you.

11.6" Display (if equipped)




Refer to the "Navigation System Owner's Manual" and "2019 Prius Prime Entune™ Audio Quick Reference Guide".

NOTE: Concentrating on the road should always be your first priority while driving. Do not use the Entune system if it will distract you.


FEATURES & OPERATIONS

Power outlets-12V DC

Front




Rear




The “POWER” switch must be set at “ACCESSORY” or “ON” mode to be used.

Qi wireless charger (if equipped)




(1)



When the engine is turned off, the last state (ON/OFF) of the charger is memorized.



(2)



A mobile device can be charged wirelessly on the tray. **(1)** Press the wireless charger power switch and the green operation indicator light turns on. **(2)** Place a mobile device on the tray as shown in the illustration. An amber indicator illuminates while charging is in progress. When charging is complete, the indicator illuminates green. Some phones, cases or cover type wireless chargers may not cause the green indicator to illuminate even though it is fully charged.

Refer to the Owner's Manual for more details on this system before attempting to use it.

Intuitive Parking Assist (if equipped)



If the sensors detect an obstacle, the buzzer and MID display informs the driver of the approximate position and distance of the obstacle by illuminating continuously (far) or blinking (near).

Note: Use  in the Multi-Information Display (MID) to change settings. The system will continue in the last state it was in (ON or OFF) when the engine is started again.


Refer to the Owner's Manual for limitations and more details.

FEATURES & OPERATIONS

Intelligent Clearance Sonar (ICS) (if equipped)


When parking, this available system scans for stationary objects, like walls or lampposts. Should the system anticipate a collision, it will emit an audible and visible alert, reduce engine or motor output, and automatically apply the brakes if needed. If your vehicle is equipped with ICS, the RCTA system will also have a braking function that may apply the vehicle's brakes if the system detects crossing vehicles while the Prius Prime is backing up.

CHANGE SETTINGS



Refer to the Owner's Manual for limitations and more details on this system.

Vehicle Stability Control (VSC)/ TRAC OFF switch




The VSC OFF switch can be used to help free a stuck vehicle in surroundings like mud, dirt or snow. While the vehicle is stopped, press switch to disable the TRAC system.

To disable both VSC and TRAC systems, press and hold the switch for at least 3 seconds.

Refer to the Owner's Manual for limitations and more details.

Blind Spot Monitor with Rear Cross Traffic Alert (BSM w/RCTA) (if equipped)



The Blind Spot Monitor is a system that has two functions:

- The Blind Spot Monitor function (assists the driver in making the decision when to change lanes)
- The Rear Cross Traffic Alert function (assists the driver when backing up)

The system is designed to use radar sensors to detect vehicles traveling in the Prius Prime's blind spot. If a vehicle is detected, the driver will be alerted via the outside rear view side mirror indicators.

Note: Use  in the Multi-Information Display (MID) to change settings. The system will continue in the last state it was in (ON or OFF) when the engine is started again.

Refer to the Owner's Manual for limitations and more details on this system before attempting to use it.

FEATURES & OPERATIONS


Intelligent Parking Assist (IPA)* (if equipped)

The Intelligent Parking Assist (IPA) system automatically operates the steering wheel to provide support when backing into an area near a target parking spot, and when departing from a parallel parking spot. (Changing the shift position and speed adjustment when moving forward or backing up are not performed automatically.)


While the IPA is operating, if the system detects an obstacle that could result in a collision, the emergency brakes operate, regardless of whether the Intelligent Clearance Sonar function is on or off.

* Refer to section S-APGS (Simple Advanced Parking Guidance System) in the Owner's Manual for limitations and more details.

TURNING IPA ASSIST MODE ON



IPA GUIDANCE SCREEN



CANCELING OF STOPPING ASSIST MODE

Assist mode will be canceled or stopped in the following cases.

Assist control is canceled when

- The system temperature preservation function operates
- There is a system malfunction
- System determined that the parking environment is not suitable for assist to continue

When assist control is canceled, firmly grasp the steering wheel, depress the brake pedal and stop the vehicle.

Start again from the beginning, as the system will already be canceled. When continuing to park manually, operate the steering wheel as you normally would.

Assist control is stopped when

- The steering wheel is operated
- The vehicle speed exceeds 4 mph (7 km/h) during assist control
- The Parking Support Brake function operates


When assist control is stopped, it can be resumed by following the guidance shown on the screen.

The Intelligent Parking Assist (IPA) system requires driver brake control. Always look around outside the vehicle and use mirrors to confirm clearance.

** Refer to section S-APGS (Simple Advanced Parking Guidance System) in the Owner's Manual for limitations and more details.*

FEATURES & OPERATIONS

Rear view monitor system



The rear view monitor system displays an image of the view from the bumper of the rear area of the vehicle. The camera for the rear view monitor system is located above the license plate.


To adjust the image on the rear view monitor screen

For 7" display, press the "APPS" button, select "Setup" and "Display". Select "Camera" to adjust the screen contrast and brightness.

For 11.6" display, press the "MENU" button and select "Display" on the "Setup" screen. Select "Camera" to adjust the screen contrast and brightness.

Refer to the Navigation System Owner's Manual for limitations and more details on this system.

Garage door opener (HomeLink®) (if equipped)



Garage door openers manufactured under license from HomeLink®* can be programmed to operate garage doors, estate gates, security lighting, etc.

Refer to the Owner's Manual for more details.

For programming assistance, contact HomeLink® at 1-800-355-3515, or visit <http://www.homelink.com>.

* HomeLink® is a registered trademark of Johnson Controls, Inc.



Quick overview-Toyota Safety Sense™ P (TSS-P)

Toyota Safety Sense™ P (TSS-P) is a set of active safety technologies designed to help mitigate or prevent collisions across a wide range of traffic situations, in certain conditions. TSS-P is designed to help support the driver's awareness, decision making and vehicle operation contributing to a safe driving experience.

Refer to the Owner's Manual for operation, setting adjustments, limitations and more details to understand these functions and complete safety precautions. For more information, please go to <http://www.toyota.com/safety-sense>



Pre-Collision System with Pedestrian Detection (PCS w/PD)

PCS w/PD is designed to provide alert, mitigation, and/or avoidance support in certain conditions, when the system detects a potential collision with a preceding vehicle is likely to occur.

The advanced millimeter-wave radar sensor system is designed to work with the camera sensor to help recognize a preceding pedestrian, and provide an alert, mitigation and/or avoidance support in certain conditions.



Lane Departure Alert with Steering Assist (LDA w/SA)

LDA w/SA is designed to provide notification when the system detects an unintended lane departure.

The Steering Assist function is designed to provide small corrective steering inputs to the steering wheel for a short period of time to help keep the vehicle in its lane.



Full-Speed Range Dynamic Radar Cruise Control (DRCC)

DRCC is designed to help maintain a pre-set distance to a preceding vehicle when the preceding vehicle is traveling at a lower speed.




Automatic High Beams (AHB)


AHB is designed to detect the headlights of oncoming vehicles and the tail lights of preceding vehicles and switch between high beams and low beams as appropriate.

Sensors

TSS-P combines an in-vehicle camera mounted in front of the inside rear view mirror and a millimeter-wave radar mounted in the front grill. These sensors support the driver assist systems.



Pre-Collision System with Pedestrian Detection (PCS w/PD)



The Pre-Collision System uses a radar sensor and camera sensor to help detect a vehicle or pedestrian in front of your vehicle.

As there is a limit to the degree of recognition accuracy and control performance that this system can provide, do not overly rely on this system. This system will not prevent collisions or lessen collision damage or injury in every situation. Do not use PCS instead of normal braking operations under any circumstances. Do not attempt to test the operation of the pre-collision system yourself, as the system may not operate or engage, possibly leading to an accident. In some situations, such as when driving in inclement weather such as heavy rain, fog, snow or a sandstorm or while driving on a curve and for a few seconds after driving on a curve, a vehicle or pedestrian may not be detected by the radar and camera sensors, preventing the system from operating or engaging properly.

Refer to the Toyota Owner's Manual for a list of additional situations in which the system may not operate properly.

Pre-Collision Warning

When the system determines that the possibility of a frontal collision is high, a buzzer will sound and a warning message will be displayed on the Multi-Information Display (MID) to urge the driver to take evasive action.

Pre-Collision Brake Assist

If the driver notices the hazard and brakes, the system may provide additional braking force using Brake Assist. This system may prime the brakes and may apply greater braking force in relation to how strongly the brake pedal is depressed.


Pre-Collision Braking

If the driver does not brake in a set time and the system determines that the possibility of a frontal collision with a preceding vehicle is extremely high, the system may automatically apply the brakes, reducing speed in order to help the driver reduce the impact and in certain cases avoid the collision.

Refer to the Toyota Owner's Manual for additional information on PCS w/PD operation, settings adjustments, limitations, and precautions before attempting to use it.

PCS PEDESTRIAN DETECTION


Under certain conditions, the PCS system included with the TSS-P package may also help to detect a pedestrian in front of your vehicle using the in-vehicle camera and front-grill mounted millimeter wave radar. The in-vehicle camera of PCS detects a potential pedestrian based on size, profile, and motion of the detected pedestrian. However, a pedestrian may not be detected depending on the conditions, including the surrounding brightness and the motion, posture, size, and angle of the potential detected pedestrian, preventing the system from operating or engaging.



As part of the Pre-Collision System, this function is also designed to first provide an alert and then automatic braking if needed.

Refer to the Toyota Owner's Manual for additional limitations and information.

CHANGING PCS ALERT TIMING




- (1) Press “<>” switches and select  from the Multi-Information Display (MID).
- (2) Press “<” switches and select  from the MID and then press “”. The setting screen is displayed.
- (3) Press “” each time to change the setting. Each time it is pressed, the response to the PCS alert timing changes as shown above. You can press “” to go back to the menu.

Note: PCS is enabled each time the engine switch is turned to Ignition On. The system can be disabled/enabled and the alert timing of the system can be changed. (Alert timing only, brake operation remains the same.)



- (1) Press “<>” switches and select  from the Multi-Information Display (MID).
- (2) Press “⬆” switches and select the  setting function from the MID and then press “○”. The setting screen is displayed.
- (3) Press “○” each time to change the setting. You can press “➡” to go back to the menu.

Lane Departure Alert with Steering Assist (LDA w/SA)




LDA in TSS-P uses an in-vehicle camera designed to detect visible white and yellow lane markers in front of the vehicle and the vehicle's position on the road. If the system determines that the vehicle is starting to unintentionally deviate from its lane, the system alerts the driver with an audio and visual alert. When the alerts occur, the driver must check the surrounding road situation and carefully operate the steering wheel to move the vehicle back to the center part of their lane.

LDA is designed to function at speeds of approximately 32 MPH or higher on relatively straight roadways.

In addition to the alert function, LDA w/SA also features a steering assist function. When enabled, if the system determines that the vehicle is on a path to unintentionally depart from its lane, the system may provide small corrective steering inputs to the steering wheel for a short period of time to help keep the vehicle in its lane.

TURNING THE LDA SYSTEM ON/OFF




Press the LDA switch to turn the LDA system on. Depress again to turn it off.

Note: Operation of the LDA system and setting adjustments continues in the same condition regardless of Ignition cycle until changed by the driver or the system is reset.

Refer to the Toyota Owner's Manual for additional information on LDA operation, settings adjustments, limitations, and precautions before attempting to use it.

LANE DEPARTURE ALERT

LDA function display



Lane Departure Alert (LDA) indicator flashes orange when operating.



(1)



(2)

LANE DEPARTURE ALERT (CONTINUED)

The LDA function  displays when the Multi-Information Display (MID) is switched to the driving assist system information screen.

(1) The system displays solid white lines on the LDA indicator when visible lane markers on the road are detected. A side flashes orange to alert the driver when the vehicle deviates from its lane.

(2) The system displays outlines on the LDA indicator when lane markers on the road are not detected or the function is temporarily cancelled.

Note: When operation conditions are no longer met, a function may be temporarily canceled. However, when the operation conditions are met again, operation of the function is automatically restored. For example, LDA may not function on the side(s) where white/yellow lines are not detectable.

Refer to the Toyota Owner's Manual for additional information on LDA operation, settings adjustments, limitations, and precautions before attempting to use it.

DISABLING STEERING ASSIST

- (1) Press “<>” switches and select  from the Multi-Information Display (MID).
- (2) Press “<” switches and select the  setting function and then press “○”.
- (3) Press “○” each time to change the setting.
- (4) Press “>” to go back to the menu.

Note: Operation of the LDA system and setting adjustments continues in the same condition regardless of Ignition cycle until changed by the driver or the system is reset.

CHANGING LDA ALERT SENSITIVITY

The driver can adjust the sensitivity of the LDA (warning) function from the Multi-Information Display (MID) customization screen.

High - Is designed to warn approximately before the front tire crosses the lane marker.


Normal - Is designed to warn approximately when the front tire crosses the lane marker.

- (1) Press “<>” switches and select  from the Multi-Information Display (MID).
- (2) Press “<” switches and select the  setting function and then press “○”.
- (3) Press “○” each time to change the setting.
- (4) Press “>” to go back to the menu.

SWAY WARNING SYSTEM



Continuous lane deviations from swaying.



Gentle swaying from driver's inattentiveness.



Acute steering wheel operation after the number of operations decrease due to driver's inattentiveness.

SWS is a function of LDA and is designed to detect swaying based on the vehicle location in the lane and the driver's steering wheel operation. To help prevent swaying, the system alerts the driver using a buzzer sound and a warning displays in the MID.

DISABLING LDA SWAY WARNING SYSTEM

- (1) Press “<>” switches and select  from the Multi-Information Display (MID).
- (2) Press “<” switches and select the  setting function and then press “○”.
- (3) Press “○” each time to change the setting.
- (4) Press “>” to go back to the menu.


Note: Operation of the LDA system and setting adjustments continues in the same condition regardless of Ignition cycle until changed by the driver or the system is reset.

ADJUSTING SWAY ALERT SENSITIVITY

- (1) Press “<>” switches and select  from the Multi-Information Display (MID).
- (2) Press “<” switches and select the  setting function and then press “○”.
- (3) Press “○” each time to change the setting.
- (4) Press “>” to go back to the menu.


Full-Speed Range Dynamic Radar Cruise Control (DRCC)

DRCC helps maintain a pre-set distance to a preceding vehicle when the preceding vehicle is traveling at a lower speed. This mode is always selected first when the cruise control button is depressed. Constant speed control mode is also available. Full-Speed Range DRCC is designed to function at speeds between 0 to approximately 110 MPH and is intended for highway use.



TURNING SYSTEM ON/OFF

(1)




Push once: On
Push again: Off


Refer to page 48 for switching to Constant Speed (Cruise) Control Mode.

ADJUSTING SET SPEED

(2)



(3)




Vehicle will cruise at a set speed, decelerate to maintain selected distance from a slower vehicle traveling in front and accelerate back up to the selected speed if the vehicle in front changes lanes or speeds up.

- (1) Push the ON-OFF button. The “RADAR READY” or “” indicator will come on.
- (2) Push the lever down to SET speed, push it up to Resume and pull it or depress brake to Cancel.
- (3) Push up to increase the set speed, push down to decrease (1 mph [1.6 km/h] or 1 km/h [0.6 mph] increments).


¹ The set speed may also be cancelled by depressing the brake pedal.

² The set speed may be resumed once vehicle speed exceeds 25 mph.



This mode employs a radar sensor to detect the presence of a preceding vehicle up to approximately 328 ft (100 m) ahead, determines the current vehicle-to-vehicle following distance and operates to maintain a preset following distance from the vehicle ahead. These distances vary based on vehicle speed.

Note: Vehicle-to-vehicle distance will close in when traveling on long downhill slopes.



(1) Constant speed cruising when there are no vehicles ahead

The vehicle travels at the speed set by the driver. The desired vehicle-to-vehicle distance can also be set by operating the vehicle-to-vehicle distance control.

(2) Deceleration cruising and follow-up cruising when a preceding vehicle driving slower than the set speed appears

When a vehicle is detected running ahead of you, the system automatically decelerates your vehicle. When a greater reduction in vehicle speed is necessary, the system applies the brakes (the brake lights will come on at this time). The system will respond to changes in the speed of the vehicle ahead in order to maintain the vehicle-to-vehicle distance set by the driver. A warning tone warns you when the system cannot decelerate sufficiently to prevent your vehicle from closing in on the vehicle ahead.


DRCC ADJUSTING DISTANCE (CONTINUED)

(3) Acceleration when there are no longer any preceding vehicles driving slower than the set speed

The system accelerates until the set speed is reached. The system then returns to constant speed cruising.

Note: When your vehicle is too close to a vehicle ahead, and sufficient automatic deceleration via the cruise control is not possible, the display will flash and the buzzer will sound to alert the driver. An example of this would be if another driver cuts in front of you while you are following a vehicle. Depress the brake pedal to ensure an appropriate vehicle-to-vehicle distance.

SWITCHING TO CONSTANT SPEED (CRUISE) CONTROL MODE




1.5 seconds

If you are already using DRCC “”, push ON-OFF button to turn the system off first, then push and hold ON-OFF button for at least 1.5 seconds to switch.

Note: When the engine is turned off, it will automatically default to DRCC.

Refer to the Toyota Owner's Manual for additional information on DRCC operation, settings adjustments, limitations, and precautions before attempting to use it.

SETTING CONSTANT SPEED (CRUISE) CONTROL




Set

To adjust speed or cancel, see steps (2) and (3) of ADJUSTING SET SPEED on page 46.

Refer to the Toyota Owner's Manual for additional information on DRCC operation, settings adjustments, limitations, and precautions before attempting to use it.

Automatic High Beams (AHB)



AHB is a safety system designed to help drivers see more of what's ahead at nighttime and reduce glare for oncoming drivers. When enabled, AHB uses an in-vehicle camera to help detect the headlights of oncoming vehicles and tail lights of preceding vehicles, then automatically switches between high and low beams as appropriate to provide the most light possible and enhance forward visibility. By using high beams more frequently, the system may allow earlier detection of pedestrians and obstacles.

Refer to the Toyota Owner's Manual for additional information on AHB operation, settings adjustments, limitations, and precautions before attempting to use it.

ACTIVATING THE AHB SYSTEM

Note: The AHB function only operates at night.

- (1) With the engine switch in IGNITION ON mode and headlight switch turned to "AUTO" or "☰☷" position, push lever away from you.
- (2) Depress the Automatic High Beam "☰☷ AUTO" switch.

The AHB indicator will come on when the headlights are turned on automatically to indicate that the system is active.

Note: Pull the lever back toward you to turn the AHB system off. The AHB indicator will turn off and the high beam indicator "☰☷" turns on.

CONDITIONS WHERE AHB WILL TURN ON/OFF AUTOMATICALLY


When all of these conditions are met, high beams will be automatically turned on (after approximately 1 second):

- Vehicle speed is above approximately 21 mph (34 km/h.)
- The area ahead of the vehicle is dark.
- There are no oncoming or preceding vehicles with headlights or tail lights turned on.
- There are few street lights on the road ahead.

If any of these conditions occur, the system is designed to automatically turn off high beams:

- Vehicle speed drops below approximately 17 mph (27 km/h.)
- The area ahead of the vehicle is not dark.
- Oncoming or preceding vehicles have headlights or tail lights turned on.
- There are many streetlights on the road ahead.

Seat belts




NOTE: If a passenger's seat belt is fully extended, then retracted even slightly, the Automatic Locking Retractor (ALR) will prevent it from being re-extended beyond that point, unless fully retracted again. This feature is used to help hold child restraint systems securely.

To find more information about seat belts, and how to install a child restraint system, refer to the Owner's Manual.


Seat belts - Shoulder belt anchor

Push up, or squeeze lock release to lower




Rear door child safety locks

Rear door



Moving the lever downward will allow the door to be opened only from the outside.

Safety Connect (if equipped)



Safety Connect is a subscription-based telematics service that uses Global Positioning System (GPS) data and embedded cellular technology to provide safety and security features to subscribers. Safety Connect is supported by Toyota's designated response center, which operates 24 hours per day, 7 days per week.


Services for subscribers include:

- Automatic collision notification
- Stolen vehicle location
- Emergency assistance ("SOS" button)
- Enhanced roadside assistance

Contact your dealer for more information about Safety Connect.

For details, refer to the "Owner's Manual" or visit www.Toyota.com/safety-connect.

Tire Pressure Monitoring (warning) System (TPMS)



The tire pressure warning system can be selected on  of the multi-information display (MID).

System rest initialization

- (1) Select  and then push and hold “”.
- (2) Select “Maintenance System” and then push “”.
- (3) Select “TPMS” then push and hold “” until the message is displayed on the multi-information display (MID) and the tire pressure warning light illuminates.

The tire pressure detected by the tire pressure warning system can be displayed on the multi-information display (MID).

Refer to the load label on the door jamb or the Owner's Manual for tire inflation specifications.


If the tire pressure indicator flashes for more than 60 seconds and then remains on, take the vehicle to your local Toyota dealer.

NOTE: The warning light may come on due to temperature changes or changes in tire pressure from natural air leakage. If the system has not been initialized recently, setting the tire pressures to factory specifications should turn off the light.


Tire repair kit & tools

TOOL LOCATION


Jack and tools



Emergency tire repair kit



Tire repair kit components



Refer to the Owner's Manual for tire changing and jack positioning procedures.

SAFETY & EMERGENCY FEATURES

Star Safety System™

Your vehicle comes standard with the Star Safety System™, which combines Anti-lock Braking System (ABS), Brake Assist (BA), Electronic Brake-force Distribution (EBD), Smart Stop Technology (SST), Traction Control (TRAC) and Vehicle Stability Control (VSC).

Refer to the Owner's Manual for more details and important information on limitations to these systems.

ANTI-LOCK BRAKE SYSTEM (ABS)

Toyota's ABS sensors detect which wheels are locking up and limits wheel lockup by "pulsing" each wheel's brakes independently. Pulsing releases brake pressure repeatedly for fractions of a second. This helps the tires attain the traction that current road conditions will allow, helping you to stay in directional control.

BRAKE ASSIST (BA)

Brake Assist is designed to detect sudden or "panic" braking, and then add braking pressure to help decrease the vehicle's stopping distance. When there's only a split second to react, Brake Assist can add additional brake pressure more quickly than just the driver alone can.

ELECTRONIC BRAKE FORCE DISTRIBUTION (EBD)

Toyota's ABS technology has Electronic Brake-force Distribution (EBD) to help maintain control and balance when braking. EBD responds to sudden stops by redistributing brake force to enhance the braking effectiveness of all four wheels.

SMART STOP TECHNOLOGY (SST)

Smart Stop Technology automatically reduces engine power when the accelerator and brake pedals are pressed simultaneously under certain conditions.

SST engages when the accelerator is depressed first and the brakes are applied firmly for longer than one-half second at speeds greater than five miles per hour.

SST doesn't engage if the brake pedal is depressed before the accelerator pedal, allowing vehicles to start on a steep hill and safely accelerate without rolling backward.

ENHANCED VEHICLE STABILITY CONTROL (VSC)

Enhanced Vehicle Stability Control provides cooperative control of the ABS, TRAC, VSC and EPS.

Enhanced VSC helps to maintain directional stability when loss of traction occurs during a turn.

TRACTION CONTROL (TRAC)

VSC helps prevent loss of traction during cornering by reducing engine power, and Traction Control helps maintain traction on loose gravel and wet, icy, or uneven surfaces by applying brake force to the spinning wheel(s).


Toyota's TRAC sensors are activated when one of the drive wheels starts to slip. TRAC limits engine output and applies the brakes to the spinning wheel. This transfers power to the wheels that still have traction to help keep you on track.

Floor mat installation

There are two types of Toyota floor mats: carpeted and all-weather. Each vehicle has model-specific floor mats. Installation is easy.

To keep your floor mat properly positioned, follow these steps:

- Only use Toyota floor mats designed for your specific model.
- Use only one floor mat at a time, using the retaining hooks to keep the mat in place.
- Install floor mats right side up.



BLUETOOTH® DEVICE PAIRING SECTION


Do not attempt the Bluetooth® Pairing process while driving.

To begin the Bluetooth® Pairing process, press the HOME button on the faceplate of your Toyota Vehicle Entune™ Multimedia Head Unit.¹


Bluetooth® Pairing for Android phone and Entune™ touch screen system

Pairing your phone is the first step in connecting with your Toyota for hands-free calling and for audio streaming via Bluetooth. This pairing process is quick and easy: all Android mobile digital devices have Bluetooth integrated; all you have to do is setup the phone and multimedia system to “talk” to each other and form a connection.²


Initiate Bluetooth® on your Android®




STEP 1
From your **APPS SCREEN**, select **SETTINGS**.



STEP 2
Select **CONNECTIONS** and select **BLUETOOTH**.



STEP 3
Ensure **BLUETOOTH** is **ON**.



STEP 4
Select **YOUR PHONE DEVICE** to make it discoverable.

Phone will seek out Bluetooth devices while remaining discoverable.



STEP 5
While your Android device is seeking out Bluetooth devices, proceed to your Entune Multimedia Head Unit on your Toyota vehicle.

¹ To determine which head unit is installed in your vehicle, refer to the Audio section in this guide. Entune™ Premium Audio screens are shown in this section. Screens and features may vary by Entune™ system.

² Some Android devices may have slightly different SETTINGS screen layout depending on manufacturer of device and Android OS version.

BLUETOOTH® DEVICE PAIRING

Initiate Bluetooth® on your Entune™ Multimedia Head Unit

Once you have Bluetooth enabled on your phone and ready to pair, you will need to initiate Bluetooth on your Entune head unit. Please follow the instructions below to pair your Bluetooth enabled phone to your Entune system.



STEP 6


On your Toyota Vehicle Entune™ Multimedia Head Unit, Select **SETUP BUTTON** on the Home Screen.



STEP 7


Select **BLUETOOTH**.

Image shown is a sample image, features may vary.



STEP 8


Select **ADD**, to add your phone device.



STEP 9


Back on your smartphone, you can now select your **TOYOTA VEHICLE** in Bluetooth Settings.

You may need to enter the provided Bluetooth PIN on your phone.



STEP 10


Your smartphone is now paired with Entune.



STEP 11

Once paired, Entune will attempt to connect audio and contacts on your phone.


Initiate Bluetooth® on your Entune™ Multimedia Head Unit



STEP 12

Using your smartphone, you will need to allow Entune access to your messaging and contacts.

It is recommended to check the “Don't ask again” box, so as not to have to press OK every time the phone makes a Bluetooth connection with your Toyota.



STEP 13

A confirmation will appear once your phone has been paired and connected.

Additional Resources

If you're having trouble pairing your phone, Toyota has you covered. You can get more information from the following sources:

Online Pairing Guide:

www.toyota.com/connect

Your Toyota Owner's Manual

Located in the vehicle glovebox

Toyota Customer
Experience Center
(800) 331-4331

Disclosures

This brochure is accurate at the time of print; content subject to change based on periodic multimedia software updates.

1. Concentrating on the road should always be your first priority while driving. Do not use the hands-free phone system if it will distract you.
2. The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Toyota is under license. A compatible Bluetooth enabled phone must first be paired. Phone performance depends on software, coverage & carrier.
3. Android is a trademark of Google Inc.
4. Apps/services vary by phone/carrier; functionality depends on many factors. Select apps use large amounts of data; you are responsible for charges. Apps & services subject to change. See Toyota.com/entune for details.

Bluetooth® Pairing for iPhone and Entune™ touch screen system

****Do not attempt the Bluetooth® Pairing process while driving.****


Pairing your phone is the first step in connecting with your Toyota for hands-free calling and for audio streaming via Bluetooth. This pairing process is quick and easy: all iPhone mobile digital devices have Bluetooth integrated; all you have to do is setup the phone and multimedia system to “talk” to each other and form a connection.

Initiate Bluetooth® on your iPhone®




STEP 1

From the **HOME SCREEN**, select **SETTINGS**.




STEP 2

Select **BLUETOOTH**.



STEP 3

Ensure **BLUETOOTH** is **ON**.



STEP 4

Your iPhone will seek out Bluetooth devices while remaining discoverable.



STEP 5

While your iPhone device is seeking out Bluetooth devices, proceed to your Entune Multimedia Head Unit on your Toyota vehicle.

Initiate Bluetooth® on your Entune™ Multimedia Head Unit

Once you have Bluetooth enabled on your phone and ready to pair, you will need to initiate Bluetooth on your Entune head unit. Please follow the instructions below to pair your Bluetooth enabled phone to your Entune system.



STEP 6

On your Toyota Vehicle Entune Multimedia Head Unit, Select **SETUP BUTTON** on the Home Screen.


For Entune™ Audio System, press the **SETUP BUTTON** on the faceplate to access the Setup Screen.



STEP 7

Select **BLUETOOTH**.

Image shown is a sample image, features may vary.



STEP 8


Select **ADD**, to add your phone device.



STEP 9


Back on your smartphone, you can now select your **TOYOTA VEHICLE** in Bluetooth Settings.

You may need to enter the provided Bluetooth PIN on your phone.



STEP 10


Your smartphone is now paired with Entune.



STEP 11

Once paired, Entune will attempt to connect audio and contacts on your phone.


BLUETOOTH® DEVICE PAIRING



STEP 12

Using your smartphone, you may need to allow Entune access to your messaging and contacts.

Only current iPhone text messages can be viewed on the head unit. iPhone does not allow text message reply.



STEP 13

A confirmation will appear once your phone has been paired and connected.

Additional Resources

If you're having trouble pairing your phone, Toyota has you covered. You can get more information from the following sources:

Online Pairing Guide:
www.toyota.com/connect

Your Toyota Owner's Manual
Located in the vehicle glovebox

Toyota Customer
Experience Center
(800) 331-4331

Disclosures

This brochure is accurate at the time of print; content subject to change based on periodic multimedia software updates.

1. Concentrating on the road should always be your first priority while driving. Do not use the hands-free phone system if it will distract you.
2. The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Toyota is under license. A compatible Bluetooth enabled phone must first be paired. Phone performance depends on software, coverage & carrier.
3. Android is a trademark of Google Inc.
4. Apps/services vary by phone/carrier; functionality depends on many factors. Select apps use large amounts of data; you are responsible for charges. Apps & services subject to change. See Toyota.com/entune for details.

NOTES

NOTES



www.toyota.com/owners

CUSTOMER EXPERIENCE CENTER

1-800-331-4331



Printed in U.S.A. 11/18
18-MKG-12452



00505QRG19PRIPM