

PE2100S

Getting Started Guide for AWS IoT Greengrass

Table of Contents

1	<i>Document information</i>	1
2	<i>Overview</i>	1
3	<i>Hardware description</i>	2
4	<i>Set up your development environment</i>	2
5	<i>Set up device hardware</i>	2
6	<i>About AWS IoT Greengrass</i>	3
7	<i>Greengrass prerequisites</i>	3
8	<i>Install AWS IoT Greengrass</i>	3
9	<i>Create a “Hello World” component</i>	4
10	<i>Debugging</i>	4
11	<i>Troubleshooting</i>	4

1 Document information

1.1 Document revision history

Date	Version	Description
2025/1/20	V01	First release

1.2 Applicable operating systems for this guide

This guide is applied to the PE2100S system with an Intel processor and a Windows operating system to run AWS Greengrass.

2 Overview

ASUS IoT PE2100S is a rugged, fanless edge computer featuring rich I/O capabilities, various connectivity options, and a fanless thermal design suitable for diverse IoT applications. The PE2100S is powered by Intel Atom x7000RE-series processors, offering power-efficient that support fanless designs. It is designed for durability to meet harsh environmental conditions, with support for extended temperatures from -20°C to 60°C.

PE2100S features up to six COM ports, six USB ports, two LAN ports and dual independent video outputs , and is primed for expansion with options for PoE LAN and COM ports modules. This rugged edge computer is designed for power-efficient and silent operation in challenging environments, achieving full CPU utilization while being cooled via an efficient, fanless thermal solution.

PE2100S also benefits from a form-fitting design inherited from previous products in the series, minimizing upgrade stress.

3 Hardware description

3.1 Datasheet

<https://www.asus.com/Websites/global/products/1l2qktqusoed2t35/pdf/cpzesvuw55mkkj6h.pdf>

3.2 Standard kit contents

Default packing list include:

- PE2100S system
- SATA cable
- Power terminal block
- wall mount kit

3.3 User provided items

Additional accessories available for order:

- Mounting options: DIN rail.
- Power Adapter + Power Cord

3.4 3rd party purchasable items

None.

4 Set up your development environment

4.1 Tools installation (IDEs, Toolchains, SDKs)

As an industrial PC, the development environment for this device should be determined by the user based on its intended use.

5 Set up device hardware

Please refer to link below for all the manuals of PE2100S, including PE2100S [user manual](#).

If you have problem access the link above, go to [ASUS PE2100S product page](#), click the “Support” then “Manual & Documents” button for all the product manuals download.

6 About AWS IoT Greengrass

To learn more about AWS IoT Greengrass, see [How AWS IoT Greengrass works](#) and [What's new in AWS IoT Greengrass Version 2](#).

7 Greengrass prerequisites

If you do not have an existing AWS account and user, refer to the online AWS documentation at Set up your AWS Account (<https://docs.aws.amazon.com/iot/latest/developerguide/settingup.html>).

To get started, follow the steps outlined in the sections below:

- Sign up for an AWS account
(<https://docs.aws.amazon.com/iot/latest/developerguide/setting-up.html#aws-registration>)
- Create an administrative user
(<https://docs.aws.amazon.com/iot/latest/developerguide/setting-up.html#create-an-admin>)
- Open the AWS IoT console
(<https://docs.aws.amazon.com/iot/latest/developerguide/setting-up.html#iot-consolelogin>)

Refer to the online documentation detailing the [prerequisites](#) needed for AWS IoT Greengrass. Follow the instructions in the following sections:

[Step 1: Set up an AWS account](#)

[Step 2: Set up your environment](#)

Pay special attention to the Notes.

8 Install AWS IoT Greengrass

Follow the online guide to [Install with automatic provisioning](#). Refer to the instructions in the following steps:

- [Set up the device environment](#)
- [Provide AWS credentials to the device](#). For development environments, you can use the option “Use long-term credentials from an IAM User”. An example of how to do this is shown below:

```
export AWS_ACCESS_KEY_ID=<the access key id for your user>  
export AWS_SECRET_ACCESS_KEY=<the secret access key for your user>
```

Note: Production environment should use temporary credentials.

- [Download the AWS IoT Greengrass Core software](#)
- [Install the AWS IoT Greengrass Core software](#)

9 Create a “Hello World” component

9.1 Create the component on your edge device

Follow the instructions online under the section [Develop and test a component on your device](#) to create a simple component on your device.

9.2 Upload the “Hello World” component

Follow the instructions online at [Create your component in the AWS IoT Greengrass service](#) to upload your component to the cloud, where it can be deployed to other devices as needed.

9.3 Deploy your component

Follow the instructions online at [Deploy your component](#) to deploy and verify that your component is running.

10 Debugging

If you meet a problem with the PE2100S system, please contact our local FAE team with your questions, ASUS FAE team would help you clarify and solve the issue.

11 Troubleshooting

For more information, refer to the online documentation [Troubleshooting Greengrass v2](#).