

FeatherWeight™

USER'S GUIDE
3106 SERIES



3 Safety Instructions

4 Product View

4-5 Operation

5-6 Maintenance and Care

6 Troubleshooting

7 Consumer Services

7 Replacement Parts

8 Warranty




Thank you for buying a BISSELL FeatherWeight™ Vacuum

We're glad you purchased a BISSELL FeatherWeight vacuum. Everything we know about floor care went into the design and construction of this home cleaning system. By purchasing this product you are helping BISSELL with our commitment to reducing our impact on the environment through an expanding range of sustainable design efforts.

Your FeatherWeight vacuum is well made, and we back it with a limited one year warranty. We also stand behind it with a knowledgeable, dedicated Consumer Services department, so, should you ever have a problem, you'll receive fast, considerate assistance.

My great-grandfather invented the floor sweeper in 1876. Today, BISSELL is a global leader in the design, manufacture, and service of high quality homecare products like your carpet cleaner.

Thanks again, from all of us at BISSELL.



Mark J. Bissell

President and Chief Executive Officer

IMPORTANT SAFETY INSTRUCTIONS

When using an electrical appliance, basic precautions should be observed, including the following:

READ ALL INSTRUCTIONS BEFORE USING YOUR VACUUM.

Always connect to a polarized outlet (left slot is wider than right). Unplug from outlet when not in use and before conducting maintenance.

WARNING: To reduce the risk of fire, electric shock, or injury:

- Do not modify the polarized plug to fit a non-polarized outlet or extension cord.
- Do not leave vacuum cleaner unattended when it is plugged in.
- Unplug from outlet when not in use and before servicing.
- Do not use outdoors or on wet surfaces.
- Do not allow children to operate vacuum cleaner or use as a toy.
- Close attention is necessary when used by or near children.
- Do not use for any purpose other than described in this User's Guide.
- Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug.
- If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, have it repaired at an authorized service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle vacuum cleaner or plug with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep openings free of dust, lint, hair, and anything that may reduce air flow.

- Keep hair, loose clothing, fingers, and all parts of body away from openings.
- Turn off all controls before plugging or unplugging vacuum cleaner.
- Use extra care when cleaning stairs.
- Do not pick up flammable materials (lighter fluid, gasoline, kerosene, etc.) or use in the presence of explosive liquids or vapors.
- Do not pick up toxic material (chlorine bleach, ammonia, drain cleaner, etc.).
- Do not use vacuum cleaner in an enclosed space filled with vapors given off by oil base paint, paint thinner, some moth proofing substances, flammable dust, or other explosive or toxic vapors.
- Do not pick up hard or sharp objects such as glass, nails, screws, coins, etc.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use without filters in place.
- Use only on dry, indoor surfaces.
- Keep appliance on a level surface.
- Do not carry the vacuum cleaner while it is running.

WARNING: The power cord on this product contains lead, a chemical known to the State of California to cause birth defects or other reproductive harm.

Wash hands after handling.

SAVE THESE INSTRUCTIONS FOR FUTURE USE

THIS APPLIANCE HAS A POLARIZED PLUG.

To reduce the risk of electric shock, this appliance has a polarized plug (one blade is wider than the other). This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install a proper outlet. Do not change the plug in any way.

Product view



Operation

How to use your vacuum


Your FeatherWeight vacuum may be used in one of three ways. See instructions below for converting your vacuum to best meet each need.

1. As a Floor Vacuum:

- A. Open the latch at the base of the hand vacuum grip and insert handle. Once handle is all the way inserted into the body of the vacuum, press the latch closed to secure the handle in place.
- B. Attach the floor nozzle by inserting it into the opening at the bottom of the dirt container. Press firmly to secure in place.

2. As a Hand Vacuum:

Release the latch from the handle and pull handle away from the unit. Press the latch closed.



Operation

How to use your vacuum continued

3. As a Multi-Purpose Vacuum:

The crevice tool and floor nozzle may be used with either the hand vacuum or the floor vacuum. To use for cleaning in tight spaces, insert the crevice tool into the opening at the bottom of the dirt container. Press firmly to secure in place. To clean a wider surface, remove the crevice tool and attach the floor nozzle by inserting it into the opening at the bottom of the dirt container. Press firmly to secure in place.



Power cord storage

1. Turn Vacuum off.
2. Unplug power cord by grasping the polarized plug, **NOT** the cord, and disconnect from outlet.
3. Loop power cord around cord wraps on the handle.
4. Clip molded plug to power cord to secure.




Maintenance and care

To maintain maximum performance from your **BISSELL FeatherWeight** vacuum, perform these simple maintenance checks:

Emptying the dirt container

1. To remove dirt from the dirt container and filter, hold the vacuum vertically as shown. Depress and hold latch on top of the vacuum to release the dirt container.
2. Gently pull dirt container away from the hand vacuum grip and empty into waste container.
3. The dirt container may be rinsed with warm water and a mild detergent if needed. The dirt container must be thoroughly dried before replacing.
4. Attach dirt container to vacuum by depressing Latch and securely fitting onto hand grip. Make sure dirt container is correctly secured.



Maintenance and care

Cleaning the filter

The key to maximum performance is a clean filter. Cleaning the filter after each use will help your FeatherWeight vacuum operate at peak efficiency.

Use only BISSELL replacement filters (#32019) in your BISSELL Featherweight.

1. Follow the steps on page 5 to remove dirt container.
2. Remove filter from the filter frame and shake over a waste container.
3. To replace the filter back onto the filter frame, line up the curved tabs of the filter frame with the curved notches on the filter, and push together to secure. Filter should be fully pressed against the unit to prevent dust from escaping.
4. Attach dirt container to vacuum by depressing latch and securely fitting onto hand vacuum grip. Make sure dirt container is correctly secured.
5. After heavy usage, you may clean the filter by washing it gently by hand in warm water and mild dish detergent. Rinse thoroughly and make certain it is completely dry before replacing it. If filter is torn, replace it with a new filter.



CAUTION:

Never operate your FeatherWeight vacuum without the filter in place. Doing so may damage the motor and void the warranty.



WARNING:

To reduce the risk of injury from moving parts and/or electrical shock, turn Power Switch OFF and disconnect polarized plug from electrical outlet before performing troubleshooting checks.

Troubleshooting

Vacuum cleaner won't run

Possible causes

1. Power Cord not firmly plugged in.
2. Blown household fuse or breaker.

Remedies

1. Check electrical outlet.
2. Check/replace fuse; reset breaker.

Vacuum cleaner won't vacuum effectively

Possible causes

1. Filter clogged, wet or dirty.
2. Dirt Container clogged.

Remedies

1. Follow instructions for cleaning Filter.
2. Follow instructions for emptying Dirt Container.

Dust blows out of the air vent

Possible causes

1. Filter not properly secured to filter frame.

Remedies

1. Follow instructions for Replacing Filter above.

Other maintenance or service not included in the manual should be performed by an authorized service representative.

Thank you for selecting a BISSELL product.

Please do not return this product to the store.

For any questions or concerns, BISSELL is happy to be of service. Contact us directly at 1-800-237-7691.



BISSELL Consumer Services

For information about repairs or replacement parts, or questions about your warranty, call:

BISSELL Consumer Services
1-800-237-7691

Monday - Friday 8 a.m. — 10 p.m. EST

Saturday 9 a.m. — 8 p.m. EST

Or write:

BISSELL HOMECARE, INC

PO Box 3606

Grand Rapids MI 49501

ATTN: Consumer Services

Or visit the BISSELL website - **www.bissell.com**

When contacting BISSELL, have model number of cleaner available.

Please record your Model Number: _____

Please record your Purchase Date: _____

NOTE: Please keep your original sales receipt. It provides proof of date of purchase in the event of a warranty claim. See Warranty on page 8 for details.

Please register your new BISSELL product at
www.bissell.com/productregistration

Replacement parts and accessories

You may purchase parts from your retailer, by calling BISSELL Consumer Services or by visiting our website.

Item	Part No.	Part Name
1	32019	Filter
2	203-2206	Crevice Tool
3	203-2207	Floor Nozzle
4	203-2208	Dirt Container
5	203-2209	Handle

1



2



3



4



5



Warranty - BISSELL FeatherWeight™ Vacuum

This warranty gives you specific legal rights, and you may also have other rights which may vary from state to state. If you need additional instruction regarding this warranty or have questions regarding what it may cover, please contact BISSELL Consumer Services by E-mail, telephone, or regular mail as described below.

Limited One Year Warranty

Subject to the ***EXCEPTIONS AND EXCLUSIONS** identified below, upon receipt of the product BISSELL Homecare, Inc. will repair or replace (with new or remanufactured components or products), at BISSELL's option, free of charge from the date of purchase by the original purchaser, for one year on any defective or malfunctioning part.

See information below on "If your BISSELL product should require service".

This warranty applies to product used for personal, and not commercial or rental service. This warranty does not apply to fans or routine maintenance components such as filters, or brushes. Damage or malfunction caused by negligence, abuse, neglect, unauthorized repair, or any other use not in accordance with the User's Guide is not covered.

If your BISSELL product should require service:

Contact BISSELL Consumer Services to locate a BISSELL Authorized Service Center in your area.

If you need information about repairs or replacement parts, or if you have questions about your warranty, contact BISSELL Consumer Services.

Website or E-mail:

www.bissell.com

Use the "Customer Service" tab.

Or Call:

BISSELL Consumer Services

1-800-237-7691

Monday - Friday 8 a.m. - 10 p.m. ET

Saturday 9 a.m. - 8 p.m. ET

Or write:

BISSELL Homecare, Inc.

PO Box 3606

Grand Rapids MI 49501

ATTN: Consumer Services

BISSELL HOMECARE, INC. IS NOT LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY NATURE ASSOCIATED WITH THE USE OF THIS PRODUCT. BISSELL'S LIABILITY WILL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

***EXCEPTIONS AND EXCLUSIONS FROM THE TERMS OF THE LIMITED WARRANTY
THIS WARRANTY IS EXCLUSIVE AND IN LIEU OF ANY OTHER WARRANTIES
EITHER ORAL OR WRITTEN. ANY IMPLIED WARRANTIES WHICH MAY ARISE BY
OPERATION OF LAW, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY
AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE ONE YEAR
DURATION FROM THE DATE OF PURCHASE AS DESCRIBED ABOVE.**

Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.



©2009 BISSELL Homecare, Inc.
Grand Rapids, Michigan
All rights reserved. Printed in China
Part Number 110-4119
Rev 4/09
Visit our website at:
www.bissell.com

