




Parts Manual

Mfg. No: 181D02-0004-01

Model Components	Page
Air Cleaner Group.	4
Blower Housing Group.	6
Controls Group.	8
Crankcase Cover/Sump Group.	10
Crankshaft Group.	12
Cylinder Group.	14
Cylinder Head Group.	16
Exhaust Group.	18
Flywheel, Ignition, and Starter Group.	20
Fuel Supply Group.	22


Not For
Reproduction



Air Cleaner Group

REF NO	PART NO	QTY	DESCRIPTION
163	84005535	1	GASKET, Air Cleaner
176	84005559	1	SEAL, O-Ring -(Air Cleaner Base)
290	84005537	2	SCREW -(Intake Elbow)
431	84005539	1	ELBOW, Intake
445	84005548	1	FILTER, A/C Cartridge
535	84005543	1	FILTER, Air Cleaner Foam
570	84005545	1	SUPPORT, Foam Element
875	84005541	1	BASE, Air Cleaner
967	84005558	1	FILTER, Pre Cleaner
968	84005557	1	COVER, Air Cleaner
1440	84005460	3	SCREW -(Air Cleaner Base to Intake Elbow)

304



1036


1319

1319A

1319B


1397A

1397




Blower Housing Group

REF NO	PART NO	QTY	DESCRIPTION
153	84005546	5	KIT, Collar/Screw
304	84005549	1	HOUSING, Blower
305	84005283	5	SCREW -(Blower Housing)
1036	-----		LABEL, Emissions -(Available from a Briggs & Stratton Authorized Dealer)
1319	794467		LABEL, Warning -(REQUIRED When Replacing Parts With Warning Labels Affixed)
1319A	797669	1	LABEL, Warning -(REQUIRED When Replacing Parts With Warning Labels Affixed)
1319B	278911GS		LABEL, Warning -(REQUIRED When Replacing Parts With Warning Labels Affixed)
1397	84005342	5	WASHER -(Blower Housing)
1397A	84005398	5	WASHER -(Blower Housing)







Controls Group

REF NO	PART NO	QTY	DESCRIPTION
188	84005407	1	SCREW -(Control Bracket)
208	84005542	1	ROD, Governor Control
209	84005534	1	SPRING, Governor
211	84005536	1	SPRING, Governed Idle
221	84005532	2	CUP, Governor
222	84005540	1	BRACKET, Control
227	84005538	1	LEVER, Governor Control
271	84005530	1	LEVER, Control
278	84005531	2	WASHER -(Governor Control Lever)
419	84005533	1	SPRING, Return
562	84005544	1	BOLT -(Governor Control Lever)




Crankcase Cover/Sump Group

REF NO	PART NO	QTY	DESCRIPTION
12	84005402	1	GASKET, Crankcase
18	84005467	1	COVER, Crankcase
19	84005399	1	KIT, Bushing/Seal -(PTO Side)
20	84005401	1	SEAL, Oil -(PTO Side)
22	84005406	15	SCREW -(Crankcase Cover/Sump)
219	84005405	1	GEAR, Governor
523	84005391	1	DIPSTICK
596	84005407	3	SCREW -(Oil Pump)
718	84005403	2	PIN, Locating
943	84005410	1	SEAL, O-Ring -(Oil Pump Cover)
965	84005408	1	COVER, Oil Pump
1024	84005409	1	PUMP, Oil
1027	84005461	1	FILTER, Oil
1055	84005404	1	TUBE, Oil Pump
1280	84005465	1	SEAL, O-Ring -(Oil Filter Cover)
1459	84005459	1	SCREW, Set
1472	84005392	1	SEAL, O-Ring -(Dipstick/Fill Plug)
1534	84005460	1	SCREW -(Oil Filter Housing)
1548	84005323	1	BEARING, Ball -(Crankcase Cover/Sump)
1548A	84005400	1	BEARING, Ball -(Crankcase Cover/Sump)
1549	-----	1	BEARING, Ball -(Part information located in Crankshaft Group.)




Crankshaft Group

REF NO	PART NO	QTY	DESCRIPTION
16	84005487	1	CRANKSHAFT
24	84005489	1	KEY, Flywheel
25	84005473	1	PISTON ASSEMBLY -(.020" Oversize)
25	84005471	1	PISTON ASSEMBLY -(Standard)
26	84005477	1	SET, Ring -(.020" Oversize)
26	84005475	1	SET, Ring -(Standard)
27	84005479	2	LOCK, Piston Pin
28	84005481	1	PIN, Piston
29	84005482	1	ROD, Connecting
46	84005470	1	CAMSHAFT
146	84005502	1	KEY, Timing
758	84005469	1	COUNTERWEIGHT
1549	84005973	1	BEARING, Ball -(Crankshaft)




Cylinder Group

REF NO	PART NO	QTY	DESCRIPTION
1	84005463	1	CYLINDER ASSEMBLY
3	84005331	1	SEAL, Oil -(Magneto Side)
3A	84005326	1	SEAL, Oil -(Magneto Side)
7	-----	1	GASKET, Cylinder Head -(Part information located in Cylinder Head Group.)
14	-----	2	STUD -(Part information located in Cylinder Head Group.)
14A	-----	2	STUD -(Part information located in Cylinder Head Group.)
14B	84005344	2	STUD -(Cylinder Head)
14C	84005345	1	STUD -(Cylinder Head)
15	84005394	1	PLUG, Oil Drain
17	84005323	1	BEARING, Ball -(Cylinder)
153	84005341	1	KIT, Collar/Screw
447	84005343	1	SCREW -(Air Guide Cover)
523	84005391	1	DIPSTICK
738	84005342	1	WASHER -(Air Guide Cover)
738A	84005340	1	WASHER -(Air Guide Cover)
773	84005347	1	RETAINER
865	84005339	1	COVER, Air Guide
904	84005325	2	BEARING, Needle
904A	84005324	1	BEARING, Needle
1080	84005338	1	GASKET, Seal Retainer
1139	84005396	2	WASHER -(Fuel Pump Bracket)
1139A	84005397	2	WASHER -(Fuel Pump Bracket)
1145	84005395	1	SEAL, O-Ring -(Oil Drain Plug)
1343	84005350	3	NUT
1472	84005392	1	SEAL, O-Ring -(Dipstick/Fill Plug)
1536	84005346	1	SCREW -(Retainer)



Cylinder Head Group


REF NO	PART NO	QTY	DESCRIPTION
5	84005462	1	HEAD, Cylinder
6	84005335	4	WASHER -(Cylinder Head)
7	84005334	1	GASKET, Cylinder Head
14	84005332	2	STUD -(Cylinder Head)
14A	84005333	2	STUD -(Cylinder Head)
21	84005527	1	CAP, Oil Fill
33	84005285	1	VALVE, Exhaust
34	84005303	1	VALVE, Intake
35	84005308	1	SPRING, Valve -(Intake)
36	84005308	1	SPRING, Valve -(Exhaust)
42	84005304	4	KEEPER, Valve
45	84005281	2	TAPPET, Valve
51	84005284	1	GASKET, Intake
54	84005283	2	SCREW -(Intake Manifold)
151	JUMPTO151	2	STUD -(Part information located in Exhaust Group.)
192	84005320	2	ADJUSTER, Rocker Arm
238	84005307	2	CAP, Valve
553	84005305	2	RETAINER, Valve Spring
580	84005529	1	SEAL, O-Ring -(Oil Fill Cap)
868	84005306	2	SEAL, Valve
883	-----	1	GASKET, Exhaust -(Part information located in Exhaust Group.)
914	84005520	2	SCREW -(Rocker Cover)
1014	84005319	1	SCREW -(Rocker Arm Support)
1022	84005525	1	GASKET, Rocker Cover
1023	84005522	1	COVER, Rocker
1026	84005282	2	ROD, Push
1029	84005309	1	ARM, Rocker
1029A	84005310	1	ARM, Rocker
1030	84005312	1	SUPPORT, Rocker Arm
1358	84005302	2	SEAT, Valve Spring
1480	84005322	1	INJECTOR, Fuel
1577	84005336	2	NUT -(Cylinder Head)
1577A	84005337	2	NUT -(Cylinder Head)
1578	84005349	1	PLATE, Clamp -(Fuel Injector)
1579	84005350	2	NUT -(Clamp Plate)
1580	84005348	2	STUD -(Clamp Plate)
1581	84005321	1	ADJUSTER, Height -(Fuel Injector)



Exhaust Group




REF NO	PART NO	QTY	DESCRIPTION
151	84005311	2	STUD -(Exhaust Manifold)
300	84005528	1	MUFFLER
613	84005524	2	SCREW -(Muffler)
676	84005490	1	DEFLECTOR, Muffler
883	84005526	1	GASKET, Exhaust
1378	84005523	2	SET, Washer/Nut

Not For Reproduction



Flywheel, Ignition, and Starter Group

REF NO	PART NO	QTY	DESCRIPTION
23	84006360	1	FLYWHEEL
58	84005554	1	ROPE, Starter
60	84005555	1	GRIP, Starter Rope
65	84005552	4	SCREW -(Rewind Starter)
317	84006252	1	COVER, Starter
332	84005491	1	NUT -(Flywheel)
455	84005556	1	CUP, Flywheel
608	84005550	1	STARTER, Rewind
668	84005492	1	SPACER
732	84006253	2	SCREW -(Starter Drive Cover)
1044	84005407	3	SCREW -(Flywheel)



Fuel Supply Group

REF NO	PART NO	QTY	DESCRIPTION
182	84005512	1	BRACKET, Fuel Tank
182A	84005508	1	BRACKET, Fuel Tank
187	84005514	1	LINE, Fuel
187A	84005509	1	LINE, Fuel
190	84005516	1	SCREW -(Fuel Tank)
191	84005518	1	GASKET, Fuel Tank
240	84005503	1	FILTER, Fuel
450	84005511	1	WASHER -(Fuel Tank Bracket)
611	84005485	1	PIPE, Fuel
674	84005507	2	SCREW -(Fuel Tank Bracket)
674A	84005319	1	SCREW -(Fuel Tank Bracket)
705	84005350	2	NUT -(Fuel Tank)
861	84005483	1	KIT, Fuel Pump
957	84005504	1	CAP, Fuel Tank
958	84005521	1	VALVE, Fuel Shut Off
972	84005506	1	TANK, Fuel
1200	84005510	1	STUD -(Fuel Tank Bracket)
1345	84005505	1	FILTER, Filler Neck
1566	84005513	4	ADAPTER, Mounting
1587	84006148	1	SET, Shim -(Fuel Pump)

