

Supplied with Camera



Battery Pack
NB-4L(*1)



Cover for
Battery Pack



Battery Charger
CB-2LV / CB-2LVE(*1)




SD Memory Card
SDC-16M



Canon Digital Camera
Solution Disk

AV Cable
AVC-DC300(*1)



All Weather Case
AW-DC50



High-Power Flash
HF-DC1

Interface Cable IFC-400PCU(*1)

Direct Interface Cable(*2)


PCMCIA Adapter

USB Card Reader

SD Memory Card (*4)
SDC-128M
SDC-512MSH



Compact Photo Printer (*3)
(SELPHY CP series)




Direct Print Compatible
Bubble Jet Printer
(PIXMA series/SELPHY DS series)

PC Card Slot

USB Port

Windows/Macintosh

Audio / Video
IN Terminal




TV / Video


AC Adapter Kit ACK-DC10



DC Coupler
DR-10



Power Cord



Compact Power Adapter
CA-DC10

- (*1) Also available for purchase separately.
- (*2) See the user guide supplied with the Bubble Jet printer for more information on the printer and interface cables.
- (*3) This camera can also be connected to the Card Photo Printer CP-10/CP-100/CP-200/CP-300.
- (*4) Not sold in some regions.

Confirming the Package Contents

Your camera package includes all of the following items. If any of these items are missing, please contact the dealer for assistance.

- Digital Camera
- Wrist Strap WS-600
- Battery Charger CB-2LV/CB-2LVE
- Battery Pack NB-4L
- Cover for Battery Pack
- SD Memory Card SDC-16M
- Interface Cable IFC-400PCU
- AV Cable AVC-DC300
- Canon Digital Camera Solution Disk
- Basic Camera User Guide
- Advanced Camera User Guide
- Direct Print User Guide
- Software Starter Guide
- System Map (this sheet)
- Warranty Card
- "For Windows® XP and Mac OS X Users" Leaflet*
- "Canon Customer Support" Leaflet*
- "Use of Genuine Canon Accessories Recommended" Leaflet*

* These leaflets are printed together on one sheet of paper. Please separate them before reading.

Optional Accessories

The following camera accessories are sold separately.

Some accessories are not sold in some regions.

Flash

- **High-Power Flash HF-DC1**
This attachable supplementary flash can be used to capture photographic subjects that are too distant for the built-in flash to illuminate.

Power Supplies

- **AC Adapter Kit ACK-DC10**
The kit includes the following accessories.
 - **Compact Power Adapter CA-DC10**
An adapter for supplying power to operate the camera.
 - **DC Coupler DR-10**
Coupler used with the power adapter.
 - **Power Cord**
- **Battery Charger CB-2LV/CB-2LVE**
An adapter for charging Battery Pack NB-4L.
- **Battery Pack NB-4L**
Rechargeable lithium-ion battery.

Connection Accessory

This connection accessory can be used with computers equipped with genuine built-in USB interfaces and running the following operating systems.

Windows: Systems running preinstalled Windows 98 Second Edition (SE), Windows Me, Windows 2000 Service Pack 4, or Windows XP (including Service Pack 1 and Service Pack 2).
Macintosh: Mac OS X (v10.2 – v10.3)

- **Interface Cable IFC-400PCU**
Use this cable to connect the camera to a computer, Compact Photo Printer (SELPHY series), or to a Bubble Jet printer (refer to your Bubble Jet printer user guide).

Direct Print Compatible Printers

Canon offers the following separately sold printers for use with the camera. You can produce photo quality prints quickly and easily by connecting them to the camera with a single cable and operating the camera's controls.

- **Compact Photo Printers (SELPHY series)**
- **Bubble Jet Printers**

For more information, visit your nearest Canon retailer.