

OPERATOR'S MANUAL

Utility Vehicle MX 550/750

Table of Contents

<i>Safe Operation Practices</i>	<i>2</i>	<i>Product Care</i>	<i>12</i>
<i>Introduction</i>	<i>5</i>	<i>Specifications.....</i>	<i>21</i>
<i>Set-Up.....</i>	<i>6</i>	<i>Warranty</i>	<i>23</i>
<i>Controls & Operation.....</i>	<i>7</i>		

WARNING

**READ AND FOLLOW ALL SAFETY RULES AND INSTRUCTIONS IN THIS MANUAL
BEFORE ATTEMPTING TO OPERATE THIS VEHICLE.
FAILURE TO COMPLY WITH THESE INSTRUCTIONS MAY RESULT IN PERSONAL INJURY.**

NOTE: This Operator's Manual covers several models. Features may vary by model. Not all features in this manual are applicable to all models and the model depicted may differ from yours.



FAILURE TO FOLLOW THE WARNINGS CONTAINED IN THIS MANUAL CAN RESULT IN SERIOUS INJURY OR DEATH.

Particularly important information is distinguished in this manual by the following notations:

▲ This symbol points out important safety instructions which, if not followed, could endanger the personal safety and/or property of yourself and others. Read and follow all instructions in this manual before attempting to operate this vehicle. Failure to comply with these instructions may result in personal injury. When you see this symbol. **HEED ITS WARNING!**

▲ **DANGER:** Indicates death or serious injury will result if proper precautions are not taken.

▲ **WARNING:** Indicates death, serious injury, or property damage can result if proper precautions are not taken.

▲ **CAUTION:** Indicates some injury or property damage may result if proper precautions are not taken.

Note: Provides key information to make procedures easier or clearer.

▲ WARNING

California Proposition 65

Engine Exhaust, some of its constituents, and certain vehicle components contain or emit chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

Battery posts, terminals, and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm. Wash hands after handling.

▲ DANGER

This vehicle was built to be operated according to the safe operation practices in this manual. As with any type of off-highway utility vehicle, carelessness or error on the part of the operator can result in serious injury. Failure to observe the following safety instructions could result in serious injury or death.

Operation

General Operation

- | | | |
|--|--|--|
| <ol style="list-style-type: none"> 1. Read, understand, and follow all instructions on the vehicle and in the manual before attempting to operate or service vehicle. Keep this manual in a safe place for future and regular reference and for ordering replacement parts. 2. This is an off-highway utility vehicle and it should not be operated on public highways. Know and comply with all laws and regulations governing the use of off-highway vehicles in your area. 3. This vehicle handles and maneuvers differently than a normal passenger car. Sharp high speed turns and abrupt maneuvers can cause vehicle to roll over or go out of control. Slow down when turning and avoid abrupt maneuvers. 4. Handling and maneuvering characteristics of vehicle change depending upon cargo load. Heavy loads affect steering, braking, stability, and overall handling of vehicle. 5. Be familiar with all instructions and controls and their proper operation before starting vehicle. 6. Never allow adults to operate this vehicle without proper instruction. 7. Never allow children under 16 years old to operate this vehicle. Children 16 years old and over should read and understand the operation instructions and safety rules in this manual and should be trained and supervised by a parent unless driver has obtained a state-issued motor vehicle driver's licence. 8. Watch for traffic when operating near or crossing roadways. This vehicle is not intended for use on any public roadway. 9. Do not operate this vehicle while under the influence of alcohol or drugs. 10. Never carry more than one passenger. This vehicle is designed to carry the driver and one passenger only. No riders are allowed in cargo box or anywhere else on vehicle, except in the driver and passenger seats. 11. Keep all body parts (i.e. head, arms, hands, legs, feet) inside vehicle when vehicle is in motion. | <ol style="list-style-type: none"> 12. Always remain seated and keep both hands on the steering wheel when driving the vehicle. 13. Sit on the center of the seat and keep both feet within the foot platform perimeter. Clean foot platform if dirty and remove any debris from around foot controls, e.g. brake pedal. 14. Do not misuse the vehicle. Reckless operation can lead to accidents, severe bodily injury or death. 15. Inspect area around vehicle before moving, especially in reverse. Back up slowly. Always look down and behind before and while backing to avoid a back-over accident. Keep bystanders out of area. 16. Avoid driving through water, since loss of control may occur. Drive belt may slip if exposed to water thus reducing vehicle pulling power and stopping vehicle entirely. Water depth should not exceed 15" (38 cm). 17. Always use vehicle lights while operating in low light situations. 18. Do not mount or leave vehicle while it is in motion or in actual operation. 19. Avoid sudden starts, stops, or turns and always use a level turn-around area. 20. Never leave vehicle unattended with the engine running. Move the shift lever to "PARK" position, turn ignition key to the "OFF" position and remove the key. 21. Check overhead clearances carefully before driving under low hanging tree branches, wires, power lines, bridges, before entering or leaving buildings, or in any other situation where the operator and/or occupant protection structure (OPS) may be struck, which could result in serious injury. 22. Always use the occupant protection structure (OPS) and seat belt for safe operation. Overturning the utility vehicle without an OPS, or with an OPS and the seat belt unfastened, can result in death or injury. 23. Always use the seat belt and never remove the occupant protection structure (OPS) or operate the vehicle without the OPS. | <ol style="list-style-type: none"> 24. The doors are designed to assist in keeping the operator and passenger inside the vehicle during operation. Do NOT operate vehicle without doors in place. 25. Improper use of the vehicle or failure to properly maintain it could result in decreased vehicle performance or personal injury. 26. Engine must be stopped when cleaning, servicing, adjusting, repairing, or installing attachments on utility vehicle. 27. After striking foreign objects, stop the vehicle and shut off the engine. Inspect for damage and repair the damage before restarting and operating. 28. Do not start or operate vehicle in an inside area, unless it is adequately ventilated. Engine exhaust contains carbon monoxide fumes, which are very poisonous and can be deadly. 29. Assure safety interlock switch is adjusted correctly so engine cannot be started unless gearshift is in the "PARK" position with the brake pedal depressed. 30. Do not touch engine or exhaust components while engine is running or soon after it is stopped. They will be hot and can cause a burn. 31. Always inspect your vehicle each time you use it to make sure it is in safe operating condition. Always follow the inspection and maintenance procedures and schedules described in this manual. 32. Do not use the differential lock when driving down hill. Do not use the differential lock at speeds over 25 mph. Allow for greater turning radius and more difficult steering when the differential lock is engaged. 33. If situations occur which are not covered in this manual, use care and good judgement. Contact your local service center or call toll free 1-877-282-8684 for the name of your nearest service center. |
|--|--|--|

Occupant Size and Capacity

1. Make sure operators are at least 16 years old and have a valid driver's license.
2. Each occupant should be able to sit with their back against the seat, feet flat on the floor, and hands on the steering wheel or handholds.

3. The operator should be tall enough to wear the seat belt properly and reach all controls.
4. Passengers should also be tall enough for the seat belt to fit properly and be able to brace themselves, as necessary, by placing both feet firmly on the floor while gripping the handholds. Keep all body parts completely inside the vehicle.

Dress Properly

1. Proper clothing can reduce the severity of injury in the event of an accident.
2. Always wear appropriate eye protection and protective clothing. It is also recommended that you wear a properly fitting D.O.T. approved helmet.

Slope Operation

Slopes are a major factor related to loss of control and rollover accidents, which can result in severe injury or death. If a slope is steeper than a 15° incline, do not operate this vehicle on that area. Exercise extreme caution while operating on slopes.

Do:

1. Travel straight up and down slopes, not across. Exercise extreme caution when changing direction on slopes.
2. Travel slowly while on a slope. Always keep the forward speed limited when going down slopes to take advantage of the engine braking action.
3. Keep all movement on the slopes slow and gradual. Avoid starting or stopping on a slope.
4. Avoid slopes with slippery, loose, or bumpy surfaces as they are especially hazardous.
5. Use extra care while carrying cargo. It may affect the stability of the vehicle. Spread the load evenly and tie down.

Do Not:

1. Do not travel near drop-offs, ditches, or embankments. The vehicle could suddenly turn over if a wheel is over the edge of a cliff, ditch, or if an edge caves in.
2. Do not stop or start suddenly when going uphill or downhill. Be especially cautious when changing direction on slopes.
3. Do not turn sideways to the hill. The vehicle may roll over. If you must turn, go slow and do so carefully and gradually.
4. Do not carry cargo or tow loads on steep slopes.

Towing

1. Always use an approved hitch and hitch point provided on the utility vehicle.
2. Do not tow more than 1200 lbs (544 kg) rolling weight (i.e. trailer plus cargo).
3. Never load more than 110 lbs (50 kg) tongue weight on tow bracket provided.
4. Go slow and use extra care when towing a trailer. Allow for increased braking distance. Load trailer properly.
5. Do not tow heavy loads on slopes greater than 5° incline. When going downhill or turning, the extra weight tends to push the tow vehicle and may cause you to lose control (i.e. braking and steering ability are reduced, towed equipment may jack-knife and cause utility vehicle to overturn).

Cargo Box Loading/Operation

1. Do not exceed vehicle's Total Load Capacity rating of 1000 lbs (453.5 kg). This includes operator, passenger, accessories, and cargo.
2. Do not exceed 500 lbs. (226.7 kg) load in cargo box.
3. Spread load evenly and secure to prevent movement.
4. Do not load above height of cargo box front panel. Load could shift forward and injure driver or passenger.
5. Avoid loads which exceed the physical dimensions of cargo box.
6. Go slow. Heavy loads will affect steering, braking, stability, and overall handling of the vehicle. Limit loads to those that can be safely controlled.
7. Avoid sudden starts, stops, and turns which could cause load to shift.

Cargo Box Lift

1. Stop vehicle on level ground, move the shift lever into the "PARK" position before raising cargo box.
2. On manual lift units, unload cargo box before raising cargo box.
3. Do not operate vehicle with cargo box in raised position.
4. Do not operate vehicle with cargo box latch unlatched. Always re-latch upon manually lowering cargo box.

When using optional electric lift:

- a. Stay in driver's seat.
- b. Keep body parts away from cargo box and keep all bystanders away.
- c. Do not allow rear wheels to hang over the edge of a drop-off when raising cargo box. The load in the cargo box may shift causing the vehicle to tip over backwards.

Safety Frame (OPS)

1. Your vehicle is equipped with an occupant protection structure (OPS) which must be maintained in a fully functional condition. Use care when driving through doorways or spaces with a low overhead.
 - a. Never modify the OPS in any way.
 - b. Never attempt to straighten or weld any part of the main frame or retaining brackets that have been damaged. Doing so may weaken the structure and endanger your safety.
 - c. Never secure any parts other than manufacturer approved accessories on the main frame or attach the safety frame with anything other than the special fasteners specified.
 - d. Never attach ropes, chains, or cables to the OPS for pulling purposes.
 - e. Although the OPS, when used with a properly secured seat belt, provides a crush-protective environment in the event of a tip-over or rollover, never take unnecessary risks.

Children

1. Tragic accidents can occur if the operator is not alert to the presence of children. Children are often attracted to the vehicle. They do not understand the dangers. Never assume that children will remain where you last saw them. Avoid run over accidents.
 - a. Keep children out of the immediate area of the vehicle and in watchful care of a responsible adult other than the operator.
 - b. Be alert and turn the vehicle off if a child enters the area.
 - c. Before and while backing, look behind and down for small children.
 - d. Never carry small children, they may fall off and be seriously injured or interfere with safe vehicle operation.
 - e. Use extreme care while approaching blind corners, doorways, shrubs, trees, or other objects that may block your vision of a child who may run into the path of the vehicle.
 - f. Remove key when vehicle is unattended to prevent unauthorized operation.
2. Never allow children under 16 years old to operate this vehicle. Children 16 years old and over should read and understand the operation instructions and safety rules in this manual, should be trained and supervised by a parent and have obtained a state-issued motor vehicle driver's license.
3. Do not let children ride in the cargo box, in the driver's or passenger's lap or anywhere other than the passenger seat. Never give small children a ride; not even in the passenger seat. They may fall off.

Service

Safe Handling of Fuel:

1. To avoid personal injury or property damage use extreme care in handling fuel. Fuel is extremely flammable and the vapors are explosive. Serious personal injury can occur when fuel is spilled on yourself or your clothes which can ignite. Wash your skin and change clothes immediately.
 - a. Use only an approved fuel container.
 - b. Never carry or fill containers inside the vehicle's bed or on a truck or trailer. Always place containers on the ground away from your vehicle before filling.
 - c. When practical, remove gas-powered vehicle from the truck or trailer and refuel it on the ground. If this is not possible, then refuel on a trailer with a portable container, rather than from a fuel dispenser nozzle.
 - d. Keep the nozzle in contact with the rim of the fuel tank or container opening at all times until fueling is complete. Do not use a nozzle lock-open device.
 - e. Extinguish all cigarettes, cigars, pipes, and other sources of ignition.

Important Notice

This UTV is designed and manufactured for **OFF-ROAD** use only. It is illegal and unsafe to operate this UTV on any public street, road or highway.

This UTV complies with all applicable **OFF-ROAD** noise level and spark arrestor laws and regulations in effect at the time of manufacture.

Please check your local riding laws and regulations before operating this UTV.

When the temperature is below -4° F (-20° C), park the UTV in a place where the temperature is higher than -4° F (-20° C). Start the UTV after the UTV has warmed up. Please see the manual on the warming up process.

Follow the proper parking procedures when the temperature is higher than 100° F (38° C): turn off the engine; make sure the radiator fan is on for 3 minutes before turning off the power switch.

Starting the UTV for the first time will take longer because the fuel will need to reach the fuel injectors. To start the UTV the first time, hold the ignition key on at 5-second intervals. Allow the starter to rest 15 seconds between each start attempt.


Universal Symbols

As a guide to the operation of your vehicle, various universal symbols have been utilized on the instruments and controls. The symbols are shown below with an indication of their meaning.

	Warning/Danger/Caution Symbol		Lift Cylinder -- Retract
	Diesel Fuel		Lift Cylinder -- Extend
	Engine Coolant -- Temperature		Lift Cylinder -- Float
	Parking Brake		Hazard Warning Lights
	Battery Charging Condition		Master Lighting Switch
	Engine Oil -- Pressure		Audible Warning Device
	Turn Signal/Hazard		Fault Indicator Light of EPS System
	Differential Lock		2WD/4WD
	Position Light Bulb		

Record Product Information

Before setting up and operating your new utility vehicle please locate the model plate and record the information in the provided area to the right. You can locate the model plate by looking on the frame above the left rear tire. See the image below. This information will be necessary, should you seek technical support via our web site, Customer Support Department, or with a local authorized service dealer.



MODEL NUMBER

SERIAL NUMBER

Thank You

Thank you for purchasing this product. It was carefully engineered to provide excellent performance when properly operated and maintained.

Please read this entire manual prior to operating. It instructs you how to safely and easily set up, operate and maintain your vehicle. Please be sure that you, and any other persons who will operate the vehicle, carefully follow the recommended safety practices at all times. Failure to do so could result in personal injury or property damage.

All information in this manual is relative to the most recent product information available at the time. Review this manual frequently to familiarize yourself with the vehicle, its features and operation. Please be aware that this Operator's Manual may cover a range of product specifications for various models. Characteristics and features discussed and/or illustrated in this manual may not be applicable to all models. We reserve the right to change product specifications, designs and vehicle without notice and without incurring obligation.

If applicable, the power testing information used to establish the power rating of the engine equipped on this vehicle can be found at www.opei.org or the engine manufacturer's web site.

If you have any problems or questions concerning the vehicle, phone your local authorized service dealer or contact us directly. We want to ensure your complete satisfaction at all times.

Throughout this manual, all references to *right* and *left* side of the vehicle are observed from the operating position.

Contents of Crate

- Utility Vehicle (1)
- Operator's Manual (1)
- Tool Kit
- Product Registration Card (1)

Note: This Operator's Manual covers several models. Utility vehicle features may vary by model. Not all features in this manual are applicable to all utility vehicle models and the utility vehicle depicted may differ from yours.

Note: All references in this manual to the left or right side and front or back of the utility vehicle are from the operating position only. Exceptions, if any, will be specified.

Note: Some components may come already assembled. If they are already assembled, skip ahead to the next step.

CAUTION

To avoid personal injury: Be sure to check and service the vehicle on a level surface with the engine shut off, the parking brake "ON" and any attachments lowered to the ground.

Pre-Start Check Items

To better prevent or avoid unnecessary repairs, it is important to know the condition of the vehicle well. Check it before operating.

✓ Visually inspect the vehicle ✓ Check engine oil level ✓ Check air filter ✓ Check brake fluid level ✓ Check coolant level ✓ Clean radiator screen (when used in dusty or muddy conditions) ✓ Check brake and pedal ✓ Check parking brake	✓ Check indicators, gauges and meters ✓ Check lights ✓ Check seat belts and roll-over protective structures ✓ Check front and rear joint boots ✓ Check tire inflation pressure ✓ Check fuel ✓ Check danger, warning and caution labels
---	--




Figure 4-1

Features

Refer to Figure 4-1 for the location of the features described below.

Fuel Cap (A)

The fuel cap is located on the right side of the vehicle to the rear of the passenger door.

Bumper (B)

The bumper is located on the front of the utility vehicle.

Headlights (C)

The headlights are located on the front of the utility vehicle and are illuminated when the headlight switch is in the "ON" position.

Turn Signals (D)

The turn signals are on the front and rear of the vehicle and are activated by the turn signal switch.

Door Handles (E)

The door handles are used to open the doors and are located on the doors.

Cargo Bed (F)

The cargo bed is used to haul materials and is located on the back of the utility vehicle. See the Specifications chart for information on cargo bed capacity and dimensions.

Cargo Bed Release Levers (G)

The cargo bed release levers are located on both the RH and LH side of the cargo bed and are used to dump/tilt the cargo bed.

Brake Lights (H)

The brake lights are located on the rear of the cargo bed and are illuminated by depressing the brake pedal or when the hazard button is in the "ON" position.

Tail Lights (I)

The tail lights are illuminated when the headlight switch is turned to the "ON" position.

Tailgate (J)

The tailgate is located on the rear of the cargo bed and can be opened by using the tailgate lever.

Tailgate Lever (K)

The tailgate lever is located on the tailgate and is used to open the tailgate.

Hand Grip (L)

The hand grip is located on the passenger side of the utility vehicle on the OPS.

Mirrors (M) (Optional, If equipped)

The mirrors are located on the passenger and driver's side of the vehicle and are used to see behind the utility vehicle.

Winch (N)

The winch is located on the front of the utility vehicle inside the bumper. The winch is controlled by the winch control.

Occupant Protection Structure (OPS) & Seat Belts (Not shown)

This utility vehicle is equipped with an Occupant Protection Structure (OPS) and seat belts. When used together they are effective in reducing crushing injuries to the operator and passenger in the event of an accidental rollover or tip-over. The safety provided by the OPS is minimized if the seat belt is not properly adjusted AND buckled. Adjust the seat belts for proper fit and connect the buckle. This seat belt is an auto-locking, retractable type.

To wear the 3-point seat belt properly:

1. Pull the seat belt latch down and across your chest toward the buckle. The belt should fit snugly across your hips and diagonally across your chest. Make sure the belt is not twisted.
2. Push the latch plate into the buckle until it clicks. Pull up on the strap to tighten.
3. Press the red release latch on the buckle to release the seat belt.

⚠ WARNING

Always wear the seat belt when operating the utility vehicle.

Use the following guidelines when using a utility vehicle equipped with OPS:

1. Be aware of overhead clearances in the area of operation. Check for clearance of door (or gate) openings and other overhead objects such as utility lines and tree branches. Overhead objects could catch the OPS and upset the utility vehicle.
2. Do not modify the OPS by drilling holes for, or welding accessories to, the structure.
3. Do not use the OPS to pull objects with the utility vehicle. Use ONLY the utility vehicle hitch for pulling.
4. Do not operate the utility vehicle without the OPS and do not remove the OPS.
5. In the event of an accident, have the OPS carefully inspected and, if necessary, replaced by your authorized dealer. Do not attempt to repair the OPS.

Operation

First 50 Hours

How a new vehicle is handled and maintained determines the life of the vehicle.

A new vehicle just off the factory production line has been, of course, tested, but various parts are not fully aligned, so the operator should pay more attention to operating the vehicle for the first 50 hours at a slower speed and avoid excessive work or operation until the various parts become “broken-in.” The manner to which you handle the vehicle during the “breaking-in” period greatly affects the life of your vehicle. Therefore, to obtain the maximum performance and the longest life of the vehicle, it is very important to properly break-in your vehicle. For better handling a new vehicle, the following precautions should be observed.

- Do not operate the vehicle at full speed for the first 50 hours.
- Do not start quickly nor apply the brakes suddenly.
- In winter, operate the vehicle after fully warming up the engine.
- Do not run the engine at speeds faster than prescribed.
- On rough roads, slow down to suitable speeds.
- Do not operate the vehicle at fast speed.

The above precautions are not limited to new vehicles. However, they should be especially observed for new vehicles.

Note: The lubricating oil is especially important for a new vehicle. Various parts need time to wear and polish themselves to the correct operating clearances. Small pieces of metal grit may develop during the operation of the vehicle; and this may wear out or damage the parts. Therefore, change the lubricating oil a little earlier than would ordinarily be required. For further details of change interval hours, see the Product Care section of this manual.

Starting the Utility Vehicle

⚠ WARNING

Seat belts reduce injury. Always wear your seat belts. The lap-style seat belts may not provide adequate protection for small children. Pay special attention when carrying a child passenger. Always use the seat belts when operating and riding in the vehicle.

General Safety

- **RECEIVE INSTRUCTION** — Entirely read this operator’s manual. Learn to operate this vehicle SAFELY. Do not risk INJURY or DEATH. Allow only those who have become competent in its usage to operate this utility vehicle.
- Before starting the engine or beginning operation, be familiar with the controls.
- Read the danger, warning and caution labels located on the vehicle.
- To avoid the danger of exhaust fumes, do not operate the utility vehicle in closed buildings without proper ventilation.

- Start engine only from operator’s seat. Never start the engine while standing outside the utility vehicle.
- Make sure the shift lever is in the NEUTRAL (N) or PARK (P) position before starting the engine.

Starting the Engine

Note: Do not use starting fluid or ether.

Note: To protect the battery and the starter, make sure that the starter is not continuously turned for more than 5 seconds.

1. Engage the parking brake.

Note: The parking brake indicator is illuminated when the parking brake is applied and turns off when it is released. See Figure 4-2.

2. Place the shift lever in the NEUTRAL (N) or PARK (P) position.

Note: The engine will not start without the gear shift in the NEUTRAL (N) or PARK (P) position and the brake depressed.

3. Insert the key into the ignition and turn it to the START position. Release the key when the engine starts. See Figure 4-3.




Figure 4-3

Note: The ignition is a 4-position switch, the positions and brief descriptions of each are below:

- a. OFF — Engine is off and the key can be removed.
- b. ACC — Accessories such as radio are on, but engine is off.
- c. ON — Engine and all accessories are on.
- d. START — Starter motor on, the key will return to the ON position when released.

Note: When the ambient temperature is below -15° C (5° F), the engine is very cold. If the engine fails to start after 5 seconds, turn off the key for 30 seconds and start again.

Stopping the Engine

1. After slowing the engine to idle, turn the key to the OFF position.
2. Remove the key.

Warming Up

⚠ CAUTION

Be sure to set the parking brake during warm-up. Be sure to set the shift lever to the PARK position during warm-up.

For 5 minutes after engine start-up, allow the engine and transmission to warm up without applying any load. This is to allow oil to reach every engine part. If load applied to the engine or transmission without warming up, damage may occur.

Driving the Utility Vehicle

1. Adjust the seat belt to fit comfortably around your lap, then buckle the seat belt.

⚠ WARNING

Do not operate the vehicle without the OPS in place and the seat belt fastened securely around your waist and chest.

2. Start the engine as instructed in the Starting the Engine section and make sure the front wheels are turned to the desired direction of travel.

⚠ CAUTION

Immediately stop the engine if the engine suddenly slows down or accelerates, unusual noises are suddenly heard, or exhaust fumes suddenly become very strong.

3. Push down on brake pedal, pull slightly back on the parking brake lever while depressing the lock button and then slowly push forward to release the parking brake.
4. Push down on brake pedal and move the shift lever into the desired setting. To avoid damaging the transmission, depress the brake pedal fully and make sure the vehicle is completely stopped before shifting into HIGH (H), LOW (L) or REVERSE (R).

⚠ WARNING

Do not stop or start suddenly when going uphill or downhill. Be cautious when changing direction on slopes. Apply brakes when going down slopes to maintain control of vehicle.

5. Release brake pedal and slowly apply pressure to the gas pedal.
6. Release gas and apply brake pedal evenly and firmly to slow down or stop.

2WD/4WD

⚠ CAUTION

When traveling at road speed, use only 2WD. When driving on icy, wet, or loose surfaces, make sure the vehicle is correctly loaded to avoid skidding and loss of steering control. Reduce the speed and engage front wheel drive. Accident may occur if the vehicle is suddenly braked, such as heavy towed loads shifting forward causing loss of control. The braking characteristics are different between two and four wheel drive. Be aware of the differences and operate carefully.

To activate the 4WD stop the utility vehicle and press down on the upper half of the 2WD/4WD switch. To return to 2WD, stop the utility vehicle and press down on the lower half of the 2WD/4WD switch. When in 2WD just the two rear tires will be filled on the instrument cluster indicator, when in 4WD all four tires will be filled. See Figure 4-4.




Figure 4-4

Differential Lock

⚠ WARNING

To avoid transmission damage, injury, or turf damage, drive slow when operating utility vehicle with differential lock engaged as steering response is noticeably reduced. Also, do not drive the utility vehicle with the differential lock engaged on concrete, asphalt, or any high traction surfaces.

The front and rear axle differentials can be activated when the utility vehicle is stopped and the shift lever is in the NEUTRAL position. To activate either axle differential press the upper portion of the front/rear axle differential switch. To deactivate the axle differential press the lower portion of the front/rear axle differential switch. Both, one or neither of the differentials can be active. When activated the differential lock indicator display will show an "X" on the indicator as shown in Figure 4-5.




Figure 4-5

Important! Engage the differential as the last option when stuck in mud or similar situation or when the left and right side wheels are turning at slightly different speeds.

Loading the Cargo Bed

⚠ WARNING

The utility vehicle may become unstable if the cargo bed is loaded incorrectly. Avoid loose and unsecured loads or uneven loading of material.

1. Verify cargo bed is securely latched before loading.
2. Securely anchor all loads in cargo bed and do not load beyond maximum capacity.
Note: The maximum box capacity is 500 lb (227 kg).
3. When loading objects into cargo bed, be sure load is securely anchored and evenly distributed.
4. Do not load above height of cargo bed. Load could shift forward striking driver or passenger or cause driver to lose control of vehicle.
5. Avoid loads which exceed physical dimensions of cargo bed.
6. Avoid concentrated loads at rear or sides of cargo bed. Be sure load is distributed evenly.
7. Reduce load and ground speed when operating over rough or hilly terrain. Do NOT overload vehicle. Limit loads to those that can be safely controlled.

Raising & Lowering the Tailgate

To open up the tailgate (a), pull up on the tailgate lever (b) and slowly lower the tailgate (a). To close the tailgate (a) lift the tailgate (a) and push it forward until it locks into place. See Figure 4-6.




Figure 4-6

Raising & Lowering the Cargo Bed (Dumping Load)

⚠ WARNING

To prevent the possibility of bodily injury from unintentional lowering of the cargo bed, be sure vehicle is on a level and stable surface and parking brake is set before raising cargo bed.

⚠ WARNING

A loaded cargo bed can be very heavy. Do not attempt to dump a heavily loaded cargo bed.

1. Park the vehicle safely on level ground and set parking brake.
2. Empty heavy loads by hand.
3. For light loads, unlatch cargo bed by pulling up on one of the cargo bed release levers. While holding the cargo bed release lever lift the cargo bed. See Figure 4-7.




Figure 4-7

4. Once unloaded, lower the cargo bed and securely latch it before operating the utility vehicle. Do not drive the utility vehicle with cargo bed in the raised position.

Towing Loads

⚠ WARNING

To help prevent personal injury due to loss of control or tipping, always tow a load slow enough to maintain control.

1. Do not tow a load that exceeds 1200 lb (544 kg) rolling weight (i.e. trailer plus cargo) and never exceed 110 lb (50 kg) tongue weight.
2. Go slow when towing a heavy load. Allow for increased braking distance. Tow load at a speed slow enough to maintain control.
3. Do not tow on slopes greater than 5°.
4. Be cautious when towing downhill, even on a gradual slope or when turning. The extra weight tends to push the tow vehicle and may cause you to lose control (braking and steering ability are reduced; towed equipment may jack-knife).
Important! Extreme angles such as high railroad crossings can place high bending loads on hitch connection.
5. Do not modify the hitch in any way.

Loading a Utility Vehicle into a Truck or onto a Trailer

⚠ WARNING

Always park the truck or trailer in a flat area, set the parking brake, turn the ignition off, and chock the wheels to prevent any unexpected movement while loading the utility vehicle.

⚠ WARNING

Fully secure the loading ramps to the truck or trailer with tie-down straps or cables to prevent the ramps from sliding off while loading. Keep bystanders and/or helpers away from ramps while loading.

Due to the overall size and dimensions, loading a utility vehicle into a truck or onto a trailer is a task that requires precision and the proper equipment to be achieved safely. By following the steps outlined below you'll be able to select the proper equipment to do the job and safely load and unload your utility vehicle.

Determine if your truck or trailer is sufficient for the task

Loading a utility vehicle into a truck or trailer that can't support its weight is extremely dangerous. It is important that before any actual loading is done, make sure your truck or trailer and loading ramps are sufficient for loading and hauling the utility vehicle. Here are some of the variables you need to take into account:

- **Length and Width:** Measure the size of your truck or trailer by taking width and length measurements at the floor level. Compare these measurements to the width and length of your utility vehicle to make sure it will fit comfortably.
- **Weight Capacity:** Making sure your truck or trailer can handle the payload of your utility vehicle is another critical task before any loading is done. If using a truck, the payload capacity must be a minimum of 3/4 ton. If hauling on a trailer, remember that the towing capacity of the vehicle will be reduced by the added weight of the utility vehicle.
- **Tailgate Considerations:** If the payload capacity is sufficient for hauling in a truck, the last thing left to consider is your truck's bed length. Make certain that your truck bed is long enough to allow the truck's tailgate to close completely when the utility vehicle is loaded into the truck bed.

Choosing the proper loading ramp(s)

Choosing a reliable ramp and understanding how to properly use it is far and above the best option for safely loading a utility vehicle into your truck or onto your trailer. Take a look at the considerations you should have in mind when choosing the proper ramp(s):

- **Capacity:** Utility vehicles are not evenly balanced, meaning it's necessary to check the axle weights before you make any choices regarding ramps. A typical ramp's capacity is based upon two axles with equally distributed loads. We recommend 3000-lb minimum capacity ramp(s) as the appropriate option for your two-person utility vehicle.
 - **Offset Track Widths:** Your utility vehicle has an offset track width front and rear, it's important to factor this in to your ramp placement and ramp width needs. Ramps need to be wide enough to accommodate the difference in the distances between the front two wheels and the rear two wheels.
 - **Ground Clearance and Wheelbase:** Utility vehicles which have low ground clearance (under 4") and a relatively long wheelbase (98" or more), make them prone to bottoming out at the crest when using straight ramps. As a solution to this issue we suggest using arched ramps.
 - **Load Height:** As with any ramp application, the distance from the ground to the truck bed or trailer impacts the overall length of the ramp you will need, the greater the load height, the longer the ramp should be. Some ramp manufacturers and retailers provide load height calculators to help you determine the correct ramp length you will need to safely load your vehicle.
- Note:** If you are still unsure of what types of ramps you will need to get the job done and are having trouble understanding these instructions, check with your local ramp or utility vehicle retailer for assistance.

Loading the Utility Vehicle

If your truck or trailer's load capacity is sufficient to transport the utility vehicle and you obtain the proper loading ramps and equipment to safely secure the utility vehicle to the truck or trailer, the only thing left to do is load it. Here's how to best accomplish this task:

1. Proceed with extreme caution. It is very difficult to overcome a mistake while in the loading process.
2. Park the truck or trailer in a flat area, set the parking brake, turn the ignition off and chock the wheels.
3. Face the truck bed or trailer towards a slight incline, which will reduce the steepness of the loading angle by bringing the bottom of the ramps up on the slight incline. See Figure 4-8.




Figure 4-8

4. Place the ramp fingers or plate edges on the edge of the trailer or truck bed. See Figure 4-9.




Figure 4-9

5. Use tie-down straps or cables to secure the ramps to the trailer or truck, via the bumper (steel bumpers only) or trailer hitch safety chain loops. Refer to instructions provided with the ramp.
6. If your utility vehicle is supplied with a roof and/or windshield, remove or fully secure them prior to loading. Roofs and windshields are not designed to withstand the wind speeds that the open road can generate, so it's best to remove them entirely to prevent any damage or accidents.
7. Follow all safety rules provided in this manual along with the manuals supplied by the trailer and ramp manufacturer. Carefully load the utility vehicle onto the truck or trailer.
8. Once the utility vehicle is on the truck or trailer, set the utility vehicle's parking brake and secure the utility vehicle to the truck or trailer. Tie-down strap placement will depend on your truck or trailer. Be sure to use only tie-down straps sufficient for the load capacity. If loaded onto a truck, close the tailgate once the utility vehicle is secured to the truck bed.
9. Stop periodically to ensure that your tie-down straps have not loosened and that the utility vehicle remains securely in place.

Important! Know the total height of your vehicle with the utility vehicle loaded before transporting. Be sure to check for low clearance bridges, doorways, etc. prior to traveling under them. The added height above the height of your truck could cause clearance issues and damage to both vehicles.

Maintenance Chart	Intervals											
	First 20 hours	First 50 hours	Every 50 hours	Every 100 hours	Every 150 hours	Every 200 hours	Every 300 hours	Every 500 hours	Every 3900 hours	Every year	Every 2 years	Every 4 years
Grease utility vehicle			✓									
Clean muffler/spark arrestor		✓		✓								
Clean spark arrestor				✓								
Check lug nuts		✓		✓								
Check battery condition				✓								
Adjust front wheel toe-in				✓								
Change oil	✓				✓							
Check fuel line				✓						✓		
Replace fuel line								✓				
Clean air filter element *	✓			✓						✓		
Check brake pedal		✓				✓						
Adjust parking brake		✓				✓				✓		
Check brake light switch		✓				✓						
Check radiator hose & clamp						✓						
Replace radiator hose & clamp											✓	
Check PCV Accumulator		✓			✓							
Check intake air line						✓						
Replace intake air line											✓	
Check brake hose & pipe		✓			✓							
Replace brake hose & pipe												✓
Check tires		✓					✓					
Change axle case oil							✓					
Adjust engine valve clearance								✓				
Check fuel injection								✓				
Check injection									✓			
Check CV shaft boots			✓									
Check exhaust system					✓							
Check wheel bearings	✓				✓							
Check engine timing							✓					
Change brake fluid											✓	
Replace remote hydraulic hose											✓	
Replace rear brake cylinder seal											✓	
Replace front brake cylinder seal											✓	
Flush cooling system											✓	
Change engine coolant											✓	

* — Perform more often in dusty conditions.

Troubleshooting

1. Engine will not start:
 - Battery has low voltage
 - Loose or corroded battery connections
 - Fuse is blown
 - Spark plug wire is loose or disconnected
 - Faulty spark plug or coil
 - No fuel or improper fuel
 - Plugged fuel filter
 - Defective starter solenoid
 - Open-circuit in wiring
2. Engine is difficult to start:
 - Engine is cold
 - Plugged fuel filter
 - Engine oil viscosity too heavy
 - Spark plug is fouled
 - Faulty spark plug or wire
 - Loose or corroded electrical connections
 - Stale or improper fuel
3. Engine misfires under load:
 - Faulty spark plug
 - Stale or dirty fuel
 - Plugged fuel filter
 - Faulty coil or wire
4. Engine does not restart when warm:
 - Poor quality fuel
 - Very hot weather conditions
 - Fuel tank vent plugged
 - Dirt in fuel filter
5. Entire electrical system does not work:
 - Blown fuse
 - Loose or corroded connections
 - Dead or faulty battery
6. Dead battery:
 - Shorted starter solenoid
 - Key switch not turned to STOP position
 - Faulty battery
7. Battery will not take a charge:
 - Dead battery
 - Loose or corroded connections
8. Difficult to shift:
 - Idle speed too fast
 - Gears not lined up. Tap throttle and let it return to idle. If still hard to shift, contact your nearest authorized service dealer
9. Indicator lights do not come on when key switch is in START position:
 - Faulty bulb
 - Faulty wiring
 - Faulty sensor
10. Engine runs unevenly:
 - Loose electrical connections
 - Choke (if equipped) or throttle cable sticking
 - Fuel line or fuel filter plugged
 - Stale or dirty fuel
- Improper fuel
- Air cleaner element plugged
- Spark plug is fouled
11. Engine overheats:
 - Air cleaner element missing or plugged
 - Air intake plugged
 - Engine oil low
 - Engine operated too long at slow engine speed
 - Cooling fan not turning
12. Engine loses power:
 - Engine overheating
 - Too much oil in engine
 - Faulty spark plug
 - Fuel supply being restricted
 - Fuel filter plugged
 - Fuel line pinched or kinked
 - Fuel pump output not adjusted to specification
 - Improper fuel
 - Air cleaner element plugged
13. Starter does not work:
 - Loose or corroded connections
 - Low battery output
 - Dead or faulty battery
 - Faulty starter
14. Starter cranks slowly:
 - Low battery output
 - Dead or faulty battery
 - Engine oil too heavy
 - Loose or corroded connections
15. Battery light comes on when engine is running:
 - Low engine speed
 - Faulty voltage regulator
 - Faulty battery
 - Faulty rotor or stator
 - Damaged wiring harness
16. Vehicle will not move:
 - Shift Lever still in NEUTRAL
 - Parking Brake still set
 - Broken or cut drive belt
 - Safely check to see if the vehicle will go in reverse and then try to go forward. If vehicle still will not move forward, contact your nearest authorized dealer

Pre-Start Checklist

- Check parking brake. Make sure the parking brake indicator light comes on when the parking brake is ON.
- Inspect the instrument panel for broken gauges and warning lamps.
- Check the headlights and turn signals. Replace if broken.
- Check seat belt and OPS. Do not operate utility vehicle until repaired if either is broken.

- Check the joint boots on the drive shaft for damage. If the joint boots are damaged, see an authorized service dealer.
- Check tire pressure. See Tire Pressure in this section.

Maintenance

⚠ WARNING

To avoid personal injury, be sure to check and service the vehicle on a flat surface with the engine off and the parking brake ON. If servicing under the cargo bed, be sure that the cargo bed is supported so that it can not inadvertently close. Do not touch muffler or exhaust pipes while they are hot; Otherwise, severe burns could result.

⚠ WARNING

If vehicle diagnosis requires the vehicle to be run with the wheels off the ground, the free wheeling state will cause the engine management system to create a lean condition. This lean condition will cause the exhaust system to become hotter than normal operating conditions. Exercise extreme caution when working around the exhaust components and allow extra time for the exhaust components to cool.

Tire Pressure

The recommended operating tire pressure is 14 psi (70 kPa) for all tires. Over-inflating above recommended tire pressure can reduce the life of the tire. Check tire pressures before each use.

Note: If the cargo bed is at maximum capacity (1000 lbs), the rear tire pressure can be increased to 18 psi (124 kPa).

Lug Nuts

Check torque of lug nuts after first 50 hours of use and every 100 hours thereafter. Tighten lug nuts in a diagonal pattern. Torque lug nuts to 65-75 lb-ft using a torque wrench.

Removing the Hood & Interior Hood Panel

⚠ CAUTION

To avoid personal injury from contact with moving parts never open operator's seat or hood cover while the engine is running.

To open the hood, pull up on the center of the upper edge of the cover (a) and lift the hood off. To close, insert the front bottom hooks into the hood. Push down on the perimeter of the cover. See Figure 5-1.




Figure 5-1

To remove the interior hood panel (a), grasp the upper left corner of the panel and pull. See Figure 5-2.




Figure 5-2

Removing the Seat

To remove the seat, lift up on the front edge of the seat and after the two pins (a) clear the bushings pull towards the front of the vehicle. See Figure 5-3. When re-installing the seat, make sure the pins (a) in the seat are inserted into the holes (b) in the frame.




Figure 5-3

Removing the Battery Access Panel

Unlock the battery access panel under the seat by rotating the lock knob, then lifting the battery access panel. See Figure 5-4.




Figure 5-4

Removing the Engine Access Panel

Lift up on the handle (a) near the front of the engine access panel under the seat, then remove the engine access panel. See Figure 5-5.




Figure 5-5

Removing the Air Filter Access Panel

Remove the two screws (a) securing the air filter access panel (b) to the front of the seat box. See Figure 5-6.




Figure 5-6

Jacking Up the Utility Vehicle

⚠ WARNING

To avoid personal injury, death, or vehicle damage do not work under the vehicle unless it is secured by safe stands or suitable blocking.

1. Jack up the front end of the utility vehicle on the front frame tube (a) only. See Figure 5-7.




Figure 5-7

2. Jack the rear of the utility vehicle only after placing a wooden block under the right (a) and left frame tube (b) for securing the engine and then supporting it. Do not apply jack pressure on the steel plate directly under the engine. See Figure 5-8.




Figure 5-8

Adjusting the Doors

If the gaps around the doors are uneven, the door can be adjusted. To adjust the doors, loosen the two bolts (a) on each hinge, adjust the door until an equal gap is achieved all the way around. Retighten all four bolts (a). See Figure 5-9.




Figure 5-9

If the door is not latching properly, the latches (a) can be adjusted. Loosen the two bolts (b) securing the latch (a), position the latch (a) so that the door closes and latches properly, then re-tighten the two bolts (b). See Figure 5-10.




Figure 5-10

Checking & Refilling Fuel

⚠ CAUTION

Do not smoke while refueling. Be sure to stop the engine before refueling.

1. Turn the key switch to ON, check the amount of fuel by the fuel gauge.
2. Fill fuel tank when fuel gauge shows 1/4 or less fuel in the tank.
3. The fuel tank holds approximately 7.4 gallons (28 L) of fuel.

Checking & Adding Oil

Important! If oil level is low, do not run the engine.

1. Park the vehicle on a flat surface with engine off, remove the seat and engine access panel to access the engine.
2. To check the oil level, remove the dipstick (a), wipe it clean, replace it without re-threading the dipstick, and pull it out again, check to see if the level is too low and add new oil to the full level on the dipstick (a). See Figure 5-11 for the location of dipstick.




Figure 5-11

3. After the new filter has been replaced, the engine oil normally decreases a little. Make sure that the engine oil does not leak through the seal and check the oil level on the dipstick. Add oil if necessary.
4. See Figure 5-12 for oil recommendations.




Figure 5-12

⚠ CAUTION

Only use engine oil with API Service Classification of SJ or Higher and JASO-MA Grade.

5. The engine oil capacity is 2.22 quarts (2.1 L).

Checking & Adding Engine Coolant

⚠ CAUTION

Do not remove radiator cap while coolant is hot. When cool, slowly rotate to the first stop and allow sufficient time for excess pressure to escape before removing the cap completely.

1. Park the vehicle on a flat surface, remove the hood panel, set the parking brake and shut off the engine.
2. Check to see that the coolant level is between the FULL (a) and LOW (b) marks of recovery tank (c). See Figure 5-13.




Figure 5-13

3. When the coolant level drops due to evaporation, add water only up to the FULL (a) level. In case of leakage add anti-freeze and water in the specified mixing ratio up to the FULL (a) level. (See Flushing the Coolant System and Changing Coolant section).
 - Use clean fresh water and anti-freeze to fill the recovery tank.
 - If water should leak, consult your local authorized service dealer.

Note: If the radiator cap has to be removed, follow the cautions above and securely retighten the cap.

Cleaning the Radiator Screen

⚠ CAUTION

Be sure to stop the engine before removing the screen.

Note: Radiator screen must be cleaned of debris to prevent engine from overheating.

1. Park the utility vehicle on a flat surface.
2. Remove the radiator cover.
3. Detach the screen and clean the radiator and radiator screen and radiator fins of all debris. See Figure 5-14.




Figure 5-14

Checking & Adding Brake Fluid

⚠ CAUTION

Never operate the vehicle if the brake fluid is below the minimum mark. Use only DOT3 from a sealed container. Other types of brake fluid may ruin synthetic resin or rubber installed in brake system components and may cause brake failure. Avoid contamination of the brake fluid, thoroughly clean around the filler cap before removing. Do not open the brake fluid reservoir cap unless absolutely necessary. Use extreme care when filling the reservoir. If brake fluid spills on coolant hose, wash off with water immediately, as brake fluid quickly ruins synthetic resin or rubber hoses.

1. Check to see that the brake fluid level of the brake fluid reservoir (a) is up to the MIN (b) level. See Figure 5-15.




Figure 5-15

2. If it is below the MIN (b) level add brake fluid, but do not exceed the MAX (c) level.

Checking the Brake Pedal

⚠ WARNING

Stop the engine and chock the wheels before checking brake pedal.

Inspect the brake pedals for free play (a), pedal stroke (b) and smooth operation. Refer to Figure 5-16.




Figure 5-16

1. Release the parking brake.
2. Step on the pedal and measure the free play (a). There should be between .3" and .5" (7-14 mm) of free play (a). If the free play (a) measurement is outside of these specifications, see an authorized service dealer to have the brake adjusted.

- Step on the pedal and measure the stroke (b). There should be less than 4.7" (120 mm) of stroke (b). If the measurement is outside of these specifications, see an authorized service dealer to have the brake adjusted.

Checking & Adjusting the Parking Brake

Pull the parking brake to apply the brakes with the key switch in the ON position and the parking brake indicator should come on. To release the parking brake, depress the parking pedal. Make sure the parking brake warning lamp on the display goes off when parking brake is OFF.

If the parking brake is in need of adjustment, proceed as follows:

- Locate the parking brake adjustment nut near the engine. See Figure 5-17.




Figure 5-17

- Loosen the lock nut (a) and then tighten the bolt (b) to adjust the parking brake. Turn the bolt until it touches, then back it off a 1/4-turn. See Figure 5-17.

If there is play in the parking brake handle there is a secondary adjustment that can be performed.

- Look inside the driver's side wheel well and locate the adjustment point. Slide back the rubber cover (a) on the adjustment nuts (b). See Figure 5-18.




Figure 5-18

- Adjust the parking brake handle nuts (b) until the free play in the handle is gone. See Figure 5-18.

Checking & Adjusting the Shift Lever

If the shifter and the display image on the instrument cluster do not match or the utility vehicle is not shifting, a shift cable adjustment can be performed.

- Remove the hood and the interior hood panel.
- Locate the shift lever adjustment nuts (a). See Figure 5-19.




Figure 5-19

- Adjust the nuts (a) up or down until the shift lever is working properly. See Figure 5-19.

Checking the Engine Start System

⚠ WARNING

Do not allow anyone near the vehicle while testing. If the vehicle does not pass the test, do not operate the vehicle.

- Sit on the operator's seat.
- Place the shift lever in the NEUTRAL position.
- Set the parking brake and stop the engine.
- Move the shift lever to: LOW, HIGH, PARK or REVERSE position. Do not step on the brake pedal.
- Turn the key to START position.
- The engine should not crank.
- If it cranks see an authorized service dealer.
- Repeat Steps 4 and 5 but when turning the key to start position step on the brake pedal. The engine should crank.
- If it does not crank see an authorized service dealer.

Adjusting the Shocks

There are three adjustment points on the shocks. The rebound (a), pre-load spring (b) and damping rate (c) can be adjusted. Refer to Figure 5-20 for the following instructions.




Figure 5-20

Rebound Adjuster (a)

The rebound adjuster is located near the bottom of the shock and controls the "bounce back" speed of the utility vehicle. To adjust the rebound or "bounce-back" speed, follow the steps below:

Note: Each position has a stop or "click" to indicate the setting.

- Insert a standard screw driver into the adjustment.
- Rotate the screw into one of the 18 positions between "S" (position 0) and "F" (18). Rotate the screw clockwise (towards the "S" or "0" position) to slow the rebound and counter-clockwise (towards the "F" or "18" position) to speed up the rebound.

Pre-Load Spring Adjuster (b)

The pre-load adjuster is located in the body of the shock and controls the height of the vehicle. It can be adjusted to accommodate for different load situations.

Note: This adjustment requires a spanner wrench to complete. A spanner wrench is included in the tool kit shipped with this utility vehicle.

- Using a spanner wrench, loosen the upper lock nut.
- Adjust the pre-load adjuster nut to the desired setting. Turn the pre-load adjuster clockwise to increase the compression force (raise the utility vehicle) and turn the pre-load adjuster nut counter-clockwise to decrease the compression force (lower the utility vehicle).

Damping Rate Adjuster (c)

The compression adjuster is located on the upper part of the shock and controls the ride of the utility vehicle and the impact resistance of the shocks.

Note: Each position has a stop or "click" to indicate which of the 18 positions it is in.

- To increase the stiffness of the suspension and increase the absorption of impacts, rotate the compression adjuster screw clockwise towards the "SLOW" (or "0") position.
- To decrease the stiffness (soften the ride) rotate the compression adjuster screw counter-clockwise towards the "FAST" (or "18") position.

To return the utility vehicle to its stock setting, use the chart below:

	Rebound Adjuster	Pre-Load Adjuster	Compression Adjuster
Front	Position 7	295 mm	Position 5
Rear	Position 4	300 mm	Position 3

* -- These settings are based on a "full load" condition. 250 lb (113 kg) driver, 250 lb (113 kg) passenger and 500 lb (227 kg) cargo load.

Service

⚠ WARNING

To avoid personal injury, be sure to check and service the vehicle on a flat surface with the engine off and the parking brake ON. If servicing under the cargo bed, be sure that the cargo bed is supported so that it can not inadvertently close. Do not touch muffler or exhaust pipes while they are hot; Otherwise, severe burns could result.

Changing the Oil

⚠ WARNING

Be sure to stop the engine before replacing oil. Allow engine to cool down sufficiently, oil can be hot and can burn.

- Park the vehicle on a flat surface and raise the cargo bed.
- To drain the used oil, remove the drain plug at the bottom of the engine and completely drain the oil into an oil pan.
- After draining, reinstall the drain plug.

- Fill with the new oil up to the upper notch on the dipstick.
- See Figure 5-21 for oil recommendations.




Figure 5-21

⚠ CAUTION

Only use engine oil with API Service Classification of SJ or Higher and JASO-MA Grade

- The engine oil capacity is 2.22 quarts (2.1 L).

Replacing Oil Filter

⚠ WARNING

Be sure to stop the engine before replacing oil filter. Allow engine to cool down sufficiently, oil can be hot and can burn.

- Park the vehicle on a flat surface, remove the seat and open the engine access cover.
- Make sure the engine is warm.
- Remove the oil filter (a). See Figure 5-22.




Figure 5-22

- Put a film of clean engine oil on the rubber seal of the new filter.
- Tighten the filter until it contacts the mounting surface.
- Tighten filter by hand an additional 1/2-turn only.

Draining the PCV Accumulator

The PCV accumulator should be drained at each oil change to remove oil condensation. There are two PCV accumulators, one near the front of the air intake box and one near the rear. To drain the PCV accumulator, pinch the valve at the bottom of the tube and allow the condensation to run out. See Figure 5-23.




Figure 5-23

Replacing Mini Fuses

The mini fuses are intended to protect the electrical system. If any of them have blown out, be sure to pinpoint the cause. (See Specifications section, Figure 6-1 for fuse box layout.)

- Disconnect the negative battery cable.
- Open the mini fuse box cover. See Figure 5-24.




Figure 5-24

- Pull out the mini fuse.
- Insert a new mini fuse into the box.
- Close the mini fuse box cover.
- Re-connect the negative battery cable.

Changing the Front & Rear Axle Case Oil

See your authorized service dealer to have the axle case oil changed.

Changing the Brake Fluid

See your authorized service dealer to have the brake fluid changed.

Replacing Radiator Hose

See your authorized service dealer to have the radiator hose changed.

Replacing Fuel Hose

See your authorized service dealer to have the fuel hose changed.

Replacing Brake Master Cylinder

See your authorized service dealer to have the brake master cylinder changed.

Replacing Front Brake Seal

See your authorized service dealer to have the front brake seal changed.

Replacing Rear Brake Cylinder Seal

See your authorized service dealer to have the rear brake seal changed.

Replacing Intake Air Line

See your authorized service dealer to have the air intake line changed.

Replacing Brake Hose

See your authorized service dealer to have the brake hoses changed.

Flushing the Coolant System & Changing Coolant

⚠ CAUTION

Do not remove radiator cap while coolant is hot. When cool slowly rotate to the first stop and allow sufficient time for excess pressure to escape before removing the cap completely.

- Stop the engine and let it cool down.
- To drain the coolant, open the radiator drain plug and remove radiator cap. The radiator cap must be removed to completely drain the coolant.
- After all coolant is drained, close the drain plug.
Note: Do not start engine without coolant.
- Fill with clean water and cooling system cleaner.
- Follow directions of the cleaner container.
- After flushing, fill with clean water and antifreeze until the coolant level is just below the radiator cap.
Note: When the antifreeze is mixed with water, the antifreeze mixing ratio must be 50-50. See the Antifreeze section.
- Install the radiator cap securely. If the cap is loose or improperly fitted, water may leak out and the engine could overheat.
- Fill with fresh water/antifreeze up to the "FULL" mark on the recovery tank. See Figure 5-13.
- Start and operate the engine for a few minutes.
- Stop the engine and let cool.
- Check coolant level of recovery tank and coolant if necessary.
- Burp (remove air from) the coolant system as instructed in the Burping (Removing Air From) the Coolant System section.

Anti-Freeze

⚠ WARNING

When using antifreeze, put on some protection such as rubber gloves. (Antifreeze contains poison.) If you should drink antifreeze, throw up at once and seek medical attention. If antifreeze comes in contact with the skin or clothing, wash it off immediately. Do not mix different types of antifreeze. The mixture can produce a chemical reaction between substances. Antifreeze is extremely flammable and explosive under certain conditions. Keep fire away from antifreeze. Keep children away from antifreeze. When draining fluids from the engine, place some container underneath the engine body. Do not pour waste onto the grounds, down a drain or into any water source. Also, observe the relevant environmental protection regulations when disposing of antifreeze.

If it freezes, coolant can damage the cylinders and radiator. If the ambient temperature falls below 0° C (32° F) or before a long-term storage, let out coolant completely, or mix fresh water with long-life coolant and fill the radiator and recovery tank with the mixture.

- Long-life coolant comes in several types. Use an ethylene glycol (EG) type for this engine.

- Before employing long-life coolant-mixed cooling water, fill the radiator with fresh water and empty it again.
 - Repeat this procedure two or three times to clean up the inside.
 - Mix the long-life coolant.
 - The procedure for the mixing of water and antifreeze differs according to the make of the antifreeze and the ambient temperature. Refer to SEA J1034 standard, more specifically also to SAE J814c.
 - Add the long-life coolant.
 - If there is a mixture leak, add long-life coolant from the same manufacturer and type in the same mixture percentage.
- Note:** Never mix long-life coolant from different manufacturers. (Different brands may have different additive components, and the engine may fail to perform as specified.)
- When the long-life coolant is mixed, do not employ any radiator cleaning agent. The long-life coolant contains anticorrosive agent. If mixed with the cleaning agent, sludge may build up, adversely affecting the engine parts.
 - The utility vehicle's genuine long-life coolant has a service life of 2 years. Be sure to change the coolant every 2 years.
 - Burp (remove air from) the coolant system as instructed in the Burping (Removing Air From) the Coolant System section.

Burping (Removing Air From) the Coolant System

To "burp" the coolant system, proceed as follows:

Note: When re-filling the coolant system, this procedure should be performed every time to avoid an overheating risk.

- Chock the rear wheel, engage the parking brake place the shift lever in NEUTRAL or PARK and jack up the front of the utility vehicle approximately 6".
- Remove the bleeder screw (a) on the radiator, fill the radiator and when fluid begins to come out of the bleeder screw hole, replace the bleeder screw (a). The bleeder screw (a) can be accessed via the front right wheel well. See Figure 5-25.




Figure 5-25

- Start the utility vehicle and let it idle.

- Remove the second bleeder screw (a) where the radiator hose (b) connects to the engine and let the engine run until a steady stream of fluid comes out of the bleeder screw (a) hole indicating there are no more air pockets in the coolant system. Replace the bleeder screw (a). See Figure 5-26.




Figure 5-26

- Top off the radiator and replace the radiator cap. Then lower the front of the utility vehicle off the jack.

Cleaning Primary Air Filter Element

Open the air cleaner cover once a week under ordinary conditions — or daily when used in a dusty place — to get rid of large particles of dust and dirt.

Note: Do not run the engine with filter element removed.

- Remove the air filter access panel.
- Remove the air filter cover (a) from the three air filter cover holders (b). See Figure 5-27.




Figure 5-27

- Remove the air filter element. See Figure 5-28.




Figure 5-28

- Remove the inner filter (a) from the paper element (b). See Figure 5-29.




Figure 5-29

- Clean the paper element with a soft brush or low pressure air. Be careful not to damage the paper pleats during cleaning.
- Inspect the inner filter for deposits or damage.
- If either filter are excessively dirty or damaged, replace filters as a set.
- Re-install the primary air filter element.
- Install the air filter case cover and be sure the crankcase breather hose is connected.

Note: Be sure to refit the air filter cover with the arrow (on the rear of air filter cover) upright. If the air filter cover is improperly fitted the evacuator valve will not function and dust will adhere to the air filter element.

Cleaning the Air Intake

Air Intake Screen

- Remove the hood and locate the air intake.
- Remove the rubber seal (b) around the front of the air intake (a) and remove the air intake screen (c). See Figure 5-30.




Figure 5-30

- Rinse the air intake screen (c) with water and replace the air intake screen (c) and rubber seal (b). See Figure 5-30.

Drain the Air Intake

1. Remove the nine Allen-head bolts (a) and washers (a) securing the middle skid plate to the bottom of the utility vehicle. See Figure 5-31.




Figure 5-31

2. Remove the drain and allow the water to run out (a). Then replace the drain and the middle skid plate. See Figure 5-32.




Figure 5-32

Check Fuel Line & Fuel Filter

⚠ WARNING

Be sure to stop the engine and remove the key. Check the fuel lines periodically. The fuel lines are subject to wear and old fuel may leak onto a running engine which may cause a fire.

The fuel line connections should be checked annually or every 100 service hours whichever comes first. The fuel line is made of rubber and wears regardless of service period.

Important! When the fuel line is disconnected for maintenance or repair, close both ends of the fuel line with a piece of clean cloth or paper to prevent dust and dirt from entering. Particular care must be taken not to allow dust and dirt into the fuel pump entrance. Even a small amount of dust or dirt can cause premature wear and the malfunction of the fuel pump and injector components.

1. Park the vehicle on a flat surface and remove the engine access panel. There is a primary fuel filter on the gas tank and an in-line fuel filter between the gas tank and the engine.
2. If the fuel line and clamps are damaged or deteriorated, replace them.

3. There are two main lines (a) coming into the primary fuel filter (b) and one main line (c) exiting the primary fuel filter (b). See Figure 5-33.




Figure 5-33

4. Check the fuel filter, if it is clogged by debris or contaminated with water, replace it.
5. To remove the in-line fuel filter clamps (b), slide the clamps (b) away from the in-line fuel filter (a). Twist and pull the fuel lines off of the in-line fuel filter (a). See Figure 5-34.




Figure 5-34

6. Check the in-line filter (a) for debris and/or water contamination. Replace as necessary.

Battery

Note: If you store a battery that is not completely charged, the battery may need to be replaced.

⚠ WARNING

Never remove the battery while the engine is running. Keep electrolyte away from eyes, hands, and clothes. If you are splattered with it, wash it away completely with water immediately and get medical attention. Wear eye protection and rubber gloves when working around the battery.

Note: The factory installed battery is the non-refillable type. If the battery is weak, charge or replace it.

Charging the Battery

⚠ WARNING

When the battery is being active, hydrogen and oxygen gases in the battery are extremely explosive. Keep open sparks and flames away from the battery at all times, especially when charging the battery. When disconnecting the cable from the battery start with the negative terminal; when connecting the cable to the battery start with the positive terminal. Always check battery charge by using a voltmeter.

1. To slow charge the battery connect the battery positive terminal to the charger positive terminal and the negative to the negative. Then recharge the battery normally.
2. A boost charge is only for emergencies, it will partially charge the battery as quickly as possible.
3. When exchanging an old battery for a new one, use a battery of equal specification. The battery type is a 12 volt battery with a minimum of 300 CCA.

Storing the Battery

When storing the vehicle for a long period, remove the battery and store in a dry place out of direct sunlight. The battery will self-discharge while it is stored. Recharge it once every three months in hot seasons and once every six months in cold seasons.

Adjusting Toe-In

1. Park utility vehicle on a flat surface.
2. Turn the steering wheel so that the front wheels are in the straight position.
3. Lock the parking brake and stop the engine.
4. Measure the distance between the center of the front tires at hub height on the front (a) and rear (b) of the tires. See Figure 5-35.




Figure 5-35

5. The front distance should be shorter than rear distance by 0-.47" (0-12 mm) (c). If not, adjust tie rod length.
 6. Loosen the lock nut and turn the inner tie rod to adjust the rod length until the proper toe-in measurement is obtained. Retighten the lock nut.
- Note:** Keep the length of the left and right tie-rods equal.

Cleaning the Spark Arrestor & Muffler

⚠ WARNING

Before touching any part of the exhaust system, be sure that it has had sufficient time to cool. Always wear safety goggles and face mask. The particulate matter contained in the muffler contains chemicals that are harmful to people, animals, and marine life. If you are unable to do this work, have it done by your dealer.

The spark arrestor (a) should be removed, inspected and cleaned every 100 hours of use. The spark arrestor (a) is located inside of muffler (b) body and fastened with bolts. See Figure 5-36.



1. Visually check the muffler for cracks or holes in the body, weldment or pipes at regular intervals.
2. USDA Forestry Division approval requires clearance between spark arrestor sleeve and muffler body to be no larger than 0.023" (0.584 mm).
3. Replace the entire muffler if it is damaged.
4. Do not operate the vehicle with a damaged muffler.

1. Check the bolts and nuts for looseness and tighten if necessary.
2. Apply grease to vehicle areas where bare metal will rust and also to pivot areas.
3. Unload from the cargo bed.
4. Inflate tires to 20 psi each.
5. Change the engine oil and run the engine to circulate oil throughout the engine block and internal moving parts for about 5 minutes.
6. With all implements lowered to the ground, coat any exposed rods with grease (if equipped).
7. Remove the battery from the vehicle. Store the battery following the battery storage procedures.
8. Keep the vehicle in a dry place where the vehicle is sheltered from the elements. Cover the vehicle.
9. Keep the vehicle indoors in a dry area that is protected from sunlight and excessive heat. If the vehicle must be stored outdoors, Cover it with a waterproof tarpaulin.

MAKE				SPECIFICATIONS
Engine	Type			1 cylinder, 4-cycle, gasoline, SOHC, liquid cooled
	Displacement		cc	546CC for 550UTV 735CC for 750UTV
	Horsepower		Kw (HP)	20.2 (27.1) for 550UTV 28.8 (38.6) for 750UTV
	Rated Revolution		rpm	5500 rpm for 550UTV 6000 for 750UTV
	Low Idling Revolution		rpm	1500 ±150
Fuel Capacity			L (U.S. gal.)	28 (7.4)
Oil Capacity			L (U.S. quart)	2.1 (2.22)
Transmission				CVT
Wheels, Drive System				4, Rear 2WD or 4WD
Differential Lock				Electronic Control, Switch
Gear Selection				H-L range FORWARD, NEUTRAL, REVERSE, PARK
Brakes	Front/Rear			Wet disc brake
	Parking Brake			Axis brake, hand braking
Steering				Manual (Electronic Power Steering Optional)
Dimensions	Length		mm (in.)	2960 (116.5)
	Width		mm (in.)	1540 (60.63)
	Height		mm (in.)	1950 (76.77)
	Front Tread Centers		mm (in.)	1310 (51.57)
	Rear Tread Centers		mm (in.)	1290 (50.79)
	Wheel Base		mm (in.)	1950 (76.77)
	Ground Clearance	Front axle	mm (in.)	295 (11.6)
		Rear Axle		330 (13.0)
Turning Diameter		m (ft.)	8.6 (28.22)	
Suspension	Front			Independent, Dual A-arm type
	Rear			Independent, Dual A-arm type
Max rolling weight (Towing capacity)			kg (lbs.)	544 (1200)
Payload capacity (Cargo Bed)			kg (lbs.)	227 (500)
Vehicle Curb Weight			kg (lbs.)	748 (1646)
Cargo Bed	Width		mm (in.)	1170 (46.06)
	Length		mm (in.)	900 (35.43)
	Depth		mm (in.)	280 (11)
	Volume		m ³ (cu. ft.)	0.29 (10.24)
	Bed height (Unloaded)		mm (in.)	810 (31.89)
	Cargo bed capacity (1 row/2 row)		kg (lbs.)	227 (500)
Sound level, operator ear			db (A)	86.5
Tire	Front			26 x 9.00-14NHS
	Rear			26 X 11.00-14NHS
Body Color				Black, yellow, camo

NOTE:

- The company reserves the right to change the specifications without notice.

Fuse Box




Figure 6-1

Traveling Speeds

550UTV

Range gear shift lever	km/h (mph)
Low	54.9 (34.1)
High	64.9 (40.3)
Reverse	20.9 (13.0)

750UTV

Range gear shift lever	km/h (mph)
Low	57 (35.4)
High	80 (49.7)
Reverse	40 (24.8)

Vehicle Limitations

The Vehicle has been thoroughly tested for proper performance with implements sold or approved by manufacturer. Use with implements which are not sold or approved and which exceed the maximum specifications listed below, or which are otherwise unfit for use on this vehicle, may result in vehicle malfunction or failures with a possibility of vehicle damage, property damage and injury to the operator or others. Any malfunctions or failures of the vehicle resulting from use with improper implements are not covered by the warranty.

Max cargo loading weight	
Cargo Bed Capacity = 227 kg (500 lb)	Max. rolling weight trailer
Vehicle Total Load Capacity = 453.5 kg (1000 lb)	544 kg (1200 lbs)
* (Operator + one passenger + opt + acc) weight + trailer weight	Max. tongue weight
	50 kg (110 lbs)

1. Above mentioned specifications are based on level ground condition.

CUB CADET LLC -- LIMITED WARRANTY

The limited warranty set forth herein is given by Cub Cadet LLC with respect to a new Cub Cadet® product (hereinafter "Product") purchased and used in the United States and/or Canada to the Initial Purchaser (as defined herein). This limited warranty does not cover Emission Control Systems and is not a Federal Emission Control Warranty Statement, as defined by U.S. federal law. Please refer to the Federal Emission Control Warranty Statement in the operator's manual for warranties covering Emission Control Systems.

Scope of the Limited Warranty

Cub Cadet LLC warrants that the Product (except with regard to the components and circumstances defined below as "Exclusions") will be free from defects in materials and workmanship during the Warranty Period, as defined below. For purposes of this limited warranty, the "Initial Purchaser" is the first person/company to purchase this new Product from an authorized Cub Cadet dealer, distributor, and/or retailer of such products, including a party for whom said Product was purchased as a gift. This limited warranty is non-transferrable. During the Warranty Period, Cub Cadet LLC will, at its option, either repair or replace any original part that is covered by this limited warranty and is determined to be defective in workmanship or material. "Commercial Use" shall be defined as any commercial, professional, agricultural, institutional, or income-producing use of the Product. See notes below as to Commercial Use Warranty.

Cub Cadet® Warranty Information	
Handheld Product*	Warranty Period
Chainsaws, Cultivators, Blowers, Brushcutters, Trimmers	3 Year
Wheeled Chore and Snow Product*	
Chipper-Shredders, Chipper-Shredder Vacuums, Blowers, Log Splitters, Snow Blowers	3 Year
Tillers, String Trimmers, Lawn Edgers, Pressure Washers CC3224, CC3425 & CC4033	3 Year†
Pressure Washers	2 Year†
Battery Powered Product	
60 Volt Max Product Series, CC30E, XT1 LT42E, ZT1 42E	3 Year†
60 Volt Max Product Series, CC30E, XT1 LT42E, ZT1 42E Batteries	4 Year†
Gas Powered Product	
Ultima ZTX Series	4 Year/500 hour (whichever comes first)
Z-Force SX	4 Year/500 hour (whichever comes first)
Walk-Behinds, Wide-Area Walk-Behinds, CC30 Riders, XT1 & XT2 Enduro Series, RZT S/SX, Ultima ZT Series, Z-Force S	3 Year†
23" Walk-Behinds, XT3 Enduro Series	4 Year†
Rotary Spreader	1 Year
Gas Blowers, PRO HW, PRO X-636	2 Year
PRO Z 500/700/900, PRO X-648/654/660, TANK LZ/SZ	3 Year
PRO Z 100 S	2 Year/NHL (No Hour Limit) or 4 Year/500 hour (whichever comes first)
Utility Vehicle*	
Challenger Series, Volunteer Series	1 Year

Additional Warranty Notes
Lead-Acid Batteries: Are covered by a one (1) year prorated limited warranty against defects in material and workmanship, with 100% replacement during the first three (3) months, from the date of original purchase by the Initial Purchaser. After three (3) months, the battery replacement credit is based on the months remaining in the twelve (12) month period, dating back to the date of original purchase by the Initial Purchaser. Any replacement battery will be warranted only for the remainder of the original warranty period.
Frames: The frame, chassis, and front axle on all XT1, XT2 and XT3 products are covered for "Residential Use" by a five (5) year limited warranty. The frame on all Ultima ZT and ZTX series products are covered for "Residential Use" by a seven year Limited Lifetime Warranty.
Mowing Decks: 1) Cub Cadet LLC warrants the mowing decks under the warranty of the product it came with unless otherwise stated. 2) When so equipped, the optional fabricated cutting deck shell (excluding wear parts, etc. thereon) shall be warranted against defects in material and workmanship for the lifetime of the product, namely for as long as it is owned by its Initial Purchaser or the party for whom it was originally purchased as a gift, or seven (7) years from the date of its initial sale to an Initial Purchaser, whichever comes first. 3) The deck shell, deck spindles, and deck steel pulleys (collectively the "Deck Assembly") on PRO Z 500 / 700 / 900 and PRO X-600 product only, shall also be warranted to be free from defects in material and workmanship for up to an additional two (2) years (a total of five (5) years from date of purchase) or 1,750 cumulative hours of operation, whichever comes first. For purposes of clarity, no hour limitation applies during the initial three (3) year period described above.
Snow Blowers: Three-Stage and Two-Stage (excluding 2X 24 models) - Auger gear boxes have a five (5) year limited warranty.
L and S Series: RZT L/LX, Z-Force L/LX/SZ, PRO Z 100 L, Z-Force Commercial (LZ/SZ), and Tank (L/S): Please refer to warranty included with Operator's Manual.
Attachments/Accessories: Please refer to warranty with Operator's Manual.
*Limited Commercial Use Warranty: Handheld products – 90 days; Chipper-Shredder Vacuums, Blowers, Log Splitters, Snow Blowers – 1 year; Utility Vehicle – 6 month.
† No Commercial Use Warranty: Tillers, String Trimmers, Lawn Edgers, Pressure Washers, Battery Powered Product, Walk Behind Mowers, 60 Volt Max Product Series, CC30 Riders, Enduro Series, RZT S/SX, Ultima ZT Series, and Z-Force.

The limited warranty is non-transferrable

How to Get Service Under This Limited Warranty

In order to qualify for the limited warranty, as set forth herein, the repairs made under this warranty must be performed by an authorized Cub Cadet service provider. To locate a Cub Cadet service provider, contact your authorized Cub Cadet dealer, distributor, or retailer, or contact Cub Cadet LLC at P.O. Box 368023, Cleveland, Ohio 44136-0019, or call 1-877-282-8684, or log on to our Website at www.cubcadet.com. For Canada, contact MTD Products Limited, 97 Kent Ave, Kitchener, ON N2G 3R2, or call 1-800-668-1238, or log on to our Website at www.cubcadet.ca. This limited product warranty is provided by Cub Cadet LLC and is the only product warranty provided by Cub Cadet LLC for the Product. A COPY OF YOUR SALES RECEIPT IS REQUIRED FOR WARRANTY SERVICE.

What This Limited Warranty Does Not Cover

This limited warranty does not cover the following (the "Exclusions"):

1. Product purchased outside of the United States or Canada.
2. Emission Control Systems. These items are subject to a separate warranty under the applicable Federal Emission Control Warranty Statement. Please refer to the applicable Federal Emission Control Warranty Statement for terms and conditions relating to Emission Control Systems.
3. Damage due to lack of maintenance and/or improper maintenance, as described in the operator's manual.
4. Normal wear and tear resulting from use of the Product.
5. Normal Wear Parts (as defined herein) are warranted to be free from defects in material and workmanship for a period of thirty (30) days from the date of original purchase by the Initial Purchaser for residential use, and for 30 days or 100 hours (whichever occurs first) for Product used commercially. Depending on Product, Normal Wear Parts include, but are not limited to items such as: belts, blades, blade adapters, grass bags, rider deck wheels, seats, shave plates, skid shoes, tines, filters, nozzles, hoses, O-rings, spray guns, wands, tires, spark plugs, fuses, bump knobs, outer spools, cutting line, inner belts, starter pulley, starter rope, drive belts, saw chains, guide bars, and other consumable items.
6. Log splitter pumps, valves, and cylinders are covered for a period of one (1) year.
7. Use of the product that is not consistent with the intended use thereof, as described in the operating instructions, including, but not limited to, abuse, misuse and/or neglect of the Product, or any use inconsistent with and/or non-compliant with instructions contained in the Operator's Manual. This includes operation in sandy and/or corrosive environments.
8. Any Product that has been altered or modified in a manner not consistent with the original design of the Product or in a manner not approved by Cub Cadet LLC.
9. Paint repairs or replacements for defective paint (including materials and application) are covered for a period of three (3) months.
10. Wheel rims (when so equipped) are covered for a period of three (3) months for manufacturing defects.

This warranty does not cover, and Cub Cadet LLC disclaims any responsibility for, matters including, but not limited to, the following:

1. Loss of time or loss of use of the Product.
2. Transportation costs and other expenses incurred in connection with the transport of the Product to and from the authorized Cub Cadet service provider.
3. Any loss or damage to other equipment or personal items.
4. Damages caused by improper maintenance or the use of other than the specified fuel, oil, or lubricants, as approved in the operator's manual.
5. Damage resulting from the installation or use of any accessory or part not approved by Cub Cadet LLC for use with the Product.

Limitations

1. THERE ARE NO IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. NO WARRANTY SHALL APPLY AFTER THE APPLICABLE WARRANTY PERIOD, AS SET FORTH ABOVE, AS TO THE PARTS AS IDENTIFIED. NO OTHER EXPRESS WARRANTY OR GUARANTY, WHETHER WRITTEN OR ORAL, EXCEPT AS MENTIONED ABOVE, GIVEN BY ANY PERSON OR ENTITY, INCLUDING A DEALER OR RETAILER, WITH RESPECT TO ANY, PRODUCT SHALL BIND CUB CADET LLC. DURING THE WARRANTY PERIOD, THE EXCLUSIVE REMEDY IS REPAIR OR REPLACEMENT OF THE DEFECTIVE PART, AS SET FORTH ABOVE. (SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU.)
2. THE PROVISIONS, AS SET FORTH HEREIN, PROVIDE THE SOLE AND EXCLUSIVE REMEDY ARISING FROM THE SALE. CUB CADET LLC SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL LOSS OR DAMAGES INCLUDING, WITHOUT LIMITATION, FOR TRANSPORTATION OR FOR RELATED EXPENSES, OR FOR RENTAL EXPENSES TO TEMPORARILY REPLACE A WARRANTED PRODUCT. (SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE EXCLUSION OR LIMITATION MAY NOT APPLY TO YOU.)
3. IN NO EVENT SHALL RECOVERY OF ANY KIND BE GREATER THAN THE AMOUNT OF THE PURCHASE PRICE OF THE PRODUCT SOLD. ALTERATION OF THE SAFETY FEATURES OF THE PRODUCT SHALL VOID THIS LIMITED WARRANTY. YOU ASSUME THE RISK AND LIABILITY FOR LOSS, DAMAGE, OR INJURY TO YOU AND YOUR PROPERTY, AND/OR TO OTHERS AND THEIR PROPERTY, ARISING OUT OF THE USE OR MISUSE OR INABILITY TO USE THE PRODUCT.
4. This limited warranty extends to the Initial Purchaser only and, except as otherwise stated herein, the applicable Warranty Period will begin on the original date of purchase of the Product. In the event that the original date of purchase of the Product is indeterminable, then the Warranty Period shall be established as beginning on the Product's date of manufacture, as determined by Cub Cadet LLC, and ending six (6) months after the applicable Product Warranty Period, as defined above. In no event shall a Product's warranty extend beyond the applicable Warranty Period.

How State Law Relates to This Warranty

This limited warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.