


Epson Stylus® CX4400 Series



Quick Guide

Basic Copying, Printing, and Scanning
Maintaining Your Epson Stylus CX4400 Series All-in-One
Solving Problems

Contents

Loading Paper	4
Using Special Papers	6
Copying a Photo or Document	7
Placing the Original on the Glass	7
Copying a Document	8
Copying a Photo	8
Printing From Your Computer	9
Printing in Windows	9
Printing with a Macintosh	11
Selecting the Correct Paper Type	14
Scanning a Photo or Document	15
Basic Scanning	15
Restoring and Correcting Photos	16
Maintaining Your All-in-One	17
Checking the Print Head Nozzles	17
Cleaning the Print Head	18
Checking the Ink Cartridge Status	19
Replacing Ink Cartridges	20
Solving Problems	25
Error Indicators	25
Problems and Solutions	26
Where To Get Help	28
Notices	29

Introduction

After you have set up your Epson Stylus® CX4400 Series all-in-one as described on the *Start Here* sheet, turn here to:

- Load paper
- Make a quick copy of a document or photo
- Get the basic steps for printing from your computer
- Scan a document or photo and restore or correct the color if necessary
- Perform routine maintenance
- Solve simple problems

This book tells you how to do most of these things without ever turning on your computer! Of course your all-in-one can do a lot more when you connect it to your Windows® or Macintosh® computer. For additional instructions, see the on-screen *User's Guide* by selecting the icon for it on your desktop.

Please follow these guidelines as you read your CX4400 Series instructions:

Warning:

Warnings must be followed carefully to avoid bodily injury.

Caution:

Cautions must be observed to avoid damage to your equipment.

Note:

Notes contain important information about your CX4400 Series.


Tip:

Tips contain hints for better copying, scanning, and printing.


Loading Paper

Follow these steps to load paper.


1. Open the paper support. Then open the output tray and pull out the extension.



2. Flip the feeder guard forward.




3. Press in the tab on the edge guide and slide it left.




4. Insert the paper, glossy or printable side up, against the right side.

Then slide the edge guide against the paper.



Letter-size plain paper



4 × 6-inch photo paper

Always load paper short edge first, even for landscape printing. Load letterhead or pre-printed paper top edge first.


You can load up to 80 sheets of plain paper and 20 sheets of photo paper. Load other special papers one sheet at a time.



Note:

The type of paper you choose affects the way your printout looks. If you are just making a copy or printing a rough draft of an image, plain paper is fine. However, for the best results, you'll want to use one of Epson's special ink jet papers designed for your printer. For example, your photos will look great printed on Epson Premium Photo Paper Glossy (see page 6 for more information).

5. Flip the feeder guard back.



Note:

For instructions on loading envelopes, see your on-screen *User's Guide*.

Using Special Papers

Epson offers a wide array of high quality papers, making it easy to maximize the impact of your photos, presentations, and creative projects.

You can purchase genuine Epson ink and paper from an Epson authorized reseller. To find the nearest reseller, call 800-GO-EPSON (800-463-7766). Or you can purchase online at www.epsonstore.com (U.S. sales) or www.epson.ca (Canadian sales).


Paper name	Size	Part number	Sheet count
Epson Ultra Premium Photo Paper Glossy	Borderless 4 × 6 inches	S041934	50
	Letter (8.5 × 11 inches)	S041935	20
Epson Premium Photo Paper Glossy	Borderless 4 × 6 inches	S041808 S041727	40 100
	Borderless 5 × 7 inches	S041464	20
	Borderless 8 × 10 inches	S041465	20
	Letter (8.5 × 11 inches)	S041286	20
		S041667	50
Epson Premium Photo Paper Semi-gloss	Borderless 4 × 6 inches	S041982	40
	Letter (8.5 × 11 inches)	S041331	20
Epson Photo Paper Glossy	Borderless 4 × 6 inches	S041809 S042038	50 100
		S041141 S041649 S041271	20 50 100
	Letter (8.5 × 11 inches)		
Epson Bright White Paper	Letter (8.5 × 11 inches)	S041586	500
Epson Premium Presentation Paper Matte	Borderless 8 × 10 inches	S041467	50
	Letter (8.5 × 11 inches)	S041257	50
Epson Premium Presentation Paper Matte Double-sided	Letter (8.5 × 11 inches)	S041568	50
Epson Presentation Paper Matte	Letter (8.5 × 11 inches)	S041062	100
	Legal (8.5 × 14 inches)	S041067	100
Epson Photo Quality Self-Adhesive Sheets	A4 (8.3 × 11.7 inches)	S041106	10
Epson Iron-On Cool Peel Transfer Paper	Letter (8.5 × 11 inches)	S041153	10

Copying a Photo or Document

Follow the instructions in this section to position your originals correctly on the glass and make color or black and white copies.


Placing the Original on the Glass

1. Open the document cover and place your original face-down on the glass, in the front right corner.



Move the photo or document slightly away from the edges.

2. Close the cover gently so you don't move the original.



Copying a Document

You can copy documents using your all-in-one, just like you would on a copy machine.

1. Load up to 80 sheets of letter-size plain paper or Epson Bright White Paper (see page 4 if you need instructions).
2. Place the document on the glass as described on page 7. Be sure to close the document cover.
3. Do one of the following:
 - To make a color copy, press the  **Color Text** button. To make a black and white copy, press the  **B&W Text** button.
 - To enlarge your document to fit on the paper you loaded, press and hold either the  **Color Text** or  **B&W Text** button for 3 seconds
 - To print a quick draft copy, press and hold the  **Stop** button as you press either the  **Color Text** or  **B&W Text** button.



If you need to stop copying, press the  **Stop** button. Do not pull out paper that is being printed; it will be ejected automatically to the output tray. Copies may not be exactly the same size as the original.

Copying a Photo

You can make borderless 4 × 6-inch copies of your color photos.

1. Load up to 20 sheets of 4 × 6-inch Epson photo paper. See page 6 for a list of Epson photo papers and other special papers.
2. Place the photo on the glass as described on page 7. Be sure to close the document cover.
3. Press the  **Color Photo** button.

Your photo is printed and automatically reduced to fit on the 4 × 6-inch paper (if necessary).

Printing From Your Computer

This section describes the basic steps for printing a photo or document stored on your Windows or Macintosh computer. For detailed instructions on printing, see the on-screen *User's Guide*.

Before you start, make sure you've installed your printer software and connected the all-in-one to your computer as described on the *Start Here* sheet.


Tip:

Periodically, it's a good idea to check Epson's support website at epson.com/support for free updates to your Epson Stylus CX4400 Series printer and scanner software. Download instructions are posted for your convenience.

With Windows, you can also click **Start** or , select **Programs** or **All Programs**, select **EPSON**, and click **EPSON Stylus CX4400 Series Driver Update**. For scanner driver updates, click **Start** or , select **Programs** or **All Programs**, select **EPSON**, select **EPSON Scan**, and click **EPSON Stylus CX4400 Series Scanner Driver Update**.

Printing in Windows

1. Load paper (see page 4).
2. Open a photo or document in a printing program.
3. Open the File menu and select **Print**. You see a window like this one:



4. Make sure **Epson Stylus CX4400 Series** is selected, then click the **Preferences** or **Properties** button.


(If you see a **Setup**, **Printer**, or **Options** button, click it. Then click **Preferences** or **Properties** on the next screen.) Your printer setting window opens.

5. On the **Main** tab, select the basic print settings:

Select the type of document you're printing
(choose **Photo** or **Best Photo** for pictures)

Select your
paper **Type**

Select your
paper **Size**



Click here for
borderless photos

Select your
document
Orientation


Make sure you choose the correct paper **Type** setting for the paper you are using (see page 14 for details).

6. If you want to reduce or enlarge your printout or print double-sided, click the **Page Layout** tab and select settings as necessary.
7. For more printing options, click the **Advanced** tab.

Note:


For more information about print settings, or instructions on saving them as a group so you can reuse them later, click ? or **Help**.

- Click **OK** to save your settings, then click **OK** or **Print** to start printing. This window appears and shows the progress of your print job.



Printing with a Macintosh


- Load paper (see page 4).
- Open a photo or document in a printing program.
- Select **Page Setup** from the File menu. Make the following settings:




* For borderless printing, choose a **Sheet Feeder - Borderless** option in the Paper Size list for your paper size (US Letter, 8 x10 in, 4 x6 in, or 5 x7 in).

- Click **OK** to close the Page Setup window.

5. Select **Print** from the File menu. You see a window like this one:



6. Choose **Print Settings** from the pop-up menu and select the following settings as necessary:



Note:

In certain programs, you may need to select **Advanced** before you can select **Print Settings**. For more information about printer settings, click the ? button.

7. Depending on your settings, you can choose other options from the pop-up menu, including:
- **Copies & Pages:** Select the number of copies you want, or a page range.
 - **Layout:** Print multiple pages per sheet or two-sided documents.
 - **Scheduler:** Schedule your print job to print at a later time.
 - **Paper Handling:** Select page printing options, such as **Reverse print order**.

- **ColorSync or Color Management:** Select ColorSync® or adjust the color controls, change the gamma setting, or turn off color adjustments in the printer software.
- **Expansion:** Reduce or enlarge the image size for borderless printing.
- **Summary:** View a list of all your selections.

8. Click the **Advanced** button to change additional settings.

Note:


For more information on advanced settings, or instructions on saving them as a group so you can reuse them later, click ?.

9. Click **Print**.

10. To monitor the progress of your print job, click the  printer icon when it appears in the dock on the bottom of your desktop.

If you're using OS X 10.2.x, click the  Print Center icon instead, then double-click **Stylus CX4400** in the Printer List window.

You see a screen like this:



11. When you're finished, close the printer window or Print Center.

Selecting the Correct Paper Type

Select the correct **Type** (see page 10) or **Media Type** (see page 12) setting in your printer software. This tells the CX4400 Series what kind of paper you're using, so the ink coverage can be adjusted accordingly.

For this paper	Select this setting
Plain paper Epson Bright White Paper Epson Presentation Paper Matte	Plain Paper/Bright White Paper
Epson Ultra Premium Photo Paper Glossy	Ultra Premium Photo Paper Glossy
Epson Premium Photo Paper Glossy	Premium Photo Paper Glossy
Epson Photo Paper Glossy	Photo Paper Glossy
Epson Premium Photo Paper Semi-gloss	Premium Photo Paper Semi-gloss
Epson Premium Presentation Paper Matte Epson Premium Presentation Paper Matte Double-sided Epson Photo Quality Self-Adhesive Sheets Epson Iron-On Cool Peel Transfer Paper	Premium Presentation Paper Matte
Envelopes	Envelope

Scanning a Photo or Document

You can use your CX4400 Series all-in-one to scan a photo or document and save it on your computer or other device, or to fax or e-mail it to someone else.

You can even restore and correct photographs as you scan (see page 16).

The Epson Scan software provides three scanning modes:

- **Full Auto Mode** scans quickly and easily using automatic settings.
- **Home Mode** previews your image and provides preset options for scanning.
- **Professional Mode** previews your image and provides a full array of tools.

Basic Scanning

You can scan from any TWAIN-compliant application—such as ArcSoft PhotoImpression™—using Epson Scan. Or you can start Epson Scan directly from your computer and save your image to a file.

1. Open the document cover and place your original face-down on the glass, in the front right corner, as shown on page 7.

Move the photo or document slightly away from the edges. To scan multiple photos, leave at least 0.8 inch between them.


2. Close the cover gently so you don't move the original.
3. Do one of the following to start Epson Scan:
 - **Windows:** Double-click the EPSON Scan icon on your desktop.
 - **Macintosh:** Double-click EPSON Scan in the Applications folder.
 - If you are scanning from an application, start your application. Then open the File menu, choose **Import** or **Acquire**, and select **Epson Stylus CX4400 Series**.

You see the Epson Scan standby window:

4. If the Mode setting in the upper right corner is set to **Full Auto Mode**, click the **Scan** button.

If you are in Home or Professional Mode, you see a different Epson Scan settings window. (You can change the mode using the Mode selector in the upper right corner.)

5. If you want to restore faded color in a photo or change settings, click **Customize**. Then follow the instructions below.
6. Click **OK**. The image is scanned and you see its icon in Windows Explorer or Macintosh Finder.




Restoring and Correcting Photos

You can automatically transform a faded, dusty, or badly exposed color photo into one with true-to-life color and sharpness as you scan. Use the **Color Restoration** and **Dust Removal** options in Epson Scan's Full Auto mode. In Home and Professional Mode, you can also select **Backlight Correction** to remove shadows from images with too much background light.

Full Auto Mode

Click the **Customize** button, click **Dust Removal** and/or **Color Restoration**, click **OK**, and click **Scan**.



Note:

For more information, see the on-screen *User's Guide*. You can also click **Help** on the Epson Scan screen for information about all the available settings.


Maintaining Your All-in-One

Follow the instructions in this chapter for checking and cleaning the print head nozzles and replacing ink cartridges.

Checking the Print Head Nozzles

If your printouts are faint or have gaps in them, some of the nozzles in the print head may be clogged or ink may be running low in one or more of the ink cartridges. Follow the steps below to check the print head nozzles.

1. Turn off the all-in-one.
2. Load letter-size paper in the sheet feeder.
3. Hold down the  Stop button as you press the  On button. Hold down both buttons until the  On light begins to flash, then release the buttons.



4. Check the nozzle check pattern that prints to see if there are gaps in the lines.



Nozzles are clean



Nozzles need cleaning

5. If there are no gaps, the print head is clean and you can continue printing.
If there are gaps or the pattern is faint, clean the print head (see page 18).


Cleaning the Print Head

If print quality has declined and the nozzle check pattern indicates clogged nozzles, you can clean the print head.

Note:

Print head cleaning uses ink, so clean it only if necessary. If the red  ink light comes on or flashes, you cannot clean the print head. In this case, replace the appropriate ink cartridge first (see page 20).

1. Make sure the all-in-one is on and the  ink light is off.
2. Hold down the  **Stop** button for at least 3 seconds until the  **On** light starts flashing. The all-in-one runs a head cleaning cycle, which takes about one minute.



Caution:

Never turn off the CX4400 Series during head cleaning or you may damage it.

3. When the  **On** light stops flashing, run a nozzle check (as described on page 17) to verify that the print head is clean.
4. If there are still gaps or lines, or the test patterns are faint, run another cleaning cycle and check the nozzles again.

Note:

If you don't see any improvement after cleaning the print head two times, turn off your all-in-one and wait at least six hours to let any dried ink soften. Then try printing again.

If you do not use your all-in-one often, it is a good idea to print a few pages at least once a month to maintain good print quality.

Checking the Ink Cartridge Status

When the red  ink light starts flashing, one or more cartridges are low on ink. You can continue printing until a cartridge needs replacement. When the red  ink light stays on, you need to replace the cartridge(s).

Note:

Yields vary considerably based on images printed, print settings, paper type, frequency of use, and temperature. For print quality, a variable amount of ink remains in the cartridge after the “replace cartridge” indicator comes on.

The printer ships with full cartridges and part of the ink from this first set of cartridges is used for charging the printer.

A window may also appear on your computer screen when you try to print when ink is low. This window can optionally display ink offers and other updates retrieved from an Epson web site. On a Windows computer that is connected to the Internet, you may see a screen asking if you want to receive these Epson offers the first time you try to print when ink is low. Click **Accept** or **Decline** to continue.

Note:

To disable checking for ink offers or updates from Epson, see the instructions in your on-screen *User's Guide*.

If a cartridge is more than six months old, print quality may decline. If necessary, try cleaning the print head (see page 18). If printouts still do not look their best, you may need to replace the cartridge.

Order or purchase these new ink cartridges: 88 Black, 88 Cyan, 88 Magenta, or 88 Yellow. You can purchase genuine Epson ink and paper from an Epson authorized reseller. To find the nearest reseller, call 800-GO-EPSON (800-463-7766). Or you can purchase online at www.epsonstore.com (U.S. sales) or www.epson.ca (Canadian sales).

Note:

You cannot print or copy when an ink cartridge is expended even if the other cartridges are not expended. Replace any expended cartridges before printing or copying.

We recommend that you use genuine Epson cartridges and do not refill them. The use of other products may affect your print quality and could result in printer damage.

Leave the expended cartridge installed until you have obtained a replacement, or the ink remaining in the print head nozzles may dry out.

If you remove an expended ink cartridge or a cartridge after the low ink message appears, you cannot reinstall and use the cartridge.


Replacing Ink Cartridges

Make sure you have a new ink cartridge before you begin. You must install new cartridges immediately after removing the old ones.

Caution:


Do not open ink cartridge packages until you are ready to install the ink. Cartridges are vacuum packed to maintain reliability.

1. Make sure the all-in-one is on and the red  ink light is on but not flashing.
2. Open the scanner and make sure its support locks in place.




Caution:

Do not touch any area shown below.




3. Press the  **Stop** button. The print head moves to the  position to indicate which cartridge is low or expended.




Caution:

Do not move the print head by hand; this may damage your all-in-one. Always press and release the  **Stop** button to move it.


4. Press the  **Stop** button again.
 - If another cartridge is low or expended, it moves to the  position. Press the  **Stop** button again to see if any more cartridges are low or expended.
 - If no other cartridges are low or expended, the print head moves to the replacement position.



5. Open the cartridge cover.



6. Squeeze the tab on the cartridge and lift it up. Dispose of it carefully. Do not take the used cartridge apart or try to refill it.



Warning:

If ink gets on your hands, wash them thoroughly with soap and water. If ink gets into your eyes, flush them immediately with water. Keep ink cartridges out of the reach of children.


7. Before you open the new cartridge package, shake it four or five times. Then remove it from the package.

Caution:


Do not touch the green chip on the front of the cartridge. This can damage the ink cartridge.

Note:

For best printing results, use up a cartridge within six months of opening the package.



8. Remove the yellow tape from the bottom of the ink cartridge.




Caution:


Do not remove any other labels or seals, or ink will leak.




9. Insert the new ink cartridge into the holder and push it down until it clicks into place.



10. Once you replace all the cartridges that need replacing, close the cartridge cover and push it down until it clicks into place.



11. Hold the scanner while you release the support. Then close the scanner.



Caution:

Do not try to close the scanner without releasing the support, or you might damage the CX4400 Series.

12. Press the **Stop** button to begin charging the ink. This takes about one and a half minutes. When it's finished, the **On** light stops flashing and remains on, and the **ink** light goes out.

Caution:

Never turn off the CX4400 Series while the **On** light is flashing or you'll waste ink. If the **ink** light flashes, press the **Stop** button and press down all the cartridges securely.

Note:

If you replaced a cartridge while copying a document or photo, cancel printing and make sure your original is still placed correctly on the document table. Then copy your original again.

Solving Problems

If you have a problem with your all-in-one, check the lights on the control panel to diagnose the cause.

You can also check “Problems and Solutions” on page 26 for basic troubleshooting suggestions, or double-click the *User’s Guide* icon on your computer desktop for more detailed help.

Error Indicators

Light status	Cause	Solution
⏻ On light Flashing	If the other lights are off, your all-in-one may be in sleep mode.	Press any button (except the ⏻ On button) to wake up the all-in-one.
📄 paper light on	Paper is out.	Load more paper, as described on page 4.
📄 paper light flashing	Paper is jammed.	Carefully remove the jam, as described on page 26.
💧 ink light flashing	One or more cartridges are low on ink.	Check ink cartridge status to determine which cartridge(s) are low, as described on page 19.
💧 ink light on	One or more ink cartridges are expended or not installed correctly.	Replace the cartridge(s) as described on page 20.
All lights are on	A part needs to be replaced.	Contact Epson for help; see page 28.
All lights are flashing	There is a problem with your all-in-one.	Turn your all-in-one off, wait a moment, and then turn it back on. If the error does not clear, contact Epson for help; see page 28.

Problems and Solutions

Check the solutions below if you're having trouble using your Epson Stylus CX4400 Series all-in-one.

Printing and Copying Problems

- If one of the Copy buttons don't work, your all-in-one may be in sleep mode. Press the button again to copy.
- Make sure your original is positioned in the front right corner of the glass. If the edges are cropped, move your original away from the edges slightly.
- Make sure your paper is loaded short edge first and is positioned against the right side with the edge guide against its left side. Don't load paper above the arrow mark inside the edge guide.
- Make sure the paper size settings are correct for the paper you loaded.

Paper Feeding Problems

- If paper doesn't feed, remove it from the sheet feeder. Flip through the stack to separate the sheets a little. Then reload the paper against the right side, and slide the edge guide against the paper (but not too tightly).
- Do not load too many sheets at once—up to 20 sheets of photo paper and 80 sheets of plain paper. Load other special papers one sheet at a time.
- If paper is jammed, follow these steps:
 1. Press one of the  Copy buttons to eject the jammed paper.
 2. If paper is still jammed, gently pull it out from the output tray or sheet feeder.
 3. If the paper is stuck inside, press the  On button to turn it off. Then open the scanner, remove the jammed paper and torn pieces, close the scanner, and turn the all-in-one back on.
 4. If the  paper light is still flashing, press the  On button and the  Color Photo button to clear the error.

Print Quality Problems

If you have any problems with the copy or print quality, try these solutions:

- Make sure the document is placed flat against the document table glass and the all-in-one is not tilted or placed on an uneven surface.
- Load the paper printable side up (usually the whiter, brighter, or glossy side).
- Make sure your paper isn't damp or curled.
- Use a support sheet with special paper or load your paper one sheet at a time. Remove sheets from the output tray so not too many collect at a time.
- Make sure the type of paper you loaded matches the paper size and paper type settings in your printer software (see page 14).
- For the best print quality, use Epson special paper (see page 6) and genuine Epson ink cartridges (see page 20).
- If you notice light or dark bands across your printouts or they are too faint, you may need to clean the print head. This unclogs the nozzles so they can deliver ink properly. Run a nozzle check as described on page 17 to see if the print head needs cleaning.
- Clean the print head as described on page 18.
- If you notice jagged vertical lines, you may need to align the print head. See your *User's Guide* for instructions.
- The ink cartridges may be low on ink (see page 20 for instructions on replacing an ink cartridge).
- If a dotted line appears in the image, clean the scanner glass with a soft, dry, lint-free cloth (paper towels are not recommended), or use a small amount of glass cleaner on a soft cloth, if necessary. Do not spray glass cleaner directly on the glass.

Where To Get Help

Epson Technical Support

Epson provides these technical support services:

Internet Support

Visit Epson's support website at epson.com/support and select your product for solutions to common problems. You can download drivers and documentation, get FAQs and troubleshooting advice, or e-mail Epson with your questions.

Speak to a Support Representative

Before you call Epson for support, please have the following information ready:

- Product name (Epson Stylus CX4400 Series)
- Product serial number (located on the label in back)
- Proof of purchase (such as a store receipt) and date of purchase
- Computer configuration
- Description of the problem

Then call:

- U.S.: (562) 276-4382, 6 AM to 6 PM, Pacific Time, Monday through Friday.
- Canada: (905) 709-3839, 6 AM to 6 PM, Pacific Time, Monday through Friday.

Toll or long distance charges may apply.

Purchase Supplies and Accessories

You can purchase genuine Epson ink and paper from an Epson authorized reseller. To find the nearest reseller, call 800-GO-EPSON (800-463-7766). Or you can purchase online at www.epsonstore.com (U.S. sales) or www.epson.ca (Canadian sales).

Other Software Technical Support

ArcSoft PhotoImpression: (510) 440-9901

Fax: (510) 440-1270; Web: www.arcsoft.com; E-mail: support@arcsoft.com

Notices

Important Safety Instructions

Before using your Epson Stylus CX4400 Series all-in-one, read and follow these safety instructions:

- Be sure to follow all warnings and instructions marked on the CX4400 Series.
- Use only the type of power source indicated on the CX4400 Series label.
- Use only the power cord that comes with the CX4400 Series. Use of another cord may cause fires or shock. Do not use the cord with any other equipment.
- Place the CX4400 Series near a wall outlet where the plug can be easily unplugged.
- Do not let the power cord become damaged or frayed.
- If you use an extension cord with the CX4400 Series, make sure the total ampere rating of the devices plugged into the extension cord does not exceed the cord's ampere rating. Also, make sure the total ampere rating of all devices plugged into the wall outlet does not exceed the wall outlet's ampere rating.
- Avoid locations that are subject to rapid changes in heat or humidity, shocks or vibrations, or dust.
- Leave enough room around the CX4400 Series for sufficient ventilation. Do not block or cover openings in the CX4400 Series case or insert objects through the slots.
- Do not place the CX4400 Series near a radiator or heating vent or in direct sunlight.
- Place the CX4400 Series on a flat, stable surface that extends beyond its base in all directions. It will not operate properly if it is tilted or at an angle.
- Make sure the back of the CX4400 Series is at least 4 inches (10 cm) away from the wall.
- Do not open the scanner section while the CX4400 Series is copying, printing, or scanning.
- Do not spill liquid on the CX4400 Series.
- Except as specifically explained in your documentation, do not attempt to service the CX4400 Series yourself.

- Unplug the CX4400 Series and refer servicing to qualified service personnel under the following conditions: if the power cord or plug is damaged; if liquid has entered the product; if the product has been dropped or the case damaged; if the product does not operate normally or exhibits a distinct change in performance. Adjust only those controls that are covered by the operating instructions.
- When storing or transporting the CX4400 Series, do not tilt it, stand it on its side, or turn it upside down; otherwise ink may leak from the cartridges.

Ink Cartridge Safety Instructions

- Keep ink cartridges out of the reach of children and do not drink the ink.
- Be careful when you handle used ink cartridges; there may be ink remaining around the ink supply port. If ink gets on your skin, wash it off with soap and water. If it gets in your eyes, flush them immediately with water.
- Do not put your hand inside the CX4400 Series or touch any cartridges during printing.
- Install a new ink cartridge immediately after removing an expended one. Leaving cartridges uninstalled can dry out the print head and may prevent the CX4400 Series from printing.
- If you remove an ink cartridge for later use, protect the ink supply area from dirt and dust and store it in the same environment as the CX4400 Series. Note that there is a valve in the ink supply port, making covers or plugs unnecessary, but care is needed to prevent the ink from staining items that the cartridge touches. Do not touch the ink cartridge ink supply port or surrounding area.

FCC Compliance Statement

For United States Users

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio and television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING

The connection of a non-shielded equipment interface cable to this equipment will invalidate the FCC Certification of this device and may cause interference levels which exceed the limits established by the FCC for this equipment. It is the responsibility of the user to obtain and use a shielded equipment interface cable with this device. If this equipment has more than one interface connector, do not leave cables connected to unused interfaces. Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

For Canadian Users

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Declaration of Conformity

According to 47CFR, Part 2 and 15 for: Class B Personal Computers and Peripherals;
and/or CPU Boards and Power Supplies used with Class B Personal Computers:

We: Epson America, Inc.
Located at: MS 3-13
3840 Kilroy Airport Way
Long Beach, CA 90806
Telephone: (562) 290-5254

Declare under sole responsibility that the product identified herein, complies with 47CFR Part 2 and 15 of the FCC rules as a Class B digital device. Each product marketed is identical to the representative unit tested and found to be compliant with the standards. Records maintained continue to reflect the equipment being produced can be expected to be within the variation accepted, due to quantity production and testing on a statistical basis as required by 47CFR §2.909. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Trade Name: Epson
Type of Product: Multifunction printer
Model: C331A

Epson America, Inc., Limited Warranty

What Is Covered: Epson America, Inc. (“Epson”) warrants to the original retail purchaser that the Epson printer covered by this limited warranty statement, if purchased and operated only in the United States or Canada, will be free from defects in workmanship and materials for a period of one (1) year from the date of original purchase. For warranty service, you must provide proof of the date of original purchase.

What Epson Will Do To Correct Problems: Should your Epson printer prove defective during the warranty period, please call the Epson ConnectionSM at (562) 276-4382 (U.S.) or (905) 709-3839 (Canada) for warranty repair instructions and return authorization. An Epson service technician will provide telephone diagnostic service to determine whether the printer requires service. If service is needed, Epson will, at its option, exchange or repair the printer without charge for parts or labor. If Epson authorizes an exchange for the defective unit, Epson will ship a replacement printer to you, freight prepaid, so long as you use an address in Canada or the U.S. (excluding Puerto Rico and U.S. Possessions). Shipments to other locations will be made freight collect. You are responsible for securely packaging the defective unit and returning it to Epson within five (5) working days of receipt of the replacement. Epson requires a debit or a credit card number to secure the cost of the replacement printer in the event that you fail to return the defective one. If your printer is being repaired, Epson will direct you to send your printer to Epson or its authorized service center, where the printer will be fixed and sent back to you. You are responsible for packing the printer and for all costs to and from the Epson authorized service center. When warranty service involves the exchange of the printer or a part, the item replaced becomes Epson property. The replacement printer or part may be new or refurbished to the Epson standard of quality, and, at Epson’s option, may be another model of like kind and quality. Epson’s liability for replacement of the covered printer will not exceed the original retail selling price of the covered printer. Exchange products and parts assume the remaining warranty period of your original product covered by this limited warranty.

What This Warranty Does Not Cover: This warranty does not apply to refurbished or reconditioned products. This warranty covers only normal use in the United States and Canada. Using this product for continuous production or similar high duty purposes is not considered normal use; damage, maintenance or service from such use will not be covered under this warranty. This warranty is not transferable. This warranty does not cover any color change or fading of prints or reimbursement of materials or services required for reprinting. This warranty does not cover damage to the Epson product caused by parts or supplies not manufactured, distributed or certified by Epson. This warranty does not cover ribbons, ink cartridges or third party parts, components, or peripheral devices added to the Epson product after its shipment from Epson, e.g., dealer or user-added boards or components. Epson is not responsible for warranty service should the Epson label or logo or the rating label or serial number be removed or should the product

fail to be properly maintained or fail to function properly as a result of misuse, abuse, improper installation, neglect, improper shipping, damage caused by disasters such as fire, flood, and lightning, improper electrical current, software problems, interaction with non-Epson products, or service other than by an Epson Authorized Servicer. If a claimed defect cannot be identified or reproduced, you will be held responsible for the costs incurred.

THE WARRANTY AND REMEDY PROVIDED ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER EXPRESS OR IMPLIED WARRANTIES INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE. SOME LAWS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES. IF THESE LAWS APPLY, THEN ALL EXPRESS AND IMPLIED WARRANTIES ARE LIMITED TO THE WARRANTY PERIOD IDENTIFIED ABOVE. UNLESS STATED HEREIN, ANY STATEMENT OR REPRESENTATIONS MADE BY ANY OTHER PERSON OR FIRM ARE VOID. EXCEPT AS PROVIDED IN THIS WRITTEN WARRANTY, NEITHER EPSON AMERICA, INC. NOR ITS AFFILIATES SHALL BE LIABLE FOR ANY LOSS, INCONVENIENCE, OR DAMAGE, INCLUDING DIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES, RESULTING FROM THE USE OR INABILITY TO USE THE EPSON PRODUCT, WHETHER RESULTING FROM BREACH OF WARRANTY OR ANY OTHER LEGAL THEORY.

In Canada, warranties include both warranties and conditions.

Some jurisdictions do not allow limitations on how long an implied warranty lasts, and some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations and exclusions may not apply to you. This warranty gives you specific legal rights and you may have other rights which vary from jurisdiction to jurisdiction.

To find the Epson Authorized Reseller nearest you, visit our website at:
<http://www.epson.com>.

To find the Epson Customer Care Center nearest you, visit: epson.com/support.

You can also write to: Epson America, Inc., P.O. Box 93012, Long Beach, CA 90809-3012

Copyright Notice

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of Seiko Epson Corporation. The information contained herein is designed only for use with this Epson product. Epson is not responsible for any use of this information as applied to other equipment.

Neither Seiko Epson Corporation nor its affiliates shall be liable to the purchaser of this product or third parties for damages, losses, costs, or expenses incurred by purchaser or third parties as a result of: accident, misuse, or abuse of this product or unauthorized modifications, repairs, or alterations to this product, or (excluding the U.S.) failure to strictly comply with Seiko Epson Corporation's operating and maintenance instructions.

Seiko Epson Corporation shall not be liable for any damages or problems arising from the use of any options or any consumable products other than those designated as Original Epson Products or Epson Approved Products by Seiko Epson Corporation.

Responsible Use of Copyrighted Materials

Epson encourages each user to be responsible and respectful of the copyright laws when using any Epson product. While some countries' laws permit limited copying or reuse of copyrighted material in certain circumstances, those circumstances may not be as broad as some people assume. Contact your legal advisor for any questions regarding copyright law.

Trademarks

Epson and Epson Stylus are registered trademarks and Exceed Your Vision is a trademark of Seiko Epson Corporation.

Epson Connection is a service mark of Epson America, Inc.



General Notice: Other product names used herein are for identification purposes only and may be trademarks of their respective owners. Epson disclaims any and all rights in those marks.

© 2007 Epson America, Inc. 5/07



411052000

CPD-23606R1
Printed in XXXXXX XX.XX-XX XXX