

EPSON Stylus® Pro 9000 Series

PRINTER GUIDE

EPSON®



Printed on recycled paper.

Copyright © 2000 by Epson America, Inc.

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of SEIKO EPSON CORPORATION. The information contained herein is designed only for use with these EPSON printers. EPSON is not responsible for any use of this information as applied to other printers.

Trademarks

EPSON, EPSON Stylus, ESC/P, and Micro Piezo are registered trademarks of SEIKO EPSON CORPORATION.

DX3, PhotoEnhance, SelecType, and EPSON Archival are trademarks and EPSON Preferred is a service mark of Epson America, Inc.

EFI, the EFI logo, Fiery, and the Fiery logo are U.S. registered trademarks of Electronics for Imaging, Inc.

General Notice: Other product names used herein are for identification purposes only and may be trademarks of their respective owners. EPSON disclaims any and all rights in those marks.

The ENERGY STAR emblem does not represent EPA endorsement of any product or service.

Legal Notices

Neither SEIKO EPSON CORPORATION nor its affiliates shall be liable to the purchaser of this product or third parties for damages, losses, costs, or expenses incurred by purchaser or third parties as a result of: accident, misuse, or abuse of this product or unauthorized modifications, repairs, or alterations to this product, or (excluding the U.S.) failure to strictly comply with SEIKO EPSON CORPORATION's operating and maintenance instructions.

SEIKO EPSON CORPORATION shall not be liable for any damages or problems arising from the use of any options or any consumable products other than those designated as Original EPSON Products or EPSON Approved Products by SEIKO EPSON CORPORATION.

FCC Compliance Statement

For United States Users

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio and television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING

The connection of a non-shielded equipment interface cable to this equipment will invalidate the FCC Certification of this device and may cause interference levels which exceed the limits established by the FCC for this equipment. It is the responsibility of the user to obtain and use a shielded equipment interface cable with this device. If this equipment has more than one interface connector, do not leave cables connected to unused interfaces. Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

For Canadian Users

This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Cet appareil numérique de la classe B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

Contents

Introduction

How To Use Your Manuals	2
Using This <i>Printer Guide</i>	3
Warnings, Cautions, and Notes	4
Where To Get Help	4
ENERGY STAR Compliance	5
Important Safety Instructions	6
Ink Cartridge Safety Instructions	7

1 Handling Paper and Other Media

Selecting Paper and Other Media	1-1
Printing on EPSON Paper and Other Media	1-2
Printing Tips for EPSON Media	1-4
Using Roll Paper	1-4
Attaching Paper to the Spindle	1-5
Removing Paper from the Spindle	1-6
Inserting the Spindle in the Printer	1-7
Loading Roll Paper for Printing	1-10
Cutting Paper Manually with the Built-in Cutter	1-13
Cutting Canvas and Other Media with the Utility Cutter	1-14
Printing Trim Lines	1-15
Using Cut Sheet Paper	1-15
Using Cut Sheet Paper Longer than 19 Inches	1-17
Printing on Posterboard	1-18
Adjusting the Platen Gap for Heavy Stock	1-20
Using the Paper Hammock	1-21
Catching Printouts in Front of the Printer	1-21
Catching Printouts Under the Printer	1-24
Setting Paper Configurations	1-25
Registering Paper Thickness, Drying Time, and Suction	1-25
Selecting Registered Paper Settings	1-26

2 Monitoring and Configuring the Printer

Using the Control Panel to Monitor the Printer	2-1
Monitoring Normal Printer Operation	2-2
Pausing and Resetting the Printer	2-2
Checking Printer Status	2-2
Printing a Status Check	2-3
Printing a Nozzle Check	2-3
Checking Ink Levels and Component Life	2-4
Responding to Control Panel Lights and Messages	2-5
Using the Control Panel to Configure the Printer	2-8
Setting Default Roll Paper Margins	2-8
Turning Off Paper Monitoring Features	2-9
Selecting the Printer's Interface	2-9
Configuring the Parallel Interface	2-10
Changing the Printer's Code Page Setting	2-11
Restoring Default Settings	2-11
Setting the Control Panel Language	2-12

3 Maintaining and Transporting the Printer

Running a Nozzle Check	3-1
Running a Cleaning Cycle	3-2
Aligning the Print Head	3-3
Printing the Alignment Patterns	3-3
Completing the Alignment Procedure	3-5
Replacing Ink Cartridges	3-7
Replacing the Paper Cutter Blade	3-11
Removing the Used Cutter Blade	3-11
Installing the New Cutter Blade	3-14
Cleaning the Printer	3-15
Transporting the Printer	3-16
Setting Up the Printer After Transporting It	3-18
Moving the Printer on the Stand	3-19
Replacing the Waste Ink System	3-20

4 Resolving Problems

Diagnosing Problems	4-1
Using Hex Dump Mode	4-2
Improving Print Quality	4-2
Solving Operational Problems	4-5
Solving Miscellaneous Printing Problems	4-7
Solving Paper Problems	4-9
Solving Roll Paper Feed Problems	4-10
Clearing Paper Jams	4-12

5 Specifications

Printing	5-1
Paper	5-2
Printable Area	5-3
Environmental	5-3
Mechanical	5-3
Electrical	5-4
Initialization	5-4
Safety Approvals	5-4
Ink Cartridges	5-5
Parallel Interface	5-6
Forward Channel	5-6
Reverse Channel	5-6
ECP Mode	5-6
Serial Interface (RS-423 Standard)	5-7

A Installing an Interface Card

B Using EPSON Drivers and Utilities for Macintosh

Connecting the Printer B-1

 Connecting to the Printer’s Parallel/USB Interface B-2

 Connecting to the Printer’s Built-in Serial Interface B-2

Setting Up Your Software B-3

 Checking System Requirements B-4

 Installing the Software B-4

 Selecting Your Printer in the Chooser B-5

 Setting Up Printer Sharing B-6

Setting Print Options B-8

 Choosing Page Setup Options B-8

 Choosing Basic Print Options B-10

 Selecting the Correct Media Type B-12

 Choosing Advanced Print Options B-14

Managing Print Jobs B-17

 Setting Up Background Printing B-18

 Using Monitor3 B-19

 Cancelling Printing B-21

Checking Printer Status B-21

 Selecting Configuration Options B-22

Running Print Head Utilities B-24

 Running Nozzle Check and Head Cleaning Utilities B-24

 Running the Print Head Alignment Utility B-25

C Using EPSON Drivers and Utilities for Windows

Connecting the Printer C-1

Setting Up Your Software C-2

 Checking System Requirements C-3

 Installing the Software C-3

 Setting Up Printer Sharing in Windows 95 and 98 C-5

 Setting Up Printer Sharing in Windows NT 4.0 and 2000 C-8

Setting Print Options	C-10
Choosing Basic Print Options	C-11
Selecting the Correct Media Type	C-13
Choosing Paper and Layout Options	C-15
Choosing Advanced Print Options	C-16
Managing Print Jobs	C-20
Using the Progress Meter	C-20
Using the Spool Manager	C-21
Checking Printer Status	C-21
Using Status Monitor 2 (EPSON Stylus Pro 9000)	C-22
Status Monitor 3 (EPSON Stylus Pro 9500)	C-23
Setting Monitoring Preferences	C-24
Running Printer Utilities	C-26
Running Nozzle Check and Head Cleaning Utilities	C-26
Running the Print Head Alignment Utility	C-27
Running the Speed and Progress Configuration Utility	C-29

Index

Introduction

The EPSON Stylus® Pro 9000 series printers are the ultimate wide-format color ink jets. Setting new standards in image quality, media handling, and performance, the EPSON Stylus Pro 9000 has redefined the wide format printing industry. The breakthrough EPSON Stylus Pro 9500 gives you photographic quality with EPSON Archival™ ink technology—for images that last a lifetime.

EPSON's Micro Piezo® dual density droplet (DX3™) print technology includes a precise and consistent dot size and an innovative six-color, high-capacity, quick-drying ink system. EPSON Archival ink achieves the widest color gamut available in a pigment solution, with color performance approaching EPSON dye-based ink.

With resolutions up to 1440 dpi, the EPSON Stylus Pro 9000 series printers support two 44-inch media rolls and cut sheets up to 1.5 mm thick. Both printers incorporate EPSON's DC-based motor technology, which allows for superior print engine accuracy, even during bidirectional printing modes at some of the fastest production speeds in the industry.

For network productivity, a high performance EFI® Fiery® X2 RIP server may be purchased. The EPSON RS-5100 server supports a variety of network configurations and protocols, with full compatibility for Macintosh®, Microsoft® Windows® 2000, Windows 98, Windows 95, Windows NT®, and UNIX® computers. The Fiery X2 RIP provides full multitasking for simultaneous spooling, Adobe® PostScript® 3 processing, and printing.

The printers may also be equipped with an optional 44-inch auto take-up reel that is compatible with most lamination systems and lets you run long print jobs unattended. For complete flexibility, the EPSON Stylus Pro 9000 series printers also support many third-party RIPs and come with custom EPSON® drivers and utilities for photographs and other non-PostScript printing.

How To Use Your Manuals

This guide is part of a set, which also includes the documentation listed below.

- The EPSON Stylus Pro 9000/9500 *Assembly and Setup Instructions* describe how to unpack and assemble the printer, install ink cartridges and paper, and prepare for printing.
- The EPSON Stylus Pro 9000 Series *Quick Reference Guide* provides a handy summary of the procedures for daily use and printer maintenance—loading paper, replacing ink cartridges, running cleaning cycles, aligning the print head, and preparing the printer for transportation. Attach it to your printer for easy reference.
- The electronic *Reference Guide* on the EPSON printer driver CD-ROM provides additional information about the printer, drivers, and utility software. You can read the guide using a web browser, such as Netscape® Navigator® or Microsoft Internet Explorer, versions 3.0 or later.

If you have the RIP Station 5100, your documentation set includes additional manuals for users and system administrators.

- The RIP Station 5100 *Getting Started* describes how to unpack the RIP, install user software and printer files from the User Software CD-ROM, and set up printing. It also describes how to install printer files via the Internet.
- The RIP Station 5100 *User Guide* describes how to set printing options and print to the RIP from Windows and Mac® OS computers.
- The RIP Station 5100 *Administrator Guide* explains basic configuration and administration of the RIP for the supported platforms and network environments. It also includes guidelines for setting up UNIX, Windows NT, and NetWare® servers to provide PostScript printing services to clients.
- The RIP Station 5100 *Color Guide* provides instructions for using ColorWise® Pro Tools, including color calibration and workflow recommendations. It also includes practical color printing tips, application-specific instructions, and an introduction to color theory.
- Release Notes provide last-minute product information and workarounds for some of the problems you may encounter.

Using This *Printer Guide*

This guide contains the following information:

Chapter 1 gives instructions for loading roll paper and cut sheets, printing on various media, and using the paper hammock.

Chapter 2 explains how to monitor the printer's status, respond to error messages on the control panel, and configure printer settings.

Chapter 3 gives instructions for cleaning and aligning the print head, replacing ink cartridges and the cutter blade, and cleaning and transporting the printer.

Chapter 4 provides troubleshooting tips and solutions for problems involving print quality, printer operation, and paper handling.

Chapter 5 provides the technical details on your printer, paper requirements, and ink cartridges.

Appendix A gives instructions for installing an optional Ethernet interface card.

Appendix B covers the installation and use of EPSON printer drivers and utilities for Macintosh computers.

Appendix C covers the installation and use of EPSON printer drivers and utilities for Windows computers.


An Index is included at the end of the book.

Warnings, Cautions, and Notes

You'll find this information throughout this guide:



Warnings must be followed carefully to avoid bodily injury.



Cautions must be observed to avoid damage to your equipment.



Notes contain important information about your printer.

Where To Get Help

EPSON provides technical support and information on the installation, configuration, and operation of professional graphics arts products through the EPSON PreferredSM Protection Plan. Dial (888) 377-6611, 6 A.M. to 8 P.M., Pacific Time, Monday through Friday, and 7 A.M. to 4 P.M., Pacific Time, Saturday.

Before you call, make sure you have your Unit ID number, which is included with the EPSON Preferred Protection Plan information that came with your printer. You'll also need your printer serial number and proof of purchase.

EPSON also provides technical assistance 24 hours a day through the electronic support services listed in the following table:

Service	Access
World Wide Web	From the Internet, you can reach EPSON's Professional Graphics Home Page at http://prographics.epson.com .
EPSON Internet FTP Site	If you have Internet FTP capability, use your Web browser (or other software for FTP downloading) to log onto ftp.epson.com with the user name anonymous and your e-mail address as the password .
EPSON E-Mail Technical Support	To receive technical advice through e-mail, go to http://support.epson.com and complete the form under the troubleshooting tab, as requested.

You can purchase ink cartridges, paper, manuals, and accessories from EPSON at (800) 873-7766. Or visit our web site at: www.epson.com (U.S. sales only). In Canada, please call (800) 873-7766 for dealer referral.



ENERGY STAR Compliance

As an ENERGY STAR Partner, EPSON has determined that this product meets the ENERGY STAR guidelines for energy efficiency.

The EPA ENERGY STAR Office Equipment program is a voluntary partnership with the computer and office equipment industry to promote the introduction of energy-efficient personal computers, monitors, printers, fax machines, and copiers in an effort to reduce air pollution caused by power generation.



Always turn the printer off using the **Power** button. When you press this button, the **Operate** light flashes briefly then goes out. Do not unplug the printer or turn off the power to the printer until the **Operate** light is off. This ensures that the print head is safely capped.

Important Safety Instructions

Before using your printer and RIP Station 5100, read the following safety instructions to make sure you use the equipment safely and effectively.

- Turn off and unplug the printer (and RIP Station 5100) before cleaning. Clean with a damp cloth only. Do not spill liquid on the printer (or RIP Station 5100).
- Do not place the printer (or RIP Station 5100) on an unstable surface or near a radiator or heating vent. Avoid areas subject to rapid changes in temperature and humidity or shock and vibrations.
- Do not place the printer near a window or in direct sunlight. Bright light can interfere with the paper sensors, causing paper jams and related problems.
- Keep the entire system away from potential sources of electromagnetic interference, such as loudspeakers or the base units of cordless telephones.
- Place the printer (and RIP Station 5100) on a flat surface. They will not operate properly if they are tilted or at an angle.
- Do not block or cover the openings in the printer case (or RIP Station 5100 case) or insert objects through the slots.
- Use only the type of power source indicated on the label.
- Connect all equipment to properly grounded power outlets. Avoid using outlets on the same circuit as photocopiers or air control systems that regularly switch on and off. Do not use outlets controlled by wall switches or timers.
- Place the printer (and RIP Station 5100) near a wall outlet where the plugs can be easily unplugged.

Placez l'imprimante près d'une prise de contact où la fiche peut être débranchée facilement.

- Do not let the power cords become damaged or frayed.

- If you use an extension cord with the printer, make sure the total ampere rating of the devices plugged into the extension cord does not exceed the cord's ampere rating. Also, make sure the total ampere rating of all devices plugged into the wall outlet does not exceed the wall outlet's ampere rating.
- Except as specifically explained in the documentation, do not attempt to service the printer (or RIP Station 5100) yourself. Opening or removing those covers that are marked "Do Not Remove" may expose you to dangerous voltage points or other risks. Refer all servicing in those compartments to service personnel.
- Power down the printer from the control panel, unplug the printer (or RIP Station 5100) and refer servicing to qualified service personnel under the following conditions:

If the power cord or plug is damaged; if liquid has entered the printer (or RIP Station 5100); if the equipment has been dropped or the case damaged; if the printer (or RIP Station 5100) does not operate normally or exhibits a distinct change in performance. Adjust only those controls that are covered by the operating instructions.

Ink Cartridge Safety Instructions

- Do not put your hand inside the printer or touch the cartridges during printing.
- To avoid damaging the printer, do not move the print head by hand.
- Under normal circumstances, ink will not come out of the cartridge. If it does get on your skin, wash it off with soap and water. If it gets in your eyes, flush them immediately with water.
- Keep ink cartridges out of the reach of children and do not drink the ink.
- Do not store ink cartridges at high or freezing temperatures. Keep cartridges away from direct sunlight.
- Do not dismantle the ink cartridges or try to refill them. This could result in damage to the print head.
- Install the ink cartridge immediately after you remove it from its package. Leaving the cartridge unpacked for a long time before use may result in reduced print quality.

- Do not use an ink cartridge beyond the date printed on the cartridge package. For best results, use cartridges within six months of installation.
- Before transporting the printer, remove the ink cartridges, close the ink valves, and install the carriage restraint (packing material). See page 3-16 for complete instructions.

Chapter 1: Handling Paper and Other Media

The EPSON Stylus Pro 9000 and 9500 print on a variety of media, including roll paper and cut sheets up to 44 inches wide. The straight-through paper path allows you to use heavy stock, including posterboard up to 59 mil (1.5 mm) thick.

Unless otherwise noted, the instructions in this chapter apply to both the EPSON Stylus Pro 9000 and 9500 printers.

- Selecting paper and other media
- Printing on EPSON paper and other media
- Using roll paper
- Using cut sheet paper
- Using the paper hammock
- Setting paper configurations

Selecting Paper and Other Media

You can print on most types of coated, glossy, plain paper, and other media. The printer comes with two spindles, so you can have two types of roll paper available for printing at all times (with manual switching). You can also purchase an optional 3-inch spindle, which allows you to use roll paper with a 3-inch core.

High-tension spindles are also available (in both 2-inch and 3-inch diameters), recommended for media such as EPSON Synthetic Paper and Fine Art Paper.

The following table shows the requirements for paper you can use in the printer:

Paper requirements

	Roll paper	Cut sheets
Size	13 to 44 in. wide (330 to 1118 mm)	11 × 17 in. to 44 × 62.2 in. (up to 1118 × 1580 mm)
Maximum roll diameter	4.05 in. (103 mm) when using 2 rolls 5.90 in. (150 mm) when using 1 roll	—
Thickness	3.15 to 19.7 mil (0.8 to 0.5 mm)	3.15 to 59 mil (0.8 to 1.5 mm)

Always test samples of paper stock in the printer before purchasing large quantities or printing large jobs. When you use non-EPSON papers or other media, you may need to “profile” their thickness and ink drying time. See page 1-25 for instructions.

Printing on EPSON Paper and Other Media

EPSON papers, which are specially formulated for the inks used in the printer, ensure high-quality results. The following tables list the product codes for the EPSON media available for your printer.



Check the EPSON web site (<http://prographics.epson.com>) or your authorized EPSON dealer for new papers and other media that may be available. Some media may not be available in your location.

EPSON Stylus Pro 9000 media product codes

Paper type	44-inch roll	36-inch roll	24-inch roll	Sheet sizes
Presentation Matte Paper	S041220	S041221	S041295	—
Glossy Paper Heavyweight	S041226	S041227	S041291	—
Semigloss Paper Heavyweight	S041228	S041229	S041292	—
Photo Glossy Paper	SP91002	SP91001	SP91021	—
Photo Semigloss Paper	SP91004	SP91003	SP91022	—
Backlight Film	SP91008	SP91007	SP91023	—
Posterboard Semigloss	—	—	—	20.25 × 28.75" S041237 28 × 40" S041236
DuPont/EPSON Publication Proofing Paper	—	S041249	S041320	13 × 19" (A3+) S041207, S041205
DuPont/EPSON Commercial Proofing Paper	—	S041251	S041296	13 × 19" (A3+) S041160
DuPont/EPSON Commercial Matte Proofing Paper	—	S041247	S041319	13 × 19" (A3+) S041201, S041203
Premium Luster Photo Paper	*	*	*	—

* Not available at time of printing. Check the EPSON web site for product codes and availability.

**Note**

Check the EPSON web site (<http://prographics.epson.com>) or your authorized EPSON dealer for new papers and other media that may be available. Some media may not be available in your location.

EPSON Stylus Pro 9500 media product codes

Paper type	44-inch roll	36-inch roll	24-inch roll	Sheet sizes
Doubleweight Matte Paper	S041387	S041386	S041385	—
Glossy Paper Photo Weight	S041389	—	S041388 (22" roll)	—
Premium Semigloss Photo Paper	—	—	—	13 × 19" (A3+) S041327
Smooth Fine Art Paper	S041433	S041432	S041431	24 × 30" S041434 36 × 44" S041435
Backlight Film for Archival Ink	*	*	*	—
Synthetic Paper	S041401	S041400	S041399	—
Adhesive Synthetic Paper	S041404	S041403	S041402	—
Photo Glossy Paper	SP91002	SP91001	SP91021	—
Photo Semigloss Paper	SP91004	SP91003	SP91022	—
Adhesive Vinyl	S041438	S041437	S041436	—
Canvas	*	*	*	—
Premium Luster Photo Paper	*	*	*	—
Semimatte Paper Photo Weight	*	*	*	—
Posterboard for Archival Ink	*	*	*	20.25 × 28.75" 28 × 40"
Textured Fine Art Paper	S041449	S041448	S041447	24 × 30" S041450 36 × 44" S041451
Translight	*	*	*	—
Tyvek™	*	*	*	—
Scrim Vinyl	*	*	*	—

* Not available at time of printing. Check the EPSON web site for product codes and availability.

Printing Tips for EPSON Media

Follow these tips for using and storing printing materials:

- Avoid touching the printable surface of the paper or other media with bare hands. Fingerprints may affect print quality. Handle media by the edges or use cotton gloves.
- Always choose the correct print mode or media type setting in your print options before you send your job.
- Always select the correct paper source (roll or sheet) from the printer's control panel.
- Keep unused media in its original packaging and store it in a cool, dry place to avoid a decline in quality. Avoid storing media or printouts where they will be exposed to high temperature, humidity, or direct sunlight.

Using Roll Paper

The printer comes with two spindles, so you can have two types or sizes of roll paper available for printing. You can use any roll paper with a 2-inch core, up to 44 inches wide. With the optional 3-inch spindle, you can also use roll paper that has a 3-inch core (one roll at a time). Manually switching from one paper roll to another is a simple process.


This section covers the following:

- Attaching and removing paper from the spindle
- Inserting the spindle in the printer
- Loading the paper for printing


Attaching Paper to the Spindle

Follow these steps:


1. Open the roll paper cover and lift out the spindle.




2. Slide the movable paper stop (flange) off the left end of the spindle.




3. Position the roll so the paper unwinds as shown:



4. Slide the roll onto the spindle so it fits securely over the paper stop.



5. Slide the movable paper stop back onto the spindle and insert it firmly into the end of the roll.



Removing Paper from the Spindle

If you need to remove the paper roll from the spindle, follow these steps:

1. Open the roll paper cover and lift out the roll and spindle.

If the paper is loaded for printing, first raise the paper set lever and roll up the paper before you remove the spindle.


2. Lay the roll down on a flat surface.
3. Loosen the movable paper stop by tapping it with your hand.
4. Slide the paper stop off the end of the spindle.
5. Remove the roll from the spindle.



To avoid damage, do not tap the end of the spindle on the floor.



Store unused roll paper in its original package—including the bag, end caps, and box—to protect the paper.




Inserting the Spindle in the Printer


After you have loaded the paper roll onto the spindle, you need to insert it into the printer. You can have two rolls of paper in the printer at the same time, and print on either one. (If you're using the optional 3-inch spindle, you can only have one roll of paper in the printer.)

Follow these steps to place the spindle and paper into the printer:


1. Open the roll paper cover.
2. Make sure the movable paper stop is firmly fixed into the left end of the paper roll.




3. Position the spindle so that the white end (with the fixed paper stop) is on the right.




4. Insert the white end into the right mounting bracket inside the printer. You can use either the upper or lower bracket.




5. Place the black end of the spindle into the left mounting bracket inside the printer.



6. To keep the paper wound when you're not printing, use one of the roll paper belts included with your printer.



When you're not using the roll paper belt, keep it wound around the end of the spindle.



Note



To remove the spindle (and paper roll) from the printer, first lift out the left end and then the right end.

7. See the next section to load the paper for printing.

Loading Roll Paper for Printing

Once the roll paper is attached to the spindle and inserted in the printer, you're ready to load it for printing. First, open the roll paper cover and make sure the spindle is inserted correctly. Then follow these steps:




To avoid feeding excess paper through the printer, make sure you don't select **Sheet** when you're using roll paper.



If you're using canvas, vinyl, or heavy stock, choose **Roll Cutter Off**. Media that is too thick may damage the cutter.

1. Make sure the printer is turned on. Then press the **Paper Source** button until one of the **Roll** lights comes on.




- Choose **Roll Auto Cut** if you want the paper to be cut automatically after each page is printed.
- Choose **Roll Cutter Off** if you're printing on canvas, vinyl, or other heavy media, if you're using the optional auto take-up reel, or if you want to print a series of pages and keep them together for later cutting.
- If you're using the auto cut setting, you can have a trim line printed on the right edge of your images or pages. If you're not using auto cut, you can have the line printed on the right and bottom edges of your pages. See page 1-15 for instructions.

You can also select roll paper settings through your print options, which will override the control panel settings. See the *RIP Station 5100 User Guide* or Appendix B or C in this manual for more information.




To avoid damaging the printer, never move the paper set lever while the **Operate** or **Pause** light is flashing.

2. Make sure the **Operate** light and **Pause** light are not flashing. Then pull the paper set lever all the way up.




Avoid touching the printable surface of the paper with bare hands. Fingerprints may affect print quality.


3. Feed the paper into the paper slot.



4. Pull the paper down so it extends all the way through the slot.




5. Turn the roll back to remove the slack. Then align the paper with the two rows of holes.





To avoid damaging the printer, never move the paper set lever while the **Operate** or **Pause** light is flashing.

6. Push the paper set lever all the way down, then close the roll paper cover. **PRESS PAUSE BUTTON** appears on the control panel display.



If you're using Auto Cut and the edge of the paper is uneven, press **Cut/Eject** to recut the edge.

7. Press the **Pause** button. The print head moves and the paper feeds into printing position automatically. **READY** appears on the control panel display. (Even if you don't press **Pause**, the paper and printer will move into printing position automatically after 10 seconds.)

Cutting Paper Manually with the Built-in Cutter

When you're not using the **Auto Cut** setting, you need to cut the paper manually after your print job is finished. If you're printing on canvas, vinyl, or other heavy media, you should use scissors or a utility cutter rather than the built-in cutter. See page 1-14 for instructions. Follow these steps to cut manually with the built-in cutter:


1. If the paper is not positioned correctly, press one of the **Paper Feed** buttons to adjust the paper position. Normally, you don't need to do this after a print job is finished.
2. Press the **Paper Source** button until the **Roll Auto Cut** light comes on.
3. Press the **Cut/Eject** button. The paper is cut.

Cutting Canvas and Other Media with the Utility Cutter

Canvas, vinyl, and other heavy media can damage the printer's built-in cutter. Make sure you choose the **Roll Cutter Off** setting on the printer's control panel before you print. If you're using the EPSON Stylus Pro 9000, you can cut the media with scissors or a utility knife.

If you have the EPSON Stylus Pro 9500, you can follow these steps to use the utility cutter that came with the printer:

1. Press the **Cut/Eject** button to feed the canvas or other material out of the printer.
2. Press one of the **Paper Feed** buttons to position the canvas on the guide track.



To avoid injury, use caution when handling the utility cutter.

3. Place the utility cutter on the guide track, then slide it along the track to cut the canvas.
4. After cutting, press the **Pause** button to return to ready mode. You may need to reload the canvas (or other material) to position it correctly for printing.

Printing Trim Lines

You can have trim lines printed on the right edge of your images or pages (if you're using Auto Cut) or on the right and bottom edge (if you're not using auto cut). Follow these steps:

1. Press the **SelecType** button. **PRINTER SETTING MENU** appears on the display.
2. Press the **Item** button until **PAGE LINE=OFF** appears on the display.
3. Press the **+** button. **PAGE LINE=ON** appears on the display.
4. Press the **Enter** button to save the new setting.
5. Press the **SelecType** button to exit the Printer Setting menu.

If you're using the RIP Station 5100 or the EPSON printer driver, you can also specify trim lines through your print options. See the RIP Station 5100 *User Guide* or Appendix B or C in this manual for more information.


Using Cut Sheet Paper

You can print on many types of cut sheet paper and other media. The printer accepts sheets ranging from 11 × 17 inches to 44 × 62.2 inches. You can leave your roll paper in the printer when you print on cut sheets; make sure it is rolled up and fastened with the roll paper belt(s), as described on page 1-9.

If you're using stock more than 19 inches long or 19 mil (0.5 mm) thick, see the following sections for additional instructions. You will not be able to follow the "autoload" procedure described in this section.

Before you start, make sure the printer is on and roll paper is not loaded for printing. Then follow these steps:

1. Make sure the roll paper cover is closed.
2. Press the **Paper Source** button repeatedly until the **Sheet** light comes on.
3. Make sure that the paper set lever is all the way down.
4. Feed the sheet into the paper slot until it meets resistance. Make sure the right edge of the paper is straight and aligned with the scale on the roll paper cover. **PRESS PAUSE BUTTON** appears on the control panel display.




5. Press the **Pause** button. The print head moves and the sheet feeds into printing position automatically. **READY** appears on the LCD panel. (Even if you don't press **Pause**, the paper and printer will move into printing position automatically after 10 seconds.)
6. Print your page. After it is finished, the sheet stays in the printer.
7. To remove your print, hold it while pressing the **Paper Feed (-)** button.


Using Cut Sheet Paper Longer than 19 Inches

Before you start, make sure the printer is on and roll paper is not loaded for printing. Then follow these steps:


1. Make sure the roll paper cover is closed.
2. Press the **Paper Source** button repeatedly until the **Sheet** light comes on.
3. Make sure the **Operate** light and **Pause** light are not flashing. Then pull the paper set lever all the way up.



4. Feed the sheet into the paper slot until it extends through the slot. Align the paper with the two rows of holes.



5. Push the paper set lever all the way down. **PRESS PAUSE BUTTON** appears on the control panel display.



To avoid damaging the printer, never move the paper set lever while the **Operate** or **Pause** light is flashing.

6. Press the **Pause** button. The print head moves and the paper feeds into printing position automatically. **READY** appears on the control panel. (Even if you don't press **Pause**, the paper and printer will move into printing position automatically after 10 seconds.)
7. Print your page. After it is finished, the printed sheet stays in the printer.
8. To remove your print, hold it while pressing the **Paper Feed (-)** button.

Printing on Posterboard


You can print on heavy stock up to 28 × 40 inches (B1), such as EPSON Posterboard Semigloss. Follow these instructions when you print on posterboard or other media more than 19 mil (0.5 mm) thick.



You can't run a cleaning cycle when posterboard is loaded for printing.

1. Set the paper hammock to catch your printouts in front of the printer. See page 1-21 for instructions. Extend the paper guides straight out in front of the printer to keep the board from bending.
2. Press the **Paper Source** button repeatedly until the **Sheet** light comes on.
3. Make sure the **Operate** light and **Pause** light are not flashing. Then pull the paper set lever all the way up.

4. Open the lower cover.




Note




If you're using stock more than 39 inches long, load it long edge first (in landscape orientation).

5. Feed the posterboard into the paper slot until the bottom edge of the board rests behind the open lower cover. Make sure the right edge is straight and aligned with the vertical row of holes.



6. Push the paper set lever all the way down, then close the lower cover. **PRESS PAUSE BUTTON** appears on the control panel display.



To avoid damaging the printer, never move the paper set lever while the **Operate** or **Pause** light is flashing.

7. Press the **Pause** button. The print head moves and the board feeds into printing position automatically. **READY** appears on the control panel. (Even if you don't press **Pause**, the board and printer will move into printing position automatically after 10 seconds.)
8. Run your print job. After it is finished, the posterboard stays in the printer.
9. To remove the print, hold it and pull the paper set lever all the way up.

Adjusting the Platen Gap for Heavy Stock

When you print on heavy stock, you may need to adjust the platen gap setting. Normally, the **AUTO** setting allows the printer to adjust automatically. However, if print quality is not satisfactory when you use heavy stock, change this setting to **WIDE**. Follow these steps:

1. Press the **SelecType** button. **PRINTER SETTING MENU** appears on the display.
2. Press the **Item** button. **PLATEN GAP=AUTO** appears on the display.
3. Press the **+** button. **PLATEN GAP=WIDE** appears on the display.

4. Press the **Enter** button to save the new setting.
5. Press the **SelecType** button to exit the Printer Setting menu.

The letter **W** appears on the right side of the control panel display to remind you of the wide setting. When you switch media, don't forget to change this setting back to **AUTO**.

Using the Paper Hammock




When you print on posterboard, set the hammock to catch printouts in front of the printer.

The paper hammock (also called the paper basket) is a cloth sheet that attaches to your printer and catches your printouts as they come out. This keeps the printouts from getting dirty or wrinkled. You can set up the hammock either to catch the paper roll under the printer or let it feed straight out in front of the printer.


Catching Printouts in Front of the Printer

Follow these steps to set up the hammock in front of the printer:


1. Pull out the paper hammock hooks all the way, so they rest on the floor.




2. Place the two rods in front of the hammock hooks.




3. Place the shorter rod on the ends of the hooks. The longer rod should rest on the floor under the hooks.



4. Push in the top of the paper hammock so that the paper will feed forward.




5. If necessary, extend the hammock fabric out on the floor in front of the printer (for large print jobs).




Catching Printouts Under the Printer

Follow these steps to set up the hammock under the printer:

1. Fit the ends of the three rods into the slots at the end of the paper hammock arms and push the hammock hooks in.



2. Pull out the top of the hammock so that printouts will feed backward.



Setting Paper Configurations

When you use non-EPSON paper or other media, you may need to register the paper's thickness and drying time. On the EPSON Stylus Pro 9500, you can also register the suction setting. The only way to tell if you need to register new media is by experimentation.

When you're using a paper stock or other printing material for the first time, always test it on a small print job. If the ink smears or printing is blurred, you need to register the paper's drying time, and thickness (or suction setting). Registration is not necessary when you use EPSON media. You can register up to four types of paper or other media. Then you can select the registered values whenever you print on that particular stock.



It's a good idea to keep a list of your registered paper types and numbers.

Drying time determines how long the printer will pause between pages or before cutting.

Registering Paper Thickness, Drying Time, and Suction

To register a new paper stock, load it into the printer and follow these steps:

1. Press the **SelectType** button until **PAPER CONFIG. MENU** appears on the display.
2. Press the **Item** button. **PAPER NUMBER=STD*** appears on the display.
3. If you're registering your first roll or batch of paper, press the **+** button to select **PAPER NUMBER=1**. Then press the **Enter** button.

For subsequent rolls, continue pressing the + button to select the number you want to register.

- Press the Item button. **THICK. PAT=PRINT** appears on the display. Press **Enter** to print the paper thickness test pattern. You may see **PAPER THICK. NO.=1** on the display.

Following is a sample pattern:

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17

5. Examine the printed pattern to determine which set of lines is the straightest (shows the smallest gap), and note the corresponding number.

In the sample pattern, the lines under number 4 are the straightest.

6. Press the + or - button to select the number noted in step 5. Then press **Enter**.
7. Press the **Item** button. **DRYING TIME=0 MIN** appears on the display. Press the + or - button to select the time in minutes, then press **Enter**. Start with one minute. If ink still smears, increase the drying time.

This is how long the print head will pause between pages (or before cutting) to let the ink dry.

For the EPSON Stylus Pro 9000, skip to step 9. For the EPSON Stylus Pro 9500, continue with step 8.

8. Press the **Item** button. **SUCTION=NORM*** appears on the display. If you're registering very thin paper, press the + or - button to select the **LOW** setting. Then press **Enter**.
9. Press the **Pause** or **SelecType** button to exit the Paper Configuration menu.

Selecting Registered Paper Settings

Once you have registered the drying time (and thickness) for a type of paper or other media, you can select it whenever you print on that paper.

1. Press the **SelecType** button until **PAPER CONFIG. MENU** appears on the display.
2. Press the **Item** button. You see **PAPER NUMBER=1**.
3. Press the + or - button to select the registered number you want to use, or select the standard setting, **STD**. Then press the **Enter** button.
4. Press the **Pause** or **SelecType** button to exit the Paper Configuration menu.

When you change media, make sure you select the correct setting or change it back to **STD**.

Chapter 2: Monitoring and Configuring the Printer


The EPSON Stylus Pro 9000 series printers include a number of monitoring utilities. The control panel displays status messages and error messages, and the lights alert you when a problem occurs or your ink runs out. If you have the RIP Station 5100, you can also use software utilities to monitor the printer. See the RIP Station 5100 *User Guide* for more information.

In addition, the control panel includes a series of SelecType™ menus that you can use to configure the printer's default settings and perform maintenance operations. This chapter tells you how to respond to the lights and messages and how to configure the printer using the control panel. The following information is included:

- Using the control panel to monitor the printer
- Checking printer status
- Responding to control panel lights and messages
- Using the control panel to configure the printer

Using the Control Panel to Monitor the Printer

The printer's control panel includes buttons, lights, and a liquid crystal display (LCD):



Monitoring Normal Printer Operation

Messages appear on the control panel display and lights come on or flash to indicate various phases of printer operation. The following table explains the status messages and lights:

Status messages

Message	Light	Explanation or response
READY	Operate light on	Printer is ready to print.
PRINTING	Operate light flashing	Printer is receiving data.
INK DRY <number> MIN	Pause light flashing	Printer is paused to let ink dry. Wait for the number of minutes shown.
RESET	All lights flash briefly	Printer is resetting.
PRESS PAUSE BUTTON	Pause light on	Press the Pause button to continue.
WAIT	Pause light on or flashing	Printer is warming up, performing maintenance, or charging ink.
PAUSE	Pause light on	Printer is paused. To resume printing, press the Pause button.

Pausing and Resetting the Printer

If you need to stop the printer during a print job, press the **Pause** button. Press the **Pause** button again to resume printing.

If you decide to cancel a job after the printer has started processing it, you can reset the printer. Press the **Pause** button and hold it down for 3 seconds. This clears all data in the printer’s memory.

Checking Printer Status

You can use the control panel to print a status check or nozzle check. These prints allow you to test the printer without sending a print job (and without connecting the printer to the RIP). You can also check the amount of ink remaining, total number of prints, and the status of your cutter blade and other printer parts.

Printing a Status Check

The status check shows the current default settings, amount of ink remaining in each cartridge, page count, and the status of various printer parts. To display this information on the control panel instead of printing it out, see page 2-4.

Follow these steps to print the status check:

1. Load a sheet of paper in the printer, following the instructions on page 1-15. (You can print test pages on roll paper, but you will use more paper.)
2. Press the **SelecType** button on the control panel. Press it repeatedly until you see **TEST PRINT MENU** on the display.
3. Press the **Item** button until you see **STATUS CHECK=PRINT** on the display.
4. Press the **Enter** button. The status check prints. The amount of ink left or component life is indicated as follows:
 - E*****F = full (or full life remaining)
 - E***** F = 3/4 full (or 3/4 life remaining)
 - E*** F = 1/2 full (or 1/2 life remaining)
 - E** F = 1/4 full (or 1/4 life remaining)
 - E* F = nearly empty (or service life near end)
 - E F = empty (or service life ended)
5. Press the **SelecType** button to exit the Test Print menu.

Printing a Nozzle Check

The nozzle check prints a pattern of dots that lets you see if any print head nozzles are clogged. If any dots are missing, you can run a cleaning cycle to clear the nozzles. Follow these steps to print the nozzle check:

1. Load a sheet of paper in the printer, following the instructions on page 1-15. (You can print test pages on roll paper, but you will use more paper.)
2. Press the **SelecType** button on the control panel. Press it repeatedly until you see **TEST PRINT MENU** on the display.

3. Press the **Item** button. You see **NOZZLE CHECK=PRINT** on the display.
4. Press the **Enter** button. The nozzle check prints as shown below:



Each line should be complete, with no gaps in the dot pattern. If any dots are missing, as shown below, you need to run a cleaning cycle. Press the **Cleaning** button on the control panel and hold it for at least 3 seconds.



For more information, see page 3-2. If you're using the EPSON printer driver, you can run the Head Cleaning utility. See page B-24 (Macintosh) or C-26 (Windows) for instructions.

Checking Ink Levels and Component Life

You can view printer status information on the control panel display without printing a status check. Follow these steps:

1. Press the **SelecType** button on the control panel. Press it several times until you see **PRINTER STATUS MENU** on the display.
2. Press the **Item** button. You see **VERSION <number>** on the display. This indicates the firmware version installed in your printer.
3. Continue pressing the **Item** button to display the amount remaining for each of the 6 inks or service life remaining for a number of printer parts. The indicators read as follows:

E*****F = full (or full life remaining)

E***** F = 3/4 full (or 3/4 life remaining)

E*** F = 1/2 full (or 1/2 life remaining)

E** F = 1/4 full (or 1/4 life remaining)

E* F = nearly empty (or service life near end)

<nn>% F = less than 10% of ink (or service life) remaining

Following is a list of the items displayed. Note that all parts on the list (except the ink cartridges and paper cutter) need to be replaced by authorized EPSON service centers.

INK LEFT-K (black)	TOTAL PRINTS
INK LEFT-C (cyan)	WASTE INK (waste ink system)
INK LEFT-M (magenta)	CR MOTOR (carriage motor)
INK LEFT-LC (light cyan)	PF MOTOR (paper feed motor)
INK LEFT-LM (light magenta)	HEAD UNIT (print head)
INK LEFT-Y (yellow)	CLEANER (cleaning unit)
CUTTER LIFE (paper cutter)	

4. Press the **SelecType** button to exit the Printer Status menu.

Responding to Control Panel Lights and Messages

When your ink or paper runs out or a problem occurs, a message appears on the display. The lights on the control panel come on or flash. The following table lists the messages alphabetically and includes an explanation and instructions for correcting the problem.

Error messages

Message	Light	Explanation	Response
COVER OPEN	Pause light on	Lower cover is open.	Close the lower cover. Make sure all three magnetic tabs are fastened.
INK COMPART. OPEN	Pause light on	You are replacing the ink cartridge(s) and the ink compartment cover is open.	Close the ink compartment cover when you are finished replacing the ink cartridge(s).
INK LOW	Ink Out light(s) flashing	Ink cartridge(s) are nearly empty (printing continues).	Replace ink cartridge(s) indicated by Ink Out light(s). See page 3-7 for instructions.
INK OUT	Ink Out light(s) on	Ink cartridge(s) are empty (printing stops).	Replace the ink cartridge(s) indicated by Ink Out light(s). See page 3-7 for instructions.
LOAD PAPER	Paper Out light on	Paper set lever is up while loading paper.	Pull the paper set lever down after you load paper.

2-6 | Monitoring and Configuring the Printer

Error messages (continued)

Message	Light	Explanation	Response
LOAD ROLL PAPER LOAD SHEET PAPER	Paper Out light on	Paper source setting in print options is different from control panel.	Make sure the right paper is loaded and the paper source setting is the same on the control panel and print options.
MAINTENANCE REQ. <error number>	—	A printer part will need to be replaced soon.	Note the error number and contact EPSON as described in the Introduction.
MAINTENANCE REQ 0100	—	The waste ink system is almost full.	Call an authorized EPSON servicer to schedule replacement of the waste ink system.
NO INK CARTRIDGE	Ink Out light(s) on	Ink cartridge(s) not installed.	Install ink cartridges as indicated by the lights. See page 3-7 for instructions.
OPTION I/F ERROR	—	Wrong interface card installed.	Turn off the printer and remove the card. See page A-3 for instructions.
PAPER JAM	Paper Out light flashing	Paper has jammed in the printer.	Remove the jammed paper. See page 4-12 for more information.
PAPER NOT CUT	Paper Out light flashing	Roll paper was not cut completely.	Cut the paper manually, then remove the cut paper from the printer. Reload paper, as described on page 1-10.
		Cut paper did not fall off.	Remove the cut paper from the printer. Reload paper.
PAPER NOT STRAIGHT	Paper Out light flashing	Paper slipped and fed into the printer at an angle.	Reload paper, making sure the edges are straight and aligned with both rows of holes.
PAPER OUT	Paper Out light on	No paper is loaded.	Load paper.
		Paper ran out.	Remove any printouts or paper remaining in the printer and load more paper. If the message appears during a print job, reset the printer by pressing the Pause button for 3 seconds. Then load paper and resend the job.
PUSH LEVER DOWN	Paper Out light on	Paper set lever was released during the printing process or another operation.	Push the paper set lever down. Start printing again from the beginning for best results.

Error messages (continued)

Message	Light	Explanation	Response
RELOAD PAPER	Paper Out light on	Paper could not be reversed into the printing position.	Remove the paper. Reload it so that the right and bottom edges are straight and aligned with both rows of holes.
		Image is too wide for the paper loaded in the printer.	Resize your image or load wider paper.
		Paper is not fully ejected.	Cut the paper at the paper insertion slot, then reload paper.
		PAPER NOT CUT error was cleared.	Reload paper.
REMOVE PAPER	Paper Out light on	Paper is too thick for head cleaning.	Push the paper set lever down to remove the paper. Head cleaning automatically starts. After cleaning, reload paper.
SERVICE REQ. <error number>	All lights flashing	An error has occurred.	Note the error number, and turn the printer off and then on. If the message remains, contact EPSON as described in the Introduction.
SERVICE REQ. <00000100>	All lights flashing	The waste ink system is full.	Contact EPSON to have the waste ink system replaced.
TURN PWR OFF AND ON	—	This message appears after you clear a paper jam.	Turn the printer off and then on again.
UNABLE TO PRINT	—	You tried to print a test pattern while an error condition was present or the ink compartment cover was open.	After 3 seconds the message disappears. Press the Pause button to exit SelecType mode. If the message appears again, clear the error before you print.
WRONG CARTRIDGE	Ink Out light(s) on	Wrong ink cartridge(s) installed.	Install the correct ink cartridge(s).

Using the Control Panel to Configure the Printer

In addition to testing the printer and checking the status of various components, you can use the SelecType menus to configure printer settings and perform maintenance operations. The following table lists the menus, their functions, and where to find additional information:

SelecType menus

Menu	Description	For more information, see
Printer Setting	Configure the printer	page 1-15, page 1-20, page 2-8
Test Print	Print a nozzle check or status check	page 2-3
Printer Status	Check ink levels and component life	page 2-4
Paper Configuration	Register paper thickness and drying time, and select registered configurations	page 1-25
Cutter Replacement	Replace the paper cutter blade	page 3-11
Head Alignment	Align the print head	page 3-3

Setting Default Roll Paper Margins

The default margins for roll paper are .12 inches or 3 mm (left and right) and .59 inches or 15 mm (top and bottom). You can use the Printer Settings menu on the control panel to set all margins to 3 mm or 15 mm.



Note

Print quality may be affected near the cut edges if you change the top and bottom margins to 3 mm.

1. Press the **SelecType** button. **PRINTER SETTING MENU** appears on the display.
2. Press the **Item** button repeatedly until **ROLL MARG=T/B15MM*** appears on the display. This is the default setting.
 - Press the **+** button once to set all margins to 3 mm. **ROLL MARG=3MM** appears on the display.
 - Press the **+** button again to set all margins to 15 mm. **ROLL MARG=15MM** appears on the display.

You can use the **+** or **-** button to cycle through all three settings.

3. When you have selected the setting you want, press the **Enter** button to save it.
4. Press the **SelecType** button to exit the Printer Setting menu.

Turning Off Paper Monitoring Features

The printer normally stops and displays an error message if you try to print an image wider than the paper, or if paper is fed at an angle. You can turn off the paper size check and/or paper alignment check if you don't want to use these monitoring features. However, ink may be sprayed on the platen if you print an image that is too wide for the paper. Follow these steps to turn off paper monitoring:

1. Press the **SelecType** button. **PRINTER SETTING MENU** appears on the display.
2. Press the **Item** button repeatedly until **PAPER SIZE CHK=ON** or **PAPER ALIGN CHK=ON** appears on the display.
3. Press the **+** button. **PAPER SIZE CHK=OFF** or **PAPER ALIGN CHK=OFF** appears on the display.
4. Press the **Enter** button to save your new setting.
5. Press the **SelecType** button to exit the Printer Setting menu.

Selecting the Printer's Interface

The printer includes both a parallel and serial interface. You can also install an optional interface card for networking or additional connectivity. By default, the printer automatically switches to whichever interface is receiving data.

You can use the control panel to select an individual interface for sending data to the printer. Follow these steps:

1. Press the **SelecType** button. **PRINTER SETTING MENU** appears on the display.
2. Press the **Item** button repeatedly until **INTERFACE=AUTO*** appears on the display. This is the default setting.

- Press the **+** button once to select the parallel interface. **INTERFACE=PARALLEL** appears on the display.
- Continue pressing the **+** button to select the **MAC** (serial) or **OPTION** (optional) interface.

You can use the **+** or **-** button to cycle through all four settings.

3. When you have selected the setting you want, press the **Enter** button to save it.
4. Press the **SelecType** button to exit the Printer Setting menu.

Configuring the Parallel Interface

You can use the control panel to change the parallel interface to ECP mode for faster printing. To use this mode, you must connect a computer directly to the printer's parallel interface (without a RIP), and the computer must support ECP mode. See your computer's documentation for more information.



Note

If you experience any problems using ECP mode, switch back to compatible mode. For USB connection, use compatible mode.

Follow these steps to configure the parallel interface:

1. Press the **SelecType** button. **PRINTER SETTING MENU** appears on the display.
2. Press the **Item** button repeatedly until **PARA. I/F=COMPAT*** appears on the display. This indicates that compatible mode (the default) is selected.
3. Press the **+** button. **PARA. I/F=ECP** appears on the display. This sets the parallel interface to ECP mode.
4. Press the **Enter** button to save your setting.
5. Press the **SelecType** button to exit the Printer Setting menu.

Changing the Printer's Code Page Setting

The printer uses the PC437 code page (U.S. and standard European character sets) by default. You can use the control panel to change it to the PC850 code page (multilingual character sets) if necessary. Follow these steps:

1. Press the **SelecType** button. **PRINTER SETTING MENU** appears on the display.
2. Press the **Item** button repeatedly until **CODE PAGE=PC437*** appears on the display.
3. Press the **+** button. **CODE PAGE=PC850** appears on the display.
4. Press the **Enter** button to save your setting.
5. Press the **SelecType** button to exit the Printer Setting menu.

Restoring Default Settings

You can erase all SelecType settings you have made and restore them to their default values. Follow these steps:

1. Press the **SelecType** button. **PRINTER SETTING MENU** appears on the display.
2. Press the **Item** button repeatedly until **INIT. PANEL=EXEC.** appears on the display.
3. Press the **Enter** button to erase all settings and restore the defaults.
4. Press the **SelecType** button to exit the Printer Setting menu.



The maintenance mode also includes a **MW7=A** setting, for use by an authorized EPSON servicer only.

Setting the Control Panel Language

All control panel messages are displayed in English. However, you can use a special printer maintenance mode to change to any of the following languages:

- French
- Italian
- German
- Spanish
- Portuguese

Make sure the printer is turned off, then follow these steps to change the language for control panel messages:

1. Press and hold the **Pause** button while you press the **Power** button to turn on the printer. **HEX DUMP=PRINT** appears on the display.
2. Press the **Item** button until **LANGUAGE=ENGLISH*** is displayed.
3. Press the **+** or **-** button until the language you want is displayed.
4. Press the **Enter** button to select the language.
5. Press the **Power** button to turn the printer off and exit maintenance mode.

Chapter 3: Maintaining and Transporting the Printer

The EPSON Stylus Pro 9000 series printers require very little maintenance to keep working at their best. This chapter describes the following routine procedures:

- Running a nozzle check
- Running a cleaning cycle
- Aligning the print head
- Replacing ink cartridges
- Replacing the paper cutter blade
- Cleaning the printer
- Transporting the printer
- Replacing the waste ink system

Running a Nozzle Check

The nozzle check prints a pattern of dots that lets you see if any print head nozzles are clogged. If any dots are missing, you can run a cleaning cycle to clear the nozzles.

Follow these steps to print the nozzle check:


1. Load a sheet of paper in the printer, following the instructions on page 1-15. (You can print the nozzle check on roll paper, but you will use more paper.)
2. Press the **SelecType** button on the control panel until you see **TEST PRINT MENU** on the display.
3. Press the **Item** button. You see **NOZZLE CHECK=PRINT** on the display.

Note


The Ink Pad number under the nozzle check pattern indicates the remaining percentage of the waste ink system. You will need to contact your authorized EPSON servicer when this number is low. The printer will stop and display an error message when the system needs to be replaced.

4. Press the **Enter** button. The nozzle check prints as shown below.

If all the lines on the check pattern are complete, with no gaps in the dot pattern, the print head doesn't need cleaning:



If dots are missing from the pattern, as shown below, you need to run a cleaning cycle. See the following section for instructions.



Running a Cleaning Cycle

If your printed image is unexpectedly light or faint or dots are missing from the image, you may need to run a cleaning cycle. This unclogs the print head nozzles so they can deliver ink properly.

The cleaning process uses ink, so you should run it only if print quality declines. Always run a nozzle check first to confirm that the head needs cleaning; the nozzle check uses only a small amount of ink.

If you have installed the EPSON printer driver and utilities, you can run the Head Cleaning utility. See page B-24 (Macintosh) or C-26 (Windows) for instructions.

Follow these steps to run the cleaning cycle from the printer's control panel:

1. Make sure none of the **Ink Out** lights is on or flashing. (If so, you need to replace the indicated ink cartridge before you can run a cleaning cycle.)
2. Press the **Cleaning** button and hold it for at least 3 seconds. The **Pause** light flashes as the printer cleans its print head. The cleaning cycle takes about three minutes and does not use any paper.
3. When the **Pause** light goes off, print a document or run a nozzle check to confirm that the head is clean.

Caution

To avoid damaging the printer, don't turn it off until the cleaning cycle is finished and the **Pause** light has stopped flashing.

You may need to run the cleaning cycle several times to get a clean nozzle check pattern. For effective cleaning, always run a test print or nozzle check between cycles. If the lines on the pattern still appear broken after several cleaning cycles, contact EPSON for assistance.

Aligning the Print Head

If banding appears on your prints, or vertical lines are not straight, you need to align the print head. You can use the Print Head Alignment utility if you have the EPSON printer driver and utilities installed. See page B-25 (Macintosh) or page C-27 (Windows) for instructions.

If you don't have the utilities installed, you can use the control panel. Both procedures align the head for all modes and resolutions. Print head alignment involves two phases:

- First you print a series of alignment or adjustment patterns.
- Then you determine which numbered row of patterns (EPSON Stylus Pro 9000) or numbered line or box (EPSON Stylus Pro 9500) has the best vertical alignment (smallest gaps). You enter the information on the control panel to change the print head alignment.

Printing the Alignment Patterns

For the EPSON Stylus Pro 9000, use 13 × 19-inch EPSON coated ink jet paper (short edge first). You'll need 4 sheets to complete the alignment procedure, which includes 12 patterns of 7 rows each and takes about 15 minutes.

For the EPSON Stylus Pro 9500, you can use EPSON roll paper. Six patterns of 15 lines or boxes are printed, which takes about 10 minutes. The patterns are repeated across the width of the paper.

Follow these steps to align the print head using the control panel:

1. Load paper in the printer.
2. Press the **SelecType** button until **HEAD ALIGNMENT MENU** is displayed.
3. Press the **Item** button. **PAPER THICK=STD** appears on the display.

3-4 | Maintaining and Transporting the Printer

If you're using EPSON paper, leave this setting on **STD**.

If you're using other media, enter the thickness value of the paper in 0.1-mm increments by pressing the **+** or **-** button.

4. Press the **Enter** button to save the setting. **ADJUST. PATT.= ALL** appears on the display.

5. Press the **Enter** button to print the full series of alignment patterns.

If you want to print a single alignment pattern, press the **+** or **-** button until the pattern number appears. Then press the **Enter** button.


- For the EPSON Stylus Pro 9500, skip to the next section, "Completing the Alignment Procedure."
 - For the EPSON Stylus Pro 9000, patterns 1 through 3 are printed on the first sheet of paper. After this sheet is printed, **PAPER OUT** appears on the display and the red **PAPER OUT** light comes on.
6. Raise the paper set lever and remove the printed sheet. Even though the **Operate** light is flashing, it is safe to raise the paper set lever.
 7. Load another sheet of paper. The next three patterns are printed.
 8. Repeat steps 6 and 7 twice, until all 12 patterns have been printed.
 9. Raise the paper set lever and remove the last printed sheet. Then lower the lever and continue the alignment procedure in the next section.

Completing the Alignment Procedure


After all the patterns have printed, continue with these steps.

1. Do one of the following:
 - For the EPSON Stylus Pro 9000, examine pattern #1 and determine which row number has the smallest gaps. In the first example below, the lines in row 4 have the smallest gaps. In the second example, row 6 has the smallest gaps.

EPSON Stylus Pro 9000 Alignment Patterns




patterns #1-5, #7, #9-12



patterns #6, #8

- For the EPSON Stylus Pro 9500, examine row #1 and determine which line or box number has the smallest gaps. In the example below, line 8 has the smallest gaps in row 1.

EPSON Stylus Pro 9500 Alignment Patterns



Note

If row 4 (EPSON Stylus Pro 9000) or line 8 (EPSON Stylus Pro 9500) shows the smallest gaps for all the sets, the head is aligned. Press **Pause** to exit head alignment mode.

2. Check the control panel display. Use the + or – button to select the best aligned row or line for pattern #1. Then press the **Enter** button to register the setting.
3. Repeat steps 1 and 2 for each pattern.

If you can't make a consistent choice as you look across the width of the paper, choose the average or most frequent number, then print the pattern again. Press **Enter** to cycle through the patterns until you reach the one you want to repeat.
4. After you have registered all the patterns, press the **Pause** button to exit head alignment mode and return to normal printer operation.



For best results, use genuine EPSON cartridges and do not refill them. Damage to your printer attributable to the use of other consumables is not covered by EPSON's warranty. Color accuracy may vary if you use non-EPSON inks.

Replacing Ink Cartridges

When one of the Ink Out lights is flashing (and INK LOW is displayed on the control panel), the corresponding cartridge is almost out of ink. Make sure you have a replacement cartridge. When the light stays on and INK OUT is displayed, the cartridge is empty. You must replace the cartridge before you can continue printing. Use only the following EPSON ink cartridges:

EPSON Stylus Pro 9000 graphic arts (dye-based) ink

- | | | | |
|-----------|---------|-----------------|---------|
| • Black | T407011 | • Light cyan | T412011 |
| • Cyan | T410011 | • Light magenta | T411011 |
| • Magenta | T409011 | • Yellow | T408011 |

EPSON Stylus Pro 9500 Archival (pigment) ink


- | | | | |
|-----------|---------|-----------------|---------|
| • Black | T474011 | • Light cyan | T479011 |
| • Cyan | T477011 | • Light magenta | T478011 |
| • Magenta | T476011 | • Yellow | T475011 |

Before you start, make sure the printer is on. Then follow these steps to replace an ink cartridge:

1. Note the color of the Ink Out light that is on or flashing. This is the cartridge that you need to replace.
2. Open the roll paper cover and locate the ink cartridge that needs replacing.




Leave the empty cartridge in the printer until you are ready to replace it.




3-8 | Maintaining and Transporting the Printer

You can leave your roll paper in the printer when you replace ink cartridges. The illustrations show paper removed for clarity only.

3. Push the lever down and let it “bounce” back up to open the ink compartment cover. **INK COMPART. OPEN** appears on the display.




4. Locate the slot containing the empty ink cartridge (corresponding to the Ink Out light). Pull the clamp forward.






If ink gets on your hands, wash them thoroughly with soap and water. If ink gets into your eyes, flush them immediately with water.

5. Carefully pull the empty cartridge straight out of the printer.




6. Make sure the replacement cartridge is the correct color, and remove it from its package.

If you're using pigment ink, shake the cartridge gently before installing it.



If you can't insert the cartridge smoothly, you may have the wrong cartridge. Check the package and product code.

7. Hold the ink cartridge with the arrow mark face-up and pointing to the rear of the printer. Then insert the ink cartridge into the slot. Don't force the cartridge.







Note

If the **Ink Out** light remains on, the cartridge may not be installed correctly. Remove the cartridge and then reinsert it as described above.

8. Push the cartridge clamp back. Make sure the corresponding **Ink Out** light goes off.



9. Close the ink compartment cover by pushing the lever down until it clicks into place.



Replacing the Paper Cutter Blade

If you notice that your paper isn't cut cleanly, the cutter blade may need to be replaced. If you use the blade to cut heavy stock or non-EPSON media, you may need to replace it more often. You can also check the status of your cutter by printing the status check sheet or using the Printer Status menu on the control panel. See page 2-3 or 2-4 for instructions.

To obtain a new cutter blade (part number C815131), contact your dealer.

To replace the cutter blade, you first need to remove the used blade, as described in the following section.




Be careful not to cut yourself while replacing the paper cutter blade.

Removing the Used Cutter Blade

Make sure the printer is on, then follow these steps to remove the blade:

1. Press the **SelectType** button repeatedly until **CUTTER REPLACE MENU** appears on the display.




2. Press the **Item** button. **CUT. REPLACE=EXEC.** appears on the display.

3-12 | Maintaining and Transporting the Printer




To avoid damaging your printer, never move the paper cutter holder by hand.

3. Press the **Enter** button. The paper cutter holder moves to the replacement position, where the arrow appears in the illustration below:




paper cutter
location

4. When the holder stops moving and **OPEN LOWER COVER** appears on the display, open the lower cover.




5. When **REPLACE CUTTER** appears on the display, you can open the casing. Push in the side pin while turning the paper cutter cover to the right.



Be careful not to let the cutter or the spring coil pop out of the casing.


6. Slowly take your finger off the side pin. The paper cutter raises so it can be removed.
7. Carefully remove the cutter blade from the printer.




Installing the New Cutter Blade

After you have removed the used cutter blade, you're ready to install the new one. Follow these steps:


1. Remove the new blade from its package.
2. Make sure the spring coil is inside the cutter holder. If necessary, reinstall the coil.
3. Fully insert the new blade into the paper cutter holder in the direction shown below.



4. Push in the side pin while turning the paper cutter cover to the left to close the casing. **CLOSE LOWER COVER** appears on the display.



5. Close the lower cover. The cutter holder moves to the home (far right) position and **READY** appears on the display.



Be careful not to touch the gears inside the printer.

To avoid damaging the components as well as the case, never use alcohol or thinners to clean the printer.

Be careful not to get water on the printer mechanism or electronic components.

Don't use a hard or abrasive brush.

Don't spray the inside of the printer with lubricants; unsuitable oils can damage the mechanism. Contact your dealer or a qualified servicer if your printer needs lubrication.

Cleaning the Printer

To keep your printer working at its best, you should clean it thoroughly several times a year.

1. Make sure the printer is turned off and all the lights on the control panel are off. Then unplug the power cord.
2. Open the roll paper cover and remove the roll paper spindles. Remove any sheet media from the printer.
3. Make sure the ink cartridge compartments are closed. Then use a soft brush to carefully clean away any dust or dirt.
4. Close the roll paper cover.
5. Open the lower cover and use a soft brush to carefully clean away any dust or dirt inside the lower cover. Then close the cover.
6. Remove the paper hammock. Then clean away any dust or dirt around the leg assembly using a soft brush.
7. If the outer case is dirty, clean it with a soft, clean cloth dampened with mild detergent. Keep the ink cartridge compartment closed to prevent water from getting inside.
8. If the area under the roll paper cover accidentally gets soiled with ink, wipe it off with a damp cloth.
9. To wash the paper hammock, remove the shafts, then machine wash with mild detergent and air dry.

Transporting the Printer

When you need to ship your printer, you should repack it using the original box and packing materials. Follow these steps to prepare the printer for shipping:




If for any reason the printer will not be level during shipping, a service technician must drain all ink from the printer before it is shipped.


1. First turn off the printer and make sure the print head is in the home (far right) position. If not, turn the printer back on, wait until the print head moves to the home position, then turn off the printer.
2. Remove the following parts:
 - Ink cartridges
 - Power cord
 - Interface cable
 - Paper hammock
 - Roll paper spindles
 - All paper or other media
 - Optional auto take-up reel (if installed)

After you remove the ink cartridges, store them in separate, resealable plastic bags.


3. Make sure the ink cartridge clamps are in the upright position (closed). Leave the ink compartment cover open. Use tape to hold the cover and the cartridge clamps in place. This automatically closes the ink valves.




4. Install the carriage shipping restraint (packaging material).
5. Close the ink valve locks on each side of the printer.



6. Remove the left and right side joint cover plates by spreading the ends and pulling outward. Keep the cover plates in a safe place.




7. While holding the printer unit, remove the screws from the left and right sides. Keep the screws in a safe place.



The printer unit weighs approximately 212 lb (96 kg). Always have four people lift it, using the hand grip areas as shown.

8. Have four people lift the printer unit off the leg assembly, using the hand grips. Lift the back of the printer first, tilt it slightly to the front, then slide it back to remove it.



9. Keep the printer level while you move it.

Setting Up the Printer After Transporting It

Setting up the printer after transporting it is almost identical to setting it up for the first time. Whenever you set up the printer, see the *Assembly and Setup Instructions*, and note the following points:

- Don't forget to open the side ink valve locks. The printer can't print while they are closed.
- Don't forget to remove any protective material (such as tape from the ink cartridge clamps).

- The first time you start printing after moving the printer, the print head nozzles may be clogged. You may need to run a cleaning cycle (see page 3-2) and realign the print head (see page 3-3) to ensure good print quality.
- If you reinstall the cartridges you removed before transporting the printer, make sure the printer is turned off when you install them. Otherwise, the printer will not be able to determine the correct level of remaining ink and the Ink Out lights may not flash to warn you when a cartridge is almost empty.


Moving the Printer on the Stand



Do not roll the printer on angled or uneven surfaces.

When you need to move the printer a short distance, such as within the same building or facility, you can roll the printer on its casters. Follow these steps:

1. Make sure that the power cord, interface cable, roll paper spindles and sheet media are removed, and the roll paper cover and lower cover are closed.
2. Release the front casters and retract the stabilizer knobs.



3. Carefully roll the printer to its new location. Relock the casters and extend the stabilizer knobs after moving.

The first time you start printing after moving the printer, the print head nozzles may be clogged. You may need to run a cleaning cycle (see page 3-2) and realign the print head (see page 3-3) to ensure print quality.

Replacing the Waste Ink System

Approximately every two years (or after 12,000 B1-size prints), you must have your authorized EPSON servicer replace the waste ink system. This is necessary to prevent damage to the print head and maintain print quality. Parts and labor for this service are not covered under the terms of the limited warranty.

You can monitor the status of the waste ink system through the control panel (see page 2-4) or through the Ink Pad number displayed on the nozzle check print (see page 2-3).

The printer will display the following message on the control panel when the waste ink system is almost full:

MAINTENANCE REQ. 0100

You should call to schedule service at this point. When the waste ink system is at full capacity, the printer will stop and display the following message:

SERVICE REQ. 00000100

Chapter 4: Resolving Problems

As you use your printer, you may occasionally experience a problem. The first thing you should do is diagnose the problem following the guidelines in this chapter. Then try the most likely solutions until the problem is fixed.

This chapter provides instructions for the following:

- Diagnosing problems
- Improving print quality
- Solving operational problems
- Solving miscellaneous printing problems
- Solving paper problems

Diagnosing Problems

The EPSON Stylus Pro 9000 series printers include a number of ways to help you diagnose problems:

- To identify the most common problems, check the messages and lights on the printer's control panel. See page 2-5 for more information.
- If you have the RIP Station 5100, check for error messages on the RIP control panel and in the Fiery Spooler or Web Spooler utilities. See the RIP Station 5100 *User Guide* for more information. (The RIP Station 5100 *User Guide* also includes troubleshooting guidelines.)
- If you're using the EPSON printer driver and Monitor3 (Macintosh) or Status Monitor (Windows) utility, check your software for error messages. See Appendix B or C for more information.
- To determine whether the problem is caused by the printer itself, disconnect the printer from the RIP and run a status check. See page 2-3 for instructions.
- You can use the printer's hex dump mode to pinpoint communication problems. Then you can fax the printout to a technical support representative or interpret it yourself. See the following section for instructions.
- If none of the suggested solutions in this chapter solve your problem, contact EPSON as described under "Where To Get Help" in the Introduction.

Using Hex Dump Mode

You can use the printer's hex dump mode to identify problems if you know how to interpret hex code. Or, you can fax the hex printout to a technical support representative.

Make sure the printer has paper loaded and is turned off. Then follow these steps:

1. Press and hold the **Pause** button while you press the **Power** button to turn on the printer. **HEX DUMP=PRINT** appears on the display.
2. Press the **Enter** button.
3. Send your problem file to the printer.

The data in the print buffer is printed with 16-byte hex data in the left column and corresponding ASCII characters in the right column. If the last data is less than 16 bytes, you need to press the **Pause** button to print it.

4. After you're finished using hex dump mode, press the **Power** button to turn the printer off and exit maintenance mode.

Improving Print Quality

You can often improve print quality by doing the following:

- Run a nozzle check and cleaning cycle. See page 3-1 for instructions.
- Align the print head. See page 3-3 for instructions.
- When you send a print job, make sure your print options are set correctly. For more information, see the *RIP Station 5100 User Guide* (if you have the RIP) or Appendix B or C (if you're using the EPSON printer driver).

If none of these suggestions help, try the solutions on the following page.

Print quality problems

Problem	Possible cause	Solution
Your print has horizontal banding.	Print head nozzles are clogged.	Run a nozzle check and cleaning cycle (page 3-1).
	The print head is out of alignment.	Align the print head, as described on page 3-3.
	You're printing at 720 dpi.	Choose 1440 dpi to eliminate banding.
	You're using the High Speed (Bi-directional) setting.	Turn off the High Speed or Bi-directional setting in your print options.
	Print options are set incorrectly for the media you're using.	Make sure the Print Mode or Media Type setting is correct for the media you're printing on.
	You're printing on the wrong side of the paper or other media.	If you're using a cut sheet, make sure the printable side is face up.
	Your ink supply is too old.	Check the Ink Out lights and replace ink cartridges if necessary, as described on page 3-7.
Your print has vertical misalignment or banding.	The print head is out of alignment.	Align the print head, as described on page 3-3.
	You're using the High Speed (Bi-directional) setting.	Turn off the High Speed or Bi-directional setting in your print options.
Colors are incorrect or missing.	Print options are set incorrectly for the media you're using.	Make sure the Print Mode or Media Type setting is correct for the media you're printing on.
	You're printing on the wrong side of the paper or other media.	If you're using roll paper, make sure it's correctly attached to the spindle. See page 1-5 for instructions. If you're using a cut sheet, make sure the printable side is face up.
	Print head nozzles are clogged.	Run a nozzle check and cleaning cycle (page 3-1).
	The color settings in your application or print options are incorrect.	Make sure your color settings are correct.

4-4 | Resolving Problems

Print quality problems (continued)

Problem	Possible cause	Solution
Your print has gaps or appears faint.	Your ink is too old.	Check the expiration date printed on each cartridge. If the cartridge is too old, replace it as described on page 3-7.
	Print options are set incorrectly for the media you're using.	Make sure the Print Mode or Media Type setting is correct for the media you're printing on.
	Print head nozzles are clogged.	Run a nozzle check and cleaning cycle (page 3-1).
	Your ink supply is low.	Check the Ink Out lights and replace ink cartridges if necessary, as described on page 3-7.
	The paper configuration setting is too thick.	Use the control panel to select thinner paper. See page 1-25 for instructions.
	The platen gap setting is too wide.	Use the control panel to change the setting from WIDE to AUTO . See page 1-20 for instructions.
Your print appears blurry or smeared.	Print options are set incorrectly for the media you're using.	Make sure the Print Mode or Media Type setting is correct for the media you're printing on.
	You're using the wrong paper configuration setting (for non-EPSON media).	Use the control panel to register and select your paper thickness and dry time. See page 1-25 for instructions. If you're using the RIP, you can set a dry time between passes in seconds.
	Your paper doesn't meet the required specifications or contains too much moisture.	Change your paper.
	You're printing on the wrong side of the paper or other media.	If you're using roll paper, make sure it's correctly attached to the spindle. See page 1-5 for instructions. If you're using a cut sheet, make sure the printable side is face up.
	Ink has leaked in the paper path.	Wipe the paper path area of the printer with a soft, clean cloth. See page 3-15 for cleaning instructions.
	You're using the High Speed (Bi-directional) setting.	Turn off the High Speed or Bi-directional setting in your print options.
	The paper configuration setting is too thin.	Use the control panel to select thicker paper. See page 1-25 for instructions.
	The platen gap setting is too narrow.	Use the control panel to change the setting from AUTO to WIDE . See page 1-20 for instructions.

Solving Operational Problems


If you can't turn the printer on, if it stops printing unexpectedly, or if nothing prints, check the following:

- The printer is turned on and the **Operate** light is on.
- The printer is plugged securely into a working electrical outlet that's not controlled by a switch or timer.
- If you're using the RIP Station 5100, make sure the interface cable is securely connected to the printer and RIP and the RIP is turned on. Check the RIP Station 5100 *User Guide* for additional troubleshooting solutions.

If none of these suggestions help, try the solutions below:

Operational problems

Problem	Possible cause	Solution
The printer stops printing unexpectedly.	If the Pause light is flashing, the printer is performing a maintenance procedure or waiting for ink to dry.	Check the display message and lights on the control panel. Wait until the Pause light stops flashing.
	An error has occurred.	Check the display message and lights on the control panel. Follow the instructions for the message on page 2-5.
The printer sounds like it's printing, but nothing prints.	The ink valve locks are closed.	Open the ink valve locks, as shown below:



Operational problems (continued)

Problem	Possible cause	Solution
Nothing prints.	The printer is not connected correctly.	Turn off the printer and RIP or computer. Make sure the interface cable is securely plugged in.
		Make sure the interface cable meets the required specifications. See Appendix B or C or the RIP Station 5100 <i>Getting Started</i> guide.
		If you're not using a RIP, make sure the interface cable is directly connected to the computer without passing through a printer switching device, Zip™ drive, or extension cable.
		If you are using Windows NT 4.0, try uninstalling the EPSON printer port. Click Start , point to Programs and EPSON Printers , then click EPSON Printer Port Uninstall . Follow the messages on the screen.
	Your PPD (PostScript printer description) and/or printer driver software are not set up correctly.	Make sure your software is installed correctly and the RIP is selected.
	The printer port setting doesn't match the printer connection port (Windows).	Click Start , point to Settings and select Printers . Right-click EPSON Stylus Pro 9000 or 9500 , then select Properties . Click the Details tab. Make sure your printer driver is selected in the Print using the following driver list. Then select the port to which your printer is connected in the Print to the following port list.
	The printer driver doesn't have enough available memory (Macintosh).	To increase the available memory in your Macintosh, select Control Panel from the Apple menu and double-click the Memory icon. You can increase the size of virtual memory to increase total available memory. Also, quit all unnecessary applications.

Solving Miscellaneous Printing Problems

If your printouts are not what you expected, try the suggestions below:

Miscellaneous printing problems

Problem	Possible cause	Solution
Your print has incorrect or garbled characters.	Your PPD and/or printer driver software are not set up correctly or not selected.	Make sure your software is installed correctly and the RIP or printer is selected.
	You have stalled print jobs.	Clear any stalled print jobs from Monitor3 (Macintosh) or the Progress Meter or Spool Manager (Windows).
	The printer is not connected correctly.	Turn off the printer and RIP or computer. Make sure the interface cable is securely plugged in at both ends. If you are using Windows NT 4.0, try uninstalling the EPSON printer port. Click Start , point to Programs and EPSON Printers , then click EPSON Printer Port Uninstall . Follow the messages on the screen.
Your print has incorrect margins.	Page size or paper size are not set correctly in your application.	Check the settings in your application. Make sure they are within the printer's printable area.
	Paper size is not set correctly in your print options.	Make sure the Paper Size setting in your print options is correct for the paper you're using.
	Paper is loaded incorrectly.	Reload paper, aligning it correctly with the row of holes in the printer. See Chapter 1 for instructions.
	The ROLL MARG (roll paper margin) setting on the control panel is incorrect.	If you're using roll paper, check the setting for ROLL MARG on the Printer Setting Menu. See page 2-8 for more information.
Your image is inverted.	The Flip Horizontal or Mirror setting is selected in your print options.	Turn off the setting. See your RS 5100 <i>User Guide</i> or page B-15 (Macintosh) or C-18 (Windows) in this manual for instructions.

Miscellaneous printing problems (continued)

Problem	Possible cause	Solution
Blank paper is printed.	Your PPD and/or printer driver software are not set up correctly or not selected.	Make sure your software is installed correctly and the RIP or printer is selected.
	Paper size is not set correctly in your print options.	Make sure the Paper Size setting in your print options is correct for the paper you're using.
	You have selected Sheet , but you're using roll paper.	Make sure your Paper Source or Media Option settings are correct.
A ruled line on your print appears to shift.	The print head is out of alignment.	Align the print head as described on page 3-3.
The bottom edge of your print is smeared.	The paper is curled toward the printable side.	Flatten the paper or curl it toward the other side.
	Print options are set incorrectly for the media you're using (for EPSON media).	Make sure the Print Mode or Media Type setting is correct for the media you're printing on.
	You're using the wrong paper configuration setting (for non-EPSON media).	Use the control panel to register and select your paper thickness. See page 1-25 for instructions.
	The platen gap setting is incorrect.	Use the control panel to change the setting from AUTO to WIDE . See page 1-20 for instructions.
Color images print in black only.	Your PPD and/or printer driver software are not set up correctly or not selected.	Make sure your software is installed correctly and the RIP or printer is selected.
	Black printing is selected in your print options.	Make sure color printing is selected.
The printer continues to feed paper after you have cancelled a job.	The printer still has print job data in its buffer.	Press the Pause button on the printer. If you're using the RIP, wait until it is idle. Then press and hold the Pause button to reset the printer.

Miscellaneous printing problems (continued)

Problem	Possible cause	Solution
Printing is too slow.	The resolution or print quality setting in your print options is too high.	Choose a lower resolution for faster printing.
	Your system doesn't have enough resources.	Clear space on your hard drive or run a defragmentation utility.
		Don't run too many applications at the same time.
		Turn off virtual memory.
		Add RAM to your system.
	You're using background printing on a Macintosh.	If you're using the EPSON driver, select EPSON Monitor3 and increase its memory requirements.
		Turn off background printing.
	You're not using ECP or Enhanced mode and/or DMA transfers (Windows).	If your computer supports ECP or Enhanced mode and/or DMA transfers, turn them on to speed up printing. See your computer documentation and page C-30 for more information.

Solving Paper Problems

If paper feed or paper jam problems occur frequently, try one or more of the following solutions:

- When you're loading roll paper, make sure you line up the edge with the row of holes on the printer. Always turn the roll back to remove the slack. See page 1-12 for more information.
- If you're not using a roll of paper that's installed in the printer, secure it with the roll paper belt. See page 1-9 for more information.
- Make sure the paper is not folded, wrinkled, or damp.
- Make sure the printer's environment falls within the required temperature and humidity range.
- Make sure the paper is not too thick or too thin. See pages 1-1 and 5-2 for paper specifications.
- Make sure no foreign objects are inside the printer.


- Make sure the printer isn't located in a brightly lit area. The paper sensor may not be able to operate correctly.
- Make sure the **Print Mode** or **Media Type** setting is correct for the media you're printing on.
- Make sure the platen gap setting is correct for the paper or media you're printing on. See page 1-20 for more information.
- If you're not using EPSON media, make sure you register and select your paper's thickness. See page 1-25 for more information.

Solving Roll Paper Feed Problems




Use the paper guides only if paper is curled and doesn't feed properly. Otherwise, the paper guides may damage your prints.


If your roll paper is curled too tightly and doesn't feed out of the printer, you can use the three paper guides. Extend the guides as shown below:



- If you have the paper hammock set up in front of the printer, extend the paper guides out so they rest on the front of the hammock.




- If you have the paper hammock set up below the printer, extend the paper guides so that they rest on the back of the hammock.




Clearing Paper Jams

When paper gets jammed in the printer, printing stops and you see a **PAPER JAM** message on the control panel display. Follow these steps to clear paper jams:


1. If roll paper is jammed, cut it by hand at the paper slot.
2. Pull the paper set lever all the way up to release the jammed paper.



3. Open the lower cover if necessary.



4. Carefully pull down the jammed paper. **TURN PWR OFF AND ON** is displayed on the control panel.




Note



If you have two rolls of paper installed, make sure you secure the roll that you are not using with the roll paper belt. See page 1-9 for more information.

5. Close the lower cover, if necessary, then press the **Power** button to turn the printer off. Press it again to turn it back on.
6. Make sure the **Paper Out** light is on and **LOAD PAPER** is displayed on the control panel. Then reload your paper.
7. If you're not going to continue printing, make sure the print head is in the home (far right) position, as shown below. If it's not, turn the printer on, wait until the print head moves to the home position, then turn off the printer.



print head

Caution



If the print head is not left in the home position, print quality may decline.

Chapter 5: Specifications

Printing

Printing method	On-demand ink jet
Nozzle configuration	Black: 64 nozzles Color: 64 nozzles for each color (cyan, magenta, yellow, light cyan, light magenta)
Printable columns	
Character mode	10 characters per inch, 437 columns
Raster graphics mode	360 dpi: 15,762 available dots 720 dpi: 31,524 available dots 1440 dpi: 63,048 available dots
Maximum printable width	43.76 inches on 44-inch paper
Maximum resolution	1440 dpi × 720 dpi
Engine reliability	
Total print volume	18,000 B1 images, 30% coverage
Print head life	Two billion dots per nozzle
Periodic maintenance	Waste ink system requires replacement after approximately 12,000 sheets (parts and labor not covered under warranty)
Cutter blade life	Approximately 2,000 B1 sheets (EPSON media up to 4.33 mil thick)
Print direction	Bidirectional or unidirectional (user-selectable)
Control code	ESC/P® Raster
Line spacing	1/6 inch or programmable in 1/360-inch increments
Paper feed speed	200 ± 10 milliseconds per 1/6-inch line
RAM	18MB
Character sets	EPSON Courier 10 characters per inch

Paper

Cut sheet paper specifications

Size	Dimensions in inches (approximate)	Dimensions in millimeters	Thickness
Super B0	44 × 62.2	1118 × 1580	3.15 to 19.7 mil (0.08 to .5 mm)
B0	40.5 × 57.3	1030 × 1456	
Super A0	36 × 50.9	914 × 1292	
A0	33 × 46	841 × 1189	
US E	34 × 44	864 × 1118	
B1	28.7 × 40.5	728 × 1030	3.15 to 59 mil (0.08 to 1.5 mm)
US D	22 × 34	559 × 864	
A1	23.4 × 33	594 × 841	
B2	20.25 × 28.75	515 × 728	
A2	16.5 × 23.4	420 × 594	
Super A3/B	13 × 19	329 × 483	
US C	17 × 22	432 × 559	
B3	14.3 × 20.25	364 × 515	
US B (ledger)	11 × 17	279 × 432	
A3	11.7 × 16.5	297 × 420	

Roll paper specifications

	Maximum roll diameter	Width	Thickness
When using 2 rolls	5.90 in. (150 mm)	13 to 44.02 in.	3.15 to 19.7 mil (0.08 to 0.5 mm)
When using 1 roll	4.05 in. (103 mm)	330 to 1118 mm	


Depending on the media, feed and print quality are guaranteed on paper thicknesses of 3.15 to 4.33 mil (0.08 to 0.11 mm), 64 to 90 gsm.

Poor quality paper may reduce print quality and cause paper jams or other problems. If you encounter problems, switch to a higher grade of paper.

Do not use curled, folded, or deckle-edge paper.

Printable Area

Minimum margins for roll paper and cut sheets:



* Default roll paper top and bottom margins are .59 inches (15 mm). You can set all margins to .12 inches (3 mm) or .59 inches (15 mm) using the control panel. See page 2-8 for instructions.

Environmental

	Operation	Storage	Transit (stored in shipping container)
Temperature	50 to 95 °F (10 to 35 °C)	–4 to 104 °F (–20 to 40 °C) (1 month at 104 °F)	–4 to 140 °F (–20 to 60 °C) (120 hours at 140 °F)
Humidity (without condensation)	20 to 80% RH	20 to 85% RH	5 to 85% RH

Mechanical

Height	49.57 inches (1259 mm)
Width	66.46 inches (1688 mm)
Depth	27.52 inches (699 mm)
Weight	211.64 lb (96 kg), without ink cartridges
Paper feed method	Friction
Paper path	Roll paper or cut sheets with manual insertion

Electrical

	120 V model	220/240 V model
Input voltage range	90 to 132 V	208 to 264 V
Rated frequency range	50 to 60 Hz	50 to 60 Hz
Input frequency range	49 to 61 Hz	49 to 61 Hz
Rated current	1.0 A	0.5 A
Power consumption	Approx. 100 W (ISO 10561 letter pattern) 30W or less in standby mode	

This product is also designed for IT power systems with phase to phase voltage 220–240V. Check the label on the back of the printer for voltage information.

Initialization

Hardware initialization at power on:

- The printer mechanism is set to its initial state.
- The input data buffer and print buffer are cleared.
- The printer returns to the last default settings.

Software initialization when the ESC@ (initialize the printer) command is received:

- The print buffer is cleared.
- The printer returns to the last default settings.

Panel button initialization by pressing the **Pause** button on the control panel for 3 seconds or more:

- The print head is capped.
- Any paper in the printer is ejected.
- The input data buffer and print buffer are cleared.
- The printer returns to the last default settings.

Safety Approvals

Safety standards	UL 1950, CSA 22.2 No. 950
EMC	FCC part 15 subpart B class B, CSA C108.8 class B

Ink Cartridges

Print yield

graphic arts ink	Approx. 28 pages/A0 (720 dpi, 40% duty) Approx. 6,400 pages/A4 (360 dpi, 5% duty)
archival ink	Approx. 30 pages/A0 (720 dpi, 40% duty) Approx. 7,400 pages/A4 (360 dpi, 5% duty)

Cartridge life

graphic arts ink	2 years from production date
archival ink	2 years from production date if unopened; within 6 months after opening package, at 77 °F (25 °C)

Temperature

Storage (uninstalled)	–22 to 104 °F (–30 to 40 °C) 1 month at 104 °F
Storage (installed)	–4 to 104 °F (–20 to 40 °C) 1 month at 104 °F
Transit	–22 to 140 °F (–30 to 60 °C) 1 month at 104 °F, 120 hours at 140 °F
Freezing	5 °F (–15 °C); ink thaws and is usable after at least 3 hours at 77 °F (25 °C)

Dimensions

Width	0.99 in. (25.1 mm)
Depth	10.24 in. (260.0 mm)
Height	4.15 in. (105.3 mm)

Weight Approximately 0.82 to 0.85 lb (370 to 385 g)

Capacity 7.4 oz (220 ml)

Print yield may vary, depending on how often you run print head cleaning cycles and how much you use the printer. Yield of the initial cartridge set is reduced because of ink charging.

Parallel Interface

Forward Channel

Data format	8-bit parallel, IEEE-1284 compatibility mode
Synchronization	$\overline{\text{STROBE}}$ pulse
Handshake timing	BUSY and $\overline{\text{ACKNLG}}$ signals
Signal level	TTL compatible
Connector	57-30360 Amphenol connector or equivalent

Reverse Channel

Transmission mode	IEEE-1284 Nibble mode
Adaptable connector	57-30360 Amphenol connector or equivalent
Synchronization	Refer to the IEEE-1284 specification
Handshaking	Refer to the IEEE-1284 specification
Signal level	IEEE-1284 Level 1 device
Data transmission timing	Refer to the IEEE-1284 specification

ECP Mode

Transmission mode	IEEE-1284 ECP mode
Adaptable connector	57-30360 Amphenol connector or equivalent
Synchronization	Refer to the IEEE-1284 specification
Handshaking	Refer to the IEEE-1284 specification
Signal level	IEEE-1284 Level 1 device
Data transmission timing	Refer to the IEEE-1284 specification

Serial Interface (RS-423 Standard)

Standard	Based on RS-423
Synchronization	Synchronous
Bit rate	Approx. 1.8M bps
Handshaking	X-ON/X-OFF and DTR protocol
Word format	Data bit: 8 bits Parity bit: None Start bit: 1 bit Stop bit: 1 bit
Connector	8-pin mini-circular connector
Recommended cable	ImageWriter® II cable (preferably Belkin brand)

Appendix A: Installing an Interface Card

If you have the RS 5100 or another RIP, you connect it to the printer using the built-in parallel interface. For connectivity without a RIP, you can install one of the following cards:


- EpsonNet Internal Print Server (10BaseT / 100BaseTX) — C823632A
- EPSON FireWire Interface Card (Type B IEEE 1394) — C823722

Before you install the card, see the documentation that came with it for setup information. Then follow these steps:

1. Make sure the printer is turned off and the power cord is unplugged.




To prevent electric shock and avoid damaging the printer, do not install an interface card when the printer is turned on or connected to an electrical outlet.



A-2 | Installing an Interface Card

2. Use a Phillips-head (+) screwdriver to remove the two screws securing the shield plate to the back of the printer. Then lift off the plate.




Be sure to keep the screws so you can use them if you re-install the shield plate.


3. Make sure you set any jumpers or DIP switches on the card. See the card's documentation for details.

On the FireWire card, make sure DIP switch 10 is set to **ON** (advanced mode).

4. Slide the interface card along the slots on both sides of the compartment. Push it in firmly to fully insert the connector into the printer's internal socket.



5. Secure the interface card in the slot with the two screws included with the card.
6. Make sure the printer has been turned off using the **Power** button. Then plug in the power cord.
7. To initialize the EpsonNet Internal Print Server, turn on the printer while holding down the status sheet button on the card for about 5 seconds.
8. Connect the appropriate cable to the card and to your network hub or computer.



To remove an interface card, turn off the printer, unplug the power cord, and follow the above steps in reverse order.

Before you can use the EpsonNet Internal Print Server, you must configure it for your network protocols and operating system. See the *EpsonNet Internal Print Server Administrator's Manual* for instructions.

Before you can print, you must install the printer software, as described on page B-3 (Macintosh) or page C-2 (Windows).

Appendix B: Using EPSON Drivers and Utilities for Macintosh



Even if you're using the RS-5100 RIP, it's a good idea to install the standard EPSON drivers and utilities for easier maintenance and troubleshooting.

Your EPSON Stylus Pro 9000 and 9500 come with drivers that let you use the printer in non-PostScript mode without a RIP. Utilities allow you to manage background printing jobs, track the status of your printer, and run print head maintenance procedures. ICC profiles for ColorSync 3.0 are included, so you can use advanced color management features of your applications or the driver itself.

The driver CD-ROM also includes an electronic *Reference Guide* to your printer and EPSON printer software. You can read the guide using a web browser, such as Netscape Navigator or Microsoft Internet Explorer, versions 3.0 or later.

This chapter includes the following information:

- Connecting the printer
- Setting up your software
- Setting print options
- Managing print jobs
- Checking printer status
- Running print head utilities

Connecting the Printer

You can connect your Macintosh directly using the printer's built-in serial interface, or you use the parallel interface with a conversion cable (such as the EPSON USB adapter, C-USB-PK4). See the appropriate section below for instructions on connecting to the serial or parallel interfaces.


If you connect the EPSON Stylus Pro 9500 to a networked Macintosh, you can use the printer sharing feature to allow network printing. See page B-6 for instructions.

If you installed the optional EPSON FireWire interface or EpsonNet Internal Print Server, you can connect through these interfaces. See Appendix A for instructions.

Connecting to the Printer's Parallel/USB Interface

To connect to the printer's built-in parallel port, you'll need a conversion cable, such as the EPSON USB adapter (C-USB-PK4). Make sure the printer's parallel interface is set to compatible (the default setting), as described on page 2-10.

1. Plug the parallel connector securely into the printer's interface. Then squeeze the wire clips together until they lock into place on both sides.



2. Plug the other end of the cable into a USB port on your Macintosh.

You must install the printer software before using the printer. See page B-4 for instructions.

Connecting to the Printer's Built-in Serial Interface


Follow these steps to use the printer's built-in serial interface:

1. For a serial connection, make sure you have an ImageWriter II cable (preferably Belkin brand).
2. Make sure both your printer and Macintosh are turned off.



Use only an ImageWriter II cable to connect the printer to your Macintosh through the serial interface. Do not use a LocalTalk® cable.

3. Connect one end of the interface cable to the serial connector on the back of the printer.

**Note**

If your Macintosh has a built-in modem, connect the interface cable to the printer port.

4. Connect the other end of the interface cable to either the modem port or printer port on the Macintosh. (Some Macintosh PowerBook® models have only one serial port.)
5. Turn on the printer by pressing the **Power** button.
6. Turn on your Macintosh.

See the next section for instructions on installing the printer software. You must install the printer software before using your printer.

Setting Up Your Software

You need to install the drivers and utilities on any Macintosh that will print to the EPSON Stylus Pro 9000 or 9500. Make sure each Macintosh meets the minimum system requirements. Then follow the procedure for installing the software. Depending on your network configuration, you may also want to set up printer sharing if you have the EPSON Stylus Pro 9500.

Checking System Requirements

Make sure your Macintosh meets the requirements listed in the table below. The memory requirements are for printing a 40 × 57-inch full-page color image. Requirements may vary, depending on the size, complexity, and resolution of your images.

System requirements

Component	Minimum	Recommended
Processor	PowerPC	300 MHz G3 or higher processor
OS	System 8.5.1	System 9.0.4 recommended for best USB support
Available memory	14MB (foreground printing) 23MB (background printing)	128MB (total)
Hard disk	12MB free for installing the software	2GB recommended
CD-ROM	Double-speed CD-ROM drive	Quad-speed or faster

Installing the Software

Before you start, turn off all virus protection programs. See your anti-virus software documentation for instructions. Then follow these steps to install your printer software:

1. Insert your printer software CD-ROM.
2. Open the **Installer** folder and double-click the icon. Then follow the instructions on the screen.
3. When you see the “installation complete” message, click **Restart**.

Follow the steps in the next section to select your printer using either the serial interface or an AppleTalk® connection.

Selecting Your Printer in the Chooser




Note

If you are using an AppleTalk network, an alert message may appear when you click the port. In this case, reselect the other port or make the AppleTalk setting **Inactive**, then select the port again.


If you are using your Macintosh in an Ethernet environment, you can connect your printer to either the printer or modem port and leave the AppleTalk setting **Active**.

After you install the software, you need to open the Chooser to select your printer. Follow these steps:

1. Make sure the printer is connected to your Macintosh and turned on.
2. Open the Chooser.
 - If you're using a serial connection, click the **SPro 9000** or **SPro 9500** icon and the port your printer is connected to.



- If you're using an AppleTalk network, click the **SPro 9000(AT)** or **SPro 9500(AT)** icon and select the AppleTalk zone you want to use. A list of all the printers connected to the selected zone appears on the right.



Click the name you assigned to your printer, then click OK.


3. Click one of the buttons to turn background printing on or off.
4. Close the Chooser.

Setting Up Printer Sharing

If you want to share the EPSON Stylus Pro 9500, you first need to set it up as a shared printer on the Macintosh to which it is connected. Then, you must specify the network path to the printer from each Macintosh that will use it, and install the printer software on those Macintosh systems.

Follow these steps to share a printer connected directly to a Macintosh with other systems on an AppleTalk network.


1. Turn on the printer.
2. Open the Chooser and click the printer's icon. Then select the port to which the printer is connected.



3. Click the **Setup** button. You see the following dialog box:



4. Check **Share this Printer**, then type the printer name and password information as needed.
5. Click **OK**. The name of the shared printer appears in the port list in the Chooser.
6. Close the Chooser.
7. On each computer from which you want to access the printer, open the Chooser, click the printer's icon, and select the printer port. You can only select from the printers connected to your current AppleTalk zone.



8. If you see a message requesting a password, enter the password for the printer, then click **OK**.
9. Select the appropriate **Background Printing** option, then close the Chooser.

Setting Print Options

When you're ready to print from an application, you need to choose page setup options and print options. The EPSON drivers offer automatic settings that optimize print quality and speed when you're using EPSON media. You can also choose advanced settings for more control over your printer and color management options.

This section covers the following:

- Choosing page setup options
- Choosing basic print options
- Choosing advanced print options



Many application settings override the printer's Page Setup options. Always verify settings to get the results you expect.




If you need more information about Print Options, you can click the ? button on any dialog box.


Choosing Page Setup Options

Many of the Page Setup options correspond to paper handling features that you can also set through the control panel. Software options give you additional settings and override control panel settings. Follow these steps to choose Page Setup options:

1. Choose **Page Setup** from the File menu. You see the Page Setup dialog box:



EPSON Stylus Pro 9000



EPSON Stylus Pro 9500

Click if your paper size is not listed.



If you're using roll paper and you choose a paper size that's larger than your image, the image will be centered in the space you selected.



These settings override settings made through the control panel.


2. From the **Paper Size** list, select your image size (if you're using roll paper) or the size of your sheet. For paper size equivalents in inches, see page 5-2. If your size is not listed, click **Customize**. Then enter the size in hundredths of an inch (or centimeters).
3. Select the type of paper you loaded in the printer from the **Paper Source** list.

If your image is more than 62 inches long, select **Roll Paper (Banner)** (EPSON Stylus Pro 9500 only). You can also use this setting to print a series of continuous images without any "margin space" between them.
4. When you're using roll paper, set the following options:
 - **Auto Rotate**
Saves paper if your document length is shorter than the printable width of the paper roll. Your image will be turned automatically by 90 degrees and printed crosswise.
 - **Auto Cut**
Choose this option if you want the paper to be cut automatically after each page is printed.
 - **Print Page Line**
Prints trim lines on the right and bottom edges of your pages.
 - **Save Roll Paper**
Saves paper by not feeding the blank portion of the last page of your document. Applicable in Roll Paper (Banner) mode (EPSON Stylus Pro 9500) only.
5. Make the settings you want for **Orientation**, **Reduce or Enlarge**, and **Printable Area**.
6. After making your settings, click **OK**.

Choosing Basic Print Options

Once you have selected your Page Setup options, you need to set printing options. See page B-14 for instructions on advanced settings. Follow these steps to make basic settings for automatic printer adjustments:


1. Choose **Print** from the **File** menu of your application. A dialog box like the following appears:



This box shows you the current settings, but you can't change them from here.

These settings appear only if you're using Photoshop 5.x. See page B-11 for more information.

EPSON Stylus Pro 9000



EPSON Stylus Pro 9500

2. Choose the number of **Copies** and indicate which **Pages** you want to print.
3. Select a **Media Type** setting appropriate for the media you're printing on, as listed in the table on page B-12 or B-13.
4. Select **Color** or **Black** ink.

5. Set the **Mode** option as follows:
- Click **Automatic** to have the printer driver analyze the contents of your image or file and make the appropriate printing adjustments. If a **Quality/Speed** slider appears in the Mode box, set it according to the priorities of your print job. (Depending on the Media Type setting, this slider may not appear.)
 - For the EPSON Stylus Pro 9500, click **PhotoEnhance** to choose from a number of settings designed for low-resolution photographs: **Standard**, **People**, **Nature**, **Soft Focus**, and **Sepia**. You can also select **Digital Camera Correction** to correct noise and other flaws common to digital camera images. (For the EPSON Stylus Pro 9000, these options are available from the Custom settings list or on the Advanced settings window.)
 - Click **Custom** and then choose one of the print job types from the custom settings list, as described below.



Note

You can also create your own settings and add them to this list. See page B-16 for more information.

Custom print job settings

Setting	Usage
Advanced Photo	Prevents the misprinting of ink dots that may occur because of the movement of the print head and paper. Available only when you choose photo or photo-quality media types.
Text/Graph	Intensifies colors and lightens the midtones and highlights. Best for print jobs with non-photographic images.
ColorSync®	Adjusts colors based on your printer's ICC profile, using the perceptual rendering intent.

6. If you're using Photoshop® 5.0 or later, you'll see settings for **Space** and **Printer Color Management** in your dialog box.

For standard RGB images, use **RGB Color** for the **Space** setting. Make sure **Printer Color Management** is checked if you're using ColorSync. (otherwise, this setting doesn't matter).

For CMYK images, use your printer profile for the **Space** setting and choose **No Color Adjustment** on the Advanced window. See page B-16 for more information.

7. Choose from the following buttons to access additional features:
- Click  to access the printer monitoring and maintenance utilities. See page B-24 for more information.
 - Click  if you want to reduce your image to fit on the page.
 - Click  to turn on background printing. This lets you use the Monitor3 utility. See page B-18 for more information.
 - Click  and then click the **Preview** button to preview your print.
 - Click  to check your ink levels (EPSON Stylus Pro 9500 only).
8. When you're finished choosing print options, click **Print**.

Selecting the Correct Media Type

The following tables list the settings to use with EPSON media:

EPSON Stylus Pro 9000 Media Type settings



Check the EPSON web site (<http://prographics.epson.com>) or your authorized EPSON dealer for new papers and other media that may be available. Some media may not be available in your location.

Product name	Product codes	Media Type setting
Presentation Matte Paper	S041220, S041221, S041295	1440 dpi printing: Photo Quality Ink Jet Paper Lower resolution printing: Presentation Matte Paper
Glossy Paper Heavyweight	S041226, S041227, S041291	Photo Paper
Semigloss Paper Heavyweight	S041228, S041229, S041292	Semigloss Photo Paper
Photo Glossy Paper	SP91002, SP91001, SP91021	Photo Quality Glossy Film
Photo Semigloss Paper	SP91004, SP91003, SP91022	Photo Quality Glossy Film
Backlight Film	SP91008, SP91007, SP91023	Photo Quality Glossy Film
Posterboard Semigloss	S041236, S041237	Semigloss Photo Paper
Premium Luster Photo Paper	*	Photo Quality Glossy Film

* Not available at time of printing. Check the EPSON web site for product code and availability.



Check the EPSON web site (<http://prographics.epson.com>) or your authorized EPSON dealer for new papers and other media that may be available. Some media may not be available in your location.



If the paper or other material you're using is not listed in the tables, check the instructions included with the paper. If you're using a non-EPSON printing material, choose the closest setting. You may have to experiment to determine which setting is best for the substrate you're using.

EPSON Stylus Pro 9500 Media Type settings


Paper type	Product code	Media Type setting
Doubleweight Matte Paper	S041385, S041386, S041387,	Doubleweight Matte Paper
Glossy Paper Photo Weight	S041389, S041388	Glossy Paper - Photo Weight
Premium Semigloss Photo Paper	S041327	Premium Semigloss Photo Paper
Smooth Fine Art Paper	S041431, S041432, S041433, S041434, S041435	*
Backlight Film for Archival Ink	*	
Synthetic Paper	S041399, S041400, S041401,	Synthetic Paper
Adhesive Synthetic Paper	S041402, S041403, S041404,	Adhesive Synthetic Paper
Photo Glossy Paper	SP91002, SP91001, SP91021	Premium Semigloss Photo Paper
Photo Semigloss Paper	SP91022, SP91003, SP91004	Premium Semigloss Photo Paper
Adhesive Vinyl	S041436, S041437, S041438	Adhesive Synthetic Paper
Canvas	*	
Premium Luster Photo Paper	*	Premium Semigloss Photo Paper
Semimatte Paper Photo Weight	*	Glossy Paper - Photo Weight
Posterboard for Archival Ink	*	
Textured Fine Art Paper	S041449, S041448, S041447, S041451, S041450	*
Translight	*	
Tyvek	*	
Scrim Vinyl	*	

* Not available at time of printing. Check the EPSON web site for driver updates, product codes, and media availability.

Choosing Advanced Print Options


The advanced print options give you complete control over your printing environment. Use these settings to experiment or to fine-tune a range of options to meet your individual needs. Follow these steps to print with advanced settings:

1. Follow steps 1 through 4 on page B-10.
2. Click **Custom** and then click **Advanced**. You see a dialog box like the following:



Each of these three configurations gives you different options on the lower part of the screen.

EPSON Stylus Pro 9000



EPSON Stylus Pro 9500

3. Choose the **Media Type** setting according to the guidelines on page B-12 or B-13. Then choose **Color** or **Black** ink.

4. Choose one of the following **Print Quality** settings:

- **Economy**
- **Normal - 360dpi**
- **Fine - 720dpi**
- **Superfine - 1440dpi**

The available print quality settings may be limited by the **Media Type** setting. Choose lower print quality for faster printing, or **Superfine - 1440dpi** for best quality.

5. Choose any of the following:

- **Super MicroWeave**
The **MicroWeave** and **Super MicroWeave** settings eliminate unwanted banding effects. These settings are automatically selected for all media types except plain paper.
- **High Speed**
For fast, bidirectional printing at lower quality. If vertical lines in your printout are misaligned when you use the **High Speed** setting, you may need to turn it off or align the print head.
- **Flip Horizontal**
For printing a mirror image of your file. Use with backlight film.

6. Choose one of the following **Color Management** configurations:

- **Color Controls (Color Adjustment)**
This configuration lets you specify individual values for adjusting brightness, contrast, saturation, and CMY inks, or choose from the Color Adjustment modes shown in the table on page B-16. (For the EPSON Stylus Pro 9500, you can also choose from three Gamma settings, which control image contrast by modifying the midtones and midlevel grays.) When you print on EPSON backlight film, choose **Vivid** mode and **+10 Saturation**.
- **PhotoEnhance4 (PhotoEnhance3)**
When you choose this configuration, you see a sample image that reflects the settings you choose. See page B-17 for a description of the available settings.

- **ColorSync**
This configuration lets you select the **Epson Standard** profile, created specifically for your printer. Don't select any other printer profile you may have on your system. Then choose from three Rendering Intent settings for mapping colors to your printer's profile. See page B-17 for more information.
 - **No Color Adjustment**
This setting disables color management in the printer driver. Choose this mode if you want to use a standalone color management mode (available under the Mode list on the EPSON Stylus Pro 9000).
7. Click **Save Settings** if you want to have your advanced settings available for reuse. Then type a name for the group of settings and click **Save**. The name is added to your list of custom settings.
8. When you're finished setting advanced printer options, click **OK**.

Color Management Settings

The following tables list the color management settings available when you choose either Color Controls (Adjustment), PhotoEnhance, or ColorSync.

Color adjustment modes

Automatic	Analyzes the color information in your image and optimizes color correction accordingly.
Photo-realistic	Produces sharper images and more vivid colors by automatically adjusting the contrast, saturation, and brightness. Corrects for overall under- or over-exposure of the original image.
Vivid	Intensifies colors and lightens the midtones and highlights. Best for print jobs with non-photographic images.
1.5 Gamma	Produces the same contrast values as earlier EPSON ink jet printers.
1.8 Gamma	Increases contrast.
2.2 Gamma	Matches image colors with sRGB devices.

PhotoEnhance settings

Tone	Lets you choose from Normal for standard images, Hard for high contrast, and Sepia for an old-fashioned look. Vivid and Monochrome settings also available on the EPSON Stylus Pro 9500.
Effect	Lets you choose from 4 special effects (and set the intensity): Sharpness , Soft Focus , Canvas , and Parchment (EPSON Stylus Pro 9500 only).
Digital Camera Correction	Corrects noise and other flaws common to digital camera images.

ColorSync Rendering Intent settings

Perceptual	For photographic images. Maintains the relationship between colors as it scales them to fit within your printer's color gamut.
Saturation	For charts and business graphics. Maintains the relative saturation of colors from one gamut to another.
Colorimetric	For projects with known colors, such as labels and packaging. Maintains colors that fall within the gamut of both your monitor and printer.

Managing Print Jobs

Your printer comes with several utilities that let you check on your print jobs and schedule, cancel, pause, or restart them. First you need to set up background printing, so you can continue to work on your Macintosh while a file is being printed. Note that background printing is slower and may also slow down your system.


This section includes instructions for the following:

- Setting up background printing
- Using Monitor3
- Cancelling printing

Setting Up Background Printing

You can set up background printing from the Chooser, as described on page B-6, or you can use the background printing button on the Print dialog box. Follow these steps to set up background printing:

1. Choose **Print** from the File menu.
2. Click the background printing button . You see the following dialog box:



3. To turn background printing on, click the **On** button.
4. To select a priority for your print job in the queue of jobs waiting to print, click one of the following:
 - **Urgent** to print before any Normal priority job
 - **Normal** to print in the order the job is received
 - **Print at:** to print at the specific time you enter in the day and time in the fields to the right
 - **Hold** to hold the print job in the print queue until you're ready to release it using Monitor3; see the following section for details.
5. Click **OK** to save your settings and return to the printer settings dialog box.
6. Click **Print** to print your document.

If you selected **Print at:** or **Hold**, your document is spooled, but held in the print queue until the print time specified or until released using Monitor3, as described in the following section.


Using Monitor3

The Monitor3 utility lets you prioritize and control your print jobs as well as monitoring their progress.

After you send a print job, click the current application icon at the right end of the menu bar and select **EPSON Monitor3**. You see a window like the following:



The Monitor3 window for the EPSON Stylus Pro 9000 is slightly different.



The progress bar tracks the current print job. To cancel, pause, or restart a print job, click the document's name, then click one of the following buttons:

- Click to delete
- Click to restart
- Click to pause


You can also do the following:

- Double-click a file in the list to preview it
- Double-click **Copies** to change the number of copies to be printed
- Click to check your ink levels (EPSON Stylus Pro 9500 only)
- Click to start the print head cleaning utility (EPSON Stylus Pro 9500 only). See page B-24 for more information about the cleaning utility.

If you want to change the printing priority of a print job or set a specific time for it to print, click the **Show details** arrow at the bottom of the window. The **Priority** list becomes active.



If you see a stop sign icon and the message Print queue on hold in the EPSON Monitor3 dialog box, select **Start print queue** from the Printer menu to release the queue and resume printing.



Click the print job whose priority you want to change. Then click the **Priority** list box and select one of the following settings:

- **Normal** prints the job in the order it is received
- **Urgent** moves the job before Normal priority jobs in the print queue
- **Hold** holds the job in the print queue until you're ready to release it for printing by clicking  restart
- **Print Time** opens the Set Print Time dialog box. Enter the date and time you want to print the document, then click OK.



Cancelling Printing

If you need to cancel a print job, follow these steps:

1. Press the **Power** button to turn off the printer.
2. Do one of the following, depending on whether you're using background printing:
 - If background printing is turned off, hold down the **⌘** key on your keyboard and press the **(.)** period key to cancel the print job.
 - If background printing is turned on, select **EPSON Monitor3** from the application menu and click **Stop Print Queue** (EPSON Stylus Pro 9500 only). Or, click the  button, then click the stop button  to cancel the print job.


Checking Printer Status

The Status Monitor utility lets you check the levels of ink in your printer and configure error messages and other features of printer operation.

Follow these steps to check ink levels:


1. Click the utility button  on the Print or Page Setup dialog box. You see the Utility menu:

Click to open the Status Monitor utility.



2. Click the **EPSON StatusMonitor** icon.

The software checks the amount of ink remaining in the printer and displays the Status Monitor window:



Click to recheck
ink levels.


3. To recheck the ink level check, click the **Update** button. To close the Status Monitor, click **OK**.

Selecting Configuration Options

You can configure the way you want the printer to handle error and warning messages, ink level checks, and print file handling in the Configuration Settings dialog box. Follow these steps:

1. Click the utility button  on the Print or Page Setup dialog box. You see the Utility menu.
2. Click the **Configuration** button.

You see the Configuration Settings dialog box:



3. Select from the following configuration options:



Note

Warning messages allowing printing to continue. Error messages are more serious and cause printing to stop.

- **Error notification** lets you choose whether you want your system to beep and display error message text or just display text if your printer encounters an error.
 - **Warning** lets you choose whether warning messages beep and display text or display text only.
 - **Temporary Spool folder** and **Temporary High Speed Copies folder** let you select the folders on your hard disk that store the temporary files created when you send a job to the printer. Click the **Select** button to change the folder from the default folder shown.
 - **Data will be sent to the printer after being stored on your disk** prevents print head pausing. Normally, graphics are sent in rectangular bands. When you select this option, your Macintosh stores the entire image on its hard drive and then sends it to the printer as a whole (recommended only for older Macintosh systems; available on the EPSON Stylus Pro 9500 only).
 - The last two checkboxes let you choose to have your software check for errors or low ink levels before starting your print job.
4. When you're finishing changing your configuration options, click **OK** to return to the Utility menu.

Running Print Head Utilities

The utilities included with your printer software let you run the following maintenance procedures from your computer:


- Nozzle check
- Print head cleaning
- Print head alignment

Running Nozzle Check and Head Cleaning Utilities

The nozzle check prints a pattern of dots that lets you see if any print head nozzles are clogged. If any dots are missing from the pattern, you can run a head cleaning cycle to clear the nozzles.

Follow these steps:

1. Click the utility button  on the Print or Page Setup dialog box. You see the Utility menu:



2. Click the button for the utility you want to run.
3. Follow the instructions on the screen to complete the process. For more information, see Chapter 3.

Running the Print Head Alignment Utility



If banding appears on your prints, or vertical lines are not straight, you need to align the print head. You can also use the control panel to align the head (as described in Chapter 3). Both procedures align the head for all modes and resolutions.

For the EPSON Stylus Pro 9000, use 13 × 19-inch EPSON coated ink jet paper (short edge first). You'll need 4 sheets to complete the procedure, which includes 12 patterns of 7 rows each and takes about 15 minutes.


For the EPSON Stylus Pro 9500, you can use EPSON roll paper. Six patterns of 15 lines or boxes are printed, which takes about 10 minutes. The patterns are repeated across the width of the page.

Follow these steps:

1. Load a paper in the printer.
2. Click the utility button  in the Print or Page Setup dialog box.
3. Click the **Print Head Alignment** button.
4. Follow the messages on your screen. The printer prints the head alignment patterns. If you're using cut sheet paper, remove each sheet after printing and load another sheet.
5. After all the patterns have printed, do one of the following:
 - For the EPSON Stylus Pro 9000, choose the row number that has the smallest gap in each pattern. In the first example below, row 4 has the smallest gaps. In the second, row 6 has the smallest gaps.




- For the EPSON Stylus Pro 9500, choose the line or box number that has the smallest gaps. In the example below, line 8 has the smallest gaps in each pattern.



This window is for the EPSON Stylus Pro 9500. If you have the 9000, you will see 12 choices instead of 6.

6. Select the row you chose in step 5 for each pattern (for example, line 8) then click **Finish**.



If you can't make a consistent choice for the patterns as you look across the width of the paper, choose the average or most frequent number. Then click the **Realignment** button and repeat from step 5.

Appendix C: Using EPSON Drivers and Utilities for Windows

Your EPSON Stylus Pro 9000 and 9500 come with drivers that let you use the printer in non-PostScript mode without a RIP. Utilities allow you to manage print jobs, track the status of your printer, and run print head maintenance procedures. ICC profiles are included, so you can use advanced color management features of your applications or the driver itself.

The driver CD-ROM also includes an electronic *Reference Guide* to the EPSON Stylus Pro 9500 and printer software. You can read the guide using a web browser, such as Netscape Navigator or Microsoft Internet Explorer, versions 3.0 or later.

This chapter includes the following information:

- Connecting the printer
- Setting up your software
- Setting print options
- Managing print jobs
- Checking printer status
- Running printer utilities

Connecting the Printer

You can connect your computer's parallel port using the printer's built-in parallel interface. You can also use a conversion cable (such as the EPSON USB adapter, C-USB-PK4) to connect to a USB port on your computer.

If you connect the EPSON Stylus Pro 9500 to a networked computer, you can use the printer sharing feature to allow network printing. See page C-5 (Windows 95/98) or C-8 (Windows NT 4.0/2000) for instructions.

If you installed the optional EPSON FireWire interface or EpsonNet Internal Print Server, you can connect through these interfaces. See Appendix A for instructions.




Note

To connect to a USB port, you'll need a conversion cable, such as the EPSON USB adapter (C-USB-PK4). Make sure the printer's parallel interface is set to compatible (the default setting), as described on page 2-10.

Make sure both your printer and computer are turned off. Then follow these steps to use the printer's built-in parallel interface:

1. Plug the cable connector securely into the printer's interface. Then squeeze the wire clips together until they lock into place on both sides.



2. Plug the other end of the cable into the computer's parallel (or USB) port.

See the next section for instructions on installing the printer software. You must install the printer software before using your printer.

Setting Up Your Software

Before you install the drivers and utilities, you need to make sure your computer meets the minimum system requirements. Then follow the procedures for installing the software. Depending on your network configuration, you may also want to set up printer sharing. Instructions are provided for both Windows 95/98 and Windows NT 4.0/2000. This section covers:

- Checking system requirements
- Installing the software
- Setting up printer sharing

Checking System Requirements

Make sure your computer meets the requirements listed in the table below. The memory requirements are for printing a 40 × 57-inch full-page color image. Requirements may vary, depending on the size, complexity, and resolution of your images.

System requirements

Component	Minimum	Recommended
Processor	i486/25 MHz for Windows 95 and NT 4.0 i486/66 MHz for Windows 98 Pentium 133 MHz for Windows 2000	Pentium® II 300 MHz or higher
OS	Windows 95, Windows 98, 2000, or Windows NT 4.0 (service pack 4 or later)	
Available memory	16MB RAM for Windows 95/98 or NT 4.0 64MB RAM for Windows 2000	128MB RAM or more
Hard disk	20MB free for Windows 95 and 98 40MB free for Windows NT 4.0 and 2000	For printing a file, space equivalent to double the file size
Monitor	VGA	Super VGA or better
CD-ROM	Double-speed CD-ROM drive	Quad-speed or faster

Installing the Software

Make sure any virus protection programs are turned off before you begin. Then follow these steps to install your printer software:

1. Make sure the printer is connected and turned off, then turn on your computer.
2. Insert your printer software CD-ROM.

The installer starts automatically:



Note

If the New Hardware Found screen or any other wizard appears, click **Cancel** and follow the steps given here. If the Digital Signature Not Found screen appears (in Windows 2000), click **Yes**.

If it doesn't start, double-click **My Computer**. Then double-click your CD-ROM icon.

3. Double-click **Install Stylus Pro 9000 or 9500 Printer Driver**. (Make sure you choose the right one.) Then follow the instructions on the screen.
4. If you're using Windows 95 or Windows NT, continue with step 5.
If you're using Windows 98 or Windows 2000, follow the on-screen instructions to turn on your printer. The printer port configuration starts automatically. If you're using a USB interface, the USB device driver installation starts automatically.
If you see an error message, your drivers may not be installed correctly. For more information, see Chapter 4 in this guide or "Troubleshooting" in the electronic *Reference Guide* on your printer software CD-ROM.
5. When you see the "installation complete" message, click **OK** and restart your system if necessary.

Setting Up Printer Sharing in Windows 95 and 98

First, you need to set up the printer as a shared printer on the computer to which it is connected. Then, you must specify the network path to the printer from each computer that will use it, and install drivers on all client systems.

Setting up the printer as a shared printer

Follow these steps to share a printer that is connected directly to your computer with other computers on a network.

1. Click **Start**, point to **Settings**, then click **Control Panel**.
2. Double-click **Network**.
3. Click the **File and Print Sharing** button. You see the following:




4. Select **I want to be able to allow others to print to my printer(s)** and click **OK**.
5. In the **Network** window, click **OK**.

If you see a message requesting the Windows 95 or 98 CD-ROM, insert the CD-ROM (or navigate to the location of your CAB files) and follow the messages on the screen. Restart your computer if requested. Then open the **Printers** folder, and continue from step 7.

6. In the **Control Panel**, double-click **Printers**.

7. Select your printer, and choose **Sharing** from the File menu. You see the following:




8. Select **Shared As**, enter a name and other information if you want, then click **OK**.

Accessing the printer through a network


To access the printer from another computer on your network, follow these steps.

1. On the computer from which you want to access the printer, click **Start**, point to **Settings**, and click **Printers**.
2. Double-click the **Add Printer** icon. You see the Add Printer Wizard.

3. Click **Next**. You see a window like the following:



4. Click **Network printer**, then click **Next**.
5. Click **Browse**. You see a window like the following:



6. Double-click the icon of the computer that is directly connected to the printer. Then click the printer's icon.
7. Click **OK** and follow the messages on the screen.

Setting Up Printer Sharing in Windows NT 4.0 and 2000


These instructions apply to users on a small network only. If you are on a large network and would like to share your printer, consult your network administrator.

First, you need to set up the printer as a shared printer on the computer to which it is connected. Then, you must specify the network path to the printer from each computer that will use it, and install the printer software on those computers.

Setting up your printer as a shared printer

Follow these steps to share a printer that is connected directly to your computer with others on a network.

1. Click **Start**, point to **Settings**, and click **Printers**.
2. Select your printer, then click **Sharing** on the File menu. You see a window like the following:




3. Click **Shared** and enter the Share Name. Do not choose any drivers from the Alternate Drivers list. Then click **OK**.


Accessing the printer through a network

To access the printer from another computer on your network, follow these steps.


1. Install the printer driver on the client computer from the software CD-ROM.
2. Open the Printer folder from the Control Panel, right-click your printer's icon, then click **Properties**.
3. Click the **Ports** tab to display the following window:



4. Click **Add Port**. You see the Printer Ports dialog box:



5. Select **Local Port**, then click **New Port**. You see the Port Name dialog box:



6. In the text box, type the following information:
\\name of computer that is connected to the printer\name of the shared printer
Then click **OK**.
7. Click **Close** to return to the Ports list.
8. Make sure the new port is added and the check box is selected. Then click **OK**.

Setting Print Options

When you're ready to print from an application, you need to choose print options and paper options. The EPSON driver offers automatic settings that optimize print quality and speed when you're using EPSON media. You can also choose advanced settings for more control over your printer and color management options.

This section covers the following:

- Choosing basic print options
- Choosing paper options
- Choosing advanced print options

Choosing Basic Print Options

Before you print, you need to set basic printing properties. See page C-16 for instructions on advanced settings. Follow these steps to make basic settings for automatic printer adjustments:

1. Choose Print from the File menu of your application. You see the Print dialog box.
2. Make sure your EPSON Stylus Pro 9000 or 9500 printer is selected, and then click the **Properties** button. (If you see a **Setup**, **Printer**, or **Options** button, click it instead. Then click **Properties** on the next window.)

A dialog box like the following appears:



EPSON Stylus Pro 9000

This box shows you the current settings, but you can't change them from here.



EPSON Stylus Pro 9500

3. Select a **Media Type** setting appropriate for the media you're printing on, as listed in the table on page C-13 or C-14.
4. Select **Color** or **Black** ink.

5. Set the **Mode** option as follows:
- Click **Automatic** to have the printer driver analyze the contents of your image or file and make the appropriate printing adjustments. If a **Quality/Speed** slider appears in the Mode box, set it according to the priorities of your print job. (Depending on the Media Type setting, this slider may not appear.)
 - For the EPSON Stylus Pro 9500, click **PhotoEnhance** to choose from a number of settings designed for low-resolution photographs: **Standard**, **People**, **Nature**, **Soft Focus**, and **Sepia**. You can also select **Digital Camera Correction** to correct noise and other flaws common to digital camera images. (For the EPSON Stylus Pro 9000, these options are available from the Custom settings list on the Advanced settings window.)
 - Click **Custom** and then choose one of the print job types from the custom settings list, as described below.

Custom print job settings

Setting	Usage
Text/Graph	Intensifies colors and lightens the midtones and highlights. Best for print jobs with non-photographic images.
ICM	Adjusts colors based on your printer's ICC profile, using the Image Color Matching system (effective in Windows 98/2000 only). If you're using an ICM-compatible monitor, adjusts printed colors to closely match screen colors.
sRGB	Adjusts colors using the small-gamut sRGB (standard red green blue) color space. Best for color matching with other sRGB devices, or for images designed for the Web.



You can also create your own settings and add them to this list. See page C-19 for more information.

6. When you're finished choosing print options, click the **Paper** tab and follow the instructions on page C-15 for choosing paper and layout options.

Selecting the Correct Media Type

The following tables list the settings designed to produce the best prints on EPSON media:

EPSON Stylus Pro 9000 Media Type settings



Note

Check the EPSON web site (<http://prographics.epson.com>) or your authorized EPSON dealer for new papers and other media that may be available. Some media may not be available in your location.

Product name	Product codes	Media Type setting
Presentation Matte Paper	S041220, S041221, S041295	1440 dpi printing: Photo Quality Ink Jet Paper Lower resolution printing: Presentation Matte Paper
Glossy Paper Heavyweight	S041226, S041227, S041291	Photo Paper
Semigloss Paper Heavyweight	S041228, S041229, S041292	Semigloss Photo Paper
Photo Glossy Paper	SP91002, SP91001, SP91021	Photo Quality Glossy Film
Photo Semigloss Paper	SP91004, SP91003, SP91022	Photo Quality Glossy Film
Backlight Film	SP91008, SP91007, SP91023	Photo Quality Glossy Film
Posterboard Semigloss	S041236, S041237	Semigloss Photo Paper
Premium Luster Photo Paper	*	Photo Quality Glossy Film

* Not available at time of printing. Check the EPSON web site for product code and availability.

For EPSON Photo Quality Ink Jet Paper, Photo Paper, and Photo Quality Glossy Film, use the corresponding Media Type setting.



Check the EPSON web site (<http://prographics.epson.com>) or your authorized EPSON dealer for new papers and other media that may be available. Some media may not be available in your location.



If the paper or other material you're using is not listed in the tables, check the instructions included with the paper. If you're using a non-EPSON printing material, choose the closest setting. You may have to experiment to determine which setting is best for the substrate you're using.

EPSON Stylus Pro 9500 Media Type settings

Paper type	Product code	Media Type setting
Doubleweight Matte Paper	S041385, S041386, S041387,	Doubleweight Matte Paper
Glossy Paper Photo Weight	S041389, S041388	Glossy Paper - Photo Weight
Premium Semigloss Photo Paper	S041327	Premium Semigloss Photo Paper
Smooth Fine Art Paper	S041431, S041432, S041433, S041434, S041435	*
Backlight Film for Archival Ink	*	
Synthetic Paper	S041399, S041400, S041401,	Synthetic Paper
Adhesive Synthetic Paper	S041402, S041403, S041404,	Adhesive Synthetic Paper
Photo Glossy Paper	SP91002, SP91001, SP91021	Premium Semigloss Photo Paper
Photo Semigloss Paper	SP91022, SP91003, SP91004	Premium Semigloss Photo Paper
Adhesive Vinyl	S041436, S041437, S041438	Adhesive Synthetic Paper
Canvas	*	
Premium Luster Photo Paper	*	Premium Semigloss Photo Paper
Semimatte Paper Photo Weight	*	Glossy Paper - Photo Weight
Posterboard for Archival Ink	*	
Textured Fine Art Paper	S041449, S041448, S041447, S041451, S041450	*
Translight	*	
Tyvek	*	
Scrim Vinyl	*	

* Not available at time of printing. Check the EPSON web site for driver updates, product codes, and media availability.


Note

Many application settings override the printer's Paper options. Always verify settings to get the results you expect.


Choosing Paper and Layout Options

Many of the paper options correspond to paper handling features that you can also set through the control panel. Software options give you additional settings and override control panel settings. Follow these steps to choose paper and layout options:

1. From the Main Print Properties box, click the **Paper** tab. You see the Paper dialog box:



EPSON Stylus Pro 9000



EPSON Stylus Pro 9500

Note

If you're using roll paper and you choose a paper size that's larger than your image, the image will be centered in the space you selected.

2. Select the type of paper you loaded in the printer from the **Paper Source** list.
3. From the **Paper Size** list, select your image size (if you're using roll paper) or the size of your sheet. For paper size equivalents in inches, see page 5-2. If your size is not listed, select **User Defined**. Then enter the size in hundredths of an inch (or centimeters).


4. When you're using roll paper, set the following options:
 - **Auto Rotate**
Saves paper if your document length is shorter than the printable width of the roll. The document will be turned automatically by 90 degrees and printed crosswise.
 - **Auto Cut**
Choose this option if you want the paper to be cut automatically after each page is printed.
 - **Print Page Line**
Prints trim lines on the right and bottom edges of your pages.
 - **Save Roll Paper**
Saves paper by not feeding the blank portion of the last page of your document. Applicable in Roll Paper (Banner) mode (EPSON Stylus Pro 9500) only.
5. Make the settings you want for **Orientation**, **Copies**, and **Printable Area**.
6. If you want to reduce or enlarge your image, click the **Layout** tab (EPSON Stylus Pro 9500 only).
7. Choose the appropriate settings, then click **OK**.

Choosing Advanced Print Options

The advanced print options give you complete control over your printing environment. Use these settings to experiment or to fine-tune a range of options to meet your individual needs. Follow these steps to print with advanced settings:


1. Follow steps 1 through 4 on page C-11.
2. Click **Custom** and then click **Advanced**.

You see a dialog box like the following:



When you choose PhotoEnhance, you see a different set of options on the lower part of the screen.

EPSON Stylus Pro 9000



EPSON Stylus Pro 9500

3. Choose the **Media Type** setting according to the guidelines on page C-13 or C-14. Then choose **Color** or **Black** ink.

4. Choose one of the following **Print Quality** settings:

- **Normal - 360dpi**
- **Fine - 720dpi**
- **Superfine - 1440dpi**

The available print quality settings may be limited by the **Media Type** setting. Choose lower print quality for faster printing, or **Superfine - 1440dpi** for best quality.

5. Choose any of the following:

- **Super MicroWeave**
The **MicroWeave** and **Super MicroWeave** settings eliminate unwanted banding effects. These settings are automatically selected for all media types except plain paper.
- **High Speed**
For fast, bidirectional printing at lower quality. If vertical lines in your printout are misaligned when you use the **High Speed** setting, you may need to turn it off or align the print head.
- **Flip Horizontal**
For printing a mirror image of your file. Use with backlight film.

6. Choose one of the following **Color Management** configurations:

- **Color Controls (Color Adjustment)**
This configuration lets you specify individual values for adjusting brightness, contrast, saturation, and CMY inks, or choose from the four Color Adjustment modes, as shown in the table on page C-19. (For the EPSON Stylus Pro 9500, you can also choose from three Gamma settings, which control image contrast by modifying the midtones and midlevel grays.) When you print on EPSON backlight film, choose **Vivid** mode and **+10 Saturation**.
- **PhotoEnhance4 (PhotoEnhance3)**
Produces sharper images and more vivid colors by automatically adjusting the contrast, saturation, and brightness. Corrects for overall under- or over-exposure of the original image. When you choose this configuration, you see a sample image that reflects the settings you choose. See page C-20 for a description of the settings.

- **No Color Adjustment**
This setting disables color management in the printer driver. Choose this mode if you want to use a standalone color management module (available under the Mode list on the EPSON Stylus Pro 9000).
 - **ICM**
Adjusts colors based on your printer's ICC profile, using the Image Color Matching system (effective in Windows 98/2000 only). If you're using an ICM-compatible monitor, adjusts printed colors to closely match screen colors.
 - **sRGB**
Adjusts colors using the small-gamut sRGB (standard red green blue) color space. Best for color matching with other sRGB devices, or for images designed for the Web.
7. Click **Save Settings** if you want to have your advanced settings available for reuse. Then type a name for the group of settings and click **Save**. The name is added to your list of custom settings.
 8. When you're finished setting advanced printer options, click **OK**.

Color Management Settings

The following tables list the color management settings available when you choose either Color Controls (Adjustment) or PhotoEnhance.

Color adjustment modes

Automatic	Analyzes the color information in your image and optimizes color correction accordingly.
Photo-realistic	Produces sharper images and more vivid colors by automatically adjusting the contrast, saturation, and brightness. Corrects for overall under- or over-exposure of the original image.
Vivid	Intensifies colors and lightens the midtones and highlights. Best for print jobs with non-photographic images.
1.5 Gamma	Produces the same contrast values as earlier EPSON ink jet printers.
1.8 Gamma	Increases contrast.
2.2 Gamma	Matches image colors with sRGB devices.

PhotoEnhance4 settings


Tone	Lets you choose from Normal for standard images, Hard for high contrast, or Sepia for an old-fashioned look. Vivid and Monochrome settings also available on the EPSON Stylus Pro 9500.
Effect	Lets you choose from 4 special effects (and set the intensity): Sharpness , Soft Focus , Canvas , and Parchment (EPSON Stylus Pro 9500 only).
Digital Camera Correction	Corrects noise and other flaws common to digital camera images.

Managing Print Jobs

Your printer comes with several utilities that let you check on your print jobs and schedule, cancel, pause, or restart them. The Progress Meter opens each time you send a print job. The Spool Manager (not available with Windows NT) appears on the taskbar when you print. Status Monitor, which also appears on the taskbar, lets you check the printer’s status as well as monitoring print jobs.

Using the Progress Meter

After you send a print job, the Progress Meter window appears on your screen:




You can use the buttons to cancel, pause, or restart your print job. You also see how much ink you have left and view printing tips (EPSON Stylus Pro 9500). If you don't want the Progress Meter to appear, you can turn it off. See page C-29 for instructions.

Using the Spool Manager

The Spool Manager (not available with Windows NT) displays the status of your print job files and lets you control them.

To open Spool Manager while you're printing, click the **EPSON Stylus Pro 9000** or **9500** button that appears on the taskbar at the bottom of the screen.

You see the Spool Manager window:



To cancel, pause, resume, or restart a print job, click the job to highlight it; then click the corresponding command button on the bottom of the window.

Checking Printer Status

The Status Monitor utility lets you check individual levels of ink in your printer, warns you when errors occur, and allows you to control the way printing is monitored. Status Monitor 2 comes with the EPSON Stylus Pro 9000 driver. Status Monitor 3 comes with the EPSON Stylus Pro 9500 driver.

Using Status Monitor 2 (EPSON Stylus Pro 9000)


The Status Monitor 2 icon appears on the Windows taskbar in the bottom right corner of your screen.

To open the utility, double-click the icon. The main window appears:



Note

You can also open the Status Monitor 2 from the Windows Start menu (under Programs, in the Epson folder).



Note

You can right-click the Status Monitor icon on the taskbar to show alert boxes in front of other windows or turn off background monitoring. The icon will disappear, but you can still access Status Monitor 2 through the Start menu.


- To check your printer's status and ink supplies, double-click **EPSON Stylus Pro 9000**. (You can also click the **Printer Status** button or choose **Printer Status** from the Printer menu.) The Printer Status window opens. You can also access the Printer Status window from the Utilities menu. Click the **Consumables** tab to check your ink levels.
- To monitor your print jobs, right-click **EPSON Stylus Pro 9000** and select **Job Status**. (You can also click the **Job Status** button or choose **Job Status** from the Printer menu.) The Job Status window opens.
- To enable alert messages, right-click **EPSON Stylus Pro 9000** and select **Monitoring Preferences**. (You can also choose **Monitoring Preferences** from the Settings menu.) The Monitoring Preferences window opens. You can have Status Monitor display a message when your ink is low or other problems occur. See page C-24 for information about monitoring preferences.

Status Monitor 3 (EPSON Stylus Pro 9500)


You can open Status Monitor 3 either from the Windows Printers utility or from an application.

1. Do one of the following:
 - Click **Start**, point to **Settings**, then select **Printers**. Right-click the **EPSON Stylus Pro 9500** icon and select **Properties**.
 - From an application, access the Main Printer Properties dialog box.
2. Click the **Utility** tab. You see the Utility menu:

Click to run
Status Monitor 3



3. Click the **EPSON Status Monitor 3** button. The following window appears. (It also opens automatically when an error occurs.)



Printer status messages appear here.


If an ink cartridge runs low or out, click here to display replacement instructions.

Setting Monitoring Preferences

You can have Status Monitor 3 alert you to any error conditions while you're working. This lets you know if one of your cartridges runs out of ink or if any other problems occur. Follow these steps to set monitoring preferences:

1. Click **Start**, point to **Settings**, and click **Printers**. Make sure your printer icon appears in the Printers window.
2. Right-click the **Stylus Pro 9500** icon, then click **Properties**.
3. Click the **Utility** tab, then click the **Speed & Progress** button. You see the Speed & Progress dialog box. See page C-29 for information about using the Speed & Progress utility.

4. Click the **Monitoring Preferences** button. You see the Monitoring Preferences window:



5. Select the Notification options you want to use.
6. If you want to have the Status Monitor icon appear in your Windows taskbar, click the Shortcut Icon checkbox. Then select the icon you want to use.



After you enable the Status Monitor Shortcut Icon, you can right-click the icon to display the Monitoring Preferences dialog box.

After you enable the shortcut, you can simply click the icon to open the Status Monitor window.

7. Select **Allow monitoring of shared printers** if your printer is shared and you want to let other users monitor it.
8. Click **OK** to save your settings.

Running Printer Utilities

The utilities included with your printer software let you run the following maintenance procedures:

- Nozzle check
- Print head cleaning
- Print head alignment
- Speed and progress configuration

Running Nozzle Check and Head Cleaning Utilities

The nozzle check prints a pattern of dots that lets you see if any print head nozzles are clogged. If any dots are missing from the pattern, you can run a head cleaning cycle to clear the nozzles.

Follow these steps:


1. Click **Start**, point to **Settings**, then select **Printers**. Right-click the **EPSON Stylus Pro 9000** or **9500** icon and select **Properties**. Or, access the Main Printer Properties dialog box.
2. Click the **Utility** tab. You see the Utility menu:



You can also access the Status Monitor 2 Printer Status window from this menu.

Click to run nozzle check.

Click to run head cleaning utility.



3. Click the button for the utility you want to run.
4. Follow the instructions on the screen to complete the process. For more information, see Chapter 3.

Running the Print Head Alignment Utility

If banding appears on your prints, or vertical lines are not straight, you need to align the print head. You can also use the control panel to align the head (as described in Chapter 3). Both procedures align the head for all modes and resolutions.


For the EPSON Stylus Pro 9000, use 13 × 19-inch EPSON coated ink jet paper (short edge first). You'll need 4 sheets to complete the procedure, which includes 12 patterns of 7 rows each and takes about 15 minutes.

For the EPSON Stylus Pro 9500, you can use EPSON roll paper. Six patterns of 15 lines or boxes are printed, which takes about 10 minutes. The patterns are repeated across the width of the page.


Follow these steps:

1. Load a sheet of paper in the printer.
2. Click **Start**, point to **Settings**, then select **Printers**. Right-click the **printer** icon and select **Properties**. Or, access the Main Printer Properties dialog box.
3. Click the **Utility** tab.
4. Click the **Print Head Alignment** button.
5. Follow the messages on your screen. The printer prints the head alignment patterns. If you're using cut sheet paper, remove each sheet after printing and load another sheet.

6. After all the patterns have printed, do one of the following:
 - For the EPSON Stylus Pro 9000, choose the row number that has the smallest gap in each pattern. In the first example below, row 4 has the smallest gaps. In the second, row 6 has the smallest gaps.



- For the EPSON Stylus Pro 9500, choose the line or box number that has the smallest gaps. In the example below, line 8 has the smallest gaps in each pattern.



7. Select the row you chose in step 6 for each pattern (for example, row 4), then click **Finish**.



This window is for the EPSON Stylus Pro 9000. If you have the 9500, you will see 6 choices instead of 12.

If you can't make a consistent choice for the patterns as you look across the width of the paper, choose the average or most frequent number. Then click the **Realignment** button and repeat from step 5.


Running the Speed and Progress Configuration Utility

With this utility, you can speed up the way your printer software processes multiple-copy print jobs, optimize your printer port for the fastest data transfer rate, and configure the progress meter.

To access the Speed & Progress dialog box, you must open your printer software from the Windows Printers utility as described below.

1. Click **Start**, point to **Settings**, then click **Printers**.
2. Right-click the **EPSON Stylus Pro 9000** or **9500** printer icon and select **Properties** (Windows 95 and 98) or **Document Defaults** (Windows NT) from the menu.
3. Click the **Utility** tab. You see the Utility menu.

4. Click the **Speed & Progress** button. You see the following dialog box:



5. Select from the following options:

- **High Speed Copies** speeds up printing of multiple copies of the same document using hard disk space as a cache. If you have multiple hard drives, you can select a high speed copy folder for storing copies.
- **Show Progress Meter** lets you control whether or not the Progress Meter is displayed when you send a print job.
- **EPSON Printer Port** (for Windows 95 and 98 only) lets you optimize the transfer rate of your printer port for EPSON printers instead of using the Windows default printer port. You may see one of these messages beneath the **EPSON Printer Port** option:

High speed (DMA) transfer enabled tells you that you're already using fast DMA transfer mode.

For higher data transfer rates, use **DMA transfer** lets you know that you can speed up printing by enabling DMA transfers on your system. See your EPSON Stylus Pro 9500 electronic *Reference Guide* for instructions on using DMA transfers, if your computer supports them. For more information, see your computer documentation or contact your computer manufacturer's technical support. If you see no message, you cannot enable DMA transfers.

6. Click **OK** to close the **Speed & Progress** dialog box and return to the Utility menu. Then click **OK** again to exit the Printers utility.

Index

A

- Accessories, purchasing, 5
- Aligning print head
 - control panel, 3-3 to 3-6
 - Macintosh, B-25 to B-26
 - Windows, C-27 to C-29
- AppleTalk setting, B-5
- Auto Cut setting, 1-10, B-9, C-16
- Auto Rotate setting, B-9, C-16

B

- Background printing, Macintosh,
B-18 to B-20
- Backlight Film, 1-2, B-15, C-18
- Banding, 4-3
- Basic printing
 - Macintosh, B-10 to B-12
 - Windows, C-11 to C-12
- Basket, paper, *see* Hammock, paper
- Belts, roll paper, 1-9
- Blank pages, 4-8
- Blurry prints, 4-4
- Buttons, control panel, 1-13,
2-1 to 2-12, 3-2

C

- Cable problems, 4-6, 4-7
- Canceling print jobs
 - control panel, 2-2
 - Macintosh, B-19, B-21
 - Windows, C-21
- Canvas, cutting, 1-14
- Cartridges, *see* Ink cartridges
- Casters, 3-19
- Chooser, selecting printer, B-5
- Cleaner (cleaning unit), 2-5
- Cleaning
 - paper hammock, 3-15
 - print head, 3-2, B-24,
C-26 to C-27
 - printer, 3-15
- Cleaning button, 2-4, 3-2

- Cleaning cycle, running
 - control panel, 3-2
 - Macintosh, B-24
 - Windows, C-26 to C-27
- Code page setting, 2-11
- Color management
 - Macintosh, B-11, B-16 to B-17
 - Windows, C-18 to C-20
- Color problems, 4-3, 4-8
- ColorSync settings, B-16, B-17
- Configuration options, Macintosh,
B-22 to B-23
- Configuring printer, 2-8 to 2-12
- Control panel
 - buttons, 1-13, 2-1 to 2-12, 3-2
 - configuring printer, 2-8 to 2-12
 - default settings, 2-8 to 2-12
 - illustration, 2-1
 - language, setting, 2-12
 - lights, 2-2, 2-5 to 2-7
 - menus, 2-8
 - messages, 2-2, 2-5 to 2-7
 - monitoring printer, 2-1 to 2-7
- CR motor (carriage motor), 2-5
- Cut sheet paper
 - heavy stock, 1-18 to 1-21
 - loading, 1-15 to 1-18
 - printable area, 5-3
- Cut/Eject button, 1-13
- Cutter Replace menu, 3-11
- Cutter, replacing blade, 3-11 to 3-14
- Cutter, utility, 1-14

D

- Data transfer, optimizing,
C-29 to C-30
- Default settings, 2-8 to 2-12
- Deleting print jobs
 - Macintosh, B-19, B-21
 - Windows, C-21
- Diagnosing problems, 4-1 to 4-2
- Dimensions of printer, 5-3
- DMA transfers, C-30

Documentation, how to use, 2 to 4

Drivers

Macintosh, B-1 to B-17

Windows, C-1 to C-20

Drying time setting, 1-25 to 1-26

E

ECP mode, 2-10, 5-6

Electrical specifications, 5-4

Energy consumption, 5-4

ENERGY STAR, 5

Engine reliability, 5-1

Environmental specifications, 5-3

EPSON

Accessories, 5

help, 4 to 5

Internet FTP Site, 5

media, 1-2 to 1-4

Preferred Protection Plan, 4

printer port, 4-7, C-30

Web site, 5

EpsonNet Internal Print Server,

installing, A-1 to A-3

Error messages, 2-5 to 2-7

Error notification, B-22 to B-23

Ethernet card, installing, A-1 to A-3

F

Faint prints, 4-4

FireWire Interface Card, installing,

A-1 to A-3

Firmware version, 2-4

Flip Horizontal setting, 4-7, B-15,

C-18

FTP site, EPSON, 5

G

Gamma setting, B-16, C-19

Graph setting, B-11, C-12

Guide track for cutting, 1-14

H

Hammock, paper

in front of printer, 1-21 to 1-23

under printer, 1-24

Head Alignment menu, 3-3

Head alignment, *see* Print head,
aligning

Head unit (print head), 2-5

Height of printer, 5-3

Help, EPSON, 4 to 5

Hex dump mode, 4-2

High Speed copies, B-23, C-30

High Speed setting, B-15, C-18

High tension spindles, 1-1

Humidity requirements, 5-3

I

Initialization, 5-4

Ink

monitoring level, 2-4 to 2-5,

B-21 to B-22, C-20 to C-25

valve locks, 3-17, 4-5

waste ink system, 2-5, 3-20, 5-1

Ink cartridges

ordering, 3-7

removing for transportation, 3-16

replacing, 3-7 to 3-10

safety instructions, 7 to 8

specifications, 5-5

Ink Out light(s), 2-5 to 2-7

Interface card, A-1 to A-3

Interface, *see* Parallel interface, Serial
interface

Internet, 5

Item button, 2-4

L

Language, control panel, 2-12

Leg assembly, removing, 3-17 to 3-18

Lights, control panel, 2-2, 2-5 to 2-7

M

Macintosh

- advanced print options,
B-14 to B-17
- background printing, B-18 to B-20
- basic print options, B-10
- color management, B-16
- ColorSync settings, B-16
- configuration options,
B-22 to B-23
- connecting printer, B-1 to B-3
- custom print job settings, B-11
- drivers, B-1 to B-17
- head cleaning utility, B-24
- installing software, B-4
- managing print jobs, B-17 to B-23
- Monitor3, B-19 to B-20
- monitoring printer, B-17 to B-23
- nozzle check utility, B-24
- page setup options, B-8
- selecting printer in chooser, B-5
- sharing printer, B-6 to B-7
- Status Monitor, B-21 to B-22
- system requirements, B-4
- Utility menu, B-21 to B-22

Maintenance, 3-1 to 3-15

Maintenance mode, 2-12, 4-2

Manuals, how to use, 2 to 4

Margins

- incorrect, 4-7
- minimum, 5-3
- setting default, 2-8

Mechanical specifications, 5-3

Media, *see* Paper

Media Type settings

- EPSON Stylus Pro 9000, B-12,
C-13
- EPSON Stylus Pro 9500, B-13,
C-14

Memory

- problems, 4-6
- specifications, 5-1

Menus, SelecType, 2-8

see also SelecType menus

Messages

- error, 2-5 to 2-7
- status, 2-2

MicroWeave setting, B-15, C-18

Monitor3, B-19 to B-20

Monitoring printer

- control panel, 2-1 to 2-7
- Macintosh, B-17 to B-23
- Windows, C-20 to C-25

Motors, 2-5

Moving printer, 3-16 to 3-19

N

Network, sharing printer on

- Macintosh, B-6 to B-7
- Windows, C-5 to C-10

Nozzle check

- control panel, 2-3 to 2-4,
3-1 to 3-3
- Macintosh, B-24
- Windows, C-26 to C-27

O

Operate light, 1-11, 1-17, 2-2

Optimizing data transfer, C-29 to C-30

P

Page count, 2-5, 5-1

Page Line setting, 1-10, 1-15, B-9, C-16

Paper

- attaching to spindle, 1-4 to 1-6
- configurations settings,
1-25 to 1-26, 4-4
- cut sheet, 1-15 to 1-21
- cutting manually, 1-13 to 1-14
- drying time setting, 1-25 to 1-26
- EPSON, 1-2 to 1-4
- hammock, 1-21 to 1-24

Paper, (*continued*)

- handling, 1-1 to 1-26
- heavy stock, 1-18 to 1-21
- inserting the spindle, 1-7 to 1-9
- jams, 4-12 to 4-13
- loading for printing, 1-10 to 1-13
- loading sheets, 1-15 to 1-18
- non-EPSON, 1-25 to 1-26
- options, Macintosh, B-8
- options, Windows, C-15
- printable area, 5-3
- problems, 4-9 to 4-13
- registering, 1-25 to 1-26
- removing from spindle, 1-6
- roll, 1-4 to 1-15
- selecting registered, 1-26
- setting default margins, 2-8 to 2-9
- sizes, 1-1, 5-2
- specifications, 5-2
- spindle, 1-4 to 1-9
- suction setting, 1-25 to 1-26
- thickness setting, 1-25 to 1-26
- trim lines, 1-15, B-9, C-16
- uneven edge, 1-13
- Paper basket, *see* Paper hammock
- Paper Config. menu, 1-25, 1-26
- Paper cutter, replacing blade, 3-11 to 3-14
- Paper Feed buttons, 1-13
- Paper feed speed, 5-1
- Paper guides, 4-10
- Paper hammock, 1-21 to 1-24
- Paper monitoring, turning off, 2-9
- Paper Out light, 2-5 to 2-7
- Paper set lever, 1-11, 1-13, 1-17, 1-18
- Paper Size setting, 4-7, B-9, C-15
- Paper Source setting, B-9, C-15
- Parallel interface
 - configuring, 2-9 to 2-10
 - connecting to, B-2, C-1 to C-2
 - problems, 4-6, 4-7
 - specifications, 5-6
- Pause button, 1-13, 1-18, 1-20
- Pause light, 2-2, 2-5

- Pausing print jobs
 - control panel, 2-2
 - Macintosh, B-19
 - Windows, C-21
- PF motor (paper feed motor), 2-5
- Photoshop color management setting, B-11
- Platen gap setting, 1-20 to 1-21, 4-4
- Posterboard, 1-18 to 1-21
- Power consumption, 5-4
- Print head
 - aligning, 3-3 to 3-6, B-25 to B-26, C-27 to C-29
 - checking status, 2-5, 3-1 to 3-3
 - cleaning, 3-2, B-24, C-26 to C-27
 - service life, 5-1
- Print jobs
 - canceled, 2-2, B-19, B-21, C-21
 - custom settings, B-11, C-12
 - managing, B-17 to B-23, C-20 to C-22
 - pausing, 2-2, B-19, C-21
 - stalled, 4-7
- Print quality, 4-2 to 4-4, B-15, C-18
- Print time, setting, B-18 to B-20
- Printer
 - checking status, 2-2, C-21 to C-25
 - cleaning, 3-15
 - code page setting, 2-11
 - configuring, 2-8 to 2-12
 - connecting to Macintosh, B-1 to B-3
 - connecting to Windows computer, C-1 to C-2
 - control panel language, 2-12
 - default settings, 2-11
 - dimensions, 5-3
 - firmware version, 2-4
 - initialization, 5-4
 - interface, selecting, 2-9
 - leg assembly, removing, 3-17 to 3-18
 - maintaining, 3-1 to 3-15
 - maintenance mode, 2-12, 4-2

Printer, (*continued*)

- monitoring, 2-1 to 2-7,
 - B-17 to B-23, C-20 to C-25
- motors, 2-5
- moving, 3-16 to 3-19
- page count, 2-5
- parallel interface, configuring, 2-10
- pausing, 2-2
- port, EPSON, 4-6, 4-7, C-30
- resetting, 2-2
- sharing, B-6 to B-7, C-5 to C-10
- specifications, 5-1
- total print volume, 5-1
- transporting, 3-16 to 3-19
- turning off, 6
- weight, 5-3
- Printer Color Management setting, B-11
- Printer Setting menu, 1-15, 1-20, 2-8 to 2-12
- Printer Status menu, 2-4
- Printing specifications, 5-1
- Problems
 - banding, 4-3
 - blank paper, 4-8
 - blurry prints, 4-4
 - cable, 4-6, 4-7
 - color, 4-3, 4-8
 - diagnosing, 4-1 to 4-2
 - faint prints, 4-4
 - garbled characters, 4-7
 - inverted image, 4-7
 - margins, 4-7
 - memory, 4-6
 - misalignment, 4-3
 - nothing prints, 4-6
 - operational, 4-5 to 4-6
 - paper, 4-9 to 4-13
 - PPD, 4-6 to 4-8
 - print quality, 4-2 to 4-4
 - printer stops printing, 4-5
 - slow printing, 4-9
 - smear prints, 4-8
- Progress Meter, C-20 to C-21, C-30

R

- RAM, *see* Memory
- Registering non-EPSON media, 1-25 to 1-26
- Resetting printer, 2-2
- Resolution
 - Macintosh, B-15
 - specifications, 5-1
 - Windows, C-18
- Roll Marg setting, 2-8, 4-7
- Roll paper
 - attaching to spindle, 1-4 to 1-6
 - Auto Cut, 1-10, B-9, C-16
 - Auto Rotate, B-9, C-16
 - belts, 1-9
 - Cutter Off, 1-10
 - cutting manually, 1-13 to 1-14
 - feed problems, 4-10 to 4-11
 - inserting the spindle, 1-7 to 1-9
 - loading for printing, 1-10 to 1-13
 - Page Line setting, 1-10, 1-15, B-9, C-16
 - printable area, 5-3
 - removing from spindle, 1-6
 - Save Roll Paper setting, B-9, C-16
 - setting default margins, 2-8
 - settings, B-9, C-16
 - spindle, 1-1, 1-4 to 1-9
 - trim lines, 1-10, 1-15, B-9, C-16

S

- Safety
 - approvals, 5-4
 - instructions, 6 to 8
- Saturation setting, B-17
- Save Roll Paper setting, B-9, C-16
- SelectType menus
 - Cutter Replace, 3-11
 - Head Alignment, 3-3
 - list, 2-8
 - Paper Configuration, 1-25 to 1-26
 - Printer Setting, 1-15, 1-20, 2-8 to 2-12

SelecType menus, (*continued*)
 Printer Status, 2-4
 Test Print, 2-3, 3-1
 Serial interface, 5-7, B-2 to B-3
 Sharing printer
 Macintosh, B-6 to B-7
 Windows, C-5 to C-10
 Slow printing, 4-9
 Specifications
 electrical, 5-3
 environmental, 5-3
 ink cartridges, 5-5
 mechanical, 5-3
 paper, 5-2
 parallel interface, 5-6
 printable area, 5-3
 printing, 5-1
 serial interface, 5-7
 Speed and Progress configuration
 utility, C-29 to C-30
 Spindle
 high tension, 1-1
 roll paper, 1-4 to 1-9
 Spool folders, B-22 to B-23, C-30
 Spool Manager, C-21
 SRGB setting, C-19
 Stabilizer knobs, 3-19
 Status check, 2-3
 Status Monitor
 Macintosh, B-21 to B-22
 Windows, C-21 to C-25
 Status Monitor 2, C-21 to C-22
 Status Monitor 3, C-23 to C-25
 Support, EPSON, 4 to 5
 System requirements
 Macintosh, B-4
 Windows, C-3

T

Technical support, 4 to 5
 Test Print menu, 2-3, 3-1
 Text/Graph setting, B-11, C-12
 Transporting printer, 3-16 to 3-19

Trim lines, printing
 control panel, 1-10, 1-15
 Macintosh, B-9
 Windows, C-16
 Troubleshooting, 4-1 to 4-13

U

USB connection, B-1 to B-2,
 C-1 to C-2
 Utility cutter, 1-14
 Utility menu
 Macintosh, B-21 to B-22
 Windows, C-23, C-26 to C-27

W

Waste ink (waste ink system), 2-5,
 3-20, 5-1
 Web site, EPSON, 5
 Weight of printer, 5-3
 Width of printer, 5-3
 Windows
 advanced print options,
 C-16 to C-20
 basic print options, C-11 to C-12
 color management, C-18 to C-20
 connecting printer, C-1 to C-2
 custom print job settings, C-12
 drivers, C-1 to C-20
 head cleaning utility, C-26 to C-27
 installing software, C-3
 managing print jobs, C-20 to C-21
 monitoring printer, C-20 to C-25
 nozzle check utility, C-26 to C-27
 paper options, C-15
 printer status, checking, C-21 to C-25
 sharing printer, C-5 to C-10
 Speed and Progress configuration
 utility, C-29 to C-30
 status alerts, C-24 to C-25
 Status Monitor 2, C-21 to C-22
 Status Monitor 3, C-23 to C-25
 system requirements, C-3
 Utility menu, C-26 to C-27

