

700C Series Corn Heads (S.N. 800001—)



OPERATOR'S MANUAL 700C Series Corn Heads OMHXE119106 ISSUE G7 (ENGLISH)

John Deere Harvester Works

Export Edition
PRINTED IN U.S.A.



Introduction

Foreword

READ THIS MANUAL carefully to learn how to operate and service your machine correctly. Failure to do so could result in personal injury or equipment damage. This manual and safety signs on your machine may also be available in other languages. (See your John Deere dealer to order.)

THIS MANUAL SHOULD BE CONSIDERED a permanent part of your machine and should remain with the machine when you sell it.

MEASUREMENTS in this manual are given in both metric and customary U.S. unit equivalents. Use only correct replacement parts and fasteners. Metric and inch fasteners may require a specific metric or inch wrench.

RIGHT-HAND AND LEFT-HAND sides are determined by facing in the direction the implement will travel when going forward.

WRITE PRODUCT IDENTIFICATION NUMBERS (P.I.N.) in the Specification section. Accurately record all the numbers to help in tracing the machine should it be stolen. Your dealer also needs these numbers when you order parts. File the identification numbers in a secure place off the machine.


WARRANTY is provided as part of John Deere's support program for customers who operate and maintain their equipment as described in this manual. The warranty is explained on the warranty certificate or statement which you should have received from your dealer.

This warranty provides you the assurance that John Deere will back its products where defects appear within the warranty period. In some circumstances, John Deere also provides field improvements, often without charge to the customer, even if the product is out of warranty. Should the equipment be abused, or modified to change its performance beyond the original factory specifications, the warranty will become void and field improvements may be denied. Setting fuel delivery above specifications or otherwise overpowering machines will result in such action.

If you are not the original owner of this machine, it is in your interest to contact your local John Deere dealer to inform them of this unit's serial number. This will help John Deere notify you of any issues or product improvements.

DX,IFC2A -19-03APR09-1/1

Identification View



SS43267,00002FF -19-01NOV13-1/1

Contents

	Page		Page
Safety Features		Attaching and Detaching	
Header Safety Features	05-1	Attaching Header to Feeder House	25-1
Safety		Attaching Header to Forage Harvester or Corn Husker	25-5
Recognize Safety Information	10-1	Detaching Header from Feeder House	25-5
Understand Signal Words	10-1	Calibration and Settings	
Follow Safety Instructions	10-1	When to Calibrate	30-1
Spanish Safety Signs and Operator's Manual	10-2	Calibration Error Codes	30-1
Ballasting for Safe Ground Contact	10-2	User Calibration Procedures	30-1
Parking and Leaving the Machine	10-2	Adjusting Feeder House Drop Rate and Sensitivity	30-2
Prepare for Emergencies	10-3	Operating the Corn Head	
Wear Protective Clothing	10-3	General Information	35-1
Stay Clear of Harvesting Units	10-3	Drive and Operate Carefully	35-1
Use Safety Lights and Devices	10-4	Corn Head Speed of Travel	35-1
Transport Combine With Header Safely	10-4	Armrest Functions	35-2
Road Transport Disconnect Switch	10-4	Active Header Control Display—Features	35-3
Practice Safe Maintenance	10-5	Description of Automatic Header Height Control Systems	35-4
Remove Paint Before Welding or Heating	10-5	Header Engage/Disengage Drive	35-4
Avoid Heating Near Pressurized Fluid Lines	10-6	Deck Plate Control and Resume	35-5
Avoid Entanglement	10-6	Combines With Fixed-Speed Feeder House	35-5
Avoid Contact With Moving Parts	10-6	Harvesting Corn With Weakened or Broken Stalks	35-6
Stay Clear of Rotating Drivelines	10-7	Harvesting Popcorn	35-6
Guards and Shields	10-7	Gatherers	35-6
Avoid High-Pressure Fluids	10-7	Row Units	35-7
Service Accumulator Systems Safely	10-8	Auger	35-7
Service Machines Safely	10-8	Hydraulic Adjustable Deck Plates	35-7
Service Drive Belts Safely	10-8	Outer Gatherer Extensions	35-8
Protect Against High Pressure Spray	10-9	Raising and Removing Inner Gatherer Points and Shields	35-8
Decommissioning — Proper Recycling and Disposal of Fluids and Components	10-9	Raising and Tilting Outer Gatherer Points and Shields	35-10
Support Machine Properly	10-10	Auger Floor Cleanout Door	35-10
Store Attachments Safely	10-10	Engaging and Disengaging StalkMaster™ Chopping Knives	35-11
Safety Signs		Attachments and Options	
Pictorial Safety Signs	15-1	Ear Savers	40-1
Replace Safety Signs	15-1	Stalk Rolls	40-2
Header Entanglement	15-1	Active Header Control Ground Sensors	40-2
Rotating Driveline	15-2		
StalkMaster™ Corn Heads	15-2		
Corn Head Shipping Weight	15-3		
Header Entanglement	15-3		
Transporting			
Transporting on Trailer	20-1		
Transporting on Combine	20-2		

Continued on next page

Original Instructions. All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

COPYRIGHT © 2017
DEERE & COMPANY
Moline, Illinois
All rights reserved.
A John Deere ILLUSTRATION™ Manual

	Page
StalkMaster™ Chopping Gear Cases (Optional)	40-3
AutoTrac RowSense	40-3
Stubble Lights	40-4

Adjustments—Corn Head

Adjusting and Leveling Gatherer Points	45-1
Adjusting Trash Knives	45-1
Adjusting Gatherer Chain Tension	45-2
Adjusting Gatherer Chain Flights	45-2
Adjusting Deck Plates	45-4
Adjusting Row Unit Drive Chain	45-5
Adjusting Row Unit Drive Sprockets With Fixed Speed Drive ONLY	45-7
Adjusting Auger Height	45-8
Adjusting Lower Stripper	45-10
Coupling the Chain	45-11
Adjusting Auger Drive Chain	45-11

Lubrication

Grease	50-1
Lubricant Storage	50-1
Alternative and Synthetic Lubricants	50-1
Mixing of Lubricants	50-1

Lubrication and Maintenance

Service Interval Chart—Every 10 Hours	55-1
Every 10 Hours of Operation	55-1
Service Interval Chart—Every 200 Hours	55-1
Every 200 Hours of Operation	55-2
Service Interval Chart—Every 400 Hours	55-6
Every 400 Hours of Operation	55-7
Service Interval Chart—Every 1000 Hours	55-7
Every 1000 Hours of Operation	55-8

Troubleshooting

Corn Head	60-1
Active Header Control (AHC)	60-3

Service

Hydraulic Cylinder Safety Stop	65-1
Remove and Install Stalk Rolls	65-1
Reversing Gatherer Chains and Sprockets for Additional Wear	65-5
Remove and Install Gatherer Chain	65-6
Remove and Install Oil Pan	65-8
Remove and Install Wear Strips	65-10
Remove and Install StalkMaster™ Chopping Knife Blades	65-10
Stubble Light Bulb Replacement	65-11
Header Warning Light Bulb Replacement	65-11

Storage


End of Season Service	70-1
Beginning of Season Service	70-1

Specifications

Specifications	75-1
Keep Machines Secure	75-2
Header Identification Number	75-3
Keep Proof of Ownership	75-3
EU Declaration of Conformity	75-4
Eurasian Economic Union	75-4
Machine Design Life	75-5
Unified Inch Bolt and Screw Torque Values	75-5
Metric Bolt and Screw Torque Values	75-6

Safety Features

Header Safety Features



A—Warning Light
B—Reflective Tape

C—Safety Decals
D—Drive Shaft Shields

E—Curtains (Chopping Models
Only)

In addition to the safety features shown here, additional decals plus safety messages and instructions in the

Operators Manual contribute to the proper operation of this corn head.

DM84283,00006F5 -19-21MAY15-1/1

H114321 —UN—05JUN15

Safety

Recognize Safety Information

This is a safety-alert symbol. When you see this symbol on your machine or in this manual, be alert to the potential for personal injury.

Follow recommended precautions and safe operating practices.



TS1389 —UN—28JUN13

DX,ALERT -19-29SEP98-1/1

Understand Signal Words

DANGER; The signal word DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.

WARNING; The signal word WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION; The signal word CAUTION indicates a hazardous situation which, if not avoided, could result in minor or moderate injury. CAUTION may also be used to alert against unsafe practices associated with events which could lead to personal injury.

A signal word—DANGER, WARNING, or CAUTION—is used with the safety-alert symbol. DANGER identifies the most serious hazards. DANGER or WARNING safety signs are located near specific hazards. General



TS187 —19—30SEP98

precautions are listed on CAUTION safety signs. CAUTION also calls attention to safety messages in this manual.

DX,SIGNAL -19-05OCT16-1/1

Follow Safety Instructions

Carefully read all safety messages in this manual and on your machine safety signs. Keep safety signs in good condition. Replace missing or damaged safety signs. Be sure new equipment components and repair parts include the current safety signs. Replacement safety signs are available from your John Deere dealer.

There can be additional safety information contained on parts and components sourced from suppliers that is not reproduced in this operator's manual.

Learn how to operate the machine and how to use controls properly. Do not let anyone operate without instruction.

Keep your machine in proper working condition. Unauthorized modifications to the machine may impair the function and/or safety and affect machine life.



TS201 —UN—15APR13

If you do not understand any part of this manual and need assistance, contact your John Deere dealer.

DX,READ -19-16JUN09-1/1

Spanish Safety Signs and Operator's Manual

Spanish versions of the operator's manual and safety signs are available for this machine through authorized John Deere dealers. See your John Deere dealer.



TS201—UN—15APR13


OUO6075,0000145 -19-22MAY08-1/1

Ballasting for Safe Ground Contact

Operating, steering and braking performance of combine can be considerably affected by heavy front end attachments which alter the center of gravity of the combine.

To maintain the necessary ground contact, ballast the combine at the rear end as necessary.

Observe the maximum permissible axle loads and total weights.



H51907—UN—10FEB99

HX,AG,SF6782 -19-05FEB99-1/1


Parking and Leaving the Machine

Lower harvesting unit to the ground.

Before leaving machine, disengage harvesting unit and separator. Move multi-function lever to neutral position and shut OFF machine. Apply parking brake, remove key, and lock the operator's cab.

Never leave machine unattended as long as engine is running.

Never leave the operator's cab when driving.



TS230—UN—24MAY89


OUO6075,0000AEB -19-11FEB14-1/1

Prepare for Emergencies

Be prepared if a fire starts.

Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.




TS291 —UN—15APR13

DX,FIRE2 -19-03MAR93-1/1

Wear Protective Clothing

Wear close fitting clothing and safety equipment appropriate to the job.

Operating equipment safely requires the full attention of the operator. Do not wear radio or music headphones while operating machine.



TS206 —UN—15APR13

DX,WEAR2 -19-03MAR93-1/1

Stay Clear of Harvesting Units

Cutterbar, auger, reel and feed rolls cannot be completely shielded due to their function. Stay clear of these moving elements during operation. Always disengage main clutch, shut off engine, set parking brake and remove key before servicing or unclogging machine.



ES 118 704


ES118704 —UN—21MAR95

OQO6075,00009E5 -19-28SEP10-1/1

Use Safety Lights and Devices

Prevent collisions between other road users, slow moving tractors with attachments or towed equipment, and self-propelled machines on public roads. Frequently check for traffic from the rear, especially in turns, and use turn signal lights.

Use headlights, flashing warning lights, and turn signals day and night. Follow local regulations for equipment lighting and marking. Keep lighting and marking visible, clean, and in good working order. Replace or repair lighting and marking that has been damaged or lost. An implement safety lighting kit is available from your John Deere dealer.



DX,FLASH -19-07JUL99-1/1

TS951 —UN—12APR90


Transport Combine With Header Safely

Whenever possible avoid transporting on public roadways with the header attached.

If the combine must be transported with the header attached, make sure that the flashing warning lights on the header are operating and the reflective material is clean and visible.

The use of a spotter or pilot vehicle is recommended on busy, narrow or hilly roads and when crossing bridges.

Drive at a speed that is safe for conditions.



OUO6075.0000034 -19-22JAN01-1/1

H51909 —UN—07MAY99

Road Transport Disconnect Switch

Road transport disconnect switch must be in road position when transporting machine on roadway.

When road transport disconnect switch is pressed, indicator light turns ON indicating switch is in road position. Road transport disconnect switch prevents the following functions:

- Header Height Resume
- Header Height Sensing
- Lateral Tilt
- Reel Raise/Lower and Reel Fore/Aft
- Unloading Auger
- Auger Swing
- Power Folding Auger (If Equipped)
- Separator Engage

H121089 —UN—15MAR17



Road Transport Disconnect
(Style A)

H117022 —UN—28MAR16



Road Transport Disconnect
(Style B)

- Header Engage
- Header Raise/Lower

After transporting machine on roadway and field operation is desired, press road transport disconnect switch for **two seconds**, allowing indicator light to turn OFF and allowing desired switch functions to operate again.

OUO6075.00046B5 -19-24APR17-1/1

Practice Safe Maintenance

Understand service procedure before doing work. Keep area clean and dry.

Never lubricate, service, or adjust machine while it is moving. Keep hands, feet, and clothing away from power-driven parts. Disengage all power and operate controls to relieve pressure. Lower equipment to the ground. Stop the engine. Remove the key. Allow machine to cool.

Securely support any machine elements that must be raised for service work.

Keep all parts in good condition and properly installed. Fix damage immediately. Replace worn or broken parts. Remove any buildup of grease, oil, or debris.

On self-propelled equipment, disconnect battery ground cable (-) before making adjustments on electrical systems or welding on machine.

On towed implements, disconnect wiring harnesses from tractor before servicing electrical system components or welding on machine.

Falling while cleaning or working at height can cause serious injury. Use a ladder or platform to easily reach each location. Use sturdy and secure footholds and handholds.



TS218 —UN—23AUG88

DX,SERV -19-28FEB17-1/1

Remove Paint Before Welding or Heating


Avoid potentially toxic fumes and dust.

Hazardous fumes can be generated when paint is heated by welding, soldering, or using a torch.

Remove paint before heating:

- Remove paint a minimum of 100 mm (4 in.) from area to be affected by heating. If paint cannot be removed, wear an approved respirator before heating or welding.
- If you sand or grind paint, avoid breathing the dust. Wear an approved respirator.
- If you use solvent or paint stripper, remove stripper with soap and water before welding. Remove solvent or paint stripper containers and other flammable material from area. Allow fumes to disperse at least 15 minutes before welding or heating.

Do not use a chlorinated solvent in areas where welding will take place.



Do all work in an area that is well ventilated to carry toxic fumes and dust away.

Dispose of paint and solvent properly.

TS220 —UN—15APR13

DX,PAINT -19-24JUL02-1/1

Avoid Heating Near Pressurized Fluid Lines

Flammable spray can be generated by heating near pressurized fluid lines, resulting in severe burns to yourself and bystanders. Do not heat by welding, soldering, or using a torch near pressurized fluid lines or other flammable materials. Pressurized lines can accidentally burst when heat goes beyond the immediate flame area.




TS953 —UN—15MAY90

DX,TORCH -19-10DEC04-1/1

Avoid Entanglement

To avoid entanglement, do not feed crop material into machine by hand or attempt to manually unplug machine while it is running. The machine can feed the crop material in faster than you can release your grip on the material.

H45810



H45810 —UN—22JUL93

SS43267,0000113 -19-10SEP12-1/1

Avoid Contact With Moving Parts

Keep hands, feet and clothing away from power driven parts. Never clean, lubricate or adjust machine when it is running.



TS256 —UN—23AUG88

JK22594,00000E3 -19-15AUG06-1/1

Stay Clear of Rotating Drivelines

Entanglement in rotating driveline can cause serious injury or death.

Keep all shields in place at all times. Make sure rotating shields turn freely.

Wear close-fitting clothing. Stop the engine and be sure that all rotating parts and drivelines are stopped before making adjustments, connections, or performing any type of service on engine or machine driven equipment.



TS1644—UN—22AUG95


DX,ROTATING -19-18AUG09-1/1

Guards and Shields

Keep guards and shields in place at all times. Ensure that they are serviceable and installed correctly.

Always disengage main clutch, shut off engine and remove key before removing any guards or shields.

Keep hands, feet and clothing away from moving parts.



TS285—UN—23AUG88

JK22594,00000E5 -19-15AUG06-1/1

Avoid High-Pressure Fluids

Inspect hydraulic hoses periodically – at least once per year – for leakage, kinking, cuts, cracks, abrasion, blisters, corrosion, exposed wire braid or any other signs of wear or damage.


Replace worn or damaged hose assemblies immediately with John Deere approved replacement parts.

Escaping fluid under pressure can penetrate the skin causing serious injury.

Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard. Protect hands and body from high-pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar



X9811—UN—23AUG88

with this type of injury should reference a knowledgeable medical source. Such information is available in English from Deere & Company Medical Department in Moline, Illinois, U.S.A., by calling 1-800-822-8262 or +1 309-748-5636.

DX,FLUID -19-12OCT11-1/1

Service Accumulator Systems Safely

Escaping fluid or gas from systems with pressurized accumulators that are used in air conditioning, hydraulic, and air brake systems can cause serious injury. Extreme heat can cause the accumulator to burst, and pressurized lines can be accidentally cut. Do not weld or use a torch near a pressurized accumulator or pressurized line.

Relieve pressure from the pressurized system before removing accumulator.

Relieve pressure from the hydraulic system before removing accumulator. Never attempt to relieve hydraulic system or accumulator pressure by loosening a fitting.

Accumulators cannot be repaired.




TS281 —UN—15APR13

DX,WW,ACCL2 -19-22AUG03-1/1

Service Machines Safely

Tie long hair behind your head. Do not wear a necktie, scarf, loose clothing, or necklace when you work near machine tools or moving parts. If these items were to get caught, severe injury could result.

Remove rings and other jewelry to prevent electrical shorts and entanglement in moving parts.




TS228 —UN—23AUG88

DX,LOOSE -19-04JUN90-1/1

Service Drive Belts Safely

When servicing drive belts always observe these precautions:

- Avoid serious injury from hand or arm entanglement. Never attempt to clean, check or adjust belts while the machine is running. Always shut off the engine, set the parking brake and remove the key.
- Do not attempt to clean belts with flammable cleaning solvents.




TS285 —UN—23AUG88

OOU6075,00026A4 -19-06FEB03-1/1

Protect Against High Pressure Spray

Spray from high pressure nozzles can penetrate the skin and cause serious injury. Keep spray from contacting hands or body.

If an accident occurs, see a doctor immediately. Any high pressure spray injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available from Deere & Company Medical Department in Moline, Illinois, U.S.A.




TS1343—JUN—18MAR92

DX,SPRAY -19-16APR92-1/1

Decommissioning — Proper Recycling and Disposal of Fluids and Components

Safety and environmental stewardship measures must be taken into account when decommissioning a machine and/or component. These measures include the following:

- Use appropriate tools and personal protective equipment such as clothing, gloves, face shields or glasses, during the removal or handling of objects and materials.
- Follow instructions for specialized components.
- Release stored energy by lowering suspended machine elements, relaxing springs, disconnecting the battery or other electrical power, and releasing pressure in hydraulic components, accumulators, and other similar systems.
- Minimize exposure to components which may have residue from agricultural chemicals, such as fertilizers and pesticides. Handle and dispose of these components appropriately.
- Carefully drain engines, fuel tanks, radiators, hydraulic cylinders, reservoirs, and lines before recycling components. Use leak-proof containers when draining fluids. Do not use food or beverage containers.
- Do not pour waste fluids onto the ground, down a drain, or into any water source.
- Observe all national, state, and local laws, regulations, or ordinances governing the handling or disposal of waste fluids (example: oil, fuel, coolant, brake fluid);



TS1133—JUN—15APR13

- filters; batteries; and, other substances or parts. Burning of flammable fluids or components in other than specially designed incinerators may be prohibited by law and could result in exposure to harmful fumes or ashes.
- Service and dispose of air conditioning systems appropriately. Government regulations may require a certified service center to recover and recycle air conditioning refrigerants which could damage the atmosphere if allowed to escape.
 - Evaluate recycling options for tires, metal, plastic, glass, rubber, and electronic components which may be recyclable, in part or completely.
 - Contact your local environmental or recycling center, or your John Deere dealer for information on the proper way to recycle or dispose of waste.


DX,DRAIN -19-01JUN15-1/1

Support Machine Properly

Always lower the attachment or implement to the ground before you work on the machine. If the work requires that the machine or attachment be lifted, provide secure support for them. If left in a raised position, hydraulically supported devices can settle or leak down.

Do not support the machine on cinder blocks, hollow tiles, or props that may crumble under continuous load. Do not work under a machine that is supported solely by a jack. Follow recommended procedures in this manual.

When implements or attachments are used with a machine, always follow safety precautions listed in the implement or attachment operator's manual.



DX,LOWER -19-24FEB00-1/1

TSS29 —UN—23AUG88

Store Attachments Safely

Stored attachments such as dual wheels, cage wheels, and loaders can fall and cause serious injury or death.

Securely store attachments and implements to prevent falling. Keep playing children and bystanders away from storage area.



DX,STORE -19-03MAR93-1/1

TSS219 —UN—23AUG88

Safety Signs

Pictorial Safety Signs

At several important places on this machine safety signs are affixed intended to signify potential hazards. The hazard is identified by a pictorial in a warning triangle. An adjacent pictorial provides information how to avoid personal injury. These safety signs, their placement on the machine and a brief explanatory text are shown below.



TS231 —19—07OCT88

SS43267,00000E8 -19-19JUN12-1/1

Replace Safety Signs

Replace missing or damaged safety signs. Use this operator's manual for correct safety sign placement.

There can be additional safety information contained on parts and components sourced from suppliers that is not reproduced in this operator's manual.




TS201 —UN—15APR13

DX,SIGNS -19-18AUG09-1/1

Header Entanglement

To avoid bodily injury or death, SHUT OFF engine before unclogging. Rolls in gathering units move faster than you can let loose of stalk.




H106348 —UN—08JAN13

SS43267,00002BE -19-27JUN13-1/1

Rotating Driveline

Entanglement in rotating driveline can cause serious injury or death. Keep all shields in place. Avoid contact with rotating parts.




H106349 —UN—08JAN13

SS43267,00002BF -19-27JUN13-1/1

StalkMaster™ Corn Heads

Avoid serious injury from contact with rotating stalk knives or thrown objects. Stay clear while StalkMaster™ corn head is running.




H106350 —UN—08JAN13

StalkMaster is a trademark of Deere & Company

SS43267,000063E -19-06JUL15-1/1

Corn Head Shipping Weight

The shipping weight of this corn head exceeds 3630 kg (8000 lbs). To avoid injury from crushing, use appropriate lifting device with adequate lift and load capabilities. Refer to Specifications section for exact weight of head.




H106516 —UN—17JAN13

SS43267,00002C1 -19-27JUN13-1/1

Header Entanglement

Avoid serious injury from entanglement. Stop engine and remove key before opening cleanout doors.



H106351 —UN—08JAN13

SS43267,00002C2 -19-27JUN13-1/1

Transporting

Transporting on Trailer

⚠ CAUTION: Follow local regulations regarding width, lighting, and marking.

IMPORTANT: Whenever possible avoid transporting combine with header attached. If possible, transport header on a truck or header trailer.

Follow trailer manufacturer recommendations regarding safe transport procedures. In absence of such instructions, follow these guidelines:

- Do not transport at speeds greater than 32 km/h (20 mph) on a trailer not equipped with brakes, and 40 km/h (25 mph) on a trailer equipped with brakes.
- Always attach a properly sized safety tow chain.
- Always verify a slow moving vehicle (SMV) sign is mounted to rear of trailer or header.
- Always verify rear of trailer is equipped with red reflectors, two red taillights and turn signals.
- To reduce transport width, points should be in folded (upwards) position.




H120733 —UN—14FEB17

OUC6041,0000B2F -19-19JUN17-1/4

1. Raise each inner gatherer point (B) until latch (A) engages.

A—Latch

B—Point




H88847 —UN—24JUL07

OUC6041,0000B2F -19-19JUN17-2/4

2. Rotate header warning lights (A) rearward.

A—Warning Light




H94376 —UN—26JUN09

Continued on next page

OUC6041,0000B2F -19-19JUN17-3/4

3. Raise both outer gatherer points until latch pin (A) engages.

A—Latch



H89293 —UN—14JAN09

OUC6041,0000B2F -19-19JUN17-4/4

Transporting on Combine

CAUTION: Follow local regulations regarding width, lighting, and marking.

IMPORTANT: Whenever possible avoid transporting on public roadways with header attached.

If combine must be transported with header attached, make sure that flashing warning lights on the header are operating and reflective material is clean and visible.

Use of a spotter or pilot vehicle is recommended on busy, narrow, or hilly roads and when crossing bridges.

Drive at a speed safe for conditions.

H121090 —UN—15MAR17



Header Raise/Lower Switch
(Style A)

H116348 —UN—19DEC16




Header Raise/Lower Switch
(Style B)

1. Completely raise the header with the header raise/lower switch.

OUC6075,00046B7 -19-19JUN17-1/5

2. Engage feeder house safety stop (A).

A—Safety Stop



H90891 —UN—26FEB08

Continued on next page

OUC6075,00046B7 -19-19JUN17-2/5

- Engage road transport disconnect switch.

NOTE: Light will be ON when switch is engaged.

H121089 —UN—15MAR17



Road Transport Disconnect
(Style A)

H117022 —UN—28MAR16



Road Transport Disconnect
(Style B)

OUC6075,00046B7 -19-19JUN17-3/5

CAUTION: When transporting on a road or highway, flashing warning lights and tail lights on both sides provide a warning to approaching vehicles. Warning lights must be turned ON when driving combine on a public road.

Swing cab ladder fully forward to orient warning light towards oncoming motorists.

Do not operate flashing warning lights if prohibited by law.

H121091 —UN—15MAR17



Hazard Lights (Style A)

H117885 —UN—29MAR16



Hazard Lights (Style B)

- Turn hazard light switch ON for all road travel.

OUC6075,00046B7 -19-19JUN17-4/5

- Turn road lights switch ON for nighttime travel. Hazard lights automatically operate when the road lights are ON.



H117808 —UN—28MAR16

Switch



Road Lights

H117803 —UN—28MAR16

OUC6075,00046B7 -19-19JUN17-5/5


Attaching and Detaching

Attaching Header to Feeder House

IMPORTANT: See your combine Operator's Manual for specific tires required when operating the header.

Latch pins are not to be actuated with the header on the ground. If multicoupler must be actuated with the header on ground, unhook cable from handle.

1. Sound horn, start engine, and lower feeder house.
2. Slowly drive combine forward until feeder house is centered in frame opening.
3. Verify that hooks (A) on both sides of the feeder house catch the front side of the main frame beam of the header.
4. Completely raise the header and verify that lower latch pins are aligned with latch openings on header.



A—Hook (2 used)



OUC6075,00046B8 -19-19JUN17-1/9

H70033—UN—19SEP01

CAUTION: Failure to raise feeder house completely and lower safety stop (A) onto hydraulic cylinder rod may result in serious injury or death.

5. Shut OFF engine, set park brake, and remove key.
6. Lower safety stop (A) onto hydraulic cylinder rod.

A—Safety Stop



Continued on next page

OUC6075,00046B8 -19-19JUN17-2/9



H121063—UN—14MAR17

H90891—UN—26FEB08

7. Remove cover (A) and clean multicoupler face (B).

A—Cover

B—Multicoupler Face



H109779 —UN—05FEB14


H109780 —UN—05FEB14

OUO6075.00046B8 -19-19JUN17-3/9

8. Open handle (A) and remove the multicoupler (B) from the storage bracket.

A—Handle

B—Multicoupler



H99084 —UN—17NOV10

Continued on next page

OUO6075.00046B8 -19-19JUN17-4/9


IMPORTANT: To prevent damage to the latching cable, do not actuate latching pins with header on ground. Attempting to actuate may also cause screws on handle to shear.

NOTE: If screw shears, see *Shear Screw Location in Combine Operator's Manual* for further information.

9. Install multicoupler (A) onto receptacle (B) and close handle (C).

A—Multicoupler
B—Receptacle

C—Handle




H89284—UN—20JUL07

OUC6075,00046B8 -19-19JUN17-5/9

IMPORTANT: Failure to close the multicoupler fully so button lock can engage could result in the header falling off while harvesting or transporting.

10. When the multicoupler handle is fully closed, button lock (A) automatically locks the couplers together.

A—Button Lock



H87894—UN—19APR07

Continued on next page

OUC6075,00046B8 -19-19JUN17-6/9

NOTE: With header attached, latch pins must move freely through latch plate holes. If latch pins do not extend through latch plates, make sure that latching plates on header are properly adjusted.

11. Latch pins (A) should move freely through latch plate holes in header when the multicoupler is latched. Latch plate (B) must make contact with the frame (C). Less clearance should be maintained between bottom of plate and pin (D) rather than top of plate and pin (E). This may require the latch plate to be flipped.

If adjustment is needed: Remove cap screws (F), flip plate (B) end for end and reinstall.



12. Tighten cap screws to specification.

Specification

Cap Screws—Torque.....130 N·m
(96 lb·ft)

A—Latch Pin
B—Latching Plate
C—Frame

D—Lower Gap
E—Upper Gap
F—Cap Screws



OUC6075,00046B8 -19-19JUN17-7/9

H100720 —UN—17MAR11

H100709 —UN—17MAR11

13. Install multicoupler cover (A) on header storage position.

A—Cover



Storage Position


Continued on next page

OUC6075,00046B8 -19-19JUN17-8/9

H89283 —UN—14JAN09

- Remove telescoping driveshaft (A) from storage position and connect to the feeder house shaft (B). Verify that the quick-attach collar fully locks. If header uses dual driveshafts, repeat on the opposite side.

A—Telescoping Driveshaft B—Feeder House Shaft



H99085—UN—17NOV10

O006075,00046B8 -19-19JUN17-9/9

Attaching Header to Forage Harvester or Corn Husker

For attaching or detaching header on a forage harvester or a corn husker, refer to the Operator's Manual for that machine.

AZ06166,0000248 -19-19JUN17-1/1

Detaching Header from Feeder House


CAUTION: Do not leave driveshafts connected to combine. Personal injury or machine damage occurs if feeder house is accidentally engaged.

- Disconnect telescoping driveshaft from the feeder house shaft (A) and place on the storage bracket. If header uses dual driveshafts, repeat on the opposite side.

IMPORTANT: Do not actuate latch pins with the header on the ground. If multicoupler must be actuated with the header on ground, unhook cable from handle.

NOTE: Latch pins fully retract when the handle is all the way up against the stop. Adjust cable mounting if latch pins are not fully retracted (see *Single Point Latching—Adjusting in the Combine Operator's Manual*).

- Remove multicoupler cover from storage position on header.
- Raise handle and remove the multicoupler from the feeder house connection point (B).
- Place multicoupler in storage position on header and lock in place using handle.



A—Feeder House Shaft

B—Multicoupler Connection

- Place cover on the feeder house connection point and lock handle.


H114755—UN—10FEB16

Continued on next page

AZ06166,00001B1 -19-19JUN17-1/2

6. Sound horn, start engine, lower feeder house until hooks (A) are below the top frame of the header, and slowly drive combine rearward.

A—Hook (2 used)



H70033—UN—19SEP01

AZ06166,00001B1 -19-19JUN17-2/2

Calibration and Settings

When to Calibrate

NOTE: All Calibration: See calibrations for your Header in your Combine Operator's Manual.

Calibration procedures must be performed before first use or if header height control sensor, deck plate position sensor or associated components are replaced.

- Header Calibration
- Lateral Tilt Angle Sensor Calibration (if equipped)

CommandCenter is a trademark of Deere & Company

- Hydraulic Adjustable Deck Plate (if equipped)
- Active Float Calibration

NOTE: Conditions causing errors must be corrected before continuing calibration.

If any errors occur during calibration procedures, error codes are displayed at:

- CommandCenter™ display

OUO6075,00046BB -19-28MAR17-1/1

Calibration Error Codes

IMPORTANT: The condition or conditions causing the error code must be corrected before the calibration procedure can continue.

If any error codes occur during the calibration procedures, call your John Deere dealer with the error code number.

AZ06166,00001B2 -19-24APR17-1/1

User Calibration Procedures

H94478 —UN—31MAR10

NOTE: For machines equipped with the Generation 4 CommandCenter™ Display, see Calibrations Application Help or Operator's Station Help for further information.


Calibrations are performed using instructions shown on screen. Operator selects the diagnostics menu, selects desired calibration, and follows instructions given.

1. Highlight diagnostic icon and press the confirm switch.
2. Highlight calibration icon (A) and press the confirm switch.
3. Highlight calibration menu (B) and press the confirm switch.
4. Rotate selection dial until desired calibration is highlighted. Press the confirm switch.
5. Highlight Enter/Accept icon (C) and press confirm switch.
6. Follow instructions shown on the screen to perform desired calibration.
7. Repeat procedure as necessary for additional calibrations.

CommandCenter is a trademark of Deere & Company



Diagnostic Icon



A—Calibration Icon
B—Calibration Menu

C—Enter/Accept Icon

H94928 —UN—11OCT10

OUO6075,00046BC -19-23MAR17-1/1

Adjusting Feeder House Drop Rate and Sensitivity

NOTE: For machines equipped with the Generation 4 CommandCenter™ Display, see Header Application Help or Operator's Station Help for further information.

Height Sensing and Active Header Float Pressure Sensitivity (Automatic Functions): Controls the response rate for header movements when operating in automatic sensing and automatic float modes.

Changing rate for automatic functions:

1. Verify that road transport disconnect switch is in field mode.
2. Press feeder house rate/sensitivity adjust switch (A) **twice** to adjust settings. Settings are adjusted between 0 to 100.

NOTE: Sensitivity setting is shown on armrest display when adjusting.

CommandCenter is a trademark of Deere & Company



A—Feeder House Rate/Sensitivity Adjust Switch

B—Selection Dial

3. Turn selection dial (B) clockwise to increase response rate or counterclockwise to decrease response rate.

OUO6075,00046BD -19-19JUN17-1/2

H99167 —UN—23NOV10

Manual Raise/Lower Speed (Manual Functions):

Controls the response rate of header raise/lower functions during manual control and during automatic height resume mode.

Changing rate for manual functions:

1. Verify that road transport disconnect switch is in field mode.
2. Press feeder house rate/sensitivity adjust switch (A) **once** to adjust settings. Settings are adjusted between 0 to 100.

NOTE: Sensitivity setting is shown on armrest display when adjusting.

3. Turn selection dial (B) clockwise to increase response rate or counterclockwise to decrease response rate.



A—Feeder House Rate/Sensitivity Adjust Switch

B—Selection Dial

OUO6075,00046BD -19-19JUN17-2/2

H99167 —UN—23NOV10


Operating the Corn Head

General Information

The gatherer points (A) are positioned between the rows of corn. Stalk rolls (B) grab the corn stalks and pull them rapidly down through the row unit.

When an ear of corn reaches the deck plates, the ear is prevented from going through due to the narrow opening. As the stalk rolls continue to pull on the stalk, the ear of corn is snapped off.

Gatherer chains (C) catch the ears and carry them to the auger (D) which delivers the ears to the combine feeder house.



H89415 —UN—01AUG07

A—Gatherer Point
B—Stalk Rolls

C—Gatherer Chain
D—Auger

KR43067,0000743 -19-23NOV10-1/1

Drive and Operate Carefully

Drive carefully so the corn head will stay on the rows. Never force the corn head or combine to the point of overloading. Overloading can cause breakdowns. Start out in a lower gear and increase speed until you find the proper ground speed at which to operate.

Listen for slipping clutches or other unusual noises. If the corn head becomes plugged, clean it out by keeping engine at operating speed, but decrease ground speed until header has been cleared.

CAUTION: Familiarize yourself with the combine and corn head Operators Manuals.

IMPORTANT: The forward movement of the combine must be approximately the same as the rearward movement of the gathering chain flights or plugging can result.

KR43067,0000744 -19-23NOV10-1/1

Corn Head Speed of Travel

Forward combine travel must be close to the same speed as rearward movement of gathering chain flights.

If ground speed is too fast, gathering chains will push stalks forward and knock off ears. If ground speed is too slow, gathering chains will jerk stalks back into the corn head, possibly shearing off stalks or knocking off ears.

KR43067,0000745 -19-23NOV10-1/1

Armrest Functions

NOTE: For machines equipped with the Generation 4 CommandCenter™ Display, see Combine Overview Application Help or Operator's Station Help for further information.

CommandCenter™ Armrest header functions: For complete information on each function, see the combine Operator's Manual.

- | | |
|--|--|
| A —Header Engage and Feeder House Reverser Switch | G —Feeder House Rate/Sensitivity Adjust Switch |
| B —Separator Engage Switch | H —Cutterbar Tilt Adjust Switch (Rigid Draper ONLY) |
| C —Header Height/HydraFlex™ Pressure Control Dial | I —Selection Dial (Operating Adjustments and Controls) |
| D —Draper Belt Speed Adjust Switch | J —Reel Speed or Belt Pickup Speed Dial |
| E —Cutterbar Pressure Adjust Switch | K —Side Belt Speed Reduction Switch (Rigid and Flex Drapers ONLY) |
| F —Road Transport Disconnect Switch | |



CommandCenter is a trademark of Deere & Company
HydraFlex is a trademark of Deere & Company

H111118 —UN—16APR14

OUO6075,00046BE -19-24APR17-1/1

Active Header Control Display—Features

NOTE: For machines equipped with the Generation 4 CommandCenter™ Display, see Header Application Help or Operator's Station Help for further information.

For complete information on each function, refer to your combine Operator's Manual.

Active Header Control Display (A): Allows operator to recognize which function is active by highlighting appropriate icon on display.

NOTE: Control button locations may be different depending on combine model and installed equipment.

IMPORTANT: Performing any header calibration may automatically enable all six header modes discussed in this section.

Header Height Sensing Button (B): Allows operator to select the position of header relative to the ground and maintain that position automatically.


Header Height Sensing Button — HydraFlex™/HydraFloat™ (B): Allows operator to adjust the cutterbar ground pressure, or weight of the cutterbar, and return to that setting automatically. HydraFlex™ /HydraFloat™ works in conjunction with header height sensing to maintain a header position relative to the ground, follow the ground contour, and return to that position automatically.

Header Height Resume Button (C): Allows operator to select the position of the feeder house relative to the machine and return to that position automatically.

Lateral Tilt Button (D): Allows operator to maintain header position relative to the ground. Sensors are used to determine the height at each end of the header. Header is tilted at the feeder house to equalize distance to the ground at each end. If equipped with Header Height Sensing—HydraFlex™ (optional), the two systems work together to maintain the closest position of cutterbar relative to the ground.

Dial-A-Speed™ Button (E): Allows operator to select an automatic operating speed for reel or belt pickup belts. Operating speed is a ratio of machine ground speed to reel/belt speed.

*CommandCenter is a trademark of Deere & Company
HydraFlex is a trademark of Deere & Company
HydraFloat is a trademark of Deere & Company*



Feeder House Float Button (F): Allows a rigid header to be operated in contact with the ground and maintain a set contact pressure. Operator selects how firmly the header contacts ground and returns to that pressure automatically.

NOTE: Feeder House Float mode is not recommended with HydraFlex™ auger or 700 series draper platforms, as excessive wear of the poly skid shoes may occur.


Reel Position Resume Button (G): Allows operator to select the height and fore/aft position of reel and return to that position automatically.

Deck Plate Position Resume (H): Allows operator to select the opening width of the adjustable deck plates (if equipped) and return to that position automatically.

Description of Automatic Header Height Control Systems

NOTE: For machines equipped with the Generation 4 CommandCenter™ Display, see Header Application Help or Operator's Station Help for further information.

Automatic Header Height Control systems compensate for uneven ground and controls horizontal and vertical position of the header. The system continuously compares the preset position and the actual position, thus keeping the header in the desired working position. Values are entered by the response rate adjust and sensitivity adjust along with the selection dial on armrest.



H100084 —UN—08FEB11

System Requirements:

- Road transport disconnect switch must be in field position.
- Engine is running.
- Header engaged.
- Desired header control mode activated.

Lateral Tilt Adjustment—Two Modes

- Manual Adjust — hydraulic components are directly activated by multi-function lever.
- Automatic Adjust — parallel adjustments of the header in relation to the ground are carried out by sensors on each end of header. This ensures that the distance between the header and the ground is equal on both the left-hand and right-hand sides.

CommandCenter is a trademark of Deere & Company

Header Height Adjustment—Four Modes

- Manual Adjust — hydraulic components are directly activated by multi-function lever.
- Automatic Height Resume — header can be set to any position within the feeder house range.
- Automatic Height Sensing — height of the header is maintained with height sensors attached to the header. This ensures that header height is always constant over rough terrain.
- Automatic Float Control — machine maintains a constant header pressure with ground contact.

IMPORTANT: Manually adjusting tilt and height settings deactivate any automatic functions.

AZ06166,00001B4 -19-19JUN17-1/1

Header Engage/Disengage Drive

NOTE: For machines equipped with the Generation 4 CommandCenter™ Display, see Header Application Help or Operator's Station Help for further information.

Operator must be in the operator seat before engaging the separator and header switches.

To engage the header.

- Switch road transport disconnect switch (A) to field position.
- Engage separator switch (B).
- Engage header switch (C).

A—Road Transport Disconnect Switch
B—Separator Switch
C—Header Switch



H99168 —UN—23NOV10

CommandCenter is a trademark of Deere & Company

AZ06166,00001B5 -19-19JUN17-1/1

Deck Plate Control and Resume

NOTE: For machines equipped with the Generation 4 CommandCenter™ Display, see Header Application Help or Operator's Station Help for further information.

Reel position switch on the multi-function lever (A) allows operator to increase and decrease opening of the adjustable deck plates.

System is active when:

- Engine is running.
- Road transport disconnect switch (B) is in field position.
- Header is engaged.
- Deck plate adjust is activated on the display screen (C).

Setting Deck Plate Opening:


1. Press left-hand side of reel position switch (D) to increase deck plate opening.
2. Press right-hand side of reel position switch (E) to decrease deck plate opening.

NOTE: Deck plate position icon and deck plate opening value appears on CommandCenter display.

Deck plates have a range of 0 (minimum opening) to 9 (maximum opening).

Deck Plate Resume:

1. Manually set desired deck plate opening.
2. Press and hold activation button 1, 2, or 3 on multi-function lever for three seconds to memorize current deck plate position. Operator can now return to preset position anytime by pressing assigned activation button.



- A—Reel Position Switch D—Reel Forward Switch
B—Road Transport Disconnect Switch E—Reel Aft Switch
C—Deck Plate Activation Icon

CommandCenter is a trademark of Deere & Company

OU06075,00046C2 -19-28MAR17-1/1

Combines With Fixed-Speed Feeder House

Refer to ADJUSTMENTS — CORN HEAD section for changing header speed on fixed speed feeder house combine.

KR43067,0000749 -19-01DEC10-1/1

Harvesting Corn With Weakened or Broken Stalks

Stalks and ears can be weakened by disease (stalk rot) or insects (corn borers), causing them to break off near the ground when contacted by corn head gatherer points and shields. This material is pushed into piles that prevent stalks from contacting the stalk rolls. Crop is lost and harvesting productivity is reduced when this occurs.

The following is a list of possible solutions to these problems:

- Reduce combine ground speed.
- Increase corn head speed with the variable speed feeder house.
- Adjust deck plates as wide as possible without allowing ears to contact the stalk rolls.
- Remove ear savers.

KR43067,0000969 -19-24OCT11-1/1

Harvesting Popcorn

- Adjust deck plates as close as possible.
- Raise cross auger so largest diameter ear passes between flighting and floor without contact.

- Decrease header backshaft speed.
- Check combine Operators Manual for correct settings.


KR43067,0000753 -19-01DEC10-1/1

Gatherers

For most conditions, operate front of gatherer points just touching the ground.

In muddy conditions, or in snow, raise header high enough to prevent scooping material into throat opening.

Adjust all points level with one another.




H89417 —UN—01AUG07

JK22594,0000242 -19-13AUG07-1/1

Row Units

An individual row unit houses a pair of trash knives, gathering chains, deck plates, and stalk rolls. Ears of corn are snapped from the stalk and conveyed to the auger by the row unit.



H89154 —UN—22NOV10

KR43067,00005BA -19-01DEC10-1/1

Auger

Auger (A) conveys crop material from the row units and directs crop material into the feeder house.

A—Auger



H89295 —UN—20JUL07

OOU6043,0001C88 -19-03JAN08-1/1

Hydraulic Adjustable Deck Plates


NOTE: To adjust or calibrate your deck plates, see your combine Operator's Manual.

Hydraulic adjustable deck plates (A) allow operator to adjust deck plates from within cab for varying stalk and ear size.

Deck plates can only be moved when engine is running and road transport disconnect switch is in field position.

Pressing reel forward switch opens deck plates and pressing reel aft switch closes deck plates.

A—Deck Plate



H89701 —UN—21AUG07

KR43067,0000360 -19-21APR09-1/1

Outer Gatherer Extensions


Outer gatherer extensions (A) prevent ear loss over the sides of low profile gatherer sheets.

When operating in conditions where the corn stalks are down, lower the extensions for smooth stalk gathering action.

Extensions are incorporated into the outer fenders and can be raised and lowered as needed.

- Raise extension by pulling extension upwards until pin (B) locks in place.
- To lower extension; push pin (B) in, and lower extension.

NOTE: Extension must be in lowered position to raise outer gatherer point.



A—Extensions

B—Pin

OUC6041,0000B30 -19-15FEB17-1/1


H120734—UN—14FEB17

Raising and Removing Inner Gatherer Points and Shields


1. Remove cap screw (A).
2. Rotate shield lock (B) rearward until clear of shield (C).

A—Cap Screw
B—Shield Lock

C—Shield



Rear of Inner Shield Shown



Continued on next page

OUC6041,0000B38 -19-27FEB17-1/3

H102222—UN—15JUN11

H102223—UN—15JUN11

3. Raise point until pin (A) locks in place.

CAUTION: Avoid serious injury when lifting and removing point and shield assembly. Assembly is heavy and awkward to handle.

4. Pull latch bar (B) and lift point and shield assembly together.

5. **IF EQUIPPED:** Disconnect any sensor harness connectors from main wiring harness. To access connectors located inside shield, cut tie bands attached to rear of shield and pull out connectors.

6. *Disconnect lift cylinder:*

- a. Remove locking cap screw (E).
- b. Apply upward pressure to the gatherer shield (C) until retaining pin is at rear of the slotted hole (D).
- c. Lift cylinder mount (F) upwards until mount clears pins.

CAUTION: Use caution when lifting. Assembly is heavy and awkward to handle.

7. Slide gatherer shield (C) sideways until shield is free of support pins (G) and lift shield assembly off mount.




8. Install gatherer shield in reverse order using the following special instructions:

- a. Tighten locking cap screw (E) to specification.

Specification

Locking Cap
Screw—Torque.....17 N·m
(150 lb-in)

A—Pin
B—Latch Bar
C—Gatherer Shield
D—Rear of Slotted Hole
E—Locking Cap Screw
F—Cylinder Mount
G—Support Pin (2 used)



H99087—UN—17NOV10

H120916—UN—24FEB17

H120811—UN—14FEB17

OUC6041,0000B38 -19-27FEB17-2/3

IMPORTANT: Do not over tighten cap screw when installing shield lock.

- b. Tighten shield lock cap screw (A) to specification.

Specification

Gatherer Shield Lock
Cap Screw—Torque.....20 N·m
(177 lb-in)

A—Cap Screw



H102222—UN—15JUN11


OUC6041,0000B38 -19-27FEB17-3/3

Raising and Tilting Outer Gatherer Points and Shields

1. Release latch pin (A) and rotate to locked position.
2. Raise outer point until pin (B) locks in place.
3. Release pin (C) and rotate gatherer shield and point outward.

A—Locking Latch Pin
B—Latch Pin

C—Latch Pin



OUO6041,0000B31 -19-14FEB17-1/1

H120812 —UN—14FEB17


H88427 —UN—23JUL07

Auger Floor Cleanout Door

CAUTION: Avoid serious injury.

- Never clean equipment with engine running.
- Engage feeder house safety stop when performing work under corn head.
- Wear proper eye and face protection to protect against falling debris.

1. Release latch (A) and open door (B).
2. Clean auger floor using clean out door on both sides of corn head.
3. Verify door is fully latched before operating corn head.



A—Latch

B—Door

KR43067,00005B2 -19-18NOV10-1/1

H99090 —UN—17NOV10

Engaging and Disengaging StalkMaster™ Chopping Knives

Headers equipped with the StalkMaster™ chopping option can disengage each chopping gear case individually. Disengaging all chopping gear cases allows the operator to use a chopping header as a non-chopping header when desired. Disengaging individual chopping gear cases allows the operator to limit the number of row units that are chopping when different amounts of residue are wanted.


1. Lower header to the ground completely *or* raise feeder house and engage feeder house safety stop.

CAUTION: Avoid serious injury or death. Do NOT perform this procedure with engine running.

2. Shut OFF engine, set park brake, and remove key.
3. Raise gatherer point and shield (see Raising and Removing Center Gatherer Shields and Points in this section).

NOTE: Engage/disengage lever is mounted on the right-hand side of chopping gear case (A).

StalkMaster is a trademark of Deere & Company



H120912—UN—23FEB17

A—StalkMaster™ Chopping Gear Case

B—Engage/Disengage Lever

4. Rotate lever (B) upwards to engage chopping blades and downwards to disengage.
5. Lower gatherer shield and point.
6. Repeat procedure for each row unit or as necessary.

AZ06166,000012D -19-19JUN17-1/1

Attachments and Options

Ear Savers

- Ear savers prevent loose ears from sliding over the gatherer chains to the ground.
- In down corn, or if stalks tend to plug up at the gatherer throat opening, remove and retain ear savers and hardware.
- In standing corn, install ear savers to prevent ear loss.


Replace ear savers as follows:

1. Remove cap screws (B) and ear savers (A).
2. Repeat for remaining rows.
3. Install ear savers in reverse order.

NOTE: *When installing ear savers, tighten cap screws to specification.*

Specification

Cap Screws—Torque.....25 N·m
(18 lb.-ft.)



A—Ear Savers

B—Cap Screws

H89201—UN—12JUL07

KR43067,000055B -19-12MAY10-1/1

Stalk Rolls

Stalk rolls pull cornstalks down so the ears are snapped off at the stalk and deposited onto the deck plates.

To help you decide which stalk rolls are best suited for your needs, see the following guidelines:

(A) Opposed Knife Stalk Rolls

Recommended if:


- Need to cut and size corn stalks to length 25.4—40.6 cm (10—16 in) at harvest.
- Need faster residue breakdown.
- Need earlier soil warm up and dry out.
- Need improved handling of residue by tillage and planting equipment, especially in high yielding corn.
- Need to reduce passes needed for shredding, cutting, or sizing stalks with other implements.
- Need a good performance in dry conditions.
- Harvesting in heavy grass, vines, and weeds.
- Need to lower power consumption on non-chopping corn heads.

(B) Straight Fluted Stalk Rolls

NOTE: Only available from John Deere Service Parts.

Recommended if:

- Need slow residue breakdown.
- Want maximum residue at planting time.
- Want to trap more snow/conservate moisture.
- Need better residue flow through narrow spaced drills when no-tilling.
- Need more complete shredding with a flail shredder.
- Need good performance in moderately dry, brittle conditions where stalks break off at or slightly below the ear.
- Need to lower power consumption by corn head.



H100708—UN—25MAR11

(C) Intermeshing Knife Stalk Rolls

NOTE: Only available from John Deere Service Parts for 8R36/38 and 12R36/38.

Recommended if:

- Need best material handling.
- Harvesting in damp, tough, and high moisture conditions.
- Need faster residue breakdown.
- Need earlier soil warm up and dry out.
- Need improved handling of residue by tillage and planting equipment, especially in high yielding corn.
- Need to reduce passes needed for shredding, cutting, or sizing stalks with other implements.


OUC6075,000476A -19-19JUN17-1/1

Active Header Control Ground Sensors

Sensor arms (A) are located under the corn head, mounted to the gatherer points (B). The sensor arm follows the contours of the ground, which activates a potentiometer. The signal provided allows the combine to maintain a desired cutting height during harvest.

A—Sensor Arm

B—Gatherer Point



H100667—UN—16MAR11

SS43267,00000CB -19-31MAY12-1/1


StalkMaster™ Chopping Gear Cases (Optional)

StalkMaster™ chopping gear cases (A) allow one pass cutting and sizing of corn stalks, eliminating the need for additional equipment passes. Operators have the option to disengage one or all of the gear cases, allowing a wide range of flexibility in residue management.

Factory installed cornstalk choppers are available on models 706C-SM, 708C-SM, 712C-SM, 716C-SM, and 718C-SM corn heads.

IMPORTANT: Replacement chopping gear cases purchased through service parts are shipped dry. Gear case **MUST** be filled with oil to the proper level before use (see Lubrication and Maintenance section for specifications).

StalkMaster is a trademark of Deere & Company



A—StalkMaster™ Chopping Gear Cases

H96323 —UN—19MAY10

OUC6041,0000B10 -19-24APR17-1/1


AutoTrac RowSense

AutoTrac RowSense uses input from sensors mounted on the corn head to assist existing GPS navigation in steering the combine during harvest.

As cornstalks pass through the gatherer points, they push a set of mounted sensor arms (A). The signals from these sensors are used to identify the location of the corn row, and make necessary adjustments to the combine steering to keep it in line with the crop.

NOT an option for 6R36/38, 8R36/38, and 12R36/38

A—Row Sensors



H96836 —UN—25MAR10

SS43267,000014C -19-11OCT12-1/1

Stubble Lights

Stubble lights (A) illuminate area directly behind the header so operator can see height of cut during nighttime harvesting.

Stubble light direction can be adjusted for best visibility.

A—Stubble Light



H120821 —UN—22FEB17

AZ06166,000012E -19-19JUN17-1/1

Adjustments—Corn Head

Adjusting and Leveling Gatherer Points


CAUTION: Raise header until points are off the ground. Shut OFF engine, set park brake, and remove key.

Set one gatherer point to an appropriate height. Set remaining points to same height.

1. Raise the gatherer point (A) until the pin (B) locks into place.
2. Pull the spring locking pin (C) and adjust height using location holes (D).
3. Fine adjustments can be made by loosening lock nut (E) and adjusting cap screw (F) up or down.

A—Gatherer Point
B—Pin
C—Spring Locking Pin

D—Location Hole
E—Lock Nut
F—Cap Screw



H114004—UN—04MAY15

AZ06166,00001B7 -19-19JUN17-1/1

Adjusting Trash Knives

Trash knives (A) prevent weeds and trash from wrapping around stalk rolls.

1. Loosen cap screws (B).
2. Adjust rear of trash knife so clearance between fin and knife (C) is to specification.

Specification

Stalk Roll Fin to Trash

Knife—Maximum

Clearance..... 1.5 mm
(1/16 in.)


3. Adjust front of trash knife to provide clearance for stalk roll flighting (D).
4. Tighten cap screws to specification.

Specification

Trash Knife Mounting

Cap Screws—Torque..... 130 N·m
(96 lb.-ft.)

5. Manually rotate stalk rolls and verify no contact exists between stalk roll and knife.
6. Repeat procedure on opposite trash knife and for remaining row units.



A—Trash Knife
B—Cap Screws and Washers
(8 used)

C—Clearance, Stalk Roll Fin to
Trash Knife
D—Clearance, Stalk Roll Flight
to Trash Knife

H101481—UN—17MAY11

KR43067,00008B5 -19-15JUN11-1/1


Adjusting Gatherer Chain Tension

Gatherer chain tension is maintained by a spring-loaded tightener. The spring is shielded by a spacer tube (A) that also serves as a stop to prevent the idler sprocket (B) from retracting too far.

- To increase gatherer chain tension, loosen nut (C) and tighten cap screw (D).
- To prevent chain from running off idler sprocket, maintain a 4.8 mm (3/16 in) maximum space between spacer tube (A) and washer (E).

A—Spacer Tube
B—Idler Sprocket
C—Nut

D—Cap Screw
E—Washer



H120815 —UN—15FEB17

AZ06166,000012F -19-21FEB17-1/1

Adjusting Gatherer Chain Flights


IMPORTANT: Be careful to avoid rocks and other obstructions in the row when running gatherers close to the ground.

Completely raise the header, shut OFF engine, set park brake, remove key, and lower feeder house safety stop.

Gathering chains are assembled at the factory with the chain flights (A) staggered between one another.

If the gathering chain tensioner range of adjustment has been reached or the chains fails, replace with a new chain. When replacing chain, also replace the drive sprocket and idler sprocket assembly to prevent premature wear of the replacement chain.

1. Open gatherer points and shields as necessary.



A—Chain Flights

H120816 —UN—15FEB17

AZ06166,00001BC -19-19JUN17-1/5


2. Loosen nut (A) until it is close to but not touching the leg of the idler support strap (B).

NOTE: Use a backup wrench on nut (A) to prevent nut from tightening against the idler support strap (B) when loosening cap screw (C).

3. Loosen cap screw (C) until nut (D) disengages.

A—Nut
B—Idler Support Strap

C—Cap Screw
D—Nut




H120817 —UN—16FEB17

Continued on next page

AZ06166,00001BC -19-19JUN17-2/5


4. On the gatherer chain (A), locate the three flights with the closest spacing (B) between them.
5. Lift gatherer chain off drive sprocket (C) and rotate chain until flights with the closest spacing are next to the guide chain (D).

A—Gatherer Chain
B—Flights With the Closest Spacing (3 used)
C—Drive Sprocket
D—Chain Guide




AZ06166,00001BC -19-19JUN17-3/5

H121352—UN—26APR17



A—Notch (3 used)
B—Chain Guide
C—Groove (3 used)
D—Flights With the Closest Spacing (3 used)



6. Adjust gatherer chain so notches (A) in the chain guide (B) are aligned with grooves (C) in flights with the closest spacing (D) as shown.

7. Place gatherer chain back on drive sprocket. Verify that notches and grooves remain aligned.

Continued on next page

AZ06166,00001BC -19-19JUN17-4/5


H121342—UN—10MAY17

H121340—UN—10MAY17

8. Tighten cap screw (A) into nut (B) until a 4.8 mm (3/16 in) maximum space is set between spacer tube (C) and washer (D).
9. Tighten nut (E) against the idler assembly.

A—Cap Screw
B—Nut
C—Spacer Tube

D—Washer
E—Nut



H121349 —UN—25APR17

AZ06166,00001BC -19-19JUN17-5/5


Adjusting Deck Plates

NOTE: Deck plates are set at factory.

1. Set deck plates to closed position (cylinder (A) fully extended). Verify that left-hand side deck plates are in the closed position. Reset and tighten the clamp (B) if necessary.
2. Clamp (B) closes and crimps tie bar when hardware is tightened. Adjust pivot arms on remaining row units.

A—Cylinder

B—Clamp



H90238 —UN—14JAN09

Continued on next page

AZ06166,0000131 -19-21FEB17-1/2


3. Loosen cap screws (A) allowing right-hand deck plate to slide.
4. Set front spacing (B) to 15 mm (23/32 in) and rear spacing (C) to 17 mm (25/32 in).
5. Tighten cap screws to specification.

Specification

Cap Screws—Torque.....95 N·m
(70 lb·ft)

A—Cap Screw (3 used)
B—Front Spacing

C—Rear Spacing




H120819—UN—19FEB17

AZ06166,0000131 -19-21FEB17-2/2

Adjusting Row Unit Drive Chain

1. Remove cap screws and washers (A), and cover (B).

A—Cap Screws and Washers
(6 used) **B—Cover**



H99229—UN—30NOV10

Continued on next page

DM84283,00006F7 -19-21MAY15-1/2

NOTE: An overtightened chain will cause undue chain wear. Row unit chain is a continuous chain without a connector link.


- 2. Loosen tensioner hardware (A).
- 3. Adjust tensioner downward to increase chain tension or upwards to decrease tension. Lower chain strand (B) should have movement of 10 mm (25/64 in.) up and 10 mm (25/64 in.) down. Tighten hardware to specifications.

Specification

Tensioner Cap	
Screws—Torque.....	90 N·m (66 lb.-ft.)

IMPORTANT: Verify O-ring seal (C) is clean and undamaged before installing cover. Replace as necessary.

- 4. Install cover using cap screws and washers. Tighten cover cap screws to specification.



A—Tensioner Hardware
B—Lower Drive Chain
C—Seal

Specification

Row Unit Drive Chain	
Cover—Torque.....	17 N·m (150 lb.-in.)

DM84283,00006F7 -19-21MAY15-2/2

H99230—UN—30NOV10

Adjusting Row Unit Drive Sprockets With Fixed Speed Drive ONLY

Sprocket Pairs for Corn Heads			
Model	Drive Side	Drive Sprocket	Driven Sprocket
6R, non-chopping	Left-hand	30	33
8R36/38 12R, non-chopping	Dual	30	33
8R30	Left-hand	24	27
All chopping corn heads (StalkMaster) 16R, non-chopping 18R, non-chopping	Dual	24	27

IMPORTANT: These sprockets must **NOT** be changed for variable speed combines.

Changing corn head drive sprockets with a variable speed feeder house can result in over-driving the corn head, resulting in machine damage. Front driven shaft should never exceed 715 rpm.

1. Drain oil and remove cover pan (see REMOVE AND INSTALL OIL PAN in SERVICE section).
2. Loosen tensioning hardware and remove drive chain.
3. Remove and install drive sprockets as necessary.
4. Install drive chain and adjust tension to proper setting (see ADJUSTING ROW UNIT DRIVE CHAIN in ADJUSTMENTS — CORN HEAD section).
5. Install cover pan.
6. Add lubrication to proper level (see REMOVE AND INSTALL OIL PAN in SERVICE section).
7. For dual drive corn heads, repeat procedure on opposite side.

IMPORTANT: For dual drive corn heads, sprockets **MUST** be same configuration on each end.

COMBINES —

NOTE: Recommended travel speed is based on average field conditions. Your field conditions may differ, requiring different sprocket configuration.

When operating at increased ground speeds, install smaller sprocket on driven shaft and larger sprocket on drive shaft.

Recommended Combine Travel Speed for Sprocket Configuration				
	Non-Chopping Corn Head		Chopping Corn Head	
Recommended Speed	Drive Sprocket	Driven Sprocket	Drive Sprocket	Driven Sprocket
7 km/h (4 mph) or Less	30 tooth	33 tooth	24 tooth	27 tooth
Above 7 km/h (4 mph)	33 tooth	30 tooth	27 tooth	24 tooth

FORAGE HARVESTERS —

NOTE: Recommended travel speed is based on average field conditions. Your field conditions may differ, requiring different sprocket configuration.

When operating at increased ground speeds, install smaller sprocket on driven shaft and larger sprocket on drive shaft.

Recommended Forage Harvester Travel Speed for Sprocket Configuration				
	Non-Chopping Corn Head		Chopping Corn Head	
Recommended Speed	Drive Sprocket	Driven Sprocket	Drive Sprocket	Driven Sprocket
5 km/h (3 mph) or Less	30 tooth	33 tooth	24 tooth	27 tooth
Above 5 km/h (3 mph)	33 tooth	30 tooth	27 tooth	24 tooth

CORN HUSKERS —

Recommended Sprocket Configuration for Corn Huskers			
Non-Chopping Corn Head		Chopping Corn Head	
Drive Sprocket	Driven Sprocket	Drive Sprocket	Driven Sprocket
33 tooth	30 tooth	27 tooth	24 tooth

KR43067,00009BF -19-09DEC11-1/1


Adjusting Auger Height

Auger can be adjusted up and down for clearance between auger flighting and floor.

1. Raise and tilt open the outer gatherer points and shields (see Raising and Tilting Outer Gatherer Points and Shields in Operating the Corn Head section of this manual).
2. Remove cap screw and washer (A).
3. Remove side shield (B).

A—Cap Screw and Washer

B—Side Shield




H121804—UN—19JUN17

AZ06166,000022E -19-20JUN17-1/5

4. Remove cap screws (A) and auger drive chain shield (B).

A—Cap Screw (3 used)

B—Auger Drive Chain Shield




H114855—UN—29JUN15

AZ06166,000022E -19-20JUN17-2/5

5. Loosen nut (A) and auger drive chain.

A—Nut



H114856—UN—29JUN15

Continued on next page

AZ06166,000022E -19-20JUN17-3/5

6. Attach an appropriate lifting device to the auger.

IMPORTANT: Due to auger and flighting tolerances (auger runout), there must be at least a minimum clearance between auger flighting and floor.

Also see **Adjusting Lower Stripper** in this section.

NOTE: In most conditions, keep bearing carriers adjusted to the lowest position in the upper holes (D). Do not use the lower holes (E) unless the corn head is equipped with a grain quality floor kit. Lowering the auger below the minimum clearances listed increases crop damage.


Improved grain quality can be obtained by installing a grain quality floor kit. A grain quality floor kit allows for lower auger flighting to floor clearances. See your John Deere dealer for further information.

Specification

Auger Flighting to Floor—Minimum Clearance (Without Grain Quality Kit).....	30—35 mm (1-3/16—1-3/8 in)
---	-------------------------------

Auger Flighting to Floor—Minimum Clearance (With Grain Quality Kit).....	15—20 mm (19/32—25/32 in)
--	------------------------------

7. Loosen carriage bolts and nuts (A) on the bearing carrier (B).
8. Adjust auger height up or down as necessary.
9. If the auger needs lowered further than the adjustment slots (C) allow:
 - a. Remove carriage bolts and nuts from the bearing carrier.
 - b. Move bearing carrier from the upper holes (D) to the lower holes (E) and reinstall carriage bolts and



- | | |
|----------------------------------|-----------------------|
| A—Carriage Bolt and Nut (4 used) | D—Upper Hole (2 used) |
| B—Bearing Carrier | E—Lower Hole (2 used) |
| C—Adjustment Slot (2 used) | |

nuts. Do not tighten carriage bolts and nuts to specification at this time.

IMPORTANT: Auger must be adjusted equally across the entire length of the auger.

10. Adjust bearing carrier on the opposite side of the header.

Continued on next page

AZ06166,000022E -19-20JUN17-4/5

H121805—UN—19JUN17

H121807—UN—19JUN17


11. For 12-, 16-, and 18-row headers, adjust the center auger support:
 - a. Loosen carriage bolts and nuts (A).
 - b. Adjust nuts (B) to move the auger up or down as necessary.
12. Verify that the auger is adjusted to give equal auger flighting to floor clearance across the length of the auger.
13. Tighten all hardware on bearing carriers and center auger support, if equipped, to specification.

Specification

Bearing Carrier
Hardware—Torque.....35 N·m
(26 lb·ft)

Center Auger Support
Hardware (12-, 16-,
and 18-Row Corn
Heads)—Torque.....88 N·m
(65 lb·ft)

14. Adjust the auger drive chain (see Adjusting Auger Drive Chain in this section).



A—Carriage Bolt and Nut (3 used) B—Nut (2 used)

15. If equipped, adjust the auger drive chain on the opposite side.
16. Install previously removed shields.

AZ06166,000022E -19-20JUN17-5/5

H121806 —UN—19JUN17

Adjusting Lower Stripper

Strippers on the rear wall of the corn head prevent crop and material from wrapping around auger as it is transported towards the feeder house. The lower stripper (A) is adjustable.


1. Loosen hardware (B).
2. Adjust stripper forward or rearward so the specified gap exists between auger flighting (C) and stripper edge (D).

Specification

Auger Flighting and
Stripper—Clearance.....6 mm
(1/4 in)

3. Tighten previously loosened hardware.

**A—Lower Stripper C—Auger Flighting
B—Hardware D—Stripper Edge**




OUC6075,000433A -19-13SEP16-1/1

H95839 —UN—25MAR10

Coupling the Chain

When securing a chain coupler link, closed end of spring lock must face in direction of chain travel.



H41470

H41470 —UN—28NOV89

KR43067,0000738 -19-09JUL15-1/1

Adjusting Auger Drive Chain

1. Remove cap screws (A) and cover (B).
2. Loosen lock nuts (C).
3. Slide idler plate (D) down to increase chain tension and slide plate up to decrease tension.
4. Tighten lock nuts to specification.



Specification

Idler Plate	
Nuts—Torque.....	90 N·m (66 lb.-ft.)

NOTE: Excess chain tension will cause undue chain wear.
Set chain tension so slack side movement is 10 mm (3/8 in.) up and 10 mm (3/8 in.) down.

A—Cap Screws
B—Cover

C—Lock Nuts
D—Idler Plate



H114322 —UN—05JUN15

H114323 —UN—05JUN15

DM84283,00006F8 -19-21MAY15-1/1

Lubrication

Grease

Use grease based on NLGI consistency numbers and the expected air temperature range during the service interval.

The following grease is recommended:

- John Deere SD POLYUREA GREASE (TY6341)


Other greases may be used if they meet the following:

- NLGI Performance Classification GC-LB

IMPORTANT: Some types of grease thicken and are not compatible with others.

If grease fitting is missing, replace immediately. Clean fittings thoroughly before using grease gun.

Product Number	Description
TY6341	Multi-Purpose, High-Temperature Extreme Pressure Grease, especially effective in rolling contact applications.



TS1667—UN—30JUN99

AG,OOU1035,1175 -19-09JUL15-1/1

Lubricant Storage

Your equipment can operate at top efficiency only when clean lubricants are used.

Use clean containers to handle all lubricants.

Store lubricants and containers in an area protected from dust, moisture, and other contamination. Store containers on their side to avoid water and dirt accumulation.

Make certain that all containers are properly marked to identify their contents.

Properly dispose of all old containers and any residual lubricant they may contain.

DX,LUBST -19-11APR11-1/1

Alternative and Synthetic Lubricants

Conditions in certain geographical areas may require lubricant recommendations different from those printed in this manual.

Some John Deere brand coolants and lubricants may not be available in your location.

Consult your John Deere dealer to obtain information and recommendations.

Synthetic lubricants may be used if they meet the performance requirements as shown in this manual.

The temperature limits and service intervals shown in this manual apply to both conventional and synthetic lubricants.

Re-refined base stock products may be used if the finished lubricant meets the performance requirements.

DX,ALTER -19-11APR11-1/1

Mixing of Lubricants

In general, avoid mixing different brands or types of oil. Oil manufacturers blend additives in their oils to meet certain specifications and performance requirements.

Mixing different oils can interfere with the proper functioning of these additives and degrade lubricant performance.

Consult your John Deere dealer to obtain specific information and recommendations.

DX,LUBMIX -19-18MAR96-1/1

Lubrication and Maintenance

Service Interval Chart—Every 10 Hours

	Every 10 Hours
Clean and Inspect AutoTrac™ RowSense™ Sensors (If Equipped)	•

*AutoTrac is a trademark of Deere & Company
RowSense is a trademark of Deere & Company*

OUO6075,00046A8 -19-25APR17-1/1

Every 10 Hours of Operation


Cleaning AutoTrac™ RowSense™ Sensors (If Equipped)

CAUTION: Shut OFF engine, set park brake, and remove key.

Raise feeder house completely and lower safety stop onto hydraulic cylinder rod.

AutoTrac™ RowSense™ sensors (A) should be checked daily to see if cleaning is necessary. If material has accumulated on sensors it may prevent free movement and affect performance. To clean row sensors, remove debris from sensors and surrounding area. Check that sensors move freely without obstruction.

A—Sensors



H95836 —UN—25MAR10

*AutoTrac is a trademark of Deere & Company
RowSense is a trademark of Deere & Company*

OUO6075,00046A9 -19-24APR17-1/1

Service Interval Chart—Every 200 Hours

	Every 200 Hours
Inspect and Adjust Chains	•
Replace Oil in Row Unit Drive Chain	•
Lubricate Auger Drive Chain	•
Check Row Unit Gear Case Oil	•
Lubricate Row Unit Slip Clutch	•
Lubricate Auger Drive Slip Clutch	•
Check StalkMaster™ Chopping Gear Case Oil (if equipped)	•
Lubricate Input Drive Shaft(s)	•

IMPORTANT: To avoid equipment damage and failure due to system contamination, always clean grease fittings before and after lubrication.

If a grease fitting is damaged or missing, replace it immediately.

IMPORTANT: When checking oil levels, always clean area around plugs before removal.

Always tighten plugs securely.

StalkMaster is a trademark of Deere & Company

OUO6075,00046AA -19-25APR17-1/1

Every 200 Hours of Operation


Inspect and Adjust Chains—Gatherer, Auger Drive, and Row Unit Drive

NOTE: Different header models may have a different number of each chain.

1. **Auger Chain (A):** Inspect condition and tension of chain. Adjust or replace as necessary (see Adjusting Auger Drive Chain in Adjustments section).
2. **Row Unit Drive Chain (B):** Inspect condition and tension of chain(s). Adjust or replace as necessary (see Adjusting Row Unit Drive Chain in Adjustments section of this manual).
3. **Gatherer Chains (C):** Inspect condition and tension of chains. Adjust or replace as necessary (see Adjusting Gatherer Chain Tension in Adjustments section).

A—Auger Drive Chain
B—Row Unit Drive Chain

C—Gatherer Chain



H120820—UN—14FEB17

Continued on next page

OUC6041,0000B39 -19-19JUN17-1/8

Replace Oil in Row Unit Drive Chain:

IMPORTANT: Keep oil level to specification to prevent excessive chain wear.

1. Completely raise header and engage feeder house safety stop.
2. Operate header for a short time to warm oil before draining.

NOTE: Drain fluid into a clean container and dispose of properly.

3. Remove drain plug (A), disengage safety stop, and lower header to drain oil.
4. Install drain plug.
5. Remove check plug (B) and access door (C).

IMPORTANT: Oil level should be checked with the header on combine and gatherer points touching ground (approximately a 25° angle).

6. Add SAE 80/90 gear lube through fill location (D) until gear lube is level with bottom of the check plug hole (E). Approximate capacity is 0.9 L (1 qt).

Specification

Drive Chain	
Oil—Capacity.....	0.9 L (1 qt)




NOTE: Verify that access door seal is clean and undamaged. Replace as necessary.

7. Install access door and check plug. Tighten access door cap screws to specification.

Specification

Access Door Cap	
Screws—Torque.....	17 N·m (150 lb·in)

8. If header uses dual driveshafts, repeat on the opposite side.



A—Drain Plug
B—Check Plug
C—Access Door

D—Fill Location
E—Check Plug Hole

Continued on next page

OUC6041,0000B39 -19-19JUN17-2/8

H99231 —UN—30NOV10

H99232 —UN—30NOV10


H99233 —UN—30NOV10

Lubricate Auger Drive Chains:

CAUTION: To avoid serious injury, never lubricate chains with the engine running.

1. Operate header for a short time before lubricating chains. A warm chain increases penetration of oil between pins and bushings.
2. Lubricate chain with SAE 30 or heavier oil. John Deere TY6240 chain lube is available in an aerosol can.
3. If header uses dual driveshafts, repeat on the opposite side.

A—Auger Drive Chain



H120822 —UN—15FEB17

OUC6041,0000B39 -19-19JUN17-3/8



Check Row Unit Gear Case Oil:

NOTE: To obtain accurate readings on the dipstick, raise the header and warm the row unit gear case oil.

1. Operate header for a short time to warm gear case oil.
2. Completely raise header and engage feeder house safety stop.
3. Shut OFF engine, set park brake, and remove key.
4. Clean area around inspection plug/dipstick (A) to avoid dirt and debris from entering gear case.
5. Remove dipstick and wipe clean.
6. Completely thread dipstick into gear case, remove, and observe fluid level on shaft.
7. If level is below the full mark (B), add TY6296 80W 90 GL-5 gear lube through the dipstick port until gear lube is level with the full mark.

IMPORTANT: Do not overfill gear case. 0.42 L (0.44 qt) of lube is required to fill gear case from the minimum mark (C) to the full mark (B). The amount of lube to add at other levels is proportional.

A—Inspection Plug/Dipstick C—Minimum Mark
B—Full Mark




H120823 —UN—02MAY17

H100565 —UN—03MAR11


Continued on next page

OUC6041,0000B39 -19-19JUN17-4/8

Lubricate Row Unit Slip Clutches:



H99158 —UN—22NOV10



H114327 —UN—05JUN15

Non-Chopping Model Shown

A—Row Unit Slip Clutch Grease Fittings B—Chopping Gear Case

IMPORTANT: Each slip clutch has multiple grease fittings for ease of access. Lubricate only **ONE** fitting per clutch.

1. Completely raise header and engage feeder house safety stop.
2. **Non-Chopping Corn Head Only:**
 - a. Locate row unit slip clutch under header. Slip clutch is mounted on the left side of gear case.
 - b. Apply ten pumps of grease to one grease fitting (A) on slip clutch.

c. Repeat lubrication on remaining rows units.

3. Chopping Corn Head Only:

- a. Locate row unit slip clutch under header. Slip clutch is mounted between gear case and chopping gear case (B).
- b. Apply ten pumps of grease to one grease fitting (A) on slip clutch.
- c. Repeat lubrication on remaining row units.


OUC6041,0000B39 -19-19JUN17-5/8

Lubricate Auger Drive Slip Clutch:

IMPORTANT: Each slip clutch has multiple grease fittings for ease of access. Lubricate only **ONE** fitting per clutch.

1. Apply ten pumps of grease to one grease fitting (A) on auger drive slip clutch.
2. If header uses dual driveshafts, repeat on the opposite side.

A—Auger Drive Slip Clutch Grease Fitting



H114324 —UN—05JUN15

Continued on next page

OUC6041,0000B39 -19-19JUN17-6/8


Check StalkMaster™ Gear Case Oil (If Equipped):

NOTE: To obtain accurate oil level readings, raise header and warm StalkMaster™ chopping gear case oil.

1. Operate header a short time to warm gear case oil.
2. Completely raise StalkMaster™ header and engage feeder house safety stop.
3. Shut OFF engine, set park brake, and remove key.
4. Remove check/fill plug (A) at the rear of gear case. Oil level should be at bottom of the check/fill plug hole. Add TY6296 80W 90 GL-5 gear lube as necessary to obtain correct level. Reinstall check/fill plug.
5. Remove check/fill plug (B) at the front of gear case. Oil level should be at bottom of the check/fill plug hole. Add TY6296 80W 90 GL-5 gear lube as necessary to obtain correct level. Reinstall check/fill plug.
6. Repeat for remaining chopping gear cases.

A—Check/Fill Plug

B—Check/Fill Plug



Front Reservoir Shown

StalkMaster is a trademark of Deere & Company

OUC6041,0000B39 -19-19JUN17-7/8

H114325 —UN—05JUN15

H99160 —UN—22NOV10

Lubricate Input Driveshaft:

1. Rotate shield as necessary to access grease fitting.
2. Grease the input driveshaft grease fitting (A).
3. If header uses dual driveshafts, repeat on the opposite side.

A—Driveshaft Grease Fitting



OUC6041,0000B39 -19-19JUN17-8/8

H99088 —UN—17NOV10

Service Interval Chart—Every 400 Hours

	Every 400 Hours
Inspect AutoTrac™ RowSense™ Sensor Bushings (If Equipped)	•

AutoTrac is a trademark of Deere & Company
RowSense is a trademark of Deere & Company

OUC6075,00046AD -19-25APR17-1/1

Every 400 Hours of Operation


Inspect AutoTrac™ RowSense™ Sensor Bushings (If Equipped)

CAUTION: Shut OFF engine, set park brake, and remove key.

Raise feeder house completely and lower safety stop onto hydraulic cylinder rod.

Annually check for excessive wear of AutoTrac™ RowSense™ sensor bushings (A) and shafts. Replace as necessary.

A—Bushings



H121123—UN—22MAR17

*AutoTrac is a trademark of Deere & Company
RowSense is a trademark of Deere & Company*

OUO6075,00046AE -19-24APR17-1/1

Service Interval Chart—Every 1000 Hours

	Every 1000 Hours
Replace Oil in Row Unit Gear Case	•
Replace Oil in Chopping Gear Case (if equipped)	•

IMPORTANT: To avoid equipment damage and failure due to system contamination, always clean grease fittings before and after lubrication.

If a grease fitting is damaged or missing, replace it immediately.

IMPORTANT: When checking oil levels, always clean area around plugs before removal.

Always tighten plugs securely.

OUO6075,00046AB -19-25APR17-1/1

Every 1000 Hours of Operation

IMPORTANT: To avoid equipment damage and failure due to system contamination, always clean grease fittings before and after lubrication.

If a grease fitting is damaged or missing, replace it immediately.

IMPORTANT: When checking oil levels, always clean area around plugs before removal.

Always tighten plugs securely.

Replace Oil in Row Unit Gear Case

NOTE: To drain and fill oil, raise header and warm row unit gear cases.

1. Operate header to warm row unit gear case oil.
2. Completely raise the header and engage feeder house safety stop.
3. Shut OFF engine, set park brake, and remove key.
4. Clean area around inspection plug/dipstick (A) to avoid dirt and debris from entering gear case.
5. Remove dipstick and wipe clean.

NOTE: Drain oil into a clean container and dispose of properly.

6. Remove drain plug (B) and allow oil to drain.
7. Reinstall drain plug.
8. Add TY6296 80W 90 GL-5 gear oil through the dipstick port.


Specification

Reservoir—Capacity..... 1100 mL
(37.2 oz)


9. Completely thread dipstick into gear case, remove, and observe fluid level on shaft.
10. If level is below the full mark (C), add oil as necessary.

IMPORTANT: Do not overfill gear case. 0.42 L (0.44 qt) of oil is required to raise level from the minimum mark (D) to the full mark (C). The amount of oil to add at other levels is proportional.


11. Reinstall dipstick.



Viewed From Above Row Unit



Viewed from Below, Behind Row Unit



A—Inspection Plug/Dipstick
B—Drain Plug

C—Full Mark
D—Minimum Mark

12. Repeat for remaining row unit gear cases.

Continued on next page

OOU6041,0000B43 -19-25APR17-1/2

H120823 —UN—02MAY17

H103951 —UN—09NOV11

H96322 —UN—13MAY10

Replace Oil in StalkMaster™ Chopping Gear Cases

NOTE: To drain and fill oil, raise header and warm chopping gear cases. Chopping blades must be engaged in order to warm front reservoir oil. Verify that chopping gear case engage/disengage lever is in the engaged position.

1. Operate header to warm chopping gear case oil.
2. Completely raise the header and engage feeder house safety stop.
3. Shut OFF engine, set park brake, and remove key.

NOTE: Drain oil into a clean container and dispose of properly.


4. Remove front and rear drain plugs (A and B) and allow oil to drain.
5. Reinstall plugs.
6. Remove front and rear check/fill plugs (C and D).
7. Add TY6296 80W 90 GL-5 gear lube to front and rear reservoirs until level with bottom of check/fill plug holes.

Specification

Rear Reservoir—Capacity.....	350 mL (11.8 oz)
Front Reservoir—Capacity.....	630 mL (21.3 oz)

8. Reinstall check/fill plugs.
9. Repeat for remaining chopping gear cases.

StalkMaster is a trademark of Deere & Company



Front Reservoir Shown

A—Rear Drain Plug
B—Front Drain Plug

C—Rear Check/Fill Plug
D—Front Check/Fill Plug

H114326 —UN—05JUN15

H99162 —UN—22NOV10

OUO6041,0000B43 -19-25APR17-2/2

Troubleshooting

Corn Head

Most corn head operating problems can be traced to improper adjustment. The following troubleshooting chart may help when problems develop, by suggesting

a probable cause and a recommended solution. When trying to solve a problem, verify the source does not come from somewhere other than where the problem exists.

Symptom	Problem	Solution
Loss of Ear Corn in the Field	Points tips set too high.	Adjust points so tips lightly touch ground when row unit skid plate is 1 inch above ground. When picking low hanging ears, raise front tip of gatherer points and run corn head with skids close to ground.
	Ground speed too fast or too slow.	Operate at a speed to meet field and ground conditions. Too much ground speed can bend stalks forward and cause ears to fall ahead of gatherer chains. Slow ground speed can cause gatherer chains to jerk stalks and snap off ears causing ears to slide off header.
		Operate at a speed where gatherer chains help guide stalks into stalk rolls.
	Not picking planter rows.	Follow planted rows to minimize ear loss.
	Row units not centered on rows.	Adjust corn head row spacing to equal row spacing of corn in field.
	Ears sliding out over gatherer chains.	Replace worn ear savers or install ear savers.
	Gatherer chain speed too fast or too slow.	Change speed of variable speed feeder house or adjust combine ground speed.
Ear Shelling at Stalk Rolls	Deck plates not adjusted correctly.	Adjust deck plates. Reduce gap between deck plates.
	Machine operating too high.	Raise point tip and run head lower.
Shelled Corn Coming Out Rear of Combine	Excessive trash intake from corn head.	Increase variable drive speed or fixed drive combine. Open deck plate spacing on corn head.
Ears Sliding Out Through the Throat	Ear savers worn out.	Replace ear savers.
Pulling up Corn stalks	Deck plates set too close together.	Gradually open deck plates until stalks feed through rolls more freely.

Continued on next page

KR43067,0000758 -19-01DEC10-1/2

Troubleshooting

Symptom	Problem	Solution
Plugging	Traveling too fast for gatherer chain speed.	Slow down to meet crop conditions or increase row unit drive speed.
	Gatherer chain flights digging into cornstalk roots.	Lower point tip and run head higher.
	Corn too dry or down.	Remove ear savers.
	Worn stalk rolls.	Replace stalk rolls.
	Stalks breaking in stalk rolls or deck plates.	Adjust opening of deck plates. Also be sure deck plates are set equally and centered over center of rolls.
	Trash winds around stalk rolls.	Set trash knives closer to stalk rolls.
	Loose gathering chains.	Check gathering chain sprockets for wear. Adjust gatherer chain tension.
	Not picking planter rows.	Follow rows to minimize ear loss.
	Ground speed too fast, causing material to overrun corn head.	Operate at a speed to meet yield and ground conditions. Faster speed causes plugging.
	Material not flowing with auger.	Check auger housing for obstructions and roughness. Check auger for 22 mm (7/8 in.) clearance between auger flight and floor. Check auger for 6 mm (1/4 in.) clearance between auger flighting and stripper.
Loss of Ear Corn From Weakened or Broken Stalks. Problem is Caused by Disease (Stalk Rot) or Insects (Corn Borers)	Corn stalks plugging in gatherer throat opening.	Remove ear savers.
	Worn stalk rolls.	Replace worn stalk rolls.
	Contact of stalk with ear savers.	Remove ear savers.
	Ground speed too fast.	Reduce ground speed.
	Feeder house speed incorrect.	Find the correct speed for your conditions by trying different feeder house speeds.
	Worn stalk rolls.	Replace stalk rolls.

KR43067,0000758 -19-01DEC10-2/2

Active Header Control (AHC)

Symptom	Problem	Solution
Active Header Control (AHC) will Not Operate	Manual raise or lower does not work.	See your John Deere dealer.
	Active Header Control not enabled.	Enable desired Active Header Control mode.
	Feeder house to header connector not connected or loose.	Connect properly.
Active Header Control (AHC) Lowers but Will Not Raise Active Header Control Raises but Will Not Lower	Header sensor not properly connected or damaged.	Connect or repair sensor.
	Defective Active Header Control relay or Active Header Control card.	See your John Deere dealer.
	Defective Active Header Control relay or Active Header Control card.	See your John Deere dealer.
	Control shaft restricted.	Check for restriction.
System Cycles or Hunts	Auto drop rate valve closed.	Adjust in-line valve.
	Incorrect drop rate adjustment.	Adjust in-line valve.
System Fails Intermittently after Manually Raising Header Over Obstacle Header Raises or Lowers Too Slow or Too Fast	Incorrect accumulator setting.	See your combine Operators Manual.
	System was deactivated.	To reactivate, press activation button in multifunction control handle.
	Incorrect drop rate adjustment.	Adjust valve stack drop rate.
	In-line valve problem.	See your John Deere dealer.

KR43067,0000759 -19-01DEC10-1/1

Service

Hydraulic Cylinder Safety Stop

CAUTION: Shut OFF engine, set park brake, and remove key.

Cracking of the hydraulic line fittings to lower the feeder house results in an instantaneous dropping of the feeder house and header.

Manual Feeder House Fore/Aft Tilt

Raise feeder house completely and lower safety stop (A) onto hydraulic cylinder rod.

Shut OFF engine, set park brake, and remove key.

Hydraulic Feeder House Fore/Aft Tilt




Raise feeder house completely and tilt hydraulic feeder house fore/aft tilt frame fully forward and lower safety stop (A) onto hydraulic cylinder rod.

Shut OFF engine, set park brake, and remove key.

NOTE: When feeder house is raised and header is engaged, feeder house fore/aft tilt automatically moves forward allowing feeder house safety stop to be lowered onto hydraulic cylinder rod. Feeder house fore/aft tilt automatically returns to last known position when lowering.

When the header is disengaged, feeder house fore/aft tilt automatically moves forward upon raising. Feeder house fore/aft tilt will not return to last known position when lowering.

A—Safety Stop



OUC6075,00046C3 -19-24APR17-1/1

H121063 —UN—14MAR17

H112829 —UN—18FEB15

H90891 —UN—26FEB08


Remove and Install Stalk Rolls

CAUTION: Completely raise header and engage feeder house safety stop before performing any work.

1. Raise gatherer point until pin (A) latches into place.

IMPORTANT: Points can damage the combine windshield. Do not push shields over back of frame.

2. Pull latch bar (B) and lift gatherer shield.
3. Repeat as necessary for access to row units.



A—Pin

B—Latch Bar


Continued on next page

AZ06166,0000136 -19-19JUN17-1/7

H89314 —UN—20JUL07

4. Remove cap screws and washers (A) from the underside of the row unit frame.
5. Remove trash knives (B).

A—Cap Screw and Washer (8 used) B—Trash Knife (2 used)



H94250—UN—10JUN09

AZ06166,0000136 -19-19JUN17-2/7


NOTE: Use a 13 mm (1/2 in) steel plate (C) between rear of stalk rolls to prevent stalk rolls from rotating.

When removing left-hand retaining nut, insert plate from top.


When removing right-hand retaining nut, insert plate from bottom.

6. Remove and discard retaining nuts (B).
7. Remove and retain the spherical washer behind nut. Inspect washer for corrosion or damage. Replace if necessary.

A—Stalk Roll C—Steel Plate
B—Retaining Nut and Spherical Washer



H93698—UN—19MAR09



H120856—UN—22FEB17


Continued on next page

AZ06166,0000136 -19-19JUN17-3/7

IMPORTANT: Place alignment marks on face of stalk roll and shaft before removal. Stalk rolls must be installed in same position as removed.

8. Locate two ports (A) behind the spiral of stalk roll. Remove stalk roll from shaft by attaching a (two arm) gear puller to ports.
9. Remove all dirt and corrosion from shaft taper, splines, and threads. Inspect stalk rolls for wear or damage. Replace as necessary.

A—Stalk Roll Removal Port (2 used)



H100588 —UN—03MAR11


AZ06166,0000136 -19-19JUN17-4/7

IMPORTANT: A new nut must be purchased from John Deere Service Parts.

10. Stalk roll retaining nut (A) contains a pre-applied thread locking patch (B) and cannot be reused.

A—Retaining Nut


B—Thread Locking Patch



H97520 —UN—04AUG10

Continued on next page

AZ06166,0000136 -19-19JUN17-5/7



Cross Section of Stalk Roll Shown

11. Using alignment marks made on face of stalk roll and shaft, simultaneously install both stalk rolls (A) on shafts (B).

IMPORTANT: Flat side of washer **MUST** face away from stalk roll.

12. Install previously removed spherical washer (C) and new retaining nut (D).

IMPORTANT: Avoid loosening of stalk rolls. Follow torque and turn procedure exactly.

NOTE: Use a 13 mm (1/2 in) steel plate between rear of stalk rolls to prevent stalk rolls from rotating.

13. Tighten retaining nut as follows:



Specification

Stalk Roll Retaining
Nut—Torque..... 135 N·m + 60° Turn
(100 lb·ft + 60° Turn)

- Using a calibrated torque wrench, tighten the retaining nut to torque specification.
- Mark stalk roll at one corner of retaining nut (E).
- Moving clockwise around retaining nut, mark stalk roll at next corner of retaining nut (F).
- Position socket on retaining nut and extend first mark (E) onto wall of socket.
- Turn retaining nut 60° (G) by tightening retaining nut until mark on socket wall reaches second mark on stalk roll (F).
- Repeat on remaining stalk roll.

A—Stalk Roll
B—Shaft
C—Spherical Washer
D—Retaining Nut

E—Mark at Corner of Retaining Nut
F—Mark at Next Corner of Retaining Nut (clockwise)
G—60° Turn



H97519 —UN—04AUG10

H101114 —UN—18APR11

H101374 —UN—05MAY11


H101375 —UN—05MAY11

Continued on next page

AZ06166,0000136 -19-19JUN17-6/7

14. Install trash knives (B) using cap screws and washers (A).
15. Adjust trash knives (see Adjusting Trash Knives in Adjustments section).

A—Cap Screw and Washer (8 used) B—Trash Knife (2 used)



AZ06166,0000136 -19-19JUN17-7/7

H94250 —UN—10JUN09

Reversing Gatherer Chains and Sprockets for Additional Wear

The gatherer chains and sprockets can be reversed for extra wear. Reverse all row units at the same time.

1. To reverse gatherer chains and sprockets:


NOTE: Mark each chain and sprocket with side it was removed from for correct placement during assembly.

- a. Remove gatherer chains (A and B) — (see Remove and Install Gatherer Chain in this section).
- b. Remove drive sprockets (C and D).
- c. Install drive sprockets on the opposite shaft.
- d. Remove sprockets (E and F).
- e. Install sprockets on the opposite shaft.

IMPORTANT: Ensure that flights are oriented in the proper direction as shown.

- f. Flip each gatherer chain over and install on the opposite side. Adjust chains (see Remove and Install Gatherer Chain in this section).

2. Repeat on remaining row units.



A—Gatherer Chain
B—Gatherer Chain
C—Drive Sprocket

D—Drive Sprocket
E—Sprocket
F—Sprocket

AZ06166,00001BD -19-26APR17-1/1

H120857 —UN—16FEB17

Remove and Install Gatherer Chain

CAUTION: Completely raise the header, shut OFF engine, set park brake, remove key, and lower feeder house safety stop before working under header.


If the gatherer chain tensioner range of adjustment has been reached or the chains fails, replace with a new chain. When replacing chain, also replace the drive sprocket and idler sprocket assembly to prevent premature wear of the replacement chain.

Gatherer chains can be removed for servicing row unit parts without uncoupling the chain.

1. Remove folding gatherer point (see Raising and Removing Inner Gatherer Points and Shields in Operating the Corn Head section of this manual).

CAUTION: Never service components of the chain drive assembly until nut (A) is tight against the leg of the idler support strap (B).

2. Loosen nut (A) until it is close to but not touching the leg of the support strap (B).



A—Nut
B—Support Strap

C—Cap Screw
D—Gatherer Chain


NOTE: Use a backup wrench on nut (A) to prevent nut from tightening against the support strap (B) when loosening cap screw (C).

3. Loosen cap screw (C) to release tension on the gatherer chain (D).
4. Remove gatherer chain from sprockets.


Continued on next page

AZ06166,00001BE -19-19JUN17-1/4

H120858 —UN—03MAY17



H121341 —UN—10MAY17




H121350 —UN—26APR17

- A—Gatherer Chain
B—Flights With the Closest Spacing (3 used)
C—Sprocket (2 used)
D—Chain Guide


5. On the gatherer chain (A), locate the three flights with the closest spacing (B) between them.
6. Install the gatherer chain onto sprockets (C) so the three flights with the closest spacing are next to the chain guide (D) as shown.

IMPORTANT: Ensure that flights are oriented in the proper direction as shown.

AZ06166,00001BE -19-19JUN17-2/4



H121340 —UN—10MAY17



H121342 —UN—10MAY17

- A—Notch (3 used)
B—Chain Guide
C—Groove (3 used)
D—Flights With the Closest Spacing (3 used)

7. Adjust gatherer chain so notches (A) in the chain guide (B) are aligned with grooves (C) in flights with the closest spacing (D) as shown.


Continued on next page

AZ06166,00001BE -19-19JUN17-3/4

8. Tighten cap screw (A) into nut (B) until a 4.8 mm (3/16 in) maximum space is set between spacer tube (C) and washer (D).
9. Tighten nut (E) against the idler assembly.

A—Cap Screw
B—Nut
C—Spacer Tube

D—Washer
E—Nut



H121349 —UN—25APR17

AZ06166,00001BE -19-19JUN17-4/4

Remove and Install Oil Pan

1. Completely raise corn head and engage feeder house safety stop.
2. Operate header for a short time to warm oil.

NOTE: Capture fluid in a clean container and dispose of properly.

3. Remove drain plug (A), disengage safety stop, and lower corn head to drain oil.

IMPORTANT: Avoid damage to reusable seal on pan. Do not use sharp objects to pry between pan and corn head frame.

4. Remove cap screws and washers (B), and oil pan (C).
5. Clean all dirt and oil from side of frame (D) where oil pan is mounted.
6. Verify seal on oil pan (E) is clean and undamaged. Replace as necessary.

NOTE: When mounting oil pan, start installing hardware at center (F) and move outward.


7. Install oil pan using cap screws and washers. Tighten to specification.

Specification


Oil Pan Cap
Screws—Torque.....30 N·m
(256 lb.-in.)

A—Drain Plug
B—Cap Screw and Washer (15 used)
C—Oil Pan


D—Surface of Frame
E—Seal
F—Center Hole



H99231 —UN—30NOV10



H99234 —UN—30NOV10



H99235 —UN—30NOV10

Continued on next page

DM84283,00006FB -19-22MAY15-1/2

8. Install drain plug (A).
9. Remove check plug (B) and access door (C).

IMPORTANT: Oil level should be checked with corn head on combine and gatherer points touching ground (approximately a 25 degree angle).

10. Add SAE 80/90 gear lube through access door opening (D) until level with bottom of check plug hole (E).

Specification

Oil Pan—Capacity..... 0.9 L
(1 qt.)

*NOTE: Verify access door seal is clean and undamaged.
Replace as necessary.*




11. Install row unit drive chain cover and check plug.
Tighten cover cap screws to specification.

Specification

Row Unit Drive Chain
Cover—Torque..... 17 N·m
(150 lb.-in.)

A—Drain Plug
B—Check Plug
C—Access Door

D—Fill Location
E—Drain Plug Hole



DM84283,00006FB -19-22MAY15-2/2

H99231 —UN—30NOV10

H99232 —UN—30NOV10


H99233 —UN—30NOV10

Remove and Install Wear Strips

1. Remove nuts and washers (A).
2. Remove socket head screws and washers (B).
3. Remove wear strip (C).
4. Install new wear strip.
5. Retain wear strip using previously removed socket head screws, washers, and nuts. Tighten socket head screws and nuts to specification.

Specification

Socket Head Screws and	
Nuts—Torque.....	10 N·m
	(89 lb-in)



A—Nut and Washer (3 used)
B—Socket Head Screw and Washer (3 used)

C—Wear Strip

H88972—UN—23JUL07

AZ06166,00001B8 -19-24APR17-1/1

Remove and Install StalkMaster™ Chopping Knife Blades


CAUTION: Knives have two cutting edges and can cause serious injury. Wear gloves when handling knives.

IMPORTANT: StalkMaster chopping knife blades must be replaced in pairs on each chopping gear case.

NOTE: StalkMaster chopping knives are wear items. Knives can be flipped for extended knife wear. Flip or replace knives as needed to maintain acceptable stalk chopping capability.

Worn, dull, or damaged knives are factors that affect corn head power consumption and stalk chopping quality, both of which can limit harvest speed. The expected wear life of chopping knives will vary with the operator's harvest conditions and operation habits.

1. Remove lock nuts (A), washers (B), cap screws (C), lower mounting plate (D), bushings (E), and chopping blades (F).
2. Flip or replace blades.
3. Inspect all hardware and bushings for excessive wear or damage and replace as necessary. Lock nuts can be reused when flipping blades. Lock nuts must be replaced when replacing knives.



A—Lock Nut (2 used)
B—Washer (2 used)
C—Round-Head Cap Screw (2 used)

D—Lower Mounting Plate
E—Bushing (2 used)
F—Chopping Blade (2 used)

4. Install components in reverse order of removal. Tighten to specification.

Specification

Chopping Blade Cap	
Screws—Torque.....	130 N·m
	(96 lb.-ft.)

H96454—UN—19MAY10

KR43067,00005B1 -19-19MAY10-1/1

Stubble Light Bulb Replacement

1. Loosen stubble light (A) mounting hardware.
2. Disconnect wiring harness from light assembly.

IMPORTANT: Do NOT touch bulb with bare fingers, oil, or water.


3. Rotate bulb base (B) to release it from housing (C).

NOTE: Bulb does not separate from base. Base and bulb assembly is replaced as one piece.

4. Install new bulb base into the housing.
5. Connect wiring harness, check alignment of light, and tighten mounting hardware.

A—Stubble Light
B—Bulb Base

C—Housing



AZ06166,0000139 -19-24APR17-1/1

H120821 —UN—22FEB17


H94014 —UN—13MAY09

Header Warning Light Bulb Replacement

1. Use flat-blade screwdriver to carefully pry off lens (A).
2. Push bulb (B) in and turn to remove.
3. Install new bulb.
4. Press previously removed lens back onto light housing.

A—Lens

B—Bulb



KR43067,000038D -19-11MAY09-1/1

H93046 —UN—31OCT08

Storage

End of Season Service

1. Lower corn head onto feeder house safety stop, wooden blocks, or the ground.
2. Open end fenders, gatherer points, and deck covers (see Operating Corn Head section for procedures).

IMPORTANT: Do not use high pressure washer spray directly on bearings or any other area that might be damaged by water. High pressure water can get past most seals and cause damage. Dry these areas, then lube and run machine.

3. Clean the corn head thoroughly. Chaff and dirt will draw moisture and cause rust.
4. Check fluid levels on all gear cases and chain drives.
5. Lubricate corn head as outlined in Lubrication and Maintenance section of this manual. Grease the threads on adjusting bolts.
6. Paint all parts where paint is worn or chipped.
7. Use a polymer protectorate on gatherer points, deck covers, and end fenders.

StalkMaster is a trademark of Deere & Company

8. Close all shields.
9. If possible, shelter the corn head in a dry place.
10. Order repair parts needed for next season.

StalkMaster™ Corn Heads Only:

- Clean all debris around chopping hub with wire brush and compressed air.
- Check fluid level on all chopping gear cases.

NOTE: See Check StalkMaster™ Gear Case Oil (if equipped) in Lubrication and Maintenance section of this manual.

- Lubricate chopping gear cases as outlined in Replace Oil in Chopping Gear Case in Lubrication and Maintenance section of this manual.
- Protect inside surface of chopping hub with corrosion protective spray (Protective spray TY22032 or equivalent is recommended).

SS43267,0000319 -19-18NOV13-1/1

Beginning of Season Service

1. Open the end fenders, gatherer points, and deck covers (see Operating the Corn Head section of this manual).

IMPORTANT: Do not spray high-pressure water directly onto bearings or any other area that can be damaged by water. High-pressure water can get past most seals and cause damage. Dry these areas, then lube and run machine.

2. Wash any dirt or debris off machine that accumulated during storage.
3. Adjust row unit, auger drive, and gatherer chains to proper tension (see Adjustments—Corn Head section of this manual).

4. Check fluid levels on all gear cases and chain drives.
5. Lubricate header as outlined in Lubrication and Maintenance section of this manual. Grease the threads of adjusting bolts.
6. Verify that all hardware is tightened to specification and all cotter pins are spread.
7. Close shields, fenders, and points.
8. Run header at half-speed for a few minutes. Check for overheating bearings, gear case leaks, or loose chains.
9. Calibrate header to the machine (see Calibration and Settings section of this manual).
10. Review your Operator's Manual.

AZ06166,00001B9 -19-19JUN17-1/1

Specifications

Specifications

NOTE: Specifications and design subject to change without notice.

Specifications given in the manual are intended for service only and do not include normal factory manufacturing tolerances.

Specifications	
Component	Description
Gatherer Points	Low profile floating-type, hinged above gatherer chains. Perma-Glide™ (polyethylene) material.
Shields and Outer Gatherers	Hinged, removable. Strut-assisted opening (shields). Perma-Glide™ (polyethylene) material.
Gatherer Chains	Heavy-duty, endless steel roller chain (no master connecting link). Integrated steel lugs.
Row Unit Drive	Enclosed gearbox with gears submerged in lubricant; driven by single input hex shaft with radial pin slip clutch.
Trash Knives	Full length, adjustable, one piece, heat-treated steel.
Slip Clutch	One per row unit. One per input driveshaft. One on auger drive.
Stalk Rolls	Straight fluted, Knife, or Inter-meshing Style (One paired set per row unit).
Adjustments and Settings	Description
Gatherer Chain Adjustment	Spring-loaded, self-adjusting.
Deck Plate Adjustment	Hydraulically adjusted.
Gatherer Point Adjustment	Manually adjusted height, pin adjust and fine-tuning.
Minimum Clearance Between Gatherer Chains and Ground	32 mm (1-1/4 in.)

Approximate Overall Width		
Model	Header ID	Width m (ft - in)
706C and 706C-SM	6R70	4.6 m (15 ft - 1 in)
706C and 706C-SM	6R75	4.6 m (15 ft - 1 in)
706C and 706C-SM	6R30	4.8 m (15 ft - 9 in)
706C	6R36/38	5.8 m (19 ft)
708C and 708C-SM	8R70	6.1 m (20 ft - 2 in)
708C and 708C-SM	8R75	6.1 m (20 ft - 2 in)
708C and 708C-SM	8R30	6.4 m (20 ft - 10 in)
708C and 708C-SM	8R36/38	7.8 m (25 ft - 8 in)
712C-SM	12R70	9.2 m (30 ft - 2 in)
712C-SM	12R75	9.2 m (30 ft - 2 in)
712C	12R36	11.2 m (36 ft - 10 in)
712C	12R38	11.8 m (38 ft - 10 in)
712C and 712C-SM	12R20	6.6 m (21 ft - 8 in)
712C and 712C-SM	12R22	7.2 m (23 ft - 6 in)
712C and 712C-SM	12R30	9.4 m (30 ft - 10 in)
716C and 716C-SM	16R30	12.3 m (40 ft - 4 in)
718C and 718C-SM	18R20	9.5 m (31 ft - 2 in)
718C and 718C-SM	18R22	9.5 m (31 ft - 2 in)
Approximate Overall Depth (All Models)		
Points in Operating Position (lowered)		3.0 m (10 ft)
Points in Service Position (raised)		2.4 m (8 ft)

Approximate Field Weight of Corn Head		
Model	Header ID	Weight kg (lb)
Non-Chopping Corn Head:		
706C	6R70	1857 kg (4094 lb)
706C	6R75	1858 kg (4097 lb)
706C	6R30	1858 kg (4097 lb)

Continued on next page

OUC6041.0000B47 -19-22FEB17-1/2

Specifications


Approximate Field Weight of Corn Head		
Model	Header ID	Weight kg (lb)
706C	6R36	1999 kg (4407 lb)
706C	6R38	2006 kg (4423 lb)
708C	8R70	2376 kg (5239 lb)
708C	8R75	2478 kg (5464 lb)
708C	8R30	2375 kg (5237 lb)
708C	8R36	2656 kg (5857 lb)
708C	8R38	2663 kg (5872 lb)
712C	12R20	3014 kg (6645 lb)
712C	12R22	3074 kg (6778 lb)
712C	12R30	3464 kg (7638 lb)
712C	12R36	4374 kg (9642 lb)
712C	12R38	4474 kg (9864 lb)
716C	16R30	4545 kg (10 019 lb)
718C	18R20	4423 kg (9753 lb)
718C	18R22	4520 kg (9967 lb)
Chopping Corn Head - StalkMaster™		
706C-SM	6R70	2090 kg (4608 lb)
706C-SM	6R75	2089 kg (4606 lb)
706C-SM	6R30	2084 kg (4595 lb)
708C-SM	8R70	2719 kg (5996 lb)
708C-SM	8R75	2712 kg (5980 lb)
708C-SM	8R30	2721 kg (6000 lb)
708C-SM	8R36	3412 kg (7522 lb)
708C-SM	8R38	3457 kg (7622 lb)
712C-SM	12R70	3858 kg (8506 lb)
712C-SM	12R75	3890 kg (8577 lb)
712C-SM	12R20	3446 kg (7598 lb)
712C-SM	12R22	3511 kg (7741 lb)
712C-SM	12R30	3921 kg (8645 lb)
716C-SM	16R30	5053 kg (11 142 lb)
718C-SM	18R20	4982 kg (10986 lb)
718C-SM	18R22	5082 kg (11 206 lb)

Perma-Glide is a trademark of Deere & Company
StalkMaster is a trademark of Deere & Company

OUO6041,0000B47 -19-22FEB17-2/2

Keep Machines Secure

1. Install vandal-proof devices.
2. When machine is in storage:
 - Lower equipment to the ground
 - Set wheels to widest position to make loading more difficult
 - Remove any keys and batteries
3. When parking indoors, put large equipment in front of exits and lock your storage buildings.
4. When parking outdoors, store in a well-lighted and fenced area.
5. Make note of suspicious activity and report any thefts immediately to law enforcement agencies.
6. Notify your John Deere dealer of any losses.



TS230—UN—24MAY89


DX,SECURE2 -19-18NOV03-1/1

Header Identification Number

Locate header identification plate (A) on base of the left-hand warning light bracket.

Record your corn head serial number in the space below.
Give this serial number to your dealer when ordering parts.

A—Header Identification Plate



H96466—UN—19MAY10

SS43267,0000119 -19-03JAN17-1/1

Keep Proof of Ownership

1. Maintain in a secure location an up-to-date inventory of all product and component serial numbers.
2. Regularly verify that identification plates have not been removed. Report any evidence of tampering to law enforcement agencies and order duplicate plates.
3. Other steps you can take:
 - Mark your machine with your own numbering system
 - Take color photographs from several angles of each machine



TS1680—UN—09DEC03

DX,SECURE1 -19-18NOV03-1/1

EU Declaration of Conformity

Deere & Company
Moline, Illinois U.S.A.

The undersigned hereby declares that:

Machine Type: Corn Head

Model(s): 700C Series

fulfill(s) all relevant provisions and essential requirements of the following directives:

DIRECTIVE	NUMBER	CERTIFICATION METHOD
Machinery Directive	2006/42/EC	Self certified, per Article 5 of the Directive
Electromagnetic Compatibility Directive	2014/30/EU	Self certified, per Annex II of the Directive

Name and address of the person in the European Community authorized to compile the technical construction file:

Brigitte Birk
John Deere GmbH & Co. KG
Mannheim Regional Center
John Deere Strasse 70
D-68163 Mannheim, Germany

This declaration of conformity is issued under the sole responsibility of the manufacturer.

Place of Declaration: East Moline, Illinois, U.S.A.

Date of Declaration: January 1, 2017

Manufacturing Unit: John Deere Harvester Works, East Moline, Illinois, U.S.A.

Name: Craig Amann

Title: Global Director, Crop Harvesting Platform, Product Engineering, Ag and Turf Division

DXCE01 —UN—28APR09



OUO6075,00045D1 -19-14MAR17-1/1

Eurasian Economic Union

This information applies only to products which bear the EAC conformity mark of the Eurasian Economic Union member states.

Manufacturer:

Deere & Company, Moline, Illinois U.S.A.


Name of the authorized representative in the Eurasian Economic Union:

Limited Liability Company
"John Deere Rus"

Address of the authorized representative:

142050, Russia, Moscow region, Domodedovo district,
Domodedovo, Beliye Stolbi micro district, vladenye
"Warehouse 104", Building 2

For technical support, contact your dealer.



EAC Marking

Date of manufacture is denoted by the product marking on or near the serial number plate.

TS1738 —UN—26APR16

DX,EAC -19-27APR16-1/1

Machine Design Life

This machine is designed and manufactured to provide a long life of productive operation, however actual attainable life depends on a number of factors including the severity of working conditions and completion of recommended maintenance. (See the Service section of this manual.)

Periodically inspect and review the machine in conjunction with your John Deere dealer. The review may result in recommendations for service, component repair,


remanufacture or replacement, or, if at the end of life, that the machine be removed from operation. (See separate decommissioning section of this manual for information on disposal and recycling of machine components.)

No machine should be operated if safety-related components are missing or in need of service. All missing or damaged safety-related components, including safety signs, should be repaired or replaced before operating.

DX,MACH,DESIGN,LIFE -19-14SEP15-1/1

Unified Inch Bolt and Screw Torque Values

TS1671 —UN—01MAY03



Bolt or Screw Size	SAE Grade 1				SAE Grade 2 ^a				SAE Grade 5, 5.1 or 5.2				SAE Grade 8 or 8.2			
	Lubricated ^b		Dry ^c		Lubricated ^b		Dry ^c		Lubricated ^b		Dry ^c		Lubricated ^b		Dry ^c	
	N·m	lb.-in.	N·m	lb.-in.	N·m	lb.-in.	N·m	lb.-in.	N·m	lb.-in.	N·m	lb.-in.	N·m	lb.-in.	N·m	lb.-in.
1/4	3.7	33	4.7	42	6	53	7.5	66	9.5	84	12	106	13.5	120	17	150
													N·m	lb.-ft.	N·m	lb.-ft.
5/16	7.7	68	9.8	86	12	106	15.5	137	19.5	172	25	221	28	20.5	35	26
									N·m	lb.-ft.	N·m	lb.-ft.				
3/8	13.5	120	17.5	155	22	194	27	240	35	26	44	32.5	49	36	63	46
			N·m	lb.-ft.	N·m	lb.-ft.	N·m	lb.-ft.								
7/16	22	194	28	20.5	35	26	44	32.5	56	41	70	52	80	59	100	74
	N·m	lb.-ft.														
1/2	34	25	42	31	53	39	67	49	85	63	110	80	120	88	155	115
9/16	48	35.5	60	45	76	56	95	70	125	92	155	115	175	130	220	165
5/8	67	49	85	63	105	77	135	100	170	125	215	160	240	175	305	225
3/4	120	88	150	110	190	140	240	175	300	220	380	280	425	315	540	400
7/8	190	140	240	175	190	140	240	175	490	360	615	455	690	510	870	640
1	285	210	360	265	285	210	360	265	730	540	920	680	1030	760	1300	960
1-1/8	400	300	510	375	400	300	510	375	910	670	1150	850	1450	1075	1850	1350
1-1/4	570	420	725	535	570	420	725	535	1280	945	1630	1200	2050	1500	2600	1920
1-3/8	750	550	950	700	750	550	950	700	1700	1250	2140	1580	2700	2000	3400	2500
1-1/2	990	730	1250	930	990	730	1250	930	2250	1650	2850	2100	3600	2650	4550	3350

Torque values listed are for general use only, based on the strength of the bolt or screw. DO NOT use these values if a different torque value or tightening procedure is given for a specific application. For plastic insert or crimped steel type lock nuts, for stainless steel fasteners, or for nuts on U-bolts, see the tightening instructions for the specific application. Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical grade.

Replace fasteners with the same or higher grade. If higher grade fasteners are used, tighten these to the strength of the original. Make sure fastener threads are clean and that you properly start thread engagement. When possible, lubricate plain or zinc plated fasteners other than lock nuts, wheel bolts or wheel nuts, unless different instructions are given for the specific application.

^aGrade 2 applies for hex cap screws (not hex bolts) up to 6 in. (152 mm) long. Grade 1 applies for hex cap screws over 6 in. (152 mm) long, and for all other types of bolts and screws of any length.


^b"Lubricated" means coated with a lubricant such as engine oil, fasteners with phosphate and oil coatings, or 7/8 in. and larger fasteners with JDM F13C, F13F or F13J zinc flake coating.

^c"Dry" means plain or zinc plated without any lubrication, or 1/4 to 3/4 in. fasteners with JDM F13B, F13E or F13H zinc flake coating.

DX,TORQ1 -19-12JAN11-1/1

Metric Bolt and Screw Torque Values

TS1670 —UN—01MAY03



Bolt or Screw Size	Class 4.8				Class 8.8 or 9.8				Class 10.9				Class 12.9			
	Lubricated ^a		Dry ^b		Lubricated ^a		Dry ^b		Lubricated ^a		Dry ^b		Lubricated ^a		Dry ^b	
	N·m	lb.-in.	N·m	lb.-in.	N·m	lb.-in.	N·m	lb.-in.	N·m	lb.-in.	N·m	lb.-in.	N·m	lb.-in.	N·m	lb.-in.
M6	4.7	42	6	53	8.9	79	11.3	100	13	115	16.5	146	15.5	137	19.5	172
									N·m	lb.-ft.	N·m	lb.-ft.	N·m	lb.-ft.	N·m	lb.-ft.
M8	11.5	102	14.5	128	22	194	27.5	243	32	23.5	40	29.5	37	27.5	47	35
			N·m	lb.-ft.	N·m	lb.-ft.	N·m	lb.-ft.								
M10	23	204	29	21	43	32	55	40	63	46	80	59	75	55	95	70
	N·m	lb.-ft.														
M12	40	29.5	50	37	75	55	95	70	110	80	140	105	130	95	165	120
M14	63	46	80	59	120	88	150	110	175	130	220	165	205	150	260	190
M16	100	74	125	92	190	140	240	175	275	200	350	255	320	235	400	300
M18	135	100	170	125	265	195	330	245	375	275	475	350	440	325	560	410
M20	190	140	245	180	375	275	475	350	530	390	675	500	625	460	790	580
M22	265	195	330	245	510	375	650	480	725	535	920	680	850	625	1080	800
M24	330	245	425	315	650	480	820	600	920	680	1150	850	1080	800	1350	1000
M27	490	360	625	460	950	700	1200	885	1350	1000	1700	1250	1580	1160	2000	1475
M30	660	490	850	625	1290	950	1630	1200	1850	1350	2300	1700	2140	1580	2700	2000
M33	900	665	1150	850	1750	1300	2200	1625	2500	1850	3150	2325	2900	2150	3700	2730
M36	1150	850	1450	1075	2250	1650	2850	2100	3200	2350	4050	3000	3750	2770	4750	3500

Torque values listed are for general use only, based on the strength of the bolt or screw. DO NOT use these values if a different torque value or tightening procedure is given for a specific application. For stainless steel fasteners or for nuts on U-bolts, see the tightening instructions for the specific application. Tighten plastic insert or crimped steel type lock nuts by turning the nut to the dry torque shown in the chart, unless different instructions are given for the specific application.

Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical property class. Replace fasteners with the same or higher property class. If higher property class fasteners are used, tighten these to the strength of the original. Make sure fastener threads are clean and that you properly start thread engagement. When possible, lubricate plain or zinc plated fasteners other than lock nuts, wheel bolts or wheel nuts, unless different instructions are given for the specific application.

^a“Lubricated” means coated with a lubricant such as engine oil, fasteners with phosphate and oil coatings, or M20 and larger fasteners with JDM F13C, F13F or F13J zinc flake coating.

^b“Dry” means plain or zinc plated without any lubrication, or M6 to M18 fasteners with JDM F13B, F13E or F13H zinc flake coating.

DX,TORQ2 -19-12JAN11-1/1

Index

	Page		Page
A		C	
Active Header Control (AHC)		Cab	
Troubleshooting	60-3	Cornerpost	
Active header control display.....	35-3	Active header control display	35-3
Active header control ground sensors	40-2	Description of automatic header height	
Adjustable deck plate	35-7	control system	35-4
Adjusting		Error codes	30-1
Header drop rate	30-2	Switches	
Adjusting auger drive chain	45-11	Deck plate controls	35-5
Adjusting auger height	45-8	Calibration	
Adjusting deck plates	45-4	Header calibration	30-1
Adjusting drive sprockets	45-7	When to calibrate	30-1
Combines	45-7	Calibration error codes	30-1
Corn huskers	45-7	Chain	
Forage harvesters	45-7	Auger chain service	55-2
Adjusting gatherer chain flights	45-2	Auger drive chain adjustment	45-11
Adjusting gatherer chain tension	45-2	Coupling the chain	45-11
Adjusting gatherer points	45-1	Gatherer chain flight adjustment	45-2
Adjusting lower stripper	45-10	Gatherer chain service	55-2
Adjusting row unit drive chain	45-5	Gatherer chain tension adjustment	45-2
Adjustments		Replacing gatherer chain	65-6
Armrest	35-2	Reversing chain and sprocket	65-5
Armrest		Row unit drive chain adjustment	45-5
Buttons	35-2	Row unit drive chain service	55-2
Error codes	30-1	Chopping gear cases	
Functions	35-2	Check oil level	55-6
Switches	35-2	Remove and install knife blades	65-10
Deck plate controls	35-5	Replace oil	55-9
Attaching		Slip clutch lubrication	55-5
Combine	25-1	StalkMaster	40-3
Corn husker	25-5	Cleanout door	35-10
Forage harvester	25-5	Combine	
Auger	35-7	Armrest	35-2
Adjust height	45-8	Switches	
Auger drive chain adjustment	45-11	Road transport disconnect switch	10-4
Auger drive chain lubrication	55-4	Cab	
Auger drive slip clutch lubrication	55-5	Switches	
Auger floor cleanout door	35-10	Road transport disconnect switch	10-4
Automatic header height control system	35-4	Switches	
AutoTrac RowSense	40-3	Road transport disconnect switch	10-4
B		Controls	
Beginning of Season Service	70-1	Armrest functions	35-2
Bolt and screw torque values		Corn head	
Metric	75-6	Attaching to feeder house	25-1
Unified inch	75-5	Detaching from feeder house	25-5
Bulb replacement		Drive and operate carefully	35-1
Header warning light	65-11	Driveshaft	25-1
Stubble light	65-11	Engage/disengage drive	35-4
Button		General information	35-1
Armrest buttons	35-2	Latching feeder house	25-1
Road transport disconnect	10-4	Speed of travel	35-1
		Transporting on trailer	20-1
		Troubleshooting	60-1
		Corn husker	
		Attaching to corn head	25-5

Continued on next page

	Page		Page
Cornerpost		Cylinder safety stop	65-1
Display		Fixed chain drive	35-5
Active header control	35-3	Fixed chain feeder house	35-5
Description of automatic header height		Adjusting sprockets	
control system	35-4	Combines	45-7
Coupling the chain	45-11	Corn huskers	45-7
		Forage harvesters	45-7
D		Forage harvester	
Deck plates		Attaching to corn head	25-5
Adjusting	35-7, 45-4		
Armrest controls	35-5	G	
Resume	35-5	Gatherer chain	
Detaching header from feeder house	25-5	Remove and install	65-6
Dimensions	75-1	Gatherers	35-6
Disengaging corn head drive	35-4	Adjusting gatherer chain flights	45-2
Display		Adjusting gatherer chain tension	45-2
Cornerpost		Leveling points	45-1
Active header control	35-3	Raising inner gatherer shields	35-8
Description of automatic header height		Raising outer gatherer shields	35-10
control system	35-4	Removing ear savers	40-1
Draining oil	65-8	Removing inner gatherer shields	35-8
Drive sprocket adjustments	45-7	Tilting outer gatherer shields	35-10
Combines	45-7	GPS guidance	
Corn huskers	45-7	AutoTrac RowSense	40-3
Forage harvesters	45-7	Grease	
		Extreme pressure and multipurpose	50-1
E			
Ear savers	40-1	H	
End of Season Service	70-1	Hardware torque values	
Engaging corn head drive	35-4	Metric	75-6
Error codes	30-1	Unified inch	75-5
Every 10 hours of operation		Header	
AutoTrac™ RowSense™ sensors	55-1	Active header control display	35-3
Every 1000 hours of operation		Calibration	30-1
Lubrication		Engage/disengage	35-4
Chopping gear cases oil	55-9	Header drop rate	
Row unit gear cases oil	55-8	Adjusting	30-2
Every 200 hours of operation		Header height	
Inspection		Automatic system description	35-4
Chains	55-2	Header identification number	75-3
Lubrication	55-2	Header identification plate	75-3
Auger drive chains	55-4	Header Safety Features	05-1
Auger drive slip clutch	55-5	Header transportation	20-2
Input driveshaft grease fitting	55-6	Header warning light	
Replace row unit drive chain oil	55-3	Bulb replacement	65-11
Row unit gear case grease level	55-4		
Slip clutches	55-5	I	
StalkMaster™ gear case oil level	55-6	Identification plate	75-3
Every 400 hours of operation		Input driveshaft grease fitting	55-6
AutoTrac™ RowSense™ bushings	55-7	Inspect chains	55-2
		Install oil pan	65-8
F		Install wear strips	65-10
Feeder house		Interval chart, lubrication and maintenance	
Adjusting drop rate and sensitivity	30-2	Every 10 hours	55-1

Continued on next page

	Page		Page
Every 1000 hours.....	55-7	Multi-function handle	
Every 200 hours.....	55-1	Adjustable deck plates.....	35-7
Every 400 hours.....	55-6		
L		O	
Leveling gatherer points.....	45-1	Oil pan	
Lights		Remove and install.....	65-8
Stubble.....	40-4	Operating the corn head	
Lubricant		Drive and operate carefully.....	35-1
Mixing.....	50-1	General information.....	35-1
Lubricant Storage		Harvesting corn with weakened or broken stalks....	35-6
Storage, Lubricant.....	50-1	Harvesting popcorn.....	35-6
Lubricants, Safety		Operating the header	
Safety, Lubricants.....	50-1	Adjusting feeder house drop rate and sensitivity	30-2
Lubrication and maintenance		Outer gatherer extensions.....	35-8
Every 10 hours.....	55-1		
Clean AutoTrac™ RowSense™ Sensors.....	55-1	P	
Every 1000 hours.....	55-7	Product identification number.....	75-3
Replace chopping gear cases oil.....	55-9		
Replace row unit gear cases oil.....	55-8	R	
Every 200 hours.....	55-1	Raising and tilting outer gatherer shields.....	35-10
Check row unit gear case grease level.....	55-4	Remove and install	
Check StalkMaster™ gear case oil level.....	55-6	StalkMaster chopping blades.....	65-10
Inspect and adjust chains.....	55-2	Remove and install gatherer chain.....	65-6
Lubricate auger drive chains.....	55-4	Remove and install inner gatherer points.....	35-8
Lubricate auger drive slip clutch.....	55-5	Remove and install inner gatherer shields.....	35-8
Lubricate input driveshaft grease fitting.....	55-6	Remove and install oil pan.....	65-8
Lubricate slip clutches.....	55-5	Remove and install stalk rolls.....	65-1
Replace row unit drive chain oil.....	55-3	Remove and install wear strips.....	65-10
Every 400 hours.....	55-6	Replace stubble light bulb.....	65-11
Inspect AutoTrac™ RowSense™ bushings.....	55-7	Replace warning light bulb.....	65-11
M		Reversing chain and sprocket for additional wear.....	65-5
Machine design life.....	75-5	Road transport disconnect switch.....	10-4
Maintenance		Row unit.....	35-7
Every 10 hours.....	55-1	Adjusting deck plates.....	45-4
Clean AutoTrac™ RowSense™ Sensors.....	55-1	Adjusting drive sprockets on fixed speed drive.....	45-7
Every 1000 hours.....	55-7	Combines.....	45-7
Replace chopping gear cases oil.....	55-9	Corn huskers.....	45-7
Replace row unit gear case oil.....	55-8	Forage harvesters.....	45-7
Every 200 hours.....	55-1	Adjusting gatherer chain flights.....	45-2
Check row unit gear case grease level.....	55-4	Adjusting gatherer chain tension.....	45-2
Check StalkMaster™ gear case oil level.....	55-6	Adjusting gatherer point height.....	45-1
Inspect and adjust chains.....	55-2	Adjusting row unit drive chain.....	45-5
Lubrication		Coupling the chain.....	45-11
Auger drive chains.....	55-4	Deck plate controls.....	35-5
Auger drive slip clutch.....	55-5	Deck plate resume.....	35-5
Input driveshaft grease fitting.....	55-6	Drive chain oil.....	55-3
Row unit slip clutches.....	55-5	Replace gear case oil.....	55-8
Replace row unit drive chain oil.....	55-3	Replacing gatherer chain.....	65-6
Every 400 hours.....	55-6	Reversing chain and sprockets.....	65-5
Inspect AutoTrac™ RowSense™		Stalk rolls.....	40-2
sensor bushings.....	55-7	Row unit gear case grease level.....	55-4
Metric bolt and screw torque values.....	75-6	Row unit gear cases	
Mixing lubricants.....	50-1	Replace oil.....	55-8
		RowSense guidance.....	40-3

Continued on next page

	Page		Page
S		Adjusting for corn huskers	45-7
Safety		Adjusting for forage harvesters	45-7
Drive and operate carefully	35-1	Stalk rolls	40-2
Features	05-1	Intermeshing knife	40-2
Feeder house safety stop	65-1	Opposed knife	40-2
Pictorial safety signs	15-1	Remove and install	65-1
Road transport disconnect switch	10-4	Straight fluted	40-2
Safe maintenance, practice	10-5	StalkMaster	
Safety, Avoid High-Pressure Fluids		Check gear case oil level	55-6
Avoid High-Pressure Fluids	10-7	Flipping chopping blades	65-10
Sensors		Remove and install chopping blades	65-10
Active header control	40-2	StalkMaster™	
Serial number plate	75-3	Slip clutch lubrication	55-5
Service		StalkMaster chopping option	40-3
Auger floor cleanout door	35-10	Storage	70-1
Bulb replacement		Stripper	
Warning light	65-11	Adjusting lower stripper	45-10
Every 10 hours		Stubble lights	40-4
AutoTrac™ RowSense™ Sensors	55-1	Bulb replacement	65-11
Every 1000 hours		Switches	
Replace chopping gear cases oil	55-9	Armrest	35-2
Replace row unit gear cases oil	55-8	Road transport disconnect switch	10-4
Every 200 hours		T	
Check row unit gear case grease level	55-4	Torque charts	
Check StalkMaster™ gear case oil level	55-6	Metric	75-6
Inspect and adjust chains	55-2	Unified inch	75-5
Lubrication		Transporting	20-2
Auger drive chains	55-4	Road transport disconnect switch	10-4
Auger drive slip clutch	55-5	Trailer	20-1
Input driveshaft grease fitting	55-6	Trash knives	
Slip clutches	55-5	Adjust	45-1
Replace row unit drive chain oil	55-3	Troubleshooting	
Every 400 hours		Active Header Control (AHC)	60-3
AutoTrac™ RowSense™ bushings	55-7	Corn head	60-1
Interval chart		U	
Every 10 hours	55-1	Unified inch bolt and screw torque values	75-5
Every 1000 hours	55-7	W	
Every 200 hours	55-1	Warning light	
Every 400 hours	55-6	Bulb replacement	65-11
Raising and tilting outer gatherer shields	35-10	Wear strips	
Remove and install inner gatherer points	35-8	Remove and install	65-10
Remove and install inner gatherer shields	35-8	Weights	75-1
Remove and install oil pan	65-8		
Remove and install stalk rolls	65-1		
Remove and install wear strips	65-10		
Replace stubble light bulb	65-11		
Reversing chain and sprockets	65-5		
Safety stops	65-1		
Settings			
Armrest functions	35-2		
Signal words, understand	10-1		
Slip clutches			
Lubrication	55-5		
Auger drive	55-5		
Specifications	75-1		
Speed of travel	35-1		
Sprockets			
Adjusting for combines	45-7		

John Deere Service Literature Available

Technical Information

Technical information can be purchased from John Deere. Publications are available in print or CD-ROM format.

Orders can be made using one of the following:

- John Deere Technical Information Store:
www.JohnDeere.com/TechInfoStore
- Call 1-800-522-7448
- Contact your John Deere dealer

Available information includes:

PARTS CATALOGS list service parts available for your machine with exploded view illustrations to help you identify the correct parts. It is also useful in assembling and disassembling.



TS189 —UN—17JAN89

DX,SERVLIT -19-07DEC16-1/4

OPERATOR'S MANUALS providing safety, operating, maintenance, and service information.



TS191 —UN—02DEC88

DX,SERVLIT -19-07DEC16-2/4

TECHNICAL MANUALS outlining service information for your machine. Included are specifications, illustrated assembly and disassembly procedures, hydraulic oil flow diagrams, and wiring diagrams. Some products have separate manuals for repair and diagnostic information. Some components, such as engines, are available in a separate component technical manual.



TS224 —UN—17JAN89

Continued on next page

DX,SERVLIT -19-07DEC16-3/4

EDUCATIONAL CURRICULUM including five comprehensive series of books detailing basic information regardless of manufacturer:

- Agricultural Primer series covers technology in farming and ranching.
- Farm Business Management series examines “real-world” problems and offers practical solutions in the areas of marketing, financing, equipment selection, and compliance.
- Fundamentals of Services manuals show you how to repair and maintain off-road equipment.
- Fundamentals of Machine Operation manuals explain machine capacities and adjustments, how to improve machine performance, and how to eliminate unnecessary field operations.
- Fundamentals of Compact Equipment manuals provide instruction in servicing and maintaining equipment up to 40 PTO horsepower.



TS1663—JUN—10OCT97

DX,SERVLIT -19-07DEC16-4/4

John Deere Service Keeps You On The Job

John Deere Parts

We help minimize downtime by putting genuine John Deere parts in your hands in a hurry.

That's why we maintain a large and varied inventory—to stay a jump ahead of your needs.



DX,IBC,A -19-04JUN90-1/1

TS100 —UN—23AUG88

The Right Tools

Precision tools and testing equipment enable our Service Department to locate and correct troubles quickly . . . to save you time and money.



DX,IBC,B -19-04JUN90-1/1

TS101 —UN—23AUG88

Well-Trained Technicians

School is never out for John Deere service technicians.

Training schools are held regularly to be sure our personnel know your equipment and how to maintain it.

Result?

Experience you can count on!



DX,IBC,C -19-04JUN90-1/1

TS102 —UN—23AUG88

Prompt Service

Our goal is to provide prompt, efficient care when you want it and where you want it.

We can make repairs at your place or at ours, depending on the circumstances: see us, depend on us.

JOHN DEERE SERVICE SUPERIORITY: We'll be around when you need us.



DX,IBC,D -19-04JUN90-1/1

TS103 —UN—23AUG88

