



OWNER'S MANUAL

4-STROKE AIR-COOLED V-TWIN GASOLINE ENGINE

FH541V
FH580V

P/N 99920-2168-08

SAFETY AWARENESS

Whenever you see the symbols shown below, heed their instructions! Always follow safe operating and maintenance practices.



DANGER

DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.



WARNING

WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.

NOTICE

NOTICE is used to address practices not related to personal injury.

NOTE

○ *NOTE* indicates information that may help or guide you in the operation or service of the vehicle.

READ THIS FIRST

For your safety, read this Owner's Manual and understand it thoroughly before operating this ENGINE.

DANGER

Exhaust gas contains carbon monoxide, a colorless, odorless poisonous gas. Inhaling carbon monoxide can cause serious brain injury or death. **DO NOT** run the engine in enclosed areas. Operate only in a well-ventilated area. Gasoline is extremely flammable and can be explosive under certain conditions, creating the potential for serious burns. When refueling, servicing fuel system, draining gasoline and/or adjusting the carburetor: Stop engine and allow it to cool before refueling. **DO NOT** smoke. Make sure the area is well-ventilated and free from any source of flame or sparks, including the pilot light of any appliance. **DO NOT** fill the tank so the fuel level rises into the filler neck or level surface of level gauge. If the tank is overfilled, heat may cause the fuel to expand and overflow through the vents in the tank cap. Wipe off any spilled gasoline immediately. Engines can become extremely hot during normal operation. To prevent fire hazard: Keep the engine at least 1 m (3.3 ft) away from buildings, obstructions and other flammable objects. **DO NOT** place flammable objects close to the engine. **DO NOT** expose combustible materials to the engine exhaust. **DO NOT** use the engine on any forest covered, brush covered or grass covered unimproved land unless spark arrester is installed on the muffler. To avoid getting an electric shock, **DO NOT** touch spark plugs, plug caps or spark plug leads during engine running. To avoid a serious burn, **DO NOT** touch a hot engine or muffler. The engine becomes hot during operation. Before you service or remove parts, stop engine and allow the engine to cool. **DO NOT** place hands or feet near moving or rotating parts. Place a protective cover over pulley, V belt or coupling. **DO NOT** run engine at excessive speeds. This may result in injury. Always remove the spark plug caps from spark plugs when servicing the engine to prevent accidental starting.

Read warning labels which are on the engine and understand them. If any label is missing, damaged, or worn get a replacement from an authorized Kawasaki engine dealer and install it in the correct position.

EMISSION CONTROL INFORMATION

Fuel Information

THIS ENGINE IS CERTIFIED TO OPERATE ON UNLEADED REGULAR GRADE GASOLINE ONLY. A minimum of 87 octane of the antiknock index is recommended. The antiknock index is posted on service station pumps in the U.S.A.

Emission Control Information

To protect the environment in which we all live, Kawasaki has incorporated an exhaust emission control system in compliance with applicable regulations of the United States Environmental Protection Agency. Also, depending on when your engine was produced, it may have an assigned emissions durability period.

*See below for the engine emissions durability period that may apply to your engine.

Exhaust Emission Control System

The exhaust emission control system applied to this engine consists of a carburetor and an ignition system having optimum ignition timing characteristics. The carburetor has been calibrated to provide specific air/fuel mixture characteristics and optimum fuel economy with a suitable air cleaner and exhaust system.

A sealed-type crankcase emission control system is also used to eliminate blow-by gasses. The blow-by gasses are led to a breather chamber through the crankcase and from there to the air cleaner.

Engine Emissions Compliance Period

Engines Greater Than or Equal To 225 cc

Durability Period – 1 000 hours (Category A)

*** If your engine has an assigned emissions durability period it will be located on the certification label attached to the engine (IMPORTANT ENGINE INFORMATION).**

High Altitude Performance Adjustment Information

To improve the EMISSIONS CONTROL PERFORMANCE of engines operated above 1 000 meters (3 300 feet) , Kawasaki requires the following Environmental Protection Agency (EPA) approved modifications. High altitude adjustment requires replacement of carburetor main jets. Installation of these optional parts may be performed by an authorized Kawasaki engine dealer or equally qualified service facility, following repair recommendations specified in the appropriate Kawasaki Service document or parts catalog.

Operating the engine with the wrong engine configuration at a given altitude may increase its emissions and decrease fuel efficiency and performance.

NOTE

○ *When properly performed, these specified modifications only are not considered to be emissions system "tampering" and engine performance is generally unchanged as a result.*

Maintenance and Warranty

Proper maintenance is necessary to ensure that your engine will continue to have low emission levels. This Owners Manual contains those maintenance recommendations for your engine. Those items identified by the Periodic Maintenance Chart are necessary to ensure compliance with the applicable standards.

As the owner of the engine, you have the responsibility to make sure that the recommended maintenance is carried out according to the instructions in this Owners Manual at your own expense.

The Kawasaki Limited Emission Control System Warranty requires that you return your engine to an authorized Kawasaki engine dealer for remedy under warranty. Please read the warranty carefully, and keep it valid by complying with the owner's obligations it contains.

Tampering with Emission Control System Prohibited

Federal law prohibits the following acts or the causing thereof: (1) the removal or rendering inoperative by any person other than for purposes of maintenance, repair, or replacement, of any device or element of design incorporated into any new engine for the purposes of emission control prior to its sale or delivery to the ultimate purchaser or while it is in use, or (2) the use of the engine after such device or element of design has been removed or rendered inoperative by any person.

Among those acts presumed to constitute tampering, do not tamper with the original emission related parts below:

- Carburetor and their internal parts
- Spark Plug
- Magneto ignition system
- Fuel filter element
- Air cleaner element
- Crankcase
- Cylinder heads
- Breather chamber and internal parts
- Intake pipe and tube

FOREWORD

We wish to thank you for purchasing this Kawasaki engine.

Please read this Owner's Manual carefully before starting your new engine so that you will be thoroughly familiar with the proper operation of your engine's control, its features, capabilities and limitations.

Also read the manual of the equipment to which this engine is attached.

To ensure a long, trouble-free life for your engine, give it the proper care and maintenance described in this manual. Always keep this manual at your fingertip so that you can refer to it whenever you need information. This manual should be considered a permanent part of the engine and should remain with the engine when it is sold.

All rights reserved. No part of this publication may be reproduced without our prior written permission.

This publication includes the latest information available at the time of printing. However, there may be minor differences between the actual product and illustrations and text in this manual.

All products are subject to change without prior notice or obligation.

KAWASAKI MOTORS, LTD.

© 2003 Kawasaki Motors, Ltd.

Mar. 2017 (2) (M)


Please note that the photographs and illustrations shown in this manual are made based on Model FH580V as a typical example among other similar models.

TABLE OF CONTENTS


GENERAL INFORMATION	8	Choke Adjustment Associated Choke Type	22
Location of Safety Related Labels	8	Separate Choke Type	24
Location of Parts	9	Throttle Cable Installation, Adjustment	24
Engine Serial Number	11	Choke Cable Installation, Adjustment	24
Tune-up Specifications	12	Engine Speed Adjustment	26
Engine Oil Capacity	12	MAINTENANCE	27
FUEL AND OIL RECOMMENDATIONS	13	Periodic Maintenance Chart	27
Fuel	13	Oil Level Check	29
Engine Oil	14	Oil Change	30
PREPARATION	15	Oil Filter Change	31
Fuel	15	Air Cleaner Service	32
Engine Oil	16	Heavy Duty Air Cleaner (Option)	32
STARTING	17	Air Cleaner Element	33
Starting the Engine	17	Cap (Dust Ejector Valve)	33
Warming Up	19	Fuel Filter and Fuel Pump Service	35
OPERATING	20	Spark Plug Service	36
Engine Inclination	20	Cooling System Cleaning	37
STOPPING	21	STORAGE	38
Stopping the Engine	21	Engine Storage Procedure	38
Ordinary Stop	21	TROUBLESHOOTING GUIDE	39
Emergency Stop	21	ENVIRONMENTAL PROTECTION	41
ADJUSTMENT	22	SPECIFICATIONS	42
Associated choke type	22	WIRING DIAGRAM	43
Throttle Cable Installation, Adjustment	22		

GENERAL INFORMATION

Location of Safety Related Labels




A. Warning Label
B. Engine Maintenance Label




EB02001BM4 C

Location of Parts




- A. Oil Gauge/Filler
- B. Oil Filter
- C. Oil Drain Plugs
- D. Air Cleaner/Carburetor
- E. Control Panel
- F. Spark Plug Caps/Spark Plugs
- G. Air Inlet Screen Guard
- H. Fan Housing
- K. Fuel Pump
- L. Fuel Tube
- M. Fuel Filter




- I. Electric Starter
- J. Voltage Regulator

10 GENERAL INFORMATION

[Heavy Duty Air Cleaner Model]



- A. Oil Gauge/Filler
- B. Oil Filter
- C. Oil Drain Plugs
- D. Air Cleaner (Heavy Duty Type)
- E. Carburetor
- F. Control Panel
- G. Spark Plug Caps/Spark Plugs
- H. Air Inlet Screen Guard
- I. Fan Housing




- J. Voltage Regulator
- K. Electric Starter

Engine Serial Number

The engine serial number (A) is the only means of identifying your particular engine from others of the same model type.

This engine serial number is needed by an authorized Kawasaki engine dealer or equally qualified service facility when ordering parts.



A. Engine Serial Number Label

12 GENERAL INFORMATION

Tune-up Specifications

ITEM	Specifications
Ignition Timing	Unadjustable
Spark Plugs: Gap	CHAMPION...RCJ8Y 0.75 mm (0.030 in.)
Low Idle Speed	1 550 r/min (rpm)
High Idle Speed	3 600 r/min (rpm)
Valve Clearance	IN 0.10 ~ 0.15 mm (0.004 ~ 0.006 in.) EX 0.10 ~ 0.15 mm (0.004 ~ 0.006 in.)
Other Specifications	No other adjustment needed

NOTE

○ *High and low idle speeds may vary depending on the equipment on which the engine is used. Refer to the equipment specification.*

Engine Oil Capacity

FH541V	1.5 L (1.6 US·qt) [when oil filter is not removed]
FH580V	1.7 L (1.8 US·qt) [when oil filter is removed]

FUEL AND OIL RECOMMENDATIONS

Fuel

Use only clean, fresh, unleaded regular grade gasoline.

NOTICE

Do not mix oil with gasoline.

Octane Rating

The octane rating of a gasoline is a measure of its resistance to “knocking”. Using a minimum of 87 octane by the antiknock index is recommended. The antiknock index is posted on service station pumps in the U.S.A..

NOTE

○ If “knocking or pinging” occurs, use a different brand of gasoline or higher octane rating.

Oxygenated Fuel

Oxygenates (either ethanol or MTBE) are added to the gasoline. If you use the oxygenated fuel be sure it is unleaded and meets the minimum octane rating requirement.

The following are the EPA approved percentages of fuel oxygenates.

ETHANOL: (Ethyl or Grain Alcohol)

You may use gasoline containing up to 10% ethanol by volume.

MTBE: (Methyl Tertiary Butyl Ether)

You may use gasoline containing up to 15% MTBE by volume.

METHANOL: (Methyl or Wood Alcohol) 5% by volume

You may use gasoline containing up to 5% methanol by volume, as long as it also contains cosolvents and corrosion inhibitors to protect the fuel system. Gasoline containing more than 5% methanol by volume may cause starting and/or performance problems. It may also damage metal, rubber, and plastic parts of your fuel system.

14 FUEL AND OIL RECOMMENDATIONS


Engine Oil

The following engine oils are recommended.

API Service Classification : SJ or SL class

Oil Viscosity

Choose the viscosity according to the temperature as follows:



NOTE

- Although 10W-40 engine oil is the recommended oil for most conditions, the oil viscosity may need to be changed to accommodate atmospheric conditions. Using 20W-50 oil in higher ambient temperatures may reduce oil consumption.

PREPARATION

Fuel



WARNING

Gasoline is extremely flammable and can be explosive under certain conditions, creating the potential for serious burns. Turn the ignition switch off. Do not smoke. Make sure the area is well ventilated and free from any source of flame or sparks; this includes any appliance with a pilot light. Never fill the tank completely to the top. If the tank is filled completely to the top, heat may cause the fuel to expand and overflow through the vents in the tank cap. After refueling, make sure the tank cap is closed securely. If gasoline is spilled on the fuel tank, wipe it off immediately.

- Level the engine before fueling.
- Remove the fuel tank cap.
- Slowly pour fuel into the tank through the fuel strainer.
- Close the tank cap securely.

16 PREPARATION


Engine Oil

Check the engine oil daily before starting the engine otherwise shortage of the engine oil may cause serious damage to the engine such as seizure.

- Place the engine on level surface. Clean area around the oil gauge before removing it.
- Remove the oil gauge (A) and wipe it with a clean cloth.
- Pour the oil slowly to “FULL” mark on the oil gauge.
- Insert the oil gauge into tube (B) WITHOUT SCREWING IT IN.
- Remove the oil gauge (A) to check the oil level. Level should be between “ADD” and “FULL” marks. Do not overfill.
- Install and tighten the oil gauge (A).

Engine Oil Capacity

FH541V	1.5 L (1.6 US·qt) [when oil filter is not removed]
FH580V	1.7 L (1.8 US·qt) [when oil filter is removed]



A. Oil Gauge

B. Tube

NOTICE

The engine is shipped without engine oil.

STARTING

Starting the Engine

DANGER

Exhaust gas contains carbon monoxide, a colorless, odorless poisonous gas. Inhaling carbon monoxide can cause serious brain injury or death. **DO NOT** run the engine in enclosed areas. Operate only in a well-ventilated area.

WARNING

Engine exhaust may ignite combustible materials and cause a fire. Keep the area around the exhaust outlet clear. Locate the unit so that the exhaust outlet points toward an open area and is located at least one meter (3.3 feet) from any obstructions.

NOTE

- *Be aware of following in order to start the engine easily in cold weather.*
- *Use proper oil for expected temperature (See FUEL AND OIL RECOMMENDATIONS chapter).*

- *Use fresh gasoline.*
- *Protect the engine or the equipment from direct exposure to weather when not in operation.*
- *Before starting the engine, disconnect all possible external loads.*
- *Open the fuel valve (A) on the equipment.*
- *Turn the ignition switch to its "ON" or "START" position. For Control Panel Switch Type, move the throttle lever on the equipment to its halfway position. Moving the lever away from its low speed end turns ignition on.*
- *Move the throttle lever to its halfway position between low speed and high speed.*

[Associated choke type]


For A Cold Engine - Place the throttle lever into "CHOKE" position.

For A Warm Engine (normal operating temperatures) - Place the throttle lever **halfway** between "SLOW" and "FAST" positions.


[Separate choke type]

For A Cold Engine - Place the choke control lever into "CHOKE" position.

18 STARTING



- Put the key (A) into the ignition switch.
- Turn the key to the START position on the equipment. Normally the engine will start within 3 seconds.



NOTICE

Do not run the electric starter continuously for more than 5 seconds, otherwise the battery may discharge quickly. If the engine does not start right away, wait 15 seconds and try again.

NOTICE

Whenever you start engine, make sure warning light is not illuminated after engine starts. If warning light comes on, stop engine immediately and check oil level (if equipped).

Warming Up

After the engine starts, move the throttle lever on the equipment to halfway between “FAST” and “SLOW”.

To warm up the engine, run it for 3 to 5 minutes with the throttle lever in the same load position (halfway) before putting the equipment under load. Then, move the throttle lever on the equipment to its “FAST” position.

NOTICE

Allow engine to warm up sufficiently (3 to 5 minutes at idle) before applying a load. This will allow oil to reach all engine parts, and allow piston clearance to reach design specifications.

NOTICE

While warming up the engine, make sure the warning lamp (oil pressure) on dash is not on. The warning lamp must not be illuminated during engine operation (if equipped).

OPERATING

Engine Inclination

This engine will operate continuously at angles up to 25° in any direction.

Refer to the operating instructions of the equipment this engine powers. Because of equipment design or application, there may be more stringent restrictions regarding the angle of operation.

<i>NOTICE</i>
Do not operate this engine continuously at angles exceeding 25° in any direction. Engine damage could result from insufficient lubrication.

STOPPING

Stopping the Engine

Ordinary Stop

- Move throttle lever to “SLOW” position.
- Keep running at the “SLOW” speed for about one minute.

<i>NOTICE</i>
Engine damage can occur from run-on or after-burning if engine is stopped suddenly from high speed loaded operation. Reduce engine speed to idle for one minute before shutting engine off.

- Turn the ignition switch to “OFF” position.

For Control Panel Switch Type, move the throttle lever against its low speed end to turn the ignition off.

Emergency Stop

- Immediately turn the ignition switch to “OFF” position.
- Close the fuel valve on the equipment.

For Control Panel Switch Type, move the throttle lever on the equipment to its low speed end. Moving the lever to its low speed end turns ignition off.



ADJUSTMENT

Two types of choke control are used for FH580V Model Engine.

Associated choke type

Throttle Cable Installation, Adjustment

Make sure that the throttle lever on the equipment has been linked to the engine with the throttle cable.

- Leave the cable clamp bolt (A) loose.
- Align the hole (B) in the speed control lever (C) with the hole (D) in the base plate (E) moving the lever (C); insert 6 mm dia. pin (or 6 mm bolt) through two holes.
- Pull up the outer housing (F) of the throttle cable until the inner wire (G) has almost no slack, and tighten the cable clamp bolt (A). Remove the 6 mm dia. pin.


Make sure that the carburetor choke valve (M) is closed completely when the throttle lever on the equipment is moved to “CHOKE” position. If not, perform “CHOKE ADJUSTMENT”.

Choke Adjustment Associated Choke Type

- Stop the engine.
- Align the hole (B) in the speed control lever (C) with the hole (D) in the base plate (E) by moving

the lever (C); insert 6 mm dia. pin (or 6 mm bolt) through two holes.


- Turn the choke setting screw (I) so that the clearance between the screw end and the tongue of the lever (J) is zero. Remove the 6 mm dia. pin or bolt.
- Make sure that the choke valve can move to full open side and full close side by turning the lever.



H. Throttle Valve

M. Choke Valve

Associated choke type



E103002BW6 C

24 ADJUSTMENT

Separate Choke Type


Throttle Cable Installation, Adjustment


- Link the throttle cable (G) to the speed control lever (C) and loosely clamp the throttle cable outer housing (F) with the cable clamp bolt (A).
- Move the throttle lever to “FAST” position.
- Pull up the outer housing (F) of the throttle cable until the inner wire (G) has almost no slack, and tighten the cable clamp bolt (A).
- Move the throttle lever to “slow” position. Make sure that the carburetor throttle valve (H) is moved smoothly.

Choke Cable Installation, Adjustment

- Link the choke cable (K) to the choke control lever (D), and loosely clamp the choke cable outer housing (L) with the cable clamp bolt (B).
- Move the equipment choke control to “OPEN” position. Make sure that the carburetor choke valve (M) is fully opened.
- Pull up the outer housing (L) of the choke cable until the inner wire (K) has almost no slack, and tighten the cable clamp bolt (B).

- Move the equipment choke control to “CHOKE” position. Make sure that the carburetor choke valve (M) is completely closed.
- Make sure that the choke valve turns from fully closed position to fully opened position when actuating the equipment choke control.





Engine Speed Adjustment

NOTE

- *Do not tamper with the governor setting or the carburetor setting to increase the engine speed. Every carburetor is adjusted at the factory and a cap or a stop plate is installed on each mixture screw.*
- *If any adjustment is necessary, see an authorized Kawasaki engine dealer or equally qualified service facility to perform the adjustment.*

MAINTENANCE

Maintenance, replacement, or repair of the emission control devices and systems may be performed by any nonroad engine repair establishment or individual.

Periodic Maintenance Chart



WARNING

Prevent accidental starting during engine service by removing the spark plug caps.

NOTE

○ *The service intervals can be used as a guide. Service more frequently as necessary by operating conditions.*

◆ : Service more frequently under dusty conditions.

◇ : Service to be performed by an authorized Kawasaki engine dealer or equally qualified service facility.

MAINTENANCE	INTERVAL						
	Daily	Every 25 hr.	Every 50 hr.	Every 100 hr.	Every 200 hr.	Every 250 hr.	Every 300 hr.
Check and add engine oil.	●						
Check for loose or lost nuts and screws.	●						
Check for fuel and oil leakage.	●						
Check battery electrolyte level.	●						
◆ Check or clean air inlet screen.	●						
◇ Clean air cleaner foam element		●					


28 MAINTENANCE

MAINTENANCE	INTERVAL						
	Daily	Every 25 hr.	Every 50 hr.	Every 100 hr.	Every 200 hr.	Every 250 hr.	Every 300 hr.
♦ Clean air cleaner paper element			•				
♦ Clean dust and dirt from cylinder and ◇ cylinder head fins.				•			
Tighten nuts and screws.				•			
Change engine oil.	Every 100 hours or 1 year whichever comes first						
Clean and regap spark plugs.				•			
Change oil filter.					•		
♦ Replace air cleaner paper element					•		
♦ Replace air cleaner element (Heavy Duty Air Cleaner).						•	
◇ Clean combustion chamber.							•
◇ Check and adjust valve clearance.							•
◇ Clean and lap valve seating surface.							•

Oil Level Check

Check oil level daily and before each time of operation. Be sure oil level is maintained. (See PREPARATION chapter.)

FH541V	1.5 L (1.6 US·qt) [when oil filter is not removed]
FH580V	1.7 L (1.8 US·qt) [when oil filter is removed]



30 MAINTENANCE


Oil Change

Change oil every 100 hours or 1 year whichever comes first.

- Run the engine to warm oil.
- Be sure the engine (equipment) is level.
- Stop the engine.
- Remove the oil drain screw and drain the oil to suitable container while engine is warm.

WARNING

Hot engine oil can cause severe burns. Allow engine temperature to drop from hot to warm before draining and handling oil.



A. Oil Drain Screw

- Install the oil drain plug.
- Remove oil gauge and refill with new oil (See FUEL AND OIL RECOMMENDATIONS chapter).
- Check the oil level (see PREPARATION chapter for oil level check).

WARNING

Engine oil is a toxic substance. Dispose of used oil properly. Contact your local authorities for approved disposal methods or possible recycling.

Oil Filter Change

- Change the oil filter every 200 hours of operation.

WARNING


Hot engine oil can cause severe burns. Allow engine temperature to drop from hot to warm level before attempting to remove oil filter.

- Drain engine oil to suitable container.

NOTICE

Before removing the oil filter, place suitable pan under filter connection.

- Rotate the oil filter (A) counterclockwise to remove it.
- Coat a film of clean engine oil on seal of new filter.
- Install new filter rotating it clockwise until seal contacts mounting surface (B). Then rotate filter 3/4 turn more by hand.
- Supply engine oil as specified.
- Run the engine for about 3 minutes, stop engine, and check oil leakage around the filter.
- Add oil to compensate for oil level due to oil filter capacity (see PREPARATION chapter for oil level check).



WARNING

Engine oil is a toxic substance. Dispose of used oil properly. Contact your local authorities for approved disposal methods or possible recycling.

32 MAINTENANCE

Air Cleaner Service

NOTICE


Do not run the engine with the air cleaner removed.

- Remove the air cleaner case (A) from the air cleaner body (C) by pulling the latches (B).

Foam Element

Clean the foam element (D) every 25 hours.

- Wash the element in detergent and water, and dry it thoroughly.



Paper Element

Clean the paper element (E) every 50 hours.

- Clean the element by tapping gently to remove dust. If very dirty, replace the element with a new one.
- Replace with a new paper - element yearly or 200 hours whichever comes first.

NOTE

- *Operating in a dusty condition may require more frequent maintenance than above.*

NOTICE

**Do not wash paper element.
Do not oil paper or foam element.
Do not use pressurized air to clean paper element.**

Heavy Duty Air Cleaner (Option)

This air cleaner element is not recommended to be cleaned. Replace the air cleaner element with a new one at the maintenance time as shown in the maintenance chart.

NOTICE

To prevent excessive engine wear, do not run the engine with the air cleaner removed.

NOTICE

**Do not wash air cleaner element.
Do not oil air cleaner element.
Do not use pressurized air to clean air
cleaner element.**

NOTE

○ *Operating in dusty condition may require more frequent maintenance.*

Air Cleaner Element


Replace the air cleaner element every 250 hrs.

Cap (Dust Ejector Valve)

Push and open the cap on the case of the air cleaner body to expel dust and/or water accumulated inside.


- Unfasten the two retaining clamps (A) and remove the case (B) from the air cleaner body (C).

- Remove the air cleaner element (D) from the air cleaner body by pulling out them.



- A. Retaining Clamps**
- B. Case**
- C. Air Cleaner Body**
- F. Cap (Dust Ejector Valve)**

34 MAINTENANCE



D. Air Cleaner Element

- Install the new air cleaner element into the air cleaner body.
- Reinstall the case and the cap (F) then securely fasten the two retaining clamps.

Fuel Filter and Fuel Pump Service

**WARNING**

Many solvents are highly flammable and may cause serious burns. Improper use of solvents can result in fire or an explosion. Do not use gasoline or low flash-point solvents to clean the fuel filter and/or the fuel pump. Clean only in a well-ventilated area away from sources of sparks or flame, including any appliances with a pilot light.

- The fuel filter can not be disassembled. If the fuel filter gets clogged, replace it with a new one.
- The fuel pump can not be disassembled. If the fuel pump fails, replace it with a new one.

Spark Plug Service



WARNING

Engines can become extremely hot during normal operation. Hot engine components can cause severe burns. Stop the engine and allow it to cool before checking spark plugs.


Clean or replace the spark plugs and reset gap (A) every 100 hours of operation.

- Disconnect the spark plug caps from spark plugs and remove the spark plugs.
- Clean the electrodes (B) by scraping or with a wire brush to remove carbon deposits.
- Inspect for cracked porcelain or other wear and damage. Replace the spark plug with a new one if necessary.
- Check the spark plug gap and reset it if necessary. The gap must be 0.75 mm (0.030 in.). To change the gap, bend only the side-electrode, using a spark plug tool.
- Install and tighten the spark plugs to 22 N·m (2.2 kgf·m, 16 ft·lb).
- Fit the spark plug caps on the spark plugs securely.

- Pull up the spark plug caps lightly to make sure of the installation of the spark plug caps.

RECOMMENDED SPARK PLUG

CHAMPION RCJ8Y



A. Spark Plug Gap

B. Electrodes

Cooling System Cleaning


Before each use, check that the guard (A) and the air inlet (rotary) screen (B) are free from grass or debris and clean if necessary. Every 100 hours of operation, check and clean the cooling fins and inside of engine shrouds to remove grass, chaff or dirt clogging the cooling system and causing overheating. When cleaning, remove the guard (A), the air inlet screen (B), and the fan housing (F) loosening the nuts (C), the bolts (D), the spacer (E) and the bolts (G),(H).

NOTICE

Do not run engine before all cooling system parts are reinstalled to keep cooling and carburetion as intended.

[Bolts and Nut Size, Tightening torque]

Bolts and Nut	Size	Length	Tightening-torque
C	M6		5.9 N·m (0.6 kgf·m, 4.3 ft·lb)
D	M6	12 mm	5.9 N·m (0.6 kgf·m, 4.3 ft·lb)
G	M6	16 mm	5.9 N·m (0.6 kgf·m, 4.3 ft·lb)
H	M6	22 mm	5.9 N·m (0.6 kgf·m, 4.3 ft·lb)



EJ12001BM4 G

STORAGE

Engine Storage Procedure

When not operating your Kawasaki engine more than 30 days, add fuel stabilizer to fuel tank and run engine for 5 minutes then drain the fuel tank.

After draining the fuel tank, run the engine at low idle until the engine stalls.



WARNING


Gasoline is extremely flammable and can be explosive under certain conditions. Drain fuel before storing the equipment for extended periods. Drain gasoline in a well-ventilated area away from any source of flame or sparks, including any appliances with a pilot light. Store gasoline in an approved container in safe location.



WARNING

Gasoline is a toxic substance. Dispose of gasoline properly. Contact your local authorities for approved disposal methods.

- Remove the spark plugs and pour approx 1 ~ 2 mL (1/2 teaspoon) of engine oil through the spark plug holes (A) and then screw the spark plugs in after turning the engine a few times. Slowly turning the engine until you feel compression and then leave it there. This blocks the air inside the cylinder and prevents rust inside the engine.



- Change engine oil for next use after period of storage (see MAINTENANCE chapter for oil change.)

TROUBLESHOOTING GUIDE

If the engine malfunctions, carefully examine the symptoms and the operating conditions, and use the table below as a guide to troubleshooting.

Symptom		Probably Cause	Remedy
Engine won't start or output is low	Insufficient compression	Loose spark plugs	Tighten properly
		Loose cylinder head bolts	◇
		Faulty pistons, cylinders, piston rings, or head gaskets	
		Faulty valves	
	No fuel to combustion chamber	No fuel in fuel tank	Fill fuel tank
		Fuel valve not in "ON" position	Open fuel valve lever.
		Blocked fuel filter or tube	Change fuel filter or fuel tube
		Blocked air vent in tank cap	Clean fuel tank cap
		Faulty carburetor	◇
	Spark plugs fouled by fuel	Clogged air cleaner	Clean
		Incorrect grade/type of fuel	Change fuel
		Water in fuel	
		Over rich fuel/air mixture	◇
		Faulty carburetor	◇
	No spark or weak spark	Faulty spark plugs	Replace spark plugs
		Engine switch left in "OFF" position	Turn engine switch to "START" position (See M)
		Faulty ignition coil	◇

40 TROUBLESHOOTING GUIDE

Symptom		Probably Cause	Remedy
Low output	Engine overheats	Clogged air cleaner	Clean
		Air inlet screen or cooling air path clogged with dirt	
		Insufficient engine oil	Replenish or change oil
		Poor ventilation around engine	Select a better location
		Carbon build-up in combustion chamber	◇
	Engine speed won't increase	Faulty governor	◇

◇ : Service to be performed by an authorized Kawasaki engine dealer or equally qualified service facility.

M : For Control Panel Switch Type, move the throttle lever on the equipment away from its low speed end to turn the engine switch to "ON".

ENVIRONMENTAL PROTECTION

To protect our environment, properly discard used batteries, engine oil, gasoline, coolant, or other components that you might dispose of in the future.

Consult an authorized Kawasaki engine dealer or equally qualified service facility or local environmental waste agency for their proper disposal procedure.


SPECIFICATIONS

	FH541V, FH580V
Type	Air-cooled, 4-stroke Vertical OHV, gasoline engine
Bore x Stroke	74 x 68 mm (2.91 x 2.68 in.)
Displacement	585 mL (35.6 cu.in.)
Ignition System	Magneto ignition
Direction of Rotation	Counterclockwise facing the PTO Shaft
Starting System	Electric starter

NOTE

○ *Specifications are subject to change without notice.*

WIRING DIAGRAM



NOTE

○ Portion Surrounded by hatching Shows Kawasaki Procurement Parts.

WARNING

Prevent sparks and/or electrical system damage by removing the negative (-) cable from the battery before attempting any repair or maintenance.

Battery Capacity Recommended

Model	FH541V, FH580V
Lawn Mower	12 V 200 CCA Class
Snow Thrower	12 V 280 CCA Class

 WARNING

The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

For repair or maintenance assistance contact an authorized Kawasaki engine dealer or equally qualified service facility.

For warranty assistance please contact an authorized Kawasaki engine dealer.

Kawasaki engine dealer locator can be found on our website: www.kawasakenginesusa.com

For further assistance email:
kawasakenginesupport@kmc-usa.com
or call 877-364-6404



Kawasaki
— ENGINES —