

Use & Care Guide

Kenmore®

OVER-THE-RANGE

#,* = color number

Models : 405.8706X

Transform SR Brands Management LLC
Hoffman Estates, IL, U.S.A. 60179 U.S.A
www.kenmore.com



TABLE OF CONTENTS

PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY	5
SPECIFICATIONS	5
IMPORTANT SAFETY INSTRUCTIONS	6
GROUNDING INSTRUCTIONS	8
RADIO INTERFERENCE	9
UTENSILS	9
CLEANING	10
NAMES OF OVEN PARTS AND ACCESSORIES	11
TURNTABLE INSTALLATION	12
OPERATION INSTRUCTIONS	13
CONTROL PANEL	13
1. Setting The Clock	14
2. Setting The Kitchen Timer	14
3. Microwave Cooking	15
4. Defrost By Weight	15
5. Defrost By Time	16
6. Speedy Cooking	16
7. Veggies	17
8. Popcorn	17
9. Potato	17
10. Snack Menus	18
11. Melt/ Soften	19
12. Auto Cook	19
13. Multi-Stage Cooking	20
14. Lock Function for Children	21
15. Inquiring Function	21
16. Setting The Vent High/ Low/ Off	22
17. Setting The Light On Or Off	22
18. User Preference	22
MAINTENANCE	24

PRODUCT RECORD

In the space below, record the data of purchase, model and serial number of your product. You will find the model and serial number printed on an identification label located on the interior liner of the Range compartment. Have these items of information available whenever you contact Sears concerning your product.

Model No. _____

Date of Purchase _____

Serial No. _____

Save these instructions and attach your sales receipt for future reference.

Kenmore Limited Warranty

Kenmore® products are sold and distributed by Kenmore and Kenmore authorized distributors and licensees in various countries.

For information on the limited warranty and authorized provider applicable to your product and country please visit: <https://www.kenmore.com/warranty-information/>

For a printed copy please contact us at 1-844-553-6667 or at the address below:

*ATTN: Kenmore Warranty Request
5407 Trillium Suite B120
Hoffman Estates, IL 60192*

PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY

- (a) Do not attempt to operate this oven with the door open since open door operation can result in harmful exposure to microwave energy.
It is important not to defeat or tamper with the safety interlocks.
- (b) Do not place any object between the oven front face and the door or allows soil or cleaner residue to accumulate on sealing surfaces.
- (c) Do not operate the oven if it is damaged. It is particularly important that the oven door close properly and that there is no damage to the:
 - (1) DOOR (bent)
 - (2) HINGES AND LATCHES (broken or loosened)
 - (3) DOOR SEALS AND SEALING SURFACE
- (d) The oven should not be adjusted or repaired by anyone except properly qualified service personnel.

SPECIFICATIONS

Model	405.8706X
Rated Voltage/Frequency	120VAC, 60Hz
Rated Input Power(Microwave)	1500 W
Rated Output Power(Microwave)	1000 W

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances basic safety precautions should be followed, including the following:

WARNING - To reduce the risk of burns, electric shock, fire, injury to persons or exposure to excessive microwave energy:

1. Read all instructions before using the appliance.
2. Read and follow the specific: "PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY" found on page 5.
3. This appliance must be grounded. Connect only to properly grounded outlet. See "GROUNDING INSTRUCTIONS" found on page 8.
4. Install or locate this appliance only in accordance with the provided installation instructions.
5. Some products such as whole eggs and sealed containers - for example, closed glass jars - are able to explode and should not be heated in this oven.
6. Use this appliance only for its intended use as described in the manual. Do not use corrosive chemicals or vapors in this appliance. This type of oven is specifically designed to heat, cook or dry food. It is not designed for industrial or laboratory use.
7. HOT CONTENTS CAN CAUSE SEVERE BURNS. DO NOT ALLOW CHILDREN TO USE THE MICROWAVE. Use caution when removing hot items.
8. Do not operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been damaged or dropped.
9. This appliance should be serviced only by qualified service personnel. Contact nearest authorized service facility for examination, repair, or adjustment.
10. Do not cover or block any openings on the appliance.
11. Do not store this appliance outdoors. Do not use this product near water - for example, near a kitchen sink, in a wet basement, near a swimming pool, or similar location.
12. Do not immerse cord or plug in water.
13. Keep cord away from heated surface.
14. Do not let cord hang over edge of table or counter.
15. When cleaning surfaces of door and oven that comes together on closing the door, use only mild, nonabrasive soaps, or detergent applied with a sponge or soft cloth.
16. To reduce the risk of fire in the oven cavity:
 - 1). Do not overcook food. Carefully attend appliance when paper, plastic, or other combustible materials are placed inside the oven to facilitate cooking.
 - 2). Remove wire twist-ties from paper or plastic bag before placing bag in oven.
 - 3). If material inside of the oven ignite, keep oven door closed, turn oven off, and disconnect the power cord, or shut off power at the fuse or circuit breaker panel.
 - 4). Do not use the cavity for storage purposes. Do not leave paper products, cooking utensils, or food in the cavity when not in use.
17. Liquids, such as water, coffee, or tea are able to be overheated beyond the boiling point without appearing to be boiling. Visible bubbling or boiling when the container is removed from the microwave oven is not always present. THIS COULD RESULT IN VERY HOT LIQUID SUDDENLY BOILING OVER WHEN THE CONTAINER IS DISTURBED OR A UTENSIL IS INSERTED INTO THE LIQUID.

To reduce the risk of injury to persons:

 - 1) Do not overheat the liquid.
 - 2) Stir the liquid both before and halfway through heating it.
 - 3) Do not use straight-sided containers with narrow necks.
 - 4) After heating, allow the container to stand in the microwave oven for a short time before removing the container.

IMPORTANT SAFETY INSTRUCTIONS

- 5) Use extreme care when inserting a spoon or other utensil into the container.
- 18. Do not operate any heating or cooking appliance beneath the appliance.
(Exception: A microwave oven investigated for use above another heating appliance.)
- 19. Do not mount unit over or near any portion of heating or cooking appliance.
(Exception: A microwave oven investigated for use above another heating appliance.)
- 20. Do not mount over sink.
- 21. Do not store anything directly on top of the appliance surface when the appliance is in operation.
- 22. Clean Ventilation Hoods Frequently - Grease should not be allowed to accumulate on hood or filter.
- 23. When flaming foods under the hood, turn the fan on.
- 24. Use care when cleaning the vent-hood filter. Corrosive cleaning agents, such as lyebased oven cleaners, may damage the filter.
- 25. Suitable for use above both gas and electric cooking equipment.

SAVE THESE INSTRUCTIONS
HOUSEHOLD USE ONLY
(NOT FOR COMMERCIAL USE)

GROUNDING INSTRUCTIONS

This appliance must be grounded. In the event of an electrical short circuit, grounding reduces the risk of electric shock by providing an escape wire for the electric current.

This appliance is equipped with a cord having a grounding wire with a grounding plug.

The plug must be plugged into an outlet that is properly installed and grounded.

WARNING - Improper use of the grounding can result in a risk of electric shock.

Consult a qualified electrician or serviceman if the grounding instructions are not completely understood, or if doubt exists as to whether the appliance is properly grounded. If it is necessary to use an extension cord, use only a 3-wire extension cord that has a 3-blade grounded plug, and 3-slot receptacle that will accept the plug on the appliance. The marked rating of the extension cord shall be equal to or greater than the electrical rating of the appliance.

DANGER - Electric Shock Hazard

Touching some of the internal components can cause serious personal injury or death.

Do not disassemble this appliance.

WARNING - Electric Shock Hazard

Improper use of the grounding can result in electric shock. Do not plug into an outlet until appliance is properly installed and grounded.

1. A short power-supply cord is provided to reduce the risks resulting from becoming entangled in or tripping over a longer cord.
2. Longer cord sets or extension cords are available and may be used if care is exercised in their use.
3. If a long cord or extension cord is used:
 - 1) The marked electrical rating of the cord set or extension cord should be at least as great as the electrical rating of the appliance.
 - 2) The extension cord must be a grounding-type 3-wire cord.
 - 3) The longer cord should be arranged so that it will not drape over the counter top or tabletop where it can be pulled on by children or tripped over unintentionally.

RADIO INTERFERENCE

1. Operation of the microwave oven may cause interference to your radio, TV or similar equipment.
2. When there is interference, it may be reduced or eliminated by taking the following measures:
 - 1) Clean door and sealing surface of the oven
 - 2) Reorient the receiving antenna of radio or television.
 - 3) Relocate the microwave oven with respect to the receiver.
 - 4) Move the microwave oven away from the receiver.
 - 5) Plug the microwave oven into a different outlet so that microwave oven and receiver are on different branch circuits.
3. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - 1) Reorient or relocate the receiving antenna.
 - 2) Increase the separation between the equipment and receiver.
 - 3) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - 4) Consult the dealer or an experienced radio/TV technician for help.)

This device complies with part 18 of the FCC Rules.

UTENSILS

CAUTION - Personal Injury Hazard

Tightly-closed utensils could explode. Closed containers should be opened and plastic pouches should be pierced before cooking.

See the instructions on "Materials you can use in microwave oven or to be avoided in microwave oven."

There may be certain non-metallic utensils that are not safe to use for microwaving.

If in doubt, you can test the utensil in question following the procedure below.

Utensil Test:

1. Fill a microwave-safe container with 1 cup of cold water (250ml) along with the utensil in question.
2. Cook on maximum power for 1 minute.
3. Carefully feel the utensil. If the empty utensil is warm, do not use it for microwave cooking.
4. Do not exceed 1 minute cooking time.

CLEANING

Be sure to unplug the appliance from the power supply.

1. Clean the cavity of the oven after using with a slightly damp cloth.
2. Clean the accessories in the usual way in soapy water.
3. The door frame and seal and neighbouring parts must be cleaned carefully with a damp cloth when they are dirty.
4. Do not use harsh abrasive cleaners or sharp metal scrapers to clean the oven door glass since they can scratch the surface, which may result in shattering of the glass.
5. Cleaning Tip---For easier cleaning of the cavity walls that the food cooked can touch: Place half a lemon in a bowl, add 300ml (1/2 pint) water and heat on 100% microwave power for 10 minutes. Wipe the oven clean using a soft, dry cloth.

Materials you can use in microwave oven

Utensils	Remarks
Browning dish	Follow manufacturer* instructions. The bottom of browning dish must be at least 3/16 inch (5mm) above the turntable. Incorrect usage may cause the turntable to break.
Dinnerware	Microwave-safe only. Follow manufacturer's instructions. Do not use cracked or chipped dishes.
Glass jars	Always remove lid. Use only to heat food until just warm. Most glass jars are not heat resistant and may break.
Glassware	Heat-resistant oven glassware only. Make sure there is no metallic trim. Do not use cracked or chipped dishes.
Oven cooking bags	Follow manufacturer* instructions. Do not close with metal tie. Make slits to allow steam to escape.
Paper plates and cups	Use for short term cooking/warming only. Do not leave oven unattended while cooking.
Paper towels	Use to cover food for reheating and absorbing fat. Use with supervision for a short-term cooking
Parchment paper	Use as a cover to prevent splattering or a wrap for steaming.
Plastic	Microwave-safe only. Follow the manufacturer* instructions. Should be labeled "Microwave Safe". Some plastic containers soften, as the food inside gets hot. "Boiling bags" and tightly closed plastic bags should be slit, pierced or vented as directed by package.
Plastic wrap	Microwave-safe only. Use to cover food during cooking to retain moisture. Do not allow plastic wrap to touch food.
Thermometers	Microwave-safe only (meat and candy thermometers).
Wax paper	Use as a cover to prevent splattering and retain moisture.

UTENSILS

Materials to be avoided in microwave oven


Utensils	Remarks
Aluminum tray	May cause arcing. Transfer food into microwave-safe dish.
Food carton with metal handle	May cause arcing. Transfer food into microwave-safe dish.
Metal or metaltrimmed utensils	Metal shields the food from microwave energy. Metal trim may cause arcing.
Metal twist ties	May cause arcing and could cause a fire in the oven.
Paper bags	May cause a fire in the oven.
Plastic foam	Plastic foam may melt or contaminate the liquid inside when exposed to high temperature.
Wood	Wood will dry out when used in the microwave oven and may split or crack.

NAMES OF OVEN PARTS AND ACCESSORIES


(In case of any differences between the appliance and the pictures in this manual, the product shall prevail.)

Remove the oven and all materials from the carton and oven cavity.

Your oven comes with the following accessories:




Glass Tray



Turntable Ring Assembly



Instruction Manual



- 1 Door Handle
- 2 Safety Door Latches
- 3 Observation Window
- 4 Turntable Motor Shaft
- 5 Waveguide Cover
- 6 Display Screen
- 7 Control Panel


TURNTABLE INSTALLATION

Cleaning the cooking compartment and putting the turntable in place.

For new installations, make sure all packaging and shipping tape has been removed from the turntable shaft.

Before using the appliance to prepare food for the first time, you will need to put the turntable in place correctly.

You must clean the cooking compartment and accessories.




How to put the turntable in place:

1. Place the turntable ring assembly ③ into the recess in the cooking compartment.

2. Place the glass tray ① on the turntable ring assembly ③.

Fit the raised, curved lines in the center of the glass tray bottom between the three spokes of the shaft. Make sure that the glass tray ① engages in the turntable motor shaft ② in the centre of the cooking compartment floor. The rollers on the shaft should fit inside the turntable bottom ridge.



Notes:

1. Never use the appliance without the turntable. Make sure that it is properly engaged. The turntable can turn clockwise or anti-clockwise.
2. Never place the glass tray upside down. The glass tray should never be restricted.
3. Both glass tray and turntable ring assembly must always be used during cooking.
4. All food and containers of food are always placed on the glass tray for cooking.
5. Never restrict the movement of the turntable.
6. If glass tray or turntable ring assembly cracks or breaks, contact your nearest authorized service center.

OPERATION INSTRUCTIONS

CONTROL PANEL

Auto Menus And Presets

VEGGIES POPCORN POTATO

SNACK
MENUS MELT/
SOFTEN AUTO
COOK

1 2 3

4 5 6

7 8 9

POWER
LEVEL 0 COOK
TIME

TIMER DEFROST CLOCK

STOP
CLEAR

USER
PREF

START
+30SEC.


FAN

|


LIGHT

1. Setting The Clock

- (1) Press " **CLOCK** " once and then the current clock will flash.
(Initial power-on, "12:00" will flash, please skip this step.)

CLOCK

- (2) Press the number keys to enter the time.
Example: To set the clock to 12:10, please press "1, 2, 1, 0" in turn.

1 2 3

- (3) Press " **CLOCK** " or " **START** " to confirm.
The clock is set.

CLOCK

Or

START
+30SEC.

! NOTE

- The clock is a 12-hour display.
- To reset the clock, please repeat step 1 to step 3.
- Upon initial power-up, if there is no operation within 5 minutes, the screen will turn off.

2. Setting The Kitchen Timer

- (1) Press " **TIMER** " once and then ":0" will display.

TIMER

- (2) Press the number keys to set the desired time.
The maximum time value is "99:99".

1 2 3

- (3) Press " **TIMER** " to confirm.
The timer starts counting down.

TIMER

! NOTE

- The kitchen timer is a timer.
- Press " **TIMER** " once to cancel the kitchen timer.

3. Microwave Cooking

The 11 power levels are available.

Power	100%	90%	80%	70%	60%	50%	40%	30%	20%	10%	0%
Display	P-HI	P-90	P-80	P-70	P-60	P-50	P-40	P-30	P-20	P-10	P-0

(1) Press " **COOK TIME** " once and then ":0" will display.

COOK TIME

(2) Press the number keys to set the cooking time.
The maximum time value is "99:99".

1 2 3

(3) Press " **POWER LEVEL** " once and then "P-HI" will display.

POWER LEVEL

(4) Press " **POWER LEVEL** " repeatedly or press the number keys to set the power level.
The 11 power levels are available.

POWER LEVEL

Or

1 2 3

(5) Press " **START** +30SEC. " to start cooking.

START
+30SEC.

! NOTE

- Opening the oven door or pressing " **STOP** CLEAR " during operation will interrupt the current mode.
Close the oven door and then press " **START** +30SEC. " to resume the operation.
- If "P-0" is selected, the oven will work with a fan for no power.
You can use this level to remove the odor of the oven.

4. Defrost By Weight

(1) Press " DEFROST " once and then "0.0" will display.

DEFROST

(2) Press the number keys to set the weight of the food.
The range of weight is 0.1~ 6.0 lbs.

1 2 3

(3) Press " **START** +30SEC. " to start defrosting.

START
+30SEC.

! NOTE

- The buzzer will sound to remind you to turn the food over during defrosting.
If no operation, the oven will continue working.

5. Defrost By Time

(1) Press " DEFROST " twice and then "0:00" will display.

DEFROST

(2) Press the number keys to set the cooking time.
The maximum time value is "99:99".

1 2 3

(3) Press " **START** " to start defrosting.
+30SEC.

START
+30SEC.

! NOTE

- The buzzer will sound to remind you to turn the food over during defrosting.
If no operation, the oven will continue working.

6. Speedy Cooking

(1) In standby mode, pressing the number keys 1 to 6 lets you quickly select a cooking time from 1 to 6 minutes. Cooking will automatically start in 2 seconds.
Then you can press " **START** " to increase the cooking time.
+30SEC.
The maximum time value is "99:99".

1 2 3

(2) In standby mode, pressing " **START** " to cook food at 100% power level for 30 seconds. Each press on the same key can increase 30 seconds and the maximum time value is "99:99".
+30SEC.

START
+30SEC.

! NOTE

- In the microwave cooking state, each more press on " **START** " can increase the cooking time by 30 seconds (except for the defrosting and auto menu).
+30SEC.
- "Food" will display if the number keys 1 to 6 or " **START** " is not selected within 5 minutes of placing the food in the oven. You must open then close the door again to clear "Food" from the display.
+30SEC.
And then press " **START** " to start cooking.
+30SEC.

7. Veggies

(1) Press " VEGGIES " once and then "Fr-1" will display.

VEGGIES

(2) Press " VEGGIES " repeatedly to set the type of the food.
"Fr-1, Fr-2" are available.

VEGGIES

(3) Press the number key "1", "2", "3", or "4" to set the weight of the food.
Example: Press "2" once, and then "2 CUP" will display.

1 2 3

(4) Press " **START** " to start cooking.
+30SEC.

START
+30SEC.

Veggies Chart

Display	Food	The Number Key	Weight
Fr-1	Fresh Vegetable	1, 2, 3, 4	1~4 cups (4 oz/cup)
Fr-2	Frozen Vegetable	1, 2, 3, 4	1~4 cups (4 oz/cup)

8. Popcorn

(1) Press " POPCORN " once and then "3.3 oz" will display.

POPCORN

(2) Press " POPCORN " repeatedly or press the number key "1", "2", or "3" to set the weight of the food. "3.3 oz, 3.0 oz, 1.75 oz" are available.
Example: Press "2" once and then "3.0 oz" displays.

POPCORN

Or

1 2 3

(3) Press " **START** " to start cooking.
+30SEC.

START
+30SEC.

9. Potato

(1) Press " POTATO " once and then "1" will display.

POTATO

(2) Press " POTATO " repeatedly or press the number key "1", "2", "3", or "4" to set the weight of the food.
"1, 2, 3, 4" are available.
Example: Press "2" once and then "2" displays.

POTATO

Or

1 2 3

"1": 1 potato

"2": 2 potatoes

"3": 3 potatoes

"4": 4 potatoes

OPERATION INSTRUCTIONS

(3) Press "**START**
+30SEC." to start cooking.

START
+30SEC.

10. Snack Menus

(1) Press "**SNACK
MENUS**" once and then "Sn-1" will display.

**SNACK
MENUS**

(2) Press "**SNACK
MENUS**" repeatedly to set the type of the food.
"Sn-1, Sn-2, Sn-3, Sn-4" are available.

**SNACK
MENUS**

(3) Press the number key to set the weight of the food.

1 2 3

(4) Press "**START**
+30SEC." to start cooking.

START
+30SEC.

Snack Menus Chart

Display	Food	The Number Key	Weight
Sn-1	Hot Dogs	1	1 piece
		2	2 pieces
		3	3 pieces
		4	4 pieces
		5	5 pieces
		6	6 pieces
Sn-2	Frozen Kids Meal	-	8.8 oz
Sn-3	Meal In A Cup	-	2.39 oz
Sn-4	Soup	1	1 cup
		2	2 cups

! NOTE

- For the menus "Sn-2, Sn-3", please skip the step (3).

11. Melt/ Soften

(1) Press " ^{MELT/}SOFTEN " once and then "So-1" will display.

MELT/
SOFTEN

(2) Press " ^{MELT/}SOFTEN " repeatedly to set the type of the food.
"So-1, So-2, So-3, So-4" are available.

MELT/
SOFTEN

(3) Press the number key to set the weight of the food.

1 2 3

(4) Press " **START** _{+30SEC.} " to start cooking.

START
+30SEC.

Melt/ Soften Chart

Display	Food	The Number Key	Weight
So-1	Melt Butter	1	1 stick
		2	2 sticks
So-2	Melt Chocolate	1	2 oz
		2	4 oz
		3	8 oz
So-3	Softening Ice Cream	1	Pint
		2	1.5 quart
So-4	Softening Cream Cheese	1	3 oz
		2	8 oz

12. Auto Cook

(1) Press " ^{AUTO}COOK " once and then "Ac-1" will display.

AUTO
COOK

(2) Press " ^{AUTO}COOK " repeatedly to set the type of the food.
"Ac-1, Ac-2, Ac-3, Ac-4, Ac-5" are available.

AUTO
COOK

(3) Press the number key to set the weight of the food.

1 2 3

(4) Press " **START** _{+30SEC.} " to start cooking.

START
+30SEC.

OPERATION INSTRUCTIONS

Auto Cook Chart

Display	Food	The Number Key	Weight
Ac-1	Bacon	1	1 slice
		2	2 slices
		3	3 slices
Ac-2	Dinner Plate	1	1 plate
		2	2 plates
Ac-3	Rice	1	1 cup
		2	2 cups
Ac-4	Frozen Breakfast	1	8 oz
		2	12 oz
Ac-5	Frozen Pizza	1	6 oz
		2	8 oz
		3	12 oz

13. Multi-Stage Cooking

Example: Cook with 80% microwave power for 5 minutes and then cook with 50% microwave power for 7 minutes.

(1) Press " **COOK TIME** " once and then ":0" will display.

COOK TIME

(2) Press the number keys to set the cooking time to 5 minutes.

1 2 3

(3) Press " **POWER LEVEL** " once and then "P-HI" will display.

POWER LEVEL

(4) Press " **POWER LEVEL** " repeatedly or press the number key "8" to set the power level to "P-80".

POWER LEVEL

Or

8

(5) Press " **COOK TIME** " once and then ":0" will display.

COOK TIME

(6) Press the number keys to set the cooking time to 7 minutes.

1 2 3

(7) Press " **POWER LEVEL** " once and then "P-HI" will display.

**POWER
LEVEL**

(8) Press " **POWER LEVEL** " repeatedly or press the number key "5" to set the power level to "P-50".

**POWER
LEVEL**

Or

5

(9) Press " **START** +30SEC. " to start cooking.

**START
+30SEC.**

! NOTE

- At most two stages of microwave cooking can be set.
- The auto menu and defrosting cannot be set as one of the multi-stage.

14. Lock Function for Children

You can use this function to disable the screen buttons and prevent your child from accidentally turning the oven on.

(1) To activate the lock: In standby mode, press and hold " **STOP CLEAR** " for three seconds.
The buzzer will sound and the "LOCK" icon will display.

**STOP
CLEAR**

(2) To deactivate the lock: In the locked state, press and hold " **STOP CLEAR** " for three seconds.
The buzzer will sound and the "LOCK" icon will disappear.

**STOP
CLEAR**

15. Inquiring Function

(1) If the clock has been set, the current time will display for two seconds by pressing " **CLOCK** " in the cooking state.

CLOCK

(2) If the kitchen timer has been set, the current remaining time will display for two seconds by pressing " **TIMER** " in the cooking state.

TIMER

(3) In the microwave cooking state, press " **POWER LEVEL** " to inquire about the power level. It will display for two seconds.

**POWER
LEVEL**

16. Setting The Vent High/ Low/ Off

(1) Press "  " once to set the vent to high and then "HI" will display.



2) Press "  " twice to set the vent to low and then "Lo" will display.



3) Press "  " thrice to set the vent to off and then "oFF" will display.



17. Setting The Light On Or Off

(1) Press "  " to set the light to on and then "on" will display.



2) Press "  " twice to set the light to off and then "oFF" will display.



18. User Preference

18.1 Setting The Volume On Or Off

(1) Press "  " once and then "oP-1" will display.



(2) Press " **START**  ", and then "Lo", "nor", "HI", and "oFF" will display in a loop.



(3) Press " **START**  " to confirm your selection when the corresponding volume displayed.



18.2 Setting The Weight Unit (Lbs/ Kg)

(1) Press "  " twice and then "oP-2" will display.



(2) Press " **START**  ", and then "oP-2 lb" and "oP-2 kg" will display in a loop.



(3) Press " **START**  " to confirm your selection when the corresponding volume displayed.



18.3 Setting The Clock Display On Or Off

(1) Press " ^{USER}_{PREF} " three times and then "oP-3" will display.

USER
PREF

(2) Press " **START** _{+30SEC.} ", and then "on" and "oFF" will display in a loop.

START
+30SEC.

(3) Press " **START** _{+30SEC.} " to confirm your selection when the corresponding option displayed.

START
+30SEC.

18.4 Setting The Demo Function On Or Off

(1) Press " ^{USER}_{PREF} " four times and then "oP-4" will display.

USER
PREF

(2) Press " **START** _{+30SEC.} ", and then "on" and "oFF" will display in a loop.

START
+30SEC.

(3) Press " **START** _{+30SEC.} " to confirm your selection when the corresponding option displayed.

START
+30SEC.

! NOTE

- If the power is not cut off, the setting will be saved all the time.

MAINTENANCE

Troubleshooting

Check your problem by using the chart below and try the solutions for each problem.

If the microwave oven still does not work properly, contact the nearest authorized service center.

TROUBLE	POSSIBLE CAUSE	POSSIBLE REMEDY
Oven will not start	a. Electrical cord for oven is not plugged in. b. Door is open. c. Wrong operation is set.	a. Plug into the outlet. b. Close the door and try again. c. Check instructions.
Arcing or sparking	a. Materials to be avoided in microwave oven were used. b. The oven is operated when empty. c. Spilled food remains in the cavity.	a. Use microwave-safe cookware only. b. Do not operate with oven empty. c. Clean cavity with wet towel.
Unevenly cooked foods	a. Materials to be avoided in microwave oven were used. b. Food is not defrosted completely. c. Cooking time, power level is not suitable. d. Food is not turned or stirred.	a. Use microwave-safe cookware only. b. Completely defrost food. c. Use correct cooking time, power level. d. Turn or stir food.
Overcooked foods	Cooking time, power level is not suitable.	Use correct cooking time, power level.
Undercooked foods	a. Materials to be avoided in microwave oven were used. b. Food is not defrosted completely. c. Oven ventilation ports are restricted. d. Cooking time, power level is not suitable.	a. Use microwave-safe cookware only. b. Completely defrost food. c. Check to see that oven ventilation ports are not restricted. d. Use correct cooking time, power level.
Improper defrosting	a. Materials to be avoided in microwave oven were used. b. Cooking time, power level is not suitable. c. Food is not turned or stirred.	a. Use microwave-safe cookware only. b. Use correct cooking time, power level. c. Turn or stir food.

Kenmore®

For Customer Care go to:

www.kenmore.com/contact-us/

to select your local area or retailer where this appliance was purchased for contact information on scheduling in-home repair service or ordering replacement parts.

