





Panasonic®

Quick Reference Guide


Multi-Function Printer
Model No. **KX-MB781C**

Do NOT connect the USB cable until prompted by the Multi-Function Station (CD-ROM).

1



2



This Quick Reference Guide provides safety instructions and a basic description of the unit's functions. An illustrated leaflet provides instructions for easy installation. Please read before using the unit and save for future reference.

The included Setup CD-ROM provides the Operating Instructions in PDF format with a detailed description on how to use the unit. Adobe® Reader® is required to view them.

For assistance, please call 1-800-263-5008 or visit us at www.panasonic.ca

Designed to be used only in Canada.

- This unit is compatible with Call Display. To use this feature, you must subscribe to the appropriate service of your service provider.

Thank you for purchasing a Panasonic Multi-Function Printer.

User record (for your future reference)


Date of purchase

Serial number (found on the rear of the unit)

Dealer's name and address

Dealer's telephone number

Attach your sales receipt here.



You can select English or French for the language.

The display and reports will be in the selected language. The default setting is English. If you want to change the setting, see following:

1. **[MENU] → [⌘][1][1][0]**
2. Press **[1]** "ENGLISH" or **[2]** "FRENCH" to select the desired language. → **[SET] → [MENU]**

Caution:

- Do not rub or use an eraser on the printed side of recording paper, as the print may smear.

Notice for product disposal, transfer, or return:

- This product can store your private/confidential information. To protect your privacy/confidentiality, we recommend that you erase the information such as phonebook (or caller information) from the memory before you dispose, transfer or return the product.

ENERGY STAR:

- As an ENERGY STAR® Partner, Panasonic has determined that this product meets the ENERGY STAR guidelines for energy efficiency. ENERGY STAR is a U.S. registered mark.



Trademarks:

- Windows and Windows Vista are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- Adobe and Reader are either registered trademarks or trademarks of Adobe Systems Incorporated in the United States and/or other countries.
- All other trademarks identified herein are the property of their respective owners.

Copyright:

- This material is copyrighted by Panasonic Communications Co., Ltd., and may be reproduced for internal use only. All other reproduction, in whole or in part, is prohibited without the written consent of Panasonic Communications Co., Ltd.

© 2007 Panasonic Communications Co., Ltd. All Rights Reserved.

For your safety

To prevent severe injury and loss of life/property, read this section carefully before using the unit to ensure proper and safe operation of your unit.

- The following symbols are used to classify and describe the level of hazard and injury caused when the denotation is disregarded and improper use is performed.

	WARNING
Denotes a potential hazard that could result in serious injury or death.	
	CAUTION
Denotes hazards that could result in minor injury or damage to the unit.	

- The following symbols are used to classify and describe the type of instructions to be observed.

	This type of symbol is used to alert users to a specific operating procedure that must be performed carefully.
	This type of symbol is used to alert users to a specific operating procedure that must not be performed.
	This type of symbol is used to alert users to a specific operating procedure that must be emphasized in order to operate the unit safely.



WARNING

Power and ground connection



Use only the power source marked on the unit. If you are not sure of the type of power supplied to your home, consult your dealer or local power company.



For safety purposes this unit is equipped with a grounded plug. If you do not have this type of outlet, please have one installed. Do not defeat this safety feature by tampering with the plug.



Do not place objects on the power cord. Install the unit where no one can step or trip on the cord.



Do not overload power outlets and extension cords. This can result in the risk of fire or electric shock.



Completely insert the AC adaptor/power plug into the power outlet. Failure to do so may cause electric shock and/or excessive heat resulting in a fire.



Regularly remove any dust, etc. from the AC adaptor/power plug by pulling it from the power outlet, then wiping with a dry cloth. Accumulated dust may cause an insulation defect from moisture, etc. resulting in a fire.



Unplug this unit from power outlets if it emits smoke, an abnormal smell or makes unusual noise. These conditions can cause fire or electric shock. Confirm that smoke has stopped and contact an authorized service centre.



Never touch the plug with wet hands. Danger of electric shock exists.

Installation



Place the unit securely on a stable levelled surface. Serious damage and/or injury may result if the unit falls.



To prevent the risk of fire or electrical shock, do not expose this product to rain or any type of moisture.

Important Information



Make sure that the unit is installed in a well ventilated room so as not to increase density of ozone in the air. Since ozone is heavier than air, it is recommended that air at floor level be ventilated.

Operating safeguards



Unplug this unit from power outlets before cleaning. Do not use liquid or aerosol cleaners.



Do not cover slots and openings on the unit. They are provided for ventilation and protection against overheating. Never place the unit near radiators, or in a place where proper ventilation is not provided.



Never push any objects through slots in this unit. This may result in the risk of fire or electric shock. Never spill any liquid on the unit.



To reduce the risk of electric shock, do not disassemble this unit. Take the unit to an authorized service centre when service is required. Opening or removing covers may expose you to dangerous voltage or other risks. Incorrect reassembly can cause electric shock when the unit is subsequently used.



Follow all warnings and instructions marked on this unit.



Do not spill liquids (detergents, cleansers, etc.) onto the telephone line cord plug, or allow it to become wet at all. This may cause a fire. If the telephone line cord plug becomes wet, immediately pull it from the telephone wall jack, and do not use.



Unplug this unit from power outlets and refer servicing to an authorized service centre when the following conditions occur:

- If the power cord is damaged or frayed.
- If liquid has been spilled into the unit.
- If the unit has been exposed to rain or water.
- If the unit does not work normally by following the operating instructions. Adjust only controls covered by the operating instructions. Improper adjustment may require extensive work by an authorized service centre.
- If the unit has been dropped or physically damaged.
- If the unit exhibits a distinct change in performance.



CAUTION

Installation and relocation



After moving the unit from cold areas to warmer areas, let the unit adjust to the warmer temperature and do not connect the unit for about 30 minutes. If the unit is connected too soon after a sudden climate change, condensation may form inside the unit causing malfunction.



Never install telephone wiring during a lightning storm.



Never install telephone jacks in wet locations unless the jack is specifically designed for wet locations.




Never touch uninsulated telephone wires or terminals unless the telephone line has been disconnected at the network interface.



Use caution when installing or modifying telephone lines.



When moving the unit, make sure you are using the side grips (①).



Laser radiation



The printer of this unit utilizes a laser. Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.


Fuser unit

The fuser unit (②) gets hot. Do not touch it.



Note:

- During or immediately after printing, the area near the recording paper exit (③) also gets warm. This is normal.



Toner cartridge

Be careful of the following when you handle the toner cartridge:



If you ingest any toner, drink several glasses of water to dilute your stomach contents, and seek immediate medical treatment.



If any toner comes into contact with your eyes, flush them thoroughly with water, and seek medical treatment.



If any toner comes into contact with your skin, wash the area thoroughly with soap and water. If there is skin irritation, seek immediate medical treatment.



If you inhale any toner, move to an area with fresh air and consult local medical personnel.

Important safety instructions

When using this unit, basic safety precautions should always be followed to reduce the risk of fire, electric shock, or personal injury.

1. Do not use this unit near water, for example near a bathtub, wash bowl, kitchen sink, etc.
2. During thunderstorms, avoid using telephones except cordless types. There may be a remote risk of an electric shock from lightning.
3. Do not use this unit to report a gas leak, when in the vicinity of the leak.

SAVE THESE INSTRUCTIONS

Operating instructions in the CD-ROM

The operating instructions in the CD-ROM consist of the following contents. Adobe Reader is required to view them.

- To view or install the operating instructions in the CD-ROM, see page 12.

1. Introduction and Installation

- Information prior to using the unit, for example how to install the toner cartridge and drum unit, and other accessories.

2. Preparation

- Main settings prior to activating the unit, such as Multi-function software information.

3. Printer

- More ways to use the printer, such as printing on special media.

4. Scanner

- More ways to use the scanner, such as saving as a file or sending as an e-mail attachment.

5. Copier

- More ways to use the copier, such as enlargement/reduction, and ways to save on your paper.

6. Fax

- Convenient ways to send faxes such as using one-touch dial feature and navigator directory, and broadcast transmission.
- More ways to receive faxes, and preventing fax reception from undesired callers.

7. Call Display

8. Distinctive Ring

9. Programmable Features

10. Useful Information

- Detailed information on character entry, and information for more ways to use the unit.

11. Help

- Troubleshooting

12. Paper Jams

13. Cleaning

14. General Information

- Specifications

Table of Contents (Quick Reference Guide)

1. Introduction and Preparation

Accessories

- 1.1 Included accessories 8
- 1.2 Accessory information 8

Connections and Setup

- 1.3 Connections 9
- 1.4 Dialing mode 9
- 1.5 Selecting the operation mode (Scan/Copy/Fax) 9

Document Requirements

- 1.6 Setting the original..... 10

Help Button

- 1.7 Help function 10

Volume

- 1.8 Adjusting volume 10

Initial Programming

- 1.9 Date and time 11
- 1.10 Your logo..... 11
- 1.11 Your fax number 11
- 1.12 Configuring the unit to access the LAN 11
- 1.13 Installing Multi-Function Station 11

2. How to Use

Printer

- 2.1 Printing from Windows applications 13

Scanner

- 2.2 Scanning from the unit (Push Scan)..... 13
- 2.3 Scanning from a computer (Pull Scan)..... 13

Copy

- 2.4 Making a copy 13

Sending Faxes

- 2.5 Sending a fax manually 14

Receiving Faxes

- 2.6 Receiving a fax automatically – Auto answer
ON 14

Useful Information

- 2.7 Cancelling the operations..... 14

3. Help

Error Messages

- 3.1 Error messages – Display 15

4. General Information

Limited Warranty


- 4.1 Limited Warranty 17

Important information


- 4.2 Important information 18

1.1 Included accessories


- ① Power cord (PFJA1030Z)*¹ ② CD-ROM (PFJKMB271Z)*¹





- ③ Drum unit (KX-FAD93A)*¹



- ④ Starter toner cartridge*²



- ⑤ Quick reference guide (English-PFQW2667Z)*¹
(French-PFQW2668Z)*¹ ⑥ Quick installation guide (PFQW2639Z)*¹



- ⑦ Telephone line cord (PQJA10075Z)*¹



*¹ Part numbers are subject to change without notice.

*² Prints about 500 letter-sized pages with a 5 % image area.

Note:

- Save the original carton and packing materials for future shipping and transportation of the unit.

1.2 Accessory information

To ensure that the unit operates properly, we recommend using the Panasonic toner cartridge and drum unit.

- **Replacement toner cartridge*¹**
 - **Model No. (Part No.): KX-FAT92A**
- **Replacement drum unit**
 - **Model No. (Part No.): KX-FAD93A**
- **Optional handset unit*²**
 - **Model No. (Part No.): KX-FA103A**

*¹ Approx. 2,000 sheets of letter size paper can be printed with KX-FAT92A.


*² See the operating instructions in the CD-ROM for connections.

1.3 Connections

Caution:

- When you operate this product, the power outlet should be near the product and easily accessible.

- ① Power cord
 - Connect to a power outlet (120 V, 60 Hz).
- ② Telephone line cord
 - Connect to a single telephone line jack (RJ11C).
- ③ [EXT] jack
 - You can connect an answering machine or an extension telephone. Remove the stopper if attached.
- ④ Answering machine (not included)
- ⑤ Handset unit (optional) connection jack
 - You can connect the optional handset unit. Remove the seal if attached.
- ⑥ Network router/Network hub (not included)
 - Also connect networked computers.
- ⑦ To the internet
- ⑧ LAN cable (not included)
 - To assure continued emission limit compliance, use only shielded LAN cable (category 5 straight cable).



Important notice for the USB connection

- Do NOT connect the USB cable until prompted by the Multi-Function Station (page 11).

Note:

- If any other device is connected to the same telephone line, this unit may disturb the network condition of the device.

Using surge protectors

- The warranty does not cover damage due to power line surges or lightning. For additional protection, we recommend using surge protectors (⑨).

1.4 Dialing mode

If you cannot dial, change this setting according to your telephone line service.


1 [MENU] → [⌘][1][2][0]

DIALING MODE	
=TONE	[▼▲]

- 2 Press [1] or [2] to select the desired setting.
 - [1] "PULSE": For rotary/pulse dial service.
 - [2] "TONE" (default): For tone dial service.
- 3 [SET]
- 4 Press [MENU] to exit.

1.5 Selecting the operation mode (Scan/Copy/Fax)


You can select the desired mode by pressing one of the following buttons.



- [SCAN]: Select this mode when using the unit as a scanner for the computer.
- [COPY]: Select this mode when using the unit as a copier.
- [FAX]: Select this mode when using the unit as a fax machine.


1.6 Setting the original

1.6.1 Using the scanner glass



- 1 Open the document cover (①).
- 2 Place the document FACE DOWN on the scanner glass (②), aligning the top left of the document with the corner to which the  mark points.
- 3 Close the document cover.

1.6.2 Using the auto document feeder



- 1 Insert the document (up to 20 pages) FACE UP into the feeder until a single beep is heard.
- 2 Adjust the width of the document guides (①) to fit the actual size of the document.

1.7 Help function

The unit contains helpful information on the following topics which can be printed for reference purposes, as follows:

- “BASIC SETTINGS”
- “FEATURE LIST”
- “DIRECTORY”
- “FAX RECEIVING”
- “COPIER”
- “REPORTS”
- “CALL DISPLAY”

- 1 Press **[MENU]** repeatedly to display “HELP”.
- 2 Press **[◀]** or **[▶]** repeatedly to display the desired item. → **[SET]**
- 3 Press **[MENU]** to exit.

1.8 Adjusting volume

Before adjusting volume, set the operation mode to fax mode (page 9).

Ringer volume

While the unit is idle, press **[▼]** or **[▲]**.

- If there are any documents in the document entrance, you cannot adjust the volume. Confirm that there are no documents in the entrance.

To turn the ringer OFF

Press **[▼]** repeatedly to display “RINGER OFF= OK?”. → **[SET]**

- The unit will not ring.
- To turn the ringer back ON, press **[▲]**.

Ringer pattern

- You can select one of 3 ringer patterns (feature #161).

Monitor volume

While using the monitor, press **[▼]** or **[▲]**.

1.9 Date and time

1 [MENU] → [⏏][1][0][1] → [SET]

M: 01/D: 01/Y: 07
TIME: 12:00AM

2 Enter the current month/date/year/hour/minute by selecting 2 digits for each.

Example: August 10, 2007 10:15 PM (12 hour clock format)

1. Press [0][8] [1][0] [0][7] [1][0] [1][5].

M: 08/D: 10/Y: 07
TIME: 10:15AM

2. Press [⌘] repeatedly to select "PM".

3 [SET]

4 Press [MENU] to exit.

1.10 Your logo

You can program your logo (name, company name, etc.) so that it appears on the top of each page sent.

1 [MENU] → [⏏][1][0][2] → [SET]

LOGO=

2 Enter your logo, up to 30 characters. → [SET]

3 Press [MENU] to exit.

1.11 Your fax number

You can program your fax number so that it appears on the top of each page sent.

1 [MENU] → [⏏][1][0][3] → [SET]

NO. =

2 Enter your fax number, up to 20 digits.

- To enter a "+", press [⌘].
- To enter a space, press [⏏].
- To enter a hyphen, press [FLASH].
- To erase a number, press [STOP].

3 [SET]

4 Press [MENU] to exit.

1.12 Configuring the unit to access the LAN

You can print documents, scan documents, receive faxes or send faxes using a computer on the LAN. To enable these features, you need to set the IP address, subnet mask, and default gateway for the unit.

Important:

- Consult your network administrator when setting the IP address, subnet mask, and default gateway.

1.12.1 Setting up automatically with a DHCP server

Your situation:

- When only one unit is connected to the LAN.

If your network administrator manages the network with a DHCP (Dynamic Host Configuration Protocol) server, it will automatically assign an IP (Internet Protocol) address, subnet mask, and default gateway to the unit.

- 1 After connecting the LAN cable to the unit and the computer, connect the power cord.
 - The IP address, subnet mask, and default gateway will be set automatically.
- 2 Install Multi-Function Station on the computer that you want to use it with.

1.13 Installing Multi-Function Station

- **Install Multi-Function Station (CD-ROM) before connecting the unit to a computer with USB cable. If the unit is connected to a computer with USB cable before installing Multi-Function Station, the [Found New Hardware Wizard] dialogue box will appear. Click [Cancel] to close it.**
- **Software features and appearance are subject to change without notice.**

Warning:

- To assure continued emission limit compliance;
 - use only shielded USB cable.
 - use only shielded LAN cable (category 5 straight cable).


- 1 Start Windows® and exit all other applications.
 - For Windows 2000, Windows XP and Windows Vista™ operating system users, you must be logged in as an administrator in order to install Multi-Function Station.
- 2 Insert the included CD-ROM into your CD-ROM drive.
- 3 [Easy installation]
 - The installation will start.
- 4 When the setup program starts, follow the on-screen instructions.
- 5 The [Connect Type] dialogue box appears.

For USB connection:

1. [Connect directly with a USB cable.] → [Next]
 - The [Connect Device] dialogue box will appear.

1. Introduction and Preparation

2. Connect the unit with the USB cable (①), then click **[Next]**.



3. Click **[Install]**, then follow the on-screen instructions.
 - The files will be copied to your computer.

For LAN connection:

1. **[Connect via the Network.]** → **[Next]**
 - The **[Select a Network Device]** dialogue box will appear.
2. Check **[Select in the searched list]** and select the unit from the list.
3. **[Next]**
4. Click **[Install]**, then follow the on-screen instructions.
 - The files will be copied to your computer.

Important notice

If you use Windows XP or Windows Vista, a message may appear after connecting the unit with the USB cable. This is normal and the software will not cause any difficulties with your operating system. You can continue the installation with no problem. This kind of message is displayed.

- **For Windows XP users**

"The software you are installing for this hardware has not passed Windows Logo testing to verify its compatibility with Windows XP."

- **For Windows Vista users**

"Would you like to install this device software?"

To view or install the operating instructions in the CD-ROM

1. Start Windows and insert the included CD-ROM into your CD-ROM drive.
2. Click **[Operating Instructions]**, then follow the on-screen instructions to view or install the operating instructions in PDF format.
 - Adobe Reader is required to view them.

Note:

- If you install the operating instructions, you can view it anytime from **[?]** on the Multi-Function Station launcher.

2.1 Printing from Windows applications

You can print a file created in a Windows application. For example, to print from WordPad, proceed as follows.

- 1 Open the document you want to print.
- 2 Select **[Print...]** from the **[File]** menu.
- 3 Select the unit's name as the active printer.
 - If you have changed the name of the unit when installing, select that name from the list.
- 4 Click **[Print]** or **[OK]**.
 - The unit will start printing.

2.2 Scanning from the unit (Push Scan)

You can easily scan the document by operating the operation panel on the unit.

2.2.1 Scan to Multi-Function Viewer

- 1 Set the original (page 10).
- 2 **[SCAN]**
- 3 Press **[▼]** or **[▲]** repeatedly to select "VIEWER". → **[SET]**
- 4 **For USB connection:**
Press **[▼]** or **[▲]** repeatedly to select "USB HOST". → **[SET]**

For LAN connection:
Press **[▼]** or **[▲]** repeatedly to select the computer that you want to send the scanned image. → **[SET]**
- 5 If necessary, change the scanning settings (scan type / resolution / file format / brightness / contrast / scan size). Press **[▶]**, press **[▼]** or **[▲]** repeatedly to select the desired setting. → **[SET]** → **[START]**

2.3 Scanning from a computer (Pull Scan)

2.3.1 Using Multi-Function scan application

By clicking an application icon, the selected application starts automatically after scanning.

- 1 Set the original (page 10).
- 2 Start Multi-Function Station. → **[Scan]**
- 3 Click the desired application icon.

2.4 Making a copy

Illegal copies

- **It is unlawful to make copies of certain documents.**

Copying certain documents may be illegal in your country. Penalties of fines and/or imprisonment may be imposed on those found guilty. The following are examples of items that may be illegal to copy in your country.

- Currency
- Bank notes and checks
- Bank and government bonds and securities
- Passports and identification cards
- Copyright material or trademarks without the consent of the owner
- Postage stamps and other negotiable instruments

This list is not inclusive and no liability is assumed for either its completeness or accuracy. In case of doubt, contact your legal counsel.

Notice:

- Install your machine near a supervised area to prevent illegal copies from being made.

2.4.1 Using the scanner glass

- 1 If the **[COPY]** light is OFF, turn it ON by pressing **[COPY]**.
- 2 Set the original (page 10).
- 3 If necessary, change the resolution and contrast according to the type of document.
- 4 If necessary, enter the number of copies (up to 99).
- 5 **[START]**
 - The unit will start copying.
- 6 After you finish copying, press **[STOP]** to reset the settings you set in step 3 and 4.

2.4.2 Using the auto document feeder

- 1 If the **[COPY]** light is OFF, turn it ON by pressing **[COPY]**.
- 2 Set the original (page 10).
- 3 If necessary, change the resolution and contrast according to the type of document.
- 4 If necessary, enter the number of copies (up to 99).
- 5 **[START]**
 - The unit will start copying.
- 6 After you finish copying, press **[STOP]** to reset the settings you set in step 3 and 4.

2.5 Sending a fax manually

2.5.1 Using the scanner glass

- 1 If the **[FAX]** light is OFF, turn it ON by pressing **[FAX]**.
- 2 Set the original (page 10).
- 3 If necessary, change the resolution and contrast according to the type of document.
- 4 Dial the fax number.
 - To send a single page, skip to step 7.
 - To send multiple pages, go to the next step.
- 5 Press **[QUICK SCAN]** to scan the document into memory.
- 6 Place the next page on the scanner glass. → **[SET]**
 - To send more pages, repeat this step.
- 7 **[START]**

2.5.2 Using the auto document feeder

- 1 If the **[FAX]** light is OFF, turn it ON by pressing **[FAX]**.
- 2 Set the original (page 10).
- 3 If necessary, change the resolution and contrast according to the type of document.
- 4 **[MONITOR]**
- 5 Dial the fax number. → **[START]**

2.6 Receiving a fax automatically – Auto answer ON

2.6.1 Activating FAX ONLY mode

Press **[FAX AUTO ANSWER]** repeatedly to display “**FAX ONLY MODE**”.

How faxes are received

When receiving calls, the unit will automatically answer all calls and only receive fax documents.

2.7 Cancelling the operations

You can cancel the current operation from the unit. You can also select the desired operation to cancel.

- 1 **[STOP]**
 - “**USER STOPPED**” is displayed.

- When “**USER STOPPED**” is not displayed, go to step 2.

2 To cancel printing:

Press **[STOP]** repeatedly to display “**STOP PRINTING?**”.

To cancel scanning:

Press **[STOP]** repeatedly to display “**STOP SCANNING?**”.

To cancel copying:

Press **[STOP]** repeatedly to display “**STOP COPYING?**”.

To cancel sending or receiving faxes:

Press **[STOP]** repeatedly to display “**STOP FAX?**”.

To cancel broadcast transmission:

Press **[STOP]** repeatedly to display “**BROAD CANCELLED?**”.

To cancel fax redialing:

Press **[STOP]** repeatedly to display “**SEND CANCELLED?**”.

3 **[SET]**

3.1 Error messages – Display

If the unit detects a problem, one or more of the following messages will appear on the display.

Display	Cause & Solution
"CALL SERVICE"	There is something wrong with the unit. Contact our service personnel.
"CARRIAGE ERROR"	There is something wrong with the carriage sensor. Contact our service personnel.
"CHANGE DRUM"	There is something wrong with the drum unit. Replace the drum unit and the toner cartridge.
"CHECK DOCUMENT"	The document was not fed into the unit properly. Remove the document, then press [STOP] to clear the message. Re-insert the document. If misfeeding occurs frequently, clean the document feeder rollers and try again.
"CHECK DRUM"	The drum unit is not inserted properly. Re-insert it correctly.
"CHECK PAPER #1"	- Recording paper is not installed or the paper input tray has run out of paper. Install paper. - Recording paper was not fed into the unit properly. Re-insert the recording paper. - The paper input tray is not installed or is not inserted completely. Insert the paper input tray into the unit.
"CHECK PICK UP INPUT TRAY #2"	Recording paper was not fed into the unit properly. Re-insert the recording paper.
"CHECK REAR COVER"	- The manual input tray (rear cover) is open. Close it. - A recording paper jam occurred near the manual input tray (rear cover). Remove the jammed paper.
"DIRECTORY FULL"	There is no space to store new items in navigator directory. Erase unnecessary items.
"DRUM LIFE LOW REPLACE SOON"	The drum life is near to an end. Replace the drum unit as soon as possible.
"FAX IN MEMORY"	- The unit has a document in memory. See the other displayed message instructions to print out the document. - If feature #442 is set to "ALWAYS", check the connection between the computer and the unit.
"KEEP COPYING"	Copying has stopped due to a recording paper jam. See the other displayed message instructions to continue copying.
"LOW TEMP."	The inside of the unit is extremely cold and cannot be operated. Use the unit in a warmer area. While the unit cannot be operated, the received documents are temporarily stored into the memory, and will be printed out automatically when the unit warms up.
"MEMORY FULL"	- When performing memory transmission, the document being stored exceeded the memory capacity of the unit. Send the entire document manually. - When making a copy, the document being stored exceeded the memory capacity of the unit. Press [STOP] to clear the message. Divide the document into sections.
"MODEM ERROR"	There is something wrong with the unit's modem. Contact our service personnel.
"NO FAX REPLY"	The other party's fax machine is busy or has run out of recording paper. Try again.

3. Help

Display	Cause & Solution
"OUT OF PAPER INPUT TRAY #2"	● Recording paper is not installed in the manual input tray. Install paper.
"PAPER JAMMED" "OPEN TOP COVER"	● A recording paper jam occurred. Remove the jammed paper.
"PC FAIL OR BUSY"	● The cable or the computer power cord is not connected correctly. Check the connections. ● The software is not running on the computer. Restart the software and try again.
"PLEASE WAIT"	● The unit is warming up. Wait for a while.
"REDIAL TIME OUT"	● The other party's fax machine is busy or has run out of recording paper. Try again.
"REMOVE DOCUMENT"	● The document is jammed. Remove the jammed document. ● Attempted to send or copy a document longer than 600 mm (23⁵/₈") using the auto document feeder. Press [STOP] to remove the document. Divide the document into two or more sheets and try again.
"REMOVE PAPER IN INPUT TRAY #2"	● The recording paper is installed in the manual input tray when trying to copy, receive faxes or print reports. Remove the recording paper from manual input tray.
"REPLACE DRUM CHANGE SUPPLIES"	● The drum unit's service life is finished. Replace the drum unit immediately.
"RX MEMORY FULL"	● The memory is full of received documents due to a lack of recording paper or a recording paper jam. Install paper or remove the jammed paper. ● If feature #442 is set to "ALWAYS", check the connection between the computer and the unit.
"TONER EMPTY" "CHANGE SUPPLIES"	● The toner's service life is finished. Replace the toner cartridge immediately.
"TONER LOW" "CHANGE SUPPLIES"	● The toner's service life is near to an end. Replace the toner cartridge as soon as possible.
"TOP COVER OPEN"	● The top cover is open. Close it.
"TRANSMIT ERROR"	● A transmission error occurred. Try again.
"WARMING UP"	● The inside of the unit is cold. Let the unit warm up. Wait for a while.
"WRONG PAPER"	● The fax message was printed on paper which is shorter than letter size paper. Use the appropriate size paper.

4.1 Limited Warranty

Panasonic Canada Inc.

5770 Ambler Drive, Mississauga, Ontario L4W 2T3

PANASONIC PRODUCT – LIMITED WARRANTY

Panasonic Canada Inc. warrants this product to be free from defects in material and workmanship and agrees to remedy any such defect for a period as stated below from the date of original purchase.

Facsimile/Multi-Function Printer Product – One (1) year, parts and labour

LIMITATIONS AND EXCLUSIONS

This warranty does not apply to products purchased outside Canada or to any product which has been improperly installed, subjected to usage for which the product was not designed, misused or abused, damaged during shipping, or which has been altered or repaired in any way that affects the reliability or detracts from the performance, nor does it cover any product which is used commercially. Dry cell batteries, toner cartridge / drum unit and ink / print cartridges are also excluded from coverage under this warranty. Rechargeable batteries are warranted for ninety (90) days from date of original purchase.

This warranty is extended to the original end user purchaser only. A purchase receipt or other proof of date of original purchase is required before warranty service is performed.

THIS EXPRESS, LIMITED WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

IN NO EVENT WILL PANASONIC CANADA INC. BE LIABLE FOR ANY SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES.

In certain instances, some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, or the exclusion of implied warranties, so the above limitations and exclusions may not be applicable.

WARRANTY SERVICE

FOR PRODUCT OPERATION ASSISTANCE, please contact:

Our Customer Care Centre: Telephone #: (905) 624-5505

1-800 #: 1-800-561-5505

Fax #: (905) 238-2360

Email link: "Contact Us" under "Customer Support" on www.panasonic.ca

FOR PRODUCT REPAIRS, please locate your nearest Authorized Servicentre at www.panasonic.ca :

Link : "Servicentres™ locator" under "Customer support"

IF YOU SHIP THE PRODUCT TO A SERVICENTRE

Carefully pack and send prepaid, adequately insured and preferably in the original carton.

Include details of the defect claimed, and proof of date of original purchase.

4.2 Important information

SAFETY PRECAUTIONS

This unit may only be connected to electrical outlets that supply 120 V AC.

NOTICE:

This equipment meets the applicable Industry Canada Terminal Equipment Technical Specifications. This is confirmed by the registration number. The abbreviation, "IC:", before the registration number signifies that registration was performed based on a Declaration of Conformity indicating that Industry Canada technical specifications were met. It does not imply that Industry Canada approved the equipment.

Before installing this equipment, users should ensure that it is permissible to be connected to the facilities of the local telecommunications company. The equipment must also be installed using an acceptable method of connection. The customer should be aware that compliance with the above conditions may not prevent degradation of service in some situations.

Repairs to certified equipment should be coordinated by a representative designated by the supplier. Any repairs or alterations made by the user to this equipment, or equipment malfunctions, may give the telecommunications company cause to request the user to disconnect the equipment.

Users should ensure, for their own protection, that the electrical ground connections of the power utility, telephone lines and internal metallic water pipe system, if present, are connected together. This precaution may be particularly important in rural areas.

CAUTION:

Users should not attempt to make such connections themselves, but should contact the appropriate electric inspection authority, or electrician, as appropriate.

NOTICE:

The **Ringer Equivalence Number (REN)** assigned to each terminal device provides an indication of the maximum number of terminals allowed to be connected to a telephone interface. The termination on an interface may consist of any combination of devices subject only to the requirement that the sum of the Ringer Equivalence Numbers of all the devices does not exceed 5.

The Ringer Equivalence Number of This Unit:
(found on the rear of the unit)

Notes

Panasonic Canada Inc.

5770 Ambler Drive, Mississauga, Ontario L4W 2T3
www.panasonic.ca



MB781C