



EU**150** HYBRID ELLIPTICAL UPRIGHT BIKE OWNER'S MANUAL

EU150_115024_OM_20240426

PLEASE CAREFULLY READ THIS ENTIRE MANUAL BEFORE OPERATING YOUR
NEW HYBRID ELLIPTICAL UPRIGHT BIKE



Congratulations On Your New Hybrid Elliptical Upright Bike and Welcome to the XTERRA Fitness Family!

Thank you for your purchase of this quality Hybrid Elliptical Upright Bike from **XTERRA Fitness**. Your new Hybrid Elliptical Upright Bike has been manufactured by one of the leading fitness manufacturers in the world. **XTERRA Fitness** will do all we can to make your ownership experience as pleasant as possible for many years to come. If you have questions, or if parts are missing or damaged, or you require customer service, call (870) 333-5500. Please have your model number and serial number handy when you call.

Please take a moment to record where you purchased your machine, as well as the date of purchase for future reference. We appreciate your confidence in **XTERRA Fitness** and we will always remember that you are the reason that we are in business. Please complete and mail your registration card today and enjoy your new Hybrid Elliptical Upright Bike.

Yours in Health,
XTERRA Fitness

Table Of Contents

Product Registration	1
Important Safety Instructions	2
EU150 Assembly Instructions	4
Operation of Your Console	13
Program Operation	17
Manufacturer's Limited Warranty	24



WARNING

THIS PRODUCT CAN EXPOSE YOU TO CHEMICALS INCLUDING TOLUENE AND ACRYLAMIDE WHICH ARE KNOWN TO THE STATE OF CALIFORNIA TO CAUSE CANCER AND BIRTH DEFECTS OR OTHER REPRODUCTIVE HARM. FOR MORE INFORMATION GO TO WWW.P65WARNINGS.CA.GOV



ATTENTION

THIS FITNESS HYBRID ELLIPTICAL UPRIGHT BIKE IS INTENDED FOR **RESIDENTIAL USE ONLY** AND IS WARRANTED FOR THE APPLICATION. ANY OTHER APPLICATION **VOIDS** THIS WARRANTY IN ITS ENTIRETY.

Product Registration

Purchase Location _____

Purchase Date _____

Record Your Serial Number

Please record the Serial Number of this fitness product in the space provided below.

Serial Number _____

Register Your Purchase

The self-addressed product registration card must be completed in full and returned to **XTERRA Fitness**. You can also go to **www.xterrafitness.com/warranty** to register online.

Power

This product uses an external power supply. The adapter must be plugged into the power jack, located on the front of the unit near the stabilizer tube. Next, plug the adapter into the appropriate wall outlet. When not in use, it is recommended to unplug the power supply from the wall outlet.

IMPORTANT: If the product has been exposed to cold temperatures, allow the product sit in room temperature to warm up before plugging in the adapter. Failure to do so may result in damage to the display or electronic components.

IMPORTANT: Do not operate the product if the power supply, its plug, or its cord has been damaged.

Important Safety Instructions

When using an electrical appliance, basic precautions should always be followed, including the following:

Read all instructions before using this appliance.

DANGER - To reduce the risk of electric shock:

1. Always unplug this appliance from the electrical outlet immediately after using and before cleaning.

WARNING - To reduce the risk of burns, fire electric shock, or injury to persons:

1. An appliance should never be left unattended when plugged in. Unplug from outlet when not in use, and before putting on or taking off parts.
2. Do not operate under blanket or pillow. Excessive heating can occur and cause fire, electric shock, or injury to persons.
3. This exercise equipment is not intended for use by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge.
4. Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
5. Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the appliance to a service center for examination and repair.
6. Do not carry this appliance by supply cord or use cord as a handle.
7. Keep the cord away from heated surfaces.
8. Never operate the appliance with the air openings blocked. Keep the air openings free of lint, hair, and the like.
9. Never drop or insert any object into any opening.
10. Do not use outdoors.
11. Do not operate where aerosol (spray) products are being use or where oxygen is being administered.
12. Connect this appliance to a properly grounded outlet only.
13. The appliance is intended for household use

14.. Max User Weight: 265 lb

Fitness Equipment Safety Instructions

- To disconnect, turn all controls to the off position, then remove the plug from the outlet.
- Do not operate equipment on deeply padded, plush or shag carpet. Damage to both carpet and equipment may result.
- Before beginning this or any exercise program, consult a physician. This is especially important for persons over the age of 35 or persons with pre-existing health conditions.
- Keep hands away from all moving parts.
- The pulse sensors are not medical devices. Various factors, including the user's movement, may affect the accuracy of heart rate readings. The pulse sensors are intended only as exercise aids in determining heart rate trends in general.
- Do not attempt to use your equipment for any purpose other than for the purpose it is intended.
- Wear proper shoes. High heels, dress shoes, sandals or bare feet are not suitable for use on your equipment. Quality athletic shoes are recommended to avoid leg fatigue.

Failure to follow all guidelines may compromise the effectiveness of the exercise experience, expose yourself (and possibly others) to injury, and reduce the longevity of the equipment.

SAVE THESE INSTRUCTIONS - THINK SAFETY!




CAUTION!! Please be careful when unpacking the carton.


Before you begin

Thank you for selecting our revolutionary XTERRA EU150 Hybrid Elliptical Upright Bike. Walking is an effective exercise for increasing cardiovascular fitness, building endurance, and toning the body. Our fitness Hybrid Elliptical Upright Bike provides an impressive selection of features designed to make your workouts at home more effective and enjoyable.


For your benefit, read this manual carefully before you use you fitness Hybrid Elliptical Upright Bike. To help us assist you, note the product model number and serial number before contacting us. Before reading further, please familiarize yourself with the parts that are labeled in the drawing below.




EU150 Pre-Assembly Check List



NO: 1



NO: 11/12




NO: 18




NO: 22



NO: 4




NO: 2



NO: 9/10



NO: 19




NO: 13



NO: 20



NO: 16/64



NO: 14/15

PART NO.	DESCRIPTION	Q'TY
1	Main Frame	1
11/12	Pedal Tube (L/R)	1/1
18	Stationary Handlebar	1
22	Seat	1
4	Rear Stabilizer	1
2	Front Stabilizer	1
9/10	Pedal (L/R)	1/1
19	Computer	1
13	Front Post	1
20	Seat Post	1
16/64	Upper Handlebar (L/R)	1/1
14/15	Bottom Handlebar (L/R)	1/1
	Hardware Bag	1
	Manual	1


EU150 Assembly Pack Checklist

Part No.	Description	Q'ty
6	Curved Washer $\Phi 22 \times \Phi 10$	4
7	Dome Nut M10	4
8	Carriage Bolt M10*75	4
30	Allen Screw M8*16	6
31	Curved Washer $\Phi 20 \times \Phi 8$	6
32	PVC CAP	6
33	Hex Head Screw M10*20	2
34	Spring Washer $\Phi 10$	2
35	Washer $\Phi 32 \times \Phi 10$	2
36	D Type Washer	2
37	Carriage Bolt	4
38	Allen Screw M6*12	4
39	Hex Head Bolt M10*78	2
40	Sleeve	2
41	Washer $\Phi 10 \times \Phi 22$	6
42	Nylon Nut M10	6
44	Carriage Bolt M10*45	4
45 L/R	Hinge Bolt (L/R)	1/1
46	Wave Washer $\Phi 16$	2
47	Washer $\Phi 27 \times \Phi 13$	2
48 L/R	Lock Nut (L/R)	1/1
	Allen Key 4mm	1
	Allen Key 6mm	1
	Allen Key 8mm	1
	Allen Wrench	2

Note: Above parts are all the parts needed to assemble this machine. Before you start to assemble, please check the hardware packing to make sure they are included.

EU150 Assembly Instructions

1 Front Stabilizer and Rear Stabilizer




1. Attach the **Front Stabilizer (2)** to the front of the **Main Frame (1)**, fasten with two **Carriage Bolts (8)**, two **Curved Washers (6)** and two **Domed Nuts (7)**.
2. Repeat for the **Rear Stabilizer (4)** to the rear of the **Main Frame (1)**.

Hardware Step 1

4 Carriage Bolts (#8)
4 Curved Washers (#7)
4 Domed Nuts (#7)

2 Support Tube




1. Connect the **Lower computer wire (58)** with the **Upper computer wire (60)**. Be careful not to pinch the wires while assembling as this may cause damage to the electronics.
2. Insert the **Front Post (13)** into the **Main Frame (1)**, tighten with **four Allen Screws (30)** and **four Curved Washers (31)**.

Hardware Step 2

4 Allen Screws (#30)
4 Curved Washers (#31)

EU150 Assembly Instructions

3 Bottom Handlebars





1. Attach the **Left Bottom Handlebar (14)** to the left side axle of the **Front Post (13)**.
Secure using one **D Type Washer (36)**,
one **Washer (35)**,
one **Spring Washer (34)** and
one **Hex Head Screw (33)**.
Attach the **PVC Cap (32)** onto the **Hex Head Screw (33)**.
2. Repeat for the **Right Bottom Handlebar (15)** to the right side axle of the **Front Post (13)**.

Hardware Step 3

2 D Type Washers (#36)
2 Washers (#35)
2 Spring Washers (#34)
2 Hex Head Screws (#33)
2 PVC Caps (#32)

4 Pedal Tubes





1. Attach the **Left Pedal Tube (11)** to the **Left Side of Crank (49)**. Secure using one **Left Lock Nut (48L)**, one **Washer (47)**, one **Wave Washer (46)** and one **Left Hinge Bolt (45L)**.
2. Attach the **Left Pedal Tube (11)** to the **Left Bottom Handlebar (14)**. Line up the holes and insert the **Sleeve (40)** then secure using one **Nylon Nut (42)**, one **Washer (41)** and one **Hex Head Bolt (39)**. Attach the **PVC Cap (32)** onto the both side of **Pedal Tube (11)**.
3. Attach the **Left Pedal (9)** onto the **Left Pedal Tube (11)**, secure using two **Carriage Bolts (44)**, two **Washers (41)**, and two **Nylon Nuts (42)**.
4. Repeat the procedure for the **Right Pedal Tube (12) & Right Pedal (10)**.

Hardware Step 4

4 PVC Caps (#32)
 2 Hex Head Bolts (#39)
 2 Sleeves (#40)
 6 Washers (#41)
 6 Nylon Nuts (#42)
 4 Carriage Bolts (#44)
 1/1 Hinge Bolt (#45L/R)
 2 Wave Washers (#46)
 2 Washers (#47)
 1/1 Lock Nut (#48L/R)

EU150 Assembly Instructions

5 Handlebars and Console




Hardware Step 5

- 2 Allen Screws (#30)
- 2 Curved Washers (#31)

Pre-assembled on Console:
4 Screws (#62)

Pre-assembled on Seat Post:
1 Carriage Bolt (#26)
1 Quadrate Plate (#27)
1 Sleeve (#28)
1 Lock Knob (#29)




1. Attach the **Stationary Handlebar (18)** to the **Front Post (13)**. Secure using two **Allen Screws (30)** and two **Curved Washers (31)**.
2. Insert the **Hand Pulse Wires (63)** through the **Grommet (61)** on the **Front Post (13)**, and then pull it out from the top of the **Front Post (13)**. Connect the **Sensor Wire & Hand Pulse Wire (63)** with the **Computer (19)** accordingly.
3. Attach the **Computer (19)** to the **Front Post (13)** and fasten with four **Screws (62)**.
4. Attach the **Seat (22)** onto the **Seat Post (20)**, line up the holes then tighten with one **Carriage Bolt (26)**, one **Quadrant Plate (27)**, one **Sleeve (28)**, and one **Lock Knob (29)**.
5. Unscrew the **Quick Release Knob (57)** from the **Main Frame (1)**, insert the **Seat Post (20)** into the **Main Frame (1)**. Line up the holes and secure seat in position with **Quick Release Knob (57)**. The correct height for seat can be adjusted after the upright elliptical is fully assembled.

EU150 Assembly Instructions


6 Handlebars

Hardware Step 6

4 Allen Screws (#38)
4 Carriage Bolts (#37)



1. Connect the **Left Top Handlebar (16)** to the **Left Bottom Handlebar (14)**. Secure using two **Allen Screws (38)** and two **Carriage Bolts (37)**.
2. Repeat for the **Right Top Handlebar (64)** to the **Right Bottom Handlebar (15)**.



1. To listen to an MP3 during your workout, connect the MP3 with the **computer (19)** by using the **audio wire (86)**.
2. Plug the **adapter (87)** into the power receptacle.

Operation of Your Console

EU150 Console



Key Functions

- START/STOP:** Press to start or stop your exercise program.
Press to start body fat measurement.
- UP:** Press UP to increase the target values.
Press UP to increase the tension level while you are exercising.
Press UP to select your desired program.
- DOWN:** Press DOWN to decrease the preset target values.
Press DOWN to decrease the tension level.
Press DOWN to select your desired program.
- ENTER:** Press to accept the desired program.
Press to accept the target value.
Press and hold for four seconds to reset all values to zero when the unit is stopped.
- Body Fat:** Press to have your body fat measurement.
- Pulse RECOVERY:** Press to have the recovery grade of F1 to F6

Functions

Time:	Shows your elapsed workout time up to 99:59. Counts down from your preset target time to 0:00 during your workout.
Speed:	Displays between the current speed up to 99.9 M/H.
Distance:	Displays the cumulative distance traveled during your workout up to 99.99 M. Counts down from your preset target time to 0 M during your workout.
RPM:	Displays the current rotation per minute.
Calories:	Displays between the cumulative calories burned at any given time during your workout up to 999. Counts down from your preset target calorie to 0 <i>Note: This is a rough guide used for comparison of different exercise sessions, which cannot be used for medical purposes.</i>
Body fat:	Hand on the pulse grip, press the body fat key, the monitor will be measure the data of fat% , bmi, bmr.
Gripped pulse	Display's the user's current heart rate in beats per minute during the workout. Both hands must hold the gripped pulse for a heart rate reading during your workout. You may preset your target pulse. The computer will alarm to remind you as soon as your current heart rate has achieved at the preset figure. <i>Note: This data is a rough guide used for comparison of different exercise sessions, which cannot be used for medical purposes.</i>
Pulse Recovery:	Your computer is equipped with a recovery program to monitor your heart rate recovery. After your workout, press the recovery button and keep both hands on the gripped pulse. The computer will cease monitoring all functions except time which will commence countdown from 00:60 to 00:00. Once zero is reached the pulse function will display a grade between F1 to F6. F1 being the best and F6 being the worst reading you can receive. Press the recovery button to return to the main display.
<i>Note: If no pulse signal input then the computer will show "P" on the PULSE window. If the computer shows "ERR" on the message window, please re-press the PULSE RECOVERY key and please make sure your hands are keeping well on the grips or the chest transmitter is attached well</i>	
WATT:	The amount of mechanical power the computer is recieving from your exercise.

DISTANCE BAR:	Every bar indicates 0.1 mile.
SPEAKER:	To listen to an MP3 during your workout, connect the MP3 to the monitor (19) by using the audio wire (86). Volume is controlled by the MP3 player.
PROGRAM:	Displays the program level from P1 to P24 P1 –Manual you can control the tension level P2 to P13 programs are preset at the factory. P14 to P17 programs are user setting P18 to P22 programs are heart rate control programs P23 Watt Control Program P24 body fat program

Remarks

The monitor will turn on automatically by pressing any key or when you start to pedal. The monitor will shut off automatically if no signal is detected for four minutes and will keep all function values. You may press Start button or start to pedal to have the computer resume.

Program Introduction & Operation

Manual Program: Manual

P1 is a manual program. User can start exercise by pressing START/STOP key. The default resistance level is 7. Users may exercise in any desirous of resistance level (Adjusting by UP/DOWN keys during the workout) with a period of time or a number of calories or a certain distance.

Operations:

1. Use UP/DOWN keys to select the MANUAL (P1) program.
2. Press the ENTER key to enter MANUAL program.
3. The TIME will flash and you can press UP or DOWN keys to set your exercise TIME. Press ENTER key to confirm your desired TIME.
4. The DISTANCE will flash and you can press UP or DOWN keys to set your target DISTANCE. Press ENTER key to confirm your desired DISTANCE.
5. The CALORIES will flash and you can press UP or DOWN keys to set your exercise CALORIES. Press ENTER key to confirm your desired CALORIES.
6. The PULSE will flash and then you can press UP or DOWN keys to set your exercise PULSE. Press ENTER key to confirm your desired Pulse.
7. Press the START/STOP key to begin exercise.

Preset Program:

Steps, Hill, Rolling, Valley, Fat Burn, Ramp, Mountain, Intervals, Random, Plateau, Fartlek, Precipice Program

PROGRAM 2 to PROGRAM 13 is the preset programs. Users can exercise with different level of loading in different intervals as the profiles show. Users may exercise in any desirous of resistance level (Adjusting by UP/DOWN keys during the workout) with a period of time or a number of calories or a certain distance.

Operations:

1. Use UP/DOWN keys to select one of the above programs from P2 to P13.
2. Press the ENTER key to enter your workout program.
3. The TIME will flash and you can press UP or DOWN keys to setting your exercise TIME. Press ENTER key to confirm your desired TIME.
4. The DISTANCE will flash and you can press UP or DOWN keys to setting your target DISTANCE. Press ENTER key to confirm your desired DISTANCE.
5. The CALORIES will flash and you can press UP or DOWN keys to setting your exercise CALORIES. Press ENTER key to confirm your desired CALORIES
6. The PULSE will flash and then you can press UP or DOWN keys to set your exercise PULSE. Press ENTER key to confirm your desired Pulse.
7. Press the START/STOP key to begin exercise.

User Setting Program: User 1, User 2, User 3, User 4

Program 14 to 17 is the user setting program. Users are free to create the values in the order of TIME, DISTANCE, CALORIES and the resistance level in 10 columns. The values and profiles will be stored in

the memory after setup. Users may also change the ongoing loading in each column by UP/DOWN keys, and they will not change the resistance level stored in the memory.

Operations:

1. Use UP/DOWN keys to select the USER program from P14 to P17.
2. Press the ENTER key to enter your workout program.
3. The column 1 will flash, and then use the UP/DOWN keys to create your personal exercise profile. Press ENTER to confirm your first column of exercise profile. The default level is load 1.
4. The column 2 will flash, and then use the UP/DOWN keys to create your personal exercise profile. Press ENTER to confirm your second column of exercise profile.
5. Follow the above description 3 and 4 to finish your personal exercise profiles. Press ENTER to confirm your desired exercise profile.
6. The TIME will flash and you can press UP or DOWN keys to setting your exercise TIME.
7. Press ENTER key to confirm your desired TIME.
8. The DISTANCE will flash and you can press UP or DOWN keys to setting your target DISTANCE. Press ENTER key to confirm your desired DISTANCE.
9. The CALORIES will flash and you can press UP or DOWN keys to setting your exercise CALORIES. Press ENTER key to confirm your desired CALORIES.
10. The PULSE will flash and then you can press UP or DOWN keys to set your exercise PULSE. Press ENTER key to confirm your desired Pulse.
11. Press the START/STOP key to begin exercise.

Heart Rate Control Program:

55% H.R.C., 65% H.R.C., 75% H.R.C., 85% H.R.C., Target H.R.C.

Program 18 to Program 22 is the Heart Rate Control Programs and Program 22 is the Target Heart Rate Control program.

Program 18 is the 55% Max H.R.C. - - Target H.R. = $(220 - \text{AGE}) \times 55\%$

Program 19 is the 65% Max H.R.C. - - Target H.R. = $(220 - \text{AGE}) \times 65\%$

Program 20 is the 75% Max H.R.C. - - Target H.R. = $(220 - \text{AGE}) \times 75\%$

Program 21 is the 85% Max H.R.C. - - Target H.R. = $(220 - \text{AGE}) \times 85\%$

Program 22 is the Target H.R.C. - - Workout by your target heart rate value.

Users can exercise according to your desired Heart Rate program by setting your AGE, TIME, DISTANCE, CALORIES or TARGET PULSE. In these programs, the computer will adjust the resistance level according to the heart rate detected. For example, the resistance level may increase every 20 seconds while the heart rate detected is lower than the TARGET H.R.C. Also the resistance level may decrease every 20 seconds while the heart rate detected is higher than the TARGET H.R.C.

Operations:

1. Use UP/DOWN keys to select one of the heart rate control program from P18 to P22.
2. Press the ENTER key to enter your workout program
3. The AGE will flash at P18 to P21 programs and you can press UP or DOWN keys to set your AGE. The default age is 35.
4. At program 22, the TARGET PULSE will flash and you can press UP or DOWN keys to set your TARGET PULSE between 80 to 180. The default TARGET PULSE is 120.
5. The TIME will flash and you can press UP or DOWN keys to set your exercise TIME. Press

- ENTER key to confirm your desired TIME.
6. The DISTANCE will flash and you can press UP or DOWN keys to set your target DISTANCE. Press ENTER key to confirm your desired DISTANCE.
 7. The CALORIES will flash and you can press UP or DOWN keys to set your exercise CALORIES. Press ENTER key to confirm your desired CALORIES.
 8. Press the START/STOP key to begin exercise.

Watt Control Program: Watt Control

Program 23 is a Speed Independent Program. Press ENTER key to set up the values of TARGET WATT, TIME, DISTANCE and CALORIES. During the exercise mode, the level of resistance is not adjustable. For example, the level of resistance may increase while the speed is too slow. Also the level of resistance may decrease while the speed is too fast. As a result, the calculated value of WATT will close to the value of TARGET WATT setup by users.

Operations:

1. Use UP or DOWN key to select the WATT CONTROL (P23) program.
2. Press ENTER key to enter your workout program.
3. The TIME will flash and you can press UP or DOWN key to set your exercise TIME. Press ENTER key to confirm your desired TIME.
4. The DISTANCE will flash and you can press UP or DOWN key to set your target DISTANCE. Press ENTER key to confirm your desired DISTANCE
5. The WATT will flash and you can press UP or DOWN key to set your target WATT value. Press ENTER key to confirm your target WATT. The default WATT value is 100.
6. The CALORIES will flash and you can press UP or DOWN key to set your exercise CALORIES. Press ENTER key to confirm your desired CALORIES.
7. The PULSE will flash and then you can press UP or DOWN keys to set your exercise PULSE. Press ENTER key to confirm your desired Pulse.
8. Press the START/STOP key to begin exercise.

NOTE:

1. $WATT = TORQUE (KGM) * RPM * 1.03$
2. In this program, the WATT value will keep constant value. It means that if you peddle quickly, the resistance level will decrease and if you peddle slowly, the resistance level will increase. Always try to keep you in the same watt value.

Body Fat Program: Body Fat

Program 24 is a special program design to calculate users' body fat ratio and to offer a specific loading profile for users. There are 3 body types divided according to the FAT% calculated.

Type1: BODY FAT% > 27

Type2: $27 \geq \text{BODY FAT\%} \geq 20$

Type3: BODY FAT % < 20


The computer will show the test results of FAT PERCENT

Operations:


1. Use the UP/DOWN keys to select the BODY FAT (P24) program.
2. Press the ENTER key to enter your workout program.
3. The HEIGHT will flash and you can press the UP or DOWN keys to set your HEIGHT. Press ENTER key to confirm your HEIGHT. The default HEIGHT is 170cm or 5'07" (5 feet 7 inches).
4. The WEIGHT will flash and you can press UP or DOWN keys to set your WEIGHT. Press ENTER key to confirm your WEIGHT. The default WEIGHT is 70kgs or 155lbs.
5. The GENDER will flash and you can press UP or DOWN keys to select your sex. The number 1 means male and 0 means female. Press ENTER key to confirm your Gender. The default sex is set as 1 (Male).
6. The AGE will flash and you can press the UP or DOWN keys to set your AGE. Press the ENTER key to confirm your AGE. The default AGE is 35.
7. Press the START/STOP key to begin body fat measurement. If the window shows "E" on the window, please make sure your hands are holding the grips well or that the chest belt is touching your body properly. Then press the START/STOP key again to begin body fat measurement.
8. After finishing your measurement, the computer will show the values of FAT PERCENT on the LCD display.
9. Press START/STOP key to begin exercise.

PRESET PROGRAM PROFILES:


PROGRAM 1 MANUAL




PROGRAM 2 STEPS




PROGRAM 3 HILL




PROGRAM 4 ROLLING




PROGRAM 5 VALLEY




PROGRAM 6 FAT BURN



PROGRAM 7 RAMP



PROGRAM 8 MOUNTAIN



PROGRAM 9 INTERVAL



PROGRAM 10 RANDOM



PROGRAM 11 PLATEAU



PROGRAM 12 FARTLEK




PROGRAM 13 PRECIPICE



USER SETTING PROGRAM



PROGRAM 14

USER 1





PROGRAM 15

USER 2



PROGRAM 16

USER 3



PROGRAM 17



USER 4



HEART RATE PROGRAM PROFILES:



PROGRAM 18

55% H.R.C.





PROGRAM 19

65% H.R.C.





PROGRAM 20

75% H.R.C.





PROGRAM 21

85% H.R.C.



PROGRAM 22



TARGET H.R.C.



WATT CONTROL PROGRAM

PROGRAM 23


WATT CONTROL



BODY FAT TEST PROGRAMS:

PROGRAM 24


BODY FAT (STOP MODE)




BODY FAT (START MODE)




One of the Following Six Profiles Will Display Automatically after Measuring Your BODY FAT:




Workout Time: 40 minutes



Workout Time: 40 minutes




Workout time: 20 minutes



Workout Time: 40 minutes



Workout Time: 40 minutes



Workout time: 20 minutes

User Direction

HOW TO ADJUST THE SEAT

The seat can be adjusted forward or backward to the position that is the most comfortable. To adjust the seat, loosen the quick release knob, slide the seat to the desired position and retighten the knob.

HOW TO MOVE THE EU150

To move the Hybrid Bike, grasp the stationary handlebar and pull back on the handle until the Hybrid Bike can be moved on the front wheels. Carefully move the Hybrid Bike to the desired location and then lower it. Before moving the machine, please make sure that the top handlebars are on same position.

HOW TO LEVEL THE EU150

The bike is equipped with adjustable end caps. If the unit is wobbly, please turn the leveling caps on the rear stabilizer to level the unit.

HOW TO CHANGE MILES TO KM

Two people are needed for this. Unplug the adaptor from the cycle.

Press the start/stop button, the enter button and the up button all at the same time and connect the adaptor.

Screen will beep and turn on.

Press the enter button until the miles or km is flashing.

Press the up button to change to km

Press enter button until the monitor resets.

Your cycle is now in km.

Manufacturer's Limited Warranty

Effective April 26, 2024 - Hybrid Elliptical Upright Bike LIMITED WARRANTY

XTERRA Fitness Inc. warrants all its home use Hybrid Elliptical Upright Bike parts for a period of time listed below, from the date of retail sale, as determined by a sales receipt or in the absence of a sales receipt, eighteen (18) months from the original factory shipping date. XTERRA Fitness's responsibilities include providing new or remanufactured parts, at XTERRA Fitness's option, and technical support to our independent dealers and servicing organizations. In the absence of a dealer or service organization, these warranties will be administered by XTERRA Fitness directly to a consumer. The warranty period applies to the following components:

Home Use Limited Warranty

Frame	Parts	Labor
1 Years	1 Year	None

NORMAL RESPONSIBILITIES OF THE CONSUMER

This warranty applies only to products in ordinary household use. The consumer is responsible for the items listed below:

1. The warranty registration card must be completed and returned to the address listed on the card within 10 days of the original purchase to validate the manufacturer's limited warranty or register online at <http://www.xterrafitness.com/warrantyreg.html>.
2. Proper use of the Hybrid Elliptical Upright Bike in accordance with the instructions provided in this manual, including maintenance.
3. Proper connection to a power supply of sufficient voltage, replacement of blown fuses, repair of loose connections or defects in house/facility wiring.
4. Expenses for making the Hybrid Elliptical Upright Bike accessible for servicing, including any item that was not part of the Hybrid Elliptical Upright Bike at the time it was shipped from the factory.
5. Damages to the Hybrid Elliptical Upright Bike finish during shipping, installation or following installation.

EXCLUSIONS

This warranty does not cover the following:

1. CONSEQUENTIAL, COLLATERAL, OR INCIDENTAL DAMAGES SUCH AS PROPERTY DAMAGE AND INCIDENTAL EXPENSES RESULTING FROM ANY BREACH OF THIS WRITTEN OR ANY IMPLIED WARRANTY. Note: Some states do not allow the exclusion or limitation of incidental or consequential damages, so this limitation or exclusion may not apply to you.
2. Damages caused by services performed by persons other than authorized XTERRA Fitness service companies, use of parts other than original XTERRA Fitness parts, or external causes such as alterations, modifications, abuse, misuse, accident, improper maintenance, inadequate power supply, or acts of God.
3. Products with original serial numbers that have been removed or altered.
4. Products that have been; sold, transferred, bartered, or given to a third party.
5. Products that are used as store display models.
6. Products that do not have a warranty registration on file at XTERRA Fitness, Inc. XTERRA Fitness reserves the right to request proof of purchase if no warranty record exists for the product.
7. Product use in any environment other than a residential setting.
8. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES EXPRESSED OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND/OR FITNESS FOR A PARTICULAR PURPOSE.

SERVICE

Keep your bill of sale. Twelve (12) months from the date on the bill of sale or eighteen (18) months from the date of factory shipping as determined by the serial number establishes the warranty period should service be required. If service is performed, it is in your best interest to obtain and keep all receipts. This written warranty gives you specific legal rights. You may also have other rights that vary from state to state. Service under this warranty must be obtained by following these steps, in order:

1. Contact your selling authorized XTERRA Fitness dealer. OR
2. Contact your local authorized XTERRA Fitness service organization.
3. If there is a question as to where to obtain service, contact our service department at (870) 333-5500.
4. XTERRA Fitness's obligation under this warranty is limited to repairing or replacing, at XTERRA Fitness's option, the product through one of our authorized service centers. All repairs must be preauthorized by XTERRA Fitness. If the product is shipped to a service center freight charges to and from the service center will be the customer's responsibility. For replacement parts shipped while the product is under warranty, the customer will be responsible for shipping and handling charges. The owner is responsible for adequate packaging upon return to XTERRA Fitness. XTERRA Fitness is not responsible for damages in shipping. Make all freight damage claims with the appropriate freight carrier. DO NOT SHIP ANY UNIT TO OUR FACTORY WITHOUT A RETURN AUTHORIZATION NUMBER. All units arriving without a return authorization number will be refused.
5. For any further information, or to contact our service department by mail, send your correspondence to:

XTERRA Fitness, Inc.
P.O. Box 2037
Jonesboro, AR 72402-2037

Product features or specifications as described or illustrated are subject to change without notice. All warranties are made by XTERRA Fitness, Inc. This warranty applies only in the 48 contiguous United States. NOTE: This does not apply to Alaska or Hawaii.

3000 Nestle Road Jonesboro, AR 72401 - Phone:870-333-5500 - Fax:870-935-7611