

2017




Cadillac

XTS Convenience & Personalization Guide

cadillac.com

Review this guide for an overview of some important features in your Cadillac XTS. Some optional equipment described in this guide (denoted by ♦) may not be included in your vehicle. More detailed information can be found in your Owner Manual.

INSTRUMENT PANEL



REMOTE KEYLESS ENTRY TRANSMITTER



Lock

Press to lock all doors.



Unlock

Press to unlock the driver's door.

Press again to unlock all doors.

Press and hold to lower all windows.

Note: To change the Remote Lock and Unlock settings, go to Remote Lock, Unlock, Start in the Vehicle Settings menu.



Remote Vehicle Start

Use to start the engine from outside the vehicle. See Adaptive Remote Start on page 4.



Vehicle Locator/Panic Alarm

Press and release to locate your vehicle. The exterior lamps flash and the horn sounds.

Press and hold for 3 seconds to activate the alarm. The turn signal lamps flash and the horn sounds for 30 seconds, or until the  button is pressed again or the vehicle is started.



Trunk Release

Press twice to open the trunk.



See Keys, Doors and Windows in your Owner Manual.

KEYLESS ACCESS SYSTEM

The Keyless Access System enables operation of the doors, ignition and trunk without removing the Remote Keyless Entry transmitter from your pocket or purse. The transmitter must be within 3 feet of the door being unlocked or the trunk.

KEYLESS UNLOCKING

With the transmitter within range:

- ▶ Press the lock button on the driver's door handle to unlock the driver's door; press it again within 5 seconds to unlock all doors.
- ▶ Press the lock button on a passenger door handle to unlock all doors.
- ▶ Press the touch pad above the license plate to open the trunk.



KEYLESS LOCKING

With the ignition off, the transmitter removed from the vehicle, and all doors closed:

- ▶ Press the lock button on any door handle to lock all doors immediately.
- ▶ If Passive Locking is turned on, all doors will lock automatically after a short delay once all doors are closed.

Note: To change the door lock and unlock settings, go to Remote Lock, Unlock, Start in the Vehicle Settings menu.

See Keys, Doors and Windows in your Owner Manual.

KEYLESS START

START

- ▶ With the vehicle in Park or Neutral, press the brake pedal and then press the **ENGINE START/STOP** button to start the engine. The green indicator on the button will illuminate.



Note: The transmitter must be in the vehicle to turn on the ignition. If the transmitter battery is weak, place the transmitter in the depression below the Accessory Power Outlet in the center console lower storage area to enable the engine to start.

STOP/OFF

- ▶ Shift to Park and press the **ENGINE START/STOP** button to turn off the engine.

Power will be available for 10 minutes to operate the audio system until the driver's door is opened and to operate the windows and sunroof until any door is opened.

ACCESSORY

- ▶ With the engine off and the brake pedal NOT depressed, press the **ENGINE START/STOP** button to place the ignition system in the Accessory mode. The yellow indicator on the button will illuminate.

See Driving and Operating in your Owner Manual.

ADAPTIVE REMOTE START

STARTING THE VEHICLE

1. Press and release the **Lock** button on the Remote Keyless Entry transmitter.
2. Immediately press and hold the **Remote Start** button until the turn signal lamps flash.

When the vehicle starts, the parking lamps will light and remain on while the engine is running. The engine will continue running for 10 minutes. Repeat these steps for a 10-minute time extension. Remote start can be extended only once.

3. Before driving, press the brake pedal and then press the **ENGINE START/STOP** button to turn on all vehicle controls.

CANCELING A REMOTE START

- ▶ Press and hold the **Remote Start** button until the parking lamps turn off.

CLIMATE CONTROL OPERATION

During a remote start, the automatic climate control system will operate at the same setting as when the vehicle was last turned off.

HEATED/VENTILATED SEAT OPERATION

If the remote start heated or ventilated seat option is selected in the Vehicle Settings, the heated or ventilated seat button indicators do not illuminate and the temperature performance of the unoccupied heated or ventilated seat may be reduced during the remote start. The heated or ventilated seat turns off when the vehicle is turned on. If heated or ventilated seat operation is desired after the vehicle has been turned on, press the heated or ventilated seat button.

See Keys, Doors and Windows in your Owner Manual.

STEERING WHEEL CONTROLS

CRUISE CONTROL

 **On/Off**

SET Set Speed

With Cruise Control on, press the control bar down fully to set the cruise speed.

RES Resume Speed

With Cruise Control on, press the control bar up fully to resume the previous set speed.

+ - Adjust Speed

When active, press the control bar up (+) or down (-) lightly to increase or decrease the set speed by 1-mph increments; press up or down fully to increase or decrease the set speed to the next 5-mph interval on the speedometer.

 **Cancel**

Press to cancel cruise control without erasing the set speed from memory.

Following Gap (Adaptive Cruise Control[♦] and Forward Collision Alert[♦])

Press repeatedly to select a setting of Far, Medium, Near or, in some vehicles, Off.

See Driving and Operating in your Owner Manual.

HEATED STEERING WHEEL[♦]

 **On/Off**

See Instruments and Controls in your Owner Manual.



VOICE RECOGNITION

 **Push to Talk**

Press to interact with the OnStar, Bluetooth or Cadillac CUE system.

 **End Call/Mute**

Press to end/reject a call or mute the audio system.

See Instruments and Controls in your Owner Manual.

5-WAY CONTROL

Moves left/right, up/down, and in.

 **Left/Right**

Press to navigate to the left or right cluster display or to toggle to the next or previous menu option.

 **Up/Down**

Press the control bar up or down to scroll through a menu.

SEL Select

Press to select a highlighted menu item.

AUDIO CONTROLS

  **Volume**

Press  or  to increase or decrease the volume.

 **Next/Previous**

Press  or  to select the next or previous favorite radio station, track or file.

See Instruments and Controls in your Owner Manual.



INSTRUMENT CLUSTER



Uplevel reconfigurable cluster shown

CLUSTER DISPLAY ZONES



Use the 5-way control on the right side of the steering wheel to navigate and select between the available display zones in each cluster configuration.

UPLEVEL CLUSTER CONFIGURATIONS♦

If equipped with the 12.3-inch reconfigurable cluster, an alternative cluster display can be selected. Vsport models also feature an available Vsport-specific configuration.

1. Use the 5-way control on the steering wheel to view the Options page in one of the display zones on the cluster.
2. Press **SEL (Select)** to enter the Options menu.
3. Scroll  down to highlight Display Layout; press **SEL**.
4. Scroll  up or  down to highlight the desired display; press **SEL**.
5. Press  to exit the menu.

See Instruments and Controls in your Owner Manual.

DRIVER INFORMATION CENTER



Uplevel reconfigurable cluster shown

The Driver Information Center (DIC) on the instrument cluster displays a variety of vehicle information. The default DIC Info Displays include a digital speedometer, trip odometers, fuel range, average fuel economy, compass, oil life, and tire pressure. Additional Info Displays are available.

INFO PAGES MENU

1. Use the 5-way control on the steering wheel to view the Options page in one of the display zones on the cluster.
2. Press **SEL** to enter the Options menu.
3. Scroll  down to highlight Info Pages; press **SEL**.
4. Scroll  up or  down to move through the list of info displays.
5. Press **SEL** to select or deselect a display item.

See Instruments and Controls in your Owner Manual.

HEAD-UP DISPLAY ♦

The Head-Up Display (HUD) projects select vehicle operating information onto the windshield. The HUD controls are located on the left side of the instrument panel.



Lift up or press down to adjust the position of the image. It cannot be adjusted side-to-side.



Press to select from four displays: Speed View; Audio/Phone View; Navigation View; and Performance View.



Lift up or press down to brighten or dim the display.
Hold down to turn off the display.

See Instruments and Controls in your Owner Manual.

TOUCH SCREEN AND CONTROLS



The controls use capacitive technology – simply touch the icon/text to access a feature or adjust a function.

CADILLAC CUE MENUS

Cadillac CUE offers a variety of entertainment, communication and vehicle system options. Touch an application icon on the touch screen to access the following items. You can use simple gestures on the touch screen just as you would on a smartphone, such as tap, drag, pinch and spread, to interact with the Cadillac CUE system.



Audio

- Radio Band
- Media
- Seek Up/Down
- Tune/Play
- Browse
- Menu



Navigation

- Zoom Out
- Zoom In
- Reset
- Destination
- Map Menu
- Seek Up/Down



Phone

- Voice Recognition
- Contacts
- Recent
- Keypad
- Voice Mail
- Phones

Note: Press and hold the  **Push to Talk** steering wheel button to activate Handset Voice Recognition. See page 12.



Climate

- Driver/Vehicle Set Temperature
- Passenger Set Temperature
- Sync Temperature Settings
- A/C Mode
- Automatic Climate On/Off
- Air Distribution Settings
- Front/Rear Settings
- Fan Speed



Settings

- Time and Date
- Language
- Valet Mode
- Radio
- Vehicle
- Bluetooth
- Phone Integration
- Voice
- Display
- Return to Factory Settings

CADILLAC CUE FEATURES

Refer to your Owner Manual for important safety information about using the infotainment system while driving.

Cadillac CUE uses a Bluetooth or USB connection to link a compatible smartphone, cell phone, USB flash drive or portable audio player/iPod® to the touch screen infotainment display. It offers a variety of entertainment options, including streaming audio from the Internet, and features enhanced hands-free voice control. For assistance, call 1-855-4-CUE-NOW (1-855-428-3669) or visit www.cadillac.com/cue.

SETTING THE TIME

1. Touch **Settings** on the home page.
2. Touch **Time and Date**.
3. Touch **Set Time**.
4. Touch + or – to adjust the hours, minutes, and AM or PM.
5. Touch **< BACK** to exit the menu.

If the Auto Set feature is enabled, the time will be updated automatically as the system obtains time information from the cellular network.

STORING FAVORITES

Radio stations from all bands (AM, FM or XM♦), tone settings, phone contacts and navigation destinations♦ can be stored in any order.

1. Display the desired radio station, tone settings, navigation destination or contact.
2. Touch and drag up the  Interaction Selector at the bottom of the screen to display the favorite screen buttons.
3. Touch and hold a favorite screen button until a beep sounds.
4. Repeat the steps to store another favorite item.

CD PLAYER (DEALER-INSTALLED ACCESSORY)

If equipped, the CD player is located in the glove box.

- ▶ Touch  **Media** until CD is displayed to play a disc.

PORTABLE AUDIO DEVICES

USB ports are located at the front of the center console and in the center console storage compartment.

- ▶ Connect an iPod®, iPhone®, MP3 player, a USB flash drive or a USB mass storage device to the USB port.
- ▶ Touch **Media** until the connected device is shown. Cadillac CUE will read the device and build a list of voice commands. Search for music on-screen or by voice commands.

APPLE CARPLAY™ AND ANDROID AUTO™♦

Apple CarPlay or Android Auto capability allows use of select smartphone apps through the infotainment display. If available, a  Projection icon will appear on the home page.

1. No app is required for Apple CarPlay. Download the Android Auto app to your phone from the Google Play store.
2. Connect your compatible smartphone by plugging the phone USB cable into a USB data port. Use your device's factory-provided USB cable. Aftermarket cables may not work.
3. The  Projection icon will change to Apple CarPlay or Android Auto, depending on the phone. Apple CarPlay or Android Auto may launch automatically upon USB connection. If not, touch the Apple CarPlay or Android Auto icon on the home page.

For more information on using Apple CarPlay or Android Auto, call 1-855-4-CUE-NOW (1-855-428-3669) or visit my.cadillac.com/learn.

CADILLAC CUE FEATURES

CADILLAC COLLECTION

In-vehicle apps — connecting to music, news, weather, travel information and more — are available for download to the radio through the Collection icon on the home page.

Downloading and using the apps requires Internet connectivity and a data plan accessed through the vehicle's OnStar 4G LTE Wi-Fi hotspot, if active, or a mobile device hotspot.

Visit my.cadillac.com/learn for more information.

See your Cadillac CUE Infotainment System Manual.

BLUETOOTH® SYSTEM

Refer to your Owner Manual for important safety information about using the Bluetooth system while driving.

Before using a Bluetooth-enabled device in the vehicle, it must be paired with the in-vehicle Bluetooth system. The pairing process is disabled when the vehicle is moving. Not all devices will support all functions. Visit my.cadillac.com/learn for more information.

PAIR A PHONE

1. To use voice recognition, press the **Push to Talk** button; after the tone, say "Pair Phone," or
Use the touch screen to select **Phone > Pair Device**.
2. Start the pairing process on the phone. Locate Cadillac CUE on the phone.
3. Confirm the codes that appear on the touch screen and the phone.
4. When pairing is complete, the phone screen is displayed. Your phone book may be downloaded depending on the phone.

See your Cadillac CUE Infotainment System Manual.

ONSTAR® WITH 4G LTE AND WI-FI®

With OnStar 4G LTE and Wi-Fi, up to seven devices (smartphones, tablets and laptops) can be connected to high-speed Internet through the vehicle's built-in Wi-Fi hotspot.

- To retrieve the SSID and password for the hotspot, press the OnStar Voice Command button on the overhead console or rearview mirror, wait for the prompt, and then say "Wi-Fi settings." The information will be displayed on the screen.

For assistance or to change the SSID and password, press the blue OnStar button or call 1-888-4-ONSTAR (1-888-466-7827).

Note: See onstar.com for a detailed instruction guide, vehicle availability, details, and system limitations.

See your Cadillac CUE Infotainment System Manual.

WIRELESS CHARGING

The Wireless Charging system is located in the storage compartment behind the climate controls. To check mobile device compatibility, visit my.cadillac.com/learn.

1. The vehicle must be On.
2. Remove all objects from the charging pad.
3. Place the mobile device face up on the symbol on the charging pad.
4. Move the device slowly until the battery charging symbol displays on the Cadillac CUE touch screen, indicating the device is charging.

See your Cadillac CUE Infotainment System Manual.

VOICE RECOGNITION

Control the music source and navigation destination, and make phone calls hands-free, using the natural voice recognition system.

1. Press the  **Push to Talk** button on the steering wheel.
 2. The radio will say “Please say a command,” followed by a beep.
 3. After the beep, say what you want it to do.
- **Hands-free calling** – Example command: “Call Amanda” or “Dial 555-1212”
 - **Connected music device search** – Example command: “Play artist [name]” or “Play song [name]”
 - **Radio control** – Example command: “Tune FM 104.3” or “Tune XM Classic Vinyl”
 - **Navigation control** ♦ – Example command: “Destination Address” or “Destination Contact”
 - **Help** – Say “Help” for voice recognition assistance

HANDSET VOICE RECOGNITION

Handset Voice Recognition pass-thru allows access to the voice recognition commands on a compatible, paired cell phone; e.g., Siri or Voice Command. Visit my.cadillac.com/learn for more information.

- ▶ To activate Handset Voice Recognition, press and hold the  **Push to Talk** steering wheel button.

See your Cadillac CUE Infotainment System Manual.

NAVIGATION ♦



Enter a destination using the Single Line Destination feature. Approximate your desired destination and the auto-fill function will enter the necessary information.

1. Touch **Navigation** on the home page.
2. Touch **Destination**.
3. Type the address, intersection or road.
4. Touch **Go**.
5. Select the desired name from the generated list.
6. Touch **Go**.

See your Cadillac CUE Infotainment System Manual.

VEHICLE PERSONALIZATION



Some vehicle features can be customized using the controls on the audio system. The Vehicle Settings menu may include Climate and Air Quality; Collision/Detection Systems; Comfort and Convenience; Lighting; Power Door Locks; or Remote Locking, Unlocking and Starting.

1. Touch **Settings** on the home page.
2. Touch **Vehicle**.
3. Touch the desired menu item.
4. Touch the desired feature and setting.
5. Touch **< BACK** to exit each menu.

See Instruments and Controls in your Owner Manual.

TEEN DRIVER

Teen Driver allows multiple keys to be registered for beginning drivers. When active, the system automatically activates certain safety systems, allows setting of some features, and limits the use of others. A Report Card records vehicle data about driving behavior. When the vehicle is started with a registered key, a Driver Information Center message displays that Teen Driver is active.

- To create a Personal Identification Number, register a key, change Teen Driver settings, or access the Report Card, go to **Settings > Teen Driver**.

See your Cadillac CUE Infotainment System Manual.

VALET MODE

- To lock/unlock various features of the vehicle, select Valet Mode under Vehicle Settings and enter a passcode. It can be used when it's desired that only an authorized user has access to personalized features.

See your Cadillac CUE Infotainment System Manual.

EXTERIOR LIGHTING



EXTERIOR LIGHTING

 **Off/On**

AUTO Automatic Light Control

Automatically activates the Daytime Running Lamps (DRLs) or the headlamps and other exterior lamps depending on outside light conditions, including the IntelliBeam® automatic high-beam system♦.

 **Parking Lamps**

 **Headlamps**


ADAPTIVE FORWARD LIGHTING (AFL)♦

The AFL system pivots the headlamps left or right in the direction of travel.

Note: The AFL system operates only when the exterior lamps control knob is in the AUTO position, at speeds greater than 2 mph, and after driving a short distance to calibrate the system.

See Lighting in your Owner Manual.

WINDSHIELD WIPERS



Move the lever to operate the windshield wipers.

HI Fast Wipes

LO Slow Wipes

INT Intermittent (Rainsense™ Sensitivity)♦

Move the lever to INT to turn on the Rainsense wipers. Rotate the INT band to adjust the automatic wiper cycling based on the amount of moisture on the windshield. The wipers activate more often as the band is rotated upward.

Note: When entering an automatic car wash, it is recommended to turn off the Rainsense wipers.

OFF

 **1x Single Wipe**

 **Washer Fluid**


Pull the lever toward you to spray washer fluid on the windshield.

See Instruments and Controls in your Owner Manual.

POWER MIRRORS

POWER MIRROR ADJUSTMENT

- ▶ Move the selector switch (A) to the Left (L) or Right (R) position to select the driver's or passenger's mirror; use the four-way control (B) to adjust the mirror.



POWER FOLDING MIRRORS♦

- ▶ Press the  **Power Folding Mirrors** button (not shown) to fold/unfold the exterior mirrors.

REVERSE TILT MIRROR

The Reverse Tilt Mirror will tilt down the driver and/or passenger mirrors to improve visibility near the rear wheels when the vehicle is shifted into Reverse.

Note: To change the Reverse Tilt Mirror settings, go to Comfort and Convenience in the Vehicle Settings menu.

See Keys, Doors and Windows in your Owner Manual.

POWER DOOR LOCKS/ SAFETY LOCKS

- ▶ Press the power door  **Lock**/ **Unlock** button on the driver's door to unlock or lock all doors.
- ▶ Pull the inside door handle to unlock a door; pull the handle again to open the door.
- ▶ Press the  **Safety Locks** button on the driver's door to prevent the rear doors from opening from the inside and to disable the rear power windows.

See Keys, Doors and Windows in your Owner Manual.

ULTRAVIEW SUNROOF♦



OPEN/CLOSE THE SUNSHADE

- ▶ Press the rear or front of the  **Sunshade** switch (A) to express-open or express-close the sunshade.

OPEN/CLOSE THE SUNROOF

- ▶ Press and hold the front of the  **Sunroof** switch (B) to vent the sunroof.
- ▶ Press the rear of the  switch to express-open the sunroof to the comfort position.
- ▶ Press the front of the  switch to express-close the sunroof.

See Keys, Doors and Windows in your Owner Manual.

TRUNK RELEASE

- ▶ To open the trunk from inside the vehicle, press the  **Trunk Release** button on the driver's door.
- ▶ To open the trunk from outside the vehicle, press the touch pad above the license plate. The vehicle must be unlocked or the transmitter must be within range of the trunk.

See Keys, Doors and Windows in your Owner Manual.

MEMORY SEATS ♦



SET MEMORY POSITIONS

With the ignition on or in Accessory mode:

1. Adjust the driver's seat, power outside mirrors and the power steering column to the desired positions.
2. Press and release the **SET** button on the driver's door. A beep will sound. Immediately press and hold button **1** until two beeps sound.
3. Repeat the steps using button **2** for a second driver.

SET EXIT POSITION

1. Adjust the driver's seat, power outside mirrors and the power steering column to the desired positions.
2. Press and release the **SET** button. A beep will sound. Immediately press and hold the **Exit** button until two beeps sound.

RECALL POSITIONS

Press button **1**, **2** or **Exit**. If the vehicle is moving, press and hold the button until the seat and mirrors reach the set position.

MEMORY SEATS ♦

PASSENGER MEMORY SEAT ♦

The front passenger memory seat operates the same as the driver's seat. Use the memory seat controls, located on the passenger's door, to save and recall settings for the front passenger's seat.

ADDITIONAL DRIVER'S SEAT ADJUSTMENTS ♦

Feature Selection

- ▶ Press and release the tab on the Feature Select control knob, located on the driver's seat, to display seat adjustment features on the Cadillac CUE screen. Press and hold the tab to scroll through the adjustments.
- ▶ Use the 4-way control pad on the control knob to make adjustments up, down, forward, or rearward to the selected feature.

Massage

- ▶ With the ignition on, press the massage control on the driver's seat to recall the last massage type and intensity.

See Seats and Restraints in your Owner Manual.


ELECTRIC PARKING BRAKE

- ▶ To apply the parking brake, pull the **(P) Parking Brake** switch on the left side of the instrument panel.
- ▶ To release the parking brake, turn on the ignition, press the brake pedal, and then press the **(P)** switch.



See Driving and Operating in your Owner Manual.

AUTOMATIC TRANSMISSION TAP SHIFT



The 6-speed automatic transmission has a Tap Shift mode that allows you to shift gears similar to a manual transmission.

USING TAP SHIFT

1. Move the shift lever to the **M** (Manual Mode) position.
2. Using the buttons on the back of the steering wheel, tap the left (–) button to downshift and the right (+) button to upshift. The current gear selection will be shown in the Driver Information Center and Head-Up Display♦.

If current vehicle speed is too high or too low for the requested gear, the shift will not occur. When coming to a stop, the transmission will automatically shift to 1st gear.

See Driving and Operating in your Owner Manual.

STABILITRAK®/TRACTION CONTROL SYSTEMS

The traction control system limits wheelspin and the StabiliTrak stability control system assists with directional control of the vehicle in difficult driving conditions. Both systems turn on automatically every time the vehicle is started.

Turn off traction control if the vehicle is stuck and rocking the vehicle is required.

- ▶ Press the  **Traction Control/StabiliTrak** button on the center of the instrument panel. The  **Traction Control Off** light on the instrument cluster will illuminate.
- ▶ Press the  button again to turn on traction control.

See Driving and Operating in your Owner Manual.

AUTOMATIC PARKING ASSIST♦

Automatic Parking Assist steers the vehicle to help park in parallel or perpendicular spaces.

- ▶ Press the  **Automatic Parking Assist** button on the center of the instrument panel to begin searching for a parking space. To switch between parallel and perpendicular parking, press and hold the  button. A beep sounds and a symbol displays in the Driver Information Center when a parking space large enough is found.
- ▶ Shift the vehicle into Reverse or Drive as directed and apply the accelerator or brake as required. Be prepared to brake. Parking Complete will be displayed and a beep will sound when the parking maneuver is complete.

See Driving and Operating in your Owner Manual.

DRIVER ASSISTANCE SYSTEMS

The driver assistance systems use advanced technologies to help avoid collisions by providing visual, audible and/or seat vibration alerts.

DRIVER AWARENESS PACKAGE

Safety Alert Seat ♦ – The driver's seat pulses, left side, right side, or simultaneously, to alert the driver of potential hazards.

- ▶ Audible alerts may be selected instead of Safety Alert Seat pulsing alerts. To change the alert setting, go to **Settings > Vehicle > Collision/Detection Systems > Alert Type**.

Forward Collision Alert ♦ – The  **Vehicle Ahead** indicator is green on the instrument cluster when a vehicle is detected and is amber when following a vehicle ahead much too closely. When approaching a vehicle directly ahead too rapidly, a red alert flashes on the windshield and the driver's seat pulses.

- ▶ To set the alert timing or turn the system off, press the  **Following Gap** button on the left side of the steering wheel.

Side Blind Zone Alert ♦ – While driving, a  warning symbol displays on the left or right side mirror when a vehicle is detected in that side blind spot area.

- ▶ To turn the system on or off, go to **Settings > Vehicle > Collision/Detection Systems > Side Blind Zone Alert**.

Rear Cross Traffic Alert ♦ – With the vehicle in Reverse, the Surround Vision system displays a bird's-eye view of the vehicle and a view of the area behind the vehicle on the touch screen. A warning of approaching cross traffic is displayed on the touch screen and the left or right side of the driver's seat pulses to indicate the direction of the cross traffic.

- ▶ To turn the system on or off, press the  **Parking Assist** button on the center of the instrument panel (this also will turn the Parking Assist and Rear Automatic Braking systems on/off).

Lane Keep Assist (Front-Wheel-Drive models only) ♦ – The  **Lane Keep Assist** indicator is green on the instrument cluster when a marked lane is detected ahead. If the vehicle crosses the detected lane, the indicator changes to amber and the system gently turns the steering wheel to assist in keeping the vehicle in the lane. Turn the steering wheel to override Lane Keep Assist.

- ▶ To turn the system on or off, press the  **Lane Keep Assist** button on the center of the instrument panel.

Lane Departure Warning (All-Wheel-Drive models only) ♦ – When crossing a detected lane marking without using a turn signal, the amber  **Lane Departure Warning** symbol flashes on the instrument cluster and the left or right side of the driver's seat pulses. Turn the steering wheel to suppress Lane Departure Warning.

- ▶ To turn the system on or off, press the  **Lane Departure Warning** button on the center of the instrument panel.

DRIVER ASSIST PACKAGE (INCLUDES DRIVER AWARENESS PACKAGE)

Front and Rear Automatic Braking ♦ – Automatically applies the brakes in potential collision situations to help reduce damage or help avoid collisions with vehicles directly ahead or behind, and with some objects behind.

- ▶ To turn the Front Automatic Braking system on or off, go to **Settings > Vehicle > Collision/Detection Systems > Auto Collision Preparation**.
- ▶ To turn the Rear Automatic Braking system on or off, press the  **Parking Assist** button on the center of the instrument panel (this also will turn the Parking Assist and Rear Cross Traffic Alert systems on/off).

DRIVER ASSISTANCE SYSTEMS

DRIVER ASSIST PACKAGE (INCLUDES DRIVER AWARENESS PACKAGE)

Adaptive Cruise Control♦ – If a vehicle is detected ahead, the vehicle accelerates or brakes moderately to maintain the driver-selected cruise speed and following gap.

- ▶ To set a following gap, press the  **Following Gap** button on the left side of the steering wheel.



See Driving and Operating in your Owner Manual.

SURROUND VISION♦

The Surround Vision system displays an image of the area surrounding the vehicle along with the front or rear camera views on the Cadillac CUE touch screen.

The system operates automatically when the car is shifted into Reverse or from Reverse to Drive when the vehicle is moving slower than 5 mph. Pressing the Cadillac CUE  **Home** button or the touch screen will turn off the system.

See Driving and Operating in your Owner Manual.

OVER-THE-AIR SOFTWARE UPDATES♦

The infotainment system can download and install vehicle software updates over a wireless Internet connection, which can be accessed through the vehicle's OnStar 4G LTE Wi-Fi hotspot, if active, or a secured Wi-Fi hotspot.

- ▶ The system will prompt high priority updates to be downloaded and installed.
- ▶ To check for updates manually, go to **Settings > Software Information > System Update**. Follow the on-screen prompts.

Visit my.cadillac.com/learn for more information.

See Instruments and Controls in your Owner Manual.

TIRES

TIRE PRESSURE MONITOR

The  **Low Tire Pressure** warning light on the instrument cluster illuminates when one or more of the vehicle's tires is significantly underinflated. Fill the tires to the proper tire pressures. The proper tire pressures for the vehicle are listed on the Tire and Loading Information label, located below the driver's door latch. Current tire pressures can be viewed in the Driver Information Center.

Refer to your Owner Manual for additional information about normal monthly tire maintenance.

TIRE SEALANT AND COMPRESSOR KIT♦

The tire sealant and compressor kit can be used to temporarily seal small punctures in the tread area of the tire. The kit is located under the trunk floor. Refer to the kit instructions for complete operating information.

See Vehicle Care in your Owner Manual.

OWNER PRIVILEGES™

ROADSIDE ASSISTANCE

1-800-224-1400

TTY Users: 1-888-889-2438

Roadside Assistance provides every Cadillac owner with the advantage of contacting a Cadillac advisor and, when appropriate, a Cadillac-trained dealer technician who can provide on-site services, including towing service, battery jump-starting, lock-out service, fuel delivery and flat tire assistance. Services are provided for up to 6 years/70,000 miles, whichever occurs first.

Roadside Assistance and OnStar®: If you have a current OnStar subscription, press the OnStar button and the vehicle will send your current GPS location to an OnStar Advisor who will speak to you, assess your problem, contact Roadside Assistance and relay your exact location so you will get the help you need.

CUSTOMER ASSISTANCE

1-800-458-8006

Cadillac Customer Assistance is available anytime to answer questions or provide additional information.

CADILLAC ONLINE OWNER CENTER

Create an account at my.cadillac.com for access to an online Owner Manual, helpful how-to videos, your service history and warranty status, OnStar reports (active OnStar account required), and more.

myCADILLAC and ONSTAR MOBILE APPS

The myCadillac mobile app connects owners to a variety of vehicle information and services, such as a searchable Owner Manual, real-time fuel information and Roadside Assistance.

Download the OnStar RemoteLink mobile app and enjoy select features for 5 years from date of vehicle delivery. With a compatible mobile device, owners can access many services, including remotely starting/stopping the vehicle, locking/unlocking the doors, and locating the vehicle on a map (on properly equipped vehicles). To learn more about OnStar services, press the blue OnStar button, call 1-888-466-7827, visit onstar.com or refer to your Owner Manual.

Download the mobile apps from your compatible mobile device's app store.



CADILLAC CUE SUPPORT

**1-885-4-CUE-NOW
(1-855-428-3669)**

For information or assistance operating the Cadillac CUE infotainment system, call Cadillac CUE Support or visit www.cadillac.com/cue.

We recommend always using ACDelco or genuine GM service parts.

Certain restrictions, precautions and safety procedures apply to your vehicle. Please read your Owner Manual for complete instructions. All information contained herein is based on the latest information available at the time of printing and is subject to change without notice. Copyright 2016 by General Motors. All rights reserved.

