Scheduled Maintenance

Follow Schedule 1 if the vehicle is operated mainly where none of the following conditions apply.
If any do apply, follow Schedule 2 (Puerto Rico residents follow Schedule 2).

- Repeated short-distance driving
- Driving in dusty conditions
- Driving with an extended use of brakes
- Driving in areas where salt or other corrosive materials are being used
- Driving on rough or muddy roads
- Extended periods of idling or low-speed operation
- Driving for a prolonged period in cold temperatures or extremely humid climates

NOTE
After the described period, continue to follow the described maintenance at the recommended intervals.

I Inspect and repair, clean, adjust, or replace if necessary. (Oil-permeated air filter cannot be cleaned using the air-blow method.)
R Replace

Schedule 1

MAINTENANCE INTERVALS / MAINTENANCE ITEM		Number of months or km (miles), whichever comes first							
	Months	6	12	18	24	30	36	42	48
	×1000 km	12	24	36	48	60	72	84	96
	(×1000 miles)	(7.5)	(15)	(22.5)	(30)	(37.5)	(45)	(52.5)	(60)
Engine valve clearance (Miller Cycle Engine V6 DOHC)									I
Engine oil		R	R	R	R	R	R	R	R
Engine oil filter		R	R	R	R	R	R	R	R
Drive belts (tension)	2.5 liter V6 DOHC				I				I
	Miller Cycle Engine V6 DOHC	Replace every 168,000 km (105,000 miles)							
Engine timing belt	2.5 liter V6 DOHC	Inspect at 96,000km (60,000 miles) Replace every 168,000 km (105,000 miles)							
	Miller Cycle Engine V6 DOHC	Replace every 96,000 km (60,000 miles)							
Hoses and tubes for emission									I*1
Air filter					R				R
Spark plugs	2.5 liter V6 DOHC	Replace every 48,000 km (30,000 miles)							
	Miller Cycle Engine V6 DOHC	Replace every 96,000 km (60,000 miles)							
Cooling system					I				I
Engine coolant		Replace at first 72,000 km (45,000 miles) or 36 months; after that, every 48,000 km (30,000 miles) or 24 months							

*1 According to state and federal regulations, failure to perform maintenance on these items will not void your emissions warranties. However, Mazda recommends that all maintenance services be performed at the recommended time or kilometrage (mileage) period to ensure long-term reliability.

Schedule 1 (Cont'd)

I Inspect and repair, clean, adjust, or replace if necessary.

MAINTENANCE INTERVALS / MAINTENANCE ITEM	Number of months or km (miles), whichever comes first								
	Months	6	12	18	24	30	36	42	48
	×1000 km	12	24	36	48	60	72	84	96
	(×1000 miles)	(7.5)	(15)	(22.5)	(30)	(37.5)	(45)	(52.5)	(60)
Idle speed					I				I
Fuel lines and hoses					I*1				I*1
Brake lines, hoses and connections					I				I
Disc brakes					I				I
Steering operation and linkages					I				I
Front and rear suspension ball joints					I				I
Drive shaft dust boots					I				I
Bolts and nuts on chassis and body					I				I
Body inspection (paint, corrosion)		I	I	I	I	I	I	I	I
Exhaust system heat shields					I				I
Air-conditioner compressor operation			I		I		I		I
Air-conditioner air-filter (if installed)		Replace once a year or every 20,000 km (12,000 miles)							
Automatic transaxle fluid level					I				I

*1 According to state and federal regulations, failure to perform maintenance on these items will not void your emissions warranties. However, Mazda recommends that all maintenance services be performed at the recommended time or kilometrage (mileage) period to ensure long-term reliability.

I Inspect and repair, clean, adjust, or replace if necessary. (Oil-permeated air filter cannot be cleaned using the air-blow method.)
R Replace

Schedule 2

MAINTENANCE ITEM / MAINTENANCE INTERVALS		Number of months or km (miles), whichever comes first											
	Months	4	8	12	16	20	24	28	32	36	40	44	48
	×1000 km	8	16	24	32	40	48	56	64	72	80	88	96
	(×1000 miles)	(5)	(10)	(15)	(20)	(25)	(30)	(35)	(40)	(45)	(50)	(55)	(60)
Engine valve clearance (Miller Cycle Engine V6 DOHC)													I
Engine oil	Except Puerto Rico	R	R	R	R	R	R	R	R	R	R	R	R
	Puerto Rico	Replace every 5,000 km (3,000 miles) or 3 months											
Engine oil filter		R	R	R	R	R	R	R	R	R	R	R	R
Drive belts (tension)	2.5 liter V6 DOHC						I						I
	Miller Cycle Engine V6 DOHC	Replace every 168,000 km (105,000 miles)											
Engine timing belt	2.5 liter V6 DOHC*2	Inspect at 96,000 km (60,000 miles) Replace every 168,000 km (105,000 miles)											
	Miller Cycle Engine V6 DOHC	Replace every 96,000 km (60,000 miles)											
Hoses and tubes for emission													I*1
Air filter				I*1			R			I*1			R
Spark plugs	2.5 liter V6 DOHC	Replace every 48,000 km (30,000 miles)											
	Miller Cycle Engine V6 DOHC	Replace every 96,000 km (60,000 miles)											
Cooling system							I						I
Engine coolant		Replace at first 72,000 km (45,000 miles) or 36 months; after that, every 48,000 km (30,000 miles) or 24 months											

*1 According to state and federal regulations, failure to perform maintenance on these items will not void your emissions warranties. However, Mazda recommends that all maintenance services be performed at the recommended time or kilometrage (mileage) period to ensure long-term reliability.

*2 If the vehicle is operated in cold districts {below −18°C (0°F)}, replace the timing belt at 96,000 km (60,000 miles).

Schedule 2 (Cont'd)

I Inspect and repair, clean, adjust, or replace if necessary.

MAINTENANCE INTERVALS / MAINTENANCE ITEM	Number of months or km (miles), whichever comes first											
Months	4	8	12	16	20	24	28	32	36	40	44	48
×1000 km	8	16	24	32	40	48	56	64	72	80	88	96
(×1000 miles)	(5)	(10)	(15)	(20)	(25)	(30)	(35)	(40)	(45)	(50)	(55)	(60)
Engine coolant level	I	I	I	I	I	I	I	I	I	I	I	I
Idle speed						I						I
Fuel lines and hoses						I*1						I*1
Brake lines, hoses and connections						I						I
Brake fluid level	I	I	I	I	I	I	I	I	I	I	I	I
Disc brakes			I			I			I			I
Tire inflation pressure and tire wear	I	I	I	I	I	I	I	I	I	I	I	I
Steering operation and linkages						I						I
Power steering fluid level	I	I	I	I	I	I	I	I	I	I	I	I
Front and rear suspension ball joints						I						I
Bolts and nuts on chassis and body			I			I			I			I
Body inspection (paint, corrosion)	I	I	I	I	I	I	I	I	I	I	I	I
Exhaust system heat shields						I						I
Drive shaft dust boots						I						I
Air-conditioner compressor operation			I			I			I			I
Air-conditioner air-filter (if installed)	Replace once a year or every 20,000 km (12,000 miles)											
Automatic transaxle fluid level						I						I
Function of all lights	I	I	I	I	I	I	I	I	I	I	I	I
Washer fluid level	I	I	I	I	I	I	I	I	I	I	I	I

*1 According to state and federal regulations, failure to perform maintenance on these items will not void your emissions warranties. However, Mazda recommends that all maintenance services be performed at the recommended time or kilometrage (mileage) period to ensure long-term reliability.