Owner's Manual

2019 MDX

Sport Hybrid

⚠WARNING

California Proposition 65 Warning

Operating, servicing and maintaining a passenger vehicle or off-highway motor vehicle can expose you to chemicals including engine exhaust, carbon monoxide, phthalates, and lead, which are known to the State of California to cause cancer and birth defects or other reproductive harm. To minimize exposure, avoid breathing exhaust, do not idle the engine except as necessary, service your vehicle in a well-ventilated area and wear gloves or wash your hands frequently when servicing your vehicle. For more information go to *www.P65Warnings.ca.gov/passenger-vehicle*.

Event Data Recorders

This vehicle is equipped with an event data recorder (EDR). The main purpose of an EDR is to record, in certain crash or near crash-like situations, such as an air bag deployment or hitting a road obstacle, data that will assist in understanding how a vehicle's systems performed. **The EDR is designed to record data related to vehicle dynamics and safety systems for a short period of time, typically 30 seconds or less. The EDR in this vehicle is designed to record such data as:**

- **How various systems in your vehicle were operating;**
- **Whether or not the driver and passenger safety belts were buckled/fastened;**
- **How far (if at all) the driver was depressing the accelerator and/or brake pedal; and,**
- **How fast the vehicle was traveling.**

These data can help provide a better understanding of the circumstances in which crashes and injuries occur. NOTE: EDR data are recorded by your vehicle only if a non-trivial crash situation occurs; no data are recorded by the EDR under normal driving conditions and no personal data (e.g., name, gender, age, and crash location) are recorded. However, other parties, such as law enforcement, could combine the EDR data with the type of personally identifying data routinely acquired during a crash investigation.

To read data recorded by an EDR, special equipment is required, and access to the vehicle or the EDR is needed. In addition to the vehicle manufacturer, other parties, such as law enforcement, that have the special equipment, can read the information if they have access to the vehicle or the EDR.

The data belongs to the vehicle owner and may not be accessed by anyone else except as legally required or with the permission of the vehicle owner.

Service Diagnostic Recorders

This vehicle is equipped with service-related devices that record information about powertrain performance. The data can be used to verify emissions law requirements and/or help technicians diagnose and solve service problems. It may also be combined with data from other sources for research purposes, but it remains confidential. Some diagnostic and maintenance information is uploaded to Acura upon vehicle start up.

California Perchlorate Contamination Prevention Act

The airbags, seat belt tensioners, and CR type batteries in this vehicle may contain perchlorate materials - special handling may apply. See *www.dtsc.ca.gov/hazardouswaste/perchlorate/*

As you read this manual, you will find information that is preceded by a NOTICE symbol. This information is intended to help you avoid damage to your vehicle, other property, or the environment.

Software End User License Agreement

Your vehicle comes equipped with software, which is governed by the End User License Agreement in Owner's Manual, and which contains a binding arbitration clause. Please refer to the End User License Agreement for the terms and conditions governing your use of the installed software, as well as the applications, services, functions, and content provided through the software. Your use of the installed software will serve as your consent to the terms and conditions of the End User License Agreement.
You may opt out within 30 days of your initial use of the Software by sending a signed, written notice to HONDA at American Honda Motor Co., Inc. Honda Automobile Customer Services Mail Stop 100-5E-8F, 1919 Torrance Blvd. Torrance, CA 90501-2746.

Privacy Notice

This vehicle may share location and usage information. To manage this setting, visit *www.acuralink.com/vehicle-data-choices*.

A Few Words About Safety

Your safety, and the safety of others, is very important. And operating this vehicle safely is an important responsibility.

To help you make informed decisions about safety, we have provided operating procedures and other information on labels and in this manual. This information alerts you to potential hazards that could hurt you or others.

Of course, it is not practical or possible to warn you about all the hazards associated with operating or maintaining your vehicle. You must use your own good judgment.

You will find this important safety information in a variety of forms, including:

- **Safety Labels** - on the vehicle.
- **Safety Messages** - preceded by a safety alert symbol ⚠ and one of three signal words: **DANGER**, **WARNING**, or **CAUTION**. These signal words mean:

⚠DANGER	You WILL be KILLED or SERIOUSLY HURT if you don't follow instructions.
⚠WARNING	You CAN be KILLED or SERIOUSLY HURT if you don't follow instructions.
⚠CAUTION	You CAN be HURT if you don't follow instructions.

- **Safety Headings** - such as Important Safety Precautions.
- **Safety Section** - such as Safe Driving.
- **Instructions** - how to use this vehicle correctly and safely.

This entire book is filled with important safety information - please read it carefully.

This owner's manual should be considered a permanent part of the vehicle and should remain with the vehicle when it is sold.

This owner's manual covers all models of your vehicle. You may find descriptions of equipment and features that are not on your particular model.

Images throughout this owner's manual (including the front cover) represent features and equipment that are available on some, but not all, models. Your particular model may not have some of these features.

This owner's manual is for vehicles sold in the United States and Canada.

The information and specifications included in this publication were in effect at the time of approval for printing. Honda Motor Co., Ltd. reserves the right, however, to discontinue or change specifications or design at any time without notice and without incurring any obligation.

Safe Driving P. 33

For Safe Driving P. 34 | Seat Belts P. 39 | Airbags P. 47

Instrument Panel P. 83

Indicators P. 84 | Gauges and Multi-Information Display (MID) P. 123

Controls P. 141

Clock P. 142 | Locking and Unlocking the Doors P. 143
Moonroof P. 171
Adjusting the Seats P. 195

Features P. 235

Audio System P. 236 | Audio System Basic Operation P. 243
Rear Entertainment System (RES)* P. 342 | Customized Features P. 362

Driving P. 447

Before Driving P. 448 | Towing a Trailer P. 454
Parking Your Vehicle P. 534 | Multi-View Rear Camera* P. 544
Fuel Economy and CO_2 Emissions P. 559

Maintenance P. 561

Before Performing Maintenance P. 562 | Maintenance Minder™ P. 565
Checking and Maintaining Wiper Blades P. 587
Remote Control and Wireless Headphone Care* P. 602

Handling the Unexpected P. 613

Tools P. 614 | If a Tire Goes Flat P. 615
Indicator, Coming On/Blinking P. 641 | Fuses P. 647
When You Cannot Open the Tailgate P. 658

Information P. 661

Specifications P. 662 | Identification Numbers P. 664
Emissions Testing P. 667 | Warranty Coverages P. 668

Contents

Quick Reference Guide P. 4

Child Safety P. 62
Exhaust Gas Hazard P. 80
Safety Labels P. 81

Safe Driving P. 33

Instrument Panel P. 83

Opening and Closing the Tailgate P. 158
Security System P. 166
Opening and Closing the Windows P. 169
Operating the Switches Around the Steering Wheel P. 172
Adjusting the Mirrors P. 192
Interior Lights/Interior Convenience Items P. 210
Climate Control System P. 223

Controls P. 141

Audio Error Messages P. 315
General Information on the Audio System P. 323
HomeLink® Universal Transceiver P. 394
Bluetooth® HandsFreeLink® P. 397
AcuraLink® P. 438

Features P. 235

Off-Highway Driving Guidelines P. 455
When Driving P. 457
Braking P. 517
Surround View Camera System* P. 546
Refueling P. 556

Driving P. 447

Maintenance P. 561

Maintenance Under the Hood P. 569
Replacing Light Bulbs P. 582
Checking and Maintaining Tires P. 591
12-Volt Battery P. 600
Remote Transmitter Care P. 601
Climate Control System Maintenance P. 604
Cleaning P. 605
Accessories and Modifications P. 611

Handling the Unexpected P. 613


Power System Won't Start P. 634
Jump Starting P. 637
Overheating P. 639
Emergency Towing P. 656
When You Cannot Unlock the Fuel Fill Door P. 657
Refueling P. 659

Information P. 661


Devices that Emit Radio Waves P. 665
Reporting Safety Defects P. 666
Authorized Manuals P. 670
Client Service Information P. 671

Index P. 675

Visual Index




- System Indicators P. 84
- Gauges P. 123
- Multi-Information Display (MID) P. 125
- (Vehicle Stability Assist® (VSA®) System OFF) Button P. 506
- Parking Sensor System Button P. 537
- Collision Mitigation Braking System™ (CMBS™) OFF Button P. 528
- Headlight Washer Button* P. 186
- Heated Windshield Button* P. 188
- Road Departure Mitigation (RDM) Button P. 494
- Automatic Brake Hold Button P. 521
- Electric Parking Brake Switch P. 517
- Information Screen P. 248
- Navigation System
  See the Navigation System Manual
- Hazard Warning Button
- On Demand Multi-Use Display™
- Audio System P. 236
- Climate Control System P. 223
- Rear Defogger/Heated Door Mirror Button P. 188
- (Surround View Camera) Button* P. 547
- POWER Button P. 172
- Steering Wheel Adjustments P. 191




- Headlights/Turn Signals P. 175, 176
- Fog Lights* P. 179
- Paddle Shifter (Shift down) P. 472
- Audio Remote Controls P. 241
- Brightness Control P. 187
- Paddle Shifter (Shift up) P. 472
- Wipers/Washers P. 183
- Adaptive Cruise Control (ACC) with Low Speed Follow (LSF) Buttons P. 478
- Multi-function Steering-wheel Controls P. 125
- TRIP Button P. 126
- Interval Button P. 486
- Lane Keeping Assist System (LKAS) Button P. 499
- Horn (Press an area around .)
- Heated Steering Wheel Button* P. 220
- Voice Control Buttons P. 258
- *Bluetooth*® HandsFreeLink® System Voice Control Buttons P. 397

* Not available on all models

Visual Index




Power Window Switches P. 169
Power Door Lock Master Switch P. 156
Door Mirror Controls P. 193
Memory Buttons P. 190
SET Button P. 190
Power Tailgate Button P. 161
Fuel Fill Door Release Button P. 557
Rearview Mirror P. 192
Driver's Front Airbag P. 50
Dynamic Mode Button P. 474
Passenger's Front Airbag P. 50
Shift Button
Electronic Gear Selector P. 465
Glove Box P. 212
Passenger's Side Interior Fuse Box P. 653
Accessory Power Socket P. 217
Accessory Power Socket* P. 217
Auxiliary Input Jack P. 240
USB Ports P. 237
AC Power Outlet* P. 218
Driver's Knee Airbag P. 54
Hood Release Handle P. 570
Driver's Side Interior Fuse Box P. 650
Driver's Side Interior Fuse Box P. 651




* Not available on all models

Visual Index



- Maintenance Under the Hood P. 569
- Windshield Wipers P. 183, 587
- Power Door Mirrors P. 193
- Side Turn Signal Lights P. 175, 582
- Door Lock/Unlock Control P. 145
- Headlights P. 176, 582
- Side Marker Lights P. 176, 582
- Front Turn Signal/Parking Lights P. 175, 582
- Tires P. 591, 615
- Fog Lights* P. 179, 582



- How to Refuel P. 557
- High-Mount Brake Light P. 586
- Opening/Closing the Tailgate P. 165
- Rear Wiper P. 185, 589
- Tailgate Outer Handle P. 165
- Multi-View Rear Camera* P. 544
- Back-Up Lights P. 585
- Brake Light and Rear Turn Signal Lights P. 583
- Rear Side Marker Lights P. 584
- Taillights P. 584

SPORT HYBRID Super Handling-All Wheel Drive™ (SPORT HYBRID SH-AWD®)

Your SPORT HYBRID SH-AWD® vehicle uses both electric motors and a gasoline engine as propulsion sources, with electric motors receiving electricity from an internal High Voltage battery.

Operating mode	EV Launch*	Engine Drive	EV Cruising*	Power Acceleration
Driving Speed	Launch Acceleration: • Rear Motor Drive	Gentle Acceleration: • Engine Drive	Low Speed Cruise: • Rear Motor Drive	Aggressive Acceleration: • Engine Drive • Motor Assist
Power Flow Monitor				
Electric motors	Drive	- / Drive	Drive	Drive
Generators	-	Generate / -	-	-
Engine	Stopped	Running	Stopped	Running
High Voltage battery	Discharges	Charges/Discharges	Discharges	Discharges

*: When Integrated Dynamics System is in SPORT+ mode, EV Launch and EV Cruising cannot be operated.
*: Operating paddle shifters when the gear position is in D or S cancels EV Launch and EV Cruising.

Operating mode	Engine Cruising	Regeneration	AWD Mode
Driving Speed	High Speed Cruise: • Engine Drive	Deceleration: • Front & Rear Regeneration	Slippery Condition: • Engine Drive • Front Generation • Rear Motor Drive
Power Flow Monitor			
Electric motors	Drive	Regenerate	Drive
Generators	Generate	Regenerate	Generate
Engine	Running	Stopped	Running
High Voltage battery	Charges/Discharges	Charges	Charges/Discharges

* Not available on all models

Energy Efficiency

As with a gasoline-powered vehicle, hybrid vehicle fuel efficiency and driving range is most impacted by your driving style. Aggressive acceleration and high-speed driving can easily trigger the system to switch the propulsion source to the gasoline-powered engine.
In addition, heavy climate control system use negatively affects vehicle range and efficiency. Either of these use patterns will more quickly reduce the High Voltage battery's state of charge.

Battery Types

There are two types of batteries used in this vehicle: a standard 12-volt battery that powers the airbags, the interior and exterior lights, and other standard 12-volt systems; and a high voltage battery that is used to power the propulsion motors and recharge the 12-volt battery.

Regenerative Energy and Regenerative Braking

When decelerating without the accelerator being depressed or the brake pedal being applied, or while driving downhill, the electric motors act as generators that recover a portion of the electrical energy that was used to accelerate the vehicle. This regenerative braking slows the vehicle in a manner similar to engine braking in a gasoline-powered vehicle.
When the high voltage battery is fully charged or its condition is affected by extreme temperatures or other factors, regenerative braking may not work.

Auto Engine Stop/Start

Your vehicle's gasoline engine will automatically stop and start during vehicle operation as needed to meet driving and battery conditions. These are some examples that could cause the gasoline engine to automatically start.

In the following cases, however, Auto Engine Stop may not activate.

- When the Integrated Dynamics System is in SPORT+ mode.
- The vehicle momentarily needs additional power for aggressive acceleration, driving uphill, or driving at high speeds.
- The climate control system is in heavy use.
- The High Voltage battery temperature is high or low.
- The High Voltage battery state of charge is low.
- When the gear position is in S or R.

Sounds Unique to the SPORT HYBRID SH-AWD® System

When you first start driving this vehicle, you will likely hear some unfamiliar sounds, particularly when you turn on the power system, or while you are driving or accelerating from a stop. Some of these sounds are unique to this vehicle's powertrain, fuel, and climate control systems; others are similar to sounds generated by conventional automobiles that typically are masked by louder noises absent from a vehicle of this design.

These sounds are not a cause for concern, and you will soon recognize them as normal and thus be able to detect any new or unusual noise should one develop.

Safety Precautions



Do not touch the High Voltage system

Attempting to take a High Voltage system component apart or disconnect one of its wires can cause severe electrical shock. Make sure that any maintenance or repairs to the High Voltage system is performed by an Acura dealer.

If a crash occurs

● Be careful of electric shock hazard.

▶If a severe crash damages your vehicle's High Voltage system, there is a possibility of electrical shock due to exposed High Voltage components or wires. If this happens, do not touch any of the High Voltage system components or any of its orange wires.

● Avoid contact with High Voltage battery fluid.

▶The High Voltage battery contains a flammable electrolyte that could leak as a result of a severe crash. Avoid skin or eye contact with the electrolyte as it is corrosive. If you accidentally come into contact with the electrolyte, rinse the exposed skin or flush your eyes with copious amounts of water for at least five minutes, and seek medical attention immediately.

● Use a fire extinguisher for an electrical fire.

▶Attempting to extinguish an electrical fire with a small quantity of water, from a garden hose for instance, can be dangerous.

● Anytime the vehicle is damaged in a crash, have it repaired by an Acura dealer.

Emergency Shutdown System for the High Voltage System

If the vehicle is involved in a crash, the emergency shutdown system will activate depending on the severity of the impact. When the system activates, the High Voltage system automatically shuts down, and the vehicle can no longer move under its own power. To return the High Voltage system back to normal operation, consult an Acura dealer.

Acura collects and recycles High Voltage batteries used in its vehicles – consult an Acura dealer for more information.


Safe Driving P. 33

Airbags P. 47

- Your vehicle is fitted with airbags to help protect you and your passengers during a moderate-to-severe collision.

Child Safety P. 62

- All children 12 and younger should be seated in the rear seat.
- Smaller children should be properly restrained in a forward-facing child seat.
- Infants must be properly restrained in a rear-facing child seat.



Exhaust Gas Hazard P. 80

- Your vehicle emits dangerous exhaust gases that contain carbon monoxide. Do not run the engine in confined spaces where carbon monoxide gas can accumulate.

Seat Belts P. 39

- Fasten your seat belt and sit upright well back in the seat.
- Check that your passengers are wearing their seat belts correctly.



Fasten your lap belt as low as possible.

Before Driving Checklist P. 38


- Before driving, check that the front seats, head restraints, steering wheel, and mirrors have been properly adjusted.

Instrument Panel P. 83

Gauges P. 123/Multi-Information Display (MID) P. 125/System Indicators P. 84

System Indicators

- Blind spot information System Indicator
- Speed-sensitive Electric Power Steering (EPS) System Indicator
- Malfunction Indicator Lamp
- Low Oil Pressure Indicator
- SPORT+ **SPORT+** Mode Indicator
- READY **READY** Indicator
- Vehicle Stability Assist® (VSA®) System Indicator
- Vehicle Stability Assist® (VSA®) OFF Indicator
- Immobilizer System Indicator
- Keyless Access System Indicator
- 12-Volt Battery Charging System Indicator
- System Message Indicator
- BRAKE HOLD Automatic Brake Hold System Indicator
- HOLD U.S. / Canada Automatic Brake Hold Indicator



System Indicators

- Low Tire Pressure/ TPMS Indicator
- High Temperature Indicator
- Low Temperature Indicator

Lights Indicators

- Lights On Indicator
- High Beam Indicator
- Fog Light Indicator*
- Auto High-Beam Indicator

System Indicators

- Electric Parking Brake System Indicator
- PARK U.S. / Canada Electric Parking Brake Indicator
- Turn Signal and Hazard Warning Indicators
- Supplemental Restraint System Indicator
- ABS **(ABS)** Indicator
- Collision Mitigation Braking System™ (CMBS™) Indicator
- Road Departure Mitigation (RDM) Indicator
- POWER SYSTEM **POWER SYSTEM** Indicator
- BRAKE U.S. / Canada Brake System Indicator (Red)
- BRAKE SYSTEM U.S. / Canada Brake System Indicator (Amber)
- Low Fuel Indicator
- Seat Belt Reminder Indicator

Controls P. 141

Clock P. 142



1. Enter the **Clock Adjustment** screen.
   Adjusting the Clock P. 142
2. Rotate ⟲ to change hour, then move ○▷.
3. Rotate ⟲ to change minute, then press ⊙.

The navigation system receives signals from GPS satellites, updating the clock automatically.


POWER Button P. 172

Press the button to change the vehicle's power mode.




Turn Signals P. 175

Turn Signal Control Lever



Lights P. 176

Light Control Switches




* Not available on all models

Wipers and Washers

P. 183

Wiper/Washer Control Lever




AUTO should always be turned **OFF** before the following situations in order to prevent severe damage to the wiper system:

- Cleaning the windshield
- Driving through a car wash
- No rain present

Steering Wheel P. 191

- To adjust, push and hold the adjustment switch to move the steering wheel to the desired position.




Unlocking the Front Doors from the Inside

P. 155

- Pull either front door inner handle to unlock and open it at the same time.



Tailgate P. 165, 160




- Press the tailgate outer handle to unlock and open the tailgate when you carry the keyless access remote.
- Press the power tailgate button on the driver's door or the remote transmitter to open and close the power tailgate.

Power Door Mirrors


P. 193

- With the power mode in ON, move the selector switch to **L** or **R**.
- Push the appropriate edge of the adjustment switch to adjust the mirror.
- Press the fold button to fold the door mirrors.




Power Windows P. 169

- With the power mode in ON, open and close the power windows.
- If the power window lock button is in the off position, each passenger's window can be opened and closed with its own switch.
- If the power window lock button is in the on position (indicator is on), each passenger's window switch is disabled.



Climate Control System P. 223


- Press the **AUTO** button to activate the climate control system.
- Press the ON/OFF button to turn the system on or off.
- Press the FRONT button or select the **Front** icon to defrost the windshield.



- Air flows from dashboard vents.
- Air flows from floor and dashboard vents.
- Air flows from floor vents.
- Air flows from floor and windshield defroster vents.

Rear Climate Control P. 233


- Press the **AUTO** button to activate the rear climate control system.
- Press the ON/OFF button to turn the system on or off.



- Air flows from the rear console vents.
- Air flow from the rear console vents and floor vents.
- Air flows from the rear floor vents.


Features P. 235

Audio System P. 243 For navigation system operation See the Navigation System Manual




*1:Icons that appear on the screen vary by the source selected.

Models with rear entertainment system



Audio Remote Controls

P. 241



- **SOURCE** Button
  Press to change the audio mode: FM/AM/SiriusXM®/CD/Rear DVD*/HDD/USB/iPod/Apple CarPlay/Android Auto/*Bluetooth*® Audio/Pandora®*/AUX.
- Left Selector Wheel
  Roll to adjust the volume up/down.
  Radio: Move to a side to change the preset station.
  Move to a side and hold to select the next or previous strong station.
  CD/HDD/USB device:
  Move to a side to skip to the beginning of the next song or return to the beginning of the current song.
  Move to a side and hold to change a folder.

Driving P. 447

Electronic Gear Selector P. 465

- Always depress the brake pedal before selecting P or changing the gear position from P.
- Select P and depress the brake pedal when turning on the power.

Gear selection

Gear Position Indicator
The gear position indicator and the shift button indicator indicate the current gear selection.



Gear Position Indicator





P **Park**
Press the P button.
Used when parking or before turning the power on or off.
Transmission is locked.

R **Reverse**
Pull back the R button.
Used when reversing.

N **Neutral**
Press the N button.
Transmission is not locked.


D **Drive**
Press the D/S button.
Used for normal driving.
Sequential shift mode can be used temporarily.

S **Drive (S)**
Press the D/S button twice.
Sequential shift mode can be used.

* Not available on all models

Paddle Shifters P. 472

Paddle shifters allow you to shift gears much like a manual transmission (1st through 7th). This is useful for regenerative braking.




When the transmission is in D

- The transmission will shift back to automatic mode once the system detects that the vehicle is cruising.

When the transmission is in S

- Holds the selected gear, and the **M** (sequential mode) indicator comes on.
- The sequential mode gear selection is shown in the instrument panel.



VSA® On and Off P. 506

- The Vehicle Stability Assist® (VSA®) system helps stabilize the vehicle during cornering and helps maintain traction while accelerating on loose or slippery road surfaces.
- VSA® comes on automatically every time you turn on the power system.
- To partially disable or fully restore VSA® function, press and hold the button until you hear a beep.

CMBS™ On and Off

P. 528

- When a possible collision is likely unavoidable, the CMBS™ can help you to reduce the vehicle speed and the severity of the collision.
- The CMBS™ is turned on every time you start the power system.
- To turn the CMBS™ on or off, press and hold the button until you hear a beep.

Tire Pressure Monitoring System (TPMS) with Tire Fill Assist P. 512, 645


- The TPMS monitors tire pressure.
- TPMS is turned on automatically every time you turn on the power system.
- TPMS fill assist provides audible and visual guidance during tire pressure adjustment.

Refueling P. 556

Fuel recommendation: Unleaded premium gasoline, pump octane number 91 or higher


Fuel tank capacity: 19.4 US gal (73.3 L)

1. Press the fuel fill door release button.
2. After refueling, wait for about five seconds before removing the filler nozzle.



AcuraWatch™

AcuraWatch™ is a driver support system which employs the use of two distinctly different kinds of sensors, a radar sensor located behind the emblem and a front sensor camera mounted to the interior side of the windshield, behind the rearview mirror.



Adaptive Cruise Control (ACC) with Low Speed Follow (LSF) P. 477

Helps maintain a constant vehicle speed and a set following-interval behind a vehicle detected ahead of yours and, if the detected vehicle comes to a stop, can decelerate and stop your vehicle, without you having to keep your foot on the brake or the accelerator.

Road Departure Mitigation (RDM) System P. 492

Alerts and helps to assist you when the system detects a possibility of your vehicle unintentionally crossing over detected lane markings and/or leaving the roadway altogether.

Lane Keeping Assist System (LKAS) P. 497

Provides steering input to help keep the vehicle in the middle of a detected lane and provides tactile and visual alerts if the vehicle is detected drifting out of its lane.

Collision Mitigation Braking System™ (CMBS™) P. 525


Can assist you when there is a possibility of your vehicle colliding with a vehicle or a pedestrian detected in front of yours. The CMBS™ is designed to alert you when a potential collision is determined, as well as to reduce your vehicle speed to help minimize collision severity when a collision is deemed unavoidable.

Maintenance P. 561


Under the Hood P. 569

- Check engine oil, engine coolant, windshield washer fluid and inverter coolant. Add when necessary.
- Check brake fluid.
- Check the 12-volt battery condition monthly.

1. Pull the hood release handle under the corner of the dashboard.



2. Locate the hood latch lever, push it to the side, and then raise the hood. Once you have raised the hood slightly, you can release the lever.



3. When finished, close the hood and make sure it is firmly locked in place.

Wiper Blades P. 587

- Replace blades if they leave streaks across the windshield.



Tires P. 591

- Inspect tires and wheels regularly.
- Check tire pressures regularly.
- Install snow tires for winter driving.

Lights P. 582

- Inspect all lights regularly.

Handling the Unexpected P. 613

Flat Tire P. 615

Vehicles with tire repair kit

- Park in a safe location and repair the flat tire using the tire repair kit.


Vehicles with compact spare tire

- Park in a safe location and replace the flat tire with the compact spare tire located under the cargo area.



Power System Won't Start P. 634

- If the battery is dead, jump start using a booster battery.




Overheating P. 639

- Park in a safe location. If you do not see steam under the hood, open the hood, and let the engine cool down.




Indicators Come On P. 641

- Identify the indicator and consult the owner's manual.



Blown Fuse P. 647

- Check for a blown fuse if an electrical device does not operate.



Emergency Towing P. 656

- Call a professional towing service if you need to tow your vehicle.



What to Do If


Q **Why do I hear an operating noise when applying the brakes?**

A This can occur when the ABS activates and does not indicate a problem. Apply firm, steady pressure on the brake pedal. Never pump the brake pedal.

Anti-lock Brake System (ABS) P. 523

Q **The rear door cannot be opened from inside the vehicle. Why?**

A Check if the childproof lock is in the lock position. If so, open the rear door with the outside door handle. To cancel this function, slide the lever upwards to the unlock position.



Q **Why do the doors lock after I unlocked the doors?**

A If you do not open the doors within 30 seconds, the doors are relocked automatically for security.

Q **Why does the beeper sound when I open the driver's door?**

A The beeper sounds when:
- The power mode is in ACCESSORY.
- The exterior lights are left on.

Q **Why does a beeper sound when I walk away from the vehicle after I close the door?**

A The beeper sounds if you move outside the walk away auto lock operating range before the door completely closes.

➡ **Locking the doors and tailgate (Walk away auto lock®)** P. 147

Q **Why does the beeper sound when I start driving?**

A The beeper sounds when the driver and/or front passenger are not wearing their seat belts.

Q **Pulling the electric parking brake switch does not release the parking brake. Why?**

A Pull the electric parking brake switch with the brake pedal depressed.

Q **I'm seeing an amber indicator of a tire with an exclamation point. What is that?**

A The Tire Pressure Monitoring System (TPMS) needs attention. Check tire pressure.

➡ **If the Low Tire Pressure/TPMS Indicator Comes On or Blinks** P. 645

Q **Depressing the accelerator pedal does not release the parking brake automatically. Why?**

A
- Fasten the driver's seat belt.
- Check if the transmission is in [P] or [N]. If so, select any other position.

Q **Why does the gear position automatically change to [P] when I open the driver's door to check for parking space lines when reversing?**

A
- Fasten the driver's seat belt.
- Close the driver's door and manually change the gear position.

▶ **When opening the driver's door** P. 468


Q **Why do I hear a screeching sound when I apply the brake pedal?**

A The brake pads may need to be replaced. Have your vehicle inspected by a dealer.

Q **Unleaded gasoline with a Pump Octane Number (PON) of 91 or higher is recommended.**
Is it possible to use unleaded gasoline with a Pump Octane Number (PON) of 87 or lower on this vehicle?

A Unleaded gasoline with a Pump Octane Number (PON) of 91 or higher is recommended.
Use of lower octane gasoline can cause occasional metallic knocking noise in the engine and will result in decreased engine performance.
Use of gasoline with a pump octane less than 87 can lead to engine damage.

This page intentionally left blank.



Safe Driving

You can find many safety recommendations throughout this chapter, and throughout this manual.

For Safe Driving
- Important Safety Precautions 34
- Important Handling Information 36
- Your Vehicle's Safety Features 37
- Safety Checklist 38

Seat Belts
- About Your Seat Belts 39
- Fastening a Seat Belt 42
- Seat Belt Inspection 46

Airbags
- Airbag System Components 47
- Types of Airbags 50
- Front Airbags (SRS) 50
- Driver's Knee Airbag 54
- Side Airbags 56
- Side Curtain Airbags 58
- Airbag System Indicators 59
- Airbag Care 61

Child Safety
- Protecting Child Passengers 62
- Safety of Infants and Small Children .. 64
- Safety of Larger Children 78

Exhaust Gas Hazard
- Carbon Monoxide Gas 80

Safety Labels
- Label Locations 81

The following pages explain your vehicle's safety features and how to use them properly. The safety precautions below are ones that we consider to be among the most important.

Important Safety Precautions

■ Always wear your seat belt

A seat belt is your best protection in all types of collisions. Airbags are designed to supplement seat belts, not replace them. So even though your vehicle is equipped with airbags, make sure you and your passengers always wear your seat belts, and wear them properly.

■ Restrain all children

Children ages 12 and under should ride properly restrained in a back seat, not the front seat. Infants and small children should be restrained in a child seat. Larger children should use a booster seat and a lap/shoulder seat belt until they can use the belt properly without a booster seat.

■ Be aware of airbag hazards

While airbags can save lives, they can cause serious or fatal injuries to occupants who sit too close to them, or are not properly restrained. Infants, young children, and short adults are at the greatest risk. Be sure to follow all instructions and warnings in this manual.

■ Don't drink and drive

Alcohol and driving don't mix. Even one drink can reduce your ability to respond to changing conditions, and your reaction time gets worse with every additional drink. So don't drink and drive, and don't let your friends drink and drive, either.

Important Safety Precautions

Some states, provinces and territories prohibit the use of cell phones other than hands-free devices by the driver while driving.

■ Pay appropriate attention to the task of driving safely

Engaging in cell phone conversation or other activities that keep you from paying close attention to the road, other vehicles, and pedestrians could lead to a crash. Remember, situations can change quickly, and only you can decide when it is safe to divert some attention away from driving.

■ Control your speed

Excessive speed is a major factor in crash injuries and deaths. Generally, the higher the speed, the greater the risk, but serious injuries can also occur at lower speeds. Never drive faster than is safe for current conditions, regardless of the maximum speed posted.

■ Keep your vehicle in safe condition

Having a tire blowout or a mechanical failure can be extremely hazardous.
To reduce the possibility of such problems, check your tire pressures and condition frequently, and perform all regularly scheduled maintenance.

■ Do not leave children unattended in the vehicle

Children, pets and people needing assistance left unattended in the vehicle may be injured if they activate one or more of the vehicle controls. They may also cause the vehicle to move, resulting in a crash in which they and/or another person(s) can be injured or killed. Also, depending on the ambient temperature, the temperature of the interior may reach extreme levels, which can result in harm or death. Even if the climate control system is on, never leave them in the vehicle unattended as the climate control system can shut off at any time.

Important Handling Information

Your vehicle has higher ground clearance than a passenger vehicle designed for use only on pavement. Higher ground clearance has many advantages for off-highway driving. It allows you to travel over bumps, obstacles, and rough terrain. It also provides good visibility so you can anticipate problems earlier.

These advantages come at some cost. Because your vehicle is taller and rides higher off the ground, it has a higher center gravity making it more susceptible to tipping or roll over if you make abrupt turns. Utility vehicles have a significantly higher rollover rate than other types of vehicles. In a rollover crash, an unbelted person is significantly more likely to die than a person wearing a seat belt. As a reminder, make sure you and your passengers always wear seat belts.

Important Handling Information


For information on how to reduce the risk of rollover, read:

Driving Guidelines for Your Utility Vehicle P. 463

Off-Highway Driving Guidelines P. 455

Failure to operate your vehicle correctly might result in a crash or a rollover.

Your Vehicle's Safety Features



The following checklist will help you take an active role in protecting yourself and your passengers.

Your Vehicle's Safety Features

Your vehicle is equipped with many features that work together to help protect you and your passengers during a crash.

Some features do not require any action on your part. These include a strong steel framework that forms a safety cage around the passenger compartment, front and rear crush zones, a collapsible steering column, and tensioners that tighten the front seat belts in a sufficient crash.

However, you and your passengers cannot take full advantage of these features unless you remain seated in the correct position and always wear your seat belts. In fact, some safety features can contribute to injuries if they are not used properly.

Safety Checklist


For the safety of you and your passengers, make a habit of checking these items each time before you drive.

- After everyone has entered the vehicle, be sure all doors and the tailgate are closed and locked. Locking the doors and the tailgate helps prevent an occupant from being ejected and an outsider from unexpectedly opening a door or the tailgate.
  ➡ **Locking/Unlocking the Doors from the Inside** P. 154
- Adjust your seat to a position suitable for driving. Be sure the front seats are adjusted as far to the rear as possible while allowing the driver to control the vehicle. Sitting too close to a front airbag can result in serious or fatal injury in a crash.
  ➡ **Adjusting the Seats** P. 195
- Adjust head restraints to the proper position. Head restraints are most effective when the center of the head restraint aligns with the center of your head. Taller persons should adjust their head restraint to the highest position.
  ➡ **Adjusting the Front and Second Row Outer Head Restraint Positions** P. 202
- Always wear your seat belt, and make sure you wear it properly. Confirm that any passengers are properly belted as well.
  ➡ **Fastening a Seat Belt** P. 42
- Protect children by using seat belts or child seats according to a child's age, height and weight.
  ➡ **Child Safety** P. 62

Safety Checklist

If the door and/or tailgate open message appears on the multi-information display (MID), a door and/or the tailgate is not completely closed. Close all doors and the tailgate tightly until the message disappears.

➡ **Multi-Information Display (MID) Warning and Information Messages** P. 105



About Your Seat Belts

Seat belts are the single most effective safety device because they keep you connected to the vehicle so that you can take advantage of many built-in safety features. They also help keep you from being thrown against the inside of the vehicle, against any passengers, or out of the vehicle. When worn properly, seat belts also keep your body properly positioned in a crash so that you can take full advantage of the additional protection provided by the airbags.

In addition, seat belts help protect you in almost every type of crash, including:
- frontal impacts
- side impacts
- rear impacts
- rollovers

■ Lap/shoulder seat belts

All six or seven seating positions are equipped with lap/shoulder seat belts with emergency locking retractors. In normal driving the retractor lets you move freely while keeping some tension on the belt. During a collision or sudden stop the retractor locks to restrain your body.
The front passenger's, second row and third row seat belts also have a lockable retractor for use with child seats.

➧ **Installing a Child Seat with a Lap/Shoulder Seat Belt** P. 72

➧About Your Seat Belts

⚠WARNING

Not wearing a seat belt properly increases the chance of serious injury or death in a crash, even though your vehicle has airbags.

Be sure you and your passengers always wear seat belts and wear them properly.

Seat belts cannot completely protect you in every crash. But in most cases, seat belts can reduce your risk of serious injury.

Most states and all Canadian provinces and territories require you to wear seat belts.

If you extend the seat belt too quickly, it will lock in place. If this happens, slightly retract the seat belt, then extend it slowly.

Continued

■ Proper use of seat belts

Follow these guidelines for proper use:

- All occupants should sit upright, well back in the seat, and remain in that position for the duration of the trip. Slouching and leaning reduce the effectiveness of the belt and can increase the chance of serious injury in a crash.
- Never place the shoulder part of a lap/shoulder seat belt under your arm or behind your back. This could cause very serious injuries in a crash.
- Two people should never use the same seat belt. If they do, they could be very seriously injured in a crash.
- Do not put any accessories on the seat belts. Devices intended to improve comfort or reposition the shoulder part of a seat belt can reduce the protective capability and increase the chance of serious injury in a crash.

■ Seat Belt Reminder



The seat belt system includes an indicator on the instrument panel to remind the driver or a front passenger or both to fasten their seat belts.

If you set the power mode to ON and a seat belt is not fastened, a beeper will sound and the indicator will blink. After a few seconds, the beeper will stop and the indicator will come on and remain illuminated until the seat belt is fastened.

The beeper will periodically sound and the indicator will blink while the vehicle is moving until the seat belt is fastened.

About Your Seat Belts

If a front passenger and rear seat passenger moves around and extends the seat belt, the lockable retractor may activate. If this happens, release the retractor by unfastening the seat belt and allow the belt to retract completely. Then refasten the belt.

Seat Belt Reminder


The indicator will also come on if a front passenger does not fasten their seat belt within six seconds after the power mode is set to ON.

When no one is sitting in the front passenger's seat, the indicator will not come on and the beeper will not sound.

The indicator also may not come on and the beeper may not sound when the occupant is not heavy enough to trigger the weight sensor. Such occupants (e.g., infants and smaller children) should be moved to the rear seat as a deploying front airbag likely will injure or kill them.

➡ **Protecting Child Passengers** P. 62

Automatic Seat Belt Tensioners



The front seats are equipped with automatic seat belt tensioners to enhance safety.

The tensioners automatically tighten the front seat belts during a moderate-to-severe frontal collision, sometimes even if the collision is not severe enough to inflate the front airbags or the driver's knee airbag.

Automatic Seat Belt Tensioners


The seat belt tensioners can only operate once. If a tensioner is activated, the SRS indicator will come on. Have a dealer replace the tensioner and thoroughly inspect the seat belt system as it may not offer protection in a subsequent crash.

During a moderate-to-severe side impact, the tensioner on that side of the vehicle also activates.


Fastening a Seat Belt

After adjusting a front seat to the proper position, and while sitting upright and well back in the seat:

Adjusting the Seats P. 195



1. Pull the seat belt out slowly.




2. Insert the latch plate into the buckle, then tug on the belt to make sure the buckle is secure.

▶ Make sure that the belt is not twisted or caught on anything.

Fastening a Seat Belt

No one should sit in a seat with an inoperative seat belt or one that does not appear to be working correctly. Using a seat belt that is not working properly may not protect the occupant in a crash. Have a dealer check the belt as soon as possible.


Never insert any foreign objects into the buckle or retractor mechanism.



3. Position the lap part of the belt as low as possible across your hips, then pull up on the shoulder part of the belt so the lap part fits snugly. This lets your strong pelvic bones take the force of a crash and reduces the chance of internal injuries.
4. If necessary, pull up on the belt again to remove any slack, then check that the belt rests across the center of your chest and over your shoulder. This spreads the forces of a crash over the strongest bones in your upper body.

■ Adjusting the Shoulder Anchor

The front seats have adjustable shoulder anchors to accommodate taller and shorter occupants.



1. Move the anchor up and down while holding the release button.
2. Position the anchor so that the belt rests across the center of your chest and over your shoulder.

Fastening a Seat Belt

⚠WARNING

Improperly positioning the seat belts can cause serious injury or death in a crash.

Make sure all seat belts are properly positioned before driving.

To release the belt, push the red **PRESS** button and then guide the belt by hand until it has retracted completely.
When exiting the vehicle, be sure the belt is properly stowed so that it will not get caught in the closing door.

Adjusting the Shoulder Anchor


The shoulder anchor height can be adjusted to four levels. If the belt contacts your neck, lower the height one level at a time.

After an adjustment, make sure that the shoulder anchor position is secure.


Continued

Models with second row bench seat


■ Seat Belt with Detachable Anchor



1. Pull out the seat belt's small latch plate and the latch plate from each holding slot in the ceiling.



2. Line up the triangle marks on the small latch plate and anchor buckle.
Make sure the seat belt is not twisted.
Attach the belt to the anchor buckle.



3. Insert the latch plate into the buckle.
Properly fasten the seat belt the same way you fasten the lap/shoulder seat belt.


Seat Belt with Detachable Anchor

⚠WARNING

Using the seat belt with the detachable anchor unlatched increases the chance of serious injury or death in a crash.

Before using the seat belt, make sure the detachable anchor is correctly latched.

To unlatch the detachable anchor, insert the latch plate into the slot on the side of the anchor buckle.



■ Advice for Pregnant Women

If you are pregnant, the best way to protect yourself and your unborn child when driving or riding in a vehicle is to always wear a seat belt and keep the lap part of the belt as low as possible across the hips.

Wear the shoulder belt across the chest avoiding the abdomen.



Wear the lap part of the belt as low as possible across the hips.

Advice for Pregnant Women

Each time you have a checkup, ask your doctor if it is okay for you to drive.

To reduce the risk of injuries to both you and your unborn child that can be caused by an inflating front airbag:

- When driving, sit upright and adjust the seat as far back as possible while allowing full control of the vehicle.
- When sitting in the front passenger's seat, adjust the seat as far back as possible.

Seat Belt Inspection

Regularly check the condition of your seat belts as follows:

- Pull each belt out fully, and look for frays, cuts, burns, and wear.
- Check that the latch plates and buckles work smoothly and the belts retract easily.
  ▶ If a belt does not retract easily, cleaning the belt may correct the problem. Only use a mild soap and warm water. Do not use bleach or cleaning solvents. Make sure the belt is completely dry before allowing it to retract.

Any belt that is not in good condition or working properly will not provide proper protection and should be replaced as soon as possible.
A belt that has been worn during a crash may not provide the same level of protection in a subsequent crash. Have your seat belts inspected by a dealer after any collision.


Seat Belt Inspection

⚠WARNING

Not checking or maintaining seat belts can result in serious injury or death if the seat belts do not work properly when needed.

Check your seat belts regularly and have any problem corrected as soon as possible.

Airbag System Components



Continued

The front, driver's knee, front side, and side curtain airbags are deployed according to the direction and severity of impact. Both side curtain airbags are deployed in a rollover. The airbag system includes:

❶ Two SRS (Supplemental Restraint System) front airbags. The driver's airbag is stored in the center of the steering wheel; the front passenger's airbag is stored in the dashboard. Both are marked **SRS AIRBAG**.

❷ Driver's knee airbag. The knee airbag is stored under the steering column. It is marked **SRS AIRBAG**.

❸ Two side airbags, one for the driver and one for a front passenger. The airbags are stored in the outer edges of the seat-backs. Both are marked **SIDE AIRBAG**.

❹ Two side curtain airbags, one for each side of the vehicle. The airbags are stored in the ceiling, above the side windows. The front and rear pillars are marked **SIDE CURTAIN AIRBAG**.

❺ An electronic control unit that, when the vehicle is on, continually monitors information about the various impact sensors, seat and buckle sensors, rollover sensor, airbag activators, seat belt tensioners, and other vehicle information. During a crash event the unit can record such information.

❻ Automatic front seat belt tensioners. In addition, the driver's and front passenger's seat belt buckles incorporate sensors that detect whether or not the belts are fastened.

❼ A driver's seat position sensor. This sensor determines the optimal force at which the airbag will deploy in a crash.

❽ Weight sensors in the front passenger's seat. The front passenger's airbag will be turned off if the weight on the seat is approximately 65 lbs (29 kg) or less (the weight of an infant or small child).

❾ Impact sensors that can detect a moderate-to-severe front or side impact.

❿ An indicator on the dashboard that alerts you that the front passenger's front airbag has been turned off.

⓫ An indicator on the instrument panel that alerts you to a possible problem with your airbag system or seat belt tensioners.

⓬ Safing Sensor

⓭ A rollover sensor that can detect if your vehicle is about to roll over and signal the control unit to deploy both side curtain airbags.

Important Facts About Your Airbags

Airbags can pose serious hazards. To do their job, airbags must inflate with tremendous force. So, while airbags help save lives, they can cause burns, bruises, and other minor injuries, sometimes even fatal ones if occupants are not wearing their seat belts properly and sitting correctly.

What you should do: Always wear your seat belt properly, and sit upright and as far back from the steering wheel as possible while allowing full control of the vehicle. A front passenger should move their seat as far back from the dashboard as possible.

Remember, however, that no safety system can prevent all injuries or deaths that can occur in a severe crash, even when seat belts are properly worn and the airbags deploy.

Do not place hard or sharp objects between yourself and a front airbag. Carrying hard or sharp objects on your lap, or driving with a pipe or other sharp object in your mouth, can result in injuries if your front airbag inflates.

Do not attach or place objects on the front and driver's knee airbag covers. Objects on the covers marked **SRS AIRBAG** could interfere with the proper operation of the airbags or be propelled inside the vehicle and hurt someone if the airbags inflate.

Important Facts About Your Airbags

Do not attempt to deactivate your airbags. Together, airbags and seat belts provide the best protection.

When driving, keep hands and arms out of the deployment path of the front airbag by holding each side of the steering wheel. Do not cross an arm over the airbag cover.

Types of Airbags

Your vehicle is equipped with four types of airbags:

- **Front airbags:** Airbags in front of the driver's and front passenger's seats.
- **Driver's knee airbag:** Airbag under the steering column.
- **Side airbags:** Airbags in the driver's and front passenger's seat-backs.
- **Side curtain airbags:** Airbags above the side windows.

Each is discussed in the following pages.

Types of Airbags

The airbags can inflate whenever the power mode is in ON.

After an airbag inflates in a crash, you may see a small amount of smoke. This is from the combustion process of the inflator material and is not harmful. People with respiratory problems may experience some temporary discomfort. If this occurs, get out of the vehicle as soon as it is safe to do so.

Front Airbags (SRS)

The front SRS airbags inflate in a moderate-to-severe frontal collision to help protect the head and chest of the driver and/or front passenger.

SRS (Supplemental Restraint System) indicates that the airbags are designed to supplement seat belts, not replace them. Seat belts are the occupant's primary restraint system.

■ Housing Locations

The front airbags are housed in the center of the steering wheel for the driver, and in the dashboard for the front passenger. Both airbags are marked **SRS AIRBAG**.

Front Airbags (SRS)


During a frontal crash severe enough to cause one or both front airbags to deploy, the airbags can inflate at different rates, depending on the severity of the crash, whether or not the seat belts are latched, and/or other factors. Frontal airbags are designed to supplement the seat belts to help reduce the likelihood of head and chest injuries in frontal crashes.

Operation

Front airbags are designed to inflate during moderate-to-severe frontal collisions. When the vehicle decelerates suddenly, the sensors send information to the control unit which signals one or both front airbags to inflate.

A frontal collision can be either head-on or angled between two vehicles, or when a vehicle crashes into a stationary object, such as a concrete wall.

How the Front Airbags Work



While your seat belt restrains your torso, the front airbag provides supplemental protection for your head and chest.

The front airbags deflate immediately so that they won't interfere with the driver's visibility or the ability to steer or operate other controls.

The total time for inflation and deflation is so fast that most occupants are not aware that the airbags deployed until they see them lying in front of them.

Continued

How the Front Airbags Work

Although the driver's and front passenger's airbags normally inflate within a split second of each other, it is possible for only one airbag to deploy. This can happen if the severity of a collision is at the margin, or threshold that determines whether or not the airbags will deploy. In such cases, the seat belt will provide sufficient protection, and the supplemental protection offered by the airbag would be minimal.

■ **When front airbags should not deploy**

Minor frontal crashes: Front airbags were designed to supplement seat belts and help save lives, not to prevent minor scrapes, or even broken bones that might occur during a less than moderate-to-severe frontal crash.

Side impacts: Front airbags can provide protection when a sudden deceleration causes a driver or front passenger to move toward the front of the vehicle. Side airbags and side curtain airbags have been specifically designed to help reduce the severity of injuries that can occur during a moderate-to-severe side impact which can cause the driver or passenger to move toward the side of the vehicle.

Rear impacts: Head restraints and seat belts are your best protection during a rear impact. Front airbags cannot provide any significant protection and are not designed to deploy in such collisions.

Rollovers: In a rollover, your best form of protection is a seat belt or, if your vehicle is equipped with a rollover sensor, both a seat belt and a side curtain airbag. Front airbags, however, are not designed to deploy in a rollover as they would provide little if any protection.

■ **When front airbags deploy with little or no visible damage**


Because the airbag system senses sudden deceleration, a strong impact to the vehicle framework or suspension might cause one or more of the airbags to deploy. Examples include running into a curb, the edge of a hole, or other low fixed object that causes a sudden deceleration in the vehicle chassis. Since the impact is underneath the vehicle, damage may not be readily apparent.

■ **When front airbags may not deploy, even though exterior damage appears severe**

Since crushable body parts absorb crash energy during an impact, the amount of visible damage does not always indicate proper airbag operation. In fact, some collisions can result in severe damage but no airbag deployment because the airbags would not have been needed or would not have provided protection even if they had deployed.


Advanced Airbags

The airbags have advanced features to help reduce the likelihood of airbag related injuries to smaller occupants.



The driver's advanced airbag system includes a seat position sensor.

Based on information from this sensor and the severity of the impact, the advanced airbag system determines the optimal deployment of the driver's airbag.



The front passenger's advanced airbag system has weight sensors.

We advise against allowing a child age 12 or under to ride in the front passenger's seat. However, **if you do allow a child age 12 or under to ride in the front passenger's seat**, note that the system will automatically turn off the front passenger's airbag if the sensors detect that the child is approximately 65 lbs (29 kg) or less.

Advanced Airbags

If there is a problem with the driver's seat position sensor, the SRS indicator will come on, and in the event of a crash, the airbag will deploy (regardless of the driver's seating position) with a force corresponding to the severity of the impact.

For the advanced airbags to work properly:

- Do not spill any liquid on or under the seats.
- Do not put any object under the passenger's seat.
- Make sure any objects are positioned properly on the floor. Improperly positioned objects can interfere with the advanced airbag sensors.
- All occupants should sit upright and wear their seat belts properly.
- Do not cover the passenger's side dashboard with a cloth, towel, cover, etc.

Passenger Front Airbag Off Indicator P. 60

Make sure the floor mat behind the front passenger's seat is hooked to the floor mat anchor. An improperly placed mat can interfere with the advanced airbag sensors.


Floor Mats P. 606

Driver's Knee Airbag

The driver's knee SRS airbag inflates in a moderate-to-severe frontal collision to help keep the driver in the proper position and to help maximize the benefit provided by the vehicle's other safety features.

SRS (Supplemental Restraint System) indicates that the airbag is designed to supplement seat belts, not replace them. Seat belts are the occupant's primary restraint system.


■ Housing Locations



The driver's knee airbag is housed under the steering column.

The airbag is marked **SRS AIRBAG**.

■ Operation



When the driver's front airbag inflates, the driver's knee airbag also inflates.

Driver's Knee Airbag

Do not attach accessories on or near a knee airbag as they can interfere with the proper operation of the airbag, or even hurt someone if the airbag inflates.

The driver should not store any items under the seat or behind their feet. The items can interfere with proper airbag deployment in the event of a moderate to sever frontal collision and may result in inadequate protection.

■ When driver's knee airbag deploys with little or no visible damage

Because the airbag system senses sudden deceleration, a strong impact to the vehicle framework or suspension might cause one or more of the airbags to deploy. Examples include running into a curb, the edge of a hole, or other low fixed object that causes a sudden deceleration in the vehicle chassis. Since the impact is underneath the vehicle, damage may not be readily apparent.


■ When driver's knee airbag may not deploy, even though exterior damage appears severe

Since crushable body parts absorb crash energy during an impact, the amount of visible damage does not always indicate proper airbag operation. In fact, some collisions can result in severe damage but no airbag deployment because the airbags would not have been needed or would not have provided protection even if they had deployed.

Side Airbags

The side airbags help protect the torso and pelvis of the driver or a front passenger during a moderate-to-severe side impact.


■ Housing Locations



The side airbags are housed in the outside edge of the driver's and passenger's seat-backs.

Both are marked **SIDE AIRBAG**.

■ Operation



When the sensors detect a moderate-to-severe side impact, the control unit signals the side airbag on the impact side to immediately inflate.

Side Airbags

Make sure you and your front seat passenger always sit upright. Leaning into the path of a side airbag can prevent the airbag from deploying properly and increases your risk of serious injury.

Do not attach accessories on or near the side airbags. They can interfere with the proper operation of the airbags, or hurt someone if an airbag inflates.

Do not cover or replace the front seat-back covers without consulting a dealer.
Improperly replacing or covering front seat-back covers can prevent your side airbags from properly deploying during a side impact.

■ When a side airbag deploys with little or no visible damage

Because the airbag system senses sudden acceleration, a strong impact to the side of the vehicle's framework can cause a side airbag to deploy. In such cases, there may be little or no damage, but the side impact sensors detected a severe enough impact to deploy the airbag.


■ When a side airbag may not deploy, even though visible damage appears severe

It is possible for a side airbag not to deploy during an impact that results in apparently severe damage. This can occur when the point of impact was toward the far front or rear of the vehicle, or when the vehicle's crushable body parts absorbed most of the crash energy. In either case, the side airbag would not have been needed nor provided protection even if it had deployed.

Side Curtain Airbags

The side curtain airbags help protect the heads of the driver and passengers in the outer seating positions during a moderate-to-severe side impact. The side curtain airbags equipped in this vehicle are also designed to help reduce the likelihood of partial and complete ejection of vehicle occupants through side windows in crashes, particularly rollover crashes.


■ Housing Locations



Side Curtain Airbag Storage

The side curtain airbags are located in the ceiling above the side windows on both sides of the vehicle.

■ Operation



Deployed Side Curtain Airbag

The side curtain airbag is designed to deploy in a rollover or a moderate-to-severe side impact.

Side Curtain Airbags

If the SRS control unit senses that your vehicle is about to rollover, it immediately deploys both side curtain airbags and activates both front seat belt tensioners.

If the impact is on the passenger's side, the passenger's side curtain airbag deploys even if there are no occupants on that side of the vehicle.

To get the best protection from the side curtain airbags, occupants should wear their seat belts properly and sit upright and well back in their seats.


Do not attach any objects to the side windows or roof pillars as they can interfere with the proper operation of the side curtain airbags.

■ **When side curtain airbags deploy in a frontal collision**
One or both side curtain airbags may also inflate in a moderate-to-severe angled frontal collision.

Airbag System Indicators

If a problem occurs in the airbag system, the SRS indicator will come on and a message appears on the multi-information display.

■ Supplemental Restraint System (SRS) Indicator



■ **When the power mode is set to ON**
The indicator comes on for a few seconds, then goes off. This tells you the system is working properly.

If the indicator comes on at any other time, or does not come on at all, have the system checked by a dealer as soon as possible. If you don't, your airbags and seat belt tensioners may not work properly when they are needed.

Supplemental Restraint System (SRS) Indicator


⚠WARNING

Ignoring the SRS indicator can result in serious injury or death if the airbag systems or tensioners do not work properly.

Have your vehicle checked by a dealer as soon as possible if the SRS indicator alerts you to a possible problem.

Continued

■ Passenger Front Airbag Off Indicator



■ When the passenger front airbag off indicator comes on

The indicator comes on to alert you that the passenger's front airbag has been turned off. This occurs when the weight sensors detect about 65 lbs (29 kg) or less, the weight of an infant or small child, on the seat.

Children age 12 or under should always ride properly restrained in a back seat.
➡ **Child Safety** P. 62

Objects placed on the seat can also cause the indicator to come on.

If the front passenger's seat is empty, the passenger's front airbag will not deploy and the indicator will not come on.

Passenger Front Airbag Off Indicator

If the indicator comes on with no front passenger and no objects on the passenger's seat, or with an adult riding there, something may be interfering with the weight sensor, such as:

- An object hanging on the seat or in the seat-back pocket.
- A child seat or other object pressing against the rear of the seat-back.
- A rear passenger pushing or pulling on the back of the front passenger's seat.
- The front seat or seat-back is forced back against an object on the seat or floor behind it.
- An object placed under the front passenger's seat.

If none of these conditions exist, have your vehicle checked by a dealer as soon as possible.

The passenger front airbag off indicator may come on and go off repeatedly if the total weight on the seat is near the airbag cutoff threshold.

Airbag Care

You do not need to, and should not, perform any maintenance on or replace any airbag system components yourself. However, you should have your vehicle inspected by a dealer in the following situations:

■ When the airbags have deployed

If an airbag has inflated, the control unit and other related parts must be replaced. Similarly, once an automatic seat belt tensioner has been activated, it must be replaced.

■ When the vehicle has been in a moderate-to-severe collision

Even if the airbags did not inflate, have your dealer inspect the following: the driver's seat position sensor, weight sensors in the passenger's seat, front seat belt tensioners, and each seat belt that was worn during the crash.

■ Do not remove or modify a front seat without consulting a dealer

This would likely disable or affect the proper operation of the driver's seat position sensor or the weight sensors in the passenger's seat. If it is necessary to remove or modify a front seat to accommodate a person with disabilities, contact an Acura dealer, or for U.S. vehicles, Acura Client Relations at 1-800-382-2238 and for Canadian vehicles, Acura Client Services at 1-888-9-ACURA-9.

Airbag Care


We recommend against the use of salvaged airbag system components, including the airbag, tensioners, sensors, and control unit.

Protecting Child Passengers

Each year, many children are injured or killed in vehicle crashes because they are either unrestrained or not properly restrained. In fact, vehicle crashes are the number one cause of death of children ages 12 and under.

To reduce the number of child deaths and injuries, every state, Canadian province and territory requires that infants and children be properly restrained when they ride in a vehicle.

Children should sit properly restrained in a rear seat. This is because:



- An inflating front or side airbag can injure or kill a child sitting in the front seat.
- A child in the front seat is more likely to interfere with the driver's ability to safely control the vehicle.
- Statistics show that children of all sizes and ages are safer when they are properly restrained in a rear seat.

Protecting Child Passengers

⚠WARNING

Children who are unrestrained or improperly restrained can be seriously injured or killed in a crash.

Any child too small for a seat belt should be properly restrained in a child seat. A larger child should be properly restrained with a seat belt, using a booster seat if necessary.

The National Highway Traffic Safety Administration and Transport Canada recommend that all children ages 12 and under be properly restrained in a rear seat. Some states or provinces/territories have laws restricting where children may ride.

- Any child who is too small to wear a seat belt correctly must be restrained in an approved child seat that is properly secured to the vehicle using either the seat belt or the lower anchors of the LATCH system.
- Never hold a child on your lap because it is impossible to protect them in the event of a collision.
- Never put a seat belt over yourself and a child. During a crash, the belt would likely press deep into the child and cause serious or fatal injuries.
- Never let two children use the same seat belt. Both children could be very seriously injured in a crash.
- Do not allow children to operate the doors, windows or seat adjustments.
- Do not leave children in the vehicle unattended, especially in hot weather when the inside of the vehicle can get hot enough to kill them. They could also activate vehicle controls causing it to move unexpectedly.

Protecting Child Passengers

⚠WARNING

Allowing a child to play with a seat belt or wrap one around their neck can result in serious injury or death.

Instruct children not to play with any seat belt and make sure any unused seat belt a child can reach is buckled, fully retracted, and locked.

To deactivate a lockable retractor, release the buckle and allow the seat belt to wind up all the way.


To remind you of the passenger's front airbag hazards and child safety, your vehicle has warning labels on the dashboard (U.S. models) and on the front visors. Please read and follow the instructions on these labels.

Safety Labels P. 81

Safety of Infants and Small Children

■ Protecting Infants

An infant must be properly restrained in a rear-facing, reclining child seat until the infant reaches the seat manufacturer's weight or height limit for the seat, and the infant is at least one year old.



■ Positioning a rear-facing child seat

Child seats must be placed and secured in a rear seating position.

When properly installed, a rear-facing child seat may prevent the driver or a front passenger from moving their seat all the way back, or from locking their seat-back in the desired position. Make sure that there is no contact between the child seat and the seat in front of it.

It can also interfere with proper operation of the passenger's advanced front airbag system.

➡ **Airbags** P. 47

If this occurs, we recommend that you install the child seat directly behind the front passenger's seat, move the seat as far forward as needed, and leave it unoccupied. Or, you may wish to get a smaller rear-facing child seat.

Protecting Infants

⚠WARNING

Placing a rear-facing child seat in the front seat can result in serious injury or death during a crash.

Always place a rear-facing child seat in the rear seat, not the front.

Many experts recommend use of a rear-facing seat for a child up to two years old if the child's height and weight are appropriate for a rear-facing seat.


Rear-facing child seats should never be installed in a forward-facing position.

Always refer to the child seat manufacturer's instructions before installation.

Do not allow a front seat to rest against a child seat installed in a rear seating position:
The weight sensor in the front seat may not correctly detect the actual weight of the occupant.

■ Protecting Smaller Children

If a child is at least one year old and has exceeded the weight and height limitations of a rear-facing child seat, the child should be properly restrained in a firmly secured forward-facing child seat until they exceed the weight and height limitations for the forward-facing child seat.



■ Forward-facing child seat placement

We strongly recommend placing a forward-facing child seat in a rear seating position.

Placing a forward-facing child seat in the front seat can be hazardous, even with advanced front airbags that automatically turn the passenger's front airbag off. A rear seat is the safest place for a child.

Protecting Smaller Children

⚠WARNING

Placing a forward-facing child seat in the front seat can result in serious injury or death if the front airbag inflates.

If you must place a forward-facing child seat in front, move the vehicle seat as far back as possible, and properly restrain the child.

Educate yourself about the laws and regulations regarding child seat use where you are driving, and follow the child seat manufacturer's instructions.

Continued

■ Selecting a Child Seat

Most child seats are LATCH-compatible (Lower Anchors and Tethers for CHildren). Some have a rigid-type connector while others have a flexible-type connector. Both are equally easy to use. Some existing and previously owned child seats can only be installed using the seat belt. Whichever type you choose, follow the child seat manufacturer's use and care instructions including recommended expiration dates as well as the instructions in this manual. Proper installation is key to maximizing your child's safety.

In seating positions and vehicles not equipped with LATCH, a LATCH-compatible child seat can be installed using the seat belt and a top tether for added security. This is because all child seats are required to be designed so that they can be secured with a lap belt or the lap part of a lap/shoulder belt. In addition, the child seat manufacturer may advise that a seat belt be used to attach a LATCH-compatible seat once a child reaches a specified weight. Please read the child seat owner's manual for proper installation instructions.

■ Important consideration when selecting a child seat

Make sure the child seat meets the following three requirements:

- The child seat is the correct type and size for the child.
- The child seat is the correct type for the seating position.
- The child seat is compliant with Federal Motor Vehicle Safety Standard 213 or Canadian Motor Vehicle Safety Standard 213.

Selecting a Child Seat

Installation of a LATCH-compatible child seat is simple.

LATCH-compatible child seats have been developed to simplify the installation process and reduce the likelihood of injuries caused by incorrect installation.


Installing a LATCH-Compatible Child Seat

A LATCH-compatible child seat can be installed in the second row seats. A child seat is attached to the lower anchors with either the rigid or flexible type of connectors.

Models with second row captain seat



Models with second row bench seat




1. Locate the lower anchors under the marks.

Installing a LATCH-Compatible Child Seat

⚠WARNING

Never attach two child seats to the same anchor. In a collision, one anchor may not be strong enough to hold two child seat attachments and may break, causing serious injury or death.


Continued




2. Place the child seat on the vehicle seat, then attach the child seat to the lower anchors according to the instructions that came with the child seat.

▶ When installing the child seat, make sure that the lower anchors are not obstructed by the seat belt or any other object.

Straight Top Tether Type



Other Top Tether Type



Second row captain seat

Straight Top Tether Type

3. Put the outer head restraint to its uppermost position, then route the tether strap between the head restraint legs, and secure the tether strap hook to the anchor. Make sure the strap is not twisted.

Other Top Tether Type

3. Put the outer head restraint to its upper most position, then route the tether strap outside the head restraint legs, and secure the tether strap hook to the anchor. Make sure the strap is not twisted.

All Types

4. Tighten the tether strap as instructed by the child seat manufacturer.

5. Make sure the child seat is firmly secured by rocking it forward and back and side to side; little movement should be felt.

6. Make sure any unused seat belt that a child can reach is buckled, the lockable retractor is activated, and the belt is fully retracted and locked.


➲ **Protecting Child Passengers** P. 62

Installing a LATCH-Compatible Child Seat


For your child's safety, when using a child seat installed using the LATCH system, make sure that the child seat is properly secured to the vehicle.
A child seat that is not properly secured will not adequately protect a child in a crash and may cause injury to the child or other vehicle occupants.

Continued

Straight Top Tether Type



Other Top Tether Type



Second row bench seat

Outer position

Straight Top Tether Type

3. Put the outer head restraint to its uppermost position, then route the tether strap between the head restraint legs, and secure the tether strap hook to the anchor. Make sure the strap is not twisted.

Outer position

Other Top Tether Type

3. Put the outer head restraint to its upper most position, then route the tether strap outside the head restraint legs, and secure the tether strap hook to the anchor. Make sure the strap is not twisted.

Center position

3. Put the center head restraint to its lowest position, then route the tether strap over the top of the head restraint and secure the tether strap hook to the anchor. Make sure the strap is not twisted.

All positions

4. Tighten the tether strap as instructed by the child seat manufacturer.

5. Make sure the child seat is firmly secured by rocking it forward and back and side to side; little movement should be felt.


6. Make sure any unused seat belt that a child can reach is buckled, the lockable retractor is activated, and the belt is fully retracted and locked.


➔ **Protecting Child Passengers** P. 62

Continued

■ Installing a Child Seat with a Lap/Shoulder Seat Belt

A child seat can be installed with a lap/shoulder belt in any rear seat or, if absolutely necessary, the front passenger seat.





1. Place the child seat on the vehicle seat.

2. Route the seat belt through the child seat according to the seat manufacturer's instructions, and insert the latch plate into the buckle.

▶ Insert the latch plate fully until it clicks.

3. Slowly pull the shoulder part of the belt all the way out until it stops. This activates the lockable retractor.

4. Let the seat belt retract a few inches and check that the retractor has switched modes by pulling on the webbing. It should not pull out again until it is reset by removing the latch plate from the buckle.


▶ If you are able to pull the shoulder belt out, the lockable retractor is not activated. Slowly pull the seat belt all the way out, and repeat steps 3 – 4.

Installing a Child Seat with a Lap/Shoulder Seat Belt

A child seat that is not properly secured will not adequately protect a child in a crash and may cause injury to the child or other vehicle occupants.



5. Grab the shoulder part of the seat belt near the buckle, and pull up to remove any slack from the lap part of the belt.
▶ When doing this, place your weight on the child seat and push it into the vehicle seat.




6. Make sure the child seat is firmly secured by rocking it forward and back and side to side; less than one inch of movement should occur near the seat belt.
7. Make sure any unused seat belt that a child can reach is buckled, the lockable retractor is activated, and the belt is fully retracted and locked.


Installing a Child Seat with a Lap/Shoulder Seat Belt


To deactivate a lockable retractor, release the buckle and allow the seat belt to wind up all the way.

Continued

■ Adding Security with a Tether








A tether anchorage point is provided behind each second and third row seating position. If you have a child seat that comes with a tether but can be installed with a seat belt, the tether may be used for additional security.

Adding Security with a Tether

Always use a tether for forward-facing child seats when using the seat belt or lower anchors.



■ Using a second row anchor

Outer positions

Straight Top Tether Type

1. Put the outer head restraint to its upper-most position, then route the tether strap between the head restraint legs, and secure the tether strap hook to the anchor. Make sure the strap is not twisted.

Outer positions


Other Top Tether Type

1. Put the outer head restraint to its upper most position, then route the tether strap outside the head restraint legs, and secure the tether strap hook to the anchor. Make sure the strap is not twisted.


Continued

Models with second row bench seat

Straight Top Tether Type



Other Top Tether Type




Center position of second row bench seat

1. Put the center head restraint to its lowest position, then route the tether strap over the top of the head restraint and secure the tether strap hook to the anchor. Make sure the strap is not twisted.

All positions

2. Tighten the tether strap as instructed by the child seat manufacturer.



■ Using a third row anchor

Straight Top Tether Type

1. Pull up the head restraint and push rearwards until it latches, then route the tether strap through the head restraint legs. Make sure the strap is not twisted.

Other Top Tether Type

1. Pull up the head restraint and push rearwards until it latches, then route the tether strap outside the head restraint legs. Make sure the strap is not twisted.

All Types

2. Open the anchor cover.
3. Secure the tether strap hook to the anchor.
4. Tighten the tether strap as instructed by the child seat manufacturer.


Safety of Larger Children

■ Protecting Larger Children

The following pages give instructions on how to check proper seat belt fit, what kind of booster seat to use if one is needed, and important precautions for a child who must sit in front.

■ Checking Seat Belt Fit

When a child is too big for a child seat, secure the child in a rear seat using the lap/shoulder seat belt. Have the child sit upright and all the way back, then answer the following questions.



■ Checklist

- Do the child's knees bend comfortably over the edge of the seat?
- Does the shoulder belt cross between the child's neck and arm?
- Is the lap part of the seat belt as low as possible, touching the child's thighs?
- Will the child be able to stay seated like this for the whole trip?

If you answer yes to all these questions, the child is ready to wear the lap/shoulder seat belt correctly. If you answer no to any question, the child needs to ride on a booster seat until the seat belt fits properly without a booster seat.

Safety of Larger Children

⚠WARNING

Allowing a child age 12 or under to sit in front can result in injury or death if the passenger's front airbag inflates.

If a larger child must ride in front, move the vehicle seat as far to the rear as possible, have the child sit up properly and wear the seat belt properly, using a booster seat if needed.

Booster Seats



If a lap/shoulder seat belt cannot be used properly, position the child in a booster seat in the rear seat. For the child's safety, check that the child meets the booster seat manufacturer's recommendations.

Protecting Larger Children-Final Checks

Your vehicle has a rear seat where children can be properly restrained. If you ever have to carry a group of children, and a child must ride in front:

- Make sure you read and fully understand the instructions and safety information in this manual.
- Move the front passenger seat as far back as possible.
- Have the child sit upright and well back in the seat.
- Check that the seat belt is properly positioned so that the child is secure in the seat.

Monitoring child passengers

We strongly recommend that you keep an eye on child passengers. Even older, more mature children sometimes need to be reminded to fasten their seat belts and sit up properly.

Booster Seats

When installing a booster seat, make sure to read the instructions that came with it, and install the seat accordingly.
There are high- and low-type booster seats. Choose a booster seat that allows the child to wear the seat belt correctly.

Some U.S. states and Canadian provinces and territories require children to use a booster seat until they reach a given age or weight (e.g. 6 years or 60 lbs). Be sure to check current laws in the state or province, or territory where you intend to drive.

Carbon Monoxide Gas

The engine exhaust from this vehicle contains carbon monoxide, a colorless, odorless, and highly toxic gas. As long as you properly maintain your vehicle, carbon monoxide gas will not get into the interior.

■ **Have the exhaust system inspected for leaks whenever**
- The exhaust system is making an unusual noise.
- The exhaust system may have been damaged.
- The vehicle is raised for an oil change.

When you operate a vehicle with the tailgate open, airflow can pull exhaust gas into the interior and create a hazardous condition. If you must drive with the tailgate open, open all the windows and set the climate control system as shown below.

1. Select the fresh air mode.
2. Select the  mode.
3. Set the fan speed to high.
4. Set the temperature control to a comfortable setting.

Adjust the climate control system in the same manner if you sit in your parked vehicle with the engine running.

Carbon Monoxide Gas

⚠WARNING

Carbon monoxide gas is toxic.

Breathing it can cause unconsciousness and even kill you.


Avoid any enclosed areas or activities that expose you to carbon monoxide.

An enclosed area such as a garage can quickly fill up with carbon monoxide gas.
Do not run the engine with the garage door closed. Even when the garage door is open, drive out of the garage immediately after starting the engine.

Label Locations

These labels are in the locations shown. They warn you of potential hazards that can cause serious injury or death. Read these labels carefully.

If a label comes off or becomes hard to read (except for the U.S. dashboard label which may be removed by the owner), contact a dealer for a replacement.








This page intentionally left blank.


Instrument Panel

This chapter describes the buttons, indicators, and gauges that are used while driving.

Indicators 84
Multi-Information Display (MID) Warning and Information Messages 105
Gauges and Multi-Information Display (MID)
Gauges 123
MID 125

Indicator	Name	On/Blinking	Explanation	Message
U.S. BRAKE Canada (Red)	Brake System Indicator (Red)	• Comes on for a few seconds when you set the power mode to ON, then goes off. • Comes on when the brake fluid level is low. • Comes on if there is a problem with the brake system.	• **Comes on while driving** - Check the brake fluid level. ➡ **What to do when the indicator comes on while driving** P. 643 • **Comes on along with the brake system indicator (amber)** - Immediately stop in a safe place. Contact a dealer for repair. The brake pedal becomes harder to operate. Depress the pedal further than you normally do. • **Comes on along with the ABS indicator** - Have your vehicle checked by a dealer. ➡ **If the Brake System Indicator (Red) Comes On** P. 643	 

Indicator	Name	On/Blinking	Explanation	Message
U.S. BRAKE SYSTEM / Canada (Amber)	Brake System Indicator (Amber)	• Comes on for a few seconds when you set the power mode to ON, then goes off. • Comes on if there is a problem with a system related to braking other than the conventional brake system. • Comes on if there is a problem with the electric parking brake system. • Comes on if there is a problem with the cooperative control with regenerative braking, the electric servo brake system, or the hill start assist system.	• **Comes on while driving** - Have your vehicle checked by a dealer. • **Stays on constantly** - Avoid high speeds and sudden braking. Take the vehicle to a dealer immediately. • With this indicator on, your vehicle still has normal braking ability.	U.S.  Canada  
		• Comes on if there is a problem with the automatic brake hold system.	**Automatic Brake Hold** P. 521	U.S.  Canada 

Indicator	Name	On/Blinking	Explanation	Message
U.S. PARK Canada (P)	Electric Parking Brake Indicator	• Comes on for a few seconds when you set the power mode to ON, then goes off. • Comes on when the parking brake is applied, and goes off when it is released. • Comes on for about 15 seconds then goes off when you push the electric parking brake switch with the power mode in OFF. • Comes on for about 15 seconds then goes off when you set the power mode to OFF with the parking brake applied.	• **Blinks and the electric parking brake system indicator comes on at the same time** - There is a problem with the electric parking brake system. The parking brake may not be set.	
		• Comes on when you pull the electric parking brake switch without depressing the brake pedal.	• Depress the brake pedal to release the parking brake. ➡ **Parking Brake** P. 517	
(P)!	Electric Parking Brake System Indicator	• Comes on for a few seconds when you set the power mode to ON, then goes off. • Comes on if there is a problem with the electric parking brake system.	• **Comes on while driving** - Avoid using the parking brake and have your vehicle checked by a dealer immediately. ➡ **If the Electric Parking Brake System Indicator Comes On** P. 644	

Indicator	Name	On/Blinking	Explanation	Message
	Automatic Brake Hold System Indicator	• Comes on for a few seconds when you set the power mode to ON, then goes off. • Comes on when the automatic brake hold system is on.	**Automatic Brake Hold** P. 521	
	Automatic Brake Hold Indicator	• Comes on for a few seconds when you set the power mode to ON, then goes off. • Comes on when the automatic brake hold is activated.	**Automatic Brake Hold** P. 521	—



Continued

Indicator	Name	On/Blinking	Explanation	Message
	Low Oil Pressure Indicator	• Comes on when you set the power mode to ON, and goes off when the power system starts. • Comes on when the engine oil pressure is low.	• **Comes on while driving** - Immediately stop in a safe place. ➡ **If the Low Oil Pressure Indicator Comes On** P. 641	
	Malfunction Indicator Lamp	• Comes on when you set the power mode to ON, and goes off either when the power system is on or after several seconds if the power system did not start. If "readiness codes" have not been set, it blinks five times before it goes off. • Comes on if there is a problem with the emissions control systems. • Blinks when a misfire in the engine's cylinders is detected.	• Readiness codes are part of the on board diagnostics for the emissions control systems. ➡ **Testing of Readiness Codes** P. 667 • **Comes on while driving** - Have your vehicle checked by a dealer. • **Blinks while driving** - Stop in a safe place where there are no flammable objects. Stop the power system for 10 minutes or more, and wait for it to cool down. Then, take your vehicle to a dealer. ➡ **If the Malfunction Indicator Lamp Comes On or Blinks** P. 642	
	12-Volt Battery Charging System Indicator	• Comes on when you set the power mode to ON, and goes off when the power system is on. • Comes on when the 12-volt battery is not charging.	• **Comes on while driving** - Turn off the climate control system and rear defogger in order to reduce electricity consumption. ➡ **If the 12-Volt Battery Charging System Indicator Comes On** P. 641	

Indicator	Name	On/Blinking	Explanation	Message
	Gear Position Indicator	• Indicates the current gear selection.	**Shifting** P. 465	—
	**M** (sequential mode) Indicator/ Sequential Mode Gear Selection Indicator	• Comes on when the manual sequential mode is applied.	**Sequential Mode** P. 471	—


Continued

Indicator	Name	On/Blinking	Explanation	Message
	Transmission System Indicator	• The indicated current gear selection blinks if there is a problem with the transmission system.	• Avoid sudden start and acceleration, and stop in a safe place immediately. Have your vehicle checked by a dealer.	
		• All the gear positions may light for several seconds.	• When all the gear positions light, immediately stop your vehicle in a safe place.	
			• Indicators go off if there is no problem. However, even if they go off, take your vehicle to a dealer for inspection.	—
		• The indicated current gear selection or all the gear positions blink if there is a problem with the transmission system, and the vehicle no longer moves.	• Immediately stop in a safe place. ➡ **Emergency Towing** P. 656 • Have your vehicle checked by a dealer.	
		• The indicated current gear selection or all the gear positions blink if you cannot select P due to the transmission system failure.	• The power system can be activated as a temporary measure. ➡ **If the Transmission System Indicator Blinks along with the Warning Message** P. 645 • Set the parking brake when parking. • Have your vehicle checked by a dealer immediately.	



Indicator	Name	On/Blinking	Explanation	Message
	Seat Belt Reminder Indicator	• Comes on and the beeper sounds if you are not wearing a seat belt when you set the power mode to ON. • If the front passenger is not wearing a seat belt, the indicator comes on about a few seconds later. • Blinks while driving if either you and/or the front passenger has not fastened a seat belt. The beeper sounds and the indicator blinks at regular intervals.	• The beeper stops and the indicator goes off when you and the front passenger fasten their seat belts. • **Stays on after you and/or the front passenger has fastened the seat belt(s)** - A detection error may have occurred in the sensor. Have your vehicle checked by a dealer. ➡ **Seat Belt Reminder** P. 40	
	Low Fuel Indicator	• Comes on when the fuel reserve is running low (approximately 2.5 U.S. gal./9.5 Liter left). • Blinks if there is a problem with the fuel gauge.	• **Comes on** - Refuel your vehicle as soon as possible. • **Blinks** - Have your vehicle checked by a dealer.	
POWER SYSTEM	**POWER SYSTEM** Indicator	• Comes on for a few seconds when you set the power mode to ON, then goes off. • Comes on if there is a problem with the electric vehicle system.	• **Comes on while driving** - Have your vehicle checked by a dealer immediately. ➡ **If the Power System Indicator Comes On** P. 646	

Continued

Indicator	Name	On/Blinking	Explanation	Message
	High Temperature Indicator	• Comes on for a few seconds when you set the power mode to ON, then goes off. • Blinks when the engine coolant temperature goes up, and stays on if the temperature continues to rise.	• **Blinks while driving** - Drive slowly to prevent overheating.	
			• **Stays on while driving** - Immediately stop in a safe place and allow the engine to cool. ➡ **Overheating** P. 639	
	Low Temperature Indicator	• Comes on for a few seconds when you set the power mode to ON, then goes off. • Comes on when the engine coolant temperature is low.	• If the indicator stays on after the engine has reached normal operating temperature, there may be problem with the temperature sensors. Have your vehicle inspected by a dealer.	—
SPORT+	**SPORT+** mode Indicator	• Comes on for a few seconds when you set the power mode to ON, then goes off. • Comes on when you press the **Dynamic Mode** button if the Sport+ mode was selected.	➡ **Integrated Dynamics System** P. 474	—
READY	**READY** Indicator	• Comes on when the vehicle is ready to drive.	➡ **Turning on the Power** P. 457	

Indicator	Name	On/Blinking	Explanation	Message
	Anti-lock Brake System (**ABS**) Indicator	• Comes on for a few seconds when you set the power mode to ON, then goes off. • If it comes on at any other time, there is a problem with the ABS.	• **Stays on constantly** - Have your vehicle checked by a dealer. With this indicator on, your vehicle still has normal braking ability but no anti-lock function. ➡ **Anti-lock Brake System (ABS)** P. 523	
	Supplemental Restraint System Indicator	• Comes on for a few seconds when you set the power mode to ON, then goes off. • Comes on if a problem with any of the following is detected: - Supplemental restraint system - Side airbag system - Side curtain airbag system - Seat belt tensioner	• **Stays on constantly or does not come on at all** - Have your vehicle checked by a dealer.	
	Auto High-Beam Indicator	• Comes on when all the operating conditions of the Auto high-beam are met.	➡ **Auto High-Beam** P. 180	—

Indicator	Name	On/Blinking	Explanation	Message
	Vehicle Stability Assist® (VSA®) System Indicator	• Comes on for a few seconds when you set the power mode to ON, then goes off. • Blinks when VSA® is active. • Comes on if there is a problem with the VSA®.	• **Stays on constantly** - Have your vehicle checked by a dealer. ➡ **Vehicle Stability Assist® (VSA®), aka Electronic Stability Control (ESC), System** P. 505	
	Vehicle Stability Assist® (VSA®) OFF Indicator	• Comes on for a few seconds when you set the power mode to ON, then goes off. • Comes on when you partially disable VSA®.	➡ **VSA® On and Off** P. 506	—


Indicator	Name	On/Blinking	Explanation	Message
	Speed-sensitive Electric Power Steering (EPS) System Indicator	• Comes on when you set the power mode to ON, and goes off when the power system is on. • Comes on if there is a problem with the EPS system.	• **Stays on constantly or does not come on at all** - Have your vehicle checked by a dealer. ➡ **If the Speed-Sensitive Electric Power Steering (EPS) System Indicator Comes On** P. 643	
	Low Tire Pressure/ TPMS Indicator	• Comes on for a few seconds when you set the power mode to ON, then goes off. • Comes on if the tire pressure of any of the tires becomes significantly low. • Blinks for about one minute, and then stays on if there is a problem with the TPMS, or when a spare tire* is temporarily installed.	• **Comes on while driving** - Stop in a safe place, check tire pressures, and inflate the tire(s) if necessary. • **Blinks and remains on** - Have your vehicle checked by a dealer. If the vehicle is fitted with a spare, get your regular tire repaired or replaced and put back on your vehicle as soon as you can.	
	Turn Signal and Hazard Warning Indicators	• Blinks when you operate the turn signal lever. • Blink along with all turn signals when you press the hazard warning button.	• **Does not blink or blinks rapidly** ➡ **Replacing Light Bulbs** P. 582	—
	High Beam Indicator	• Comes on when the high beam headlights are on.	—	—

* Not available on all models


Continued

Indicator	Name	On/Blinking	Explanation	Message
	Lights On Indicator	• Comes on when the light switch in a position other than **OFF** or when the switch is set to **AUTO** and the exterior lights come on.	• If you set the power mode to ACCESSORY or VEHICLE OFF while the exterior lights are on, a chime sounds when the driver's door is opened.	—
	Fog Light Indicator*	• Comes on when the fog lights are on.	—	—
	Immobilizer System Indicator	• Comes on briefly when you set the power mode to ON, then goes off. • Comes on if the immobilizer system cannot recognize the key information.	• **Blinks** - You cannot start the power system. Set the power mode to VEHICLE OFF, then select the ON mode again. • **Repeatedly blinks** - The system may be malfunctioning. Have your vehicle checked by a dealer. • Do not attempt to alter this system or add other devices to it. Electrical problems can occur.	—

* Not available on all models

Indicator	Name	On/Blinking	Explanation	Message
	Security System Alarm Indicator	• Blinks when the security system alarm has been set.	**Security System Alarm** P. 166	—
	System Message Indicator	• Comes on for a few seconds when you set the power mode to ON, then goes off. • Comes on along with a beep when a problem is detected. A system message on the MID appears at the same time.	• While the indicator is on, roll the multi-function steering wheel control to see the message again. • Refer to the Indicators information in this chapter when a system message appears on the MID. Take the appropriate action for the message. • The MID does not return to the normal screen unless the warning is canceled, or the multi-function steering-wheel controls is rolled.	—
	Keyless Access System Indicator	• Comes on for a few seconds when you set the power mode to ON, then goes off. • Comes on as soon as a problem is detected in the keyless access system or keyless starting system.	• Have your vehicle checked by a dealer.	

Continued

Indicator	Name	On/Blinking	Explanation	Message
	Lane Keeping Assist System (**LKAS**) Indicator (Amber)	• Comes on for a few seconds when you set the power mode to ON, then goes off. • Comes on if there is a problem with the LKAS.	• **Stays on constantly** - Have your vehicle checked by a dealer.	
	Lane Keeping Assist System (**LKAS**) Indicator (Green)	• Comes on when you press the **MAIN** button.	➡ **Lane Keeping Assist System (LKAS)** P. 497	—
		• Comes on when the LKAS is in operation, or the LKAS button is pressed, but the temperature inside the front sensor camera is too high. The LKAS cancels automatically. The beeper sounds simultaneously.	• Use the climate control system to cool down the camera. • **Goes off** - The camera has been cooled down and the system activates normally. ➡ **Front Sensor Camera** P. 475	
		• Comes on when the area around the camera is blocked by dirt, mud, etc. Stop your vehicle in a safe place, and wipe it off with a soft cloth. • May come on when driving in bad weather (rain, snow, fog, etc.)	• Have your vehicle checked by a dealer if the indicator and message come back on after you cleaned the area around the camera.	



Indicator	Name	On/Blinking	Explanation	Message
	Road Departure Mitigation (RDM) Indicator	• Comes on for a few seconds when you set the power mode to ON, then goes off. • Comes on if there is a problem with the RDM system.	• **Stays on constantly** - Have your vehicle checked by a dealer.	
		• Comes on when the RDM system shuts itself off.	• **Stays on** - The temperature inside the camera is too high. Use the climate control system to cool down the camera. The system activates when the temperature inside the camera cools down. ➡ **Front Sensor Camera** P. 475	
			• **Stays on** - The area around the camera is blocked by dirt, mud, etc. Stop your vehicle in a safe place, and wipe it off with a soft cloth. • Have your vehicle checked by a dealer if the indicator and message come back on after you cleaned the area around the camera. ➡ **Front Sensor Camera** P. 475	

Continued

Indicator	Name	On/Blinking	Explanation	Message
	Adaptive Cruise Control (**ACC**) with Low Speed Follow (LSF) Indicator (Amber)	• Comes on for a few seconds when you set the power mode to ON, then goes off. • Comes on if there is a problem with ACC with LSF.	• **Comes on while driving** - Have your vehicle checked by a dealer.	
	Adaptive Cruise Control (**ACC**) with Low Speed Follow (LSF) Indicator (Green)	• Comes on when you press the **MAIN** button.	➡ **Adaptive Cruise Control (ACC) with Low Speed Follow (LSF)** P. 477	—
		• Comes on if anything covers the radar sensor cover and prevents the sensor from detecting a vehicle in front. • May come on when driving in bad weather (rain, snow, fog, etc.) • ACC has been automatically canceled.	• When the radar sensor gets dirty, stop your vehicle in a safe place, and wipe off dirt using a soft cloth. • Have your vehicle checked by a dealer if the message does not disappear even after you clean the sensor cover.	

Indicator	Name	On/Blinking	Explanation	Message
	Adaptive Cruise Control (**ACC**) with Low Speed Follow (LSF) Indicator (Green)	• Comes on when ACC with LSF is in operation, but the temperature inside the front sensor camera is too high. ACC with LSF cancels automatically. The beeper sounds simultaneously.	• Use the climate control system to cool down the camera. • **Goes off** - The camera has been cooled down and the system activates normally.	
		• Comes on when the area around the camera is blocked by dirt, mud, etc. Stop your vehicle in a safe place, and wipe it off with a soft cloth. • May come on when driving in bad weather (rain, snow, fog, etc.)	• Have your vehicle checked by a dealer if the indicator and message come back on after you cleaned the area around the camera.	



Indicator	Name	On/Blinking	Explanation	Message
	Collision Mitigation Braking System™ (CMBS™) Indicator	• Comes on for a few seconds when you set the power mode to ON, then goes off. • Comes on when you deactivate the CMBS™. A multi-information display message appears for five seconds. • Comes on if there is a problem with the CMBS™.	• **Stays on constantly without the CMBS™ off** - Have your vehicle checked by a dealer. ➡ **Collision Mitigation Braking System™ (CMBS™)** P. 525	 

Indicator	Name	On/Blinking	Explanation	Message
	Collision Mitigation Braking System™ (CMBS™) Indicator	• Comes on when the CMBS™ system shuts itself off.	• **Stays on** - The area around the camera is blocked by dirt, mud, etc. Stop your vehicle in a safe place, and wipe it off with a soft cloth. ➡ **Front Sensor Camera** P. 475	
			• When the radar sensor gets dirty, stop your vehicle in a safe place, and wipe off dirt using a soft cloth. • Have your vehicle checked by a dealer if the message does not disappear even after you clean the sensor cover. ➡ **Collision Mitigation Braking System™ (CMBS™)** P. 525	
			• **Stays on** - The temperature inside the camera is too high. Use the climate control system to cool down the camera. The system activates when the temperature inside the camera cools down. ➡ **Front Sensor Camera** P. 475	


Indicator	Name	On/Blinking	Explanation	Message
	Blind spot information System Indicator	• Comes on for a few seconds when you set the power mode to ON, then goes off. • Stays on while blind spot information system is turned off.	➔ **Customized Features** P. 131	
		• Comes on when mud, snow, or ice accumulates in the vicinity of sensor.	• **Comes on while driving** - Remove the obstacle in the vicinity of sensor. ➔ **Blind spot information System** P. 509	
		• Comes on if there is a problem with the system.	• **Comes on while driving** - Have your vehicle checked by a dealer.	



Multi-Information Display (MID) Warning and Information Messages

The following messages appear only on the MID. Roll the multi-function steering-wheel controls to see the message again with the system message indicator on.



Message	Condition	Explanation
	• Appears if any door or the tailgate is not completely closed.	• Goes off when all doors and the tailgate are closed.
	• Appears when the hood is opened.	• Close the hood.

Continued

Message	Condition	Explanation
	• Appears when the washer fluid is low.	• Refill washer fluid. ➔ **Refilling Window Washer Fluid** P. 581
	• Appears while you are customizing the settings and the transmission is in other than P.	➔ **Customized Features** P. 131
	• Appears when there is a problem with the sensor on the 12-volt battery.	• Have your vehicle checked by a dealer. ➔ **Checking the 12-Volt Battery** P. 600
	• Appears along with the battery charging system indicator when the battery is not charging.	• Turn off the climate control system and rear defogger to reduce electricity consumption. ➔ **If the 12-Volt Battery Charging System Indicator Comes On** P. 641


Message	Condition	Explanation
	• Appears when the scheduled maintenance is due soon. • Consequently, **Maintenance Due Now** and **Maintenance Past Due** follow.	**Maintenance Minder Messages on the Multi-Information Display (MID)** P. 566
U.S.  Canada 	• Appears when there is a problem with the power tailgate system.	• Manually open or close the power tailgate. • Have your vehicle checked by a dealer.




Message	Condition	Explanation
U.S.  Canada 	• Appears if there is a problem with the starter system.	• Hold the **POWER** button up to 15 seconds to start the power system. ➡ **Turning on the Power** P. 457 Have your vehicle checked by a dealer.
	• Appears when you set the power mode to ACCESSORY or ON.	➡ **Turning on the Power** P. 457
	• Appears three seconds after you bring the keyless access remote in front of the **POWER** button when **To Start, Hold Remote Near Start Button** appears. **To Start Engine: Brake + Push** appears sequentially.	• Unless you bring the keyless access remote in front of the **POWER** button, this message does not appear. ➡ **If the Keyless Access Remote Battery is Weak** P. 635





Message	Condition	Explanation
	• Appears when the power mode is in ACCESSORY.	—
	• Appears after the driver's door is opened when the power mode is in ACCESSORY.	• Change the power mode to VEHICLE OFF. ➡ **POWER Button** P. 172
	• Appears when you close the door with the power mode is in ON without the keyless access remote inside the vehicle.	• Disappears when you bring the keyless access remote back inside the vehicle and close the door. ➡ **Keyless Access Remote Reminder** P. 174
	• Appears when the keyless access remote's battery becomes weak.	➡ **Replacing the Button Battery** P. 601
	• Appears if the keyless access remote's battery is too weak to start the power system or the key is not within operating range to start the power system. The beeper sounds six times.	• Bring the keyless access remote in front of the **POWER** button to be touched with. ➡ **If the Keyless Access Remote Battery is Weak** P. 635

Continued






Message	Condition	Explanation
	• Appears when the transmission system temperature is too high.	• Immediately stop in a safe place in P. • Let the engine idle until the message disappears.
	• Appears when you turn the power system on with the transmission not in P.	• Press the P button.
	• Appears if there is a problem with the electric system. • Appears when you set the power mode to OFF while driving.	• Immediately stop in a safe place and set the parking brake. • Continue driving if the message goes off soon after. • If there is a problem with the transmission system, the transmission system indicator comes on. ➡ **Transmission System Indicator** P. 90
	• Appears if you depress the accelerator pedal when the transmission is in N.	• Release the accelerator pedal. After that, depress the brake pedal and change the transmission position.




Message	Condition	Explanation
	• Appears when you attempt to put the transmission into another gear position with the transmission in P and the engine OFF.	• To select another gear position while in P the engine must be ON.
	• Appears when you try to change the gear position after the position has automatically been changed to P with the driver's door open and the driver's seat belt unfastened.	• Press the P button If you leave the vehicle.
	• Appears when the vehicle is stopped with the driver's seat belt unfastened and there is a chance that the vehicle may roll unintentionally.	• Press the P button before release the brake pedal when idling, parking or exiting the vehicle. ➡ **Shift Operation** P. 467
	• Appears for a few seconds if you have not pressed the N button long enough to initiate Neutral-Hold mode.	➡ **If you want to keep the transmission in N position [car wash mode]** P. 469
	• Appears when you press and hold N button for more than 2 seconds.	• Disappears when you set the gear position to other than N. ➡ **If you want to keep the transmission in N position [car wash mode]** P. 469

Message	Condition	Explanation
	• Appears when you try to change the gear position without depressing the brake pedal.	• Depress the brake pedal, then select a shift button.
	• Appears when you try to change the gear position without releasing your foot off the accelerator pedal.	• Release your foot off the accelerator pedal, then select a shift button.
	• Appears when the P button is pressed while the vehicle is moving. • Appears if you change the gear position to R while the vehicle is moving forward, or to D while the vehicle is reversing.	• Make sure that the vehicle comes to a stop before operating the select button.
	• Appears when you set the power mode to ON without fastening the driver's seat belt. • Appears when you change the gear position after P has been automatically selected with the driver's door open, the driver's seat belt unfastened, then the brake pedal is released.	• Fasten the seat belt properly before you start to drive. ➡ **Shift Operation** P. 467
	• Appears when you press the P button but it is not engaged due to low ATF temperature.	• Depress the brake pedal until this message disappear.

Message	Condition	Explanation
	• Appears when pressing the **Dynamic Mode** button. ▶ Press again to change the next mode.	**Integrated Dynamics System** P. 474
	• Appears if there is a problem with the active damper system.	• Have your vehicle checked by a dealer. With this icon on, your vehicle has limited damping ability without the active damper system.
	• Appears if there is a problem with the cooling system.	• Drive slowly to prevent overheating and have your vehicle checked by a dealer as soon as possible.
	• Appears when there is a problem with the headlights.	• **Appears while driving** - The headlights may not be on. When conditions allow you to drive safety, have your vehicle checked by a dealer as soon as possible.
	• Appears if there is a problem with the parking sensor system.	• Check if the area around the sensor(s) is covered with mud, ice, snow, etc. If the indicator(s) stays on or the beeper does not stop even after you clean the area, have the system checked by a dealer.

Continued



Message	Condition	Explanation
	• Appears if the automatic brake hold is automatically canceled while it is in operation.	• Immediately depress the brake pedal.
	• Appears when the automatic brake hold system is turned off.	➔ **Automatic Brake Hold** P. 521
	• Appears when the automatic brake hold button is pressed without wearing the driver's seat belt.	• Fasten the driver's seat belt. ➔ **Automatic Brake Hold** P. 521
	• Appears when the automatic brake hold button is pressed without depressing the brake pedal while the automatic brake hold is in operation.	• Press the automatic brake hold button with the brake pedal depressed. ➔ **Automatic Brake Hold** P. 521
	• Appears when the parking brake is applied automatically while it is in operation.	➔ **Automatic Brake Hold** P. 521 ➔ **Parking Brake** P. 517




Message	Condition	Explanation
	• Appears if there is a problem with the Auto high-beam.	• Manually operate the headlight switch. • If you are driving with the high-beam headlights when this happens, the headlights are changed to low beams.
	• Appears if the temperature inside the camera is too high and either the auto high beams are in operation or the headlight switch is turned to **AUTO**.	• Use the climate control system to cool down the camera. • **Goes off** - The camera has cooled down. To resume the system, turn the headlight switch to **AUTO**. ➡ **Front Sensor Camera** P. 475
	• Appears when the area around the camera is blocked by dirt, mud, etc. Stop your vehicle in a safe place, and wipe it off with a soft cloth. • May appear when driving in bad weather (rain, snow, fog, etc.)	• Have your vehicle checked by a dealer if the message comes back on after you have cleaned the area around the camera.
	• Appears after the 12-volt battery charging system indicator comes on.	• Your vehicle has less ability to accelerate and may be harder to start on an incline. • Contact a dealer immediately.
	• Appears if there is a problem with the acoustic vehicle alerting system.	• Have your vehicle checked by a dealer immediately.

Continued



Message	Condition	Explanation
	• Appears when the high voltage battery temperature is too low to operate (approx. –22°F [–30°C] or below).	• You can start the engine and use the climate control system to warm up the interior, which will also warm the high voltage battery enough for you to drive the vehicle. • The engine speed does not increase even if you fully depress the accelerator pedal.
	• Appears when the high voltage battery and other system control temperatures are too low to operate (approx. –40°F [–40°C] or below).	• You must wait for an increase in the ambient temperature or move the vehicle to a warmer location. • Consult a dealer.
	• Appears when the high voltage battery is running extremely low due to continuous slow driving.	• Driving at low speed for a long time decreases the amount of electricity generated, leading to high voltage battery drain.
	• Appears when the high voltage battery is drained even further and a stop is needed to charge the battery.	• Stop in a safe place in P, then charge the high voltage battery by idling the engine. ➡ **If the 12-Volt Battery Charging System Indicator Comes On** P. 641
	• Appears while the high voltage battery is being charged with the engine running after the vehicle is parked with an extremely low battery level.	• Do not drive the vehicle until **Ready To Drive** appears. ➡ **READY Indicator** P. 92



Message	Condition	Explanation
	• Appears when the rear motor fluid temperature is extremely low.	• The vehicle speed is temporarily limited up to 81 mph (130 km/h). This is canceled after the fluid temperature rises.
	• Appears if the AWD system has a problem due to a hybrid system or power distribution control failure.	• Set the power mode to OFF, then set it back to ON. Have your vehicle checked by a dealer if the message appears again.

Message	Condition	Explanation
	• Flashes when the system senses a likely collision with a vehicle in front of you.	• Take the appropriate means to prevent a collision (apply the brakes, change lanes, etc.) ➡ **Collision Mitigation Braking System™ (CMBS™)** P. 525 ➡ **Adaptive Cruise Control (ACC) with Low Speed Follow (LSF)** P. 477
	• Appears when ACC with LSF has been automatically canceled.	• You can resume the set speed after the condition that caused ACC with LSF to cancel improves. Press the **RES/+/SET/–** switch up. ➡ **Adaptive Cruise Control (ACC) with Low Speed Follow (LSF)** P. 477
	• Appears when the vehicle speed slows down to 25 mph (40 km/h) and the vehicle ahead of you goes out of the ACC with LSF range while ACC with LSF is in operation.	• ACC with LSF has been automatically canceled. ➡ **Adaptive Cruise Control (ACC) with Low Speed Follow (LSF)** P. 477
	• Appears when pressing the **RES/+/SET/–** switch down while the vehicle speed is less than 25 mph (40 km/h) and the vehicle ahead of you goes out of the ACC with LSF range.	• ACC with LSF cannot be set. ➡ **Adaptive Cruise Control (ACC) with Low Speed Follow (LSF)** P. 477
	• Appears when the distance between your vehicle and the vehicle ahead of you is too close while ACC with LSF is in operation.	• ACC with LSF has been automatically canceled. ➡ **Adaptive Cruise Control (ACC) with Low Speed Follow (LSF)** P. 477

Message	Condition	Explanation
	• Appears when pressing the **RES/+/SET/–** switch down while the distance between your vehicle and the vehicle ahead of you is too close.	• ACC with LSF cannot be set. ➡ **Adaptive Cruise Control (ACC) with Low Speed Follow (LSF)** P. 477
	• Appears when pressing the **RES/+/SET/–** switch down while the driver's seat belt is unfastened.	• ACC with LSF cannot be set. ➡ **Adaptive Cruise Control (ACC) with Low Speed Follow (LSF)** P. 477
	• Appears when pressing the **RES/+/SET/–** switch down while the transmission is not in D.	• ACC with LSF cannot be set. ➡ **Adaptive Cruise Control (ACC) with Low Speed Follow (LSF)** P. 477

Continued

Message	Condition	Explanation
	• Appears when the vehicle is stopped on a very steep slope while ACC with LSF is in operation.	• ACC with LSF has been automatically canceled. ➔ **Adaptive Cruise Control (ACC) with Low Speed Follow (LSF)** P. 477
	• Appears when pressing the **RES/+/SET/–** switch down while the vehicle is stopped on a very steep slope.	• ACC with LSF cannot be set. ➔ **Adaptive Cruise Control (ACC) with Low Speed Follow (LSF)** P. 477
	• Appears when pressing the **RES/+/SET/–** switch down while the parking brake is applied.	• ACC with LSF cannot be set. ➔ **Adaptive Cruise Control (ACC) with Low Speed Follow (LSF)** P. 477 ➔ **Parking Brake** P. 517

Message	Condition	Explanation
	• Appears if ACC with LSF is canceled while your vehicle is automatically stopped by ACC with LSF. The beeper sounds.	• Immediately depress the brake pedal.
	• Appears when pressing the **RES/+/SET/–** switch down while the vehicle is moving and the brake pedal is depressed.	• ACC with LSF cannot be set. ➡ **Adaptive Cruise Control (ACC) with Low Speed Follow (LSF)** P. 477
	• Appears when you unlock and open the driver's door while the power system is on by two-way keyless access remote.	➡ **Remote Engine Start with Vehicle Feedback** P. 459

Continued

Message	Condition	Explanation
 	Lane Keeping Assist System (LKAS) • Appears when the vehicle is driving out of a detected lane. The steering wheel vibrates rapidly.	• Keep the vehicle within the lane you are driving. ➔ **Lane Keeping Assist System (LKAS)** P. 497
	Road Departure Mitigation (RDM) System • Appears when the vehicle is driving out of a detected lane. When you selected **Warning Only** - The steering wheel vibrates rapidly when the vehicle is drifting out of a detected lane. When you selected **Normal** or **Wide** - The steering wheel vibrates rapidly when the vehicle is drifting out of a detected lane. The system also steers the vehicle to help you remain within your driving lane.	• Keep the vehicle within the lane you are driving. ➔ **Road Departure Mitigation (RDM) System** P. 492 • You can change the setting for the road departure mitigation system. **Normal**, **Wide**, and **Warning Only** can be selected. ➔ **Customized Features** P. 131
	• Blinks when you fail to steer the vehicle. The beeper sounds simultaneously.	• Operate the steering wheel to resume the LKAS.
	• Appears when the LKAS is in operation, or the LKAS button is pressed, but there is a problem with a system related to the LKAS. The LKAS cancels automatically. The beeper sounds simultaneously.	• If any other system indicators come on, such as the VSA®, ABS and brake system, take appropriate action. ➔ **Indicators** P. 84

Gauges

Gauges include the speedometer, tachometer, fuel gauge, high voltage battery charge level gauge, and related indicators. They are displayed when the power mode is in ON.

■ Speedometer

Displays your driving speed in mph (U.S.) or km/h (Canada).

■ Tachometer

Shows the number of engine revolutions per minute.

■ Fuel Gauge

Displays the amount of fuel left in the fuel tank.

»Fuel Gauge

NOTICE

You should refuel when the reading approaches E. Running out of fuel can cause the engine to misfire, damaging the catalytic converter.

The actual amount of remaining fuel may differ from the fuel gauge reading.

Continued

■ High Voltage Battery Charge Level Gauge

Shows the remaining high voltage battery charge level.

High Voltage Battery Charge Level Gauge

The high voltage battery charge level may decrease under the following conditions:

- When the 12-volt battery has been replaced.
- When the 12-volt battery has been disconnected.
- When the high voltage battery control system corrects its reading.

The charge level reading will be corrected automatically while driving.

Changes in the temperature of the high voltage battery can increase or decrease the battery's charging capacity. If temperature changes cause the battery's capacity to change, the number of indicators in the battery charge level gauge may also change, even if the amount of charging remains the same.


MID

The MID shows the odometer, trip meter, outside temperature indicator, and other gauges. It also displays important messages such as warnings and other helpful information.

■ Switching the Display

■ Main displays


Roll the multi-function steering-wheel controls to change the display.



Continued

■ **Lower displays**

Press the **TRIP** button to change the display.



■ Odometer

Shows the total number of miles (U.S.) or kilometers (Canada) that your vehicle has accumulated.

■ Trip Meter

Shows the total number of miles (U.S.) or kilometers (Canada) driven since the last reset. Meters A and B can be used to measure two separate trips.

■ Resetting a trip meter

To reset a trip meter, display it, then press and hold the **TRIP** button until the trip meter is reset to **0.0**.

Trip Meter

Switch between trip meter A and trip meter B by pressing the **TRIP** button.

■ Outside Temperature

Shows the outside temperature in Fahrenheit (U.S.) or Celsius (Canada).

■ Adjusting the outside temperature display

Adjust the temperature reading up to ±5°F or ±3°C if the temperature reading seems incorrect.

Outside Temperature

The temperature sensor is located in the front bumper.
Road heat and exhaust from another vehicle can affect the temperature reading when your vehicle speed is less than 19 mph (30 km/h).

It may take several minutes for the display to be updated after the temperature reading has stabilized.

Use the MID's customized features to correct the temperature.

➡ **Customized Features** P. 131

■ Average Fuel Economy

Shows the estimated average fuel economy of each trip meter in mpg (U.S.) or l/100 km (Canada). The display is updated at set intervals. When a trip meter is reset, the average fuel economy is also reset.

Average Fuel Economy

You can change when to reset the average fuel economy.

➡ **Customized Features** P. 131

Continued

■ Instant Fuel Economy

Shows the instant fuel economy as a bar graph in mpg (U.S.) or l/100 km (Canada).

■ Range

Shows the estimated distance you can travel on the remaining power and fuel. This estimated distance is based on the vehicle's current fuel economy.

■ Elapsed Time

Shows the time elapsed since Trip A or Trip B was reset.

■ Average Speed

Shows the average speed in mph (U.S.) or km/h (Canada) since Trip A or Trip B was reset.


Elapsed Time

You can change when to reset the elapsed time.
➔ **Customized Features** P. 131

Average Speed

You can change when to reset the average speed.
➔ **Customized Features** P. 131

SH-AWD® Torque Distribution Monitor



The indicators on the display show the amount of torque being transferred to the right front, left front, right rear, and left rear wheels.

➡ **SPORT HYBRID Super Handling-All Wheel Drive™ (SPORT HYBRID SH-AWD®)** P. 508

Current Mode for Dynamic Mode

Shows the current mode for Dynamic Mode.

➡ **Integrated Dynamics System** P. 474

Turn-by-Turn Directions

Shows you turn-by-turn driving directions to your destination linked with the navigation system.

➡ **Refer to the navigation system**

Turn-by-Turn Directions

The multi-information display shows a compass when the route guidance is not used.

You can select whether the turn-by-turn display comes on or not during the route guidance.

➡ **Customized Features** P. 131, 362

Continued

■ Engine Oil Life and Maintenance Items

Shows the remaining oil life and Maintenance Minder™.

➢ **Maintenance Minder™** P. 565

■ Tire Pressure Monitor

Shows each tire's pressure.


➢ **Tire Pressure Monitoring System (TPMS) with Tire Fill Assist** P. 512

■ Customized Features

Use the MID to customize certain features.

■ How to customize

Select the **Vehicle Settings** screen by rolling the multi-function steering-wheel controls while the power mode is in ON, and the vehicle is at a complete stop. Push the multi-function steering-wheel controls.



Customized Features

To customize other features, roll the multi-function steering-wheel controls.

➡ **List of customizable options** P. 134
➡ **Example of customization settings** P. 139

Customization is possible when you see the driver's ID (**Driver 1** or **Driver 2**) on the screen.
The driver's ID indicates which remote transmitter you have used to unlock the driver's door. The customized settings are recalled every time you unlock the driver's door with that remote.

Put the transmission into P before you attempt to change any customized setting.


Customizing is also available from the information screen.
You cannot have **Vehicle Settings** displayed on the multi-information display while the information screen shows the same menu.


➡ **Customized Features** P. 362

Continued

■ **Customization flow**

Roll the multi-function steering-wheel controls to select **Vehicle Settings** and push the multi-function steering-wheel controls.





* Not available on all models

Continued

■ **List of customizable options**

Setup Group	Customizable Features	Description	Selectable Settings
Driver Assist System Setup	**Forward Collision Warning Distance**	Changes at which distance forward collision warning alerts.	**Long/Normal**[*1]**/Short**
	ACC Forward Vehicle Detect Beep	Causes the system to beep when the system detects a vehicle, or when the vehicle goes out of the ACC with LSF range.	**On/Off**[*1]
	ACC Display Speed Unit	Changes the speed unit for ACC with LSF on the MID.	**mph**[*1]**/km/h** (U.S.) **mph/km/h**[*1] (Canada)
	Road Departure Mitigation Setting	Changes the setting for the road departure mitigation system.	**Normal**[*1]**/Wide/Warning Only**
	Lane Keeping Assist Suspend Beep	Causes the system to beep when the LKAS is suspended.	**On/Off**[*1]
	Blind Spot Info	Changes the setting for the blind spot information.	**Audible And Visual Alert**[*1]**/ Visual Alert/Off**

*1:Default Setting

Setup Group	Customizable Features	Description	Selectable Settings
Meter Setup	**Language Selection**	Changes the displayed language.	**English**[*1]**/Français/Español**
	Adjust Outside Temp. Display	Adjusts the temperature reading by a few degrees.	**-5°F** ~ **±0°F**[*1] ~ **+5°F** (U.S.)
			-3°C ~ **±0°C**[*1] ~ **+3°C** (Canada)
	"Trip A" Reset Timing	Changes the setting of how to reset trip meter A, average fuel economy A, average speed A, and elapsed time A.	**When Refueled/IGN Off/ Manually Reset**[*1]
	"Trip B" Reset Timing	Changes the setting of how to reset trip meter B, average fuel economy B, average speed B, and elapsed time B.	**When Refueled/IGN Off/ Manually Reset**[*1]
	Reverse Alert Tone	Causes the beeper to sound once when the change the gear position to R.	**On**[*1]**/Off**
	Turn by Turn Display	Select whether the turn-by-turn display comes on during the route guidance.	**On**[*1]**/Off**

*1:Default Setting

Continued

Setup Group	Customizable Features	Description	Selectable Settings
Driving Position Setup	**Memory Position Link**	Turns the driving position memory system on and off.	**On**[*1]**/Off**
	Easy Entry/Exit	Moves the seat rearward and steering wheel fully up when you get in/get out of the vehicle. Changes the setting for this feature.	**Seat & Steering Wheel**[*1]**/ Seat Only/Steering Wheel Only/Off**
Keyless Access Setup	**Door Unlock Mode**	Changes which doors unlock when you grab the driver's door handle.	**Driver's Door or Tailgate Only**[*1]**/All Doors**
	Keyless Access Light Flash	Causes some exterior lights to flash when you unlock/lock the doors.	**On**[*1]**/Off**
	Keyless Access Beep	Causes the beeper to sound when you unlock/lock the doors.	**On**[*1]**/Off**
	Remote Start System On/Off	Turns the remote engine start feature on and off.	**On**[*1]**/Off**
	Walk Away Auto Lock	Changes the settings for the automatic locking the doors when you walk away from the vehicle while carrying the keyless access remote.	**On/Off**[*1]

*1: Default Setting

Setup Group	Customizable Features	Description	Selectable Settings
Lighting Setup	**Interior Light Dimming Time**	Changes the length of time the interior lights stay on after you close the doors.	**60sec/30sec*1/15sec**
	Headlight Auto Off Timer	Changes the length of time the exterior lights stay on after you close the driver's door.	**60sec/30sec/15sec*1/0sec**
	Auto Light Sensitivity*	Changes the timing for the headlights to come on.	**Max/High/Mid*1/Low/Min**
Door Setup	**Auto Door Lock**	Changes the setting for when the doors automatically lock.	**With Vehicle Speed*1/Shift From P/Off**
	Auto Door Unlock	Changes the setting for when the doors automatically unlock.	**All Doors When Driver's Door Opens*1/All Doors When Shifted To Park/All Doors When Ignition Switched Off/Off**
	Key And Remote Unlock Mode	Sets up either the driver's door or all doors to unlock on the first operation of the remote or built-in key.	**Driver Door*1/All Doors**
	Keyless Lock Answer Back	LOCK/UNLOCK- The exterior lights flash. LOCK (2nd push)- The beeper sounds.	**On*1/Off**
	Security Relock Timer	Changes the time it takes for the doors to relock and the security system to set after you unlock the vehicle without opening any door.	**90sec/60sec/30sec*1**
	Auto Folding Door Mirror	Changes how you can fold the door mirrors.	**Auto Fold With Keyless*1/ Manual Only**

*1: Default Setting

* Not available on all models


Continued

Setup Group	Customizable Features	Description	Selectable Settings
Power Tailgate Setup	**Keyless Open Mode**	Changes the keyless setting for when the power tailgate opens.	**Anytime**[*1]**/When Unlocked**
	Power Open By Outer Handle	Changes the setting to open power tailgate by tailgate outer handle.	**Off (Manual Only)/On (Power/Manual)**[*1]
Dynamic Mode Setup	**Preferred Dynamic Mode**	Changes the Dynamic Mode setting for when you set the power mode to ON.	**Last Used**[*1]**/Comfort/ Normal/Sport**
Maintenance Info.	**Maintenance Reset**	Resets/Cancels the engine oil life display when you have performed the maintenance service.	**Cancel/Reset**
Default All	—	Cancels/Resets all the customized settings as default.	**Cancel/Set**

*1: Default Setting

■ **Example of customization settings**

The steps for changing the **"Trip A" Reset Timing** setting to **When Refueled** are shown below. The default setting for **"Trip A" Reset Timing** is **Manually Reset**.



1. Roll the multi-function steering-wheel controls to select **Vehicle Settings**, then push the multi-function steering-wheel controls.



2. Roll the multi-function steering-wheel controls until **Meter Setup** appears on the display.


3. Push the multi-function steering-wheel controls.

▶ **Language Selection** appears first on the display.

Continued



4. Roll the multi-function steering-wheel controls until **"Trip A" Reset Timing** appears on the display, then push the multi-function steering-wheel controls.
▶ The display switches to the customization setup screen, where you can select **When Refueled**, **IGN Off**, **Manually Reset**, or **Exit**.




5. Roll the multi-function steering-wheel controls and select **When Refueled**, then push the multi-function steering-wheel controls.
▶ The **When Refueled Setup** screen appears, then the display returns to the customization menu screen.



6. Roll the multi-function steering-wheel controls until **Exit** appears on the display, then push the multi-function steering-wheel controls.
7. Repeat Step 6 until you return to the normal screen.

Controls

This chapter explains how to operate the various controls necessary for driving.



Clock 142
Locking and Unlocking the Doors
Key Types and Functions 143
Low Keyless Access Remote Signal Strength 144
Locking/Unlocking the Doors from the Outside 145
Locking/Unlocking the Doors from the Inside 154
Childproof Door Locks 156
Auto Door Locking/Unlocking 157
Opening and Closing the Tailgate ... 158
Security System
Immobilizer System 166
Security System Alarm 166
Opening and Closing the Windows ... 169
Moonroof 171
Operating the Switches Around the Steering Wheel
POWER Button 172
Turn Signals 175
Light Switches 176
Fog Lights* 179
Daytime Running Lights 179
Auto High-Beam 180
Wipers and Washers 183
Brightness Control 187
Rear Defogger/Heated Door Mirror Button . 188
Driving Position Memory System 189
Adjusting the Steering Wheel 191
Adjusting the Mirrors
Interior Rearview Mirror 192
Power Door Mirrors 193
Adjusting the Seats
Front Seats 195
Second Row Seats 198
Third Row Seats 207
Armrest 208
Interior Lights/Interior Convenience Items
Interior Lights 210
Interior Convenience Items 212
Climate Control System
Using Automatic Climate Control 223
Rear Climate Control System 230
Automatic Climate Control Sensors ... 234


* Not available on all models

Adjusting the Clock

The clock is automatically updated through the navigation system, so the time does not need to be adjusted.
You can adjust the time manually in the information screen, with the power mode in ON.

■ Adjusting the Time

■ Using the Settings menu on the information screen



1. Press the **SETTINGS** button.
2. Rotate ⟲ to select **Clock Settings**, then press ⊙.
   ▶ Repeat the procedure to select **Clock Adjustment**.
3. Rotate ⟲ to change hour, then move ⊙▷.
4. Rotate ⟲ to change minute, then press ⊙.

Clock

These indications are used to show how to operate the interface dial.
Rotate ⟲ to select.
Press ⊙ to enter.
Move ⊙▷ to select a secondary menu.

You can customize the clock display to show the 12 hour clock or 24 hour clock.
➡ **Customized Features** P. 362

You can turn the clock display in the information screen on and off.
➡ **Customized Features** P. 362

Except Canadian models
You cannot adjust the time while the vehicle is moving.


Key Types and Functions

This vehicle comes with the following keys:



Use the keys to turn on and off the power system, and to lock and unlock all the doors and tailgate. You can also use the keyless access system to lock and unlock all the doors and tailgate.

Built-in Key



The built-in key can be used to lock/unlock the doors when the keyless access remote battery becomes weak and the power door lock/unlock operation is disabled.

To remove the built-in key, slide the release knob and then pull out the key. To reinstall the built-in key, push the built-in key into the keyless access remote until it clicks.

Key Types and Functions

All the keys have an immobilizer system. The immobilizer system helps to protect against vehicle theft.

➡ **Immobilizer System** P. 166

Follow the advice below to prevent damage to the keys:

- Do not leave the keys in direct sunlight, or in locations with high temperature or high humidity.
- Do not drop the keys or set heavy objects on them.
- Keep the keys away from liquids, dust and sand.
- Do not take the keys apart except for replacing the battery.


If the circuits in the keys are damaged, the power system may not activate, and the keyless access system may not work.
If the keys do not work properly, have them inspected by a dealer.

You can remotely turn the power system on using the two-way keyless access remote.

➡ **Remote Engine Start with Vehicle Feedback** P. 459

Continued

■ Key Number Tag



Contains a number that you will need if you purchase a replacement key.

Low Keyless Access Remote Signal Strength

The vehicle transmits radio waves to locate the keyless access remote when locking/unlocking the doors and tailgate, or to activate the power system.

In the following cases, locking/unlocking the doors and tailgate, or activating the power system may be inhibited or operation may be unstable:

- Strong radio waves are being transmitted by nearby equipment.
- You are carrying the keyless access remote together with telecommunications equipment, laptop computers, cell phones, or wireless devices.
- A metallic object is touching or covering the keyless access remote.

Key Number Tag

Keep the key number tag separate from the key in a safe place outside of your vehicle.
If you wish to purchase an additional key, contact a dealer.


If you lose your key and you cannot activate the power system, contact a dealer.

Low Keyless Access Remote Signal Strength

Communication between the keyless access remote and the vehicle consumes the keyless access remote's battery.
Battery life is about two years, but this varies depending on regularity of use.
The battery is consumed whenever the keyless access remote is receiving strong radio waves. Avoid placing it near electrical appliances such as televisions and personal computers.

Locking/Unlocking the Doors from the Outside

■ Using the Keyless Access System



When you carry the keyless access remote, you can lock/unlock the doors and the tailgate.

You can lock/unlock the doors and tailgate within a radius of about 32 inches (80 cm) of the outside door handle or tailgate outer handle.

Locking/Unlocking the Doors from the Outside

If the interior light switch is in the door activated position, the interior light comes on when you unlock the doors and tailgate.
No doors opened: The light fades out after 30 seconds.
Doors and tailgate relocked: The light goes off immediately.


➡ **Interior Lights** P. 210


Using the Keyless Access System

If you do not open a door or the tailgate within 30 seconds of unlocking the vehicle with the keyless access system, the doors and tailgate will automatically relock.

You can lock or unlock doors using the keyless access system only when the power mode is in VEHICLE OFF.

Continued






■ Locking the doors and tailgate


Press the door lock button on the front or rear doors, or on the tailgate.

▶ Some exterior lights flash; the beeper sounds; all the doors and tailgate lock; and the security system sets.

Using the Keyless Access System

- Do not leave the keyless access remote in the vehicle when you get out. Carry it with you.
- Even if you are not carrying the keyless access remote, you can lock/unlock the doors and tailgate while someone else with the remote is within range.
- The door may be unlocked if the door handle is covered with water in heavy rain or in a car wash if the keyless access remote is within range.
- If you grip a door handle wearing gloves, the door sensor may be slow to respond or may not respond by unlocking the doors.
- After locking the door, you have up to two seconds during which you can pull the door handle to confirm whether the door is locked. If you need to unlock the door immediately after locking it, wait at least two seconds before gripping the handle, otherwise the door will not unlock.
- The door might not open if you pull it immediately after gripping the door handle. Grip the handle again and confirm that the door is unlocked before pulling the handle.
- Even within the 32 inches (80 cm) radius, you may not be able to lock/unlock the doors with the keyless access remote if it is above or below the outside handle.
- The keyless access remote may not operate if it is too close to the door and door glass.





■ Locking the doors and tailgate (Walk away auto lock®)

When you walk away from the vehicle while carrying the keyless access remote, the doors will automatically lock.

The auto lock function activates when all doors and tailgate are closed, and the keyless access remote is within about 5 feet (1.5 m) radius of the outside door handle.

Exit vehicle while carrying keyless access remote and close door(s).

1. While within about 5 feet (1.5 m) radius of the vehicle.
▶ The beeper sounds; the auto lock function will be activated.

2. Carry the keyless access remote beyond about 5 feet (1.5 m) from the vehicle and remain outside this range for 2 or more seconds.
▶ Some exterior lights flash; the beeper sounds; all doors and tailgate will then lock.

Locking the doors and tailgate (Walk away auto lock®)

The auto lock function is set to OFF as the factory default setting. The auto lock function can be set to ON using the information screen or multi-information display (MID).

If you set the auto lock function to ON using the information screen or the MID, only the remote transmitter that was used to unlock the driver's door prior to the setting change can activate auto lock.

➡ **Customized Features** P. 131, 362

After the auto lock function has been activated, when you stay within the locking/unlocking operation range, the indicator on the keyless access remote will continue to flash until the doors are locked.

When you stay beside the vehicle within the operation range, the doors will automatically lock approximately 30 seconds after the auto lock function activating beeper sounds.

When you open a door after the auto lock function activating beeper sounds, the auto lock function will be delayed until all doors and tailgate are closed.

Under the following circumstances, the auto lock function will not activate:

- The keyless access remote is inside the vehicle.
  ▶The beeper will not sound.
- The keyless access remote is taken out of its operational range before all the doors are closed.
  ▶The beeper will sound.

Continued

To temporarily deactivate the function:

1. Set the power mode to OFF.
2. Open the driver's door.
3. Using the master door lock switch, operate the lock as follows:
Lock → Unlock → Lock → Unlock.
▶ The beeper sounds and the function is deactivated.

To restore the function:

- Set the power mode to ON.
- Lock the vehicle without using the auto lock function.
- With the keyless access remote on you, move out of the auto lock function operation range.
- Open any door.

Locking the doors and tailgate (Walk away auto lock®)

You must wait until the power tailgate fully closes before the auto lock function will be activated.

The auto lock function does not operate when any of the following conditions are met.

- The keyless access remote is inside the vehicle.
- A door or the hood is not closed.
- The power mode is set to any mode other than OFF.
- The keyless access remote is not located within a radius of about 5 feet (1.5 m) from the vehicle when you get out of the vehicle and close the doors.


Auto lock function operation stop beeper


After the auto lock function has been activated, the auto lock operation stop beeper sounds for approximately two seconds in the following cases.

- The keyless access remote is put inside the vehicle through a window.
- You are located too close to the vehicle.
- The keyless access remote is put inside the tailgate.

If the warning beeper sounds, check that you are carrying the keyless access remote. Then, open/close a door and confirm the auto lock activation beeper sounds once.

In the case that the keyless access remote is out of operating range when you close a door or the tailgate, a beeper will sound to indicate that the auto lock function has been canceled.





■ Unlocking the doors and tailgate

Grab the driver's door handle:

▶ The driver's door unlocks.

▶ Some exterior lights flash twice and the beeper sounds twice.

Grab the front passenger's door or rear door handle:

▶ All doors and the tailgate unlock.

▶ Some exterior lights flash twice and the beeper sounds twice.

Press and hold the tailgate outer handle:

▶ The tailgate unlocks and opens.

▶ Some exterior lights flash twice and the beeper sounds twice.

➡ **Opening/Closing the Tailgate** P. 165

Using the Keyless Access System

The light flash, beep and door unlock mode settings can be customized using the information screen or MID.

➡ **Customized Features** P. 131, 362


When you go into the keyless access system working range with all the doors locked, the LED puddle lights come on for 30 seconds.
The lights do not come on if you have previously stayed within the range for more than two minutes, or the doors have been locked for a few days.
The feature activates again after you drive the vehicle, then lock the doors.

You can also unlock and open with the power tailgate.

➡ **Opening/Closing the Tailgate** P. 165

Continued

■ Using the Remote Transmitter



*1: **Checking Door Lock Status** P. 153

■ Locking the doors and tailgate

Press the lock button.

Once:

▶ Some exterior lights flash, all the doors and tailgate lock, and the security system sets.

Twice (within five seconds after the first push):

▶ The beeper sounds and verifies the security system is set.

■ Unlocking the doors and tailgate

Press the unlock button.

Once:

▶ Some exterior lights flash twice, and the driver's door unlocks.

Twice:

▶ The remaining doors and tailgate unlock.

Using the Remote Transmitter

If you do not open a door or the tailgate within 30 seconds of unlocking the vehicle with the remote transmitter, the doors and tailgate will automatically relock.
You can change the relock timer setting.
➡ **Customized Features** P. 131, 362

You can lock or unlock doors using the remote transmitter only when the power mode is in VEHICLE OFF.

The remote transmitter uses low-power signals, so the operating range may vary depending on the surroundings.

The remote will not lock the vehicle when a door or the tailgate is open.


If the distance at which the remote transmitter works varies, the battery is probably low.
If the LED does not come on when you press a button, the battery is dead.
➡ **Replacing the Button Battery** P. 601

You can customize the door unlock mode setting.
➡ **Customized Features** P. 131, 362

■ Locking/Unlocking the Doors Using a Key

If the lock or unlock button of the keyless access remote does not work, use the key instead.

➡ **Replacing the Button Battery** P. 601



Fully insert the key and turn it.

Locking/Unlocking the Doors Using a Key

When you lock the driver's door with a key, all the other doors and tailgate lock at the same time. When unlocking, the driver's door unlocks first. Turn the key a second time within a few seconds to unlock the remaining doors and the tailgate.


You can customize the door unlock mode setting.

➡ **Customized Features** P. 131, 362

Continued

■ Locking a Door Without Using a Key

If you do not have the key on you, or if for some reason you cannot lock a door using the key, you can lock the door without it.



■ Locking the front doors

Push the lock tab forward ❶ or push the master door lock switch in the lock direction ❷, and close the door.

■ Locking the rear doors

Push the lock tab forward and close the door.


■ Lockout prevention system

The doors and tailgate cannot be locked when the keyless access remote is inside the vehicle.

Locking a Door Without Using a Key

When you lock the driver's door, all the other doors and tailgate lock at the same time.
Before locking a door, make sure that the key is not inside the vehicle.

Checking Door Lock Status



You can remotely check if your vehicle's doors are all locked or any are unlocked using the keyless access remote from extended distances.

Press the lock button, the Amber (LEFT) LED blinks once. Then after three seconds one of the following feedback will come:

- Green (center) comes on: Acknowledges that the doors are locked.
- Red (right) comes on: Acknowledges that doors are not locked, or any door is not completely closed.
- Red (right) blinks three times: The remote does not receive the door lock status from the vehicle.

Checking Door Lock Status

Operate the remote in an open space. If there are buildings or other obstacles between your vehicle and the remote, the remote may not work even within the operable range. However, the range required for unlocking the tailgate and all the doors as well as activating the panic function is the same as that required for operating the standard keyless access remote.


Using the Remote Transmitter P. 150

When checking the door lock status, you can also turn the power system on or off.

Remote Engine Start with Vehicle Feedback P. 459

Locking/Unlocking the Doors from the Inside

■ Using the Lock Tab




■ Locking a door
Push the lock tab forward.

■ Unlocking a door
Pull the lock tab rearward.

Using the Lock Tab

When you lock the door using the lock tab on the driver's door, all of the other doors and the tailgate lock at the same time.
When you unlock the door using the lock tab on the driver's door, only the driver's door will unlock.

■ Unlocking Using the Front Door Inner Handle



Pull the front door inner handle.

▶ The door unlocks and opens in one motion.

Unlocking and opening the driver's door from the inner handle unlocks all the other doors.

To avoid all the doors to be unlocked, use the lock tab on the driver's door to unlock, then lock again before opening the door.

▶ This setting works for one time only. If you do not want all the doors to be unlocked all the time, customize the **Auto Door Unlock** setting to **Off** using the MID or information screen.

Unlocking Using the Front Door Inner Handle


The front door inner handles are designed to allow front seat occupants to open the door in one motion. However, this feature requires that front seat occupants never pull a front door inner handle while the vehicle is in motion.

Children should always ride in a rear seat where childproof door locks are provided.

➡ **Childproof Door Locks** P. 156

Continued

■ Using the Master Door Lock Switch



Press the master door lock switch in as shown to lock or unlock all the doors and the tailgate.


Using the Master Door Lock Switch

When you lock/unlock either front door using the master door lock switch, all the other doors and the tailgate lock/unlock at the same time.

Childproof Door Locks

The childproof door locks prevent the rear doors from being opened from the inside regardless of the position of the lock tab.

■ Setting the Childproof Door Locks



Slide the lever in the rear door to the lock position, and close the door.

■ When opening the door

Open the door using the outside door handle.

Childproof Door Locks

To open the door from the inside when the childproof door lock is on, put the lock tab in the unlock position, lower the rear window, put your hand out of the window, and pull the outside door handle.

Auto Door Locking/Unlocking

Your vehicle locks or unlocks all doors automatically when a certain condition is met.

■ Auto Door Locking

■ Drive lock mode

All doors and tailgate lock when the vehicle's speed reaches about 10 mph (15 km/h).

■ Auto Door Unlocking

■ Driver's door open mode

All doors unlock when the driver's door is opened.

Auto Door Locking/Unlocking

You can turn off or change to another auto door locking/unlocking setting using the information screen or MID.

Customized Features P. 131, 362

Precautions for Opening/Closing the Tailgate

Always make sure individuals and objects are clear of the tailgate before opening or closing it.

- Open the tailgate all the way.
  ▶ If it is not fully opened, the tailgate may begin to close under its own weight.
- Be careful when it is windy. The wind may cause the tailgate to close.

Keep the tailgate closed while driving to:
▶ Avoid possible damage.
▶ Prevent exhaust gas from leaking into the vehicle.
➔ **Carbon Monoxide Gas** P. 80

Precautions for Opening/Closing the Tailgate

⚠WARNING

Anyone caught in the path of a tailgate that is being opened or closed can be seriously injured.

Make sure that all people are clear of the tailgate before opening or closing it.

Be careful not to hit your head on the tailgate or to put your hands between the tailgate and the cargo area when closing the tailgate.

When you are storing or picking up luggage from the cargo area while the engine is idling, do not stand in front of the exhaust pipe. You may get burned.

Do not allow any passenger in the cargo space. They may get hurt during hard braking, a sudden acceleration, or a crash.

The power tailgate can be operated by pressing the power tailgate button on the remote transmitter or driver's door, or pressing the outer handle or button on the tailgate.

The power tailgate can be opened when the transmission is in P.

Precautions for Opening/Closing the Tailgate

NOTICE

Do not push or pull on the power tailgate when it is being automatically opened or closed.
Forcibly opening or closing the power tailgate while in operation can deform the tailgate frame.


When operating the power tailgate, make sure there is enough space around your vehicle. People near the tailgate may be seriously hurt if the tailgate hits or closes on their heads. Be especially cautious if children are around.

The power tailgate may not open or close under the following conditions:

- You start the power system while the tailgate is automatically opening or closing.
- The vehicle is parked on a steep hill.
- The vehicle is swayed in a strong wind.
- The tailgate or the roof is covered with snow or ice.

Opening/Closing the Power Tailgate

■ Using the Remote Transmitter



Press the power tailgate button for more than one second to operate when the power mode is in VEHICLE OFF (LOCK).

▶ Some exterior lights flash and the beeper sounds.

If you press the button again while the power tailgate is moving, it reverses direction.

■ Customizing when to open the tailgate

Anytime: The power tailgate unlocks and opens at the same time. This is the default setting.

When Unlocked: The tailgate opens when all doors are unlocked.

Customized Features P. 131, 362

Opening/Closing the Power Tailgate

If you close the power tailgate when all the doors are locked, the power tailgate locks automatically.

If you replace the 12-volt battery or the power tailgate fuse while the tailgate is open, the power tailgate may be disabled. The power tailgate resumes once you manually close the tailgate.


Installing aftermarket components other than Acura genuine accessories on the power tailgate may prevent it from fully opening or closing.

Make sure the power tailgate is fully open before you get your luggage in and out.

Make sure the power tailgate is fully closed before you start the vehicle.

The beeper sounds when you start driving while the power tailgate is still open, or closing.

■ Using the Power Tailgate Button



To open or close the power tailgate, press the power tailgate button for about one second.

▶ Some exterior lights flash and the beeper sounds.

If you press the button again while the power tailgate is moving, it reverses direction.

Opening/Closing the Power Tailgate

If the power tailgate meets resistance while opening or closing, the auto reverse feature reverses the direction. The beeper sounds three times.


The auto reverse function stops sensing when the tailgate is almost closed to make sure that it fully closes.

Do not touch the sensors located on both sides of the tailgate. The power tailgate does not close if you touch either sensor when you are trying to close the tailgate.

Be careful not to scratch the sensors with a sharp object. If scratched, they can be damaged, and the power tailgate closing feature malfunctions.

Continued

■ Using the Tailgate Outer Handle



If you press the outer handle of the tailgate for no longer than one second, the tailgate opens automatically.

▶ The beeper sounds.

▶ If you want to open the tailgate manually, press the outer handle for more than one second.

➡ **Opening/Closing the Tailgate** P. 165

If you are carrying the keyless access remote, you do not have to unlock the tailgate before opening it.

If you press the outer handle again while the power tailgate is moving, it reverses direction.

Using the Tailgate Outer Handle

Do not leave the keyless access remote in the cargo area before closing the tailgate.

Even if you are not carrying the keyless access remote, you can lock/unlock the tailgate while someone else with the remote is within range.

You can change the power tailgate operation setting on and off.

➡ **Customized Features** P. 131, 362

■ Using the Tailgate Inner Button


Tailgate Inner Button

Press the button on the tailgate to close the power tailgate.

▶ The beeper sounds.

If you press the button again while the power tailgate is moving, it reverses direction.

■ Auto-Closer

If you manually close the power tailgate, it latches automatically.

Auto-Closer

The auto-closer feature does not activate if you press and hold the tailgate outer handle while the power tailgate is closing.

Do not put any force on the tailgate while the power tailgate is latching.

Keep your hands away from the tailgate when you manually close the tailgate and let it latch automatically. It is dangerous to put your hands around the tailgate as it starts to latch itself.

Continued

■ Power Tailgate Fall Detection

Automatically lowers the power tailgate when there is a possibility that the fully opened power tailgate can fall down by its own weight (for example, by snow on the tailgate). The beeper sounds while the power tailgate lowers.

Power Tailgate Fall Detection


If you try to manually close the power tailgate immediately after it fully opens, the power tailgate fall detection may activate.

Once the power tailgate fall detection activates, wait until the power tailgate fully closes. Keep away from the power tailgate when it is in motion.

If the power tailgate fall detection constantly activates, consult at a dealer.

Opening/Closing the Tailgate


■ Using the Tailgate Outer Handle



When all the doors are unlocked, the tailgate is unlocked.

Press the outer handle of the tailgate and lift open the tailgate.

If you are carrying the keyless access remote, you do not have to unlock the tailgate before opening it.



To close the tailgate, grab the inner handle, pull the tailgate down, and push it closed from outside.

If you close the tailgate when the driver's door is locked, the tailgate locks automatically.

Opening/Closing the Tailgate

Do not leave the keyless access remote in the cargo area before closing the tailgate.

Even if you are not carrying the keyless access remote, you can lock/unlock the tailgate while someone else with the remote is within range.

Immobilizer System

The immobilizer system prevents a key that has not been pre-registered from starting the power system. Each key contains electronic transmitters that use electronic signals to verify the key.

Pay attention to the following when pressing the **POWER** button:

- Do not allow objects that emit strong radio waves near the **POWER** button.
- Make sure the key is not covered by or touching a metal object.
- Do not bring a key from another vehicle's immobilizer system near the **POWER** button.
- Do not put the key near magnetic items. Electronic devices, such as televisions and audio systems emit strong magnetic fields. Note that even a key chain can become magnetic.

Immobilizer System

NOTICE

Leaving the key in the vehicle can result in theft or accidental movement of the vehicle.
Always take the key with you whenever you leave the vehicle unattended.

Do not alter the system or add other devices to it. Doing so may damage the system and make your vehicle inoperable.

Security System Alarm

The security system alarm activates when the tailgate, hood or doors are forcibly opened. The alarm does not activate if the tailgate or doors are opened with the key, remote transmitter or keyless access system.

However, the alarm activates if a door is opened with the key and then the hood is opened before the power mode is set to ON.

■ When the security system alarm activates

The horn sounds intermittently, and some exterior lights flash.

■ To deactivate the security system alarm

Unlock the vehicle using the key, remote transmitter, or keyless access system. The system, along with the horn and flashing lights, is deactivated.

Security System Alarm

Do not alter the system or add other devices to it. Doing so may damage the system and make your vehicle inoperable.

The security alarm continues for a maximum of two minutes until the security system alarm deactivates.

■ Setting the security system alarm

The security system alarm automatically sets when the following conditions have been met:

- The power mode is set to VEHICLE OFF (LOCK).
- The hood is closed.
- All doors and the tailgate are locked from outside with the key, remote transmitter, or keyless access system.

■ When the security system alarm sets

The security system alarm indicator in the instrument panel blinks. The blinking interval changes after about 15 seconds.

■ To cancel the security system alarm

The security system alarm is canceled when the vehicle is unlocked using the remote transmitter, keyless access system, or the power mode is set to ON. The security system alarm indicator goes off at the same time.

Security System Alarm


Do not set the security system alarm when someone is in the vehicle or a window is open. The system can accidentally activate when:

- Unlocking the door with the lock tab.
- Opening the hood with the hood release.

If the 12-volt battery goes dead after you have set the security system alarm, the security alarm may go off once the 12-volt battery is recharged or replaced. If this occurs, deactivate the security system alarm by unlocking a door using the key, remote transmitter, or keyless access system.

Continued

■ Panic Mode



■ The panic button on the remote transmitter

If you press the panic button for approximately one second, the following will occur for about 30 seconds:

- The horn sounds.
- Some exterior lights flash.

■ Canceling panic mode

- Press any button on the remote transmitter.
- Set the power mode to ON.


Opening/Closing the Power Windows

The power windows can be opened and closed when the power mode is in ON, using the switches on the doors.

The driver's side switches can be used to open and close all the windows. The power window lock button on the driver's side must be switched off (not pushed in, indicator off) to open and close the windows from anywhere other than the driver's seat.

When the power window lock button is pushed in, the indicator comes on and you can only operate the driver's window. Turn the power window lock button on if a child is in the vehicle.

■ Opening/Closing Windows with Auto-Open/Close Function



■ Manual operation

To open: Push the switch down lightly, and hold it until the desired position is reached.
To close: Pull the switch up lightly, and hold it until the desired position is reached.

■ Automatic operation

To open: Push the switch down firmly.
To close: Pull the switch up firmly.

The window opens or closes completely. To stop the window at any time, push or pull the switch briefly.

Continued

Opening/Closing the Power Windows

⚠WARNING

Closing a power window on someone's hands or fingers can cause serious injury.

Make sure your passengers are away from the windows before closing them.

The power windows can be operated for up to 10 minutes after you set the power mode to VEHICLE OFF (LOCK).
Opening either front door cancels this function.


Auto Reverse

If a power window senses resistance when closing automatically, it will stop closing and reverse direction.

The driver's window auto reverse function is disabled when you continuously pull up the switch.

The auto reverse function stops sensing when the window is almost closed to ensure that it fully closes.


■ Opening the Windows and Moonroof with the Remote



To open: Press the unlock button, and then within 10 seconds, press it again and hold it.

If the windows and moonroof stop midway, repeat the procedure.

■ Opening/Closing the Windows and Moonroof with the Key




To open: Unlock the driver's door with the key. Within 10 seconds of returning the key to the central position, turn the key in the unlock direction and hold it there.

To close: Lock the driver's door with the key. Within 10 seconds of returning the key to the central position, turn the key in the lock direction and hold it there.

Release the key to stop the windows and moonroof at the desired position. If you want further adjustment, repeat the same operation.

■ Opening/Closing the Moonroof

You can only operate the moonroof when the power mode is in ON. Use the switch in the front of the ceiling to open and close the moonroof.



■ Automatic operation

To open: Pull the switch back firmly.
To close: Push the switch forward firmly.

The moonroof will automatically open or close all the way. To stop the moonroof midway, push the switch briefly.

■ Manual operation

To open: Pull the switch back lightly, and hold it until the desired position is reached.
To close: Push the switch forward lightly, and hold it until the desired position is reached.

■ Tilting the moonroof up

To tilt: Push on the center of the moonroof switch.
To close: Push the switch forward firmly, then release.

Opening/Closing the Moonroof

⚠WARNING

Opening or closing the moonroof on someone's hands or fingers can cause serious injury.

Make sure all hands and fingers are clear of the moonroof before opening or closing it.

NOTICE

Opening the moonroof in below freezing temperature or when it is covered with snow or ice can damage the moonroof panel or motor.

The power moonroof can be operated for up to 10 minutes after you set the power mode to VEHICLE OFF (LOCK).
Opening either front door cancels this function.


When resistance is detected, the auto reverse function causes the moonroof to change directions, then stop. Auto reverse stops sensing when the moonroof is almost closed to ensure that it fully closes. Make sure that all objects, including fingers, are clear of the moonroof.

You can use the remote transmitter or the key to operate the moonroof.

➡ **Opening the Windows and Moonroof with the Remote** P. 170
➡ **Opening/Closing the Windows and Moonroof with the Key** P. 170


POWER Button

Changing the Power Mode



POWER Button

POWER Button Operating Range



You can start the power system when the keyless access remote is inside the vehicle.
The power system may also start if the keyless access remote is close to the door or window, even if it is outside the vehicle.

If the battery of the keyless access remote is getting low, the power system may not start when you press the **POWER** button. If the power system does not start, refer to the following link.

➡ **If the Keyless Access Remote Battery is Weak** P. 635

Do not leave the power mode in ACCESSORY or ON when you get out.

■ Automatic Power Off


If you leave the vehicle for 30 to 60 minutes with the transmission in P and the power mode in ACCESSORY, the vehicle automatically goes into the mode to VEHICLE OFF (LOCK) to avoid draining the 12-volt battery.

■ Power Mode Reminder

If you open the driver's door when the power mode is set to ACCESSORY, a warning buzzer sounds.

Continued

■ Keyless Access Remote Reminder



Warning buzzers may sound from inside and/or outside the vehicle to remind you that the keyless access remote is out of the vehicle. If the buzzer continues even after the remote is put back inside, place it to be within its operational range.

■ When the power mode is in ON

If the keyless access remote is taken out of the vehicle, and the driver's door is closed, a warning buzzer sounds from both inside and outside the vehicle. A warning message on the MID notifies the driver inside that the remote is outside of the vehicle.

■ When the power mode is in ACCESSORY

If the keyless access remote is taken out of the vehicle, and the driver's door is closed, a warning buzzer sounds from outside the vehicle.

Keyless Access Remote Reminder


When the keyless access remote is within the system's operational range, and the driver's door is closed, the warning function cancels.

If the keyless access remote is taken out of the vehicle after the power system has been turned on, you can no longer change the **POWER** button mode or restart the power system. Always make sure if the remote is in your vehicle when you operate the **POWER** button.

Removing the keyless access remote from the vehicle through a window does not activate the warning buzzer.

Do not put the keyless access remote on the dashboard or in the glove box. It may cause the warning buzzer to go off. Under some other conditions that can prevent the vehicle from locating the remote, the warning buzzer may also go off even if the remote is within the system's operational range.

Turn Signals




The turn signals can be used when the power mode is in ON.

■ **One-touch turn signal**

When you lightly push up or down and release the turn signal lever, the exterior turn signals and turn signal indicator blink three times. This feature can be used when signaling for a lane change.

Light Switches

■ Manual Operation



Turns on parking, side marker, tail, and rear license plate lights

Turns on headlights, parking, side marker, tail, and rear license plate lights

Rotating the light switch turns the lights on and off, regardless of the power mode setting.

■ High beams

Push the lever forward until you hear a click.

■ Low beams

When in high beams, pull the lever back to return to low beams.

■ Flashing the high beams

Pull the lever back, and release it.

■ Lights off

Turn the lever to **OFF** either when:

- The transmission is in P.
- The parking brake is applied.

To turn the lights on again, turn the lever to **OFF** to cancel the lights off mode. Even if you do not cancel the lights off mode, the lights come on automatically when:

- The transmission is taken out of P and the parking brake is released.
- The vehicle starts to move.

Light Switches

If you leave the power mode in VEHICLE OFF (LOCK) while the lights are on, a chime sounds when the driver's door is opened.

When the lights are on, the lights on indicator in the instrument panel will be on.

Lights On Indicator P. 96

Do not leave the lights on when the power system is off because it will cause the 12-volt battery to discharge.

Models without automatic headlight adjusting system

If you sense that the level of the headlights is abnormal, have the vehicle inspected by a dealer.

Models with automatic headlight adjusting system

Your vehicle is equipped with the automatic headlight adjusting system that automatically adjusts the vertical angle of the high/low beam headlights. If you find a significant change in the vertical angle of the headlights, there may be a problem with the system. Have your vehicle checked by a dealer.

■ Automatic Operation (automatic lighting control)



Automatic lighting control can be used when the power mode is in ON.

When the light switch is in **AUTO**, the headlights and other exterior lights will switch on and off automatically depending on the ambient brightness.


The headlights comes on when you unlock a door in dark areas with the headlight switch in **AUTO**.

▶ Once you lock the door, the headlights will go off.

Automatic Operation (automatic lighting control)

We recommend that you turn on the lights manually when driving at night, in a dense fog, or in dark areas such as long tunnels or parking facilities.

The light sensor is in the location shown below.



U.S. models

You can adjust the auto light sensitivity as follows:

Setting	The exterior lights come on when the ambient light is at
Max	Bright
High	
Mid	
Low	
Min	Dark

Customized Features P. 131, 362

Continued

■ Headlight Integration with Wiper

The headlights automatically come on when the wipers are used several times within a certain number of intervals with the headlight switch in **AUTO**.
The headlights automatically go off a few minutes later if the wipers are stopped.

Headlight Integration with Wiper

This feature activates while the headlights are off in **AUTO**.
The instrument panel brightness does not change when the headlights come on.

At dark ambient light levels, the automatic lighting control feature turns on the headlights, regardless of the number of wiper sweeps.

■ Automatic Lighting Off Feature

The headlights, all other exterior lights, and the instrument panel lights turn off 15 seconds after you set the power mode to VEHICLE OFF (LOCK), take the remote with you, and close the driver's door.


If you set the power mode to VEHICLE OFF (LOCK) with the headlight switch on, but do not open the door, the lights turn off after 10 minutes (3 minutes, if the switch is in the **AUTO** position).

The lights turn on again when you unlock or open the driver's door. If you unlock the door, but do not open it within 15 seconds, the lights go off. If you open the driver's door, you will hear a lights on reminder chime.

Automatic Lighting Off Feature

You can change the headlight auto off timer setting.
➡ **Customized Features** P. 131, 362

Fog Lights*



Fog Light Switch

When the low beam headlights are on, turn the fog light switch on to use the fog lights.

Daytime Running Lights

The daytime running lights come on when the following conditions have been met:

- The power mode is in ON.
- The headlight switch is in **AUTO** or  .
- The parking brake is released.

The lights remain on even if you set the parking brake. Setting the power mode to VEHICLE OFF (LOCK) will turn off the daytime running lights.

The daytime running lights are off once the headlight switch is turned on, or when the head light switch is in **AUTO** and it is getting darker outside.


* Not available on all models

Auto High-Beam

Using a camera mounted to the inside of the windshield, this system detects light sources ahead of the vehicle. Depending on the light source, the system automatically switches the headlights to high beam for optimal visibility at night.

The system operates when:

- The headlight switch is in **AUTO**.
- The lever is in the low beam position.
- The low beams are on and the system recognizes that you are driving at night.
- The vehicle speed is above 45 mph (72 km/h).




How it works

When the camera detects lights coming from a preceding or oncoming vehicle, the headlights remain in low beam.

When the camera detects no lights coming from a preceding or oncoming vehicle, the headlights change to high beam.

The view angle or distance that the camera can detect lights ahead differs depending on conditions, such as the brightness of the lights and the weather.



Auto High-Beam

The auto high-beam determines when to change the headlight beams by responding to the brightness of the lights ahead of your vehicle. In the following cases, the system may not respond to the lights properly:


- The brightness of the lights from the preceding or oncoming vehicle is intense or poor.
- Visibility is poor due to the weather (rain, snow, fog, windshield frost, etc.).
- Other light sources, such as street lights and electric billboards are illuminating the road ahead.
- The brightness level of the road ahead constantly changes.
- The road is bumpy or has many curves.
- A vehicle cuts in front of you, or a vehicle in front of you is not in the preceding or oncoming direction.
- Your vehicle is tilted with a heavy load in the rear.

If you find the timing of beam changes inconvenient for driving, change the headlight beams manually.

If you do not want the system to be activated at any time when the headlight switch is in **AUTO**, consult a dealer or disable the system.

Disabling or Re-enabling the System P. 182

Operating the System



To activate the system, turn the headlight switch to **AUTO** and then set the headlights to low beam. The auto high-beam indicator will come on.

➡ **Light Switches** P. 176

The high beams remain on unless:

- The speed of the vehicle drops below 30 mph (48 km/h).
- The windshield wipers have been running at a high speed for more than a few seconds.
- You enter a well lit location.

The high beams come back on once the condition that caused them to turn off no longer exists.

If needed, you can temporarily turn the system off manually. Turn on the high beams by pushing the lever forward until you hear a click, or flash the high beams once by pulling the lever toward you. To turn the system back on, repeat one of the procedures.

Operating the System

For the auto high-beam to work properly:

- Do not place an object that reflects light on the dashboard.
- Keep the windshield around the camera clean.
- Do not attach an object, sticker or film to the area around the camera.

If the camera receives a strong impact, or repairing of the area near the camera is required, consult a dealer.

If the **Some Driver Assist Systems Cannot Operate: Camera Temperature Too High** message appears:


- Use the climate control system to cool down the interior and, if necessary, also use defroster mode with the airflow directed toward the camera.
- Start driving the vehicle to lower the windshield temperature, which cools down the area around the camera.

If the **Some Driver Assist Systems Cannot Operate: Clean Front Windshield** message appears:

- Park your vehicle in a safe place, and clean the windshield. If the message does not disappear after you have cleaned the windshield and driven for a while, have your vehicle checked by a dealer.

Continued

■ Disabling or Re-enabling the System



Disable or re-enable the system when the vehicle is parked with the power mode in ON and the light switch is in the **AUTO** position.

Disabling the system: Pull the light switch lever toward you and hold it for at least 40 seconds. The auto high-beam indicator in the meter will blink twice.


Re-enabling the system: Pull the light switch lever toward you and hold it for at least 30 seconds. The auto high-beam indicator in the meter will blink once.

Disabling or Re-enabling the System

The auto high-beam is in the previously selected disabled or re-enabled setting each time you start the power system.

Wipers and Washers

■ Windshield Wipers/Washers



1 **MIST**
2 **OFF**
3 **AUTO**
4 **LO**: Low speed wipe
5 **HI**: High speed wipe

The windshield wipers and washers can be used when the power mode is in ON.

■ MIST

The wipers run at high speed until you release the lever.

■ Wiper switch (OFF, AUTO, LO, HI)

Move the lever up or down to change the wiper settings.

■ Washer

Sprays while you pull the lever toward you. When you release the lever for more than one second, the spray stops, the wipers sweep two or three more times to clear the windshield, then stop.

Wipers and Washers

NOTICE

Do not use the wipers when the windshield is dry. The windshield will get scratched, or the rubber blades will get damaged.

Turn the washers off if no washer fluid comes out. The pump may get damaged.

The wiper motor may stop motor operation temporarily to prevent an overload. Wiper operation will return to normal within a few minutes, once the circuit has returned to normal.

NOTICE

In cold weather, the blades may freeze to the windshield.
Operating the wipers in this condition may damage the wipers. Use the defroster or heated windshield* to warm the windshield, then turn the wipers on.


If the wipers stop operating due to an obstacle such as the build-up of snow, park the vehicle in a safe place.

Rotate the wiper switch to **OFF**, and set the power mode to ACCESSORY or VEHICLE OFF (LOCK), then remove the obstacle.

* Not available on all models

Continued

■ Automatic Intermittent Wipers



When you push the lever down to **AUTO**, the windshield wipers sweep once, and go into the automatic mode.

The wipers operate intermittently, at low speed, or at high speed and stops in accordance with the amount of rainfall the rainfall sensor detects.

■ Auto sensitivity adjustment

When the wiper function is set to **AUTO**, you can adjust the sensitivity of the rainfall sensor (using the adjustment ring) so that wipers will operate in accordance with your preference.

Sensor sensitivity




Low sensitivity

High sensitivity

Automatic Intermittent Wipers

The rainfall sensor is in the location shown below.




NOTICE

AUTO should always be turned **OFF** before the following situations in order to prevent severe damage to the wiper system:

- Cleaning the windshield
- Driving through a car wash
- No rain present

■ Rear Wiper/Washer



1 **INT**: Intermittent
2 **ON**: Continuous wipe
3 **OFF**
4 Washer

The rear wiper and washer can be used when the power mode is in ON.

■ Wiper switch (OFF, INT, ON)

Change the wiper switch setting according to the amount of rain.

■ Washer ( )

Sprays while you rotate the switch to this position.
Hold it to activate the rear wiper and to spray the washer. Once released, the washer spray will stop and the rear wiper will return to its selected switch setting after a few sweeps.

■ Operating in reverse


When you select the transmission to R with the windshield wipers activated, the rear wiper operates automatically as follows even if its switch is off.

Windshield Wiper Operation	Rear Wiper Operation
Intermittent	Intermittent
Low speed wipe High speed wipe	Continuous

Continued

Canadian models

■ Headlight Washers




Turn the headlights on and press the headlight washer button to operate.
The headlight washers also operate when you turn the windshield washers for the first time after the power mode is set to ON.

Headlight Washers

The headlight washers use the same fluid reservoir as the windshield washers.

Brightness Control



When the power mode is in ON, you can use the + or – button to adjust instrument panel brightness.
Brighten: Press the + button.
Dim: Press the – button.

You will hear a beep when the brightness reaches minimum or maximum. Several seconds after adjusting the brightness, you will be returned to the previous display.



■ Brightness level indicator

The brightness level is shown on the MID while you are adjusting it.

Brightness Control

Instrument panel brightness varies, depending on whether the exterior lights are on or off. The instrument panel dims to reduce glare when they are on.


When it is bright outside and the headlight integration with the wiper is activated, the instrument panel brightness does not change.

To cancel the reduced instrument panel brightness when the exterior lights are on, press the + button until the brightness display is up to max, the beeper sounds.

The brightness can be set differently for when the exterior lights are on, and when they are off.

Rear Defogger/Heated Door Mirror Button

Press the rear defogger and heated door mirror button to defog the rear window and mirrors when the power mode is in ON.




The rear defogger and heated door mirrors automatically switch off after 10-30 minutes depending on the outside temperature.

Rear Defogger/Heated Door Mirror Button

This system consumes a lot of power, so turn it off when the window has been defogged. Also, do not use the system for a long time while the power system is stopped. This may weaken the 12-volt battery, making it difficult to turn the power system on.

When the power mode is set to ON and the outside temperature is below 41°F (5°C), the heated door mirror may automatically activate for 10 minutes.

Heated Windshield Button*



Press the heated windshield button to deice the windshield when the power mode is in ON.

Heated Windshield Button*

This system consumes a lot of power, so turn it off when the window has been deiced. Also, do not use the system for a long period when the power system is stopped. This may weaken the 12-volt battery, making it difficult to turn the power system on.

When the outside temperature is below 39°F (4°C), the heated windshield may automatically activate. The system deactivates itself once the outside temperature reaches 43°F (6°C).

* Not available on all models


Driving Position Memory System

You can store two driver's seat (except for power lumbar), steering wheel and door mirror positions with the driving position memory system.
When you unlock and open the driver's door with a remote transmitter, or keyless access system, door mirrors adjust to one of the two preset positions and the seat adjusts to retracted positions of one of the two preset positions automatically.

The steering wheel and the seat will move to the stored position when you set the power mode to ACCESSORY.

When you enter the vehicle, the MID briefly shows you which remote transmitter you used to unlock the vehicle.

- **DRIVER 1** transmitter is linked to memory button 1.
- **DRIVER 2** transmitter is linked to memory button 2.



The driver's seat moves rearward and steering wheel fully up depending on the set seating position once you

- Stop the vehicle.
- Put the transmission in P.
- Turn the power system off.
- Then open the driver's door.

Once the power mode is in the ACCESSORY position, the driver's seat and steering wheel moves to the **DRIVER 1** or **2** preset position.

Driving Position Memory System

Using the information screen or MID, you can disable the automatic seat, steering wheel and door mirrors adjustment function.

➡ **Customized Features** P. 131, 362

The driver's seat easy exit feature can be turned ON/OFF.

➡ **Customized Features** P. 131, 362


System Operation

The system will not operate if:

- The vehicle speed is above 3 mph (5 km/h).
- Either memory position button is pressed while the seat or steering wheel is in motion.
- The seat or steering wheel position is adjusted while in operation.
- The memory 1 or 2 position is set fully to the rear.

Continued

■ Storing a Position in Memory




1. Set the power mode to ON. Adjust the driver's seat, the steering wheel and the door mirrors to the desired position.
2. Press the **SET** button.
   ▶ You will hear the beeper, and the memory button indicator light will blink.
3. Press and hold memory button 1 or 2 within five seconds of pressing the **SET** button.
   ▶ Once the seat, the steering wheel and the outside mirror positions have been memorized, the indicator light on the button you pressed stays on and you will hear the double-beep.

Storing a Position in Memory

After you press the **SET** button, the storing operation will be canceled when:

- You do not press the memory button within five seconds.
- You readjust the seat, the steering wheel or the outside mirror position before the double-beep.
- You set the power mode to any position except ON.

■ Recalling the Stored Position



1. Put the transmission into P.
2. Apply the parking brake.
3. Press a memory button (1 or 2).
   ▶ You will hear the beeper, and the indicator light will blink.

The seat, the steering wheel and the door mirrors will automatically move to the memorized positions. When it has finished moving, you will hear the beeper, and the indicator light stays on.


Recalling the Stored Position

The seat, the steering wheel and the door mirrors will stop moving if you:

- Press the **SET** button or memory button 1 or 2.
- Adjust the seat position, door mirrors, or steering wheel.
- Put the transmission into a position other than P.

Adjusting the Steering Wheel

The steering wheel height and distance from your body can be adjusted so that you can comfortably grip the steering wheel in an appropriate driving posture.



Push and hold the adjustment switch to move the steering wheel in, out, up or down.

▶ Make sure you can see the instrument panel gauges and indicators.

Adjusting the Steering Wheel

⚠WARNING


Adjusting the steering wheel position while driving may cause you to lose control of the vehicle and be seriously injured in a crash.

Adjust the steering wheel only when the vehicle is stopped.

Interior Rearview Mirror

Adjust the angle of the rearview mirror when you are sitting in the correct driving position.

■ Automatic Dimming Rearview Mirror and Power Door Mirrors*



When you are driving after dark, the automatic dimming rearview mirror and power door mirrors* reduce the glare from headlights behind you, based on inputs from the mirror sensor. This feature is always active.

Adjusting the Mirrors

Keep the inside and outside mirrors clean and adjusted for best visibility.


Adjust the mirrors before you start driving.
➡ **Front Seats** P. 195

Automatic Dimming Rearview Mirror and Power Door Mirrors*

The auto dimming function cancels when the transmission is in R.

 * Not available on all models

Power Door Mirrors



You can adjust the door mirrors when the power mode is set to ON.

■ **Mirror position adjustment**


L/R selector switch: Select the left or right mirror. After adjusting the mirror, return the switch to the center position.

Mirror position adjustment switch: Press the switch left, right, up, or down to move the mirror.

■ **Folding door mirrors**

Press the fold button to fold the door mirrors.

■ Reverse Tilt Door Mirror



If activated, either side door mirror automatically tilts downward when you put the transmission into [R]; this improves close-in visibility on the selected side of the vehicle when backing up. The mirror automatically returns to its original position when you take the transmission out of [R].

To activate this feature, set the power mode to ON and slide the selector switch to the left or right side.

Continued

■ Automatic Folding Door Mirror Function

■ Folding the door mirrors

Lock all doors from outside the vehicle.

▶ The mirrors start folding automatically.

➡ **Locking and Unlocking the Doors** P. 143

■ Unfolding the door mirrors

Unlock the driver's or all doors from outside the vehicle.

▶ The mirrors start unfolding automatically.

➡ **Locking and Unlocking the Doors** P. 143

Automatic Folding Door Mirror Function

Door mirrors will not unfold automatically if fold button is pressed.


➡ **Folding door mirrors** P. 193

You can turn the automatic folding door mirror function on and off.

➡ **Customized Features** P. 131, 362

Door mirrors will not fold automatically when locking from inside the vehicle using lock tab or master door lock switch.

Front Seats



Adjust the driver's seat as far back as possible while allowing you to maintain full control of the vehicle. You should be able to sit upright, well back in the seat and be able to adequately press the pedals without leaning forward, and grip the steering wheel comfortably. The passenger's seat should be adjusted in a similar manner, so that it is as far back from the front airbag in the dashboard as possible.

Adjusting the Seats

⚠WARNING

Sitting too close to a front airbag can result in serious injury or death if the front airbags inflate.


Always sit as far back from the front airbags as possible while maintaining control of the vehicle.

The National Highway Traffic Safety Administration and Transport Canada recommend that drivers allow at least 10 inches (25 cm) between the center of the steering wheel and the chest.


Always make seat adjustments before driving.

Adjusting the Seat Positions

Adjusting the front power seats



Continued



■ **Lumbar Support Adjustment Switch**


Press the top: To move the lumbar support up.

Press the bottom: To move the lumbar support down.

Press the front: To increase the entire lumbar support.

Press the rear: To decrease the entire lumbar support.

Adjusting the Seat-Backs



Adjust the driver's seat-back to a comfortable, upright position, leaving ample space between your chest and the airbag cover in the center of the steering wheel.

The front seat passenger should also adjust their seat-back to a comfortable, upright position.

Reclining a seat-back so that the shoulder part of the belt no longer rests against the occupant's chest reduces the protective capability of the belt. It also increases the chance of sliding under the belt in a crash and being seriously injured. The farther a seat-back is reclined, the greater the risk of injury.

Adjusting the Seat-Backs

⚠WARNING

Reclining the seat-back too far can result in serious injury or death in a crash.

Adjust the seat-back to an upright position, and sit well back in the seat.

Do not put a cushion, or other object, between the seat-back and your back. Doing so may interfere with proper seat belt or airbag operation.

If you cannot get far enough away from the steering wheel and still reach the controls, we recommend that you investigate whether some type of adaptive equipment may help.

Second Row Seats

■ Adjusting the Seat Positions

Models with bench seat



Horizontal Position Adjustment
Pull up the bar to move the seat, then release the bar.

Seat-back Angle Adjustment
Pull up the lever to change the angle.

Second Row Seats

Once a seat is adjusted correctly, rock it back and forth to make sure it is locked in position.

Models with captain seat




Horizontal Position Adjustment
Pull up the bar to move the seat, then release the bar.

Seat-back Angle Adjustment
Pull up the lever to change the angle.


Continued

■ Third Row Seat Access



Pressing the button on the seat-back, or seat cushion tilts the second row outer seat's seat-back forward.

▶ The whole seat slides forward.



Pulling up on the strap also tilts the seat-back forward.

Third Row Seat Access

The button is disabled when the vehicle is moving.

When you enter the third row seat, be careful not to trip over the second row seat belt.

■ Folding Down the Second Row Seat

Separately fold down the left and right halves of the second row seat to make room for cargo.


Models with bench seat

1. Store the center seat belt first. Insert the latch plate into the slot on the side of the anchor buckle.

2. Retract the seat belt into the holder on the ceiling.

➡ **Seat Belt with Detachable Anchor** P. 44

3. Lower the center head restraint to its lowest position. Put the armrest back into the seat-back.



All Models

4. Pull up on the seat-back angle adjustment lever.

To return the seat to the original position, pull up the seat-back in the upright position.

Folding Down the Second Row Seat

Make sure that the folded seat-back does not press against the front passenger seat, as this can cause the weight sensors in the front passenger seat to work improperly.

➡ **Passenger Front Airbag Off Indicator** P. 60

The front seats must be far enough forward so they do not interfere with the second row seats as they fold down.

To lock the seat-back upright, push it backwards until it locks.

Make sure the seat-back, head restraints and seat cushion are securely latched back into place before driving. Also, make sure all rear shoulder belts are positioned in front of the seat-back.


Models with bench seat

Make sure the center shoulder belt is re-positioned in the holding slot.

Head Restraints

Your vehicle is equipped with head restraints in all seating positions.

■ Adjusting the Front and Second Row Outer Head Restraint Positions



Position head in the center of the head restraint.

Head restraints are most effective for protection against whiplash and other rear-impact crash injuries when the center of the back of the occupant's head rests against the center of the restraint. The tops of the occupant's ears should be level with the center height of the restraint.

Head Restraints


⚠WARNING


Improperly positioning head restraints reduces their effectiveness and increases the likelihood of serious injury in a crash.

Make sure head restraints are in place and positioned properly before driving.

In order for the head restraint system to work properly:

- Do not hang any items on the head restraints, or from the restraint legs.
- Do not place any objects between an occupant and the seat-back.
- Install each restraint in its proper location.






To raise the head restraint: Pull it upward.
To lower the head restraint: Push it down while pressing the release button.

Continued

■ Changing the Second Row Center Seat Head Restraint Position*



A passenger sitting in the second row center seating position should adjust the height of their head restraint to an appropriate position before the vehicle begins moving.

To raise the head restraint:
Pull it upward.

To lower the head restraint:
Push it down while pressing the release button.

■ Removing and Reinstalling the Head Restraints

Front and second row head restraints

Head restraints can be removed for cleaning or repair.

To remove a head restraint:
Pull the restraint up as far as it will go. Then push the release button, and pull the restraint up and out.

To reinstall a head restraint:
Insert the legs back in place, then adjust the head restraint to an appropriate height while pressing the release button. Pull up on the restraint to make sure it is locked in position.

Removing and Reinstalling the Head Restraints


⚠WARNING

Failure to reinstall, or correctly reinstall, the head restraints can result in severe injury during a crash.

Always replace the head restraints before driving.

 * Not available on all models

Folding Down the Third Row Head Restraint



A passenger in the third row seating position should put the head restraint in the upright position before the vehicle begins moving.

To fold down the head restraint:
Pull the handle.

To put the head restraint back in the upright position:
Pull up the head restraint and push rearward until it latches.

Maintain a Proper Sitting Position

After all occupants have adjusted their seats and head restraints, and put on their seat belts, it is very important that they continue to sit upright, well back in their seats, with their feet on the floor until the vehicle is safely parked and the power system is off.

Sitting improperly can increase the chance of injury during a crash. For example, if an occupant slouches, lies down, turns sideways, sits forward, leans forward or sideways, or puts one or both feet up, the chance of injury during a crash is greatly increased.

In addition, an occupant who is out of position in the front seat can be seriously or fatally injured in a crash by striking interior parts of the vehicle or being struck by an inflating front airbag.

Maintain a Proper Sitting Position

⚠WARNING

Sitting improperly or out of position can result in serious injury or death in a crash.


Always sit upright, well back in the seat, with your feet on the floor.

Third Row Seats

■ Folding Down the Third Row Seat

Separately fold down the left and right halves of the third row seat to make room for cargo.

■ To fold down the seat



1. Pull the handle on the seat-back fully.
▶ The head restraint tilts downward.
2. Push the seat-back forward while pulling the handle.

■ To return the seat to the original position

1. Pull the seat-back up with the handle pulled.
2. Push the head restraint up to its original position.

Folding Down the Third Row Seat


Make sure all items in the cargo area or items extending to the third row seats are properly secured. Loose items can fly forward if you have to brake hard.

To return the seat to the original position

Make sure the seat-back and head restraints are securely latched back into place before driving.

Armrest


■ Using the Front Seat Armrest




The console lid can be used as an armrest.

To adjust:
Slide the armrest to a desired position.

Using the Rear Seat Armrest



Pull down the armrest in the center backrest.




The console lid can be used as an armrest.

To adjust:
Slide the armrest to a desired position.

Interior Lights

■ Interior Light Switches



■ ON

The interior lights come on regardless of whether the tailgate and doors are open or closed.

■ Door activated

The interior lights come on in the following situations:

- When the tailgate or any of the doors are opened.
- You unlock the driver's door.
- When the power mode is set to VEHICLE OFF (LOCK).

■ OFF

The interior lights remain off regardless of whether the tailgate or any doors are open or closed.

Interior Light Switches

In the door activated position, the interior lights fade out and go off about 30 seconds after the doors are closed.

The lights go off after about 30 seconds in the following situations:

- When you unlock the driver's door but do not open it.
- When you set the power mode to VEHICLE OFF (LOCK) but do not open a door.

You can change the interior lights dimming time.

➡ **Customized Features** P. 131, 362

The interior lights go off immediately in the following situations:


- When you lock the driver's door.
- When you close the driver's door in ACCESSORY mode.
- When you set the power mode to ON.

To avoid draining the 12-volt battery, do not leave the interior light on for an extended length of time when the power system is off.

If you leave any of the tailgate or doors open in VEHICLE OFF (LOCK) mode, the interior lights go off after about 15 minutes.

■ Map Lights

Front



Second and third row




■ Front

The map lights can be turned on and off by pressing the (map light) button.

■ Second and third row

The map lights can be turned on and off by pressing the (map light) button when the front interior light switch is in the door activated position.

■ Cargo Area Lights



■ ON

The light comes on when you open the tailgate, and goes off when closed.

■ OFF


The light stays off with or without opening the tailgate.

Map Lights


When the interior light switch is in the door activated position and any door is open, the map light will not go off when you press the button.

Interior Convenience Items

■ Glove Box




Press the button to open the glove box. You can lock the glove box with the built-in key.



■ Removable shelf

The shelf in the glove box is detachable. To remove it, disengage the tabs.



The removed shelf can be stored upside down in the glove box.


Glove Box

⚠WARNING


An open glove box can cause serious injury to your passenger in a crash, even if the passenger is wearing the seat belt.

Always keep the glove box closed while driving.

■ Front and Rear* Console Compartment



Pull the passenger's side handle to open the console compartment.



Pull the driver's side handle to open the utility tray in the console lid.



■ Console Tray


Slide or lift the tray when you use the console compartment.

▶ To lift this tray, slide it rearward, then pull it up.

* Not available on all models

Continued

■ Center Pocket




Press the raised detent to open the lid. To close the lid, push it down until it latches.

■ Under-floor Storage Area



Pull the handle to open the cargo floor lid.

■ Beverage Holders




■ Front seat beverage holders

Are located in the console between the front seats.



■ Door side beverage holders

Are located on the both of the front and rear door side pockets.




Beverage Holders

NOTICE

Spilled liquids can damage the upholstery, carpeting, and electrical components in the interior.

Be careful when you are using the beverage holders. Hot liquid can scald you.

Continued



■ **Second row seat beverage holders**

Fold the armrest down to use the rear seat beverage holders.



Are located in the console between the second row seats.



■ **Third row seat beverage holders**


■ Accessory Power Sockets

The accessory power sockets can be used when the power mode is in ACCESSORY or ON.



■ Accessory power socket (center pocket)

Open the lid and the cover to use it.



■ Accessory power socket (front console compartment)*

Pull the handle and open the cover to use it.

Accessory Power Sockets

NOTICE

Do not insert an automotive type cigarette lighter element. This can overheat the power socket.

The accessory power sockets are designed to supply power for 12-volt DC accessories that are rated 180 watts (15 amps) or less.

To prevent 12-volt battery drain, only use the power socket with the power system on.

* Not available on all models

Continued



■ **Accessory power socket (cargo area)**
Open the cover to use it.

Canadian models

■ AC Power Outlet

The AC power outlet can be used when the power system is on.



Open the cover to use it. Plug in the appliance slightly, turn it 90° clockwise, then push it all the way.

AC Power Outlet


NOTICE

Do not use the AC power outlet for electric appliances that require high initial peak wattage, such as cathode-ray tube type televisions, refrigerators, electric pumps, etc. It is not suitable for devices that process precise data, such as medical equipment, and that require an extremely stable power supply, such as microcomputer-controlled electric blankets, touch sensor lamps, etc.

The AC power outlet is designed to supply power for up to 115 volt appliances that are rated 150 watts or less.

Continued use of any electric appliance/device exceeding these ratings may result in damage to the appliance/device.

Coat Hooks




There is a coat hook on the rear grab handle of both sides. Pull it down to use it.

Coat Hooks

The coat hooks are not designed for large or heavy items.

Tie-down Anchors



The tie-down anchors on the cargo area floor can be used to install a net for securing items.

Tie-down Anchors

Do not let anyone access items in the cargo area while driving. Loose items can cause injury if you have to brake hard.

Continued

■ Sunglasses Holder




To open the sunglasses holder, press and release the indent. To close, press it again until it latches.

You can store eyeglasses and other small items in this holder.

Sunglasses Holder

Keep the holder closed while driving except when accessing stored items.

■ Heated Steering Wheel*



The power mode must be in ON to use the heated steering wheel.

Press the button on the left side of the steering wheel.

When a comfortable temperature is reached, press the button again to turn it off.

The heated steering wheel is turned off every time you start the power system, even if you turned it on the last time you drove the vehicle.

Heated Steering Wheel*

Do not use the heated steering wheel continuously when the power system is off. Under such conditions, the 12-volt battery may be weakened, making the power system difficult to start.

* Not available on all models

Front Seat Heaters and Seat Ventilation*



Models with seat ventilation



Models without seat ventilation



The power mode must be in ON to use the seat heaters and ventilators*.

1. Select .
2. Change the setting with one of the following:
   The **Low** icon: The LO setting (one indicator on)
   The **Mid** icon: The MID setting (two indicators on)
   The **High** icon: The HI setting (three indicators on)
   Auto: The system automatically selects the setting most suitable to the ambient environment.
   Off: Turn off the system.

When the power mode is turned on after it is turned off, the previous setting of front seat heaters and ventilators* are maintained.

Front Seat Heaters and Seat Ventilation*

⚠WARNING

Heat induced burns are possible when using seat heaters.

Persons with a diminished ability to sense temperature (e.g., persons with diabetes, lower-limb nerve damage, or paralysis) or with sensitive skin should not use seat heaters.

Do not use the seat heaters and the seat ventilation even in LO when the power system is off. Under such conditions, the 12-volt battery may be weakened, making the power system difficult to start.

After a certain period of time, the strength setting for the seat heaters will automatically be reduced by one level at a time until the seat heater shuts off. The elapsed time varies according to the interior environment.

* Not available on all models

Continued


■ Second Row Outer Seat Heaters*



The power mode must be in ON to use the seat heaters.

Press the seat heater button:
Once - The HI setting (three indicators on)
Twice - The MID setting (two indicators on)
Three times - The LO setting (one indicator on)
Four times - The OFF setting (no indicators on)

■ Integrated Sunshades*



Pull the tab and roll up the sunshade all the way. Use the hooks to hang it.

Second Row Outer Seat Heaters*

⚠WARNING

Heat induced burns are possible when using seat heaters.

Persons with a diminished ability to sense temperature (e.g., persons with diabetes, lower-limb nerve damage, or paralysis) or with sensitive skin should not use seat heaters.

Do not use the seat heaters even in LO when the power system is off. Under such conditions, the 12-volt battery may be weakened, making the power system difficult to start.

After a certain period of time, the strength setting for the seat heaters will automatically be reduced by one level at a time until the seat heater shuts off. The elapsed time varies according to the interior environment.


Integrated Sunshades*

Use the sunshades only when the windows are fully closed. Using the shade while a window is open can unhook and blow off the shade, hitting and hurting anyone sitting near the window.

 * Not available on all models

Using Automatic Climate Control

The automatic climate control system maintains the interior temperature you select. The system also selects the proper mix of heated or cooled air that raises or lowers the interior temperature to your preference as quickly as possible.



Use the system when the power system is on.

1. Press the **AUTO** button.
2. Adjust the interior temperature using the driver's side or passenger's side temperature control switch.
3. Press the ON/OFF (On/Off) button to cancel.

Using Automatic Climate Control

If any buttons/icons on the touch screen are pressed while using the climate control system in auto, the function of the button/icon that was pressed will take priority.
The AUTO indicator will go off, but functions unrelated to the button/icon that was pressed will be controlled automatically.

To prevent cold air from blowing in from outside, the fan may operate at low speed for a while after the **AUTO** button has been pressed.

If the interior is very warm, you can cool it down more rapidly by partially opening the windows, turning the system on auto, and setting the temperature to low. Change the fresh air mode to recirculation mode until the temperature cools down.


When you set the temperature to the lower or upper limit, **Lo** or **Hi** is displayed.

Pressing the ON/OFF button switches the climate control system between on and off. When turned on, the system returns to your last selection.

Continued

■ Operating from the On Demand Multi-Use Display™


In addition to the button/switch controls, you can operate the climate control system from the On Demand Multi-Use Display™ touch screen.



Using Automatic Climate Control

When you unlock the doors with your remote, the driver's ID (**Driver 1** or **Driver 2**) is detected, and the climate control settings are turned to the respective mode automatically when you set the power mode to ON.

Changing the Interior Temperature Setting



1. Select the driver's or passenger's side temperature control icon.

2. Change the temperature setting from the following:

Temperature bar: Select a point where your desired temperature setting is.
Farther to the left is for a lower, and to the right for a higher setting.

+/−: To raise or lower the temperature setting one degree at a time.
While you select and hold +/−, the temperature decreases or increases.

Max Cool: To rapidly cool down the interior.
▶ The A/C indicator comes on. The setting returns to the previously selected value when you select it again.

Max Heat: To rapidly warm up the interior.
▶ The A/C indicator goes off. The setting returns to the previously selected value when you select it again.

Using Automatic Climate Control

If you select the **Max Heat** during Auto Engine Stop, the engine restarts automatically.

Continued


■ Switching the vent mode



Select a desired vent mode icon, or **Front Mode Auto**: The system automatically selects the vent mode most suitable to the ambient environment.

Vent mode
: Dashboard vents
: Dashboard and floor vents
: Floor vents
: Floor and defroster vents

■ A/C on and off




1. Select **A/C**.
2. Select **On** or **Off**.

Switching the vent mode

While the climate control system is in auto, **Front Mode Auto** is highlighted.

■ SYNC on and off



1. Select **SYNC**.
2. Select **On** for synchronization mode.
   ▶ When in synchronization mode, the front passenger's side temperature and the rear passenger compartment become the same as the driver's side settings.
3. Adjust the temperature or change the mode from the driver's side.


SYNC on and off

When you press the FRONT button or select the **Front** icon, the system synchronizes the driver's and front passenger's temperature settings.

When the system is not in SYNC mode, the driver's side temperature, the front passenger's side temperature and the rear passenger compartment (if it is on) can be set separately.

You can also turn off SYNC mode by changing the front passenger's side temperature or rear passenger's temperature.

■ Changing the fan speed



1. Select .
   ▶ When the left or right side of the is selected, the fan speed level goes up or down one level at a time.
2. Change the fan speed with one of the following:
   The fan speed level indicators: Select your desired speed level. The smaller indicator is for a slower speed, and the larger for a faster speed.
   +/−: To go up or down one level at a time.
   Front Fan AUTO: The system automatically selects the fan speed most suitable to the ambient environment.

Changing the fan speed

While the climate control system is in auto, **Front Fan AUTO** is highlighted.

Continued

■ Switching between the Recirculation and Fresh Air Modes



Select [car] or [air] currently shown to switch between the modes depending on environmental conditions.

▶ Selecting [car] or [air] currently shown changes the display to the **Fresh Air/ Recirculation** display. You can also switch the mode by selecting [car] or [air] icon appearing in the display.

[car] (Recirculation Mode): Recirculates air from the vehicle's interior through the system.
[air] (Fresh Air Mode): Maintains outside ventilation. Keep the system in fresh air mode in normal situations.

■ Defrosting the Windshield and Windows



Pressing the FRONT button or selecting the **Front** icon appearing after the vent mode icon is selected turns the air conditioning system on and automatically switches the system to fresh air mode.

Press the FRONT button or select the **Front** icon again to turn off, the system returns to the previous settings.

■ To rapidly defrost the windows



1. Press the FRONT button, or select the vent mode icon and then the **Front** icon.
2. Select the recirculation mode.

➡ **Switching between the Recirculation and Fresh Air Modes** P. 228

Defrosting the Windshield and Windows

For your safety, make sure you have a clear view through all the windows before driving.
Do not set the temperature near the upper or lower limit.
When cold air hits the windshield, the outside of the windshield may fog up.


If the side windows fog up, adjust the vents so that the air hits the side windows.

To rapidly defrost the windows

After defrosting the windows, switch over to fresh air mode.
If you keep the system in recirculation mode, the windows may fog up from humidity. This impedes visibility.

Rear Climate Control System

■ Using the Rear Climate Control System From the Front Panel



Use the system when the power system is on.

1. Select **REAR**.

2. Select **Auto**.

▶ The rear system changes to auto mode.

3. Adjust the rear passenger's compartment temperature using the temperature control icon.

4. Select the **On/Off** to cancel.

▶ When the turned back on, the system returns to your last selection.

Rear Climate Control System

If any icons on the touch screen are pressed while using the rear climate control system in auto, the function of the icon that was pressed will take priority.

Rear Lock: Appears on the front panel. When selected, it disables the rear panel control.
LOCK: Appears on the rear control panel while the rear lock is on.

If the rear lock is on while in SYNC mode, the rear control panel is disabled. **LOCK SYNC** appears on the rear control panel.

■ Changing the rear temperature setting



+/− (Temperature Control) Icon

Change the temperature setting from the following:

+/−: To raise or lower the temperature setting one degree at a time.

While you select and hold +/−, the temperature decreases or increases.

■ Switching the vent mode



Vent Mode Icon

Select a desired vent mode icon.

Vent mode

: Rear console vents

: Rear console vents and floor vents

: Rear floor vents

Changing the rear temperature setting

When you set the temperature to the lower or upper limit, **Lo** or **Hi** is displayed.

Continued


■ Changing the fan speed



Fan Speed Level Indicators

Change the fan speed with one of the following:
The fan speed level indicators: Select your desired speed level. The smaller indicator is for a slower speed, and the larger for a faster speed.
+/−: To go up or down one level at a time.

■ Using the Rear Climate Control System From the Rear Panel



Use the system when the power system is on.

1. Press the **AUTO** button.


2. Adjust the interior temperature using the rear temperature control button.


3. To turn off the rear climate control system, press button.

Using the Rear Climate Control System From the Rear Panel

When the **Rear Lock** icon on the front control panel is off, the temperature of the rear passenger compartment can be controlled independently.

Automatic Climate Control Sensors





The automatic climate control system is equipped with sensors. Do not cover or spill any liquid on them.



Features

This chapter describes how to operate technology features.

Audio System
- About Your Audio System 236
- USB Ports 237
- Auxiliary Input Jack 240
- Audio System Theft Protection 240
- Audio Remote Controls 241

Audio System Basic Operation 243
- On Demand Multi-Use Display™ 244
- Information Screen 248
- Adjusting the Sound 256
- Display Setup 257
- Voice Control Operation 258
- Playing AM/FM Radio 261
- Playing SiriusXM® Radio 264
- Playing a CD 275
- Playing Hard Disk Drive (HDD) Audio ... 278
- Playing an iPod 291
- Song By Voice™ (SBV) 294
- Playing Pandora®*1 298
- Playing a USB Flash Drive 300
- Playing *Bluetooth*® Audio 303
- Siri Eyes Free 305
- Apple CarPlay 306
- Android Auto 310

Audio Error Messages 315

General Information on the Audio System 323

Rear Entertainment System (RES)* .. 342

Customized Features 362

HomeLink® Universal Transceiver ... 394

***Bluetooth*® HandsFreeLink®**
- Using HFL 397
- HFL Menus 400

AcuraLink® 438


*1: Available only on U.S. models.

* Not available on all models

About Your Audio System

The audio system features AM/FM radio and SiriusXM® Radio service. It can also play audio CDs, WMA/MP3/AAC files, Hard Disk Drive (HDD) audio, USB flash drives, and iPod, iPhone and *Bluetooth*® devices.

You can operate the audio system from the remote controls on the steering wheel, or the icons on the On Demand Multi-Use Display™.



About Your Audio System

SiriusXM® Radio is available on a subscription basis only. For more information on SiriusXM® Radio, contact a dealer.

General Information on the Audio System
P. 323

SiriusXM® Radio is available in the United States and Canada, except Hawaii, Alaska, and Puerto Rico.

SiriusXM® is a registered trademark of SiriusXM Radio, Inc.

Video CDs, DVDs*, and 3-inch (8-cm) mini CDs are not supported.


iPod, iPhone and iTunes are trademarks of Apple Inc.

State or local laws may prohibit the operation of handheld electronic devices while operating a vehicle.

When the screen is viewed through polarized sunglasses, a rainbow pattern may appear on the screen due to optical characteristics of the screen. If this is disturbing, please operate the screen without polarized sunglasses.

* Not available on all models

USB Ports



■ In the front console compartment

Install the device USB connector or the USB flash drive to the USB port (2.5A).

▶ The USB port (2.5A) is for charging devices, playing audio files and connecting compatible phones with Apple CarPlay or Android Auto.

The USB ports (2.5A) are only for charging devices.

USB Ports

- Do not leave the iPod or USB flash drive in the vehicle. Direct sunlight and high temperatures may damage it.
- We recommend using an extension cable with the USB port.
- Do not connect the iPod or USB flash drive using a hub.
- Do not use a device such as a card reader or hard disk drive, as the device or your files may be damaged.
- We recommend keeping your data backed up before using the device in your vehicle.
- Displayed messages may vary depending on the device model and software version.

If the audio system does not recognize the iPod, try reconnecting it a few times or reboot the device. To reboot, follow the manufacturer's instructions provided with the iPod or visit the following website:

- U.S.: *www.apple.com/ipod*.
- Canada: *www.apple.com/ca/ipod*.

The USB port can supply up to 2.5A of power. It does not output 2.5A unless requested by the device.
For amperage details, read the operating manual of the device that needs to be charged.
Set the power mode to ACCESSORY or ON first.

Continued

Models without rear console compartment

Models without rear entertainment system



Models with rear entertainment system



■ On the back of the front console compartment

The USB ports (2.5A) are only for charging devices.

USB Ports

USB Ports (2.5A)

This port is for battery charge only. You cannot play music even if you have connected a music player to it.


Under certain conditions, a device connected to the port may generate noise in the radio you are listening to.

Models with rear console compartment



■ **In the rear console compartment**


The USB ports (2.5A) are only for charging devices.



■ **On the back of the rear console compartment**

The USB ports (2.5A) are only for charging devices.

Auxiliary Input Jack



Use the jack to connect standard audio devices.

1. Open the **AUX** cover.
2. Connect a standard audio device to the input jack using a 1/8 inch (3.5 mm) stereo miniplug.
▶ The audio system automatically switches to the AUX mode.

Auxiliary Input Jack

You can return to the AUX mode by selecting **Source** on the On Demand Multi-Use Display™.

Audio System Theft Protection


The audio system is disabled when it is disconnected from the power source, such as when the 12-volt battery is disconnected or goes dead. In certain conditions, the system may display a code entry screen. If this occurs, reactivate the audio system.

■ Reactivating the audio system

1. Set the power mode to ON.
2. Turn on the audio system.
3. Press and hold the audio system power button for more than two seconds.
▶ The audio system is reactivated when the audio control unit establishes a connection with the vehicle control unit. If the control unit fails to recognize the audio unit, you must go to a dealer and have the audio unit checked.

Audio Remote Controls

Allows you to operate the audio system while driving. The information is shown on the multi-information display (MID).



SOURCE Button
Cycles through the audio modes as follows:
FM → AM → SiriusXM® → CD → Rear DVD* → HDD → USB/iPod/Apple CarPlay/Android Auto → *Bluetooth*® Audio → Pandora®* → AUX

Left Selector Wheel
Roll Up: To increase the volume.
Roll Down: To decrease the volume.
Push: To mute. Push again to unmute.

- When listening to the radio
  Move to the right: To select the next preset radio station.
  Move to the left: To select the previous preset radio station.
  Move to the right and hold: To select the next strong station.
  To select the next channel. (SiriusXM® only)
  Move to the left and hold: To select the previous strong station.
  To select the previous channel. (SiriusXM® only)
- When listening to a CD, HDD, iPod, USB flash drive, or *Bluetooth*® Audio
  Move to the right: To skip to the next song.
  Move to the left: To go back to the beginning of the current or previous song.
  Move to the right and hold: To go to the next folder. (*Bluetooth*® Audio only)
  Move to the left and hold: To go to the previous folder. (*Bluetooth*® Audio only)

Audio Remote Controls

Some mode appears only when an appropriate device or medium is used.

Models with rear entertainment system

If you operate some remote control switch while rear source mode is selected, the rear source mode changes to the front source mode.

Selecting an Audio Source P. 244


* Not available on all models

Continued

- When listening to a CD, HDD or USB flash drive
  Move to the right and hold: To skip to the next folder.
  Move to the left and hold: To go back to the previous folder.
- When listening to Pandora®*
  Move to the right: To skip to the next track.
  Move to the right and hold: To select the next station.
  Move to the left and hold: To select the previous station.

 * Not available on all models

To use the audio system, the power mode must be in ACCESSORY or ON.



Use the interface dial or **ENTER/MENU** button to access phone, information or smartphone functions.

Interface dial (ENTER/MENU button):
Rotate left or right to scroll through the available choices. Press to set your selection. Move right, left, up or down to select a secondary menu.
Press to switch the display to the **Information Menu** screen while the trip computer screen or clock/wallpaper screen is displayed.

BACK button: Press to go back to the previous display.

(Day/Night) button: Press to change the information screen brightness.
Press (Day/Night) once and make an adjustment using the interface dial.

► Each time you press (Day/Night), the mode switches between the daytime mode, nighttime mode and off mode.

Audio System Basic Operation

Voice Control System
The navigation/audio system is voice operable.
➡ **Voice Control Operation** P. 258

These indications are used to show how to operate the interface dial.

Rotate to select.

Press to enter.

Move ◁, △, ▷ or ▽ to select a secondary menu.


Audio function items
➡ **Preset Memory** P. 262, 266
➡ **Radio Text** P. 263
➡ **Music Search** P. 276, 280, 292, 301
➡ **Scan** P. 263, 274, 277, 281, 302
➡ **Random/Repeat** P. 277, 282, 293, 302

When you unlock the doors with your remote, the driver's ID (**Driver 1** or **Driver 2**) is detected, and the audio system settings and preset memory are turned to the respective mode automatically when you set the power mode to ON.

On Demand Multi-Use Display™

Use the On Demand Multi-Use Display™ to operate the audio system.

■ Selecting an Audio Source



Select **Source**, then select an item on the source list to switch the audio source.

Models with rear entertainment system

Select **Front/Rear** to changes between the front side audio source selection and rear side audio source selection.

Selecting the Audio Source using Front Control Panel P. 356

On Demand Multi-Use Display™

Icons that appear on the screen vary by the source selected.

Select ⮌ or X to go back to the previous screen.

Use the ⏫/⏬ icons to turn the page.

Selecting an Audio Source

You can change the order of source list displayed.




1. Select **Audio Menu**, then **Edit Source Order**.
2. Select ⬆ or ⬇.

You can also change the source order by pressing and holding the source on the source list for two seconds.

* Not available on all models

Displaying the Menu Items



Select **Audio Menu** to display the menu items.

The following items are available:


- **Edit Source Order**: Displays the **Edit Source Order** screen.
  Selecting an Audio Source P. 244
- **Sound Settings**: Displays the **Sound Settings** screen.
  Adjusting the Sound P. 256
- **Edit/Delete HDD Music** (HDD mode): Displays the **Edit/Delete HDD Music** screen.
  Editing an Album or Playlist P. 284
- **Radio Text** (FM mode): Displays the text information broadcast by the current RDS station.
  Radio text P. 263

Continued

- **SportsFlash** (SiriusXM® mode): Displays the SportsFlash™ list. If the favorite sport team is not registered, the setup screen of SportsFlash™ is displayed.
  - **Live Sports Alert** P. 270
  - **Customized Features** P. 362
- **Traffic & Weather Now** (SiriusXM® mode): Displays to the Traffic & Weather Now screen.
  - **Traffic and Weather Information** P. 272
- **View Channel Schedule** (SiriusXM® mode): Displays the SiriusXM® channel schedule.
- **Audio Settings**: Displays the **Audio Settings** screen.
  - **Customized Features** P. 362
- **Screen Settings**: Displays the **Screen Settings** screen.
  - **Changing the Screen Settings** P. 247
- **RES Settings***: Displays the **RES Settings** screen.
  - **Rear System Setup** P. 360
  - **Customized Features** P. 362

 * Not available on all models

Changing the Screen Settings



1. Select **Audio Menu**, then select **Screen Settings**.
2. Use +, −, or other icons to adjust the setting.

Changing the Screen Settings

The following are adjustable screen settings:

- **Sync Display Brightness**
  Selects whether the screen brightness synchronizes with the instruments panel brightness.
- **Brightness**
- **Contrast**
- **Black Level**
- **Beep**
  Mutes a beep that sounds every time you touch the screen.
- **Keyboard**
  Changes the on-screen keyboard from the alphabetical order to the qwerty type.


Instead of using +, −, or icons, you can also touch the point where your desired setting is.

Information Screen

Displays the navigation, HFL information, clock/wallpaper, trip computer, Apple CarPlay and Android Auto. From this screen, you can go to various setup options.

■ Switching the Display

Press the **NAV**, **PHONE**, **INFO** and **SMARTPHONE** buttons to go to the corresponding display.



■ **Navigation**
Shows the navigation screen.
➡ **Refer to the Navigation System Manual**

■ **Phone**
Shows the HFL information.
➡ ***Bluetooth*® HandsFreeLink®** P. 397

■ **Info**
Shows the **AcuraLink Messages**, **Trip Computer**, **Clock/Wallpaper**, **Traffic Incidents**, **Power Distribution Monitor** or **Voice Recognition Guide**. Press ⟲ or **INFO** button to display the **Information Menu** screen.

AcuraLink Messages:
Shows a AcuraLink® message menu list.
➡ **AcuraLink Message** P. 442

Trip computer:
Current Drive
Shows the range, instant and average fuel economy, and EV/total drive of the current trip, as well as the average fuel economy from your last trip.

History of Trip A
Shows the range, average fuel economy and distances traveled for the current trip, as well as the average fuel economy and distances traveled during the last three driving cycles.
Each time you reset the trip meter A, the information on the display updates. The history of the previous three driving cycles is kept.

Continued

Deleting the history manually

1. Press ⟲ on the **History of Trip A** screen to select **Delete History**.

2. A confirmation message appears on the screen. Rotate ⟲ to select **Yes**, then press ⟲.

Clock/Wallpaper:
Shows a clock screen or an image you import.

Traffic Incidents:
Shows a traffic incidents list.

➡ **Refer to the Navigation System Manual**

Power Distribution Monitor:
Displays the power flow monitor.

➡ **Power Distribution Monitor** P. 251

Voice Recognition Guide:
Shows a voice recognition guide screen.


■ Smartphone
Displays the Apple CarPlay or Android Auto.

➡ **Apple CarPlay** P. 306
➡ **Android Auto** P. 310

Power Distribution Monitor

Power flow monitor

Consists of the information screen showing the vehicle's power flow and torque distribution indicators.




Shows motor and engine power flow, indicating what supplies power to the vehicle, or if the High Voltage battery is being charged.

Power flow pattern	Color of indicators	Vehicle's Condition
	Blue	Power is supplied by the motors and the engine.

Continued

Power Distribution Monitor

While the vehicle is stationary with the engine running, the following may appear on the screen.




The High Voltage battery charge level gauge shows the current High Voltage battery charge level.

Power flow pattern	Color of indicators	Vehicle's Condition
	Blue	Power is only supplied by the motors.
	Blue	Power is only supplied by the engine.
	Green	The motors charge the High Voltage battery.

■ SPORT HYBRID SH-AWD® torque distribution monitor

The indicators on the screen show the amount of torque being transferred to each wheel or regenerative energy being supplied to the High Voltage battery.

➔ **SPORT HYBRID Super Handling-All Wheel Drive™ (SPORT HYBRID SH-AWD®)**
P. 508




Continued

■ Wallpaper Setup

You can change, store, and delete the wallpaper on the information screen.

■ Import wallpaper



1. Connect the USB flash drive to the USB port (2.5A).
   USB Ports P. 237
2. Press the **SETTINGS** button.
3. Rotate to select **Clock Settings**, then press .
   ▶ Repeat the procedure to select **Clock/ Wallpaper Type**.
4. Move to select **Wallpaper** tab.
   ▶ The screen will change to the wallpaper list.
5. Rotate to select **Options...**, then press .
   ▶ Repeat the procedure to select, **Add New Wallpaper**.



6. Rotate to select a desired picture.
   ▶ The preview is displayed on the left side on the screen.
7. Rotate to select **Start Import**, then press to save the data.
   ▶ The display will return to the wallpaper list.

Wallpaper Setup

- When importing wallpaper files, the image must be in the USB flash drive's root directory. Images in a folder cannot be imported.
- The file name must be fewer than 210 characters.
- The file format of the image that can be imported is BMP (bmp) or JPEG (jpg).
- The individual file size limit is 10 MB.
- The maximum image size is 5,800 x 5,800 pixels.
- Up to 10 files can be saved for each driver (Driver 1 and Driver 2).
- If the USB flash drive does not have any pictures, the **No files detected** message appears.


■ **Select wallpaper**

1. Press the **SETTINGS** button.
2. Rotate to select **Clock Settings**, then press.
▶ Repeat the procedure to select **Clock/Wallpaper Type**.
3. Move to select **Wallpaper**.
▶ The screen changes to the wallpaper list.
4. Rotate to select a desired wallpaper, then press.
▶ The preview is displayed on the left side on the screen.
▶ The pop-up menu appears on the screen.
5. Rotate to select **Set**, then press.
▶ The display will return to the **Clock Settings** screen.

■ **Delete wallpaper**

1. Press the **SETTINGS** button.
2. Rotate to select **Clock Settings**, then press.
▶ Repeat the procedure to select **Clock/Wallpaper Type**.
3. Move to select **Wallpaper**.
▶ The screen changes to the wallpaper list.
4. Rotate to select a wallpaper that you want to delete, then press.
▶ The preview is displayed on the left side on the screen.
▶ The pop-up menu appears on the screen.
5. Rotate to select **Delete**, then press.
▶ The confirmation message will appear.
6. Rotate to select **Yes**, then press to delete completely.
▶ The display will return to the wallpaper list.

Adjusting the Sound



1. Select **Audio Menu**, then select **Sound Settings**.
2. Select the **Bass**, **Treble**, **Fader**, **Balance**, **Center**, **Subwoofer**, **SVC** (Speed-sensitive Volume Compensation) or **DTS Neural Surround**.
3. Use [+], [−] or other icons to adjust the setting.

Adjusting the Sound

The SVC has four modes: **Off**, **Low**, **Mid**, and **High**. SVC adjusts the volume level based on the vehicle speed. As you go faster, audio volume increases. As you slow down, audio volume decreases.

DTS Neural Surround is a trademark of DTS, Inc.

Instead of using [+], [−] or icons, you can also touch the point where your desired setting is.

Display Setup

You can change the brightness of the information screen and On Demand Multi-Use Display™.


■ Changing the Screen Brightness

Information Screen



1. Press the **SETTINGS** button.
2. Rotate ⟲ to select **System Settings**, then press ⊛.
3. Rotate ⟲ to select **Brightness**, then press ⊛.
4. Rotate ⟲ to adjust the setting.
5. Press ⊛.
   ▶ The display will return to the **System Settings** screen.

On Demand Multi-Use Display™



1. Select **Audio Menu**, then select **Screen Settings**.
2. Use +, − to adjust the setting.

Changing the Screen Brightness

You can change the **Contrast** and **Black Level** settings in the same manner.

Voice Control Operation

Your vehicle has a voice control system that allows hands-free operation.
The voice control system uses the (Talk) and (hang-up/back) buttons on the steering wheel and a microphone near the map lights in the ceiling.

■ Voice Recognition

To achieve optimum voice recognition when using the voice control system:

- Make sure the correct screen is displayed for the voice command that you are using.
  The system recognizes only certain commands.
  Available voice command P. 259
- Close the windows and moonroof.
- Adjust the dashboard and side vents so air does not blow onto the microphone in the ceiling.
- Speak clearly in a natural speaking voice without pausing between words.
- Reduce any background noise if possible. The system may misinterpret your command if more than one person is speaking at the same time.


Voice Control Operation

When you press the button, a helpful prompt asks what you would like to do. Press and release the button again to bypass this prompt and give a command.

Voice Recognition

The voice control system can only be used from the driver's seat because the microphone unit removes noises from the front passenger's side.

Voice Portal Screen



When the (Talk) button is pressed, available voice commands appear on the screen.
For a complete list of commands, say "*Voice Help*" after the beep.

The system only recognizes the commands on the following pages, at certain screens. Free form voice commands are not recognized.

Navigation

Refer to the Navigation System Manual

Audio

When the system recognizes the Audio command, the screen will change the dedicated screen for the voice recognition of the audio.

- *Tune to FM <87.7-107.9>*
- *Tune to AM <530-1710>*
- *SiriusXM Channel <0-999>*
- *SXM Channel <0-999>*
- *More*
- *Back*
- *Cancel*
- *Play Artist <Artist>*
- *Play <Artist>*
- *Play Album <Album>*
- *Play <Album>*
- *Play Song <Song>*
- *Play <Song>*
- *Play Composer <Composer>*
- *Play <Composer>*
- *Play Genre <Genre>*
- *Play <Genre>*
- *Play Playlist <Playlist>*
- *Play <Playlist>*
- *List Artist <Artist>*
- *List <Artist>*
- *List Album <Album>*
- *List <Album>*
- *List Composer <Composer>*
- *List <Composer>*
- *List Genre <Genre>*
- *List <Genre>*
- *List Playlist <Playlist>*
- *List <Playlist>*

Continued

■ Phone

This can be only used when the phone is connected. When the system recognizes the Phone command, the screen will change the dedicated screen for the voice recognition of the phone.

- *Dial by Number*
- *Redial*
- *Back*
- *Cancel*
- *Call <Your Contact Name>*
- *Dial <Your Contact Name>*
- *Call <Your Contact Name> <Type>*
- *Dial <Your Contact Name> <Type>*
- *Call <Voice Tag>*
- *Dial <Voice Tag>*

Phone commands are not available if using Apple CarPlay.

■ Voice Help

You can see a list of the available commands on the screen.

- *Phone Commands*
- *Audio Commands*
- *Navigation Commands*
- *Voice Settings*
- *Voice Recognition Guide*

Playing AM/FM Radio


Skip/Seek Icons
Select |◀◀ or ▶▶| to search up and down the selected band for a station with a strong signal.

VOL/⏻ (Volume/Power) Knob
Press to turn the audio system on and off.
Turn to adjust the volume.

Source
Select to change a band or change an audio source.

ⓘ (Information) Icon
Select to display the current station details.
Select ⮌ to display the previous screen.

Preset Icons
Tune the preset radio frequency. Select and hold the preset icon to store that station.
Select ◀◀ or ▶▶ to display preset 6 onwards.



Audio Menu
Select to display the menu items.

Tune
Select to display the manual input screen of radio frequency.

Stations
Select to display the station list screen.

Models with HD Radio™ feature

HD Radio List
Select to display the sub-channel list screen.

On Demand Multi-Use Display™

Continued

■ Preset Memory

To store a station:
1. Tune to the selected station.
2. Select and hold the preset number you want to store that station.

■ Radio Data System (RDS)

Provides text data information related to your selected RDS-capable FM station.

■ To find an RDS station from Station List

1. Select **Stations**.
2. Select station on the list.

■ Manual update

Updates your available station list at any time.
1. Select **Stations**.
2. Select **Refresh** on the list.

Playing AM/FM Radio

You can control the AM/FM radio using voice commands.
➡ **Voice Control Operation** P. 258

The **ST** indicator appears on the display indicating stereo FM broadcasts.
Stereo reproduction in AM is not available.

Switching the Audio Mode
Press the **SOURCE** button on the steering wheel.
➡ **Audio Remote Controls** P. 241


You can store 6 AM stations and 12 FM stations into the preset memory.

Models with HD Radio™ feature

HD Radio Technology manufactured under license from iBiquity Digital Corporation. U.S. and Foreign Patents. HD Radio™ and the HD, HD Radio, and "Arc" logos are proprietary trademarks of iBiquity Digital Corp.



■ Radio frequency manual tune screen



1. Select **Tune**.
2. Enter the desired radio frequency using the numeric keypad.
3. Select **OK** to tune into the frequency.

You can also tune into the radio frequency of your choice following the procedures below instead of inputting its frequency value.
1. Touch the desired frequency value on the frequency bar.
2. Select and hold the frequency indicator, then slide it to the desired frequency value on the frequency bar.

Radio frequency manual tune screen

You can tune the range of FM frequency between 87.7 to 107.9MHz and range of AM frequency between 530 to 1710kHz.

Tune icons:
Select |◀ or ▶| to tune the radio frequency.

Seek icons:
Select |◀◀ or ▶▶| to search the selected band up or down for a station with a strong signal.

■ Radio text

Display the radio text information of the selected RDS station.
1. Select **Audio Menu**.
2. Select **Radio Text**.

Radio text

The text indicator comes on when you received a text message. The indicator stays on until you read the message.


The radio text information is not updated automatically. If you want to display the latest information, return to the previous screen and select **Radio Text** again.

■ Scan

Samples each of the strongest stations on the selected band for 10 seconds.

Select **SCAN**.
To turn off scan, select **Stop Scan**.

Playing SiriusXM® Radio



Category Up/Down Icons
Select ◀ or ▶ to display and select a SiriusXM® Radio category.

VOL/⏻ (Volume/Power) Knob
Press to turn the audio system on and off.
Turn to adjust the volume.

Source
Select to change an audio source.

ⓘ (Information) Icon
Select to display the current channel details.
Select ⮌ to display the previous screen.

Preset Icons
Tune the preset channel. Select and hold the preset icon to store that channel. Select ◀◀ or ▶▶ to display preset 4 onwards.

On Demand Multi-Use Display™

Audio Menu
Select to display the menu items.

Browse
Select to display the channel list of **Categories**, **Channels** or **Featured channels** types.

Tune
Select to display the channel number input screen.

Presets/Controls
Select to change between the **Presets** mode and **Controls** mode of the Replay function.


Channel Up/Down Icons
Select ◀ or ▶ to the previous or next channel.
Select and hold to rapidly skip 10 channels at a time.

To Play SiriusXM® Radio

1. Select the SiriusXM® mode.
- **Audio Remote Controls** P. 241
- **On Demand Multi-Use Display™** P. 244

2. Select a channel using the ◀, ▶ icons or the preset numbers (**1**-**12**) on the preset mode screen.

SiriusXM® channel manual tune screen



1. Select **Tune**.
2. Enter the desired channel number using the numeric keypad.
3. Select **OK** to tune into the channel.

You can also tune into the channel of your choice following the procedures below instead of inputting its channel number.
1. Touch the desired channel number on the channel bar.
2. Select and hold the channel indicator, then slide it to the desired channel number on the channel bar.

Playing SiriusXM® Radio

You can control the SiriusXM® radio using voice commands.
- **Voice Control Operation** P. 258

In the channel mode, all available channels are selectable. In the category mode, you can select a channel within a category (Jazz, Rock, Classical, etc.).

There may be instances when SiriusXM® Radio does not broadcast all the data fields (artist name, title). This does not indicate a problem with your audio system.

SiriusXM® Radio stations load in ascending order, which can take about a minute. Once they have loaded you will be able to scroll up or down to make your selections.


Tune Start:
When you change a channel, a song being played on that channel restarts from the beginning with this function. This can be turned on or off from the **Play the Song from the Beginning** setting.
- **Customized Features** P. 362

SiriusXM® channel manual tune screen

Channel icons:
Select ⏮ or ⏭ to the previous or next channel. Select and hold to rapidly skip 10 channels at a time.

Continued

To change the tune mode:



Channel/Category Icon

1. Select **Tune**.
2. Select **Channel/Category** icon.

■ Preset Memory

To store a station:
1. Tune to the selected channel.
2. Select **Presets/Controls** icon to set the **Presets**.
3. Select and hold the preset number you want to store that channel.

Playing SiriusXM® Radio


You can store 12 SiriusXM® stations into the preset memory.

■ TuneMix™ (Multi-channel preset)

You can store up to 10 of your preferred music channels and listen to them randomly.



1. Tune a channel.
2. Select and hold the preset number you want to store that channel.



3. Select **Add**.
4. Select **Done** to return the previous screen.

To delete a multi-channel preset:
1. Select and hold the preset number you want to delete that channel.
2. Select the channel icon.
3. Select **Delete**.
4. Select **Done** to return the previous screen.

TuneMix™ (Multi-channel preset)

TuneMix™ is registered trademarks of SiriusXM® Radio, Inc.

To store a multi-channel preset, you need to setup the **TuneMix** setting to **On**.
➡ **Customized Features** P. 362

TuneMix™ is available for music channels only.

Continued

■ Listening to Featured Channels

Suggested channel listing received from SiriusXM® can be displayed and selected.

1. Select **Browse**.
2. Select **Featured Channels**.
3. Select a channel.

■ Displaying a Channel Schedule

You can check a channel schedule by selected channel list on the On Demand Multi-Use Display™.

1. Select **Audio Menu**.
2. Select **View Channel Schedule**.

You can also check the other channel by the following procedure.

3. Select **Categories**, **Channels** or **Presets**.
4. Select a channel.

Listening to Featured Channels

Up to three featured channels by SiriusXM® can be displayed.

■ Replay Function

The system constantly records up to the last 60 minutes of your currently tuned channel and all the preset channel broadcast, starting from the moment you turn the power mode to ON. You can rewind and replay the last 60 minutes of each broadcast.



1. Select **Presets/Controls** to set the **Controls**.
2. Select an option.

The following items are available:
▶/❚❚: Pauses or plays a storing broadcast.
LIVE: Returns to real-time broadcast.
|◀◀: Skips to the previously stored channel.
▶▶|: Skips to the next channel.
15: Select to skip back 15 seconds in the current selection. Select and hold to fast-rewind the current selection.
15: Select to skip forward 15 seconds in the current selection. Select and hold to fast-forward the current selection.


■ Returning to real-time broadcast

Select LIVE while listening to the playback channel.

Replay Function

The system starts storing broadcast in memory when the power mode is turned ON. You can go back to the program from that point.

You can no longer replay any program once the power mode is turned OFF as it erases memory. You can check how long the program has been stored in memory from the On Demand Multi-Use Display™.




(A): Shows how much time the replayed segment is behind the real-time broadcast
(B): Replayed segment
(C): Length stored in memory

Continued

■ Live Sports Alert

While listening to other channels you can receive sports alerts such as scores from your favorite teams.

■ To set up a sports alert



1. Select **Audio Menu**.
2. Select **Audio Settings**.
3. Select **SiriusXM**.
4. Select **SportsFlash**.
5. Select **Notification**, then select **Enable**.
6. Select **Favorite Teams**, then select a team.

Live Sports Alert

The sports alert function at SiriusXM® mode only.

To set up a sports alert

Sports alerts cut in only when SiriusXM® mode is on. Selecting **Enable once** from customized settings disables the alert feature next time you turn the power mode to ON.

➡ **Customized Features** P. 362

■ **Receiving a sports alert**

1. A pop-up appears and notifies you of a sports alert.

2. Select **Listen Now**.



The following items are available:

: Pauses or plays a current sports alert.

: Returns to real-time broadcast.

: Skips to the previously stored sports alert.

: Skips to the next stored sports alert.

: Select to skip back 15 seconds to the current sports alert. Select and hold to fast-rewind the current sports alert.

: Select to skip forward 15 seconds to the current sports alert. Select and hold to fast-forward the current sports alert.

Back: Returns to previous channel.

■ **Listening to a missed sports alert**

1. Select **Audio Menu**.

2. Select **SportsFlash**.


3. Select an item.

Continued

■ Traffic and Weather Information

You can receive the SiriusXM® traffic and weather information service in SiriusXM® mode.

■ To set up a traffic & weather information



1. Select **Audio Menu**.
2. Select **Audio Settings**.
3. Select **SiriusXM**.
4. Select **Traffic & Weather Now Setup**.
5. Select the region.
   ▶ When you do not want to receive the information, select **No City Selected**.

Traffic and Weather Information

The traffic and weather information function in SiriusXM® mode only.

Traffic & Weather Now are registered trademarks of SiriusXM® Radio, Inc.


To set up a traffic & weather information

When you listen to the traffic and weather information service, set up the applicable city using **Traffic & Weather Now Setup**.

■ **Listening a traffic and weather information**

1. Select **Audio Menu**.

2. Select **Traffic & Weather Now**.



The following items are available:

: Pauses or plays a stored broadcast.

: Returns to real-time broadcast.

: Skips to the previously stored channel.

: Skips to the next channel.

: Select to skip back 15 seconds in the current broadcast. Select and hold to fast-rewind the current broadcast.

: Select to skip forward 15 seconds in the current broadcast. Select and hold to fast-forward the current broadcast.

Back: Returns to previous channel.

Continued

■ Scan

Sample each channel on the selected mode for 10 seconds.

1. Select **Presets/Controls** to set the **Controls**.

2. Select **SCAN**.

3. Select **Scan Channels** or **Scan Presets**.

To turn off scan, select **Stop Scan**.

Scan

You can select desired channel by songs using **Scan Presets**.

The "Scan Songs in Presets" function is based on TuneScan™ technology of SiriusXM®.

The "Featured Channels" function is based on Featured Favorites™ technology of SiriusXM®.

TuneScan™ and Featured Favorites™ are registered trademarks of SiriusXM® Radio, Inc.


Scan Mode Menu Items

Scan Channels: Scans for channels with a strong signal in the selected mode.

Scan Presets: Scans for desired preset channel by songs. Select ▶▶| (skip up) or |◀◀ (skip down) to skip to the next/previous stored selection.

Playing a CD

Your audio system supports audio CDs, CD-Rs and CD-RWs in either MP3, WMA, or AAC*1 format. With the CD loaded, select the CD mode.



Folder Up/Down Icons
Select ◀ or ▶ to skip to the next folder, and to skip to the beginning of the previous folder in MP3, WMA, or AAC.

VOL/⏻ (Volume/Power) Knob
Press to turn the audio system on and off.
Turn to adjust the volume.

Source
Select to change an audio source.

ⓘ (Information) Icon
Select to display the current track/file details.
Select ⮌ to display the previous screen.

Repeat Icon
Select to repeat the current track/file.

SCAN Icon
Select to listen to a 10-second sampling of each track/file.

CD Slot
Insert a CD about halfway into the CD slot.

Audio Menu
Select to display the menu items.

⏏ (CD Eject) Button
Press to eject a CD.

Search
Select to display the music search list screen.

Skip/Seek Icons
Select ⏮ or ⏭ to change tracks (files in MP3, WMA, or AAC).
Select and hold to move rapidly within a track/file.

On Demand Multi-Use Display™

Random Icon
Select to play tracks/files in random order.

*1:Only AAC format files recorded with iTunes are playable on this unit.

Continued

How to Select a File from the Music Search List (MP3/WMA/AAC)

Folder Selection



File Selection



1. Select **Search**.
2. Select a folder.

3. Select a track.

Playing a CD

NOTICE

Do not use CDs with adhesive labels. The label can cause the CD to jam in the unit.

WMA and AAC files protected by digital rights management (DRM) cannot be played.
The audio system skips to the next file.

Text data appears on the display under the following circumstances:
- When you select a new folder, file, or track.
- When you change the audio mode to CD.
- When you insert a CD.

If you eject the CD but do not remove it from the slot, the system reloads the CD automatically after several seconds.


How to Select a Play Mode

You can select scan, repeat, and random modes when playing a track or file.



■ Scan

Select **SCAN** to provides 10-second sampling of each tracks/files.



■ Random/Repeat

Select repeat or random icon repeatedly until a desired mode.

■ To turn off a play mode

To turn off scan, select **Stop Scan**.

To turn off random/repeat, select repeat or random icon repeatedly.

How to Select a Play Mode

Play Mode Menu Items

SCAN

Scan Folders (MP3/WMA/AAC): Provides a 10-second sampling of the first file in each of the main folders.

Scan Tracks (MP3/WMA/AAC): Provides a 10-second sampling of all files in the current folder in MP3, WMA, or AAC.

Repeat

(repeat off): Repeat mode to off.

(repeat track): Repeats the current track/file.

(repeat folder) (MP3/WMA/AAC): Repeats all files in the current folder.

Random


(random off): Random mode to off.

(random in folder) (MP3/WMA/AAC): Plays all files in the current folder in random order.

(random all tracks): Plays all tracks/files in random order.

Playing Hard Disk Drive (HDD) Audio

The Hard Disk Drive (HDD) Audio function plays tracks from music CDs that have been recorded onto the built-in HDD. You can arrange the tracks in playlists or play the tracks using various search methods.



Playlist/Album Up/Down Icons
Select ▶ to skip to the next playlist/album, and ◀ to skip to the beginning of the previous playlist/album.

VOL/⏻ (Volume/Power) Knob
Press to turn the audio system on and off.
Turn to adjust the volume.

Source
Select to change an audio source.

ⓘ (Information) Icon
Select to display the current track details.
Select ⮌ to display the previous screen.

Repeat Icon
Select to repeat the current track.

SCAN Icon
Select to use a scan feature.

Random Icon
Select to play tracks in random order.

CD Slot
Insert a CD about halfway into the CD slot.

Audio Menu
Select to display the menu items.

⏏ (CD Eject) Button
Press to eject a CD.

Browse
Select to display the music search list screen.

Track Menu
Select to display the track menu.

Skip/Seek Icons
Select ⏮ or ⏭ to change tracks.
Select and hold to move rapidly within a track.

On Demand Multi-Use Display™

Recording a Music CD to HDD

When **Recording from CD** is set to **Auto**, the songs on music CDs are automatically recorded to the HDD the first time you play each disc. You can then play the songs directly from the HDD.

➡ **Customized Features** P. 362



Stop Recording

Select ◉. (in CD mode)

Recording a CD Manually

When **Recording from CD** is set to **Manual**, the songs on music CDs can be manually recorded to the HDD.

Select ◉. (in CD mode)

Recording a Music CD to HDD

You can add tracks to user playlists, where you can mix and match tracks from other CDs recorded on the HDD.

➡ **Editing an Album or Playlist** P. 284
➡ **Editing Track Information** P. 287

If you turn off the power system or the audio system is turned off while recording a CD, there may be pauses between songs when you play back from the HDD.

Repeat, random, and scan functions are not available during recording.

You can play music from other sources (e.g., SiriusXM®, HDD, etc.) while recording.

Please note that there is no compensation offered in the case of unsuccessful recording of audio data or the loss of audio data due to any cause whatsoever.

Clearing the HDD

Any music tracks stored on the HDD can be deleted.

➡ **Deleting all HDD Data** P. 290

Continued

How to Select a Track from the Music Search List



1. Select **Browse**.
2. Select the items on that menu.
▶ Title information is displayed if found in the Gracenote® Album Info (Gracenote® Media Database) stored on the HDD.
▶ The HDD has two types of playlists: original playlists and user playlists. An original playlist is automatically created for each album when a music CD is recorded.

How to Select a Track from the Music Search List

You can control the HDD audio using voice commands.
➡ **Voice Control Operation** P. 258
➡ **Song By Voice™ (SBV)** P. 294

Music tracks recorded on HDD cannot be recorded onto CDs or other devices.


Tracks are recorded at four times the playback speed using ultra-efficient compression technology; therefore, sound quality may vary slightly from the original.

If the HDD is ever replaced, all music data is lost and cannot be recovered.

If there is a problem, you may see an error message on the On Demand Multi-Use Display™.
➡ **Hard Disk Drive (HDD) Audio** P. 316

How to Select a Play Mode

You can select scan, repeat, and random modes when playing a track.



Scan

Select **SCAN** to provides 10-second sampling of each tracks.

How to Select a Play Mode

Play Mode Menu Items

SCAN

The following menu items vary depending on the category you selected by the **Browse** list.

Scan Albums: Provides a 10-second sampling of all tracks in current album.

Scan Tracks: Provides a 10-second sampling of all tracks on the HDD.

Scan Artists: Provides a 10-second sampling of all tracks in current artist.


Scan Playlists: Provides a 10-second sampling of all tracks in current playlist.

Scan Genres: Provides a 10-second sampling of all tracks in current genre.

Scan Composers: Provides a 10-second sampling of all tracks in current composer.

Scan Rec. Date: Provides a 10-second sampling of all tracks in current recorded date.

Continued



■ Random/Repeat

Select repeat or random icon repeatedly until a desired mode.

■ To turn off a play mode

To turn off scan, select **Stop Scan**.

To turn off random/repeat, select repeat or random icon repeatedly.

Random/Repeat

Random/Repeat


The following menu items vary depending on the category you selected by the **Browse** list.

Repeat

- (repeat off): Changes repeat mode to off.
- (repeat track): Repeats the current track.
- (repeat album): Repeats all tracks in the current album.
- (repeat playlist): Repeats all tracks in the current playlist.
- (repeat artist): Repeats all tracks in the current artist.
- (repeat genre): Repeats all tracks in the current genre.
- (repeat composer): Repeats all tracks in the current composer.
- (repeat recorded date): Repeats all tracks in the current recorded date.

Editing a Current Track

You can edit the information of the current selected track on the playlist.



1. Select **Track Menu**.
2. Select the items on that menu.

The following items are available:
Replay: Select to replay from the beginning of current selected track.
Add to Playlist: Add a current selected track to the playlist.
Edit Name: Edit current selected track information.
Delete: Delete a current selected track from the album and playlist.
Move: Change the order of tracks currently playing in an album or playlist.

Random/Repeat

Random

(random off): Changes random mode to off.

(random all tracks): Plays all tracks in random order.

(random in album): Plays all tracks in the current album in random order.

(random in playlist): Plays all tracks in the current playlist in random order.

(random in artist): Plays all tracks in the current artist in random order.

(random in genre): Plays all tracks in the current genre in random order.


(random in composer): Plays all tracks in the current composer in random order.

(random in recorded date): Plays all tracks in the current recorded date in random order.

Continued

■ Editing an Album or Playlist

Change the playlist name, album name, genre, and track order of the current playlist. You can also delete tracks, playlists, and albums.



■ **Editing an album**

1. Select **Audio Menu**.
2. Select **Edit/Delete HDD Music**.
3. Select the items other than **Tracks** and **Playlists** on that menu.
4. Select an album that you want to edit or delete.
5. To edit an album name:
   Select **Edit Name**, then select **Album Name**.
   ▶ Enter the album name using the keyboard, then select **OK**.

   To delete an album:
   Select **Delete**, then select **Yes**.

   To edit track information or delete a track:
   Select **List Tracks**.
   ➡ **Editing Track Information** P. 287
6. Select **Done**.


Editing an Album or Playlist

The maximum number of original playlists is 50 with a maximum of 99 songs in each playlist.

Each album CD counts as an original playlist. Adding a track from a user playlist into the same user playlist will cause the track to appear twice in the playlist.

Deleting an album (original playlist) also deletes the album tracks you have stored in any user playlists.

Deleting a user playlist or deleting all tracks from a user playlist does not remove the playlist folder. The folder retains the playlist name and artist information.



■ Editing a playlist

1. Select **Audio Menu**.
2. Select **Edit/Delete HDD Music**.
3. Select **Playlists**.
4. Select a playlist that you want to edit or delete.

5. To edit a playlist name:
Select **Edit Name**, then select **Playlist Name**.
▶ Enter the playlist name using the keyboard, then select **OK**.

To delete a playlist:
Select **Delete**, then select **Yes**.

To edit track information or delete a track:
Select **List Tracks**.
➡ **Editing Track Information** P. 287

6. Select **Done**.

Continued



■ **Creating a new playlist**


1. Select **Audio Menu**.
2. Select **Edit/Delete HDD Music**.
3. Select **Playlists**.

4. Select **Create New Playlist**.

5. Enter the playlist name using the keyboard, then select **OK**.
6. Select an item, then select desired track.
7. Select **Done**.

■ Editing Track Information

Change the track title, artist name, genre and composer. You can also delete tracks.



1. Select **Audio Menu**.
2. Select **Edit/Delete HDD Music**.
3. Select **Tracks**.
4. Select a track you want to edit or delete.

5. To edit track information:
Select **Edit Name**, then select **Track Name**, **Track Artist**, etc.
▶ Enter the track name, track artist, etc. using the keyboard, then select **OK**.


To delete a track:
Select **Delete**, then select **Yes**.


6. Select **Done**.


Continued

■ Displaying Music Information

Music information (album name, artist name, genre) can be acquired by accessing the Gracenote® Album Info.








1. Select **Audio Menu**.
2. Select **Edit/Delete HDD Music**.
3. Select an item about which you want to acquire information.
4. Select **Edit Name**.
5. Select **Get Music Information**.
   ► The system starts to access the Gracenote® Album Info.

Updating Gracenote® Album Info

Update the Gracenote® Album Info (Gracenote® Media Database) that is included with the navigation system.



1. Select **Audio Menu**.
2. Select **Audio Settings**.
3. Select **CD/HDD**.
4. Insert the update disc into the disc slot or connect the USB flash drive that includes the update.
5. Select **Update Gracenote Album Information**.
6. Select **Update by CD** or **Update by USB**.
   ▶ The system starts updating and the confirmation message appears on the screen. Select **OK** to finish.

Updating Gracenote® Album Info


To acquire updated files:
- Consult a dealer.
- U.S.: Visit *www.acura.com*.
- Canada: Visit *www.acura.ca*.

Once you perform an update, any information you edited before will be overwritten or erased.

Continued

■ Deleting all HDD Data

Delete all music data on the HDD.




1. Select **Audio Menu**.
2. Select **Audio Settings**.
3. Select **CD/HDD**.
4. Select **Delete All HDD Data**.
▶ The confirmation message will appear.
5. Select **Yes**.

Playing an iPod

Connect the iPod using your USB connector to the USB port (2.5A), then select the iPod mode.

USB Ports P. 237



VOL/ (Volume/Power) Knob
Press to turn the audio system on and off.
Turn to adjust the volume.

Source
Select to change an audio source.

(Information) Icon
Select to display the current song details.
Select to display the previous screen.

Repeat Icon
Select to repeat the current song.

/ (Play/Pause) Icon
Select to pause or play a song.

Skip/Seek Icons
Select or to change songs.
Select and hold to move rapidly within a song.

Audio Menu
Select to display the menu items.

Browse
Select to display the music search list screen.

On Demand Multi-Use Display™

Shuffle Icon
Select to change a play mode in album shuffle or shuffle all songs.

How to Select a Song from the Music Search List



1. Select **Browse**.
2. Select the items on that menu.

How to Select a Song from the Music Search List


You can control an iPod using voice commands.
➔ **Voice Control Operation** P. 258
➔ **Song By Voice™ (SBV)** P. 294

Available operating functions vary on models and/or versions. Some functions may not be available on the vehicle's audio system.

If there is a problem, you may see an error message on the On Demand Multi-Use Display™.
➔ **iPod/USB Flash Drive** P. 317

■ How to Select a Play Mode

You can select repeat and shuffle modes when playing a song.



■ Shuffle/Repeat

Select shuffle or repeat icon repeatedly until a desired mode.

■ To turn off a play mode

To turn off the shuffle or repeat, select shuffle or repeat icon repeatedly.

How to Select a Play Mode

Play Mode Menu Items

Repeat

(repeat off)*1: Repeat mode to off.

(repeat song): Repeats the current song.

(repeat all): Repeats the all songs.

Shuffle

(shuffle off): shuffle mode to off.

(shuffle all songs): Plays all available songs in a selected list (playlists, artists, albums, songs, genres, or composers) in random order.


(shuffle albums): Plays all available albums in a selected list (playlists, artists, albums, songs, genres, or composers) in random order.

*1: Not available on all iPod.

Song By Voice™ (SBV)

Use SBV to search for and play music from your HDD or iPod using voice commands.

■ To enable SBV




1. Press the **SETTINGS** button.
2. Rotate ☎ to select **System Settings**, then press ⊛.
3. Move ◁○ or ○▷ to select the **Voice Reco.** tab.
4. Rotate ☎ to select **Song By Voice**.
5. Press ⊛ to select **On** or **Off**.

Song By Voice™ (SBV)

Setting options:

- **On** (factory default): Song By Voice™ commands are available.
- **Off**: Disable the feature.

■ Searching for music using SBV



1. Set the **Song By Voice** setting to **On**.

2. Press the (Talk) button and say *"Audio"* to activate the SBV feature for the HDD and iPod.

3. Press the button and say a command.
- ▶ Example 1: Say *"(List) 'Artist A'"* to view a list of songs by that artist. Select the desired song to start playing.
- ▶ Example 2: Say *"Play 'Artist A'"* to start playing songs by that artist.

4. To cancel SBV, press the (hang-up/back) button on the steering wheel. The selected song continues playing.

Once you have canceled this mode, you need to press the button and say *"Audio"* again to re-activate this mode.

Searching for music using SBV

Song By Voice™ Commands List
➡ **Voice Control Operation** P. 258

NOTE:
Song By Voice™ commands are available for tracks stored on the HDD or iPod.


You can add phonetic modifications of difficult words so that it is easier for SBV to recognize artists, songs, albums, and composers in voice commands.
➡ **Phonetic Modification** P. 296

SBV may not be able to recognize languages other than English for the artist name, song title, album title, and composers.

Continued

■ Phonetic Modification

Add phonetic modifications of difficult or foreign words so that it is easier for SBV to recognize artists, songs, albums, and composers in voice commands when searching for music on the HDD or iPod.




1. Press the **SETTINGS** button.
2. Rotate ⟲ to select **System Settings**, then press ⟲.
3. Move ◁○ or ○▷ to select the **Voice Reco.** tab.
4. Rotate ⟲ to select **Song By Voice Phonetic Modification**, then press ⟲.
5. Rotate ⟲ to select **New Modification**, then press ⟲.
6. Rotate ⟲ to select **HDD** or **iPod**, then press ⟲.

Phonetic Modification

Song By Voice Phonetic Modification is grayed out when **Song By Voice** is set to **Off**.

You can store up to 2,000 phonetic modification items.





On Demand Multi-Use Display™



7. Rotate ⟲ to select the item to modify (e.g., **Artist**), then press ⊙.
▶ The list of the selected item appears on the screen.

8. Rotate ⟲ to select an entry (e.g., **No Name**), then press ⊙.
▶ The pop-up menu appears on the screen.

9. Rotate ⟲ to select **Modify**, then press ⊙.
▶ To listen to the current phonetic modification, rotate ⟲ to select **Play**, then press ⊙.
▶ To delete the current phonetic modification, rotate ⟲ to select **Delete**, then press ⊙.

10. Enter the phonetic spelling you wish to use (e.g., *"Artist A"*) when prompted.

11. Select **OK** to exit.
▶ The artist *"No Name"* is phonetically modified to *"Artist A."* When in the SBV mode, you can press the 🎤 (Talk) button and use the voice command *"Play 'Artist A'"* to play songs by the artist *"No Name."*

Playing Pandora®*1


Your audio system allows you to listen to music from the Pandora® app on a compatible smartphone.
This function is available when the phone is paired and connected to the vehicle's *Bluetooth*® HandsFreeLink® (HFL) system, or with an iPhone, you can connect using your USB cable to the USB port (2.5A).

Phone Setup P. 405
USB Ports P. 237

Playing Pandora®*1

Pandora®, the Pandora logo, and the Pandora trade dress are trademarks or registered trademarks of Pandora Media, Inc., used with permission. Pandora is currently available exclusively in the United States.

To find out if your phone is compatible with this feature, visit *www.handsfreelink.com/Acura*, or call 1-888-528-7876.



VOL/⏻ (Volume/Power) Knob
Press to turn the audio system on and off.
Turn to adjust the volume.

Source
Select to change an audio source.

(Information) Icon
Select to display the current track details.
Select ↩ to display the previous screen.

Like/Dislike Icons
Select to evaluate a track.

Play/Pause Icon
Select to pause or play a track.

Station Up/Down Icons
Select to change a station.

Audio Menu
Select to display the menu items.

Stations
Select to display the station list screen.

Bookmark Track Icon
Bookmarks the current track.

Bookmark Artist Icon
Bookmarks the current artist.

On Demand Multi-Use Display™

Skip Icon
Select to skip a track.


*1:Available only on U.S. models.

How to Select a Track from the Stations List

1. Select **Stations**.
2. Select a item to select a track.

Create Station

Select track or artist name.



You can create a station by **Genre**, **Current Track** or **Current Artist**.
1. Select **Stations**.
2. Select **Create Station**.
3. Select the item you want to create a station.

You can also create a station by the following procedure.
1. Select track name or artist name.
2. Select **Yes**.

Select the connecting method

If the two devices that install Pandora app are connected via the USB and *Bluetooth*® connection separately, you can select the USB or *Bluetooth*® connection to use the Pandora®.

1. Select the **PANDORA** on the source list screen.
2. Select **USB** or **Bluetooth**.

Playing Pandora®*1

Pandora® is a personalized Internet radio service that selects music based on an artist, track, or genre a user enters, and streams what is likely to be of interest.

To use this service in your vehicle, the Pandora® app must first be installed on your phone. Visit *www.pandora.com*. for more information.

If you cannot operate Pandora® through the audio system, it may be streaming through *Bluetooth*® Audio. Make sure Pandora® mode on your audio system is selected.

Available operating functions vary on software versions. Some functions may not be available on the vehicle's audio system.

If there is a problem, you may see an error message on the On Demand Multi-Use Display™.
Pandora® P. 319

There are restrictions on the number of tracks you can skip or dislike in a given hour.


If your phone is connected to Android Auto, Pandora® is only available through the Android Auto interface.
Visit the Android Auto website to check compatibility.

Playing a USB Flash Drive

Your audio system reads and plays sound files on a USB flash drive in either MP3, WMA, or AAC*1 format.

Connect your USB flash drive to the USB port (2.5A), then select the USB mode.

USB Ports P. 237



VOL/ (Volume/Power) Knob
Press to turn the audio system on and off.
Turn to adjust the volume.

Source
Select to change an audio source.

(Information) Icon
Select to display the current file details.
Select to display the previous screen.

Repeat Icon
Select to repeat the current file.

SCAN Icon
Select to listen to a 10-second sampling of each file.

Folder Up/Down Icons
Select ◀ or ▶ to skip to the next folder, and to skip to the beginning of the previous folder.

Audio Menu
Select to display the menu items.

Search
Select to display the music search list screen.

Skip/Seek Icons
Select |◀◀ or ▶▶| to change files.
Select and hold to move rapidly within a file.

On Demand Multi-Use Display™

Random Icon
Select to play all files in random order.

*1:Only AAC format files recorded with iTunes are playable on this unit.

How to Select a File from the Music Search List

Folder Selection



File Selection



1. Select **Search**.
2. Select a folder.

3. Select a file.

Playing a USB Flash Drive

Use the recommended USB flash drives.

General Information on the Audio System P. 323

Files in WMA/AAC format protected by digital rights management (DRM) are not played.
The audio system skips to the next file.


If there is a problem, you may see an error message on the On Demand Multi-Use Display™.

iPod/USB Flash Drive P. 317

Continued


■ How to Select a Play Mode

You can select scan, repeat, and random modes when playing a file.



■ Scan

Select **SCAN** to provide a 10-second sampling of each file.



■ Random/Repeat

Select repeat or random icon repeatedly until a desired mode.

■ To turn off a play mode

To turn off scan, select **Stop Scan**.

To turn off random or repeat, select repeat or random icon repeatedly.

How to Select a Play Mode

Play Mode Menu Items

SCAN

Scan Folders: Provides a 10-second sampling of the first file in each of the main folders.

Scan Tracks: Provides a 10-second sampling of all files in the current folder.

Repeat

(repeat off): Repeat mode to off.

(repeat track): Repeats the current file.

(repeat folder): Repeats all files in the current folder.

Random

(random off): Random mode to off.

(random in folder): Plays all files in the current folder in random order.


(random all tracks): Plays all files in random order.

Playing *Bluetooth*® Audio

Your audio system allows you to listen to music from your *Bluetooth*-compatible phone.

This function is available when the phone is paired and connected to the vehicle's *Bluetooth*® HandsFreeLink® (HFL) system.

Phone Setup P. 405



Source
Select to change an audio source.

VOL/⏻ (Volume/Power) Knob
Press to turn the audio system on and off.
Turn to adjust the volume.

(Information) Icon
Select to display the current file details.
Select ⮌ to display the previous screen.

Play Icon

Pause Icon

Folder Up/Down Icons
Select ◀ or ▶ to change folders.

Audio Menu
Select to display the menu items.

Browse
Select to display the track list screen.

Skip/Seek Icons
Select ⏮ or ⏭ to change files.

On Demand Multi-Use Display™

Playing *Bluetooth*® Audio

Not all *Bluetooth*-enabled phones with streaming audio capabilities are compatible with the system. For a list of compatible phones:

- U.S.: Visit *www.handsfreelink.com/Acura*, or call 1-888-528-7876.
- Canada: For more information on smartphone compatibility, call 1-888-528-7876.

In some states, it may be illegal to perform some data device functions while driving.

If more than one phone is paired to the HFL system, there will be a delay before the system begins to play.


Some functions may not be available on some devices.

If a phone is currently connected via Apple CarPlay or Android Auto, *Bluetooth*® Audio from that phone is unavailable. However, a second previously paired phone can stream *Bluetooth*® Audio by selecting **Connect to Audio** from the **Edit Bluetooth Device**.

Phone Setup P. 405

Continued

■ To Play *Bluetooth*® Audio Files




1. Make sure that your phone is paired and connected to HFL.
2. Select the *Bluetooth*® Audio mode.

If the phone is not recognized, another HFL-compatible phone, which is not compatible for *Bluetooth*® Audio, may already be connected.

■ To pause or resume a file
Select the play icon or pause icon.

■ Searching for Music



1. Select **Browse**.
2. Select a search category (e.g., Albums).
3. Select an item.
▶ The selection begins playing.

To Play *Bluetooth*® Audio Files

To play the audio files, you may need to operate your phone. If so, follow the phone maker's operating instructions.

The pause function may not be available on some phones.

Switching to another mode pauses the music playing from your phone. This function may not be available on some phones.

Searching for Music

Depending on the *Bluetooth*® device you connect, some or all of the lists may not be displayed.


Features

Siri Eyes Free

You can talk to Siri using the Talk button on the steering wheel when your compatible iPhone is paired to *Bluetooth*® HandsFreeLink®.

Phone Setup P. 405

Using Siri Eyes Free



Siri Eyes Free

Siri is a trademark of Apple Inc.

Check Apple Inc. website for features available for Siri.

We recommend against using Siri other than in Siri Eyes Free while operating a vehicle.

Using Siri Eyes Free


Some commands work only on specific phone features or apps.

Apple CarPlay

If you connect an Apple CarPlay-compatible iPhone to the system via the 2.5A USB port (), you can use the information screen, instead of the iPhone display, to make a phone call, listen to music, view maps (navigation), and access messages.

USB Ports P. 237

■ Apple CarPlay Menu



*1:The operation methods may differ from your connected iPhone.

Apple CarPlay

Only iPhone 5 or newer versions with iOS 8.4 or later are compatible with Apple CarPlay.

Park in a safe place before connecting your iPhone to Apple CarPlay and when launching any compatible apps.

To use Apple CarPlay, connect the USB cable to the 2.5A USB port ().

USB Ports P. 237

To directly access the Apple CarPlay phone function, press the **PHONE** button. While connected to Apple CarPlay, calls are only made through Apple CarPlay. If you want to make a call with *Bluetooth*® HandsFreeLink®, turn Apple CarPlay OFF or detach the USB cable from your iPhone.

Setting Up Apple CarPlay P. 308

When your iPhone is connected to Apple CarPlay, it is not possible to use the *Bluetooth*® Audio or *Bluetooth*® HandsFreeLink®. However, other previously paired phones can stream audio via *Bluetooth*® while Apple CarPlay is connected.

Phone Setup P. 405

For details on countries and regions where Apple CarPlay is available, as well as information pertaining to function, refer to the Apple homepage.

■ **Phone**
Access the contact list, make phone calls, or listen to voice mail.

■ **Messages**
Check and reply to text messages, or have messages read to you.

■ **Music**
Play music stored on your iPhone.

■ **Maps**
Display Apple Maps and use the navigation function just as you would on your iPhone.

Only one navigation system (pre-installed navigation or Apple Maps) can give directions at a time. When you are using one system, directions to any prior destination set on the other system will be canceled, and the system you are currently using will direct you to your destination.

Apple CarPlay

Apple CarPlay Operating Requirements & Limitations
Apple CarPlay requires a compatible iPhone with an active cellular connection and data plan. Your carrier's rate plans will apply.

Changes in operating systems, hardware, software, and other technology integral to providing Apple CarPlay functionality, as well as new or revised governmental regulations, may result in a decrease or cessation of Apple CarPlay functionality and services. Acura cannot and does not provide any warranty or guarantee of future Apple CarPlay performance or functionality.

It is possible to use 3rd party apps if they are compatible with Apple CarPlay. Refer to the Apple homepage for information on compatible apps.

Continued

■ Setting Up Apple CarPlay

After you have connected your iPhone to the system via the 2.5A USB port (), use the following procedure to set up Apple CarPlay. Use of Apple CarPlay will result in the transmission of certain user and vehicle information (such as vehicle location, speed, and status) to your iPhone to enhance the Apple CarPlay experience. You will need to consent to the sharing of this information on the information screen.

■ Enabling Apple CarPlay



Enable Once: Allows only once. (Prompt shows again next time.)
Always Enable: Allows anytime. (Prompt does not show again.)
Cancel: Does not allow this consent.

You may change the consent settings under the **Smartphone Settings** menu.


Setting Up Apple CarPlay

You can also use the method below to set up Apple CarPlay:
Press the SETTINGS→Select Smartphone Settings→Apple CarPlay Device List

Use of user and vehicle information
The use and handling of user and vehicle information transmitted to/from your iPhone by Apple CarPlay is governed by the Apple iOS terms and conditions and Apple's Privacy Policy.

■ Operating Apple CarPlay with Siri

Press and hold the talk button to activate Siri.



Operating Apple CarPlay with Siri

Below are examples of questions and commands for Siri.

- What movies are playing today?
- Call dad at work.
- What song is this?
- How's the weather tomorrow?
- Read my latest email.
- Find a table for four tonight in Chicago.

For more information, please visit *www.apple.com/ios/siri*.

Android Auto

When you connect an Android phone to the audio system via the 2.5A USB port (), Android Auto is automatically initiated. When connected via Android Auto, you can use the information screen to access the Phone, Google Maps (Navigation), Google Play Music, and Google Now functions. When you first use Android Auto, a tutorial will appear on the screen.

We recommend that you complete this tutorial while safely parked before using Android Auto.

➔ **USB Ports** P. 237

➔ **Auto Pairing Connection** P. 313

Android Auto

To use Android Auto, you need to download the Android Auto app from Google Play to your smartphone.

Only Android 5.0 (Lollipop) or later versions are compatible with Android Auto.
Bluetooth A2DP cannot be used with Android Auto phone.

Park in a safe place before connecting your Android phone to Android Auto and when launching any compatible apps.


To use Android Auto, connect the USB cable to the 2.5A USB port ().

➔ **USB Ports** P. 237

When your Android phone is connected to Android Auto, it is not possible to use the *Bluetooth*® Audio. However, other previously paired phones can stream audio via *Bluetooth*® while Android Auto is connected.

➔ **Phone Setup** P. 405

Android Auto Menu



*1:The operation methods may differ from your connected Android phone.

Android Auto

For details on countries and regions where Android Auto is available, as well as information pertaining to function, refer to the Android Auto homepage.

Android Auto Operating Requirements & Limitations

Android Auto requires a compatible Android phone with an active cellular connection and data plan. Your carrier's rate plans will apply.

Changes in operating systems, hardware, software, and other technology integral to providing Android Auto functionality, as well as new or revised governmental regulations, may result in a decrease or cessation of Android Auto functionality and services. Acura cannot and does not provide any warranty or guarantee of future Android Auto performance or functionality.

It is possible to use 3rd party apps if they are compatible with Android Auto. Refer to the Android Auto homepage for information on compatible apps.

Continued

❶ Maps (Navigation)
Display Google Maps and use the navigation function just as you would with your Android phone. When the vehicle is in motion, it is not possible to make keyboard entries. Stop the vehicle in a safe location to undertake a search or provide other inputs.

Only one navigation system (pre-installed navigation or Android Auto) can give directions at a time. When you are using one system, directions to any prior destination set on the other system will be canceled, and the system you are currently using will direct you to your destination.
The information screen shows you turn-by-turn driving directions to your destination.

❷ Phone (Communication)
Make and receive phone calls as well as listen to voicemail.

❸ Google Now (Home screen)
Display useful information organized by Android Auto into simple cards that appear just when they're needed.

❹ Music and audio
Play Google Play Music and music apps that are compatible with Android Auto. To switch between music apps, press this icon.


❺ Go back to the previous screen of this audio system.

❻ Voice
Operate Android Auto with your voice.

■ Auto Pairing Connection

When you connect an Android phone to the unit via the 2.5A USB port (), Android Auto is automatically initiated.

■ Enabling Android Auto



Enable Once: Allows only once. (Prompt shows again next time.)
Always Enable: Allows anytime. (Prompt does not show again.)
Cancel: Does not allow this consent.

You may change the consent settings under the **Smartphone Settings** menu.

Enabling Android Auto

Only initialize Android Auto when you are safely parked. When Android Auto first detects your phone, you will need to set up your phone so that auto pairing is possible. Refer to the instruction manual that came with your phone.


You can use the method below to change Android Auto settings after you have completed the initial setup:
Press the SETTINGS→Select Smartphone Settings→Android Auto Device List

Use of user and vehicle information
The use and handling of user and vehicle information transmitted to/from your phone by Android Auto is governed by Google's Privacy Policy.

Continued

■ Operating Android Auto with Voice Recognition

Press and hold the talk button to operate Android Auto with your voice.



Operating Android Auto with Voice Recognition

Below are examples of commands you can give with voice recognition:

- Reply to text.
- Call my wife.
- Navigate to Acura.
- Play my music.
- Send a text message to my wife.
- Call flower shop.

For more information, please refer to the Android Auto homepage.

You can also activate the voice recognition function by moving ○▷.

CD Player

If a disc error occurs, you may see the following error messages.

Error Message	Cause	Solution
This function is not available because the system has encountered a file error or a DRM protected file.	Track/file format not supported	• Current track/file will be skipped. The next supported track/file plays automatically.
This is a bad disc. Please see your owner's manual for more details. Push Eject.	Mechanical error	• Press the ⏏ (eject) button and remove the disc, and check that the error message is cleared. • Check that the disc is not damaged or deformed, and insert the disc again. ➡ **Protecting CDs** P. 324 • If the error message reappears, press the ⏏ button, and pull out the disc. • Insert a different disc. If the new disc plays, there is a problem with the first disc. • If the error message repeats, or the disc cannot be removed, contact a dealer. Do not try to force the disc out of the player.
Mecha Error		
This is a bad disc. Please see your owner's manual for more details.	Servo error	
Check the disc	Disc error	• Check that the disc is not damaged or deformed. ➡ **Protecting CDs** P. 324
Heat Error	High temperature	• Turn the audio system off and allow the player to cool down until the error message is cleared.

Hard Disk Drive (HDD) Audio

If an error occurs while playing the Hard Disk Drive (HDD) Audio, you may see the following error messages. If you cannot clear the error message, contact a dealer.

Error Message	Solution
HDD access error. Please consult your dealer.	—
The navigation system temperature is too high. For protection, the system will shut off until it cools down.	Turn the audio system off and allow the player to cool down until the error message is cleared.
The navigation system atmospheric pressure is too low. For protection, the system will shut off until the pressure returns to safe levels.	The navigation system has difficulty reading the HDD when the atmospheric pressure is too low. The navigation system starts up automatically when the atmospheric pressure returns to safe levels.
Unplayable File	Appears when a file format not supported. Current track will be skipped. The next supported track plays automatically.
There is no data available.	Appears when the HDD is empty or there are no available files in the HDD.
This function is not available during CD recording while the CD is recording to the HDD.	Appears when no available function is selected while the CD is recording to the HDD.
Generating voice recognition commands. Please try again later.	Appears when no available function is selected while the dictionary of the Song By Voice™ recognition function is generated.

iPod/USB Flash Drive

If an error occurs while playing an iPod or USB flash drive, you may see the following error messages. If you cannot clear the error message, contact a dealer.

Error Message	Solution
Communication error detected. When safe, please reconnect your device.	Appears when there is a problem with the audio system. Check if the device is compatible with the audio system.
This USB device is incompatible. Please see your owner's manual for more details.	Appears when an incompatible device is connected. Disconnect the device. Then turn the audio system off, and turn it on again. Do not reconnect the device that caused the error.
This version of iOS is not supported.	Appears when an unsupported iPod is connected. If it appears when a supported iPod is connected, update the iPod software to the newer version.
There is an authentication error. When safe, please reconnect your device.	Appears when the system does not acknowledge the iPod. Reconnect the iPod.
This function is not available because the system has encountered a file error or a DRM protected file.	Appears when you select the grayed-out option on the screen while displaying the DRM or an unsupported format file.

Continued

Error Message	Solution
There is no data detected. When safe, please check your device and try again.	iPod Appears when the iPod is empty. USB flash drive Appears when the USB flash drive is empty or there are no MP3, WMA, or AAC files in the USB flash drive. iPod and USB flash drive Check that compatible files are stored on the device.
Unsupported	Appears when an unsupported device is connected. If it appears when a supported device is connected, reconnect the device.
USB hubs are not supported. To listen to audio, directly connect device to USB port.	Appears when the USB device is connected via the USB hubs. Disconnect the USB hubs and directly connect the device to the USB port (2.5A).

U.S. models

Pandora®

If an error occurs while playing Pandora®, you may see the following error messages.
If you cannot clear the error message, contact a dealer.

Error Message	Solution
This USB device is incompatible. Please see your owner's manual for more details.	Appears when an incompatible device is connected. Disconnect the device. Then turn the audio system off, and turn it again. Do not reconnect the device that caused the error.
There is an unsupported device detected. When safe, please reconnect your device.	Appears when there is a problem with the audio system. Check if the device is compatible with the audio system.
No stations have been created. When safe, please create a station on the device.	Appears when there is no station list on the device. Use the device to create a station.
There is no active station.	
This PANDORA station is currently not available. Please select another station.	
Music licenses force us to limit the number of tracks you may skip each hour.	Appears when you try to skip a track over the predetermined number of times in an hour.
The system is unable to save rating. The system is unable to save bookmark. or The system is unable to skip.	Appears when the commanded operation is failed. Try again later.
There is no data available.	Appears when no data is available with Pandora® activated. Reboot the app and reconnect the device.

Continued

Error Message	Solution
The PANDORA app version on your device is not supported. When safe, please update the app and try again later.	Appears when Pandora® version is not supported. Update Pandora® to the latest version.
PANDORA is performing system maintenance. Please try again later.	Appears when the Pandora® server is in maintenance. Try again later.
The system cannot connect to PANDORA. When safe, please check your device.	Appears when Pandora® is unable to play music. Check your device.
The system is unable to play PANDORA. When safe, login to PANDORA.	
The maximum number of stations that can be created is 100. To create more, please delete one or more previously created stations.	Appears when the number of created stations reaches the limitation. Delete one or more created stations from Pandora® app on the connected device.
The system is unable to create a new station. Please try again.	Appears when there is a temporary error with the audio system. Try again later.
The system is unable to play PANDORA. Please try again later.	Appears when your connected device has network problems. Check your device.
When safe, please check your device.	Appears when your connected device has some kind of problem such as being out of the service area. Check that the connected device is within the service area, and then try again to play Pandora®. If the problem persists, consult a dealer.
The system is unable to play PANDORA. Music licensing restricts play in this area.	Appears when you try playing the Pandora® in the country where the service is not available.

Apple CarPlay/Android Auto

If an error occurs while using the Apple CarPlay or Android Auto, you may see the following error messages. If you cannot clear the error message, contact a dealer.

Error Message	Solution
Information Screen **A charging error has occurred with the connected device. When safe, please check the compatibility of the device and USB cable. Please see your owner's manual for more details.** On Demand Multi-Use Display™ **This USB device is incompatible. Please see your owner's manual for more details.**	Appears when an incompatible device is connected. Disconnect the device. Then turn the audio system off, and turn it again. Do not reconnect the device that caused the error.
Unable to start Apple CarPlay. When safe, please confirm the USB connection.	Appears when Apple CarPlay or Android Auto fails to recognize your device. Check if your device is compatible with Apple CarPlay or Android Auto, or the latest version of the app is installed on your device.
Unable to start Android Auto. When safe, please confirm the USB connection.	
Unable to start Apple CarPlay. When safe, please try again.	Appears when Apple CarPlay or Android Auto fails to recognize your device. Reconnect your device and try again.
Unable to start Android Auto. When safe, please try again.	
Unable to start Apple CarPlay with your device. Your device is connected in digital audio mode.	Appears when your connected device is incompatible with Apple CarPlay. Check if your device is compatible with Apple CarPlay.

Continued

Error Message	Solution
This device is not compatible with Android Auto.	Appears when your connected device is incompatible with Android Auto. Check if your device is compatible with Android Auto or the latest version of the app is installed on your device.
Please update to the latest version of Android Auto.	Appears when your version of the Android Auto is not supported. Update Android Auto to the latest version.
Connection failed. Please confirm Bluetooth connection status and try again.	Appears when *Bluetooth*® connection is failed. Check the *Bluetooth*® connection of this audio system and your connected device.

SiriusXM® Radio Service

■ Subscribing to SiriusXM® Radio

1. You need your radio ID ready before registering for subscription. To see the ID in the On Demand Multi-Use Display™, select channel up/down icons until **CH000** and the radio ID appears.
2. Have your radio ID and credit card number ready, and either call or visit the SiriusXM® website to subscribe.

■ Receiving SiriusXM® Radio

Switch to the SiriusXM® mode by pressing the **SOURCE** button on the steering wheel, or through the On Demand Multi-Use Display™, and stay in this mode for about 30 minutes until the service is activated. Make sure your vehicle is in an open area with good reception.

■ SiriusXM® Radio Display Messages

Loading...:
SiriusXM® is loading the audio or program information.
No Signal:
The signal is too weak in the current location.
Unsubscribed channel:
You are not subscribed to the channel selected.
Unavailable channel:
No such channel exists, the channel is not part of your subscription, or the artist or title information is unavailable.
Check the antenna, Disconnected antenna, Shorted antenna:
There is a problem with the SiriusXM® antenna. Contact a dealer.

Subscribing to SiriusXM® Radio

Contact Information for SiriusXM® Radio:
- U.S.: SiriusXM® Radio at *www.siriusxm.com/subscribenow* or 1-866-635-2349
- Canada: SiriusXM® Canada at *www.siriusxm.ca/subscribe-now* or 1-877-209-0079

Receiving SiriusXM® Radio

The SiriusXM® satellites are in orbit over the equator; therefore, objects south of the vehicle may cause satellite reception interruptions. Satellite signals are more likely to be blocked by tall buildings and mountains the farther north you travel from the equator.

You may experience reception problems under the following circumstances:
- In a location with an obstruction to the south of your vehicle.
- In tunnels
- On the lower level of a multi-tiered road
- Large items carried on the roof rack

Recommended CDs

- Use only high-quality CD-R or CD-RW discs labeled for audio use.
- Use only CD-R or CD-RW discs on which the recordings are closed.
- Play only standard round-shaped CDs.

The CD packages or jackets should have one of these marks.

COMPACT disc DIGITAL AUDIO

COMPACT disc DIGITAL AUDIO ReWritable

COMPACT disc DIGITAL AUDIO Recordable

COMPACT disc ReWritable

COMPACT disc Recordable

■ CDs with MP3, WMA or AAC files

- Some software files may not allow for audio play or text data display.
- Some versions of MP3, WMA or AAC formats may be unsupported.

■ Protecting CDs

Follow these precautions when handling or storing CDs:

- Store a CD in its case when it is not being played.
- When wiping a CD, use a soft clean cloth from the center to the outside edge.
- Handle a CD by its edge. Never touch either surface.
- Never insert foreign objects into the CD player.
- Keep CDs out of direct sunlight and extreme heat.
- Do not place stabilizer rings or labels on the CD.
- Avoid fingerprints, liquids, and felt-tip pens on the CD.

Recommended CDs

A Dual-disc cannot play on this audio unit. If recorded under certain conditions, a CD-R or CD-RW may not play either.


Protecting CDs

NOTICE

Do not insert a damaged CD. It may be stuck inside and damage the audio unit.

Examples:

- Bubbled, wrinkled, labeled, and excessively thick CDs



- Damaged CDs
- Poor quality CDs



- Small CDs



Compatible iPod, iPhone, and USB Flash Drives

■ iPod and iPhone Model Compatibility

Model
iPod (5th generation)
iPod classic 80GB/160GB (launch in 2007)
iPod classic 120GB (launch in 2008)
iPod classic 160GB (launch in 2009)
iPod nano (1st to 7th generation) released between 2005 and 2012
iPod touch (1st to 5th generation) released between 2007 and 2012
iPhone 3G/iPhone 3GS/iPhone 4/iPhone 4s/iPhone 5/iPhone 5c/iPhone 5s/iPhone 6/iPhone 6s/iPhone 7

■ USB Flash Drives

- A USB flash drive of 256 MB or higher is recommended.
- Some digital audio players may not be compatible.
- Some USB flash drives (e.g., a device with security lockout) may not work.
- Some software files may not allow for audio play or text data display.
- Some versions of MP3, WMA, or AAC formats may be unsupported.

iPod and iPhone Model Compatibility

This system may not work with all software versions of these devices.

USB Flash Drives

Files on the USB flash drive are played in their stored order. This order may be different from the order displayed on your PC or device.

Honda App License Agreement

■ END USER LICENSE AGREEMENT

PLEASE CAREFULLY READ THIS END USER LICENSE AGREEMENT (THIS "AGREEMENT") WHICH GOVERNS YOUR USE OF THE SOFTWARE INSTALLED ON YOUR HONDA OR ACURA VEHICLE (YOUR "VEHICLE") AS WELL AS THE APPLICATIONS, SERVICES, FUNCTIONS, AND CONTENT PROVIDED THROUGH THE SOFTWARE (COLLECTIVELY, THE "SERVICES"). YOUR USE OF THE SOFTWARE OR SERVICES WILL SERVE AS YOUR CONSENT TO THE TERMS OF THIS AGREEMENT. THE SOFTWARE IS OWNED (OR LICENSED), PROVIDED, AND/OR OPERATED BY AMERICAN HONDA MOTOR CO. INC., ("HONDA," "US," "WE," OR "OUR"), WITH ITS BUSINESS ADDRESS AT 1919 TORRANCE BLVD., TORRANCE, CA 90501. REFERENCE TO "HONDA" IN THIS AGREEMENT INCLUDES HONDA'S PARENT COMPANY AND ITS AFFILIATES AND DESIGNATED AGENTS. THE SERVICES ARE OWNED (OR LICENSED), PROVIDED, AND/OR OPERATED BY HONDA OR A THIRD-PARTY SERVICE PROVIDER (A "PROVIDER"). REFERENCE TO A "PROVIDER" IN THIS AGREEMENT INCLUDES SUCH PROVIDER'S PARENT COMPANY, AFFILIATES, AND DESIGNATED AGENTS.

A. Description of the Software. The SOFTWARE includes the software, firmware and the like, installed and executing on your VEHICLE during manufacture, and thereafter updated from time to time by HONDA, you or an authorized HONDA dealer (a "DEALER"). The SOFTWARE allows you to access and use a variety of SERVICES, including but not limited to: (a) HONDA applications, services, and content provided through the SOFTWARE (together, "HONDA SERVICES"); and (b) PROVIDER applications, services, and content provided through the SOFTWARE (together, "PROVIDER SERVICES"), each of which may provide access to various information, media, content, and services.

B. SOFTWARE Licensing and Intellectual Property.

1. SOFTWARE. This AGREEMENT grants you a non-exclusive, limited, and revocable license to use the SOFTWARE and SERVICES solely (a) as installed on your VEHICLE by HONDA, (b) as updated on your Vehicle by HONDA, you (but only as and when directed by HONDA), or a DEALER and (c) as permitted under the terms of this AGREEMENT.

2. HONDA Services. The SOFTWARE may provide you with access to various HONDA SERVICES. Installation, activation, or use of HONDA SERVICES may require your consent to additional terms, conditions, and privacy policies applicable to those HONDA SERVICES (the "HONDA TERMS"). You acknowledge and agree that any collection, use, sharing of data generated by your VEHICLE or your use of your VEHICLE, and your use of the HONDA SERVICES shall be subject to this AGREEMENT and any additional HONDA TERMS that may be specifically applicable to such HONDA SERVICES or data generation. The HONDA SERVICES may collect, use, and share such data while you are using the SOFTWARE.

3. Open-Source Software. The SOFTWARE and SERVICES may incorporate software licensed to HONDA under free or open-source licenses which govern HONDA's distribution and your use of such software. HONDA and the third-party authors, licensors, and distributors of such software disclaim all warranties and all liability arising from any and all use or distribution of the software. To the extent such software is provided under terms that differ from the applicable free or open-source licenses, those terms are offered by HONDA alone. Additional information regarding free and open-source software incorporated in the SOFTWARE and SERVICES is available in this manual or within the SOFTWARE.

4. Provider Services. The SOFTWARE may provide you with access to various PROVIDER SERVICES. Installation or use of such PROVIDER SERVICES may require your consent to additional terms, conditions, and privacy policies of the applicable PROVIDER (the "PROVIDER TERMS"). This AGREEMENT restricts the manner in which you can install and use PROVIDER SERVICES but does not grant you a license or permission to use such PROVIDER SERVICES. Your permission to use PROVIDER SERVICES is limited and subject to any license grants, conditions, and limitations included in the PROVIDER TERMS. You acknowledge that any collection, use, sharing of your information, targeted advertising practices by PROVIDERS, and your use of the PROVIDER SERVICES shall be subject to both this AGREEMENT and any applicable PROVIDER TERMS. The PROVIDER SERVICES may collect, use, and share such information while you are using the SOFTWARE.

5. License Limitations and Restrictions on Use.
(a) Limited License. You understand and agree that the SOFTWARE and SERVICES are licensed, not sold, to you solely for use in accordance with this AGREEMENT and any applicable PROVIDER TERMS, and any documentation for the VEHICLE made available to you by HONDA (any "DOCUMENTATION"). HONDA and its licensors reserve all rights in the SOFTWARE and HONDA SERVICES not expressly granted to you under this AGREEMENT. PROVIDERS and their licensors reserve all rights in the PROVIDER SERVICES not expressly granted to you under the applicable PROVIDER TERMS.

(b) Restrictions on Use. The licenses granted under this AGREEMENT do not permit you to use the SOFTWARE or SERVICES on a device other than your VEHICLE. As a condition of using the SOFTWARE and SERVICES, you agree that you may not and will not:

(1) copy, download, distribute, modify, publish, sell, rent, lease, lend, license, sublicense, reuse, or create derivative works of the SOFTWARE or SERVICES or any of the content or other material within the SOFTWARE or SERVICES, including without limitation, HONDA or PROVIDER names, logos, or any other trademarks of HONDA or PROVIDERS or used in association with the SOFTWARE or any SERVICES, except as required to use the SOFTWARE or SERVICES in accordance with this AGREEMENT, any applicable PROVIDER TERMS, and the DOCUMENTATION;

(2) access or use the SOFTWARE or SERVICES in any manner intended to damage or impair the operation of the SOFTWARE or SERVICES or interfere with anyone else's use and enjoyment of the SOFTWARE or SERVICES;

(3) access or attempt to access any system or server on which the SOFTWARE or SERVICES is hosted or modify or alter the SOFTWARE or SERVICES in any way;

(4) use the SOFTWARE or SERVICES for any unlawful purpose, or in violation of any third party rights;

(5) use the SOFTWARE or SERVICES in violation of any applicable traffic regulations, rules or laws, including but not limited to any driver distraction laws, rules or regulations;

(6) violate the terms of this AGREEMENT, any HONDA TERMS, any PROVIDER TERMS or other applicable third-party terms, conditions, and privacy policies; or

(7) reverse engineer, decompile, disassemble, attempt to derive the source code of, nor permit others to reverse engineer, decompile, or disassemble, or attempt to derive the source code of the SOFTWARE or SERVICES, except and only to the extent that such activity is expressly permitted (a) by applicable law notwithstanding this limitation or (b) the terms of applicable free or opensource software licenses.

6. Intellectual Property Rights. All title and intellectual property rights in and to the SOFTWARE and SERVICES, the accompanying DOCUMENTATION, and all copies of the SOFTWARE or SERVICES are owned by HONDA, PROVIDERS, or their suppliers or licensors. This AGREEMENT does not grant you any rights in connection with any trademarks or service marks of HONDA, PROVIDERS, or their licensors, affiliates, or suppliers.

7. Export Restrictions: You acknowledge that the SOFTWARE and SERVICES are subject to U.S., European Union, and other export jurisdictions. You agree to comply with all applicable international and national laws that apply to the SOFTWARE and SERVICES, including the U.S. Export Administration Regulations, as well as end-user, end-use, and destination restrictions issued by the U.S. and other governments.

C. SOFTWARE Operation

1. HONDA reserves the right to suspend or terminate your access to and use of the SOFTWARE or SERVICES if you are found to be in violation of this AGREEMENT or as reasonably deemed necessary by HONDA.

2. Eligibility/Registration/Activation. The SOFTWARE is intended for and available to individuals who (a) are of legal age of majority in their jurisdiction of residence (and at least 18 years of age), or are younger than 18 years of age and possess a valid driver's license issued by their jurisdiction of residence, and (b) own or have permissive access to a compatible VEHICLE. We do not knowingly collect any information, including personal information, from children under 13. If we learn or are notified that we have collected personal information of a child under 13, we will immediately take steps to delete such information.

3. Use of PROVIDER SERVICES through the SOFTWARE. Certain PROVIDER SERVICES made available through the SOFTWARE may require that you register or otherwise have an account with the PROVIDER and agree to PROVIDER TERMS. Any use of any of such PROVIDER SERVICES within the SOFTWARE is subject to this AGREEMENT and the applicable PROVIDER TERMS. HONDA does not exercise control over such PROVIDER SERVICES and is not responsible or liable for the availability, security, or content of such PROVIDER SERVICES, and the inclusion of any PROVIDER SERVICES does not imply a referral from, the approval of, or the endorsement by HONDA of such PROVIDER SERVICES. HONDA is not responsible or liable, directly or indirectly, for any damage relating to or resulting from your use of the PROVIDER SERVICES.

4. Links to Third Party Sites: The SOFTWARE may provide you with the ability to access third-party sites and content through the use of the SOFTWARE or SERVICES. The third-party sites and content are not under the control of HONDA. HONDA is not responsible or liable, directly or indirectly, for such third-party websites and their content or for any damage relating to or resulting from your access or use of such websites and content.

5. Unauthorized Use and Abuse. You are responsible for ensuring your (and any authorized third parties') use of the SOFTWARE and SERVICES remains in compliance with this AGREEMENT and all other applicable HONDA TERMS and PROVIDER TERMS. You acknowledge and agree that any use of the SOFTWARE or SERVICES occurring through your VEHICLE will be deemed your actions and that HONDA and PROVIDERS may rely upon such actions. You agree to immediately notify us if you suspect fraudulent or abusive activity involving the SOFTWARE or SERVICES. If you so notify us or if we otherwise suspect fraudulent or abusive activity, you agree to cooperate with us in any fraud investigation and to use any fraud prevention measures we prescribe. Your failure to immediately notify us or cooperate to use such measures will result in your liability for all fraudulent usage or abusive activity associated with your VEHICLE.

6. SOFTWARE Updates. The SOFTWARE and SERVICES may be updated when your VEHICLE is serviced by a DEALER or remotely, over-the-air, by HONDA from time to time; such updates may occur with or without further notice or your future consent. The SOFTWARE may be updated at HONDA's discretion and for any purpose including, without limitation, to patch or otherwise improve the SOFTWARE or SERVICES functionality, security, or stability. All updates to the SOFTWARE and SERVICES are subject to this AGREEMENT and any other applicable HONDA TERMS and PROVIDER TERMS.

7. Uninstalling, Removing, and Replacing the SOFTWARE. Replacing SOFTWARE or HONDA SERVICES with software or firmware not provided and installed by HONDA or a DEALER will render all representations and warranties for the SOFTWARE, HONDA SERVICES, and VEHICLE functionality reliant upon the SOFTWARE or HONDA SERVICES null and void.

D. SOFTWARE Operational Notices and Warnings

1. Vehicle Geolocation Information. You acknowledge that your VEHICLE may be equipped with certain traffic and map features. The traffic feature will automatically collect and transmit, through GPS technology, your Vehicle's current location (longitude and latitude), travel direction and speed ("VEHICLE GEOLOCATION INFORMATION") to HONDA and PROVIDERS. The VEHICLE GEOLOCATION INFORMATION is used by HONDA and PROVIDERS to provide traffic and navigation-related information to you, but may also be used to provide other SERVICES or offers to you. HONDA will not use such VEHICLE GEOLOCATION INFORMATION for its own marketing efforts, or provide such information to unaffiliated third parties for their own purposes, without your express consent.

2. Potential Map Inaccuracy and Route Safety. Maps used by this system may be inaccurate because of changes in roads, traffic controls, routing, or driving conditions. Always use good judgment and common sense when following suggested routes. Do not follow the route suggestions if doing so would result in an unsafe or illegal driving maneuver, if you would be placed in an unsafe situation, or if you would be directed into an area that you consider unsafe. Do not rely on any navigation features included in the system to route you to emergency services. Not all emergency services such as police, fire stations, hospitals, or clinics are likely to be contained in the map database for such navigation features. Ask local authorities or an emergency services operator for such locations and routes. The driver is ultimately responsible for the safe operation of the vehicle and therefore, must evaluate whether it is safe to follow the suggested directions. Any navigation features are provided only as an aid. Make your driving decisions based on your observations of local conditions and existing traffic regulations. Navigation features are not a substitute for your personal judgment. Any route suggestions made by the SOFTWARE or SERVICES should never replace any local traffic regulations or your personal judgment or knowledge of safe driving practices.

3. Speech Recognition: You acknowledge and understand that HONDA and PROVIDERS may record, retain, and use voices commands when you use the speech recognition components of the SOFTWARE or SERVICES. You and all VEHICLE operators and passengers (a) consent to the recording and retention of voice commands in support of providing speech recognition components and (b) release HONDA and PROVIDERS from all claims, liabilities, and losses that may result from any use of such recorded voice commands. Recognition errors are inherent in speech recognition. It is your responsibility to monitor any speech recognition functions included in the system and address any errors. Neither HONDA nor PROVIDERS will be liable for any damages arising out of errors in the speech recognition process.

4. Distraction Hazards. Navigation features may require manual (non-verbal) input or setup. Attempting to perform such set-up or insert data while driving can seriously distract your attention and could cause a crash or other serious consequences; the ability to undertake such interactions may also be limited by state or local law, which laws you are responsible to know and follow. Even occasional short scans of the screen may be hazardous if your attention has been diverted away from your driving at a critical time. Pull over and stop the vehicle in a safe and legal manner before attempting to access a function of the system requiring prolonged attention. Do not raise the volume excessively. Keep the volume at a level where you can still hear outside traffic and emergency signals while driving. Driving while unable to hear these sounds could result in a crash.

E. Information Collection and Storage

1. Information Collection, Use, Transmission and Storage of Data. Consent to Use of Data: You agree that HONDA and PROVIDERS may collect and use your information gathered in any manner as part of product support services related to the SOFTWARE or related services. HONDA may share such information with third parties, including, without limitation, PROVIDERS, third party software and services suppliers, their affiliates and/or their designated agents, solely to improve their products or to provide services or technologies to you. HONDA, third party software and systems suppliers, their affiliates and/or their designated agent may disclose this information to others, but not in a form that personally identifies you.

2. Information Storage. Depending on the type of multimedia system you have in your VEHICLE, certain information may be stored for ease of use of the SOFTWARE including, without limitation, search history, location history in certain applications, previous and saved destinations, map locations within certain applications, and device numbers and contact information.

(a) Vehicle Health Information. Your VEHICLE may remotely transmit information regarding the status and health of your VEHICLE ("VEHICLE INFORMATION") to HONDA without notification to you. VEHICLE INFORMATION may contain VEHICLE maintenance and malfunction status that is derived from VEHICLE diagnostic data and includes, but is not limited to, status of powered doors and windows, battery life data, battery charging data, VEHICLE speed, coolant temperature, air compressor revolution, output power, warning codes, diagnostic trouble codes, fuel injection volume, and engine rotations per minute. VEHICLE HEALTH INFORMATION may be used by HONDA for research and development, to deliver HONDA SERVICES and information to you, and to contact you, and is retained only for a period of time necessary to fulfill these goals.

(b) VEHICLE Geolocation Data (non-navigation/map based). If you opt-in to geolocation-based SERVICES, your vehicle's geolocation data (latitude and longitude) will be automatically sent from your VEHICLE to HONDA and PROVIDERS.

(c) You understand that the inputting or uploading of information to your VEHICLE's multimedia system or the SOFTWARE or SERVICES is at your own risk and that HONDA is not responsible for unauthorized access to or use of any personal or other information. All information uploaded to the SOFTWARE and SERVICES may be stored on your VEHICLES's multimedia system and you understand that the security and safety of your VEHICLE's multimedia system is your sole responsibility.

F. NO WARRANTY. You understand and agree that your use of the SOFTWARE and SERVICES are solely at your own risk and that you will be solely responsible for any damage to your VEHICLE's multimedia system or any other equipment or any loss of data that may result from your use of the SOFTWARE or SERVICES. THE SOFTWARE AND SERVICES ARE PROVIDED ON AN "AS IS" AND "AS AVAILABLE" BASIS WITHOUT ANY WARRANTY OF ANY KIND, EXPRESSED, IMPLIED OR STATUTORY. WE SPECIFICALLY DISCLAIM ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT. HONDA makes no warranties that the SOFTWARE or SERVICES will meet your requirements, or that the SOFTWARE or SERVICES will be uninterrupted, timely, secure, non-infringing or error free. You understand and agree that you are responsible for any and all charges, costs or expenses associated with your use of the SOFTWARE or SERVICES. Advice or information, whether oral or written, obtained by you from us or through the SOFTWARE or SERVICES are provided for informational purposes only and will not create any warranty not expressly made herein. You should not rely on any such information or advice. We assume no liability or responsibility for any errors or omissions in the SOFTWARE or SERVICES. We do not make any warranty or representation that your use of the material displayed on, or obtained through, the SOFTWARE or SERVICES is non-infringing of any rights of any third party. Any decision or action taken by you on the basis of information or content provided via the application is at your sole discretion and risk. HONDA and PROVIDERS are not responsible or liable for any such decision, or for the accuracy, completeness, usefulness, or availability of any content or information displayed, transmitted, or otherwise made available via the SOFTWARE or SERVICES. To the extent jurisdictions do not allow the exclusion of certain warranties, some of the above exclusions may not apply to you.

G. LIMITATIONS ON LIABILITY. You and HONDA are each waiving important rights.
1. Limitations on YOUR liability. HONDA cannot recover from you any consequential, indirect, incidental, or special damages, or attorney's fees in connection with your use of the SOFTWARE or HONDA SERVICES. HONDA WAIVES TO THE FULLEST EXTENT ALLOWED BY LAW ANY CLAIM FOR DAMAGES OTHER THAN DIRECT, COMPENSATORY DAMAGES AS LIMITED IN THIS AGREEMENT.

2. Limitation on HONDA and PROVIDER liability. Neither HONDA nor PROVIDERS will be liable to you or any other party for consequential, indirect, incidental, special, or punitive damages (including without limitation lost profits) in connection with your use of the SOFTWARE or SERVICES, even if HONDA or PROVIDERS are aware of the possibility of such damages. These limitations apply to all claims, including, without limitation, claims in contract and tort (such as negligence, product liability and strict liability). To the extent that a jurisdiction does not permit the exclusion or limitation of liability as set forth herein our liability is limited to the maximum extent permitted by law in such states. If HONDA or PROVIDERS are found liable to you for any reason, you agree that the aggregate liability of all these parties to you for any claim is limited to ten U.S. dollars (US $10.00). Neither HONDA nor any PROVIDER would have agreed to provide the SOFTWARE or SERVICES to you if you did not agree to this limitation. This amount is the sole and exclusive liability of HONDA and PROVIDERS to you, and is payable as liquidated damages and not as a penalty. Except where prohibited by law, you may not bring any claim against HONDA or any third-party beneficiary more than two (2) years after the claim arises. We do not have any liability for SOFTWARE or SERVICES interruptions of any length.

(a) Release of HONDA and PROVIDERS For yourself and anyone else claiming under you, you agree to release and discharge HONDA, PROVIDERS, their respective officers, directors, and employees, and each third-party beneficiary from all claims, liabilities and losses in connection with the SOFTWARE or SERVICES, including, but not limited to claims for personal injury or property damage arising from the total or partial failure of performance of the SOFTWARE or SERVICES, even if caused by or based upon the negligence, gross negligence, strict products liability, Deceptive Trade Practices Act violations, bad faith, or breach of warranty of us or the malfunction of the SOFTWARE or SOFTWARE SERVICES. YOU AGREE TO WAIVE TO THE FULLEST EXTENT ALLOWED BY LAW, ANY CLAIM FOR DAMAGES OTHER THAN DIRECT, COMPENSATORY DAMAGES AS LIMITED IN THIS AGREEMENT. YOU HEREBY RELEASE AND DISCHARGE HONDA AND ITS LICENSORS AND CONTRACTORS (INCLUDING ANY THIRD PARTIES PROVIDING ALL OR PART OF THE SOFTWARE OR SERVICES) FROM AND AGAINST ANY CLAIMS, DAMAGES, EXPENSES AND LIABILITY ARISING FROM OR RELATED TO ANY INJURIES, DAMAGES, OR LOSSES TO ANY PERSON (INCLUDING DEATH) OR PROPERTY OF ANY KIND RESULTING IN WHOLE OR PART, DIRECTLY OR INDIRECTLY, FROM YOUR USE OF THE SOFTWARE OR SERVICES.

H. Survival. You agree that the limitations of liability and indemnities in this AGREEMENT will survive even after the AGREEMENT has ended. These limitations of liability apply not only to you, but to anyone using the SOFTWARE or SERVICES via your VEHICLE, to anyone making a claim on your behalf, and to any claims made by your family, employees, customers, or others arising out of or relating to your VEHICLE, the SOFTWARE, or SERVICES.

I. Availability/Interruption. The SOFTWARE and certain SERVICES are made available through your VEHICLE's compatible multimedia system when the VEHICLE is turned on. Certain SERVICES may be available only through your compatible mobile device when it is within the operating range of the VEHICLE and a wireless carrier. The availability of the SOFTWARE and SERVICES may be subject to transmission limitation or interruption, including but not limited to technical obsolesce or sunsetting of the hardware, software or firmware, inside of or external to the Vehicle, required for data transmission or receipt. HONDA does not guarantee that the SOFTWARE, SERVICES, or any portion thereof will be available at all times or in all areas. You acknowledge and agree that HONDA is not responsible for performance degradation, interruption or delays. You acknowledge that HONDA shall not be liable to you if the SOFTWARE or SERVICES in a given location are not available. If the SOFTWARE or SERVICES are not available within your intended location, you agree that your sole remedy shall be to cease using the SOFTWARE and SERVICES.

J. PRODUCT SUPPORT: Product support for the SOFTWARE is provided by HONDA. For product support, please refer to HONDA instructions provided in the DOCUMENTATION. Should you have any questions concerning this AGREEMENT, or if you desire to contact HONDA for any other reason, please refer to the HONDA contact information provided in the DOCUMENTATION.

K. Termination and Transfer.

1. Termination. This AGREEMENT is effective until terminated by you or US. WE may terminate this AGREEMENT for any or no reason, and with or without notice to you. Your rights under this AGREEMENT will terminate automatically without notice from US if you fail to comply with any term of this AGREEMENT. Upon termination of this AGREEMENT, you shall cease all use of the SOFTWARE and SERVICES.

2. Transfer: You may permanently transfer your rights under this AGREEMENT only as part of a sale or transfer of the VEHICLE, provided you retain no copies, you transfer all of the SOFTWARE and HONDA SERVICES (including all component parts, the media and printed materials, and any upgrades), and the recipient agrees to the terms of this AGREEMENT. You agree to notify HONDA upon the sale or transfer of the VEHICLE. To contact HONDA, please refer to the HONDA contact information provided in the DOCUMENTATION.

L. Changes to the SOFTWARE or SERVICES. WE may change, modify, or update the SOFTWARE or SERVICES from time to time. Unless explicitly stated otherwise, any new features or services that augment or enhance the SOFTWARE or SERVICES in the future shall respectively be considered part of the SOFTWARE or SERVICES and subject to this AGREEMENT. WE reserve the right at any time and from time to time to interrupt, restrict, modify, suspend, discontinue, temporarily or permanently, the SOFTWARE or SERVICES (or any portion thereof), with or without notice to you, and you agree that HONDA shall not be liable to you or to any third party for any modification, suspension or discontinuance of the SOFTWARE or SERVICES.

M.ARBITRATION:

PLEASE READ THIS ARBITRATION PROVISION CAREFULLY TO UNDERSTAND YOUR RIGHTS. YOU AGREE THAT ANY CLAIM THAT YOU MAY HAVE IN THE FUTURE MUST BE RESOLVED THROUGH BINDING ARBITRATION. YOU WAIVE THE RIGHT TO HAVE YOUR DISPUTE HEARD IN COURT AND WAIVE THE RIGHT TO BRING CLASS CLAIMS. YOU UNDERSTAND THAT DISCOVERY AND APPEAL RIGHTS ARE MORE LIMITED IN ARBITRATION.

Arbitration is a method of resolving a claim, dispute or controversy without filing a lawsuit. By agreeing to arbitrate, the right to go to court is waived and instead claims, disputes or controversies are submitted to binding arbitration. This provision sets forth the terms and conditions of our agreement. YOU and HONDA agree and acknowledge that this Agreement affects interstate commerce and the Federal Arbitration Act ("FAA") applies. By using the Software, Vehicle, or Services, YOU elect to have disputes resolved by arbitration. YOU, HONDA or any involved third party may pursue a Claim. "Claim" means any dispute between YOU, HONDA, or any involved third party relating to your use of the Software, the Vehicle, or the Services, this Agreement, or our relationship, including any representations, omissions or warranties. "Claim" does not include personal injury or wrongful death claims. YOU or HONDA may seek remedies in small claims court or provisional judicial remedies without arbitrating. In addition, notwithstanding anything herein to the contrary, YOU or HONDA may seek equitable relief in a court of competent jurisdiction.

YOU or HONDA may select arbitration with American Arbitration Association, JAMS or National Arbitration and Mediation. Contact these sponsors for their rules. The hearing will be in the federal district where YOU reside. If agreed, it may be by telephone or written submissions. Filing and arbitrator fees to be paid per the sponsor rules. You may contact the sponsor for a fee waiver. If no fee waivers, HONDA will pay filing and arbitrator fees up to $5,000, unless law requires more. Each party is responsible for other fees. Arbitrator may award costs or fees to prevailing party, if permitted by law. HONDA will not seek fees, unless the claims are frivolous.

Arbitrator shall be an attorney or current or retired judge familiar with automotive or consumer software. The arbitrator shall follow substantive law, statute of limitations and decide all issues relating to the interpretation, construction, enforceability and applicability of this provision. The arbitrator may order relief permitted by law. This provision is governed and enforceable by the FAA. An award shall include a written opinion and be final, subject to appeal by the FAA.
This provision survives termination of this Agreement or relationship, bankruptcy, assignment or transfer. If part of this provision is unenforceable, the remainder remains in effect. If unenforceability allows arbitration as a class action, then this provision is entirely unenforceable. YOU may opt out within 30 days of your initial use of the Software by sending a signed, written notice to HONDA at Honda Financial Services, P.O. Box 165007, Irving, TX 75016. HONDA reserves the right to make changes to this provision after providing written notice and an opportunity to opt out.

N. Miscellaneous: You may not assign this AGREEMENT without HONDA's prior written consent. This AGREEMENT and any additional HONDA TERMS and PROVIDER TERMS represents the entire agreement between you and US. HONDA may amend the terms of this AGREEMENT by providing you with notices of such updated terms. If you do not consent to be bound by the updated terms, your sole remedy will be to cease using the SOFTWARE and SERVICES. If any part of this AGREEMENT is found invalid, void, or unenforceable, the balance of the AGREEMENT will remain valid and enforceable according to its terms. To the fullest extent permitted by law, and except as explicitly provided otherwise, this AGREEMENT and any disputes arising out of or relating to it will be governed by the laws of the State of California, except that California laws concerning choice of law or conflicts shall not apply if they would cause the substantive law of another jurisdiction to apply. Notwithstanding the foregoing, Section M shall be governed by the Federal Arbitration Act and the laws of the State of California, as applicable, as set forth therein. The failure to enforce any term of this AGREEMENT on one occasion shall not prevent enforcement on any other occasion or the enforcement of any other term. Headings and captions shall not be considered included for purposes of interpretation or application hereof, but are for convenience only.

Legal Information on Apple CarPlay/Android Auto

■ OWNER'S MANUAL LICENSE/LIABILITY STATEMENTS

USE OF APPLE CARPLAY IS SUBJECT TO YOUR AGREEMENT TO THE CARPLAY TERMS OF USE, WHICH ARE INCLUDED AS PART OF THE APPLE iOS TERMS OF USE. IN SUMMARY, THE CARPLAY TERMS OF USE DISCLAIM APPLE AND ITS SERVICE PROVIDERS' LIABILITY IF THE SERVICES FAIL TO PERFORM CORRECTLY OR ARE DISCONTINUED, STRICTLY LIMIT APPLE AND ITS SERVICE PROVIDERS' OTHER LIABILITIES, DESCRIBE THE KINDS OF USER INFORMATION (INCLUDING, FOR EXAMPLE, VEHICLE LOCATION, VEHICLE SPEED, AND VEHICLE STATUS) BEING GATHERED AND STORED BY APPLE AND ITS SERVICE PROVIDERS, AND DISCLOSE CERTAIN POSSIBLE RISKS ASSOCIATED WITH THE USE OF CARPLAY, INCLUDING THE POTENTIAL FOR DRIVER DISTRACTION. SEE APPLE'S PRIVACY POLICY FOR DETAILS REGARDING APPLE'S USE AND HANDLING OF DATA UPLOADED BY CARPLAY.

USE OF ANDROID AUTO IS SUBJECT TO YOUR AGREEMENT TO THE ANDROID AUTO TERMS OF USE WHICH MUST BE AGREED TO WHEN THE ANDROID AUTO APPLICATION IS DOWNLOADED TO YOUR ANDROID PHONE. IN SUMMARY, THE ANDROID AUTO TERMS OF USE DISCLAIM GOOGLE AND ITS SERVICE PROVIDERS' LIABILITY IF THE SERVICES FAIL TO PERFORM CORRECTLY OR ARE DISCONTINUED, STRICTLY LIMIT GOOGLE AND ITS SERVICE PROVIDERS' OTHER LIABILITIES, DESCRIBE THE KINDS OF USER INFORMATION (INCLUDING, FOR EXAMPLE, VEHICLE LOCATION, VEHICLE SPEED, AND VEHICLE STATUS) BEING GATHERED AND STORED BY GOOGLE AND ITS SERVICE PROVIDERS, AND DISCLOSE CERTAIN POSSIBLE RISKS ASSOCIATED WITH THE USE OF ANDROID AUTO, INCLUDING THE POTENTIAL FOR DRIVER DISTRACTION. SEE GOOGLE'S PRIVACY POLICY FOR DETAILS REGARDING GOOGLE'S USE AND HANDLING OF DATA UPLOADED BY ANDROID AUTO.

■ DISCLAIMER OF WARRANTIES; LIMITATION ON LIABILITY

YOU EXPRESSLY ACKNOWLEDGE AND AGREE THAT USE OF APPLE CARPLAY OR ANDROID AUTO ("THE APPLICATIONS") IS AT YOUR SOLE RISK AND THAT THE ENTIRE RISK AS TO SATISFACTORY QUALITY, PERFORMANCE, ACCURACY AND EFFORT IS WITH YOU TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, AND THAT THE APPLICATIONS AND INFORMATION ON THE APPLICATIONS IS PROVIDED "AS IS" AND "AS AVAILABLE," WITH ALL FAULTS AND WITHOUT WARRANTY OF ANY KIND, AND HONDA HEREBY DISCLAIMS ALL WARRANTIES AND CONDITIONS WITH RESPECT TO THE APPLICATIONS AND INFORMATION ON THE APPLICATIONS, EITHER EXPRESS, IMPLIED OR STATUTORY, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES AND/OR CONDITIONS OF MERCHANTABILITY, SATISFACTORY QUALITY, FITNESS FOR A PARTICULAR PURPOSE, ACCURACY, QUIET ENJOYMENT, AND NON-INFRINGEMENT OF THIRD PARTY RIGHTS. NO ORAL OR WRITTEN INFORMATION OR ADVICE GIVEN BY HONDA OR AN AUTHORIZED REPRESENTATIVE SHALL CREATE A WARRANTY. AS EXAMPLES, AND WITHOUT LIMITATION, HONDA DISCLAIMS ANY WARRANTY REGARDING THE ACCURACY OF DATA PROVIDED BY THE APPLICATIONS, SUCH AS THE ACCURACY OF DIRECTIONS, ESTIMATED TRAVEL TIME, SPEED LIMITS, ROAD CONDITIONS, NEWS, WEATHER, TRAFFIC, OR OTHER CONTENT PROVIDED BY APPLE, GOOGLE, THEIR AFFILIATES, OR THIRD PARTY PROVIDERS; HONDA DOES NOT GUARANTEE AGAINST LOSS OF APPLICATION DATA, WHICH MAY BE LOST AT ANY TIME; HONDA DOES NOT GUARANTEE THAT THE APPLICATIONS OR ANY SERVICES PROVIDED THROUGH THEM WILL BE PROVIDED AT ALL TIMES OR THAT ANY OR ALL SERVICES WILL BE AVAILABLE AT ANY PARTICULAR TIME OR LOCATION. FOR EXAMPLE, SERVICES MAY BE SUSPENDED OR INTERRUPTED WITHOUT NOTICE FOR REPAIR, MAINTENANCE, SECURITY FIXES, UPDATES, ETC., SERVICES MAY BE UNAVAILABLE IN YOUR AREA OR LOCATION, ETC. IN ADDITION, YOU UNDERSTAND THAT CHANGES IN THIRD PARTY TECHNOLOGY OR GOVERNMENT REGULATION MAY RENDER THE SERVICES AND/OR APPLICATIONS OBSOLETE AND/OR UNUSABLE.

TO THE EXTENT NOT PROHIBITED BY LAW, IN NO EVENT SHALL HONDA OR ITS AFFILIATES BE LIABLE FOR PERSONAL INJURY, OR ANY INCIDENTAL, SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES WHATSOEVER, INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF PROFITS, CORRUPTION OR LOSS OF DATA, FAILURE TO TRANSMIT OR RECEIVE ANY DATA, BUSINESS INTERRUPTION OR ANY OTHER COMMERCIAL DAMAGES OR LOSSES, ARISING OUT OF OR RELATED TO THE APPLICATIONS OR YOUR USE OF OR INABILITY TO USE THE APPLICATIONS OR INFORMATION ON THE APPLICATIONS, HOWEVER CAUSED, REGARDLESS OF THE THEORY OF LIABILITY (CONTRACT, TORT OR OTHERWISE) AND EVEN IF HONDA WERE ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. SOME STATES AND JURISDICTIONS DISALLOW THE EXCLUSION OR LIMITATION OF LIABILITY FOR DAMAGES, SO THESE LIMITATIONS AND EXCLUSIONS MAY NOT APPLY TO YOU. IN NO EVENT SHALL HONDA'S TOTAL LIABILITY TO YOU FOR ALL DAMAGES (OTHER THAN AS MAY BE REQUIRED BY APPLICABLE LAW IN CASES INVOLVING PERSONAL INJURY) EXCEED THE AMOUNT OF FIVE DOLLARS ($5.00). THE FOREGOING LIMITATIONS WILL APPLY EVEN IF THE ABOVE STATED REMEDY FAILS OF ITS ESSENTIAL PURPOSE.

About Open Source Licenses

■ Important information on the software

About the software license of the product

The software installed in the product contains open source software.
See the following Alpine website for details on the open source software.
http://www.alpine.com/h/e/oss/download/

License information

DOLBY DIGITAL*

Manufactured under license from Dolby Laboratories. Dolby and the double-D symbol are registered trademarks of Dolby Laboratories.

DTS


For DTS patents, see *http://patents.dts.com*. Manufactured under license from DTS Licensing Limited. DTS, the Symbol, & DTS and the Symbol together are registered trademarks, and DTS Digital Surround and Neural Surround are trademarks of DTS, Inc. © DTS, Inc. All Rights Reserved.

* Not available on all models

Allows the rear passengers to enjoy a different entertainment source, such as DVD, CD, and radio, than the front passengers.

Wireless Headphones

The rear seat passengers can listen to audio from the rear entertainment system by a wireless headphone that comes with your vehicle.



To turn on the switch: Press the (power) button at the right earpiece. The indicator comes on.

To adjust the volume: Turn the dial at the right earpiece.

Rear Entertainment System (RES)*

CAUTION: Radio Frequency Radiation Exposure
The Rear Entertainment System remote complies with FCC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines.
The Rear Entertainment System remote should be kept at least 7.9 inches (20 cm) or more away from a person's body when operated.

Wireless Headphones


Your vehicle comes with two wireless headphones.

Wear the headphone correctly with the earpiece marked with L goes to your left ear and R goes to your right ear.
Wearing the headphone backward may affect the audio reception.

 * Not available on all models

Auxiliary Console Panel

Auxiliary input jacks and headphone connectors for the rear entertainment system are on the back of the front console compartment.



V = Video jack
L = Left audio jack
R = Right audio jack

■ Auxiliary input jacks

The system will accept auxiliary inputs from standard video games and video equipment. Some video game power supplies may cause poor picture quality.

■ Headphone connectors

The headphones can also be used by connecting to the auxiliary console panel. There are two headphone connectors for the rear passengers. Each connector has its own volume control.

HDMI™ Port

There is an HDMI port on the back of the front console compartment. The system will accept HDMI input from video games and video equipment which are equipped with an HDMI port.




Open the outlet cover and insert the cable.

HDMI™ Port

- Do not leave the HDMI connected device in the vehicle. Direct sunlight and high temperatures may damage it.
- We recommend keeping your data backed up before using the device in your vehicle.
- Displayed messages may vary depending on the device model and software version.

The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing LLC in the United States and other countries.

Overhead Screen




Press the open button to open and pull down the screen.

Overhead Screen

You can use the rear control panel as a remote. Press the release button to detach it.


Operating the System

To operate the system, set the power mode to ON or ACCESSORY. Press the **REAR** ⏻ (power) button to turn on the system.



Rear Control Panel Operation

The rear passengers can operate the system with the rear control panel.



DUAL Button
Press to change the screen mode to dual.

SINGLE Button
Press to change the screen mode to single.

SOURCE Button
Press to select the audio source.

(Power) Button
Press to turn the system on or off (when rear power is turned on).

(Light-up) Button
Press to illuminate the buttons on the rear control panel.

CH/FOLDER Bar
Press to change the channel (Radio) or folder (Disc/USB).

TUNE/SKIP Bar
Press |◀◀ or ▶▶| to search up and down the selected band for a station with a strong signal (FM/AM).
Press |◀◀ or ▶▶| to change tracks. Press and hold to move rapidly within a track/file (Disc/USB/DVD).

(Play/Pause) Button
Press to play or pause the playback.

SWAP Button
Press to swap left side screen and right side screen.

MENU Button
Press to display the audio menu.

Interface Dial, ▲/▼/▶/◀ (Directional) Buttons, and ENTER Button
Rotate the interface dial or press directional button to select items. Press the **ENTER** button to make a selection.

DVD bar
Press to change the DVD mode.

AUX bar
Press to change the input source toggling through the auxiliary input jack(s), HDMI port and USB port (2.5A).

SETUP Button
Press to display the setup items.

CANCEL Button
Press to go back to the previous display or operation.

CATEGORY Bar
Press to change the category (SiriusXM®).

TITLE SCROLL Button
Press to display the track title, artist, and other text information.


Selecting the Audio Source



1. Press the **REAR** ⏻ (power) button on the front control panel.
2. Press the **SOURCE** button on the rear control panel.
3. Select the audio source. Press the **ENTER** button.
   ▶ You can also change the audio source by the front control panel.
   ➡ **Front Control Panel Operation** P. 356
4. Select a station, channel, track, or chapter using the **CH/FOLDER**, **TUNE/SKIP**, or **CATEGORY** bars.

Rear Control Panel Operation

In the procedures of this section, "select" means the following actions:



Rotate the interface dial or press the directional buttons on the rear control panel.

The rear control panel can be detached from the ceiling unit and used as a remote control.
➡ **Overhead Screen** P. 345

The screen is displayed on the overhead screen.

Continued

■ Rear DVD Menu




1. Press the **MENU** button (in DVD mode).
2. Select an item. Press the **ENTER** button.

The following items are available:

- **Top Menu**: Displays the top menu of the DVD.
- **Menu**: Displays the menu of the DVD.
- **Play Mode**: Displays while a DVD is playing and changes the DVD's audio, subtitle, or angle settings.
  ➡ **Setting the play mode** P. 349
- **Search/NumInput**: Skips to a title or chapter by entering the number.
  ➡ **Searching a title/chapter** P. 350
- **Repeat**:
  (title repeat): Repeats the current title.
  (chapter repeat): Repeats the current chapter.
- **Pause/Play**: Pause or play the playback.
- **Stop**: Stops the playback.
- **Return**: Hides the rear audio menu.

■ Setting the play mode




1. Press the **MENU** button (in DVD mode).
2. Select **Play Mode**. Press the **ENTER** button.
3. Select an item. Press the **ENTER** button.
4. Select an option. Press the **ENTER** button.

The following items are available:
- **Audio**: Selects the language of the DVD audio.
- **Subtitle**: Selects the language of the DVD subtitle.
- **Angle**: Selects the angle of a scene shot with multiple cameras.

Continued

■ Searching a title/chapter



1. Press the **MENU** button (in DVD mode).
2. Select **Search/NumInput**. Press the **ENTER** button.
3. Select an item. Press the **ENTER** button.
4. Select a number. Press the **ENTER** button.

The following items are available:

- **Title**: Skips to a title you specify.
- **Chapter**: Skips to a chapter you specify.
- **NumInput**: Enters a number of a title or chapter to skip. Enter a number and press the **ENTER** button. Select **DONE**.

Screen and Surround Settings



1. Press the **SETUP** button (in DVD mode).
2. Select an item. Press the **ENTER** button.

The following items are available:

- **Brightness**: Adjusts the screen's brightness. Adjust the brightness using the interface dial and press the **ENTER** button.
- **Appearance**: Selects the color of the rear menu screen.
- **Display Adjust**: Adjusts the screen's preferences.
  ➡ **Adjusting the screen** P. 352
- **Aspect Ratio**: Selects an aspect ratio of the image.
  ➡ **Setting the aspect ratio** P. 353
- **PERSONAL SURROUND**: Sets the surround of the wireless headphones. You can choose from three options: **Music**, **Cinema**, or **Voice**. Select **Off** to disable the feature.
- **Language**: Sets the system language used on all screens. You can choose from three languages: **English**, **Français** (French), or **Español** (Spanish).

Continued

■ Adjusting the screen



1. Press the **SETUP** button (in DVD mode).
2. Select **Display Adjust**. Press the **ENTER** button.
3. Select an item. Press the **ENTER** button.
4. Make the adjustment. Press the **ENTER** button.

The following items are available:

- **Contrast**: Adjusts the screen's contrast.
- **Black Level**: Adjusts the screen's black level.
- **Color**: Adjusts the screen's color strength.
- **Tint**: Adjusts the screen's hue.
- **Reset**: Resets all the settings to their factory default.

■ **Setting the aspect ratio**



1. Press the **MENU** button (in DVD mode).
2. Select **Aspect Ratio**. Press the **ENTER** button.
3. Select an item. Press the **ENTER** button.
4. Select an option. Press the **ENTER** button.

The following items are available:

- **Wide**: Selects the wide screen option (**Normal**, **Full**, **Super Full**, **Ultra Full**).
- **Zoom**: Selects the zoom screen option (**Super Zoom**, **Ultra Zoom**).

Continued

■ Dual Screen Mode

Select between the two screen modes, single or dual.

Rear Control Panel Operation P. 346


■ Single mode

The selected source is displayed in the center of the screen.

■ Dual mode

Two separate screens are displayed side by side. You can only select one output source from the front audio system. The other source must come from "**REAR AUX Video**" or "**REAR AUX HDMI**".

■ Single mode to dual mode



■ Dual mode to single mode



Front Control Panel Operation


Operate the Rear Entertainment System (RES) from the On Demand Multi-Use Display™.

■ Selecting the Audio Source using Front Control Panel



1. Press the **REAR** ⏻ (power) button on the front control panel.
2. Select **Front/Rear** to switch **Rear** mode.
3. Select **Source**.
   ▶ The rear source is displayed on the On Demand Multi-Use Display™.
4. Select the audio source on the On Demand Multi-Use Display™.
   ▶ The rear source is heard from the front speakers.
5. Select a station, channel, track, or chapter in the same way as the front audio system.
   ➡ **Selecting an Audio Source** P. 244

Operating the DVD Rear Entertainment System



Source
Select to change an audio source.

Front/Rear
Select to change between the front side audio source selection and rear side audio source selection.

VOL/⏻ (Volume/Power) Knob
Press to turn the audio system on and off.
Turn to adjust the volume.

ⓘ (Information) Icon
Select to display the current DVD details.
Select ⮌ to display the previous screen.

Repeat Icon
Select to repeat the current chapter or title.

Play/Pause Icon
Select to pause or play a DVD.

Stop Icon
Select to stop the playback.

Title Up/Down Icons
Select ◀ or ▶ to skip to the next title, and to skip to the beginning of the previous title.

Audio Menu
Select to display the menu items.

Top Menu
Select to display the top page of the DVD's title menu.

Menu
Select to display the menu.

Advanced
Select to display the DVD setting menu.

Chapter Up/Down Icons
Select |◀◀ or ▶▶| to change chapters.
Select and hold to fast forward and reverse.

On Demand Multi-Use Display™

Continued

DVD Setup



1. Select **Audio Menu**.
2. Select **Audio Settings**.
3. Select **DVD**.

The following items are available:

- **DVD Auto Play**: Turns the auto play feature on or off.
- **Audio Language**: Selects a language for the audio that is available on the DVD.
- **Subtitle Language**: Selects a language for the subtitle that is available on the DVD.
- **Menu Language**: Selects a language for the DVD menu that is available on the DVD.
- **Dynamic Range**: Sets whether to control the range of the loud and low sounds.

Operating the DVD Rear Entertainment System


Play Mode Menu Item
Repeat

(repeat off): Repeat mode to off.

(repeat chapter): Repeats the current chapter.

(repeat title): Repeats the current title.

Setting the DVD Menu




Select **Advanced**.

The following items are available:

- **Audio/Subtitle**: Selects the language of the DVD audio and the DVD subtitle.
- **Angle**: Selects the angle of a scene shot with multiple cameras.
- **Number Input**: Enters a number of a title or chapter to skip.
- **Return**: Return to the previous screen.
- **Search**: Skips to a title or chapter.

Continued

■ Rear System Setup



1. Select **Audio Menu**.
2. Select **RES Settings**.

The following items are available:

- **Rear Control**: Sets whether to use the rear control panel to control the RES. When setting is set to **On**, operates the RES using the rear control panel.
- **Rear Speaker**: Sets the front audio source to play through the rear speakers, even when the RES is on. The RES source can only be heard through the wireless headphones. When setting is set to **On**, outputs the sound of the front source to the rear speakers.
- **Single/Dual Screen Mode**: Selects a source to continue playing when you switch from dual mode to single mode on the overhead screen.

Playable Discs

The discs that come with these labels can be played in your vehicle's rear entertainment system.

Also look for the region code of 1 or ALL on the package or jacket on the disc.

DVD-ROMs are not playable in this unit.

The disc packages or jackets should have one of these marks.



Also includes:



Playable Discs

This product incorporates copyright protection technology that is protected by U.S. patents and other intellectual property rights.

Use of this copyright protection technology must be authorized by Rovi Corporation, and is intended for home and other limited viewing uses only unless otherwise authorized by Rovi Corporation. Reverse engineering and disassembly are prohibited.

For DTS patents, see *http://patents.dts.com*. Manufactured under license from DTS Licensing Limited. DTS, the Symbol, & DTS and the Symbol together are registered trademarks, and DTS Digital Surround and Neural Surround are trademarks of DTS, Inc. © DTS, Inc. All Rights Reserved.


Manufactured under license from Dolby Laboratories. Dolby, Pro Logic, MLP Lossless and the double-D symbol are trademarks of Dolby Laboratories.

Use the information screen and On Demand Multi-Use Display™ to customize certain features.

Information Screen

■ How to customize

Select your desired setting item by pressing the **SETTINGS** button, then rotating while the power mode is ON and the vehicle is at a complete stop. Press .



Customized Features

When you customize settings, make sure that the vehicle is at a complete stop and transmission is put into P.

Information Screen

To customize other features, rotate , move , , or , and press .

List of customizable options P. 369

How to customize

The following settings can be customized on the On Demand Multi-Use Display™.

- **Edit Source Order**
- **Sound Settings**
- **Edit/Delete HDD Music**
- **Audio Settings**
- **Screen Settings**
- **RES Settings***


How to customize P. 385

* Not available on all models

Information Screen


■ Customization flow

Press the **SETTINGS** button.




- **Navigation Settings** → See the Navigation System Manual.
- **Bluetooth/ Phone Settings**
  - **Default**
  - **Bluetooth**
    - **Bluetooth**
    - **Bluetooth Device List**
    - **Edit Pairing Code**
  - **Phone**
    - **Edit Speed Dial**
    - **Auto Transfer**
    - **Auto Answer**
    - **Ring Tone**
    - **Automatic Phone Sync**
    - **Use Contact Photo**
  - **Text/Email**
    - **Enable Text/Email**
    - **Select Account**
    - **New Text/Email Alert**


Continued




*1: Models with multi-view rear camera
*2: Models with surround view camera system


Vehicle Settings
Default
Driver Assist
Forward Collision Warning Distance
ACC Forward Vehicle Detect Beep
ACC Display Speed Unit
Road Departure Mitigation Setting
Lane Keeping Assist Suspend Beep
Blind Spot Info
Meter
Language Selection
Adjust Outside Temp. Display
"Trip A" Reset Timing
"Trip B" Reset Timing
Reverse Alert Tone
Turn by Turn Display
Driving Position
Memory Position Link
Easy Entry/Exit


Continued



* Not available on all models


Clock Settings
Default
Clock/Wallpaper Type
Clock Adjustment
Clock Format
Auto Time Zone
Auto Daylight
Clock Reset
AcuraLink Settings
Default
AcuraLink Msg Notice
Delete AcuraLink Messages
AcuraLink Subscription Status

Continued



* Not available on all models

Information Screen

■ **List of customizable options**

Setup Group	Customizable Features		Description	Selectable Settings
Bluetooth/ Phone Settings	**Default**		Cancels/Resets all customized items in the **Bluetooth/Phone Settings** group as default.	**Yes/No**
	Bluetooth	**Bluetooth**	Turns the *Bluetooth*® on and off.	**On**[*1]**/Off**
		Bluetooth Device List	Pairs a new phone to HFL, edits or deletes a paired phone, or creates a security PIN. ➡ **Phone Setup** P. 405	—
		Edit Pairing Code	Changes a pairing code. ➡ **To change the pairing code setting** P. 407	**Random/Fixed**[*1]
	Phone	**Edit Speed Dial**	Edits, adds or deletes a speed dial entry. ➡ **Phone Setup** P. 405	—
		Auto Transfer	Sets calls to automatically transfer from your phone to HFL when you enter the vehicle.	**On**[*1]**/Off**
		Auto Answer	Sets whether to automatically answer an incoming call after about four seconds.	**On/Off**[*1]

*1:Default Setting

Continued

Setup Group	Customizable Features		Description	Selectable Settings
Bluetooth/ Phone Settings	**Phone**	**Ring Tone**	Selects the ring tone.	**Fixed/Mobile Phone**[*1]**/Off**
		Automatic Phone Sync	Sets a phonebook data to be automatically imported when a phone is paired to HFL.	**On/Off**
		Use Contact Photo	Displays a caller's picture on an incoming call screen.	**On**[*1]**/Off**
	Text/Email	**Enable Text/Email**	Turns the text/e-mail message function on and off.	**On**[*1]**/Off**
		Select Account	Selects a mail or text message account.	—
		New Text/Email Alert	Selects whether a pop-up alert comes on the screen when HFL receives a new text message/E-mail.	—

*1:Default Setting

Setup Group	Customizable Features		Description	Selectable Settings
Models with multi-view rear camera **Camera Settings**	**Default**		Cancels/Resets all customized items in the **Camera Settings** group as default.	**Yes/No**
	Rear Camera	**Fixed Guideline**	Selects whether the fixed guidelines come on the rear camera monitor.	**On**[*1]**/Off**
		Dynamic Guideline	Selects whether the dynamic guidelines come on the rear camera monitor.	**On**[*1]**/Off**
	Cross Traffic Monitor	**Cross Traffic Monitor**	Turns the cross traffic monitor feature on and off.	**On**[*1]**/Off**

*1:Default Setting

Setup Group	Customizable Features		Description	Selectable Settings
Models with surround view camera system **Camera Settings**	**Default**		Cancels/Resets all customized items in the **Camera Settings** group as default.	**Yes/No**
	Surround View Camera	**Fixed Guideline**	Sets whether to turn on the reference line display.	**On**[*1]**/Off**
		Dynamic Guideline	Sets whether to turn on the projection line display.	**On**[*1]**/Off**
		Auto Show Camera after Reverse	Sets the rear view to be automatically switched to the front view when the transmission is out of R.	**On/Off**[*1]
		Default Camera Mode in Forward	Sets which screen to display when the surround view camera system is turned on while the vehicle is moving forward.	(Front Ground View)[*1]**/Last Used/** (Front Wide View)/ (Side View)
		Default Camera Mode in Reverse	Sets which screen to display when the surround view camera system is turned on while the vehicle is reversing.	(Rear Ground View)[*1]**/Last Used/** (Rear Normal View)/ (Rear Wide View)
		Show Camera When Decelerating	Sets the screen to automatically return to the camera view at vehicle speeds of 7 mph (12 km/h) or lower.	**On/Off**[*1]

*1:Default Setting

Setup Group	Customizable Features		Description	Selectable Settings
Models with surround view camera system **Camera Settings**	**Surround View Camera**	**Clear Parking Guidance Automatically**	Turns the parking guide lines on and off.	**On**[*1]**/Off**
	Cross Traffic Monitor	**Cross Traffic Monitor**	Turns the cross traffic monitor feature on and off.	**On**[*1]**/Off**

*1:Default Setting

Continued

Setup Group	Customizable Features		Description	Selectable Settings
Vehicle Settings	**Default**		Cancels/Resets all customized items in the **Vehicle Settings** group as default.	**Yes/No**
	Driver Assist	**Forward Collision Warning Distance**	Changes at which distance CMBS™ alerts.	**Long/Normal**[*1]**/Short**
		ACC Forward Vehicle Detect Beep	Causes the system to beep when the system detects a vehicle, or when the vehicle goes out of the ACC with LSF range.	**On/Off**[*1]
		ACC Display Speed Unit	Changes the speed unit for ACC with LSF on the MID.	**mph**[*1]**/km/h** (U.S.) **mph/km/h**[*1] (Canada)
		Road Departure Mitigation Setting	Changes the setting for the road departure mitigation system.	**Normal**[*1]**/Wide/ Warning Only**
		Lane Keeping Assist Suspend Beep	Causes the system to beep when the LKAS is suspended.	**On/Off**[*1]
		Blind Spot Info	Changes the setting for the blind spot information.	**Audible And Visual Alert**[*1]**/Visual Alert/ Off**

*1:Default Setting

Setup Group		Customizable Features	Description	Selectable Settings
Vehicle Settings	**Meter**	**Language Selection**	Changes the displayed language on the MID.	**English**[*1]**/Français/ Español**
		Adjust Outside Temp. Display	Adjusts the temperature reading by a few degrees.	**-5°F ~ ±0°F**[*1] **~ +5°F** (U.S.) **-3°C ~ ±0°C**[*1] **~ +3°C** (Canada)
		"Trip A" Reset Timing	Changes the setting of how to reset trip meter A, average fuel economy A, average speed A, and elapsed time A.	**When Refueled/IGN Off/Manually Reset**[*1]
		"Trip B" Reset Timing	Changes the setting of how to reset trip meter B, average fuel economy B, average speed B, and elapsed time B.	**When Refueled/IGN Off/Manually Reset**[*1]
		Reverse Alert Tone	Causes the beeper to sound once when the transmission is put into R.	**On**[*1]**/Off**
		Turn by Turn Display	Selects whether the turn-by-turn display comes on during the route guidance.	**On**[*1]**/Off**

*1:Default Setting

Continued

Setup Group	Customizable Features		Description	Selectable Settings
Vehicle Settings	**Driving Position**	**Memory Position Link**	Turns the driving position memory system on and off.	**On**[*1]**/Off**
		Easy Entry/Exit	Moves the seat fully rearward and steering wheel fully up when you get in/get out of the vehicle. Changes the setting for this feature.	**Seat & Steering Wheel**[*1]**/Seat Only/ Steering Wheel Only/Off**
	Keyless Access	**Door Unlock Mode**	Changes which doors unlock when you grab the driver's door handle.	**Driver's Door or Tailgate Only**[*1]**/All Doors**
		Keyless Access Light Flash	Causes some exterior lights to flash when you unlock/lock the doors.	**On**[*1]**/Off**
		Keyless Access Beep	Causes the beeper to sound when you unlock/ lock the doors.	**On**[*1]**/Off**
		Remote Start System On/Off	Turns the remote engine start feature on and off.	**On**[*1]**/Off**
		Walk Away Auto Lock	Changes the settings for the automatic locking the doors when you walk away from the vehicle while carrying the keyless access remote.	**On/Off**[*1]

*1:Default Setting

Setup Group	Customizable Features		Description	Selectable Settings
Vehicle Settings	**Lighting**	**Interior Light Dimming Time**	Changes the length of time the interior lights stay on after you close the doors.	**60seconds**/ **30seconds**[*1]/ **15seconds**
		Headlight Auto Off Timer	Changes the length of time the exterior lights stay on after you close the driver's door.	**60seconds**/ **30seconds**/ **15seconds**[*1]/ **0seconds**
		Auto Light Sensitivity[*]	Changes the timing for the headlights to come on.	**Max**/**High**/**Mid**[*1]/ **Low**/**Min**

*1:Default Setting

* Not available on all models

Setup Group	Customizable Features		Description	Selectable Settings
Vehicle Settings	**Door**	**Auto Door Lock**	Changes the setting for when the doors automatically lock.	**With Vehicle Speed**[*1]**/Shift from P/ Off**
		Auto Door Unlock	Changes the setting for when the doors unlock automatically.	**All Doors When Driver's Door Opens**[*1]**/All Doors When Shifted to Park/All Doors When Ignition Switched Off/Off**
		Key And Remote Unlock Mode	Sets up either the driver's door or all doors to unlock on the first push of the remote or built-in key.	**Driver Door**[*1]**/All Doors**
		Keyless Lock Answer Back	LOCK/UNLOCK- The exterior lights flash. LOCK (2nd push)- The beeper sounds.	**On**[*1]**/Off**
		Security Relock Timer	Changes the time it takes for the doors to relock and the security system to set after you unlock the vehicle without opening any door.	**90seconds/ 60seconds/ 30seconds**[*1]
		Auto Folding Door Mirror	Changes how you can fold the door mirrors.	**Auto Fold With Keyless**[*1]**/Manual Only**

*1:Default Setting

Setup Group	Customizable Features		Description	Selectable Settings
Vehicle Settings	**Power Tailgate**	**Keyless Open Mode**	Changes the keyless setting for when the power tailgate opens.	**Anytime**[*1]**/When Unlocked**
		Power Open By Outer Handle	Selects whether to enable the power tailgate open operation using the tailgate outer handle.	**Off (Manual only)/ On (Power/ Manual)**[*1]
	Dynamic Mode	**Preferred Dynamic Mode**	Changes the dynamic mode setting for when you set the power mode to ON.	**Last Used**[*1]**/Comfort/ Normal/Sport**
	Maintenance Info.	**Maintenance Reset**	Resets the engine oil life display when you have performed the maintenance service.	—

*1:Default Setting

Setup Group	Customizable Features		Description	Selectable Settings
Clock Settings	**Default**		Cancels/Resets all customized items in the **Clock Settings** group as default.	**Yes/No**
	Clock/ Wallpaper Type	**Clock**	Changes the clock display type.	**Analog/Digital**[*1]/ **Small Digital/Off**
		Wallpaper	• Changes the wallpaper type. • Imports an image file for a new wallpaper. • Deletes an image file for a wallpaper. ➡ **Wallpaper Setup** P. 254	**Blank/Galaxy**[*1]/ **Metallic/Options...**
	Clock Adjustment		Adjusts Clock. ➡ **Wallpaper Setup** P. 254	—
	Clock Format		Selects the digital clock display from 12H to 24H.	**12H**[*1]**/24H**
	Auto Time Zone		Sets the audio system to automatically adjust the clock when driving through different time zones.	**On**[*1]**/Off**
	Auto Daylight		Sets the audio system to automatically adjust the clock ("spring ahead" or "fall back" by one hour) when a daylight saving time change occurs.	**On**[*1]**/Off**
	Clock Reset		Resets the clock settings to the factory default.	**Yes/No**

*1:Default Setting

Setup Group	Customizable Features	Description	Selectable Settings
AcuraLink Settings	**Default**	Cancels/Resets all customized items in the **AcuraLink Settings** group as default.	**Yes/No**
	AcuraLink Msg Notice	Selects whether newly received AcuraLink messages are to be displayed.	**On**[*1]**/Off**
	Delete AcuraLink Message	Deletes AcuraLink messages.	—
	AcuraLink Subscription Status	Displays your current AcuraLink subscription status.	—

*1:Default Setting

Setup Group	Customizable Features		Description	Selectable Settings
System Settings	**Default**		Cancels/Resets all customized items in the **System Settings** group as default.	**Yes/No**
	Display	**Sync Display Brightness**	Selects whether the display brightness synchronizes with the instrument panel brightness.	**On**[*1]**/Off**
		Brightness	Changes the brightness of the information screen.	—
		Contrast	Changes the contrast of the information screen.	—
		Black Level	Changes the black level of the information screen.	—
	Feedback	**Guidance Volume**	Changes the volume of the audio speakers.	**0~8**[*1]**~11**
		Verbal Reminder	Turns the verbal reminders on and off.	**On**[*1]**/Off**

*1:Default Setting

Setup Group		Customizable Features	Description	Selectable Settings
System Settings	**Voice Reco.**	**Voice Prompt**	Turns the voice prompt on and off.	**On**[*1]**/Off**
		Song By Voice	Turns the Song By Voice™ on and off. ➡ **Song By Voice™ (SBV)** P. 294	**On**[*1]**/Off**
		Song By Voice Phonetic Modification	Modifies a voice command for music stored in the HDD or an iPod. ➡ **Phonetic Modification** P. 296	—
		Phonebook Phonetic Modification	Modifies a voice command for the phonebook. ➡ **Phonebook Phonetic Modification** P. 419	—
		Guidance Volume	Changes the volume of the voice prompt.	—

*1:Default Setting

Continued

Setup Group	Customizable Features		Description	Selectable Settings
System Settings	**Others**	**Units**	Changes the distance unit on the navigation map screen.	**mile**[*1]**/km** (U.S.) **mile/km**[*1] (Canada)
		Language	Changes the display language.	**English**[*1]**/Français/ Español**
		Operation Restriction Tips[*]	Alerts you when manual control of the system is disabled to prevent distraction while driving. Only voice commands are available.	**On**[*1]**/Off**
		Header Clock Display	Selects whether the clock display comes on.	**On**[*1]**/Off**
		System Device Information	Displays the system/device information.	—
		Factory Data Reset	Resets all the settings to their factory default. ➡ **Defaulting All the Settings** P. 393	—
Smartphone Settings	**Default**		Cancels/Resets all customized items in the **Smartphone Settings** group as default.	**Yes/No**
	Apple CarPlay Device List		Sets up the Apple CarPlay connection.	—
	Android Auto Device List		Sets up the Android Auto connection.	—
	Smartphone Volume		Adjusts the volume of the smartphone function.	**1~8**[*1]**~11**
	Version		Shows software version of Apple CarPlay and Android Auto unit.	—

*1:Default Setting

* Not available on all models

On Demand Multi-Use Display™

■ How to customize

While the vehicle is at a complete stop with the power mode in ON, select **Audio Menu**, then select a setting item.




Continued


On Demand Multi-Use Display™

■ Customization flow

Select **Audio Menu**.



- Edit Source Order
- Sound Settings
  - Bass
  - Treble
  - Fader
  - Balance
  - Center
  - Subwoofer
  - SVC
  - DTS Neural Surround
- Edit/Delete HDD Music
- Audio Settings
  - SiriusXM
    - Play the Song from the Beginning
    - SportsFlash
    - Traffic & Weather Now Setup
    - Channel Art
    - TuneMix
  - CD/HDD
    - Recording Options
      - Recording from CD
      - Recording Quality
    - HDD Information
    - Update Gracenote Album Information
    - Delete All HDD Data



* Not available on all models

Continued

On Demand Multi-Use Display™

■ **List of customizable options**

Setup Group	Customizable Features	Description	Selectable Settings
Edit Source Order		Changes the order of source list. ➡ **Selecting an Audio Source** P. 244	—
Sound Settings	**Bass**	Adjusts the settings of the audio speaker's sound. ➡ **Adjusting the Sound** P. 256	—
	Treble		
	Fader		
	Balance		
	Center		
	Subwoofer		
	SVC		
	DTS Neural Surround		
Edit/Delete HDD Music		Change the playlist name, album name, genre, and track order of the current playlist. You can also delete tracks, playlists, and albums. ➡ **Editing an Album or Playlist** P. 284	—
Audio Settings SiriusXM	**Play the Song from the Beginning**	Turns on and off the Tune Start function.	**On/Off***1

*1:Default Setting

Setup Group	Customizable Features			Description	Selectable Settings
Audio Settings	**SiriusXM**	**SportsFlash**	**Notification**	Turns on and off the sports alert function.	**Disable/Enable once/ Enable**[*1]
			Beep	Causes the system to beep when the sports alert is notified.	**On**[*1]**/Off**
			Favorite Teams	Selects your favorite sport teams.	—
		Traffic & Weather Now Setup		Selects a city for using the SiriusXM® traffic and weather information.	—
		Channel Art		Turns on and off the channel art display.	**On**[*1]**/Off**
		TuneMix		Turns multiple channel mix preset on and off.	**On/Off**[*1]
	CD/ HDD	**Recording Options**	**Recording from CD**	Selects whether the songs on music CDs are automatically recorded to the HDD.	**Auto**[*1]**/Manual**
			Recording Quality	Selects the quality of the music files recorded to the HDD.	**Standard**[*1]**/High**
		HDD Information		Displays the HDD capacity.	—
		Update Gracenote Album Information		Updates the Gracenote® Album Info (Gracenote® Media Database) from CD or USB.	**Update by CD/ Update by USB**
		Delete All HDD Data		**Deleting all HDD Data** P. 290	—

*1:Default Setting

Setup Group	Customizable Features		Description	Selectable Settings
Audio Settings	**DVD***	**DVD Auto Play**	Turns the auto play feature on or off.	**On**[*1]**/Off**
		Audio Language	Selects a language for the audio that is available on the DVD.	—
		Subtitle Language	Selects a language for the subtitle that is available on the DVD.	—
		Menu Language	Selects a language for the DVD menu that is available on the DVD.	—
		Dynamic Range	Sets whether to control the range of the loud and low sounds.	**On**[*1]**/Off**
	Other	**HD Radio Mode***	Selects whether the audio system automatically switches to the digital radio waves or receives the analog waves only.	**Auto**[*1]**/Analog**
		Cover Art	Turns on and off the cover art display.	**On**[*1]**/Off**

*1:Default Setting

 * Not available on all models

Setup Group	Customizable Features	Description	Selectable Settings
Screen Settings	**Sync Display Brightness**	Selects whether the screen brightness synchronizes with the instruments panel brightness.	**Off/On***1
	Brightness	Changes the brightness of the On Demand Multi-Use Display™.	—
	Contrast	Changes the contrast of the On Demand Multi-Use Display™.	—
	Black Level	Changes the black level of the On Demand Multi-Use Display™.	—
	Beep	Mutes a beep that sounds every time you touch the screen.	**Off/On***1
	Keyboard	Changes the on-screen keyboard from the alphabetical order to the qwerty type.	**Alphabet/QWERTY***1

*1:Default Setting


Setup Group	Customizable Features	Description	Selectable Settings
RES Settings*	**Rear Control**	Select weather to use the rear control panel to control the RES.	**On*1/Off**
	Rear Speaker	Sets the front audio source to play through the rear speakers, even when the RES is on. The RES source can only be heard through the wireless headphones.	**On*1/Off**
	Single/Dual Screen Mode	Selects a source to continue playing when you switch from dual mode to single mode on the overhead screen.	—

*1:Default Setting

 * Not available on all models

Defaulting All the Settings

You can reset all the menu and customized settings as the factory defaults.



1. Press the **SETTINGS** button.
2. Rotate ⟲ to select **System Settings**, then press ⟲.
3. Rotate ⟲ to select **Factory Data Reset**, then press ⟲.
   ▶ The pop-up menu appears on the screen.
4. Rotate ⟲ to select **Yes**, then press ⟲.
   ▶ The confirmation message will appear.
5. Rotate ⟲ to select **Yes**, then press ⟲ again to reset the settings.
   ▶ The confirmation message will appear. Press ⟲ to select **OK**.

Defaulting All the Settings

When you transfer the vehicle to a third party, reset all settings to default and delete all personal data.

Driver 1 and **Driver 2** has stored each settings and personal data separatory.
Perform both **Driver 1** and **Driver 2** data reset.

The following settings will be reset:

- Routing & Guidance: Rerouting, Unverified Area Routing, Traffic Rerouting, Edit Waypoint Search Area, Guidance Mode, Street Name Guidance
- Route Preference
- Audio preset settings
- Phonebook entries
- Other display and each item settings

The HomeLink® Universal Transceiver can be programmed to operate up to three remote controlled devices around your home, such as garage doors, lighting, or home security systems.

■ Important Safety Precautions

Refer to the safety information that came with your garage door opener to test that the safety features are functioning properly. If you do not have the safety information, contact the manufacturer.


Before programming HomeLink, make sure that people and objects are out of the way of the garage or gate to prevent potential injury or damage.

When programming a garage door opener, park just outside the garage door's path.

HomeLink® Universal Transceiver

Before programming HomeLink to operate a garage door opener, confirm that the opener has an external entrapment protection system, such as an "electronic eye," or other safety and reverse stop features. If it does not, HomeLink may not be able to operate it.

Training HomeLink




If it is necessary to erase a previously entered learned code:

- Press and hold the two outside buttons for about 20 seconds, until the red indicator blinks. Release the buttons, and proceed to step 1.
- If you are training the second or third button, go directly to step 1.

The instructions on the next page should work for most gate or garage openers, but may not work for all. For detailed instructions about your specific remote opener, visit *http://www.homelink.com* or call (800) 355-3515.

Continued

■ Training a Button



Training HomeLink

Retraining a Button

If you want to retrain a programmed button for a new device, you do not have to erase all button memory. You can replace the existing memory code using this procedure:

1. Press and hold the desired HomeLink button until the HomeLink indicator begins to blink.

Standard transmitter
Indicator remains on for about 25 secs.

Rolling code transmitter
Indicator remains on for about 25 secs.

2. Quickly release the HomeLink button and follow steps 1 - 3 under "Training a Button." You do not need to press and release the HomeLink button again in step 2.

Erasing Codes

To erase all the codes, press and hold the two outside buttons until the HomeLink indicator begins to blink (about 10 to 20 secs). You should erase all codes before selling the vehicle.


If you have any problems, see the device's instructions, visit *www.homelink.com*, or call HomeLink at (800) 355-3515.

HomeLink® is a registered trademark of Gentex Corporation.

Bluetooth® HandsFreeLink® (HFL) allows you to place and receive phone calls using your vehicle's audio system, without handling your cell phone.

Using HFL

HFL Buttons



(Pick-up) button: Press to go to the **Speed Dial/Call History** on the MID or to answer an incoming call.

(Hang-up/back) button: Press to end a call, to cancel a command or to clear the phone information on the MID.

(Talk) button: Press to give HFL voice commands.

PHONE button: Press to go directly to the phone menu screen.

Interface dial (ENTER/MENU button): Rotate to select an item on the screen, then press . Move , , or to select secondary menu.

Bluetooth® HandsFreeLink®

Place your phone where you can get good reception. To use HFL, you need a *Bluetooth*-compatible cell phone. For a list of compatible phones, pairing procedures, and special feature capabilities:

- U.S.: Visit *www.handsfreelink.com/Acura*, or call 1-888-528-7876.
- Canada: For more information on smartphone compatibility, call 1-888-528-7876.

To use HFL, the **Bluetooth** setting must be **On**. If there is an active connection to Apple CarPlay, HFL is unavailable.

Customized Features P. 362

Voice control tips:


- Aim the vents away from the ceiling and close the windows, as noise coming from them may interfere with the microphone.
- Press and release the button when you want to call a number using a stored voice tag, a phonebook name, or a number. Speak clearly and naturally after a beep.
- If the microphone picks up voices other than yours, the command may be misinterpreted.
- To change the volume level, use the audio system's volume knob or the remote audio controls on the steering wheel.

State or local laws may prohibit the operation of handheld electronic devices while operating a vehicle.

Continued

■ HFL Status Display

The On Demand Multi-Use Display™ notifies you when there is an incoming call.



Bluetooth® HandsFreeLink®

If you receive a call while using the audio system, the system resumes its operation an after ending the call.

Bluetooth® Wireless Technology
The *Bluetooth*® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc., and any use of such marks by Honda Motor Co., Ltd., is under license. Other trademarks and trade names are those of their respective owners.


HFL Limitations
An incoming call on HFL will interrupt the audio system when it is playing. It will resume when the call is ended.

HFL Status Display

The information that appears on the information screen varies between phone models.

You can change the system language.
➡ **Customized Features** P. 362

■ Limitations for Manual Operation



Certain manual functions are disabled or inoperable while the vehicle is in motion. You cannot select a grayed-out option until the vehicle is stopped.

Only previously stored speed dial entries with voice tags, phonebook names, or numbers can be called using voice commands while the vehicle is in motion.

➡ **Speed Dial** P. 416

HFL Menus

The power mode must be in ACCESSORY or ON to use HFL.

■ Bluetooth/Phone Settings screen





1. Press the **SETTINGS** button.
2. Rotate ⟲ to select **Bluetooth/Phone Settings**, then press ⟲.

HFL Menus

To use HFL, you must first pair your *Bluetooth*-compatible cell phone to the system while the vehicle is parked.


Some functions are limited while driving. A message appears on the screen when the vehicle is moving and the operation is canceled.





*1: Appears only when a phone is connected to HFL.

Continued




Turn the text/e-mail message function on and off.

Select a mail or text message account.

Select whether a pop-up alert comes on the screen when HFL receives a new text/e-mail message.

*1: Appears only when a phone is connected to HFL.

■ Phone Menu screen




Press the **PHONE** button to display the menu items.

- **Speed Dial**[*1]
  - **More Speed Dials** — Display another paired phone's speed dial list.
  - **New Entry**
    - **Manual Input** — Enter a phone number to store as a speed dial number.
    - **Import from Phonebook** — Select a phone number from the phonebook to store as a speed dial number.
    - **Import from Call History** — Select a phone number from the call history to store as a speed dial number.
  - **(Existing entry list)** — Dial the selected number in the speed dial list.
- **Call History**[*1]
  - **All**[*2] — Display the last 20 outgoing, incoming and missed calls.
  - **Dialed** — Display the last 20 outgoing calls.
  - **Received** — Display the last 20 incoming calls.
  - **Missed** — Display the last 20 missed calls.
- **Phonebook**[*1] — Display the paired phone's phonebook.
- **Roadside Assistance** — Makes a call to the number for the Roadside Assistance service.

*1: Appears only when a phone is connected to HFL.


*2: This function is not available if your phone is not supported.

Continued



*1: Appears only when a phone is connected to HFL.
*2: This function is not available if your phone is not supported.

■ Phone Setup



■ To pair a cell phone (when there is no phone paired to the system)

1. Press the **PHONE** button.
2. Rotate ☎ to select **Yes**, then press ⊛.
3. Make sure your phone is search or discoverable mode, then press ⊛.
   ▶ HFL automatically searches for a *Bluetooth* device.
4. When your phone appears on the list, select it by pressing ⊛.
   ▶ If your phone does not appear, you can select **Options...** and **Refresh** to search again.
   ▶ If your phone still does not appear, select **Options...** to select **Device Not Found?** and search for *Bluetooth* devices using your phone. From your phone, select **HandsFreeLink**.
5. HFL gives you a pairing code on the information screen.
   ▶ Confirm if the pairing code on the screen and your phone match.
   This may vary by phone.
6. A notification appears on the screen if pairing is successful.

Phone Setup

Your *Bluetooth*-compatible phone must be paired to HFL before you can make and receive hands-free calls.

Phone Pairing Tips:
- You cannot pair your phone while the vehicle is moving.
- Up to six phones can be paired.
- Your phone's battery may drain faster when it is connected to HFL.
- If your phone is not ready for pairing or not found by the system within three minutes, the system will time out and returns to idle.


Once you have paired a phone, you can see it displayed on the screen with one or two icons on the right side.
These icons indicate the following:
: The phone can be used with HFL.
: The phone is compatible with *Bluetooth*® Audio.

When pairing is completed, an **Automatic Phone Sync** prompt appears. Select **On** if you want your call history and phonebook automatically imported to HFL.

➡ **Changing the Automatic Phone Sync setting** P. 415

If there is an active connection to Apple CarPlay, pairing of additional *Bluetooth*-compatible devices is unavailable.

Continued



■ **To pair a cell phone (when a phone has already been paired to the system)**

1. Press the **SETTINGS** button.


2. Rotate ☎ to select **Bluetooth/Phone Settings**, then press ⊛.
▶ Repeat the procedure to select **Bluetooth Device List**, then **Add Bluetooth Device**.

3. Make sure your phone is in search or discoverable mode, then press ⊛.
▶ HFL automatically searches for a *Bluetooth* device.

4. When your phone appears on the list, select it by pressing ⊛.
▶ If your phone does not appear, you can select **Options...** and **Refresh** to search again.
▶ If your phone still does not appear, select **Options...** to select **Device Not Found?** and search for *Bluetooth* devices using your phone. From your phone, select **HandsFreeLink**.


5. HFL gives you a pairing code on the information screen.
▶ Confirm if the pairing code on the screen and your phone match.
This may vary by phone.

6. A notification appears on the screen if pairing is successful.



■ To change the currently paired phone

1. Press the **SETTINGS** button.
2. Rotate ⟲ to select **Bluetooth/Phone Settings**, then press ⟲.
   ▶ Repeat the procedure to select **Bluetooth Device List**.
3. Select a phone to connect.
   ▶ HFL disconnects the connected phone and starts searching for another paired phone.
4. Select **Connect to Phone**, **Connect to Audio**, or **Connect Both**.



■ To change the pairing code setting

1. Press the **SETTINGS** button.
2. Rotate ⟲ to select **Bluetooth/Phone Settings**, then press ⟲.
   ▶ Repeat the procedure to select **Edit Pairing Code**.
3. Rotate ⟲ to select **Fixed** or **Random**, then press ⟲.


»To change the pairing code setting

The pairing code may be six or four digits depending on your phone.

The default pairing code is **0000** until you change the setting.
To create your own, select **Fixed**, and delete the current code, then enter a new one.

For a randomly generated pairing code each time you pair a phone, select **Random**.

Continued




■ To replace an already-paired phone with a new phone

1. Press the **SETTINGS** button.
2. Rotate ⟲ to select **Bluetooth/Phone Settings**, then press ⟲.
   ▶ Repeat the procedure to select **Bluetooth Device List**.
3. Rotate ⟲ to select a paired phone you want to replace, then press ⟲.
4. Rotate ⟲ to select **Replace This Device**, then press ⟲.
5. HFL enters the pairing process and searches a new phone.
   ▶ Follow the prompts to pair a new phone.
6. A notification appears on the screen if pairing is successful.

To replace an already-paired phone with a new phone

The replaced phone will keep the same speed dial entries, and security PIN information from the previously paired phone.




■ To delete a paired phone

1. Press the **SETTINGS** button.
2. Rotate ⟲ to select **Bluetooth/Phone Settings**, then press ⟲.
   ▶ Repeat the procedure to select **Bluetooth Device List**.
3. Rotate ⟲ to select a phone you want to delete, then press ⟲.
4. Rotate ⟲ to select **Delete This Device**, then press ⟲.
5. A confirmation message appears on the screen. Rotate ⟲ to select **Yes**, then press ⟲.
6. A notification appears on the screen if pairing is successful.


Continued

■ To Set Up a Text/e-mail Message Option



■ To turn on or off the text/e-mail message function

1. Press the **SETTINGS** button.
2. Rotate ⟲ to select **Bluetooth/Phone Settings**, then press ⟲.
3. Rotate ⟲ to select **Enable Text/Email**.
4. Press ⟲ to select **On** or **Off**.



■ To turn on or off the text/e-mail message notice

1. Press the **SETTINGS** button.
2. Rotate ⟲ to select **Bluetooth/Phone Settings**, then press ⟲.
3. Rotate ⟲ to select **New Text/Email Alert**.
4. Press ⟲ to select **On** or **Off**.

To Set Up a Text/e-mail Message Option

To use the text/e-mail message function, you need a *Bluetooth*-compatible cell phone. For a list of compatible phones, pairing procedures, and special feature capabilities:

- U.S.: Visit *www.handsfreelink.com/Acura*, or call 1-888-528-7876.
- Canada: For more information on smartphone compatibility, call 1-888-528-7876.


Some text/e-mail features may not be available depending on a cellular phone.

To turn on or off the text/e-mail message notice

On: A pop-up notification comes on every time you receive a new text message.
Off: The message you receive is stored in the system without notification.

To Create a Security PIN

You can protect each of the six cell phones with a security PIN.



1. Press the **SETTINGS** button.
2. Rotate ⟲ to select **Bluetooth/Phone Settings**, then press ⟲.
   ▶ Repeat the procedure to select **Bluetooth Device List**.
3. Rotate ⟲ to select a phone you want to add a security PIN to, then press ⟲.
4. Rotate ⟲ to select **Edit PIN**, then press ⟲.
5. Enter a new four-digit number.
   ▶ Select X to delete. Select X of the right side upper screen, the screen returns to the previous screen.
6. Select **OK** to enter the security PIN.
7. Re-enter the four-digit number.
   ▶ The screen returns to the screen in step 4.

To Create a Security PIN

If the phone is already security PIN protected, you need to enter the current security PIN before clearing the PIN or creating a new one.

Continued

■ Editing User Name






Edit the user name of a paired phone as follows:

1. Press the **SETTINGS** button.
2. Rotate ⟲ to select **Bluetooth/Phone Settings**, then press ⟲.
   ▶ Repeat the procedure to select **Bluetooth Device List**.
3. Rotate ⟲ to select a phone you want to edit, then press ⟲.
4. Rotate ⟲ to select **Edit Device Name**, then press ⟲.
5. Enter a new name of the phone.
   ▶ Use the keyboard on the On Demand Multi-Use Display™ to enter the name, then select **OK**.

Automatic Transferring


If you get into the vehicle while you are on the phone, the call can be automatically transferred to HFL.



1. Press the **SETTINGS** button.
2. Rotate to select **Bluetooth/Phone Settings**, then press .
3. Rotate to select **Auto Transfer**.
4. Press to select **On** or **Off**.

Auto Answer

You can set HFL to automatically answer an incoming call in four seconds.



1. Press the **SETTINGS** button.
2. Rotate to select **Bluetooth/Phone Settings**, then press .
3. Rotate to select **Auto Answer**.
4. Press to select **On** or **Off**.

Continued

■ Ring Tone


You can change the ring tone setting.



1. Press the **SETTINGS** button.
2. Rotate ⟲ to select **Bluetooth/Phone Settings**, then press ⟲.
   ▶ Repeat the procedure to select **Ring Tone**.
3. Rotate ⟲ to select **Fixed**, **Mobile Phone** or **Off**, then press ⟲.

■ Use Contact Photo

You can display a caller's picture on an incoming call screen.



1. Press the **SETTINGS** button.
2. Rotate ⟲ to select **Bluetooth/Phone Settings**, then press ⟲.
3. Rotate ⟲ to select **Use Contact Photo**.
4. Press ⟲ to select **On** or **Off**.

Ring Tone

Fixed: The fixed ring tone sounds from the speaker.
Mobile Phone: The ring tone stored in the connected cell phone sounds from the speaker.
Off: No ring tones sound from the speaker.

■ Automatic Import of Cellular Phonebook and Call History



■ When Automatic Phone Sync is set to On:

When your phone is paired, the contents of its phonebook and call history are automatically imported to HFL.




■ Changing the Automatic Phone Sync setting

1. Press the **SETTINGS** button.
2. Rotate ⟲ to select **Bluetooth/Phone Settings**, then press ⟲.
   ▶ Repeat the procedure to select **Automatic Phone Sync**.
3. Rotate ⟲ to select **On** or **Off**, then press ⟲.

Continued

Automatic Import of Cellular Phonebook and Call History

When you select a person from the list in the cellular phonebook, you can see up to three category icons. The icons indicate what types of numbers are stored for that name.




On some phones, it may not be possible to import the category icons to HFL.

The phonebook is updated after every connection. Call history is updated after every connection or call.

■ Speed Dial

Up to 20 speed dial numbers can be stored per phone.




To store a speed dial number:

1. Press the **PHONE** button.
2. Rotate ⟲ to select **Speed Dial**, then press ⊙.
   ▶ Repeat the procedure to select **New Entry**.
3. Rotate ⟲ to select a place to choose a number from, then press ⊙.
   From **Import from Call History**:
   ▶ Select a number from the call history.
   From **Manual Input**:
   ▶ Input the number manually.
   From **Import from Phonebook**:
   ▶ Select a number from the linked cell phone's imported phonebook.
4. When the speed dial is successfully stored from **Import from Call History** or **Import from Phonebook**, you are asked to create a voice tag for the number. Rotate ⟲ to select **Yes** or **No**, then press ⊙.
5. Using the 🎤 button, follow the prompts to store a voice tag for the speed dial entry.

Speed Dial

When a voice tag is stored, press the 🎤 button to call the number using the voice tag. Say *"Call"* and the voice tag name.




■ To add a voice tag to a stored speed dial number

1. Press the **SETTINGS** button.
2. Rotate ⟲ to select **Bluetooth/Phone Settings**, then press ⟲.
   ▶ Repeat the procedure to select **Edit Speed Dial**.
3. Select an existing speed dial entry.
   ▶ From the pop-up menu, rotate ⟲ to select **Edit**, then press ⟲.
4. Rotate ⟲ to select **Voice Tag**, then press ⟲.
   ▶ From the pop-up menu, rotate ⟲ to select **Record**, then press ⟲.
5. Press ⟲.
   ▶ Using the button, follow the prompts to complete the voice tag.
6. You will receive a confirmation message on the screen. Rotate ⟲ to select **OK**, then press ⟲.

Speed Dial


Avoid using duplicate voice tags.
Avoid using "home" as a voice tag.
It is easier for HFL to recognize a longer name. For example, use "John Smith" instead of "John."

Continued



■ To delete a voice tag

1. Press the **SETTINGS** button.
2. Rotate ☜ to select **Bluetooth/Phone Settings**, then press ⍥.
   ▶ Repeat the procedure to select **Edit Speed Dial**.
3. Select an existing speed dial entry.
   ▶ From the pop-up menu, rotate ☜ to select **Edit**, then press ⍥.
4. Rotate ☜ to select **Voice Tag**, then press ⍥.
   ▶ From the pop-up menu, rotate ☜ to select **Clear**, then press ⍥.
5. A confirmation message appears on the screen. Rotate ☜ to select **Yes**, then press ⍥.




■ To delete a speed dial

1. Press the **SETTINGS** button.
2. Rotate ☜ to select **Bluetooth/Phone Settings**, then press ⍥.
   ▶ Repeat the procedure to select **Edit Speed Dial**.
3. Select an existing speed dial entry.
   ▶ From the pop-up menu, rotate ☜ to select **Delete**, then press ⍥.
4. A confirmation message appears on the screen. Rotate ☜ to select **Yes**, then press ⍥.

■ Phonebook Phonetic Modification

Add phonetic modifications or a new voice tag to the phone's contact name so that it is easier for HFL to recognize voice commands.



■ To add a new voice tag

1. Press the **SETTINGS** button.
2. Rotate ⟲ to select **System Settings**, then press ⊙.
3. Rotate ⟲ to select **Phonebook Phonetic Modification**, then press ⊙.
4. Rotate ⟲ to select the phone you want to add phonetic modification to, then press ⊙.
5. Rotate ⟲ to select **Options...**, then press ⊙.
6. Rotate ⟲ to select **New Voice Tag**, then press ⊙.

Phonebook Phonetic Modification

You can store up to 20 phonetic modification items.

Continued



7. Move ◁○ or ○▷ and rotate ⟳ to select a contact name, then press ⊛.
▶ The pop-up menu appears on the screen.

8. Rotate ⟳ to select **Modify**, then press ⊛.
9. Press ⊛.
▶ Using the button, follow the prompts to complete the voice tag.
10. You will receive a confirmation message on the screen. Rotate ⟳ to select **OK**, then press ⊛.
11. Rotate ⟳ to select **Options...**, then press ⊛.
12. Rotate ⟳ to select **OK**, then press ⊛.




■ To modify a voice tag

1. Press the **SETTINGS** button.
2. Rotate ⟲ to select **System Settings**, then press ⟲.
3. Rotate ⟲ to select **Phonebook Phonetic Modification**, then press ⟲.
4. Rotate ⟲ to select the phone you want to add phonetic modification to, then press ⟲.
5. Rotate ⟲ to select a contact name you want to modify, then press ⟲.
   ▶ The pop-up menu appears on the screen.
6. Rotate ⟲ to select **Modify**, then press ⟲.
7. Press ⟲.
   ▶ Using the 🎤 button, follow the prompts to complete the voice tag.
8. You will receive a confirmation message on the screen. Rotate ⟲ to select **OK**, then press ⟲.
9. Rotate ⟲ to select **Options...**, then press ⟲.
10. Rotate ⟲ to select **OK**, then press ⟲.

Phonebook Phonetic Modification


You can only modify or delete contact names for the currently connected phone.

Continued



■ **To delete a modified voice tag**

1. Press the **SETTINGS** button.
2. Rotate to select **System Settings**, then press .
3. Rotate to select **Phonebook Phonetic Modification**, then press .
4. Rotate to select the phone you want to delete phonetic modification, then press .
5. Rotate to select a contact name you want to delete, then press .
   ▶ The pop-up menu appears on the screen.
6. Rotate to select **Delete**, then press .
   ▶ Items to be deleted are indicated with a trash icon.
7. Rotate to select **Options...**, then press .
8. Rotate to select **OK**, then press .




■ **To delete all modified voice tags**

1. Press the **SETTINGS** button.
2. Rotate to select **System Settings**, then press .
3. Rotate to select **Phonebook Phonetic Modification**, then press .
4. Rotate to select the phone you want to delete phonetic modification, then press .
5. Rotate to select **Options...**, then press .
6. Rotate to select **Delete All**, then press .
7. You will receive a confirmation message on the screen. Rotate to select **Yes**, then press .

Continued

■ Making a Call



You can make calls by inputting any phone number, or by using the imported phonebook, call history, speed dial entries, or redial.


Making a Call

Any voice-tagged speed dial entry, phonebook name, or number can be dialed by voice from most screens. Press the button and say *"Call"* and the voice tag name, *"Call by name"* and the phonebook name, or *"Call"* and the phone number.

The maximum range between your phone and vehicles is 30 feet (10 meters).

Once a call is connected, you can hear the voice of the person you are calling through the audio speakers.

While there is an active connection with Apple CarPlay, phone calls cannot be made with HandsFreeLink® and are only made from Apple CarPlay.



■ To make a call using the imported phonebook

1. Press the **PHONE** button.
2. Rotate ⟲ to select **Phonebook**, then press ⟲.
3. Rotate ⟲ to select a contact name, then press ⟲.
   ▶ The phonebook is stored alphabetically.
4. Rotate ⟲ to select a number, then press ⟲.
   ▶ Dialing starts automatically.

To make a call using the imported phonebook

You can call a stored voice-tagged speed dial number, phonebook name, or number using voice commands.

Speed Dial P. 416

You can use the keyboard on the On Demand Multi-Use Display™ for a partial match search.




Continued




■ To make a call using a phone number

1. Press the **PHONE** button.
2. Rotate ☜ to select **Dial**, then press ⍥.
3. Select a number.
▶ Use the keyboard on the On Demand Multi-Use Display™ for entering numbers.
4. Select ☎.



■ To make a call using redial

1. Press the **PHONE** button.
2. Rotate ☜ to select **Redial**, then press ⍥.
▶ Dialing starts automatically.




■ To make a call using the call history

Call history is stored by **All**[*1], **Dialed**, **Received**, and **Missed**.

1. Press the **PHONE** button.
2. Rotate ⟲ to select **Call History**, then press ⟲.
3. Move ◁ or ▷ to select **All**[*1], **Dialed**, **Received**, and **Missed**.
4. Rotate ⟲ to select a number, then press ⟲.

▶ Dialing starts automatically.

On MID



Steering switches

1. Press the ☎ button.
2. Move the left selector wheel right to select **Call History**.
3. Roll the left selector wheel to select a number.
4. Push the left selector wheel or the ☎ button.

▶ Dialing starts automatically.

To make a call using the call history

The call history displays the last 20 dialed, received, or missed calls.
(Appears only when a phone is connected to HFL.)

These icons next to the number indicate the following:
☎: Dialed calls.
☎: Received calls.
☎: Missed calls.

Steering switches

The call history displays the last 12 dialed, received, or missed calls.

*1: This function may not be available depending on a cellular phone.


Continued



■ To make a call using a speed dial entry

1. Press the **PHONE** button.
2. Rotate ⟲ to select **Speed Dial**, then press ⟲.
3. Rotate ⟲ to select a number, then press ⟲.
   ▶ Dialing starts automatically.

On MID



Steering switches

1. Press the 📞 button.
2. Move the left selector wheel left to select **Speed Dial**.
3. Roll the left selector wheel to select a number.
4. Push the left selector wheel or the 📞 button.
   ▶ Dialing starts automatically.

To make a call using a speed dial entry

Rotate ⟲ to select **More Speed Dials** to view another paired phone's speed dial list. You can make a call from that list using the currently connected phone.

When a voice tag is stored, press the 🎙 button to call the number using the voice tag.
➡ **Speed Dial** P. 416


Any voice-tagged speed dial entry, phonebook name or number can be dialed by voice from any screen. Press the 🎙 button and follow the prompts.

Steering switches


The speed dial displays the 20 speed dial entries.

Receiving a Call

Information Screen



On Demand Multi-Use Display™



When there is an incoming call, an audible notification sounds (if activated) and the **Incoming Call** screen appears.

Press the button to answer the call.
Press the button to decline or end the call.

Receiving a Call

Call Waiting

Press the button to put the current call on hold to answer the incoming call.

Press the button again to return to the current call.

Ignore the incoming call if you do not want to answer it.


Press the button if you want to hang up the current call.

Continued

■ Options During a Call

The following options are available during a call.

Information Screen



On Demand Multi-Use Display™



Mute Icon

Information Screen

Phone Call Active - Transfer to Mobile: Transfer a call from HFL to your phone.

On Demand Multi-Use Display™

Mute: Mute your voice.
Transfer to Mobile: Transfer a call from HFL to your phone.
Touch Tones: Send numbers during a call. This is useful when you call a menu-driven phone system.

The available options are shown on the On Demand Multi-Use Display™.
Select the option.

▶ The **Mute** icon is checked when **Mute** is selected. Select **Mute** again to turn it off.

Options During a Call

Touch Tones: Available on some phones.

Features

■ Receiving a Text/E-mail Message

HFL can display newly received text and e-mail messages as well as 20 of the most recently received messages on a linked cell phone. Each received message can be read aloud and replied to using a fixed common phrase.



1. A pop-up appears and notifies you of a new text or e-mail message.
2. Rotate ⟲ to select **Read** to listen to the message, then press ⏻.
   ▶ The text or e-mail message is displayed. The system automatically starts reading out the message.
3. To discontinue the message read-out, press ⏻.

Receiving a Text/E-mail Message

The system does not display any received messages while you are driving. You can only hear them read aloud.

With some phones, you may be able to display up to 20 most recent text and e-mail messages.

State or local laws may limit your use of the HFL text/e-mail message feature. Only use the text/e-mail message feature when conditions allow you to do so safely.


When you receive a text or e-mail message for the first time since the phone is paired to HFL, you are asked to turn the **New Text/Email Alert** setting to **On**.

➡ **To turn on or off the text/e-mail message notice** P. 410

Continued

■ Selecting a Mail Account

If a paired phone has text message or mail accounts, you can select one of them to be active and receive notifications.



1. Press the **SETTINGS** button.
2. Rotate ⟲ to select **Bluetooth/Phone Settings**, then press ⊙.
   ▶ Repeat the procedure to select **Select Account**.
3. Rotate ⟲ to select **Text Messages** or an e-mail account you want, then press ⊙.

Selecting a Mail Account

You can also select a mail account from the folder list screen or the message list screen.
Rotate ⟲ to select **Select Account**, then press ⊙.




You can only receive notifications from one text message or mail account at a time.

■ Displaying Messages

Message List



Text Message



■ Displaying text messages

1. Press the **PHONE** button.
2. Rotate ⟲ to select **Text/Email**, then press ⊛.
   ▶ Select account if necessary.
3. Rotate ⟲ to select a message, then press ⊛.
   ▶ The text message is displayed. The system automatically starts reading the message aloud.
4. Rotate ⟲ to select **View Full Message**.
5. Press ⊛ to displays the full text of the message.

Displaying Messages

The ✉ icon appears next to an unread message.

If you delete a message on the phone, the message will also be deleted from the system. If you send a message from the system, the message goes to your phone's outbox.

To see the previous or next message, move ◁○ or ○▷ on the text message screen.

Continued


Folder List



Message List



E-mail Message




■ Displaying e-mail messages

1. Press the **PHONE** button.
2. Rotate ⟲ to select **Text/Email**, then press ⟲.
3. Rotate ⟲ to select a folder, then press ⟲.
4. Rotate ⟲ to select a message, then press ⟲.
   ▶ The e-mail is displayed. The system automatically starts reading the message aloud.
5. Rotate ⟲ to select **View Full Message**.
6. Press ⟲ to displays the full text of the message.

Displaying e-mail messages

Received text and e-mail messages may appear in the message list screen at the same time. In this case, text messages are titled **No Subject**.




■ Read or stop reading a message

1. Go to the text or e-mail message screen.
▶ The system automatically starts reading the message aloud.
➡ **Displaying Messages** P. 433

2. Rotate ⟲ to select **Stop Reading Messages**.

3. Press ⟲ to stop reading.
Press ⟲ again to start reading the message from the beginning.



■ Reply to a message

1. Go to the text or e-mail message screen.
▶ The system automatically starts reading the message aloud.
➡ **Displaying Messages** P. 433

2. Rotate ⟲ to select **Reply**, then press ⟲.

3. Rotate ⟲ to select the reply message, then press ⟲.
▶ **Message sent** appears on the screen when the reply message was successfully sent.


Reply to a message

The available fixed reply messages are as follows:
- **Talk to you later, I'm driving.**
- **I'm on my way.**
- **I'm running late.**
- **OK**
- **Yes**
- **No**

You cannot add, edit, or delete reply messages.

Only certain phones receive and send messages when paired and connected. For a list of compatible phones:
- U.S.: Visit *www.handsfreelink.com/Acura*, or call 1-888-528-7876.
- Canada: For more information on smartphone compatibility, call 1-888-528-7876.

Continued



■ **Making a call to a sender**

1. Go to the text message screen.
▶ The system automatically starts reading the message aloud.
➔ **Displaying text messages** P. 433

2. Rotate ⟲ to select **Call**, then press ⏺.

■ Roadside Assistance

Provides a nationwide service for unexpected incidents. You can call for assistance using a phone paired and connected to *Bluetooth*® HandsFreeLink®.



1. Press the **PHONE** button.
2. Rotate ⟲ to select **Roadside Assistance**, then press ⟲.
3. Rotate ⟲ to select a phone number, then press ⟲.
   ▶ Dialing starts automatically.

Roadside Assistance

If you are subscribed to a paid AcuraLink package, you can call roadside assistance using the **LINK** button instead of your phone.

➡ **AcuraLink®** P. 438

Is a subscription-based service that provides convenient features such as voice communication in case of emergency, online security, one-on-one operator assistance, and the transmission of important messages regarding your vehicle's status.

Canadian models


For information on traffic rerouting and traffic information updates, provided by the AcuraLink server, see the Navigation System Manual.

■ In Case of Emergency

■ Automatic collision notification

When connected to the AcuraLink operator:

Information screen



On Demand Multi-Use Display™



If your vehicle's airbags deploy or if the unit detects that the vehicle is severely impacted, your vehicle will automatically attempt to connect to the AcuraLink operator. Once connected, information about your vehicle, its positioning, and its condition will be sent to the operator; you also can speak to the operator when connected.

AcuraLink®

AcuraLink also provides services you can operate from the Internet or your smartphone.

To subscribe to AcuraLink, or to get more information about all of its features, contact an Acura dealer, or visit *owners.acura.com* (U.S.) or *www.acura.ca/owners/acuralink* (Canada).

In Case of Emergency

Your vehicle may not be able to connect to the operator if the battery level is low, the line is disconnected, or you do not have adequate cellular coverage.


You cannot use emergency services when:
- You travel outside the AcuraLink service coverage areas.
- There is a problem with the connecting devices, such as the **ASSIST** button, microphone, speakers, or the unit itself.
- You are not subscribed to the service or your subscription is no longer valid.

You cannot operate other navigation or phone related functions using the screens while talking to the operator.
Only the operator can terminate the connection to your vehicle.

Automatic collision notification

If the unit fails to connect to the operator, it repeatedly tries until it succeeds.

■ Manual operator connection



If you need to talk to the AcuraLink operator in an emergency situation, you can manually connect to them by pressing the **ASSIST** button with the power mode in ACCESSORY or ON.

1. Open the cover attached to the ceiling console.
2. Press the **ASSIST** button.
   ▶ You are connected to the AcuraLink operator.

Manual operator connection

Do not press the button while driving. When you need to contact the operator, park the vehicle in a safe place.

If the unit fails to connect to the operator, it automatically cancels the action after three minutes.

In an emergency, the cover can be broken through to press the **ASSIST** button.

Continued

■ Security Features

Your subscribed telematics service provider can track your vehicle's location, remotely lock or unlock doors, and help you find your vehicle.
To use these features, you need your user ID and personal identification number (PIN).

■ Stolen vehicle tracking

This feature searches and tracks down your vehicle position even if it is on the move. If you believe that your vehicle has been stolen, contact the police as well as the provider.

■ Remote door lock/unlock

The provider can remotely lock or unlock doors upon your request.

■ Vehicle finder

This feature is convenient to use when trying to locate your vehicle in large areas, such as a crowded parking lot. If you cannot locate your vehicle after using the remote transmitter's answerback function, you can contact the provider which can then flash your vehicle's exterior lights and sound the horn.

■ Security alarm notification

If the security system in your vehicle detects an abnormal condition, such as someone tampering with the lock on your vehicle, the provider notifies you by your preferred method.

Security Features

The contact information of your provider, your user ID and PIN will be given when you subscribe to AcuraLink. If you forget any of the above, contact a dealer, or visit *owners.acura.com* (U.S.) or *www.acura.ca/owners/acuralink* (Canada).


You can also activate the remote door lock/unlock and vehicle finder features from the Internet or using your smartphone app. Ask a dealer, or visit *owners.acura.com* (U.S.) or *www.acura.ca/owners/acuralink* (Canada) for details.

Vehicle finder

The lights will stop flashing and horn will stop sounding under the following conditions:
- When 30 seconds have elapsed.
- You unlock the doors using the remote transmitter.
- You unlock the doors using the keyless access system.
- You unlock the doors using the built-in key.
- The power mode is set to ACCESSORY or ON.

■ Operator Assistance

Connect to the AcuraLink operator when trying to find a destination or for roadside assistance.



1. Press the **LINK** button.
▶ Connection to the operator begins.



2. Talk to the operator.
▶ To disconnect, select **End Call** or press the (Hang-up/back) button on the steering wheel.

Operator Assistance

Remain attentive to road conditions and driving during operator assistance.

Continued

■ AcuraLink Message



AcuraLink sends you messages on vehicle features, safety and emissions recall campaigns, maintenance reminders, and diagnostic information.
When you receive a new message, an icon appears on the information screen.

■ Message category

There are six message categories.

- **Feature Guide**: Appears for the first 30 days of ownership, introducing vehicle features each day.
- **Quick Tips**: Supplements your Owner's Manual with updated vehicle information.
- **Diagnostic Information**: Appears when a warning indicator or message comes on.
  Rotate ⟲ to select **Check Later** or **Check Now**.
  ▶ Selecting **Check Now** lets you know if you should see a dealer immediately or later in accordance with the warning severity level.
- **Scheduled Dealer Appointment**: An appointment made through the Acura server or Acura Owners website can be rescheduled or canceled from this option.
  ➡ P. 444
- **Maintenance Minder**: Lets you know which maintenance item is due along with a reminder message.
- **Recalls/Campaigns**: Reminds you of a recall or important safety information. You should also be notified by mail.

AcuraLink Message

Messages may not appear immediately after your vehicle purchase. It can take several days for your dealer to register your vehicle's ID.

If an icon includes an exclamation point, it indicates that Acura gives high priority to this message compared to the one without.

- A!: An unread message with high priority
- A✓: An unread message


Message category

Message categories can be added, edited, or deleted through broadcast messages from Acura.

You can call your dealer, find the nearest dealer, or schedule appointments from the message options in **Maintenance Minder**, **Recalls/Campaigns**, and **Diagnostic Information**.

➡ **Message Options** P. 443

■ Reading a message



1. Press the **INFO** button or press , follow the message on the information screen.
2. Rotate to select **AcuraLink/Messages**, then press .
   ▶ AcuraLink messages appears.
3. Rotate to select a category, then press .
   ▶ If there are unread messages in a category, a message icon appears next to that category.
4. Rotate to select a message you want to read, then press .

■ Message Options

While a message is displayed, you can use options to take immediate action to the message.

Available options are:

- **Read Messages Aloud**: Reads the message aloud. Select **Stop Reading Messages** to cancel it.
- **View Full Message**: Displays the entire message.
- **Phone number**: Dials a number displayed in the message via HFL.
- **Delete**: Deletes the displayed message.
- **Call Your Dealer**: Calls your Acura dealer using HFL.
- **Find Acura Dealer**: Searches for the nearest Acura dealer.
- **Roadside Assistance**: Makes a call to the number for the Roadside Assistance service.
- **Schedule Dealer Appoi...**: Automatically sets an appointment date at your dealer.

Reading a message

If there is no message listed on the menu, each category items are grayed out and cannot be selected.

The message icon disappears once you read the message.

However, the exclamation mark that indicates that the message has a high priority remains.

- : A read message with high priority.

Message Options

The available options vary by message category.

You can delete all messages in a category at once.
➡ **Customized Features** P. 362

Continued

■ Dealer Appointments

You can confirm the scheduled appointment date when you receive a **Maintenance Minder**, **Recalls/Campaigns**, or **Diagnostic Information** message, or reschedule any existing appointments.

1. Select a **Maintenance Minder**, **Recalls/Campaigns**, **Diagnostic Information**, or **Scheduled Dealer Appointment** message.
2. Rotate ⟲ to select **Schedule Dealer Appoi...** or **Reschedule Appoint...** (depending on the screen). Press ⟲.
   ▶ A suggested time and date are displayed.
3. Rotate ⟲ to select **Confirm Appointment**. Press ⟲ to accept the time and date.
4. Press ⟲ to select **OK**.

Dealer Appointments


To set up an automated dealer appointment when a regular maintenance is due, visit the Acura Owners website at *owners.acura.com* (U.S.) or *www.acura.ca/owners/acuralink* (Canada), and set the required option. A reminder message will be sent as the date for the dealer appointment approaches. A reminder message will also be sent if you schedule an appointment online using Schedule Service Appointment function.

If you are not satisfied with the proposed appointment date and time, call your dealer directly.

To cancel the scheduled appointment, select **Cancel Appointment** when a message is displayed.

■ AcuraLink Subscription Status

You can confirm your AcuraLink subscription status.



1. Press the **SETTINGS** button.


2. Rotate ⟲ to select **AcuraLink Settings**, then press ⟲.

▶ Repeat the procedure to select **AcuraLink Subscription Status**.

Item	Information
A-link	You can check the signal strength.
Current Contract	The AcuraLink subscription number and subscription level is displayed.
Service	You can confirm the type of service.
Subscription	You can confirm the expiration date.
Status	The following message can be displayed: • **Check Antenna**: There is a problem with the AcuraLink antenna. Contact a dealer. • **No Signal**: Signal is not received. • **No data**: The signal is received, but some error has occurred in the system. • **OK**: The system is receiving the signal or traffic data*.

* Not available on all models

This page intentionally left blank.



Driving

This chapter discusses driving and refueling.

Before Driving..... 448
Towing a Trailer..... 454
Off-Highway Driving Guidelines..... 455
When Driving
- Turning on the Power 457
- Dual Clutch Transmission 464
- Shifting..... 465
- Acoustic Vehicle Alerting System..... 473
- Integrated Dynamics System..... 474
- Front Sensor Camera 475
- Adaptive Cruise Control (ACC) with Low Speed Follow (LSF) 477
- Road Departure Mitigation (RDM) System ...492
- Lane Keeping Assist System (LKAS)... 497
- Vehicle Stability Assist® (VSA®), aka Electronic Stability Control (ESC), System 505
- Agile Handling Assist 507
- SPORT HYBRID Super Handling-All Wheel Drive™ (SPORT HYBRID SH-AWD®).. 508
- Blind spot information System..... 509
- Tire Pressure Monitoring System (TPMS) with Tire Fill Assist..... 512
- Tire Pressure Monitoring System (TPMS) - Required Federal Explanation..... 514
- High Voltage Battery..... 516

Braking
- Brake System 517
- Anti-lock Brake System (ABS)..... 523
- Brake Assist System 524
- Collision Mitigation Braking System™ (CMBS™) 525

Parking Your Vehicle
- When Stopped 534
- Parking Sensor System 536
- Cross Traffic Monitor..... 540

Multi-View Rear Camera* 544
Surround View Camera System* 546
Refueling
- Fuel Information 556
- How to Refuel 557

Fuel Economy and CO_2 Emissions.... 559

* Not available on all models

Driving Preparation

Check the following items before you start driving.

■ Exterior Checks

- Make sure there are no obstructions on the windows, door mirrors, exterior lights, or other parts of the vehicle.
  ▶ Remove any frost, snow, or ice.
  ▶ Remove any snow on the roof, as this can slip down and obstruct your field of vision while driving. If frozen solid, remove ice once it has softened.
  ▶ When removing ice from around the wheels, be sure not to damage the wheel or wheel components.
- Make sure the hood is securely closed.
  ▶ If the hood opens while driving, your front view will be blocked.
- Make sure the tires are in good condition.
  ▶ Check air pressures, and check for damage and excessive wear.
  ➡ **Checking and Maintaining Tires** P. 591
- Make sure there are no people or objects behind or around the vehicle.
  ▶ There are blind spots from the inside.

Exterior Checks

NOTICE

When doors are frozen shut, use warm water around the door edges to melt any ice. Do not try to force them open, as this can damage the rubber trim around the doors. When done, wipe dry to avoid further freezing.

Do not pour warm water into the key cylinder. You will be unable to insert the key if the water freezes in the hole.

Heat from the engine and exhaust can ignite flammable materials left under the hood, causing a fire. If you've parked your vehicle for an extended period, inspect and remove any debris that may have collected, such as dried grass and leaves that have fallen or have been carried in for use as a nest by a small animal. Also check under the hood for leftover flammable materials after you or someone else has performed maintenance on your vehicle.

■ Interior Checks

- Store or secure all items on board properly.
  ▶ Carrying too much cargo, or improperly storing it, can affect your vehicle's handling, stability, stopping distance, and tires, and make it unsafe.
  ➡ **Maximum Load Limit** P. 451
- Do not pile items higher than the seat height.
  ▶ They can block your view and may be thrown forward in the event of sudden braking.
- Do not place anything in the front seat footwells. Make sure to secure the floor mat.
  ▶ An object or unsecured floor mat can interfere with your brake and accelerator pedal operation while driving.
- If you have any animals on board, do not let them move around in the vehicle.
  ▶ They may interfere with driving and a crash could occur.
- Securely close and lock all doors and the tailgate.
  ➡ **Locking/Unlocking the Doors from the Inside** P. 154
- Adjust your seating position properly.
  ▶ Adjust the head restraint, too.
  ➡ **Adjusting the Seats** P. 195
  ➡ **Adjusting the Front and Second Row Outer Head Restraint Positions** P. 202
- Adjust the mirrors and steering wheel properly.
  ▶ Adjust them while sitting in the proper driving position.
  ➡ **Adjusting the Steering Wheel** P. 191
  ➡ **Adjusting the Mirrors** P. 192

Interior Checks

The headlight aim is set by the factory, and does not need to be adjusted. However, if you regularly carry heavy items in the cargo area, have the aiming readjusted at a dealer or by a qualified technician.

Canadian models

Your vehicle is equipped with the automatic headlight adjusting system that automatically adjusts the vertical angle of the low beam headlights.

Continued

- Be sure items placed on the floor behind the front seats cannot roll under the seats.
  ▶ They can interfere with the driver's ability to operate the pedals, the operation of the seats, or the operation of the sensors under the seats.
- Everyone in the vehicle must fasten their seat belt.
  ➡ **Fastening a Seat Belt** P. 42
- Make sure that the indicators in the instrument panel come on when you start the vehicle, and go off soon after.
  ▶ Always have a dealer check the vehicle if a problem is indicated.
  ➡ **Indicators** P. 84

Maximum Load Limit


Models with bench seat

The maximum load for your vehicle is 1,173 lbs (532 kg).

Models with captain seat

The maximum load for your vehicle is 1,005 lbs (456 kg).
See the Tire and Loading Information label attached to the driver's doorjamb.

Label Example


TIRE AND LOADING INFORMATION

SEATING CAPACITY | TOTAL 7 | FRONT 2 | REAR 5

The combined weight of occupants and cargo should never exceed 532 kg or 1,173 lbs.

TIRE	SIZE	COLD TIRE PRESSURE	SEE OWNER'S MANUAL FOR ADDITIONAL INFORMATION
FRONT	XXXX/XXXXX XXX	XXXKPA, XXPSI	
REAR		XXXKPA, XXPSI	
SPARE	XXXX/XXXXX XXXX	XXXKPA, XXPSI	

This figure includes the total weight of all occupants, cargo, and accessories, and the tongue load if you are towing a trailer.

Steps for Determining Correct Load Limit -

(1) Locate the statement "The combined weight of occupants and cargo should never exceed XXX kg or XXX lbs." on your vehicle's placard.

(2) Determine the combined weight of the driver and passengers that will be riding in your vehicle.

(3) Subtract the combined weight of the driver and passengers from XXX kg or XXX lbs.

Maximum Load Limit

⚠WARNING

Overloading or improper loading can affect handling and stability and cause a crash in which you can be hurt or killed.

Follow all load limits and other loading guidelines in this manual.

Gross Vehicle Weight Rating (GVWR):
The maximum allowable weight of the vehicle, all occupants, all accessories, all cargo.
➡ **Specifications** P. 662

Gross Axle Weight Rating (GAWR):
The maximum allowable weight of the vehicle axle.
➡ **Specifications** P. 662

Continued


(4) The resulting figure equals the available amount of cargo and luggage load capacity. For example, if the "XXX" amount equals 1,400 lbs. and there will be five 150 lb. passengers in your vehicle, the amount of available cargo and luggage load capacity is 650 lbs.
(1,400 - 750 (5 x 150) = 650 lbs.)

(5) Determine the combined weight of luggage and cargo being loaded on the vehicle. That weight may not safely exceed the available cargo and luggage load capacity calculated in step 4.

(6) If your vehicle will be towing a trailer, load from your trailer will be transferred to your vehicle. Consult this manual to determine how this reduces the available cargo and luggage load capacity of your vehicle.

In addition, the total weight of the vehicle, all occupants, accessories, cargo, and trailer tongue load must not exceed the Gross Vehicle Weight Rating (GVWR) or the Gross Axle Weight Rating (GAWR). Both are on a label on the driver's doorjamb.

Load Limits Example



Maximum Load Limit

Towing a Trailer:
See Towing a Trailer to determine whether your vehicle is designed to tow a trailer.

Towing a Trailer P. 454

Your vehicle is not designed to tow a trailer. Attempting to do so can void your warranties.

Towing Your Vehicle

Your vehicle is not designed to be towed behind a motor home. If your vehicle needs to be towed in an emergency, refer to the emergency towing information.

Emergency Towing P. 656

General Information

Your vehicle has been designed primarily for use on pavement, however, its higher ground clearance allows you to occasionally travel on unpaved roads. It is not designed for trail-blazing, or other challenging off-highway activities.

If you decide to drive on unpaved roads, you will find that it requires somewhat different driving skills and that your vehicle will handle somewhat differently than it does on pavement. Pay attention to the precautions and tips in this section, and get acquainted with your vehicle before leaving the pavement.

Important Safety Precautions

To avoid loss of control or rollover, be sure to follow all precautions and recommendations:

- Be sure to store cargo properly and do not exceed your cargo load limits.
  ➡ **Maximum Load Limit** P. 451
- Whenever you drive, make sure you and your passengers always wear seat belts.
- Keep your speed low, and never go faster than the conditions allow.
- It's up to you to continually assess the situation and drive within the limits.

⚠WARNING

Improperly operating this vehicle on or off-pavement can cause a crash or rollover in which you and your passengers could be seriously injured or killed.

- Follow all instructions and guidelines in this owner's manual.
- Keep your speed low, and don't drive faster than conditions permit.

Failure to operate your vehicle correctly might result in a crash or a rollover.


➡ **Important Handling Information** P. 36
➡ **Precautions While Driving** P. 463


Spinning the tires can also damage the SPORT HYBRID Super Handling-All Wheel Drive™ system.

Avoiding Trouble

- **Check Out Your Vehicle** before you leave the pavement and make sure that all scheduled maintenance has been completed. Pay special attention to the condition of the tires, and check the tire pressures.
- **Remember** the route you choose presents limits (too steep or bumpy), you have limits (driving skill and comfort), and your vehicle has limits (traction, stability, and power). Failing to recognize these limits will likely put you and your passengers in a hazardous situation.
- **Accelerating and Braking** should be done slowly and gradually. Trying to start or stop too fast can cause a loss of traction and you could lose control.
- **Avoiding Obstacles and Debris** in the road reduces the likelihood of a rollover or damage to your suspension or other components.
- **Driving on Slopes** increases your risk of a rollover, particularly if you attempt to drive across a slope that is too steep. Going straight up or down a slope is usually the safest. If you can't clearly see all conditions or obstacles on a slope, walk it before you drive it. If there is any doubt whether you can safely pass, don't try it. Find another route. If you get stuck when climbing, do not try to turn around. Back down slowly following the same route you took up the hill.
- **Crossing a Stream** - Avoid driving through deep water. If you encounter water in your route (a small stream or large puddle, for example), evaluate it carefully before going ahead. Make sure it is shallow, flowing slowly, and has firm ground underneath. If you are not sure of the depth or the ground, turn around and find another route. Driving through deep water can also damage your vehicle. The water can get into the transmission and differential, diluting the lubricant and causing an eventual failure. It can also wash the grease out of the wheel bearings.
- **If You Get Stuck**, carefully go in the direction that you think will get you unstuck. Do not spin the tires as this will only make things worse and could damage the transmission. If you are unable to free yourself, your vehicle will need to be towed. Front and rear tow hooks are provided for this purpose.

Turning on the Power





1. Make sure the parking brake is applied.
▶ The electric parking brake indicator comes on for 15 seconds when you press the electric parking brake switch.

2. Depress the brake pedal.

Turning on the Power

Keep your foot firmly on the brake pedal when starting the power system.


The engine is harder to start in cold weather and in thinner air found at altitudes above 8,000 feet (2,400 meters).

When turning on the power system in cold weather, turn off all electrical accessories such as the lights, climate control system, and rear defogger in order to reduce 12-volt battery drain.

If you live in a region where winter is extremely cold, an engine block heater and transmission clutch actuator heater will improve starting and warming of the engine. Consult a dealer for details.

If exhaust system sounds abnormal or you can smell exhaust gas inside the vehicle, have your vehicle checked by a dealer. There may be a problem with the engine or exhaust system.

Continued



3. Press the **POWER** button without depressing the accelerator pedal.
- ▶ The **Ready To Drive** message appears on the multi-information display (MID).
- ▶ If the High Voltage battery is fully charged, the gasoline engine may not start.
- ▶ If the High Voltage battery charge level is low, the gasoline engine starts.
- ▶ When the ambient temperature is extremely low, the vehicle does not move until certain conditions are met.
  A warning message appears instead of **Ready To Drive**.
  - **Multi-Information Display (MID) Warning and Information Messages** P. 105

■ Stopping the Power System

You can turn the power system off when the vehicle is completely stopped.

1. Put the transmission into P.

2. Press and hold the **POWER** button.

Turning on the Power

The immobilizer system protects your vehicle from theft.
If an improperly coded key (or other device) is used, the power system does not activate.
- **Immobilizer System** P. 166

When you set the power mode to ON, you may feel the brake pedal slightly sink down. This is normal.

Bring the keyless access remote close to the **POWER** button if the battery in the keyless access remote is weak.
- **If the Keyless Access Remote Battery is Weak** P. 635

The power system may not activate if the keyless access remote is subjected to strong radio waves.


The engine may not run when the vehicle is ready for driving.
You can start driving with the **READY** indicator on.
If you press the **POWER** button while depressing the brake pedal with the **READY** indicator on, the power mode is set to VEHICLE OFF and you cannot start driving.
- **READY Indicator** P. 92

Do not hold the **POWER** button to start the power system.
If the power system does not start, set the power mode to OFF and wait at least 30 seconds before trying again.

■ Remote Engine Start with Vehicle Feedback

You can remotely turn the power system on using the two-way keyless access remote from extended distances.

■ To turn the power system on



The power system is on for up to 10 minutes without you starting the vehicle.
To extend the time for another 10 minutes during the first 10 minutes, press the button, then press and hold the ENGINE HOLD button.

▶ The amber LED blinks, then the green LED comes back on if a 10-minute extension request was transmitted successfully.

After pressing the (lock) button, wait for the green LED to blink. This indicates that the all the doors and the tailgate are locked.

Continued

⚠WARNING

Carbon monoxide gas is toxic and can rapidly accumulate in closed or even partly enclosed areas.

Breathing it can cause unconsciousness and even kill you.


Never use the remote engine starter with the vehicle parked in a garage or other areas with limited ventilation.

The remote engine start may violate local laws. Before using the remote engine start, check your local laws.

Remote Engine Start run timer extension
The power system is on for another 10 minutes from the time of extension request. The max time is 20 minutes, if the extension request is made after 10 minutes of first 10 minutes.

The vehicle may start in EV mode depending on High Voltage battery conditions.
▶If the High Voltage battery is fully charged, the gasoline engine may not start.
▶If the High Voltage battery charge level is low, the gasoline engine starts.

■ To turn the power system off



Remote Engine Start with Vehicle Feedback

If there are buildings and obstacles between your vehicle and the remote, the range will be reduced. This distance may vary by external electrical interference.

The power system may not be turned on by the remote engine start if:

- You have disabled a remote engine start setting using the MID.
- The power mode is not in VEHICLE OFF (LOCK).
- The transmission is in a position other than P.
- The hood is open, or any door or the tailgate is unlocked.
- You have already used the remote twice to turn the power system on.
- Another registered keyless access remote is in the vehicle.
- There is any antenna failure.
- The door is unlocked with the built-in key.
- The engine oil pressure is low.
- The engine coolant temperature is extremely high.
- The telematics unit malfunctions.
- The security system alarm is not set.

Before turning the power system on, make sure to check the door lock status using the remote. When you press the button, wait for the green LED to blink. If the red LED turns on, the doors and tailgate did not lock, and the power system is not turned on.

Remote Engine Start with Vehicle Feedback

While the power system is on, the vehicle will automatically precondition inside the vehicle.
When it is warm outside:
- The climate control system is activated in recirculation mode.
- The seat ventilation* is activated.

When it is cold outside:
- The defroster is activated at a moderately warm temperature.
- The rear defogger and door mirror heaters are activated.
- The seat heaters and heated steering wheel are activated*.

Heated Steering Wheel* P. 220
Front Seat Heaters and Seat Ventilation* P. 221, 222

* Not available on all models

Continued

■ Starting to Drive

When the power system was started using the two-way keyless access remote

1. Depress the brake pedal and press the **POWER** button simultaneously.

When the power system was started in any case

2. Keeping your right foot on the brake pedal, press the D/S button. Select R when reversing.

3. With the parking brake applied, release the brake pedal and gently depress the accelerator pedal.

▶ Make sure the electric parking brake indicator goes off.

➔ **Parking Brake** P. 517

➔ **If the Transmission System Indicator Blinks along with the Warning Message** P. 645

■ Hill start assist system

Hill start assist keeps the brake engaged briefly to help prevent the vehicle from rolling on inclines as you move your foot from the brake pedal to the accelerator.

Change the gear position to D or S when facing uphill, or R when facing downhill, then release the brake pedal.

Starting to Drive

When the power system was started using the two-way keyless access remote

The power system is turned off when the gear position is changed from P before the **POWER** button is pressed. Follow step 1 when starting to drive.

You can also release the parking brake by pulling the electric parking brake switch while depressing the brake pedal.
When facing downhill, you can start your vehicle more smoothly by manually releasing it with the electric parking brake switch than by releasing it with the accelerator pedal.

Hill start assist system

Hill start assist may not prevent the vehicle from rolling downhill on a very steep or slippery slope, and will not operate on small inclines.

Hill start assist is not a replacement for the parking brake.

Precautions While Driving

■ Driving Guidelines for Your Utility Vehicle

Utility vehicles have a significantly higher rollover rate than other types of vehicles. To prevent rollovers or loss of control:

- Take corners at slower speeds than you would with a passenger vehicle.
- Avoid sharp turns and abrupt maneuvers whenever possible.
- Do not modify your vehicle in any way that you would raise the center of gravity.
- Do not carry heavy cargo on the roof.
  Never carry more than 165 lbs (75 kg) of cargo on the roof rack (Acura accessory).

■ In Rain

Avoid driving in deep water and on flooded roads. This can damage the engine or driveline, or cause electrical component failure.

■ Other Precautions

If there is a strong impact with something under the vehicle, stop in a safe location. Check the underside of the vehicle for damage or any fluid leaks.

≫Precautions While Driving

NOTICE

Do not select a shift button while pressing the accelerator pedal. You could damage the transmission.

NOTICE

If you repeatedly turn the steering wheel at an extremely low speed, or hold the steering wheel in the full left or right position for a while, the electric power steering (EPS) system heats up. The system goes into a protective mode, and limits its performance. The steering wheel becomes harder and harder to operate. Once the system cools down, the EPS system is restored. Repeated operation under these conditions can eventually damage the system.

If the power mode is set to ACCESSORY while driving, the power system will shut down and all steering and brake power assist functions will stop, making it difficult to control the vehicle.

Do not press the N button, as you will lose regenerative braking (and acceleration) performance.

During the first 600 miles (1,000 km) of operation, avoid sudden acceleration or full throttle operation so as not to damage the power system or powertrain.

Avoid hard braking for the first 200 miles (300 km). You should also follow this when the brake pads are replaced.

Dual Clutch Transmission

■ Creeping

As with a conventional gasoline-powered vehicle with an automatic transmission, this vehicle will creep.
Keep the brake pedal firmly depressed when stopped.

■ Kickdown

Quickly depressing the accelerator pedal while driving uphill may cause the transmission to drop to a lower gear, unexpectedly increasing vehicle speed. Depress the accelerator pedal carefully, especially on slippery roads and curves.

Driving Guidelines for Your Utility Vehicle

Failure to operate your vehicle correctly might result in a crash or a rollover.

➡ **Important Handling Information** P. 36
➡ **Precautions While Driving** P. 463

Shifting

Change the gear position in accordance with your driving needs.

■ Shift button positions



P **Park**
Used when parking, before turning off or starting the power system

R **Reverse**
Used when reversing

N **Neutral**
Transmission is not locked

D **Drive**
Used for:
- Normal driving (gears change between 1st and 7th automatically)
- Temporarily driving in the sequential mode

S **Drive (S)**
Used for:
- Automatically changing gears between 1st and 6th (6th gear is used only at high speed)
- Driving in the sequential mode

Shifting

⚠WARNING

The vehicle can roll away if left unattended without confirming that Park is engaged.

A vehicle that rolls away could cause a crash resulting in serious injury or death.


Always keep your foot on the brake pedal until you have confirmed that P is shown on the gear position Indicator.

To prevent malfunction and unintended engagement:
- Do not spill any liquids on or around shift buttons.
- Do not place or drop any objects on or around shift buttons.
- Do not let passengers or children operate the shift buttons.

You may occasionally find that it takes longer than usual for the vehicle to start moving when you select R, release the brake pedal, and/or depress the accelerator pedal. This may occur when the High Voltage battery level is extremely low, and does not indicate a vehicle malfunction.

Continued

■ P (parking) button




The gear position changes to P when you press the P button while the vehicle is parked with the power mode in ON.
The indicators on the sides of the P button come on.

Shifting

When shifting gears in extremely low temperatures (–22°F/–30°C), there may be a short delay before the shift is indicated in the display. Always confirm you are in the correct gear before driving.

Shift Operation



Shift Operation

NOTICE

When you change D to R and vice versa, come to a complete stop and keep the brake pedal depressed. Operating the shift button before the vehicle has come to a complete standstill can damage the transmission.

Use the gear position indicator and the shift button indicator to check the gear position before selecting a shift button.

If the indicator of the currently selected gear position, or all the gear position indicators are blinking simultaneously, there is a problem with the transmission.
Avoid sudden acceleration and have the transmission checked by a dealer as soon as possible.

The fuel supply may be cut off if you drive at engine speeds in or over the tachometer's red zone (engine speed limit). If this happens, you may experience a slight jolt.

When the engine speed is increased while the transmission is in N, P or R, the fuel supply may be cut off even without the engine speed entering the tachometer's red zone.

The beeper sounds once when you change to R.

Continued

■ When opening the driver's door

If you open the driver's door under the following conditions, the gear position automatically changes to P.

- The vehicle is in stationary with the power mode in ON, or moving at 1 mph (2 km/h) or slower.
- The transmission is in other than P.
- You have unfastened the driver side seat belt.

▶ If you manually change the gear position from P with the brake pedal depressed, the gear position will automatically return to P once you release the brake pedal.

■ When turning off the power mode

If you turn the power system off while the vehicle is stationary, and the transmission is in other than P, the gear position automatically changes to P.

When opening the driver's door

While the system is designed to automatically change the gear position to P under the described conditions, in the interest of safety you should always select P before opening the driver's door.
Make sure to park the vehicle in a safe place.
When Stopped P. 534

If you want to drive the vehicle after the gear position has automatically changed to P under the described conditions, close the door, fasten the seat belt, depress the brake pedal, then change the gear position.

If you leave the vehicle, turn off the power system and lock the doors.

■ If you want to keep the transmission in [N] position [car wash mode]


With the **READY** indicator on:

1. Press and hold the brake pedal.

2. Select [N], then release the button to display [N] (Neutral) hold mode on the MID.

3. Press and hold [N] again for two seconds.

▶ This puts the vehicle in car wash mode which must be used when your vehicle is pulled through a conveyor type automatic car wash where you or an attendant do not remain in the vehicle.



If the **POWER** button is pressed after car wash mode has been activated, the power mode will change to ACCESSORY and a message will be displayed on the MID.

▶ The gear position remains in [N] with the power mode in ACCESSORY for 15 minutes, then, it automatically changes to [P] and the power mode changes to OFF.

▶ Manually changing to [P] cancels ACCESSORY mode. The [P] indicator comes on and the power mode changes to OFF. You must always shift to [P] when car wash mode is no longer needed.

If you want to keep the transmission in [N] position [car wash mode]

The transmission may not stay in [N] position while the following indicators are on or when the message below appears:

- Malfunction indicator lamp
- Transmission system indicator
- **POWER SYSTEM** indicator
- 12-Volt battery charging system indicator
- The **Charging System Problem** message on the MID.

Continued

■ **Restriction on selecting a gear position**

You cannot select a gear position under certain circumstances that may lead to a crash.

When the transmission is in:	1. Under the circumstances of that:	2. You cannot select:	3. The gear position remains in/changes to:	How to change the gear position
P	The brake pedal is not depressed.	Other gear position	P	Release the accelerator pedal and depress the brake pedal.
	The accelerator pedal is depressed.			
N	The vehicle is moving at low speed without the brake pedal depressed.		N	
	The vehicle is moving at low speed with the accelerator pedal depressed.			
N, D or S	The vehicle is moving forward.	R		Stop your vehicle in a safe place, depress the brake pedal, and select the appropriate gear position.
R or N	The vehicle is moving backward.	D, S		
R, N, D or S	The vehicle is moving.	P		
P or N	The **READY** indicator is not on.	A gear position other than P or N	P or N	Make sure that the **READY** indicator comes on.

■ Sequential Mode

Use the paddle shifters to change between 1st and 7th gears without releasing your hands from the steering wheel. The transmission will switch to the sequential mode.

■ When the transmission is in [D]:

The vehicle will go into the sequential mode momentarily, and the sequential mode gear selection indicator will come on.

Once you start traveling at a constant speed, the sequential mode will automatically switch off, and the sequential mode gear selection indicator will go off.

Hold the [+] paddle shifter for two seconds or push the [D/S] button to return to normal drive.

■ When the transmission is in [S]

The vehicle will go into the sequential mode, and the **M** (sequential mode) indicator and sequential mode gear selection indicator will come on.

If the vehicle speed increases and the engine speed reaches near the tachometer's red zone, the transmission automatically shifts up to the next gear.


You can cancel this mode by holding the [+] paddle shifter for two seconds or push the [D/S] button. When the sequential mode is canceled, the sequential mode indicator and sequential mode gear selection indicator will turn off.

Sequential Mode

The vehicle is engine operated when SPORT+ mode is on.

Continued

■ Sequential Mode Operation



Sequential Mode Operation

Each paddle shift operation makes a single gear change.
To change gears continuously, release the paddle shifter before pulling it again for the next gear.

If the sequential mode gear selection indicator blinks when you try to shift up or down, this means your vehicle speed is not in its allowable gear range. Slightly accelerate to shift up and decelerate to shift down while the indicator is blinking.

The transmission is in S and SPORT+ mode, to prioritize the engine performance enhancement, the transmission may not allow for shifting up while the engine speed is low.


Acoustic Vehicle Alerting System

Alerts pedestrians when a vehicle is propelled solely by electricity, approaching at speeds around 12 mph (20 km/h) or less.

Integrated Dynamics System

Modifies the dynamic character of the vehicle. There are four modes to select from: **Comfort**, **Normal**, **Sport**, and **Sport+**.
Press the **Dynamic Mode** button to select a mode. The mode you have selected appears on the MID.
You can customize the mode default setting using the MID.

Customized Features P. 131, 362




When you restart the power system with **Sport+** mode, the mode is changed to **Sport** automatically.

Front Sensor Camera

The camera, used in systems such as LKAS, RDM, ACC with LSF, CMBS™, and auto high-beam, is designed to detect an object that triggers any of the systems to operate its functions.

■ Camera Location and Handling Tips



This camera is located behind the rearview mirror.

To help reduce the likelihood that high interior temperatures will cause the camera's sensing system to shut off, when parking, find a shady area or face the front of the vehicle away from the sun. If you use a reflective sun shade, do not allow it to cover the camera housing. Covering the camera can concentrate heat on it.

Front Sensor Camera

Never apply a film or attach any objects to the windshield, hood, or front grille that could obstruct the camera's field of vision and cause the system to operate abnormally.
Scratches, nicks, and other damage to the windshield within the camera's field of vision can cause the system to operate abnormally. If this occurs, we recommend that you replace the windshield with a genuine Acura replacement windshield. Making even minor repairs within the camera's field of vision or installing an aftermarket replacement windshield may also cause the system to operate abnormally. After replacing the windshield, have a dealer recalibrate the camera. Proper calibration of the camera is necessary for the system to operate properly.

Do not place an object on the top of the instrument panel. It may reflect onto the windshield and prevent the system from detecting lane lines properly.

Continued

Front Sensor Camera

If the **Some Driver Assist Systems Cannot Operate: Camera Temperature Too High** message appears:

- Use the climate control system to cool down the interior and, if necessary, also use defroster mode with the airflow directed towards the camera.
- Start driving the vehicle to lower the windshield temperature, which cools down the area around the camera.

If the **Some Driver Assist Systems Cannot Operate: Clean Front Windshield** message appears:


- Park your vehicle in a safe place, and clean the windshield. If the message does not disappear after you have cleaned the windshield and driven for a while, have your vehicle checked by a dealer.

Adaptive Cruise Control (ACC) with Low Speed Follow (LSF)

Helps maintain a constant vehicle speed and a set following-interval behind a vehicle detected ahead of yours and, if the detected vehicle comes to a stop, can decelerate and stop your vehicle, without you having to keep your foot on the brake or the accelerator.

When ACC with LSF slows your vehicle by applying the brakes, your vehicle's brake lights will illuminate.

When to use



■ Vehicle speed for ACC with LSF: **A vehicle is detected ahead within ACC with LSF range** – ACC with LSF operates at speeds up to 90 mph (145 km/h).
No vehicle is detected within ACC with LSF range – ACC with LSF operates at the speed of about 25 mph (40 km/h) or above.

■ Gear position for ACC with LSF: In D or S.

Continued

Adaptive Cruise Control (ACC) with Low Speed Follow (LSF)

⚠WARNING

Improper use of ACC with LSF can lead to a crash.

Use ACC with LSF only when driving on expressways or freeways and in good weather conditions.

⚠WARNING

ACC with LSF has limited braking capability and may not stop your vehicle in time to avoid a collision with a vehicle that quickly stops in front of you.


Always be prepared to apply the brake pedal if the conditions require.

Important Reminder

As with any system, there are limits to ACC with LSF. Use the brake pedal whenever necessary, and always keep a safe interval between your vehicle and other vehicles.

Be careful not to severely impact the radar sensor cover.

■ How to activate the system



Adaptive Cruise Control (ACC) with Low Speed Follow (LSF)

When the **MAIN** button is pressed, both ACC with LSF and the Lane Keeping Assist System (LKAS) are either turned on or off.

ACC with LSF may not work properly under certain conditions.


ACC with LSF Conditions and Limitations
P. 483

When not using ACC with LSF: Turn off adaptive cruise by pressing the **MAIN** button. This also will turn off the Lane Keeping Assist System (LKAS).


Do not use ACC with LSF under the following conditions:

- On roads with heavy traffic or while driving in continuous stop and go traffic.
- On roads with sharp turns.
- On roads with steep downhill sections, as the set vehicle speed can be exceeded by coasting. In such cases, ACC with LSF will not apply the brakes to maintain the set speed.
- On roads with toll collection facilities or other objects between lanes of traffic, or in parking areas, or facilities with drive through access.

To Set the Vehicle Speed



When driving at about 25 mph (40 km/h) or above: Take your foot off the pedal and press down the **RES/+/SET/–** switch when you reach the desired speed. The moment you release the switch, the set speed is fixed, and ACC with LSF begins.
When driving at slower than about 25 mph (40 km/h): If the vehicle is moving and the brake pedal is not depressed, pressing the switch fixes the set speed to about 25 mph (40 km/h) regardless of current vehicle speed. If your vehicle is stationary, you can set the vehicle speed even with the brake pedal depressed.



When ACC with LSF starts operating, the vehicle icon, interval bars and set speed appear on the MID.


Continued

■ When in Operation

■ There is a vehicle ahead

ACC with LSF monitors if a vehicle ahead of you enters the ACC with LSF range. If a vehicle is detected doing so, the ACC with LSF system maintains or decelerates your vehicle's set speed in order to keep the vehicle's set following-interval from the vehicle ahead.

➡ **To Set or Change Following-interval** P. 486



ACC with LSF Range: 394 ft. (120 m)




A vehicle icon appears on the MID.

When a vehicle whose speed is slower than your set speed is detected in front of you, your vehicle starts to slow down.

When in Operation

If the vehicle detected ahead of you slows down abruptly, or if another vehicle is detected cutting in front of you, the beeper sounds, a message appears on the MID, and the head-up warning lights* come on.

Depress the brake pedal, and keep an appropriate interval from the vehicle ahead.



Even if the interval between your vehicle and the vehicle detected ahead is short, ACC with LSF may start accelerating your vehicle under the following circumstances:

- The vehicle ahead of you is going at almost the same speed as, or faster than, your vehicle.
- A vehicle that cuts in front of you is going faster than your vehicle, gradually increasing the interval between the vehicles.

* Not available on all models

■ There is no vehicle ahead



A vehicle icon with dotted-line contour appears on the MID.

Your vehicle maintains the set speed without having to keep your foot on the brake or accelerator pedal.
If there previously was a vehicle detected ahead that kept your vehicle from traveling at the set speed, ACC with LSF accelerates your vehicle to the set speed, and then maintains it.

While stationary and no vehicle is detected, ACC with LSF automatically cancels and a beeper sounds.

■ When you depress the accelerator pedal

You can temporarily increase the vehicle speed. In this case, there is no audible or visual alert even if a vehicle is in the ACC with LSF range.
ACC with LSF stays on unless you cancel it. Once you release the accelerator pedal, the system resumes the set speed.
There are times when the vehicle speed will decrease when the accelerator pedal is lightly applied.

When in Operation

You can also set the system to beep when a vehicle in front of you comes in and goes out of the ACC with LSF detecting range. Change the **ACC Forward Vehicle Detect Beep** setting.

➡ **Customized Features** P. 131, 362

Limitations

You may need to use the brake to maintain a safe interval when using ACC with LSF. Additionally, ACC with LSF may not work properly under certain conditions.

➡ **ACC with LSF Conditions and Limitations** P. 483

Continued

■ A vehicle detected ahead is within ACC with LSF range and slows to a stop



Your vehicle also stops, automatically. The **Stopped** message appears on the MID. When the vehicle ahead of you starts again, the vehicle icon on the MID blinks. If you press the **RES/+/SET/–** switch up or down, or depress the accelerator pedal, ACC with LSF operates again within the prior set speed.

A vehicle detected ahead is within ACC with LSF range and slows to a stop

⚠WARNING

Exiting a vehicle that has been stopped while the ACC with LSF system is operating can result in the vehicle moving without operator control.

A vehicle that moves without operator control can cause a crash, resulting in serious injury or death.

Never exit a vehicle when the vehicle is stopped by ACC with LSF.

■ ACC with LSF Conditions and Limitations

The system may automatically shut off and the **ACC** indicator will come on under certain conditions. Some examples of these conditions are listed below. Other conditions may reduce some of the ACC functions.

➡ **Front Sensor Camera** P. 475

■ Environmental conditions

Driving in bad weather (rain, fog, snow, etc.).

■ Roadway conditions

Driving on a snowy or wet roadway (obscured lane marking, vehicle tracks, reflected lights, road spray, high contrast).

■ Vehicle conditions

- The outside of the windshield is blocked by dirt, mud, leaves, wet snow, etc.
- An abnormal tire or wheel condition (Wrong sized, varied size or construction, improperly inflated, compact spare tire*, etc.).
- The camera temperature gets too high.
- The parking brake is applied.
- When the front grille is dirty.
- The vehicle is tilted due to a heavy load or suspension modifications.
- When tire chains are installed.

ACC with LSF Conditions and Limitations

The radar sensor for ACC with LSF is shared with the Collision Mitigation Braking System™ (CMBS™).

➡ **Collision Mitigation Braking System™ (CMBS™)** P. 525

You can read about handling information for the camera equipped with this system.

➡ **Front Sensor Camera** P. 475

Always keep the radar sensor cover clean.

Never use chemical solvents or polishing powder for cleaning the sensor cover. Clean it with water or a mild detergent.

Do not put a sticker on the radar sensor cover or replace the radar sensor cover.

If you need the radar sensor to be repaired, or removed, or the radar sensor cover is strongly impacted, turn off the system by pressing the **MAIN** button and take your vehicle to a dealer.

* Not available on all models

Continued

■ Detection limitations

- A vehicle suddenly crosses in front of you.
- The interval between your vehicle and the vehicle ahead of you is too short.
- A vehicle cuts in front of you at a slow speed, and it brakes suddenly.
- When you accelerate rapidly and approach the vehicle ahead of you at high speed.
- The vehicle ahead of you is a motorcycle, bicycle, mobility scooter, or other small vehicle.
- When there are animals in front of your vehicle.
- When you drive on a curved or winding or undulating road that makes it difficult for the sensor to properly detect a vehicle in front of you.
- The speed difference between your vehicle and a vehicle in front of you is significantly large.
- An oncoming vehicle suddenly comes in front of you.
- Your vehicle abruptly crosses over in front of an oncoming vehicle.
- When driving through a narrow iron bridge.
- When the vehicle ahead of you brakes suddenly.
- When the vehicle ahead of you has a unique shape.
- When your vehicle or the vehicle ahead of you is driving on one edge of the lane.

ACC with LSF Conditions and Limitations


Have your vehicle checked by a dealer if you find any unusual behavior of the system (e.g., the warning message appears too frequently).

If the front of the vehicle is impacted in any of the following situations, the radar sensor may not work properly. Have your vehicle checked by a dealer:

- The vehicle mounted onto a bump, curb, chock, embankment, etc.
- You drive the vehicle where the water is deep.
- Your vehicle has a frontal collision.

To Adjust the Vehicle Speed

Increase or decrease the vehicle speed using the **RES/+/SET/–** switch on the steering wheel.



- Each time you press the switch up or down, the vehicle speed is increased or decreased by about 1 mph or 1 km/h accordingly.
- If you keep the switch pressed up or down, the vehicle speed increases or decreases by about 5 mph or 5 km/h accordingly.


To Adjust the Vehicle Speed

If a vehicle detected ahead is going at a speed slower than your increased set speed, ACC with LSF may not accelerate your vehicle. This is to maintain the set interval between your vehicle and the vehicle ahead.

You can switch the displayed set speed measurements on the MID between mph and km/h.
Customized Features P. 131, 362

Continued

■ To Set or Change Following-interval



Press the (interval) button to change the ACC with LSF following-interval.
Each time you press the button, the following-interval (the interval behind a vehicle detected ahead of you) setting cycles through short, middle, long, and extra long following-intervals.

Determine the most appropriate following-interval setting based on your specific driving conditions. Be sure to adhere to any following-interval requirements set by local regulation.


The higher your vehicle's following-speed is, the longer the short, middle, long or extra long following-interval becomes. See the following examples for your reference.

Following-interval		When the Set Speed is:	
		50 mph (80 km/h)	65 mph (104 km/h)
Short		83 feet 25 meters 1.1 sec	100 feet 31 meters 1.1 sec
Middle		110 feet 33 meters 1.5 sec	137 feet 42 meters 1.5 sec
Long		154 feet 47 meters 2.1 sec	200 feet 61 meters 2.1 sec
Extra Long		204 feet 62 meters 2.8 sec	265 feet 81 meters 2.8 sec

When your vehicle stops automatically because a vehicle detected ahead of you has stopped, the interval between the two vehicles will vary based on the ACC with LSF interval setting.

Continued

■ To Cancel



To cancel ACC with LSF, do any of the following:

- Press the **CANCEL** button.
- Press the **MAIN** button.
  ▶ ACC with LSF indicator goes off.
- Depress the brake pedal.
  ▶ When the LSF function has stopped the vehicle, you cannot cancel ACC with LSF by depressing the brake pedal.

To Cancel

Resuming the prior set speed: After you have canceled ACC with LSF, you can resume the prior set speed while it is still displayed.
Press the **RES/+/SET/–** switch up.

The set speed cannot be set or resumed when ACC with LSF has been turned off using the **MAIN** button. Press the **MAIN** button to activate the system, then set the desired speed.

■ Automatic cancellation

The beeper sounds and a message appears on the MID when ACC with LSF is automatically canceled. Any of these conditions may cause the ACC with LSF to automatically cancel:

- Bad weather (rain, fog, snow, etc.)
- When the radar sensor behind the emblem gets dirty.
- The vehicle ahead of you cannot be detected.
- An abnormal tire condition is detected, or the tires are skidding.
- Driving on a mountainous road, or driving off road for extended periods.
- Abrupt steering wheel movement.
- When the ABS, VSA® or CMBS™ is activated.
- When the ABS or VSA® system indicator comes on.
- When the vehicle is stopped on a very steep slope.
- When you manually apply the parking brake.
- When the detected vehicle within the ACC with LSF range is too close to your vehicle.
- When the detected vehicle goes out of the ACC with LSF range while your vehicle is stationary.
- The camera behind the rearview mirror, or the area around the camera, including the windshield, gets dirty.

The ACC with LSF automatic cancellation can be also triggered by the following causes. In these cases, the electric parking brake will be automatically applied.


- The driver's seat belt is unfastened when the vehicle is stationary.
- The vehicle stops for more than 10 minutes.
- The power system is turned off.

Automatic cancellation

Even though ACC with LSF has been automatically canceled, you can still resume the prior set speed. Wait until the condition that caused ACC with LSF to cancel improves, then press the **RES/+/SET/–** switch up.

Continued

■ To Switch ACC with LSF to Cruise Control



Press and hold the (interval) button for one second. **Cruise Mode Selected** appears on the MID for two seconds, and then the mode switches to Cruise.
To switch back to ACC with LSF, press and hold the button again for one second. **ACC Mode Selected** appears on the MID for two seconds.

■ When to use

Desired speed in a range above roughly 25 mph (40 km/h) ~.

■ To Set the Vehicle Speed

Take your foot off the pedal and press the **RES/+/SET/–** switch down when you reach the desired speed.
The moment you release the **RES/+/SET/–** switch, the set speed is fixed, and cruise control begins. The **CRUISE CONTROL** indicator comes on.

■ To Adjust the Vehicle Speed

Each time you press the **RES/+/SET/–** switch up or down, the vehicle speed is increased or decreased by about 1 mph (1.6 km/h).
If you keep the **RES/+/SET/–** switch pressed up or down, the vehicle speed increases or decreases until you release it. This speed is then set.

To Switch ACC with LSF to Cruise Control

Always be aware which mode you are in. When you are driving in Cruise mode, the system will not assist you to maintain a following-interval from a vehicle ahead of you.

You can switch the displayed set speed measurements on the MID between mph and km/h.
Customized Features P. 131, 362

To Cancel

To cancel cruise control, do any of the following:

- Press the **CANCEL** button.
- Press the **MAIN** button.
- Depress the brake pedal.

The **CRUISE CONTROL** indicator goes off.

To Cancel

Resuming the prior set speed:
After cruise control has been canceled, you can still resume the prior set speed by pressing the **RES/+/SET/–** switch up while driving at a speed of at least 25 mph (40 km/h) or more.

You cannot set or resume in the following situations:


- When vehicle speed is less than 25 mph (40 km/h).
- When the **MAIN** button is turned off.

At vehicle speeds of 22 mph (35 km/h) or less, cruise control is canceled automatically.

Road Departure Mitigation (RDM) System

Alerts and helps to assist you when the system detects a possibility of your vehicle unintentionally crossing over detected lane markings and/or leaving the roadway altogether.

■ How the System Works



The front camera behind the rearview mirror monitors left and right lane markings (in white or yellow). If your vehicle is getting too close to detected lane markings without a turn signal activated, the system, in addition to a visual alert, applies steering torque and alerts you with rapid vibrations on the steering wheel, to help you remain within the detected lane.

➢ **Customized Features** P. 131, 362

As a visual alert, the **Lane Departure** message appears on the MID.

If the system determines that its steering input is insufficient to keep your vehicle on the roadway, it may apply braking.

▶ Braking is applied only when the lane markings are solid continuous lines.

The system cancels assisting operations when you turn the steering wheel to avoid crossing over detected lane markings.

If the system operates several times without detecting driver response, the system beeps to alert you.

Road Departure Mitigation (RDM) System

Important Safety Reminder

Like all assistance systems, the RDM system has limitations.

Over-reliance on the RDM system may result in a collision. It is always your responsibility to keep the vehicle within your driving lane.

The RDM system only alerts you when lane drift is detected without a turn signal in use. The RDM system may not detect all lane markings or lane or roadway departures; accuracy will vary based on weather, speed and lane marker condition. It is always your responsibility to safely operate the vehicle and avoid collisions.

You can read about handling information for the camera equipped with this system.

➢ **Front Sensor Camera** P. 475

The RDM system may not work properly or may work improperly under the certain conditions:

➢ **RDM Conditions and Limitations** P. 495

There are times when you may not notice RDM functions due to your operation of the vehicle, or road surface conditions.

How the System Activates

The system becomes ready to start searching for lane markings when all the following conditions are met:

- The vehicle is traveling between about 45 and 90 mph (72 and 145 km/h).
- The vehicle is on a straight or slightly curved road.
- The turn signals are off.
- The brake pedal is not depressed.
- The wipers are not in continuous operation.
- The vehicle is not accelerating or braking, and the steering wheel is not being turned.
- The system makes a determination that the driver is not actively accelerating, braking or steering.

How the System Activates

The RDM system may automatically shut off and the indicator comes and stays on.


Indicators P. 99

RDM system function can be impacted when the vehicle is:

- Not driven within a traffic lane.
- Driven on the inside edge of a curve, or outside of a lane.
- Driven in a narrow lane.

Continued

■ RDM On and Off



Press the RDM button to turn the system on and off.

▶ The indicator in the button comes on and the message appears on the MID when the system is on.

RDM On and Off

When you have selected **Warning Only** from the customized options using the MID, the system does not operate the steering wheel and braking.

■ RDM Conditions and Limitations

The system may not properly detect lane markings and the position of your vehicle under certain conditions. Some examples of these conditions are listed below.

■ Environmental conditions

- Driving in bad weather (rain, fog, snow, etc.).
- Sudden changes between light and dark, such as an entrance or exit of a tunnel.
- There is little contrast between lane lines and the roadway surface.
- Driving into low sunlight (e.g., at dawn or dusk).
- Strong light is reflected onto the roadway.
- Driving in the shadows of trees, buildings, etc.
- Shadows of adjacent objects are parallel to lane markings.
- Roadway objects or structures are misinterpreted as lane markers.
- Reflections on the interior of the windshield.
- Driving at night or in a dark condition such as a tunnel.

Continued

■ **Roadway conditions**

- Driving on a snowy or wet roadway (obscured lane marking, vehicle tracks, reflected lights, road spray, high contrast).
- Driving on a road with temporary lane markings.
- Faint, multiple, or varied lane markings are visible on the roadway due to road repairs or old lane markings.
- The roadway has merging, split, or crossing lines (e.g., such as at an intersection or crosswalk).
- The lane markings are extremely narrow, wide, or changing.
- The vehicle in front of you is driving near the lane lines.
- The road is hilly or the vehicle is approaching the crest of a hill.
- Driving on rough or unpaved roads, or over bumpy surfaces.
- When objects on the road (curb, guard rail, pylons, etc.) are recognized as white lines (or yellow lines).
- Driving on roads with double lines.

■ **Vehicle conditions**

- Headlight lenses are dirty or the headlights are not properly adjusted.
- The outside of the windshield is streaked or blocked by dirt, mud, leaves, wet snow, etc.
- The inside of the windshield is fogged.
- The camera temperature gets too high.
- An abnormal tire or wheel condition (wrong sized, varied size or construction, improperly inflated, compact spare tire*, etc.).
- The vehicle is tilted due to a heavy load or suspension modifications.
- When tire chains are installed.


* Not available on all models

Lane Keeping Assist System (LKAS)

Provides steering input to help keep the vehicle in the middle of a detected lane and provides tactile and visual alerts if the vehicle is detected drifting out of its lane.

■ Steering input assist

The system applies torque to the steering to keep the vehicle between the left and right lane lines. The applied torque becomes stronger as the vehicle gets closer to either of the lane lines.



When you operate the turn signals to change lanes, the system is suspended, and resumes after the signals are off.

If you make a lane change without operating the turn signals, the LKAS alerts activate, and torque is applied to the steering.

Continued

Lane Keeping Assist System (LKAS)

Important Safety Reminders

The LKAS is for your convenience only. It is not a substitute for your vehicle control. The system does not work if you take your hands off the steering wheel or fail to steer the vehicle.

➡ **Multi-Information Display Warning and Information Messages** P. 122

Do not place objects on the instrument panel. Objects may reflect on the windshield and prevent correct detection of the traffic lanes.

The LKAS only alerts you when lane drift is detected without a turn signal in use. The LKAS may not detect all lane markings or lane departures; accuracy will vary based on weather, speed, and lane marker condition. It is always your responsibility to safely operate the vehicle and avoid collisions.

The LKAS is convenient when it is used on freeways.

The LKAS may not work properly or may work improperly under the certain conditions:

➡ **LKAS Conditions and Limitations** P. 503


You can read about handling information for the camera equipped with this system.

➡ **Front Sensor Camera** P. 475

The LKAS may not function as designed while driving in frequent stop and go traffic, or on roads with sharp curves.


■ Lane Keep Support Function

Provides assistance to keep the vehicle in the center of the lane. When the vehicle nears a white or yellow line, steering force of the electric power steering will become stronger.



■ Lane Departure Warning Function

When the vehicle enters the warning area, the LKAS alerts you with slight steering wheel vibration as well as a warning display.



Lane Keeping Assist System (LKAS)


When it fails to detect lanes, the system will temporarily be canceled. When a lane is detected, the system will recover automatically.

When the System can be Used

The system can be used when the following conditions are met.

- The lane in which you are driving has detectable lane markers on both sides, and your vehicle is in the center of the lane.
- The vehicle speed is between 45 and 90 mph (72 and 145 km/h).
- You are driving on a straight or slightly curved road.
- The turn signals are off.
- The brake pedal is not depressed.
- The wipers are not in continuous operation.

How to activate the system




1. Press the **MAIN** button.
▶ The LKAS is on in the MID.
The system is ready to use.

2. Press the LKAS button.
▶ Lane outlines appear on the MID.
The system is activated.

When the System can be Used


If the vehicle drifts toward either left or right lane line due to the system applying torque, turn off the LKAS and have your vehicle checked by a dealer.

Continued



3. Keep your vehicle near the center of the lane while driving.
▶ The dotted outer lines change to solid ones once the system starts operating after detecting the left and right lane markings.

■ To Cancel




To cancel the LKAS:
Press the **MAIN** or LKAS button.

The LKAS is turned off every time you turn the power system off, even if you turned it on the last time you drove the vehicle.

To Cancel

Pressing the **MAIN** button also turns ACC with LSF on and off.



When the LKAS is suspended, the lane lines on the MID change to contour lines, and the beeper sounds (if activated).

■ **The system operation is suspended if you:**

- Set the wipers to continuous operation.
  ▶ Turning the wipers off resumes the LKAS.
- Set the wiper switch to **AUTO** and the wipers operate continuously.
  ▶ The LKAS resumes when the wipers stop or operate intermittently.
- Decrease the vehicle speed to about 40 mph (64 km/h) or less.
  ▶ Increasing the vehicle speed to about 45 mph (72 km/h) or more resumes the LKAS.
- Depress the brake pedal.
  ▶ The LKAS resumes and starts detecting the lane lines again once you release the brake pedal.

Continued

■ **The LKAS may automatically be suspended when:**
- The system fails to detect lane lines.
- The steering wheel is quickly turned.
- You fail to steer the vehicle.
- Driving through a sharp curve.
- Driving at a speed in excess of approximately 90 mph (145 km/h).

Once these conditions no longer exist, the LKAS automatically resumes.

■ **The LKAS may automatically be canceled when:**
- The camera temperature gets extremely high or low.
- The camera behind the rearview mirror, or the area around the camera, including the windshield, gets dirty.
- The ABS or VSA® system engages.

The beeper sounds if the LKAS is automatically canceled.

■ LKAS Conditions and Limitations

The system may not detect lane markings and therefore may not keep the vehicle in the middle of a lane under certain conditions, including the following:

■ Environmental conditions

- Driving in bad weather (rain, fog, snow, etc.).
- Sudden changes between light and dark, such as an entrance or exit of a tunnel.
- There is little contrast between lane lines and the roadway surface.
- Driving into low sunlight (e.g., at dawn or dusk).
- Strong light is reflected onto the roadway.
- Driving in the shadows of trees, buildings, etc.
- Shadows of adjacent objects are parallel to lane markings.
- Roadway objects or structures are misinterpreted as lane markers.
- Reflections on the interior of the windshield.
- Driving at night or in a dark condition such as a tunnel.

Continued

■ **Roadway conditions**

- Driving on a snowy or wet roadway (obscured lane marking, vehicle tracks, reflected lights, road spray, high contrast).
- Driving on a road with temporary lane markings.
- Faint, multiple, or varied lane markings are visible on the roadway due to road repairs or old lane markings.
- The roadway has merging, split, or crossing lines (e.g., such as at an intersection or crosswalk).
- The lane markings are extremely narrow, wide, or changing.
- The vehicle in front of you is driving near the lane lines.
- The road is hilly or the vehicle is approaching the crest of a hill.
- Driving on rough or unpaved roads, or over bumpy surfaces.
- When objects on the road (curb, guard rail, pylons, etc.) are recognized as white lines (or yellow lines).
- Driving on roads with double lines.

■ **Vehicle conditions**


- Headlight lenses are dirty or the headlights are not properly adjusted.
- The outside of the windshield is streaked or blocked by dirt, mud, leaves, wet snow, etc.
- The inside of the windshield is fogged.
- The camera temperature gets too high.
- An abnormal tire or wheel condition (wrong sized, varied size or construction, improperly inflated, compact spare tire*, etc.).
- The vehicle is tilted due to a heavy load or suspension modifications.

 * Not available on all models

Vehicle Stability Assist® (VSA®), aka Electronic Stability Control (ESC), System

VSA® helps to stabilize the vehicle during cornering if the vehicle turns more or less than what was intended. It also assists in maintaining traction on slippery surfaces. It does so by regulating engine and motor output and selectively applying the brakes.

VSA® Operation



When VSA® activates, you may notice that the engine and motor do not respond to the accelerator. You may also notice some noise from the hydraulic system. You will also see the indicator blink.

Vehicle Stability Assist® (VSA®), aka Electronic Stability Control (ESC), System

The VSA® may not function properly if tire type and size are mixed. Make sure to use the same size and type of tire, and the air pressures as specified.


When the VSA® system indicator comes on and stays on while driving, there may be a problem with the system. While this may not interfere with normal driving, have your vehicle checked by a dealer immediately.

VSA® cannot enhance stability in all driving situations and does not control the entire braking system. You still need to drive and corner at speeds appropriate for the conditions and always leave a sufficient margin of safety.

The main function of the VSA® system is generally known as Electronic Stability Control (ESC). The system also includes a traction control function.

Continued

■ VSA® On and Off



This button is on the driver side control panel. To partially disable VSA® functionality/ features, press and hold it until you hear a beep.

Your vehicle will have normal braking and cornering ability, but traction control function will be less effective.

To restore VSA® functionality/features, press the OFF (VSA® OFF) button until you hear a beep.

VSA® is turned on every time you turn the power system on, even if you turned it off the last time you drove the vehicle.

Vehicle Stability Assist® (VSA®), aka Electronic Stability Control (ESC), System

In certain unusual conditions when your vehicle gets stuck in shallow mud or fresh snow, it may be easier to free it with the VSA® temporarily switched off.

When the OFF button is pressed, the traction control function becomes less effective. This allows for the wheels to spin more freely at low speed. You should only attempt to free your vehicle with the VSA® off if you are not able to free it when the VSA® is on.

Immediately after freeing your vehicle, be sure to switch VSA® on again. We do not recommend driving your vehicle with the VSA® system switched off.

You may hear a motor sound coming from the engine compartment while system checks are being performed immediately after turning the power system on or while driving. This is normal.

Agile Handling Assist

Lightly brakes each of the front and rear wheels, as needed, when you turn the steering wheel, and helps support the vehicle's stability and performance during cornering.

Agile Handling Assist

The agile handling assist cannot enhance stability in all driving situations. You still need to drive and corner at speeds appropriate for the conditions and always leave a sufficient margin of safety.

When the VSA® system indicator comes on and stays on while driving, the agile handling assist does not activate.

You may hear a sound coming from the engine compartment while the agile handling assist is activated. This is normal.

SPORT HYBRID Super Handling-All Wheel Drive™ (SPORT HYBRID SH-AWD®)

The system controls and transfers varying amounts of motor and/or engine torque to each wheel in accordance with the driving conditions.

SPORT HYBRID SH-AWD® helps to enhance driving stability, and lets you handle situations like slippery surfaces, such as snow, sand, mud, and steep hills, better than when driving with standard two wheel drive. However, the system does not help to enhance braking. Be cautious about the following:

- It is still your responsibility to drive safely when you steer, accelerate, and apply brakes.
- Leave a sufficient margin when braking on slippery surfaces.

SPORT HYBRID Super Handling-All Wheel Drive™ (SPORT HYBRID SH-AWD®)

Do not drive through deep water.

The SPORT HYBRID SH-AWD® system may not function properly if tire type and size are mixed. Make sure to use the same size and type of tire, and the air pressures as specified.

Tire and Wheel Replacement P. 597

Blind spot information System


Is designed to detect vehicles in specified alert zones adjacent to your vehicle, particularly in harder to see areas commonly known as "blind spots."

When the system detects vehicles approaching from behind in adjacent lanes, the appropriate indicator comes on for a few seconds, providing assistance when you change lanes.

■ How the system works

- The transmission is in D or S.
- Your vehicle speed is between 20 mph (32 km/h) and 100 mph (160 km/h)

Alert zone range
A: Approx. 1.6 ft. (0.5 m)
B: Approx. 10 ft. (3 m)
C: Approx. 10 ft. (3 m)



Blind spot information System

⚠WARNING

Failure to visually confirm that it is safe to change lanes before doing so may result in a crash and serious injury or death.
Do not rely only on the blind spot information system when changing lanes.


Always look in your mirrors, to either side of your vehicle, and behind you for other vehicles before changing lanes.

Important Safety Reminder
Like all assistance systems, blind spot information system has limitations. Over reliance on blind spot information system may result in a collision.

The blind spot information system alert indicator may not come on under the following conditions:
- A vehicle does not stay in the alert zone for more than two seconds.
- A vehicle is parked in a side lane.
- The speed difference between your vehicle and the vehicle you are passing is greater than 6 mph (10 km/h).
- An object not detected by the radar sensors approaches or passes your vehicle.
- A vehicle running in the adjacent lane is a motorcycle or other small vehicle.

Continued

■ When the system detects a vehicle



Blind spot information System Alert Indicator: Located near the pillar on both sides.

Comes on when:

- A vehicle enters the alert zone from behind to overtake you with a speed difference of no more than 31 mph (50 km/h) from your vehicle.
- You pass a vehicle with a speed difference of no more than 12 mph (20 km/h).

Blinks and a beeper sounds when:

You move the turn signal lever in the direction of the detected vehicle. The beeper sounds three times.

Blind spot information System

The system is for your convenience only. Even if an object is within the alert zone, the following situations may occur.

- The blind spot information system alert indicator may not come on due to obstruction (splashes, etc.) even without the **Blind Spot Info Not Available** MID appearing.
- The blind spot information system alert indicator may come on even with the message appearing.

The system does not operate when in R.

You can turn off the audible alert, or all the blind spot information system alert using the information screen or MID.

➡ **Customizable Features** P. 134, 362

Blind spot information system may be adversely affected when:


- Objects (guard rails, poles, trees, etc,.) are detected.
- An object that does not reflect radio waves well, such as a motorcycle, is in the alert zone.
- Driving on a curved road.
- A vehicle is moving from a far lane to the adjacent lane.
- The system picks up external electrical interference.
- The rear bumper or the sensors have been improperly repaired or the rear bumper has been deformed.
- The orientation of the sensors has been changed.
- In bad weather (Heavy rain, snow, and fog).

Blind spot information System

For a proper blind spot information system operation:

- Always keep the rear bumper corner area clean.
- Do not cover the rear bumper corner area with labels or stickers of any kind.
- Take your vehicle to a dealer if you need the rear bumper corner area or the radar sensors to be repaired, or the rear bumper corner area is strongly impacted.

Tire Pressure Monitoring System (TPMS) with Tire Fill Assist



Monitors the tire pressure while you are driving. If your vehicle's tire pressure becomes significantly low, the low tire pressure/TPMS indicator comes on and a message appears on the MID.

Tire Pressure Monitoring System (TPMS) with Tire Fill Assist

Conditions such as low ambient temperature and altitude change directly affect tire pressure and can trigger the low tire pressure/TPMS indicator to come on.

If the Low Tire Pressure/TPMS Indicator Comes On or Blinks P. 645

Tire pressure checked and inflated in:

- Warm weather can become under-inflated in colder weather.
- Cold weather can become over-inflated in warmer weather.

The low tire pressure/TPMS indicator will not come on as a result of over inflation.

The TPMS audibly and visually informs you of changes in tire pressure of the individual tire that you are adjusting using audible and visual indications.

If a change in tire pressure has been significant, the system beeps and the hazard lights flash continuously for five seconds when the specified tire pressure is reached. Stop filling the tire.

Tire Pressure Monitor



To select the tire pressure monitor, set the power mode to ON, and roll the multi-function steering-wheel controls until you see the tire pressure screen.

The pressure for each tire is displayed in psi (U.S.) or kPa (Canada).



Tire Pressures Low is displayed when a tire has significantly low pressure. The specific tire is displayed on the screen.

Tire Pressure Monitor

The pressure displayed on the MID can be slightly different from the actual pressure as measured by a gauge. If there is a significant difference between the two values, or if the low tire pressure/TPMS indicator and the message on the MID do not go off after you have inflated the tire to the specified pressure, have the system checked by a dealer.

Tire Pressure Monitor Problem may appear if you drive with the compact spare tire*, or there is a problem with the TPMS.

* Not available on all models

Tire Pressure Monitoring System (TPMS) - Required Federal Explanation

Each tire, including the spare (if provided), should be checked monthly when cold and inflated to the inflation pressure recommended by the vehicle manufacturer on the vehicle placard or tire inflation pressure label.

(If your vehicle has tires of a different size than the size indicated on the vehicle placard or tire inflation pressure label, you should determine the proper tire inflation pressure for those tires.)

As an added safety feature, your vehicle has been equipped with a tire pressure monitoring system (TPMS) that illuminates a low tire pressure telltale



when one or more of your tires is significantly under-inflated.

Accordingly, when the low tire pressure telltale illuminates, you should stop and check your tires as soon as possible, and inflate them to the proper pressure.

Driving on a significantly under-inflated tire causes the tire to overheat and can lead to tire failure. Under-inflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability.

Please note that the TPMS is not a substitute for proper tire maintenance, and it is the driver's responsibility to maintain correct tire pressure, even if under-inflation has not reached the level to trigger illumination of the TPMS low tire pressure telltale.

Your vehicle has also been equipped with a TPMS malfunction indicator to indicate when the system is not operating properly. The TPMS malfunction indicator is combined with the low tire pressure telltale. When the system detects a malfunction, the telltale will flash for approximately one minute and then remain continuously illuminated. This sequence will continue upon subsequent vehicle start-ups as long as the malfunction exists.

When the malfunction indicator is illuminated, the system may not be able to detect or signal low tire pressure as intended.

TPMS malfunctions may occur for a variety of reasons, including the installation of replacement or alternate tires or wheels on the vehicle that prevent the TPMS from functioning properly.

Always check the TPMS malfunction telltale after replacing one or more tires or wheels on your vehicle to ensure that the replacement or alternate tires and wheels allow the TPMS to continue to function properly.

High Voltage Battery


The High Voltage battery gradually discharges when the vehicle is not in use. As a result, if your vehicle is parked for an extended period of time, the battery level may get low. Keeping your vehicle's battery level low can shorten the battery life. To maintain the battery, drive your vehicle for more than 30 minutes to recharge the battery at least once every three months.

To help maintain the battery life, when parking under the direct sunlight during summer, try find a shaded area.

Brake System

■ Parking Brake

Use the parking brake to keep the vehicle stationary when parked. When the parking brake is applied, you can manually or automatically release it.



■ To apply

The electric parking brake can be applied any time the vehicle has battery, no matter which position the power mode is in.

Press the electric parking brake switch gently and securely.

▶ The electric parking brake indicator comes on.

Brake System

When you depress the brake pedal, you may hear a whirring sound from the engine compartment. This is because the brake system is in operation, and it is normal.

Parking Brake

You may hear the electric parking brake system motor operating from the rear wheel area when you apply or release the parking brake. This is normal.


The brake pedal may slightly move due to the electric parking brake system operation when you apply or release the parking brake. This is normal.

You cannot apply or release the parking brake if the 12-volt battery goes dead.

➡ **Jump Starting** P. 637

If you press and hold the electric parking brake switch while driving, the brakes on all four wheels are applied by the VSA® system until the vehicle comes to a stop. The electric parking brake then applies, and the switch should be released.

Continued



■ To release

The power mode must be in ON in order to release the electric parking brake.

1. Depress the brake pedal.

2. Pull the electric parking brake switch up.
▶ The electric parking brake indicator goes off.

Manually releasing the parking brake using the switch helps your vehicle start slowly and smoothly when facing down hill on steep hills.


Parking Brake

In the following situations, the parking brake automatically operates.

- When the vehicle stops more than 10 minutes while ACC with LSF is activated.
- When the driver's seat belt is unfastened while your vehicle is stopped automatically by ACC with LSF.
- When the power system is turned off while ACC with LSF is activated.
- When the vehicle stops with the automatic brake hold system activated for more than 10 minutes.
- When the driver's seat belt is unfastened while your vehicle is stopped and automatic brake hold is applied.
- When the power system is turned off while automatic brake hold is applied.
- When there is a problem with the Automatic Brake Hold System while automatic brake hold is applied.

■ To release automatically

Depressing the accelerator pedal releases the parking brake.
Use the accelerator pedal to release the brake when you are starting the vehicle facing uphill, or in a traffic jam.


Accelerator Pedal

Gently depress the accelerator pedal.
When on a hill, it may require more accelerator input to release.

▶ The electric parking brake indicator goes off.

You can release the parking brake automatically when:

- You are wearing the driver's seat belt.
- The power system is on.
- The transmission is not in P or N.

Parking Brake

If the parking brake cannot be released automatically, release it manually.

When the vehicle is traveling uphill, the accelerator pedal may need to be pressed farther to automatically release the electric parking brake.

The parking brake cannot be released automatically while the following indicators are on:

- Malfunction indicator lamp
- Transmission system indicator

The parking brake may not be released automatically while the following indicators are on:

- Electric parking brake system indicator
- VSA® system indicator
- **ABS** indicator
- Supplemental restraint system indicator

Continued

■ Foot Brake

Your vehicle is equipped with disc brakes at all four wheels. The brake assist system increases the stopping force when you depress the brake pedal hard in an emergency situation. The anti-lock brake system (ABS) helps you retain steering control when braking very hard.

➡ **Brake Assist System** P. 524
➡ **Anti-lock Brake System (ABS)** P. 523

Foot Brake

Check the brakes after driving through deep water, or if there is a buildup of road surface water. If necessary, dry the brakes by lightly depressing the pedal several times.

If you hear a continuous metallic friction sound when applying the brakes, this is caused by the brake wear indicator rubbing on the brake rotor and indicates that the brake pads need to be replaced. Have the vehicle checked by a dealer. If you hear only an occasional squeak or squeal when you initially apply the brake pedal, this may be normal and caused by high frequency vibration of the brake pads against the rotating brake disc.

Constantly using the brake pedal while going down a long hill builds up heat, which reduces the brake effectiveness. Apply regenerative braking by taking your foot off the accelerator pedal and downshifting to a lower gear.

Do not rest your foot on the brake pedal while driving, as it will lightly apply the brakes and cause them to lose effectiveness over time and reduce pad life. It will also confuse drivers behind you.

■ Automatic Brake Hold

Keeps the brake applied after releasing the brake pedal until the accelerator pedal is pressed. You can use this system while the vehicle is temporarily stopped, like at traffic lights and in heavy traffic.

■ Turning on the system




Automatic Brake Hold Button

Fasten your seat belt properly, then start the power system. Press the automatic brake hold button.

- The automatic brake hold system indicator comes on. The system is turned on.

■ Activating the system




Brake Pedal

Depress the brake pedal to come to a complete stop. The transmission must be in D, S or N.

- The automatic brake hold indicator comes on. Braking is kept for up to 10 minutes.
- Release the brake pedal after the automatic brake hold indicator comes on.

■ Canceling the system



Accelerator Pedal

Depress the accelerator pedal while the transmission is in D or S. The system is canceled and the vehicle starts to move.

- The automatic brake hold indicator goes off. The system continues to be on.

Automatic Brake Hold

⚠WARNING

Activating the automatic brake hold system on steep hills or slippery roads may still allow the vehicle to move if you remove your foot from the brake pedal.

If a vehicle unexpectedly moves, it may cause a crash resulting in serious injury or death.

Never activate the automatic brake hold system or rely on it to keep a vehicle from moving when stopped on a steep hill or slippery roads.

⚠WARNING

Using the automatic brake hold system to park the vehicle may result in the vehicle unexpectedly moving.

If a vehicle moves unexpectedly, it may cause a crash, resulting in serious injury or death.


Never leave the vehicle when braking is temporarily kept by automatic brake hold and always park the vehicle by putting the transmission in P and applying the parking brake.

Continued

■ **The system automatically cancels when:**
- You depress the brake pedal and change to P or R.
- You engage the parking brake.

■ **The system automatically cancels and the parking brake is applied when:**
- Braking is kept for more than 10 minutes.
- The driver's seat belt is unfastened.
- The power system is turned off.
- There is a problem with automatic brake hold system.

■ **Turning off the automatic brake hold system**



While the system is on, press the automatic brake hold button again.

▶ The automatic brake hold system indicator goes off.

If you want to turn off automatic brake hold while the system is in operation, press the automatic brake hold button with the brake pedal depressed.

Automatic Brake Hold

While the system is activated, you can turn off the power system or park the vehicle through the same procedure as you normally do.

When Stopped P. 534

Whether the system is on, or the system is activated, the automatic brake hold turns off once the power system is off.

Turning off the automatic brake hold system

Make sure to turn off the automatic brake hold system before using an automated car wash.

You may hear an operating noise if the vehicle moves while the automatic brake hold system is in operation.

Anti-lock Brake System (ABS)

■ ABS

Helps prevent the wheels from locking up, and helps you retain steering control by pumping the brakes rapidly, much faster than you.

The electronic brake distribution (EBD) system, which is part of the ABS, also balances the front-to-rear braking distribution according to vehicle loading.

You should never pump the brake pedal. Let the ABS work for you by always keeping firm, steady pressure on the brake pedal. This is sometimes referred to as "stomp and steer."

■ ABS operation

You may hear an operating noise when the ABS is working. Depress the brake pedal and keep holding the pedal firmly down. On dry pavement, you will need to press on the brake pedal very hard before the ABS activates. However, you may feel the ABS activate immediately if you are trying to stop on snow or ice.

ABS may activate when you depress the brake pedal when driving on:
- Wet or snow covered roads.
- Roads paved with stone.
- Roads with uneven surfaces, such as potholes, cracks, manholes, etc.

When the vehicle speed goes under 6 mph (10 km/h), the ABS stops.

Anti-lock Brake System (ABS)

NOTICE

The ABS may not function correctly if you use a tire of the wrong size or type.

If the **ABS** indicator comes on while driving, there may be a problem with the system.
While normal braking will not be affected, there is a possibility that the ABS will not be operating. Have your vehicle checked by a dealer immediately.

The ABS is not designed for the purpose of reducing the time or distance it takes for a vehicle to stop: It is designed to limit brake lockup which can lead to skidding and loss of steering control.

In the following cases, your vehicle may need more distance to stop than a vehicle without the ABS:
- You are driving on rough or uneven road surfaces, such as gravel or snow.
- The tires are equipped with tire chains.

The following may be observed with the ABS system:
- Motor sounds coming from the engine compartment when the brakes are applied, or when system checks are being performed after the power system has been turned on and while the vehicle accelerates.
- Brake pedal and/or the vehicle body vibration when ABS activates.

These vibrations and sounds are normal to ABS systems and are no cause for concern.

Brake Assist System

Designed to assist the driver by generating greater braking force when you depress the brake pedal hard during emergency braking.

■ Brake assist system operation


Press the brake pedal firmly for more powerful braking.

Collision Mitigation Braking System™ (CMBS™)

Can assist you when there is a possibility of your vehicle colliding with a vehicle or a pedestrian detected in front of yours. The CMBS™ is designed to alert you when a potential collision is determined, as well as to reduce your vehicle speed to help minimize collision severity when a collision is deemed unavoidable.

■ How the system works

When to use



The system starts monitoring the roadway ahead when your vehicle speed is about 3 mph (5 km/h) and there is a vehicle in front of you.

The CMBS™ activates when:
- The speed difference between your vehicle and a vehicle or pedestrian detected in front of you becomes about 3 mph (5 km/h) and over with a chance of a collision.
- Your vehicle speed is about 62 mph (100 km/h) or less and there is a chance of a collision with an oncoming detected vehicle or a pedestrian in front of you.

Continued

Collision Mitigation Braking System™ (CMBS™)

Important Safety Reminder
The CMBS™ is designed to reduce the severity of an unavoidable collision. It does not prevent a collision nor stop the vehicle automatically. It is still your responsibility to operate the brake pedal and steering wheel appropriately according to the driving conditions.

The CMBS™ may not activate or may not detect a vehicle in front of your vehicle under certain conditions:
➡ **CMBS™ Conditions and Limitations** P. 529

You can read about handling information for the camera equipped with this system.
➡ **Front Sensor Camera** P. 475

Be careful not to severely impact the radar sensor cover.

How the system works


Rapid vibrations on the steering wheel alert you when your vehicle speed is between 19 and 62 mph (30 and 100 km/h) with an oncoming vehicle detected in front of you.

When the CMBS™ activates, it may automatically apply the brake. It will be canceled when your vehicle stops or a potential collision is not determined.

■ When the system activates

The system provides visual, audible and tactile alerts of a possible collision, and stops if the collision is avoided.

▶ Take appropriate action to prevent a collision (apply the brakes, change lanes, etc.)



At system's earliest collision alert stage, you can change the distance (**Long**/**Normal**/**Short**) between vehicles at which alerts will come on through MID setting options.

➡ **List of customizable options** P. 134, 362

■ Vibration alert on the steering wheel

When a potential collision to an oncoming detected vehicle is determined, the system alerts you with rapid vibration on the steering wheel, in addition to visual and audible alerts.


▶ Take appropriate action to prevent a collision (apply the brakes, operate the steering wheel, etc.).

When the system activates

The camera in the CMBS™ is also designed to detect pedestrians.
However, this pedestrian detection feature may not activate or may not detect a pedestrian in front of your vehicle under certain conditions.
Refer to the ones indicating the pedestrian detection limitations from the list.

➡ **CMBS™ Conditions and Limitations** P. 529

The head-up warning* uses a lens located at the front end of the dashboard.
Do not cover the lens or spill any liquid on it.



Vibration alert on the steering wheel



Vibration alert function is disabled when the electric power steering (EPS) system indicator comes on.

➡ **Speed-sensitive Electric Power Steering (EPS) System Indicator** P. 95


* Not available on all models

■ Collision Alert Stages

The system has three alert stages for a possible collision. However, depending on circumstances, the CMBS™ may not go through all of the stages before initiating the last stage.

Distance between vehicles		CMBS™			
		The sensors detect a vehicle	Audible & Visual WARNINGS	Steering Wheel	Braking
Stage one		There is a risk of a collision with the vehicle ahead of you.	When in **Long**, visual and audible alerts come on at a longer distance from a vehicle ahead than in **Normal** setting, and in **Short**, at a shorter distance than in **Normal**.	In case of an oncoming vehicle detected, rapid vibration is provided.	—
Stage two		The risk of a collision has increased, time to respond is reduced.	Visual and audible alerts.	—	Lightly applied
Stage three		The CMBS™ determines that a collision is unavoidable.			Forcefully applied

■ CMBS™ On and Off



Press and hold the button until the beeper sounds to switch the system on or off.

When the CMBS™ is off:

- The CMBS™ indicator in the instrument panel comes on.
- A message on the MID reminds you that the system is off.

The CMBS™ is turned on every time you start the power system, even if you turned it off the last time you drove the vehicle.

Collision Mitigation Braking System™ (CMBS™)

The CMBS™ may automatically shut off, and the CMBS™ indicator will come and stay on under certain conditions:

CMBS™ Conditions and Limitations P. 529

■ CMBS™ Conditions and Limitations

The system may automatically shut off and the CMBS™ indicator will come on under certain conditions. Some examples of these conditions are listed below. Other conditions may reduce some of the CMBS™ functions.

➡ **Front Sensor Camera** P. 475

■ Environmental conditions

- Driving in bad weather (rain, fog, snow, etc.).
- Sudden changes between light and dark, such as an entrance or exit of a tunnel.
- There is little contrast between objects and the background.
- Driving into low sunlight (e.g., at dawn or dusk).
- Strong light is reflected onto the roadway.
- Driving in the shadows of trees, buildings, etc.
- Roadway objects or structures are misinterpreted as vehicles and pedestrians.
- Reflections on the interior of the windshield.
- Driving at night or in a dark condition such as a tunnel.

■ Roadway conditions

- Driving on a snowy or wet roadway (obscured lane marking, vehicle tracks, reflected lights, road spray, high contrast).
- The road is hilly or the vehicle is approaching the crest of a hill.
- Driving on curvy, winding, or undulating roads.

CMBS™ Conditions and Limitations

Have your vehicle checked by a dealer if you find any unusual behavior of the system (e.g., the warning message appears too frequently).

If the front of the vehicle is impacted in any of the following situations, the radar sensor may not work properly. Have your vehicle checked by a dealer:

- The vehicle mounted onto a bump, curb, chock, embankment, etc.
- You drive the vehicle where the water is deep.
- Your vehicle has a frontal collision.

If you need the radar sensor to be repaired, or removed, or the radar sensor cover is strongly impacted, turn off the system by pressing the CMBS™ off button and take your vehicle to a dealer.

Continued

■ **Vehicle conditions**

- Headlight lenses are dirty or the headlights are not properly adjusted.
- The outside of the windshield is blocked by dirt, mud, leaves, wet snow, etc.
- The inside of the windshield is fogged.
- An abnormal tire or wheel condition (wrong sized, varied size or construction, improperly inflated, compact spare tire*, etc.).
- When tire chains are installed.
- The vehicle is tilted due to a heavy load or suspension modifications.
- The camera temperature gets too high.
- Driving with the parking brake applied.
- When the radar sensor behind the emblem gets dirty.

 * Not available on all models

■ **Detection limitations**

- A vehicle or pedestrian suddenly crosses in front of you.
- The distance between your vehicle and the vehicle or pedestrian ahead of you is too short.
- A vehicle cuts in front of you at a slow speed, and it brakes suddenly.
- When you accelerate rapidly and approach the vehicle or pedestrian ahead of you at high speed.
- The vehicle ahead of you is a motorcycle, bicycle, mobility scooter or other small vehicle.
- When there are animals in front of your vehicle.
- When you drive on a curved, winding or undulating road that makes it difficult for the sensor to properly detect a vehicle in front of you.
- The speed difference between your vehicle and a vehicle or pedestrian in front of you is significantly large.
- An oncoming vehicle suddenly comes in front of you.
- Another vehicle suddenly comes in front of you at an intersection, etc.
- Your vehicle abruptly crosses over in front of an oncoming vehicle.
- When driving through a narrow iron bridge.
- When the lead vehicle suddenly slows down.

Continued

Limitations applicable to pedestrian detection only

- When there is a group of people in front of your vehicle walking together side by side.
- Surrounding conditions or belongings of the pedestrian alter the pedestrian's shape, preventing the system from recognizing that the person is a pedestrian.
- When the pedestrian is shorter than about 3.3 feet (1 meter) or taller than about 6.6 feet (2 meters) in height.
- When a pedestrian blends in with the background.
- When a pedestrian is bent over or squatting, or when their hands are raised or they are running.
- When several pedestrians are walking ahead in a group.
- When the camera cannot correctly identify that a pedestrian is present due to an unusual shape (holding luggage, body position, size).

■ Automatic shutoff

The CMBS™ may automatically shut itself off and the CMBS™ indicator comes and stays on when:

- The temperature inside the system is high.
- You drive off-road or on a mountain road, or curved and winding road for an extended period.
- An abnormal tire condition is detected (wrong tire size, flat tire, etc.).
- The camera behind the rearview mirror, or the area around the camera, including the windshield, gets dirty.

Once the conditions that caused the CMBS™ to shut off improve or are addressed (e.g., cleaning), the system comes back on.

■ With Little Chance of a Collision

The CMBS™ may activate even when you are aware of a vehicle ahead of you, or when there is no vehicle ahead. Some examples of this are:

■ When Passing
Your vehicle approaches another vehicle ahead of you and you change lanes to pass.

■ At an intersection
Your vehicle approaches or passes another vehicle that is making a left or right turn.

■ On a curve
When driving through curves, your vehicle comes to a point where an oncoming vehicle is right in front of you.

■ Through a low bridge at high speed
You drive under a low or narrow bridge at high speed.

■ Speed bumps, road work sites, train tracks, roadside objects, etc.
You drive over speed bumps, steel road plates, etc., or your vehicle approaches train tracks or roadside objects [such as a traffic sign and guard rail] on a curve or, when parking, stationary vehicles and walls.

Collision Mitigation Braking System™ (CMBS™)

For the CMBS™ to work properly:

Always keep the radar sensor cover clean.

Never use chemical solvents or polishing powder for cleaning the sensor cover. Clean it with water or a mild detergent.

Do not put a sticker on the radar sensor cover or replace the radar sensor cover.

Do not paint, or apply any coverings or paint to radar sensor area. This can impact CMBS™ operation.

When Stopped

1. Depress the brake pedal firmly.
2. With the brake pedal depressed, press the electric parking brake switch slowly, but fully.
3. Change the gear position to P.
4. Turn off the power system.
   The electric parking brake indicator goes off in about 15 seconds.

Parking Your Vehicle

⚠WARNING

The vehicle can roll away if left unattended without confirming that Park is engaged.

A vehicle that rolls away could cause a crash resulting in serious injury or death.

Always keep your foot on the brake pedal until you have confirmed that P is shown on the gear position Indicator.

Do not park your vehicle near flammable objects, such as dry grass, oil, or timber.
Heat from the exhaust can cause a fire.

When Stopped

NOTICE

The following can damage the transmission:

- Depressing the accelerator and brake pedals simultaneously.
- Holding the vehicle in place when facing uphill by depressing the accelerator pedal or creeping.
  ➔ **Creeping** P. 464
- Changing to P before the vehicle stops completely.

Always confirm the electric parking brake is set, particularly if you are parked on an incline.

If during in Auto Engine Stop, the gear position changes to P and the engine restarts automatically under the following conditions:

- The power system is on.
- The gear position is not in P.
- You unfasten the driver side seat belt and open the door.


When Stopped

In extremely cold temperatures, the parking brake may freeze up if applied. If such temperatures are expected, do not apply the parking brake but, if parking on a slope, either turn the front wheels so they will contact the curb if the vehicle rolls down the slope or block the wheels to keep the vehicle from moving. If you do not take either precaution, the vehicle may roll unexpectedly, leading to a crash.

Parking Sensor System

The corner and center sensors monitor obstacles near your vehicle, and the beeper and information screen let you know the approximate distance between your vehicle and the obstacle.

■ The sensor location and range



Parking Sensor System


Even when the system is on, always confirm if there is no obstacle near your vehicle before parking.

The system may not work properly when:
- The sensors are covered with snow, ice, mud or dirt.
- The vehicle is on uneven surface, such as grass, bumps, or a hill.
- The vehicle has been out in hot or cold weather.
- The system is affected by devices that emit ultrasonic waves.
- Driving in bad weather.

The system may not sense:
- Thin or low objects.
- Sonic-absorptive materials, such as snow, cotton, or sponge.
- Objects directly under the bumper.

Do not put any accessories on or around the sensors.

■ Parking sensor system on and off




With the power mode in ON, press the parking sensor system button to turn on or off the system. The indicator in the button comes on when the system is on.

The rear center and corner sensors and the front corner sensors start to detect an obstacle when the transmission is in R, and the vehicle speed is less than 5 mph (8 km/h).

The front center and corner sensors start to detect an obstacle when the transmission is not in P or R, and the vehicle speed is less than 5 mph (8 km/h).

Continued

■ **When the distance between your vehicle and obstacles becomes shorter**

Length of the intermittent beep	Distance between the Bumper and Obstacle		Indicator	Information Screen
	Corner Sensors	Center Sensors		
Moderate	—	Rear: About 45-28 in (115-70 cm) Front: About 39-28 in (100-70 cm)	Blinks in Yellow*1	 Indicators light where the sensor detects an obstacle.
Short	About 28-18 in (70-45 cm)	About 28-18 in (70-45 cm)	Blinks in Amber	
Very short	About 18-14 in (45-35 cm)	About 18-14 in (45-35 cm)		
Continuous	About 14 in (35 cm) or less	About 14 in (35 cm) or less	Blinks in Red	

*1: At this stage, only the center sensors detect obstacles.

■ Turning off All Rear Sensors

1. Make sure that the parking sensor system is not activated. Set the power mode to VEHICLE OFF (LOCK).
2. Press and hold the parking sensor system button, and set the power mode to ON.
3. Keep pressing the button for 10 seconds. Release the button when the indicator in the button flashes.
4. Press the button again. The indicator in the button goes off.
▶ The beeper sounds twice. The rear sensors are now turned off.

To turn the rear sensors on again, follow the above procedure. The beeper sounds three times when the rear sensors come back on.

Turning off All Rear Sensors

When you set the gear position to R, the indicator in the parking sensor system button blinks as a reminder that the rear sensors have been turned off.

Cross Traffic Monitor

Monitors the rear corner areas using the radar sensors when reversing, and alerts you if a vehicle approaching from a rear corner is detected.

The system is convenient when you are backing out of a parking space.

Cross Traffic Monitor


⚠CAUTION

Cross Traffic Monitor cannot detect all approaching vehicles and may not detect an approaching vehicle at all.

Failure to visually confirm that it is safe to back up the vehicle before doing so may result in a collision.

Do not solely rely on the system when reversing; always also use your mirrors, and look behind and to the sides of your vehicle before reversing.

How the System Works



Radar sensors:
Underneath the rear bumper corners

The system activates when:

- The power mode is in ON.
- The Cross Traffic Monitor is turned on.
  Cross Traffic Monitor On and Off P. 543
- The transmission is in R.
- Your vehicle is moving at 3 mph (5 km/h) or lower.

When a vehicle is detected approaching from a rear corner, Cross Traffic Monitor alerts you with a buzzer and a displayed warning.

The system will not detect a vehicle that approaches from directly behind your vehicle, nor will it provide alerts about a detected vehicle when it moves directly behind your vehicle.

The system does not provide alerts for a vehicle that is moving away from your vehicle, and it may alert for pedestrians, bicycles, or stationary objects.

Cross Traffic Monitor

Cross Traffic Monitor may not detect or may delay alerting an approaching vehicle, or may alert without an approaching vehicle under the following conditions:

- An obstacle, such as another vehicle and a wall, near your vehicle's rear bumper, is blocking the radar sensor's scope.
- Your vehicle is moving at the speed of about 3 mph (5 km/h) or higher.
- A vehicle is approaching at the speed other than between about 6 mph (10 km/h) and 16 mph (25 km/h).
- The system picks up external interference such as other radar sensors from another vehicle or strong radio wave transmitted from a facility nearby.
- Either corner of the rear bumper is covered with snow, ice, mud or dirt.
- When there is bad weather.
- Your vehicle is on an incline.
- Your vehicle is tilted due to a heavy load in the rear.
- Your vehicle is reversing towards a wall, a pole, a vehicle, and so on.


The rear bumper or the sensors have been improperly repaired or the rear bumper has been deformed. Have your vehicle checked by a dealer.

For proper operation, always keep the rear bumper corner area clean.
Do not cover the rear bumper corner area with labels or stickers of any kind.


Continued

■ When the System Detects a Vehicle

Models with multi-view rear camera system



Models with surround view camera system



An arrow icon appears on the side a vehicle is approaching on the information screen.

Cross Traffic Monitor

The parking sensor system's alerting buzzer overrides the Cross Traffic Monitor buzzer when the sensors are detecting obstacles at the closest range.


When the System Detects a Vehicle

If the on the lower right changes to in amber when the transmission is in R, mud snow or ice, etc. may have accumulated in the vicinity of the sensor. The system is temporarily canceled. Check the bumper corners for any obstructions, and thoroughly clean the area if necessary.

If the comes on when the transmission is in R, there may be a problem with the Cross Traffic Monitor system. Do not use the system and have your vehicle checked by a dealer.

If the display remains the same with the transmission in R, there may be a problem with the rear camera system and the Cross Traffic Monitor system.
Do not use the system and have your vehicle checked by a dealer.

■ Cross Traffic Monitor On and Off




You can switch on and off the system using the information screen.

➔ **Customized Features** P. 362

About Your Multi-View Rear Camera

The information screen can display your vehicle's rear view. The display automatically changes to the rear view when the transmission is put into R.

■ Multi-View Rear Camera Display Area



About Your Multi-View Rear Camera

The rear camera view is restricted. You cannot see the corner ends of the bumper or what is underneath the bumper. Its unique lens also makes objects appear closer or farther than they actually are.

Visually confirm that it is safe to drive before backing up. Certain conditions (such as weather, lighting, and high temperatures) may also restrict the rear view. Do not rely on the rearview display which does not give you all information about conditions at the back of your vehicle.

If the camera lens is covered with dirt or moisture, use a soft, moist cloth to keep the lens clean and free of debris.

You can change the **Fixed Guideline** and **Dynamic Guideline** settings.

➡ **Customized Features** P. 362

Fixed Guideline
On: Guidelines appear when you put the transmission into R.
Off: Guidelines do not appear.
Dynamic Guideline
On: Guidelines move according to the steering wheel direction.
Off: Guidelines do not move.

 * Not available on all models

You can view three different camera modes on the rearview display. Press the selector knob to switch the mode.

 : Wide view mode

 : Normal view mode

 : Top down view mode

- If the last used viewing mode was Wide or Normal view mode, the same mode is selected the next time you put the transmission into R.
- If Top down view mode was last used before you turned the power mode to OFF, Wide View mode is selected next time you set the power mode to ON and put the transmission into R.
- If Top down view mode was last used more than 10 seconds after you change from R, Wide View mode is selected the next time you put the transmission into R.

Is a four camera system that views areas commonly known as "blind spots" from different angles, then displays the images on the information screen. This system can be used to:

- Check the right and left sides of the vehicle while crossing at intersections with poor visibility (fog, heavy rain, obstructed view, etc.).
  Checking from the front wide view at intersections P. 554
- Check for obstacles in front of the vehicle when parking or maneuvering in confined areas.
  Checking the sides of your vehicle P. 554
- Check for obstacles when you are moving in R.
  When Parking Your Vehicle P. 550
- Assist you when backing into or parallel parking the vehicle in a lined parking space.
  Reversing into a Parking Space Marked with Parking Lines P. 551
  Parallel Parking into a Parking Space Marked with Parking Lines P. 552

Surround View Camera System*

⚠WARNING

Failure to visually assess the area around the vehicle (directly or by use of the mirrors) may result in a crash causing serious injury or death.

The areas shown in the surround view camera system display are limited. The display may not show all pedestrians or other objects around your vehicle.

Do not solely rely only on the surround view camera system display to assess whether it is safe to move your vehicle.


⚠WARNING

Failure to pay proper attention to your surroundings while driving may result in a crash causing serious injury or death.

To help mitigate the chances of a collision, only look at the surround view camera system display when it is safe to do so.

 * Not available on all models

Displaying an Image From the Surround View Cameras



■ **For frontal views:**
Press the **CAMERA** button when the vehicle is stationary or moving at 7 mph (12 km/h) or slower. Press the button again to switch camera views.

■ **For rear reviews:**
Change the gear position to R when the vehicle is stationary. Press the **CAMERA** button to switch to rear view mode.

You can customize the display setting.
➡ **Customized Features** P. 362

Surround View Camera System*

The surround view camera system does not eliminate all blind spots. The system is for your convenience only.

Always keep the camera lenses clean and free from debris.

Displaying an Image From the Surround View Cameras

The navigation system is disabled when the gear position is in R.


Operating the audio system while the surround view camera system screen is displayed cancels the surround view camera system screen and starts up the audio system screen.

If you press the **CAMERA** button while the vehicle speed is more than 9 mph (15 km/h), the standby screen appears.
When **Show Camera When Decelerating** is on, and the vehicle speed is reduced below 7 mph (12 km/h), the screen switches to a surround view camera system image.
➡ **Customized Features** P. 362

* Not available on all models

Continued


■ Camera Locations and Images



■ Reference Lines and Guides

The following can be displayed when the system is on.
Guide lines: Help you to get a sense of a distance between your vehicle and the rear surroundings. The distance may appear differently than the actual distance.
Projection lines: Indicate vehicle direction while the steering wheel is in the current position.

Depending on your parking situation, you can select **Back-in Left Park Guidance**, **Back-in Right Park Guidance**, **Left Parallel Park Guidance**, or **Right Parallel Park Guidance** from **Camera Menu** to display:



Initial position guide: Marks the point where your vehicle is headed when reversing.
Steering position alignment guide: Indicates when to change the steering wheel position.

Reference Lines and Guides

The positions/distances indicated by the guide lines and camera views on the display may differ from the actual positions/distances due to the changes in the vehicle height, road conditions, and other factors. The guide lines should be used as a reference only.

The guide lines can be turned on and off using the information screen.
➡ **Customized Features** P. 362


If you turn the guide lines off, they remain off until you turn them back on.

Using the Surround View Camera System

■ When Parking Your Vehicle


■ Checking for Obstacles at the Back of Your Vehicle

The display automatically changes to the rear view when the gear position is changed to R.



When Parking Your Vehicle


The ground view can be displayed even with the door mirrors folded. However, the viewable angle and blind spot change.
Do not refer to the surround view camera system when the door mirrors are folded.



Checking for Obstacles at the Back of Your Vehicle

When changing the gear position from/to R, you may experience a delay in switching between the information screen and a rear view image.

■ Reversing into a Parking Space Marked with Parking Lines



1. With your vehicle at a complete stop, press the **CAMERA** button, then press the **ENTER/MENU** button. Rotate to select **Back-in Left Park Guidance** or **Back-in Right Park Guidance**. Press .

2. Move the vehicle forward perpendicular to the parking space and stop where the initial positioning guide in the display is at the center of the parking space.

3. Turn the steering wheel fully to the left (if the parking space is on the passenger side) at a stop.

▶ The steering position alignment guide is displayed.

4. Slowly move the vehicle forward.

▶ Stop the vehicle when the steering position alignment guide enters the parking space.

5. Turn the steering wheel fully to the right (if the parking space is on the passenger side) at a stop. Start reversing the vehicle slowly.

6. Stop the vehicle when it is parallel to the parking lines.


7. Return the steering wheel to its center position, then reverse the vehicle slowly until it is parked within the space.

Continued


Reversing into a Parking Space Marked with Parking Lines

If the steering position alignment guide does not fit in the parking lines, the parking space is too small for the vehicle.

Reference lines can be useful only when the parking space is in a rectangular shape with straight parking marks and when vehicles in the next parking spaces are within the spaces.




■ Parallel Parking into a Parking Space Marked with Parking Lines



1. Press the **CAMERA** button, then press the **ENTER/MENU** button. Rotate to select **Left Parallel Park Guidance** or **Right Parallel Park Guidance**. Press .
2. Move the vehicle forward parallel to the parking space and stop when the initial positioning guide shown in the display overlaps the front corner of the space.
3. Turn the steering wheel fully to the right (if the parking space is on the passenger side) at a stop.
▶ The steering position alignment guide is displayed.
4. Slowly reverse the vehicle.
▶ Stop the vehicle when the steering position alignment guide overlaps the sideline of the parking space.
5. Turn the steering wheel fully to the left (if the parking space is on the passenger side) at a stop. Reverse the vehicle slowly.
6. Stop the vehicle when it is parallel to the parking lines.
7. Return the steering wheel to its center position, then reverse the vehicle slowly until it is parked within the space.


Parallel Parking into a Parking Space Marked with Parking Lines

Reference lines can be useful only when the parking space is in a rectangular shape with straight parking marks and when vehicles in the next parking spaces are within the spaces.



Checking for the Sides of Your Vehicle

You can display the front ground view screen using all the four cameras for the system. Pressing the **CAMERA** button when the vehicle speed is at below 7 mph (12 km/h) changes the image as follows.




Continued

Checking for the Sides of Your Vehicle

When the vehicle speed exceeds 9 mph (15 km/h), the front or side view on the screen automatically switches to the information screen. The front or side view screen resumes when **Show Camera When Decelerating** is on, and the vehicle speed is reduced below 7 mph (12 km/h).


Customized Features P. 362



*1: When **Show Camera When Decelerating** is on.


■ Checking from the front wide view at intersections

The front wide view screen is useful when you need to check for vehicles crossing from either direction at an intersection with poor visibility.



■ Checking the sides of your vehicle

The side view screens are convenient when you pull over at a curb or tollbooth, or slowly pass by oncoming vehicles on a narrow road.



Checking from the front wide view at intersections

The front wide view image is a wide-angled view. The displayed image will be largely distorted, and objects may appear closer or more distant than they actually are.

Checking the sides of your vehicle

When the door mirrors are folded, the side views cannot be displayed.

Surround View Camera System Limitations

The system may not work properly under the following conditions.

Conditions		Solutions
The images may not appear clearly when:	• You activate the system in bad weather (heavy rain, snow, fog, etc.) or in the dark. • Camera temperatures are high. • A sudden change between light and dark such as an entrance or exit of a tunnel. • You drive into the sunlight (e.g., at dawn or dusk.)	Do not use the surround view camera system but rely only on visual confirmation until the conditions allow the system to work properly.
	• A camera lens is covered with dirt, moisture, or debris. • A camera lens is scratched.	Clean camera lenses with a soft cloth moisturized with water, mild detergent or glass cleaner.
	The information screen is dirty.	Wipe off the screen using a soft dry cloth.
A camera angle is altered.	A camera or the area around the camera has been severely impacted.	Do not use the surround view camera system and contact a dealer.
An error message is displayed while the surround view camera system is in use.		

Fuel Information

■ **Fuel recommendation**

Unleaded premium gasoline, pump octane number 91 or higher

Use of lower octane gasoline can cause occasional metallic knocking noise in the engine and will result in decreased engine performance.
Use of gasoline with a pump octane less than 87 can lead to engine damage.

■ **Top tier detergent gasoline**

Because the level of detergency and additives in gasoline vary in the market, Acura endorses the use of "TOP TIER Detergent Gasoline" where available to help maintain the performance and reliability of your vehicle. TOP TIER Detergent Gasoline meets a new gasoline standard jointly established by leading automotive manufacturers to meet the needs of today's advanced engines.

Qualifying gasoline retailers will, in most cases, identify their gasoline as having met "TOP TIER Detergent Gasoline" standards at the retail location. This fuel is guaranteed to contain the proper level of detergent additives and be free of metallic additives. The proper level of detergent additives, and absence of harmful metallic additives in gasoline, help avoid build-up of deposits in your engine and emission control system.

For further important fuel-related information for your vehicle, or on information on gasoline that does not contain MMT, visit Acura Owners at *owners.acura.com* In Canada, visit *www.acura.ca* for additional information on gasoline. For more information on top tier gasoline, visit *www.toptiergas.com*.

■ **Fuel tank capacity: 19.4 US gal (73.3 L)**

Fuel Information


NOTICE

We recommend quality gasoline containing detergent additives that help prevent fuel system and engine deposits. In addition, in order to maintain good performance, fuel economy, and emissions control, we strongly recommend the use of gasoline that does NOT contain harmful manganese-based fuel additives such as MMT, if such gasoline is available.

Use of gasoline with these additives may adversely affect performance, and cause the malfunction indicator lamp on your instrument panel to come on. If this happens, contact a dealer for service. Some gasoline today is blended with oxygenates such as ethanol. Your vehicle is designed to operate on oxygenated gasoline containing up to 15% ethanol by volume. Do not use gasoline containing methanol. If you notice any undesirable operating symptoms, try another service station or switch to another brand of gasoline.

How to Refuel

Your fuel tank is not equipped with a fuel filler cap. You can insert the filler nozzle directly into the filler neck. The tank seals itself again when you pull out the filler nozzle.



1. Stop your vehicle with the service station pump on the left side of the vehicle in the rear.
2. Turn off the power system.
3. Press the fuel fill door release button.
   ▶ The fuel fill door opens.

How to Refuel

⚠WARNING

Gasoline is highly flammable and explosive. You can be burned or seriously injured when handling fuel.


- **Turn the power system off, and keep heat, sparks, and flame away.**
- **Handle fuel only outdoors.**
- **Wipe up spills immediately.**

The fuel filler opening is designed to accept only service station filler nozzles for refueling. Use of smaller diameter tubes (e.g., those used to siphon fuel for other uses) or other non-service station devices can damage the area in and around the filler opening.

The filler nozzle automatically stops to leave space in the fuel tank so that fuel does not overflow as a result of changes in air temperature.

If the filler nozzle keeps turning off when the tank is not full, there may be a problem with the pump's fuel vapor recovery system. Try filling at another pump. If this does not fix the problem, consult a dealer.

Continued



4. Place the end of the filler nozzle on the lower part of filler opening, then insert it slowly and fully.
- ▶ Make sure that the end of the filler nozzle goes down along with the filler pipe.
- ▶ Keep the filler nozzle level.
- ▶ When the tank is full, the filler nozzle will click off automatically.
- ▶ After filling, wait about five seconds before removing the filler nozzle.

5. Shut the fuel fill door by hand.

How to Refuel

Do not continue to add fuel after the filler nozzle has automatically stopped. Additional fuel can exceed the full tank capacity.

If you have to refuel your vehicle from a portable container, use the funnel provided with your vehicle.

Refueling From a Portable Fuel Container
P. 659

Improving Fuel Economy and Reducing CO_2 Emissions

Achieving fuel economy and reducing CO_2 emissions is dependent on several factors, including driving conditions, load weight, idling time, driving habits, and vehicle condition. Depending on these and other factors, you may not achieve the rated fuel economy of this vehicle.


Maintenance and Fuel Economy

You can optimize your fuel economy with proper maintenance of your vehicle. Always maintain your vehicle in accordance with the messages displayed on the MID.

- Use the recommended viscosity engine oil.
  Recommended Engine Oil P. 572
- Maintain the specified tire pressure.
- Do not load the vehicle with excess cargo.
- Keep your vehicle clean. A buildup of snow or mud on your vehicle's underside adds weight and increases wind resistance.

Improving Fuel Economy and Reducing CO_2 Emissions

Direct calculation is the recommended method to determine actual fuel consumed while driving.




In Canada, posted fuel economy numbers are established following a simulated test. For more information on how this test is performed, please visit *http://oee.nrcan.gc.ca/*

This page intentionally left blank.

Maintenance

This chapter discusses basic maintenance.



Before Performing Maintenance
- Inspection and Maintenance 562
- Safety When Performing Maintenance..563
- Parts and Fluids Used in Maintenance Service...564

Maintenance Minder™ 565

Maintenance Under the Hood
- Maintenance Items Under the Hood.. 569
- Opening the Hood 570
- Engine Compartment Cover..... 571
- Recommended Engine Oil 572
- Oil Check 573
- Adding Engine Oil 574
- Changing the Engine Oil and Oil Filter...575
- Cooling System 577
- Inverter Coolant 579
- Transmission Fluid 580
- Brake Fluid 581
- Refilling Window Washer Fluid..... 581

Replacing Light Bulbs 582

Checking and Maintaining Wiper Blades... 587

Checking and Maintaining Tires
- Checking Tires 591
- Tire and Loading Information Label .. 592
- Tire Labeling 592
- DOT Tire Quality Grading (U.S. Vehicles).. 594
- Wear Indicators..... 596
- Tire Service Life 596
- Tire and Wheel Replacement 597
- Tire Rotation 598
- Winter Tires 599

12-Volt Battery 600

Remote Transmitter Care 601

Remote Control and Wireless Headphone Care* 602

Climate Control System Maintenance ..604

Cleaning
- Interior Care 605
- Exterior Care..... 607

Accessories and Modifications 611

* Not available on all models

Inspection and Maintenance

For your safety, perform all listed inspections and maintenance to keep your vehicle in good condition. If you become aware of any abnormality (noise, smell, insufficient brake fluid, oil residue on the ground, etc.), have your vehicle inspected by a dealer. (Note, however, that service at a dealer is not mandatory to keep your warranties in effect.) Refer to the separate maintenance booklet for detailed maintenance and inspection information.

■ Types of Inspection and Maintenance

■ Daily inspections

Perform inspections before long distance trips, when washing the vehicle, or when refueling.

■ Periodic inspections

- Check the brake fluid level monthly.
  ➡ **Checking the Brake Fluid** P. 581
- Check the tire pressure monthly. Examine the tread for wear and foreign objects.
  ➡ **Checking and Maintaining Tires** P. 591
- Check the operation of the exterior lights monthly.
  ➡ **Replacing Light Bulbs** P. 582
- Check the condition of the wiper blades at least every six months.
  ➡ **Checking and Maintaining Wiper Blades** P. 587

Inspection and Maintenance

U.S. models

Maintenance, replacement, or repair of emissions control devices and systems may be done by any automotive repair establishment or individuals using parts that are "certified" to EPA standards.

According to state and federal regulations, failure to perform maintenance on the maintenance main items marked with # will not void your emissions warranties. However, all maintenance services should be performed in accordance with the intervals indicated by the multi-information display (MID).

➡ **Maintenance Service Items** P. 567

If you want to perform complex maintenance tasks that require more skills and tools, you can purchase a subscription to the Service Express website at *www.techinfo.honda.com*.

➡ **Authorized Manuals** P. 670

If you want to perform maintenance yourself, make sure that you have the necessary tools and skills first. After performing maintenance, update the records in the separate maintenance booklet.

Safety When Performing Maintenance

Some of the most important safety precautions are given here.
However, we cannot warn you of every conceivable hazard that can arise in performing maintenance. Only you can decide whether you should perform a given task.

■ Maintenance Safety

- To reduce the possibility of fire or explosion, keep cigarettes, sparks, and flames away from the 12-volt battery, all High Voltage system, and all fuel related parts.
- Never leave rags, towels, or other flammable objects under the hood.
  ▶ Heat from the engine and exhaust can ignite them, causing a fire.
- To clean parts, use a commercially available degreaser or parts cleaner, not gasoline.
- Wear eye protection and protective clothing when working with the 12-volt battery or compressed air.
- Engine exhaust contains carbon monoxide, which is poisonous and can kill you.
  ▶ Only operate the engine if there is sufficient ventilation.

Safety When Performing Maintenance

⚠WARNING

Improperly maintaining this vehicle or failing to correct a problem before driving can cause a crash in which you can be seriously hurt or killed.

Always follow the inspection and maintenance recommendations according to the schedules in this owner's manual.

⚠WARNING

Failure to properly follow maintenance instructions and precautions can cause you to be seriously hurt or killed.

Always follow the procedures and precautions in this owner's manual.

Continued

■ Vehicle Safety

- The vehicle must be in a stationary condition.
  ▶ Make sure your vehicle is parked on level ground, the parking brake is set, and the power system is turned off.
- Be aware that hot parts can burn you.
  ▶ Make sure to let the power system including the engine and exhaust system cool thoroughly before touching vehicle parts.
- Be aware that moving parts can injure you.
  ▶ Do not activate the power system unless instructed, and keep your hands and limbs away from moving parts. When the power system is on, the engine can automatically start, or the radiator fan may start operating without the engine running.

Parts and Fluids Used in Maintenance Service

The use of Acura genuine parts and fluids is recommended when maintaining and servicing your vehicle. Acura genuine parts are manufactured according to the same high quality standards used in Acura vehicles.

Parts and Fluids Used in Maintenance Service

NOTICE

Do not press the engine cover forcibly. This may damage the engine cover and component parts.

If the engine oil life is less than 15%, you will see the Maintenance Minder messages appear on the multi-information display (MID) every time you set the power mode to ON. The messages notify you when to change the engine oil, or when to bring your vehicle to a dealer for indicated maintenance services.

To Use Maintenance Minder™


■ Displaying the Maintenance Minder Information

Maintenance items, which should be serviced at the same time that you replace the engine oil, appear on the MID.

You can view them on the engine oil life screen at any time.

1. Set the power mode to ON.

2. Roll the multi-function steering-wheel controls until the engine oil life appears on the MID.



Continued

Displaying the Maintenance Minder Information



Based on the engine operating conditions, the remaining engine oil life is calculated and displayed as a percentage.

Displayed Engine Oil Life (%)	Calculated Engine Oil Life (%)
100	100 to 91
90	90 to 81
80	80 to 71
70	70 to 61
60	60 to 51
50	50 to 41
40	40 to 31
30	30 to 21
20	20 to 16
15	15 to 11
10	10 to 6
5	5 to 1
0	0

There is a list of maintenance main and sub items you can view on the MID.


Maintenance Service Items P. 567

■ Maintenance Minder Messages on the Multi-Information Display (MID)

Maintenance Message	Oil Life Display	Explanation	Information
Maintenance Due Soon 	15% 	The remaining engine oil life is 15 to 6 percent. Once you switch the display by rolling the multi-function steering-wheel controls, this message will go off.	The engine oil is approaching the end of its service life, and the maintenance items should be inspected and serviced soon.
Maintenance Due Now 	5% 	The remaining engine oil life is 5 to 1 percent. Roll the multi-function steering-wheel controls to switch to another display.	The engine oil has almost reached the end of its service life, and the maintenance items should be inspected and serviced as soon as possible.
Maintenance Past Due 	Negative Distance U.S.  Canada 	The remaining engine oil life has passed its service life, and a negative distance appears after driving over 10 miles (U.S. models) or 10 km (Canadian models). Roll the multi-function steering wheel control to switch to another display.	The engine oil life has passed. The maintenance items must be inspected and serviced immediately.

The system message indicator (ⓘ) comes on along with the Maintenance Minder message.

Maintenance Service Items



Maintenance Service Items

- Independent of the Maintenance Minder information, replace the brake fluid every 3 years.
- Adjust the valves during services A, B, 1, 2, or 3 if they are noisy.

CODE	Maintenance Main Items
A	• Replace engine oil*1
B	• Replace engine oil*1 and oil filter • Inspect front and rear brakes • Check expiration date for Temporary Tire Repair Kit bottle* • Inspect tie rod ends, steering gearbox, boots • Inspect suspension components • Inspect driveshaft boots • Inspect brake hoses and lines (Including ABS/VSA®) • Inspect all fluid levels and condition of fluids • Inspect exhaust system# • Inspect fuel lines and connections#

*1: If the message **Maintenance Due Now** does not appear more than 12 months after the display is reset, change the engine oil every year.
#: See information on maintenance and emissions warranty.
*2: If you drive in dusty conditions, replace the air cleaner element every 15,000 miles (24,000 km).
*3: If you drive primarily in urban areas that have high concentrations of soot in the air from industry and from diesel-powered vehicles, replace the dust and pollen filter every 15,000 miles (24,000 km).

CODE	Maintenance Sub Items
1	• Rotate tires
2	• Replace air cleaner element*2 • Replace dust and pollen filter*3
3	• Replace transmission fluid*4
4	• Replace spark plugs • Replace timing belt and inspect water pump*5 • Inspect valve clearance
5	• Replace engine coolant
6	• Replace twin motor unit fluid*6


*4: Driving in mountainous areas at very low vehicle speeds results in higher transmission temperature. This requires transmission fluid changes more frequently than recommended by the Maintenance Minder. If you regularly drive your vehicle under these conditions, have the transmission fluid changed at 30,000 miles (48,000 km), then every 25,000 miles (40,000 km).
*5: If you drive regularly in very high temperatures (over 110°F, 43°C), in very low temperatures (under -20°F, -29°C), replace every 60,000 miles/100,000 km.
*6: Driving in mountainous areas at very low vehicle speeds results in higher level of mechanical (Shear) stress to fluid. This requires twin motor unit fluid changes more frequently than recommended by the Maintenance Minder. If you regularly drive your vehicle under these conditions, have the twin motor unit fluid changed at 7,500 miles (12,000 km), then every 15,000 miles (24,000 km).

* Not available on all models

Continued

■ Resetting the Display

Reset the engine oil life display if you have performed the maintenance service.



1. Set the power mode to ON.

2. Go to the **Maintenance Info.** group.

Customized Features P. 131

3. Push the multi-function steering-wheel controls.

▶ The oil life reset mode is displayed on the MID.

4. Select **Reset** with the multi-function steering-wheel controls, then push the multi-function steering wheel control.

▶ The displayed maintenance items disappear, and the engine oil life display returns to **100%**.

▶ To cancel the oil life reset mode, select **Cancel**, then push the multi-function steering-wheel controls.

Resetting the Display

NOTICE


Failure to reset the engine oil life after a maintenance service results in the system showing incorrect maintenance intervals, which can lead to serious mechanical problems.

The dealer will reset the engine oil life display after completing the required maintenance service. If someone other than a dealer performs maintenance service, reset the engine oil life display yourself.


You can reset the engine oil life display using the information screen.

Customized Features P. 362


Maintenance Items Under the Hood



Opening the Hood



1. Park the vehicle on a level surface, and set the parking brake.
2. Pull the hood release handle under the driver's side lower corner of the dashboard.
   ▶ The hood will pop up slightly.



3. Push the hood latch lever (located under the front edge of the hood to the center) to the side and raise the hood. Once you have raised the hood slightly, you can release the lever.



4. Lift the hood up most of the way.
   ▶ The hydraulic support will lift it up the rest of the way and hold it up.

When closing, lower it to approximately 12 inches (30 cm), then press down firmly with your hands.

Opening the Hood

NOTICE

Do not open the hood when the wiper arms are raised. The hood will strike the wipers, resulting in possible damage to the hood and/or the wipers.


Do not press the engine cover forcibly. This may damage the engine cover and component parts.

When closing the hood, check that the hood is securely latched.

If the hood latch lever moves stiffly, or if you can open the hood without lifting the lever, the latch mechanism should be cleaned and lubricated.

Engine Compartment Cover

The component parts in the engine compartment are protected by a cover.
You may need to remove the cover when you perform certain maintenance work.
Pull up on the engine compartment cover carefully until all pins are removed from their grommets.



Remove the Engine Compartment Cover


Recommended Engine Oil

- **Genuine Acura Motor Oil**
- **Premium-grade 0W-20 detergent oil with an API Certification Seal on the container.**



Oil is a major contributor to your engine's performance and longevity. If you drive the vehicle with insufficient or deteriorated oil, the engine may fail or be damaged.

This seal indicates the oil is energy conserving and that it meets the American Petroleum Institute's latest requirements.



Use a Genuine Acura Motor Oil or another commercial engine oil of suitable viscosity for the ambient temperature as shown.

■ Synthetic oil

You may also use synthetic motor oil if it is labeled with the API Certification Seal and is the specified viscosity grade.


Recommended Engine Oil

Engine Oil Additives


Your vehicle does not require oil additives. In fact, they may adversely affect the engine performance and durability.

Oil Check

We recommend that you check the engine oil level every time you refuel.
Park the vehicle on level ground.
Turn off the power system. You can check the oil level without the engine having run beforehand. If the engine has been running, wait approximately three minutes before you check the oil.



1. Remove the dipstick (orange).
2. Wipe the dipstick with a clean cloth or paper towel.
3. Insert the dipstick back all the way into its hole.




4. Remove the dipstick again, and check the level. It should be between the upper and lower marks. Add oil if necessary.

Oil Check

If the oil level is near or below the lower mark, slowly add oil, being careful not to overfill.

Adding Engine Oil



1. Unscrew and remove the engine oil fill cap.
2. Add oil slowly.
3. Reinstall the engine oil fill cap, and tighten it securely.
4. Wait for three minutes and recheck the engine oil dipstick.

Adding Engine Oil

NOTICE


Do not fill the engine oil above the upper mark. Overfilling the engine oil can result in leaks and engine damage.

If any oil spills, wipe it away immediately. Spilled oil may damage the engine compartment components.

Changing the Engine Oil and Oil Filter

You must change the engine oil and oil filter regularly in order to maintain the engine's lubrication. The engine may be damaged if they are not changed regularly.

Change the oil and filter in accordance with the maintenance message on the multi-information display.




1. Run the engine until it reaches normal operating temperature, and then turn the engine off.
2. Open the hood and remove the engine oil fill cap.
3. Remove the drain bolt and washer from the bottom of the engine, and drain the oil into a suitable container.

Changing the Engine Oil and Oil Filter

NOTICE

You may damage the environment if you do not dispose of the oil in a suitable way. If you are changing the oil by yourself, appropriately dispose of the used oil. Put the oil in a sealed container and take it to a recycling center. Do not throw the oil away into a garbage can or onto the ground.

Continued



4. Remove the oil filter and dispose of the remaining oil.
5. Check that the filter gasket is not stuck to the engine contact surface.
▶ If it is stuck, you must detach it.
6. Wipe away dirt and dust adhering to the contact surface of the engine block, and install a new oil filter.
▶ Apply a light coat of new engine oil to the filter gasket.
7. Put a new washer on the drain bolt, then reinstall the drain bolt.
▶ Tightening torque:
29 lbf·ft (39 N·m, 4.0 kgf·m)
8. Pour the recommended engine oil into the engine.
▶ Engine oil change capacity (including filter):
4.5 US qt (4.3 L)
9. Reinstall the engine oil fill cap securely and start the engine.
10. Run the engine for a few minutes, and then check that there is no leak from the drain bolt or oil filter.
11. Stop the engine, wait for three minutes, and then check the oil level on the dipstick.
▶ If necessary, add more engine oil.

Changing the Engine Oil and Oil Filter

You will need a special wrench to replace the oil filter. You can buy this wrench from a dealer.

When installing the new oil filter, follow the instructions supplied with the oil filter.

Reinstall the engine oil fill cap. Start the engine. The low oil pressure indicator should go off within five seconds. If it does not, turn off the engine, and check your work.


Cooling System


Specified coolant: Acura Long Life Antifreeze/Coolant Type 2

This coolant is premixed with 50% antifreeze and 50% water. Do not add any straight antifreeze or water.

We recommend you check the engine coolant level every time you refuel. Check the reserve tank first. If it is completely empty, also check the coolant level in the radiator. Add the engine coolant accordingly.

■ Reserve Tank





1. **Make sure the engine and radiator are cool.**
2. Check the amount of coolant in the reserve tank.
   ▶ If the coolant level is below the **MIN** mark, add the specified coolant until it reaches the **MAX** mark.
   ➡ **Engine Compartment Cover** P. 571
3. Inspect the cooling system for leaks.

Cooling System

⚠WARNING

Removing the radiator cap while the engine is hot can cause the coolant to spray out, seriously scalding you.

Always let the engine and radiator cool down before removing the radiator cap.

NOTICE


Genuine Acura engine coolant is a 50/50 mixture of antifreeze and water that can withstand freezing at temperatures as low as about –31°F (–35°C). If your vehicle is consistently subjected to temperatures below this, the concentration of antifreeze in the coolant should be increased. Consult a dealer for details.

If Acura antifreeze/coolant is not available, you may use another major brand of non-silicate coolant as a temporary replacement. Check that it is a high quality coolant recommended for aluminum engines. Continued use of any non-Acura coolant can result in corrosion, causing the cooling system to malfunction or fail. Have the cooling system flushed and refilled with Acura antifreeze/coolant as soon as possible.

Do not add rust inhibitors or other additives to your vehicle's cooling system. They may not be compatible with the coolant or with the engine components.

Continued

■ Radiator



1. **Make sure the engine and radiator are cool.**
2. Remove the engine compartment cover.
   ➡ **Engine Compartment Cover** P. 571
3. Turn the radiator cap 1/8 turn counter-clockwise and relieve any pressure in the cooling system.
4. Push down and turn the radiator cap counterclockwise to remove it.
5. The coolant level should be up to the base of the filler neck. Add coolant if it is low.
6. Put the radiator cap back on, and tighten it fully.

Radiator

NOTICE

Pour the fluid slowly and carefully so you do not spill any. Clean up any spills immediately; they can damage components in the engine compartment.

Inverter Coolant


Specified coolant: Acura Long Life Antifreeze/Coolant Type 2

This coolant is premixed with 50% antifreeze and 50% water. Do not add any straight antifreeze or water.

We recommend you check the inverter coolant level every time you refuel. Check the filler tank. Add the inverter coolant accordingly.

Have a dealer replace the inverter coolant.

■ Checking the Coolant



1. Check the fluid level in the tank.
2. If the coolant level has dropped below the **MIN** level, have your vehicle serviced at a dealer.
   ▶ Only a properly trained technician can refill the coolant and check the system for leaks.

Inverter Coolant

NOTICE

Genuine Acura engine coolant is a 50/50 mixture of antifreeze and water that can withstand freezing at temperatures as low as about –31°F (–35°C). If your vehicle is consistently subjected to temperatures below this, the concentration of antifreeze in the coolant should be increased. Consult a dealer for details.

If Acura antifreeze/coolant is not available, you may use another major brand of non-silicate coolant as a temporary replacement. Check that it is a high quality coolant recommended for aluminum engines. Continued use of any non-Acura coolant can result in corrosion, causing the cooling system to malfunction or fail. Have the cooling system flushed and refilled with Acura antifreeze/coolant as soon as possible.

Do not add rust inhibitors or other additives to your vehicle's coolant system. They may not be compatible with the coolant or with the motor components.

Transmission Fluid

■ Dual Clutch Transmission Fluid

Specified fluid: Acura Automatic Transmission Fluid ATF DW-1

Have a dealer check the fluid level and replace if necessary.

Do not attempt to check or change the dual clutch transmission fluid yourself.

Dual Clutch Transmission Fluid

NOTICE

Do not mix Acura ATF DW-1 with other transmission fluids.


Using a transmission fluid other than Acura ATF DW-1 may adversely affect the operation and durability of your vehicle's transmission, and damage the transmission.

Any damage caused by using a transmission fluid that is not equivalent to Acura ATF DW-1 is not covered by Acura's new vehicle limited warranty.

Brake Fluid

Specified fluid: Acura Heavy Duty Brake Fluid DOT 3

Checking the Brake Fluid



The fluid level should be between the **MIN** and **MAX** marks on the side of the reserve tank.

Refilling Window Washer Fluid

If the washer fluid is low, a message appears on the MID.
Pour the washer fluid carefully. Do not overflow the reservoir.

Brake Fluid

NOTICE

Brake fluid marked DOT 5 is not compatible with your vehicle's braking system and can cause extensive damage.

If the specified brake fluid is not available, you should use only DOT 3 or DOT 4 fluid from a sealed container as a temporary replacement.

Using any non-Acura brake fluid can cause corrosion and decrease the longevity of the system. Have the brake system flushed and refilled with Acura Heavy Duty Brake Fluid DOT 3 as soon as possible.

If the brake fluid level is at or below the **MIN** mark, have a dealer inspect the vehicle for leaks or worn brake pads as soon as possible.

Refilling Window Washer Fluid

NOTICE

Do not use engine antifreeze or a vinegar/water solution in the windshield washer reservoir. Antifreeze can damage your vehicle's paint. A vinegar/water solution can damage the windshield washer pump.
Use only commercially available windshield washer fluid.
Avoid prolonged use of hard water to prevent lime scale build up.

Headlights

Headlights are LED type. Have an authorized Acura dealer inspect and replace the light assembly.

Front Turn Signal/Parking, Daytime Running and Front Side Marker Lights

Front turn signal/parking, daytime running and front side marker lights are LED type. Have an authorized Acura dealer inspect and replace the light assembly.

Fog Lights*

Fog lights are LED type. Have an authorized Acura dealer inspect and replace the light assembly.

Side Turn Signal/Emergency Indicator Lights

Door mirror side turn lights are LED type. Have an authorized Acura dealer inspect and replace the light assembly.

Headlights


The headlight aim is set by the factory, and does not need to be adjusted. However, if you regularly carry heavy items in the cargo area, have the aiming readjusted at a dealer or by a qualified technician.

 * Not available on all models


Brake Light and Rear Turn Signal Light Bulbs

When replacing, use the following bulbs.

Brake Light: 21 W
Rear Turn Signal Light: 21 W




1. Remove the cover.
▶ Starting at the bottom, carefully pull the cover straight out, working upward until all pins are removed from their grommets.
▶ The grommets should remain in the body.



2. Use a Phillips-head screwdriver to remove the bolts.
3. Pull the light assembly out of the rear pillar.

Continued



4. Turn the socket counter-clockwise and remove it. Remove the old bulb.
5. Insert a new bulb.
6. Slide the light assembly onto the guide on the body.
7. Align the pins with the body grommets, then push in until they fully seat.


Taillights/Rear Side Marker Lights

Taillights/rear side marker lights are the LED type. Have an authorized Acura dealer inspect and replace the light assembly.


Back-Up Light Bulbs

When replacing, use the following bulbs.

Back-Up Light: 21 W



1. Remove the cover by prying on the edge using a flat-tip screwdriver.
▶ Wrap the flat-tip screwdriver with a cloth to prevent scratches.



2. Turn the socket counter-clockwise and remove it. Remove the old bulb.
3. Insert a new bulb.

Taillights

Taillights are the LED type. Have an authorized Acura dealer inspect and replace the light assembly.

Rear License Plate Lights

Rear license plate lights are LED type. Have an authorized Acura dealer inspect and replace the light assembly.

High-Mount Brake Light

High-mount brake light is LED type. Have an authorized Acura dealer inspect and replace the light assembly.

Puddle Lights

Puddle lights are LED type. Have an authorized Acura dealer inspect and replace the light assembly.


Checking Wiper Blades

If the wiper blade rubber has deteriorated, it will leave streaks and the hard surfaces of the blade may scratch the window glass.

Changing the Front Wiper Blade Rubber



1. Lift the driver side wiper arm first, then the passenger side.




2. Pry on the edge of the lock tab using a flat-tip screwdriver to push it up.
Wrap the flat-tip screwdriver with a cloth to prevent scratches.
3. Slide the holder off the wiper arm.

Changing the Front Wiper Blade Rubber


NOTICE

Avoid dropping the wiper arm onto the windshield, it may damage the wiper arm and/or the windshield.


Continued



4. Slide the wiper blade out of the holder by pulling the tabbed end out.



5. Remove the retainers from the wiper blade that has been removed, and mount to a new wiper blade.
▶ Correctly align the wiper blade protrusion and the retainer grooves.




6. Slide the new wiper blade onto the holder from the bottom end.
▶ The tab on the holder should fit in the indent of the wiper blade.
7. Slide the holder onto the wiper arm, then push down the lock tab.
8. Lower the passenger side wiper arm first, then the driver side.


Changing the Rear Wiper Blade Rubber



1. Raise the wiper arm off.



2. Slide the wiper blade out from the end with the indent.




3. Remove the retainers from wiper blade and mount to a new rubber blade.

Changing the Rear Wiper Blade Rubber

NOTICE

Avoid dropping the wiper arm, it may damage the rear window.

Continued



4. Slide the new wiper blade onto the holder.
▶ Make sure it is engaged correctly, then install the wiper blade assembly onto the wiper arm.

Checking Tires

To safely operate your vehicle, your tires must be of the proper type and size, in good condition with adequate tread, and properly inflated.

■ Inflation guidelines

Properly inflated tires provide the best combination of handling, tread life, and comfort. Refer to the driver's doorjamb label or specifications page for the specified pressure.

Underinflated tires wear unevenly, adversely affect handling and fuel economy, and are more likely to fail from overheating.

Overinflated tires make your vehicle ride harshly, are more prone to road hazards, and wear unevenly.

Every day before you drive, look at each of the tires. If one looks lower than the others, check the pressure with a tire gauge.

At least once a month or before long trips, use a gauge to measure the pressure in all tires, including the spare*. Even tires in good condition can lose 1–2 psi (10–20 kPa, 0.1–0.2 kgf/cm^2) per month.

■ Inspection guidelines

Every time you check inflation, also examine the tires and valve stems.
Look for:

- Bumps or bulges on the side or in the tread. Replace the tire if you find any cuts, splits, or cracks in the side of the tire. Replace it if you see fabric or cord.
- Remove any foreign objects and inspect for air leaks.
- Uneven tread wear. Have a dealer check the wheel alignment.
- Excessive tread wear.
  Wear Indicators P. 596
- Cracks or other damage around valve stem.

* Not available on all models

Checking Tires

⚠WARNING

Using tires that are excessively worn or improperly inflated can cause a crash in which you can be seriously hurt or killed.

Follow all instructions in this owner's manual regarding tire inflation and maintenance.


Measure the air pressure when tires are cold. This means the vehicle has been parked for at least three hours, or driven less than 1 mile (1.6 km). If necessary, add or release air until the specified pressure is reached.

If checked when hot, tire pressure can be as much as 4–6 psi (30–40 kPa, 0.3–0.4 kgf/cm^2) higher than if checked when cold.

Have a dealer check the tires if you feel a consistent vibration while driving. New tires and any that have been removed and reinstalled should be properly balanced.

Tire and Loading Information Label

The label attached to the driver's doorjamb provides necessary tire and loading information.




Tire and Loading Information Label

The tire and loading information label attached to the driver's doorjamb contains:

1. The number of people your vehicle can carry.
2. The total weight your vehicle can carry. Do not exceed this weight.
3. The original tire sizes for front, rear, and spare.
4. The proper cold tire pressure for front, rear, and spare.

Tire Labeling



The tires that came on your vehicle have a number of markings. Those you should be aware of are described as shown.

■ Tire Sizes

Whenever tires are replaced, they should be replaced with tires of the same size.

Tire Sizes

Following is an example of tire size with an explanation of what each component means.

P235/60R18 102T

P: Vehicle type (P indicates passenger vehicle).
235: Tire width in millimeters.
60: Aspect ratio (the tire's section height as a percentage of its width).
R: Tire construction code (R indicates radial).
18: Rim diameter in inches.
102: Load index (a numerical code associated with the maximum load the tire can carry).
T: Speed symbol (an alphabetical code indicating the maximum speed rating).

■ Tire Identification Number (TIN)

The tire identification number (TIN) is a group of numbers and letters that look like the example in the side column. TIN is located on the sidewall of the tire.

■ Glossary of Tire Terminology

Cold Tire Pressure – The tire air pressure when the vehicle has been parked for at least three hours or driven less than 1 mile (1.6 km).
Load Rating – Means the maximum load that a tire is rated to carry for a given inflation pressure.
Maximum Inflation Pressure – The maximum tire air pressure that the tire can hold.
Maximum Load Rating – Means the load rating for a tire at the maximum permissible inflation pressure for that tire.
Recommended Inflation Pressure – The cold tire inflation pressure recommended by the manufacturer.
Treadwear Indicators (TWI) – Means the projections within the principal grooves designed to give a visual indication of the degrees of wear of the tread.

Tire Identification Number (TIN)

DOT B97R FW6X 2209
DOT: This indicates that the tire meets all requirements of the U.S. Department of Transportation.
B97R: Manufacturer's identification mark.
FW6X: Tire type code.
22 09: Date of manufacture.
09: Year
22: Week

DOT Tire Quality Grading (U.S. Vehicles)

The tires on your vehicle meet all U.S. Federal Safety Requirements. All tires are also graded for treadwear, traction, and temperature performance according to Department of Transportation (DOT) standards. The following explains these gradings.

■ Uniform Tire Quality Grading

Quality grades can be found where applicable on the tire sidewall between tread shoulder and maximum section width.

■ Treadwear

The treadwear grade is a comparative rating based on the wear rate of the tire when tested under controlled conditions on a specified government test course. For example, a tire graded 150 would wear one and one-half (1 1/2) times as well on the government course as a tire graded 100. The relative performance of tires depends upon the actual conditions of their use, however, and may depart significantly from the norm due to variations in driving habits, service practices and differences in road characteristics and climate.

Uniform Tire Quality Grading

For example:
Treadwear 200
Traction AA
Temperature A

All passenger car tires must conform to Federal Safety Requirements in addition to these grades.

■ Traction

The traction grades, from highest to lowest, are AA, A, B, and C. Those grades represent the tire's ability to stop on wet pavement as measured under controlled conditions on specified government test surfaces of asphalt and concrete. A tire marked C may have poor traction performance.

■ Temperature

The temperature grades are A (the highest), B, and C, representing the tire's resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on a specified indoor laboratory test wheel. Sustained high temperature can cause the material of the tire to degenerate and reduce tire life, and excessive temperature can lead to sudden tire failure. The grade C corresponds to a level of performance which all passenger car tires must meet under the Federal Motor Vehicle Safety Standard No. 109. Grades B and A represent higher levels of performance on the laboratory test wheel than the minimum required by law.


Traction

Warning: The traction grade assigned to this tire is based on straight-ahead braking traction tests, and does not include acceleration, cornering, hydroplaning, or peak traction characteristics.

Temperature

Warning: The temperature grade for this tire is established for a tire that is properly inflated and not overloaded. Excessive speed, underinflation, or excessive loading, either separately or in combination, can cause heat buildup and possible tire failure.

Wear Indicators



The groove where the wear indicator is located is 1/16 inch (1.6 mm) shallower than elsewhere on the tire. If the tread has worn so that the indicator is exposed, replace the tire. **Worn out tires have poor traction on wet roads.**

Tire Service Life

The life of your tires is dependent on many factors, including driving habits, road conditions, vehicle loading, inflation pressure, maintenance history, speed, and environmental conditions (even when the tires are not in use).

In addition to regular inspections and inflation pressure maintenance, it is recommended that you have annual inspections performed once the tires reach five years old. All tires, including the spare*, should be removed from service after 10 years from the date of manufacture, regardless of their condition or state of wear.

 * Not available on all models

Tire and Wheel Replacement

Replace your tires with radials of the same size, load range, speed rating, and maximum cold tire pressure rating (as shown on the tire's sidewall). Using tires of a different size or construction can cause certain vehicle systems such as the ABS and Vehicle Stability Assist® (VSA®) system to work incorrectly.

It is best to replace all four tires at the same time. If that isn't possible, replace the front or rear tires in pairs.

If you replace a wheel, only use TPMS specified wheels approved for your vehicle. Make sure that the wheel's specifications match those of the original wheels.

Tire and Wheel Replacement

⚠WARNING


Installing improper tires on your vehicle can affect handling and stability. This can cause a crash in which you can be seriously hurt or killed.

Always use the size and type of tires recommended in this owner's manual.

Tire Rotation


Rotating tires according to the maintenance messages on the MID helps to distribute wear more evenly and increase tire life.

■ Tires without rotation marks



Rotate the tires as shown here.


■ Tires with rotation marks



Rotate the tires as shown here.

Tire Rotation

Tires with directional tread patterns should only be rotated front to back (not from one side to the other). Directional tires should be mounted with the rotation indication mark facing forward, as shown below.



Winter Tires

If driving on snowy or frozen roads, mount all season marked **M+S** tires, snow tires, or tire chains; reduce speed; and maintain sufficient distance between vehicles when driving.

Be particularly careful when operating the steering wheel or brakes to prevent skidding.

Use tire chains, snow tires, or all season tires when necessary or according to the law.

When mounting, refer to the following points.

For winter tires:
- Select the size and load ranges that are the same as the original tires.
- Mount the tires to all four wheels.

For tire chains:
- Install them on the front tires only.
- Because your vehicle has limited tire clearance, we strongly recommend using the chains listed below:

  Cable-type: SCC Cable Chain Super Z LT - ZT735
- Follow the chain manufacturer's instruction when installing. Mount them as tightly as you can.
- Check that the chains do not touch the brake lines or suspension.
- Drive slowly.

Winter Tires

⚠WARNING

Using the wrong chains, or not properly installing chains, can damage the brake lines and cause a crash in which you can be seriously injured or killed.

Follow all instructions in this owner's manual regarding the selection and use of tire chains.


NOTICE

Traction devices that are the wrong size or improperly installed can damage your vehicle's brake lines, suspension, body, and wheels. Stop driving if they are hitting any part of the vehicle.

When tire chains are mounted, follow the chain manufacturer's instructions regarding vehicle operational limits.

If your vehicle is equipped with summer tires, be aware that these tires are not designed for winter driving conditions. For more information, contact a dealer.

Checking the 12-Volt Battery



The condition of the battery is monitored by a sensor located on the negative terminal of the battery. If there is a problem with this sensor, the multi-information display (MID) will display a warning message. If this happens, have you vehicle inspected by a dealer.

Check the battery terminals for corrosion monthly.

If your vehicle's battery is disconnected or goes dead:

- The audio system is disabled.
  ➡ **Audio System Theft Protection** P. 240
- The clock resets.
  ➡ **Clock** P. 142

Charging the 12-Volt Battery

Disconnect both battery cables to prevent damaging your vehicle's electrical system. Always disconnect the negative (–) cable first, and reconnect it last.

12-Volt Battery

⚠WARNING

The battery gives off explosive hydrogen gas during normal operation.

A spark or flame can cause the battery to explode with enough force to kill or seriously hurt you.

When conducting any battery maintenance, wear protective clothing and a face shield, or have a skilled technician do it.


WARNING: Battery post, terminals, and related accessories contain lead and lead compounds.
Wash your hands after handling.

When you find corrosion, clean the battery terminals by applying a baking powder and water solution. Clean the terminals with a damp towel. Cloth/towel dry the battery. Coat the terminals with grease to help prevent future corrosion.

When replacing the battery, the replacement must be of the same specifications.
Consult a dealer for more information.


Replacing the Button Battery

If the indicator does not come on when the button is pressed, replace the battery.



Battery type: CR2032

1. Remove the built-in key.
▶ As a convenience, lightly place masking tape over the remote buttons to hold them in place.



2. Remove the upper half of the cover by carefully prying on the edge with a coin.
▶ Wrap a coin with a cloth to prevent scratching the transmitter.
3. Press down on the center of the assembly and remove the battery.
▶ When removing the button battery, be careful not to touch parts around it.
4. Make sure to replace the battery with the correct polarity.

Replacing the Button Battery

⚠WARNING

CHEMICAL BURN HAZARD
The battery that powers the remote transmitter can cause severe internal burns and can even lead to death if swallowed.
Keep new and used batteries away from children.
If you suspect that a child has swallowed the battery, seek medical attention immediately.

NOTICE
An improperly disposed of battery can damage the environment. Always confirm local regulations for battery disposal.

Replacement batteries are commercially available or at a dealer.


NOTICE
The Remote transmitter is equipped with two batteries: A standard replaceable CR2032 coin button battery and an integral non-replaceable rechargeable battery. To prevent permanent damage to the rechargeable battery, replace the CR2032 battery every three to four years.

Models with Rear Entertainment System

Replacing the Battery

■ Remote Control

If it takes several pushes on the remote control buttons to operate the rear entertainment system, replace the battery.



Battery type: BR3032

1. Remove the cover.
2. Make sure to replace the battery with the correct polarity.

Replacing the Battery

⚠WARNING

CHEMICAL BURN HAZARD
The battery that powers the remote control can cause severe internal burns and can even lead to death if swallowed.
Keep new and used batteries away from children.
If you suspect that a child has swallowed the battery, seek medical attention immediately.

NOTICE

An improperly disposed of battery can damage the environment. Always confirm local regulations for battery disposal.


Replacement batteries are commercially available or at a dealer.

Make sure to replace all the batteries at once.

 * Not available on all models


■ Wireless Headphone

If there is no sound coming from the wireless headphone, replace the battery.



Battery type: AAA

1. Remove the screw.



2. Open the cover.
3. Make sure to replace the battery with the correct polarity.

Dust and Pollen Filter

The climate control system is equipped with a dust and pollen filter that collects pollen, dust, and other debris in the air. The Maintenance Minder™ messages will let you know when to replace the filter.

We recommend that you replace the dust and pollen filter sooner when using your vehicle in areas with high concentrations of dust.

Dust and Pollen Filter


If the airflow from the climate control system deteriorates noticeably, and the windows fog up easily, the filter may need to be replaced. Please contact a dealer for replacement.

Interior Care

Use a damp cloth with a mixture of mild detergent and warm water to remove dirt. Use a clean cloth to remove detergent residue.

Cleaning Seat Belts

Use a soft brush with a mixture of mild soap and warm water to clean the seat belts. Let the belts air dry. Wipe the openings of the seat belt anchors using a clean cloth.



Interior Care

Do not spill liquids inside the vehicle. Electrical devices and systems may malfunction if liquids are splashed on them.

Do not use silicone based sprays on electrical devices such as audio devices and switches. Doing so may cause the items to malfunction or cause a fire inside the vehicle.
If a silicone based spray is inadvertently used on electrical devices, consult a dealer.

Depending on their composition, chemicals and liquid aromatics may cause discoloration, wrinkles, and cracking to resin-based parts and textiles.
Do not use alkali solvents or organic solvents such as benzene or gasoline.


After using chemicals, make sure to gently wipe them away using a dry cloth.
Do not place used cloths on top of resin based parts or textiles for long periods of time without washing.

Continued

■ Cleaning the Window

Wipe using a glass cleaner.

■ Floor Mats



The front and second row passenger's floor mats hook over floor anchors, which keep them from sliding forward. To remove a mat for cleaning, turn the anchor knobs to the unlock position. When reinstalling the mat after cleaning, turn the knobs to the lock position.

Do not put additional floor mats on top of the anchored mats.

■ Maintaining Genuine Leather

To properly clean leather:

1. Use a vacuum or soft dry cloth first to remove any dirt or dust.
2. Clean the leather with a soft cloth dampened with a solution comprised of 90% water and 10% neutral soap.
3. Wipe away any soap residue with a clean damp cloth.
4. Wipe away residual water and allow leather to air dry in the shade.

Cleaning the Window

Wires are mounted to the inside of the rear window. Wipe along the same direction as the wires with a soft cloth so as not to damage them.

Be careful not to spill fluids, such as water or glass cleaner, on or around the cover of both the front sensor camera and the rainfall/light sensor.

➔ **Automatic Operation (automatic lighting control)** P. 177
➔ **Automatic Intermittent Wipers** P. 184
➔ **Front Sensor Camera** P. 475

Floor Mats

If you use any floor mats that were not originally provided with your vehicle, make sure they are designed for your specific vehicle, fit correctly, and are securely anchored by the floor anchors.
Position the rear seat floor mat properly. If they are not properly positioned, the floor mat can interfere with the front seat functions.

Maintaining Genuine Leather

It is important to clean or wipe away dirt or dust as soon as possible. Spills can soak into leather resulting in stains. Dirt or dust can cause abrasions in the leather. In addition, please note that some dark colored clothing can rub onto the leather seats resulting in discoloration or stains.

Exterior Care

Dust off the vehicle body after you drive.
Regularly inspect your vehicle for scratches on painted surfaces. A scratch on a painted surface can result in body rust. If you find a scratch, promptly repair it.

■ Washing the Vehicle

Wash the vehicle regularly. Wash more frequently when driving in the following conditions:


- If driving on roads with road salt.
- If driving in coastal areas.
- If tar, soot, bird droppings, insects, or tree sap are stuck to painted surfaces.

■ Using an Automated Car Wash

- Make sure to follow the instructions indicated on the automated car wash.
- Fold in the door mirrors.
- For models equipped with automatic intermittent wipers, turn the wipers off.

Washing the Vehicle

Do not spray water into the air intake vents. It can cause a malfunction.



Do not spray water onto the capless unit when the fuel fill door is open. It can cause damage to the fuel system or engine.

Using an Automated Car Wash

When using an automated car wash that pulls the vehicle through with a conveyor, make sure vehicle is in car wash mode.

➡ **If you want to keep the transmission in N position [car wash mode]** P. 469

Continued

■ Using High Pressure Cleaners

- Keep sufficient distance between the cleaning nozzle and the vehicle body.
- Take particular care around the windows. Standing too close may cause water to enter the vehicle interior.
- Do not spray high pressure water directly into the engine compartment. Instead, use low pressure water and a mild detergent.

■ Applying Wax

A good coat of automotive body wax helps protect your vehicle's paint from the elements. Wax will wear off over time and expose your vehicle's paint to the elements, so reapply as necessary.

■ Maintaining the Bumpers and Other Resin Coated Parts

If you get gasoline, oil, engine coolant, or battery fluid on resin coated parts, they may be stained or the coating may peel. Promptly wipe it away using a soft cloth and clean water.

■ Cleaning the Window

Wipe using a glass cleaner.

Applying Wax

NOTICE

Chemical solvents and strong cleaners can damage the paint, metal, and plastic on your vehicle. Wipe away spills immediately.

Maintaining the Bumpers and Other Resin Coated Parts

Ask a dealer about the correct coating material when you want to repair the painted surface of the parts made of resin.

■ Maintaining Aluminum Wheels

Aluminum is susceptible to deterioration caused by salt and other road contaminants. When necessary, as early as possible use a sponge and mild detergent to wipe away these contaminants. Do not use a stiff brush or harsh chemicals (including some commercial wheel cleaners). These can damage the protective finish on aluminum alloy wheels, resulting in corrosion. Depending on the type of finish, the wheels also may lose their luster or appear burnished. To avoid water stains, wipe the wheels dry with a cloth while they are still wet.

■ Fogged Exterior Light Lenses

The inside lenses of exterior lights (headlights, brake lights, etc.) may fog temporarily if you have driven in the rain, or after the vehicle has been run through a car wash. Dew condensation also may build up inside the lenses when there is a significant enough difference between the ambient and inside lens temperatures (similar to vehicle windows fogging up in rainy conditions). These conditions are natural processes, not structural design problems in the exterior lights.
Lens design characteristics may result in moisture developing on the light lens frame surfaces. This also is not a malfunction.
However, if you see large amounts of water accumulation, or large water drops building up inside the lenses, have your vehicle inspected by a dealer.


Continued

■ Painting the Vehicle


Refer to the temperature notice label affixed to the driver's doorjamb before painting the vehicle.

Painting the Vehicle

U.S. models



Canadian models



Accessories

When installing accessories, check the following:

- Do not install accessories on the windshield. They can obstruct your view and delay your reaction to driving conditions.
- Do not install any accessories over areas marked SRS Airbag, on the sides or backs of the front seats, on front or side pillars, or near the side windows. Accessories installed in these areas may interfere with proper operation of the vehicle's airbags or may be propelled into you or another occupant if the airbags deploy.
- Be sure electronic accessories do not overload electrical circuits or interfere with proper operation of your vehicle.
  Fuses P. 647
- Before installing any electronic accessory, have the installer contact a dealer for assistance. If possible, have a dealer inspect the final installation.

Accessories and Modifications

⚠WARNING

Improper accessories or modifications can affect your vehicle's handling, stability, and performance, and cause a crash in which you can be seriously hurt or killed.

Follow all instructions in this owner's manual regarding accessories and modifications.

⚠WARNING

Use of improperly designed, engineered or manufactured high-voltage battery assemblies could cause a fire in your vehicle.

A vehicle fire could result in a crash or injury.

Only use a genuine Acura high-voltage battery assembly, or its equivalent, in your vehicle.

Acura Genuine accessories are recommended to ensure proper operation on your vehicle.

Modifications

Do not modify your vehicle in a manner that may affect its handling, stability, or reliability, or install non-genuine Acura parts or accessories that may have a similar effect.

Even minor modifications to vehicle systems can affect overall vehicle performance. Always make sure all equipment is properly installed and maintained, and do not make any modification to your vehicle or its systems that might cause your vehicle to no longer meet federal, state, province, territory, and local regulations.

The on-board diagnostic port (OBD-II/SAE J1962 connector) installed on this vehicle is intended to be used with automobile system diagnostic devices or with other devices that Acura has approved. Use of any other type of device may adversely affect the vehicle's electronic systems or allow them to be compromised, possibly resulting in a system malfunction, drained battery, or other unexpected problems.

Do not modify or attempt to repair your vehicle's high-voltage hybrid power system or otherwise modify vehicle electrical systems. Disassembling or modifying electrical equipment can result in a crash or a fire.

If you ever need to replace your vehicle's high-voltage battery assembly outside of warranty coverage, we highly recommend that you only use a genuine Acura high-voltage battery assembly. Genuine Acura high-voltage battery assemblies are designed to work with your vehicle's hybrid power system and have been designed, engineered and manufactured to avoid overcharging situations. Non-genuine high-voltage battery assemblies may not have been similarly designed, engineered and manufactured, and installation of such assemblies could result in overcharging, fires, loss of power, or other conditions that may increase the likelihood of a crash or injury.


Handling the Unexpected

This chapter explains how to handle unexpected troubles.

Tools
Types of Tools 614
If a Tire Goes Flat
Changing a Flat Tire* 615
Temporarily Repairing a Flat Tire* 622
Power System Won't Start 634
Checking the Procedure 634
If the Keyless Access Remote Battery is Weak 635
Emergency Power System Off 636
Jump Starting 637
Overheating
How to Handle Overheating 639
Indicator, Coming On/Blinking
If the Low Oil Pressure Indicator Comes On ... 641
If the 12-Volt Battery Charging System Indicator Comes On 641
If the Malfunction Indicator Lamp Comes On or Blinks 642
If the Brake System Indicator (Red) Comes On 643
If the Speed-Sensitive Electric Power Steering (EPS) System Indicator Comes On 643
If the Low Tire Pressure/TPMS Indicator Comes On or Blinks 645
If the Transmission System Indicator Blinks along with the Warning Message 645
If the Power System Indicator Comes On .. 646
Fuses
Fuse Locations 647
Inspecting and Changing Fuses 655
Emergency Towing 656
When You Cannot Unlock the Fuel Fill Door 657
When You Cannot Open the Tailgate ..658
Refueling 659
Refueling From a Portable Fuel Container 659

* Not available on all models

Types of Tools



Types of Tools

The tools are stored in the cargo area.

Changing a Flat Tire*

If a tire goes flat while driving, grasp the steering wheel firmly, and brake gradually to reduce speed. Then, stop in a safe place. Replace the flat tire with a compact spare tire. Go to a dealer as soon as possible to have the full-size tire repaired or replaced.

1. Park the vehicle on firm, level, non-slippery surface and apply the parking brake.
2. Change the gear position to P.
3. Turn on the hazard warning lights and set the power mode to VEHICLE OFF.

Changing a Flat Tire*

Follow compact spare precautions:
Periodically check the tire pressure of the compact spare. It should be set to the specified pressure.
Specified Pressure: 60 psi (420 kPa, 4.2 kgf/cm^2)

When driving with the compact spare tire, keep the vehicle speed under 50 mph (80 km/h). Replace with a full-size tire as soon as possible.

The compact spare tire and wheel in your vehicle are specifically for this model. Do not use them with another vehicle. Do not use another type of compact spare tire or wheel with your vehicle.

Do not mount tire chains on a compact spare tire. If a chain-mounted front tire goes flat, remove one of the full-size rear tires and replace it with the compact spare tire. Remove the flat front tire and replace it with the full-size tire that was removed from the rear. Mount the tire chains on the front tire.

Do not use a puncture-repairing agent other than the one provided in the kit that came with your vehicle (if equipped). If a different agent is used, you may permanently damage the tire pressure sensor.

* Not available on all models

Continued


■ Getting Ready to Replace the Flat Tire



1. Push the rear edge of the handle on the floor lid and open the lid.



2. Take out the cargo floor box.



3. Take the jack, wheel nut wrench, and jack handle bar out of the tool case.

Changing a Flat Tire*


NOTICE

Do not use the jack if it doesn't work properly. Call your dealer or a professional towing service.


The wheel nut wrench supplied with your vehicle is specially adapted to fit the holder shaft. Do not use any other tool.

The subwoofer is located on the rear right side. Do not store anything in this area. Doing so may compromise vehicle audio performance.


* Not available on all models



4. Remove the cover on the cargo area lining to access the shaft for the spare tire hoist.




5. Put the wheel nut wrench with the jack handle bar on the hoist shaft.
Turn the wrench to the left to lower the spare tire to the ground.




6. Keep turning the wheel nut wrench to create slack in the cable.
7. Remove the bracket from the spare tire.

Continued



8. Place a wheel block or rock in front and rear of the wheel diagonal to the flat tire.




9. Place the compact spare tire (wheel side up) under the vehicle body, near the tire that needs to be replaced.



10. Loosen each wheel nut about one turn using the wheel nut wrench.


How to Set Up the Jack



1. Place the jack under the jacking point closest to the tire to be changed.



2. Turn the end bracket clockwise as shown in the image until the top of the jack contacts the jacking point.
▶ Make sure that the jacking point tab is resting in the jack notch.



3. Raise the vehicle, using the jack handle bar and the jack handle, until the tire is off the ground.

Continued

How to Set Up the Jack

⚠WARNING

The vehicle can easily roll off the jack, seriously injuring anyone underneath.


Follow the directions for changing a tire exactly, and no person should place any portion of their body under a vehicle that is supported by a jack.

Do not use the jack with people or luggage in the vehicle.


Use the jack provided in your vehicle.
Other jacks may not support the weight ("load") or may not fit the jacking point.

The following instructions must be followed to use the jack safely:
- Do not use while the power system is on.
- Use only where the ground is firm and level.
- Use only at the jacking points.
- Do not get in the vehicle while using the jack.
- Do not put anything on top of or underneath the jack.


■ Replacing the Flat Tire



1. Remove the wheel nuts and flat tire.



2. Wipe the mounting surfaces of the wheel with a clean cloth.
3. Mount the compact spare tire.
4. Screw the wheel nuts until they touch the lips around the mounting holes, and stop rotating.




5. Lower the vehicle and remove the jack. Tighten the wheel nuts in the order indicated in the image. Go around, tightening the nuts, two to three times in this order.
Wheel nut torque:
94 lbf·ft (127 N·m, 13.0 kgf·m)


Replacing the Flat Tire

Do not over tighten the wheel nuts by applying extra torque using your foot or a pipe.

Storing the Flat Tire



1. Remove the center cap.
2. Place the flat tire face up under the hoist.
3. Insert the hoist bracket into the center hole of the flat tire.
4. Slowly turn the wheel nut wrench clockwise to take up the hoist cable slack. Make sure the bracket is seated in the center hole of the flat tire.



5. Turn the wheel nut wrench with the jack handle bar (clockwise) until the flat tire rests against the underbody of the vehicle, and you hear the hoist click.
6. Securely store the jack, wheel nut wrench, and jack handle bar back in the tool case. Store the case in the cargo area.

Storing the Flat Tire

⚠WARNING

Loose items can fly around the interior in a crash and can seriously injure the occupants.
Store the jack and tools securely before driving.

TPMS and the Spare Tire

If you replace a flat tire with the spare tire, the low tire pressure/TPMS indicator comes on while you are driving. After driving for a few miles (kilometers), the indicator will start blinking for a short time and then stay on. **Tire Pressure Monitor Problem** appears on the multi-information display (MID), but this is normal.

If you replace the tire with a specified regular tire, the warning message on the MID and the low tire pressure/TPMS indicator will go off after a few miles (kilometers).

TPMS and the Spare Tire

The system cannot monitor the pressure of the spare tire. Manually check the spare tire pressure to be sure that it is correct.

Use TPMS specific wheels. Each is equipped with a tire pressure sensor mounted inside the tire behind the valve stem.

Temporarily Repairing a Flat Tire*

If the tire has a large cut or is otherwise severely damaged, you will need to have the vehicle towed. If the tire only has a small puncture, from a nail for instance, you can use the temporary tire repair kit so that you can drive to the nearest service station for a more permanent repair.

If a tire goes flat while driving, grasp the steering wheel firmly, and brake gradually to reduce speed. Then stop in a safe place.

1. Park the vehicle on a firm, level, and non-slippery surface and apply the parking brake.
2. Change the gear position to P.
3. Turn on the hazard warning lights and set the power mode to VEHICLE OFF.

Temporarily Repairing a Flat Tire*

The kit should not be used in the following situations. Instead, contact a dealer or roadside assistance to have the vehicle towed.

- The tire sealant has expired.
- More than one tire is punctured.
- The puncture or cut is larger than 3/16 inch (4mm).
- The tire side wall is damaged or the puncture is outside the contact area.



When the puncture is:	Use Kit
Smaller than 3/16 inch (4 mm)	Yes
Larger than 3/16 inch (4 mm)	No

- Damage has been caused by driving with the tires extremely under inflated.
- The tire bead is no longer seated.
- The rim is damaged.


Do not remove a nail or screw that punctured the tire. If you remove it from the tire, you may not be able to repair the puncture using the kit.

NOTICE

Do not use a puncture-repairing agent other than the one provided in the kit that came with your vehicle. If a different agent is used, you may permanently damage the tire pressure sensor.

 * Not available on all models

Getting Ready to Temporarily Repair the Flat Tire




Getting Ready to Temporarily Repair the Flat Tire

Repair notification label and speed restriction label are applied to the side of temporary tire repair kit.

When making a temporary repair, carefully read the instruction manual provided with the kit.


Continued



1. Pull the handle on the cargo area floor lid and open the lid.




2. Take out the cargo floor box.




3. Take the kit out of the case.
4. Place the kit face up, on flat ground near the flat tire, and away from traffic. Do not place the kit on its side.


Injecting Sealant and Air



1. Remove the valve cap from the tire valve stem.



2. Remove the sealant/air hose from the packaging.



3. Attach the sealant/air hose onto the tire valve stem. Screw it until it is tight.

Injecting Sealant and Air

⚠WARNING

Tire sealant contains substances that are harmful and can be fatal if swallowed.


If accidentally swallowed, do not induce vomiting. Drink plenty of water and get medical attention immediately.


For skin or eye contact, flush with cool water and get medical attention if necessary.

In cold temperatures, the sealant may not flow easily. In this situation, warm it up for five minutes before using.

The sealant can permanently stain clothing and other materials. Be careful during handling and wipe away any spills immediately.

Continued





4. Plug in the compressor to the accessory power socket.
▶ Be careful not to pinch the cord in a door or window.
▶ Do not plug any other electric devices into other accessory power sockets.
➡ **Accessory Power Sockets** P. 217

5. Turn the power system on.
▶ Keep the power system on while injecting sealant and air.
➡ **Carbon Monoxide Gas** P. 80

6. Turn the selector knob to **REPAIR**.

Injecting Sealant and Air

⚠WARNING

Running the engine with the vehicle in an enclosed or even partly enclosed area can cause a rapid build-up of toxic carbon monoxide.

Breathing this colorless, odorless gas can cause unconsciousness and even death. Only run the engine to power the air compressor with the vehicle outdoors.


NOTICE


Do not operate the temporary tire repair kit compressor for more than 15 minutes. The compressor can overheat and become permanently damaged.


There are three accessory power sockets:
- In the console compartment
- In the front of the center pocket
- In the left side panel in the cargo area

➡ **Accessory Power Sockets** P. 217

Until the sealant injection is complete, the pressure shown on the pressure gauge will appear higher than actual. After the sealant injection is complete the pressure will drop and then begin to rise again as the tire is inflated with air. This is normal. To accurately measure the air pressure using the gauge, turn the air compressor off only after the sealant injection is complete.







7. Press the inflator switch to turn on the compressor.
▶ The compressor starts injecting sealant and air into the tire.
▶ When the sealant injection is complete, continue to add air.

8. After the air pressure reaches 35 psi (240 kPa), turn off the kit.
▶ To check the pressure, occasionally turn off the compressor and read the gauge.

9. Unplug the power plug from the accessory power socket.

10. Unscrew the sealant/air hose from the tire valve stem. Reinstall the valve cap.


11. Press the pressure relief button until the gauge returns to 0 psi (0 kPa).

Injecting Sealant and Air

If the required air pressure is not reached within 10 minutes, the tire may be too severely damaged for the kit to provide the necessary seal, and your vehicle will need to be towed.


See an Acura dealer for a replacement sealant bottle and proper disposal of an empty bottle.

Continued




12. Apply the repair notification label to the flat surface of the wheel.
▶ The wheel surface must be clean to ensure the label adheres properly.


■ Distributing the Sealant in the Tire



1. Apply the speed restriction label to the location as shown.
2. Drive the vehicle for about 10 minutes.
▶ Do not exceed 50 mph (80 km/h).
3. Stop the vehicle in a safe place.



4. Recheck the air pressure using the sealant/air hose on the compressor.



5. Turn the selector knob to **AIR**.

▶ Do not turn the air compressor on to check the pressure.

➡ **Inflating an Under-inflated Tire** P. 631

6. If the air pressure is

- Less than 25 psi (175 kPa):

Do not add air or continue driving. The leak is too severe. Call for help and have your vehicle towed.


➡ **Emergency Towing** P. 656

- 35 psi (240 kPa) or more:

Continue driving for another 10 minutes or until you reach the nearest service station, whichever is sooner. Do not exceed 50 mph (80 km/h). If you have not reached a service station, stop and check the tire pressure.

▶ If the air pressure does not go down after 10 minutes of driving, you do not need to check the tire pressure again.

Continued



- Greater than 25 psi (175 kPa), but less than 35 psi (240 kPa):

Turn the air compressor on to inflate the tire until the tire pressure reaches 35 psi (240 kPa).

➡ **Inflating an Under-inflated Tire** P. 631


Then drive carefully for 10 more minutes or until you reach the nearest service station, whichever is sooner. Do not exceed 50 mph (80 km/h). If you have not reached a service station, stop and check the tire pressure.

▶ You should repeat this procedure as long as the air pressure is within this range.

7. Unscrew the sealant/air hose from the tire valve stem.
Reinstall the valve cap.

8. Press the pressure relief button until the gauge returns to 0 psi (0 kPa).

9. Repackage and properly stow the kit.



Distributing the Sealant in the Tire


⚠WARNING

Running the engine with the vehicle in an enclosed or even partly enclosed area can cause a rapid build-up of toxic carbon monoxide.

Breathing this colorless, odorless gas can cause unconsciousness and even death. Only run the engine to power the air compressor with the vehicle outdoors.

■ Inflating an Under-inflated Tire

You can use the kit to inflate a non-punctured, under-inflated tire.




1. Open the cargo area floor lid.

➡ **Getting Ready to Temporarily Repair the Flat Tire** P. 623


2. Remove the kit from the case.

3. Place the kit, face up, on flat ground near the flat tire, away from traffic. Do not place the kit on its side.

4. Remove the sealant/air hose from the kit.



5. Remove the valve cap.




6. Attach the sealant/air hose onto the tire valve stem. Screw it until it is tight.


Inflating an Under-inflated Tire

NOTICE

Do not operate the temporary tire repair kit compressor for more than 15 minutes. The compressor can overheat and become permanently damaged.

Continued





7. Plug in the kit to the accessory power socket.
- ▶ Be careful not to pinch the cord in a door or window.
- ▶ Do not plug any other electronic devices into other accessory power sockets.
  - ➡ **Accessory Power Sockets** P. 217

8. Turn the power system on.
- ▶ Keep the power system on while injecting air.
  - ➡ **Carbon Monoxide Gas** P. 80

9. Turn the selector knob to **AIR**.

10. Press the inflator switch to turn on the kit.
- ▶ The compressor starts to inject air into the tire.


11. Inflate the tire to the specified air pressure.

Inflating an Under-inflated Tire

⚠WARNING

Running the engine with the vehicle in an enclosed or even partly enclosed area can cause a rapid build-up of toxic carbon monoxide.

Breathing this colorless, odorless gas can cause unconsciousness and even death. Only run the engine to power the air compressor with the vehicle outdoors.



12. Turn off the kit.
- ▶ Check the pressure gauge on the air compressor.
- ▶ If overinflated, press the pressure relief button.

13. Unplug the kit from the accessory power socket.

14. Unscrew the sealant/air hose from the tire valve stem. Reinstall the valve cap.

15. Press the pressure relief button until the gauge returns to 0 psi (0 kPa).

16. Repackage and properly stow the kit.

Checking the Procedure

When the **READY** indicator does not come on and the **Ready To Drive** message does not appear on the multi-information display, check the following items and take appropriate action.

Checking the Procedure


If you must start the vehicle immediately, use an assisting vehicle or booster battery to jump start it.

➡ **Jump Starting** P. 637


Checklist	Condition	What to Do
Check if the related indicator or multi-information display messages come on.	The **Temperature Is Too Cold For Vehicle To Operate** message appears.	➡ **Multi-Information Display (MID) Warning and Information Messages** P. 105
	The **To Start, Hold Remote Near Start Button** message appears. ▶Make sure the keyless access remote is in its operating range. ➡ **POWER Button Operating Range** P. 172	➡ **If the Keyless Access Remote Battery is Weak** P. 635
	The **POWER SYSTEM** indicator comes on.	Have your vehicle checked by a dealer.
	The transmission system indicator blinks and **Transmission Problem Apply Parking Brake When Parked** message appears.	➡ **If the Transmission System Indicator Blinks along with the Warning Message** P. 645
Check the brightness of the interior lights.	The interior lights are dim or do not come on at all.	Have the 12-volt battery checked by a dealer.
	The interior lights come on normally.	Check all fuses, or have your vehicle checked by a dealer. ➡ **Inspecting and Changing Fuses** P. 655
Check the gear position.	The transmission is not in P.	Change the gear position to P.
Check the immobilizer system indicator.	When the immobilizer system indicator is blinking, the power system cannot be turned on.	➡ **Immobilizer System Indicator** P. 96

If the Keyless Access Remote Battery is Weak

If the beeper sounds, the **To Start, Hold Remote Near Start Button** message appears on the multi-information display, and the indicator on the **POWER** button flashes, and the **READY** indicator does not come on.
Turn on the power system as follows:



1. Touch the center of the **POWER** button with the **A** logo on the keyless access remote while the indicator on the **POWER** button is flashing. The buttons on the keyless access remote should be facing you.
▶ The indicator flashes for about 30 seconds.



2. Depress the brake pedal and press the **POWER** button within 10 seconds after the beeper sounds while the indicator stays on.
▶ If you don't depress the pedal, the mode will change to ACCESSORY.

Emergency Power System Off

The **POWER** button may be used to turn the power system off due to an emergency situation even while driving. If you must turn the power system off, do either of the following operations:

- Press and hold the **POWER** button for about two seconds.
- Firmly press the **POWER** button three times.

The steering wheel will not lock. However, because turning off the power system disables the power assist the power system provides to the steering and braking systems, it will require significantly more physical effort and time to steer and slow the vehicle. Use both feet on the brake pedal to slow down the vehicle and stop immediately in a safe place.


The gear position automatically changes to P after the vehicle comes to a complete stop. Then, the power mode changes to VEHICLE OFF.

Emergency Power System Off


Do not press the **POWER** button while driving unless it is absolutely necessary for the power system to be turned off.
If you press the **POWER** button while driving, the beeper sounds.

Jump Starting Procedure

Turn off the power to electric devices, such as audio and lights. Turn off the power system, then open the hood.



1. Pull up on the engine cover, remove it from the pins.
- ▶ Start on the passenger side and lift up on the outermost edge of the cover.
- ▶ Move towards the driver side while applying uniform upward pressure.



2. Connect the first jumper cable to your vehicle's 12-volt battery ⊕ terminal.

3. Connect the other end of the first jumper cable to the booster battery ⊕ terminal.
- ▶ Use a 12-volt booster battery only.
- ▶ When using an automotive battery charger to boost your 12-volt battery, select a lower charging voltage than 15 volt. Check the charger manual for the proper setting.

4. Connect the second jumper cable to the booster battery ⊖ terminal.

Jump Starting

⚠WARNING


A 12-volt battery can explode if you do not follow the correct procedure, seriously injuring anyone nearby.

Keep all sparks, open flames, and smoking materials away from the 12-volt battery.

Securely attach the jumper cables clips so that they do not come off when the engine vibrates. Also be careful not to tangle the jumper cables or allow the cable ends to touch each other while attaching or detaching the jumper cables.

12-volt Battery performance degrades in cold conditions and may prevent the engine from starting.

Continued



5. Connect the other end of the second jumper cable to the engine hanger as shown. Do not connect this jumper cable to any other part.
6. If your vehicle is connected to another vehicle, start the assisting vehicle's engine and increase its rpm slightly.
7. Attempt to start your vehicle's engine. If it turns over slowly, check that the jumper cables have good metal-to-metal contact.

■ What to Do After the Engine Starts

Once your vehicle's engine has started, remove the jumper cables in the following order.

1. Disconnect the jumper cable from your vehicle's ground.
2. Disconnect the other end of the jumper cable from the booster battery ⊖ terminal.
3. Disconnect the jumper cable from your vehicle's 12-volt battery ⊕ terminal.
4. Disconnect the other end of the jumper cable from the booster battery ⊕ terminal.

Have your vehicle inspected by a nearby service station or a dealer.

How to Handle Overheating

Overheating symptoms are as follows:

- The high temperature indicator comes on or the engine suddenly loses power.
- The **Stop Driving When Safe. Engine Temperature Too Hot** message appears on the multi-information display (MID).
- Steam or spray comes out of the engine compartment.

■ First thing to do

1. Immediately park the vehicle in a safe place.

2. Turn off all accessories and turn on the hazard warning lights.

▶ **No steam or spray present:** Keep the power system on and open the hood.

▶ **Steam or spray is present:** Turn off the power system and wait until it subsides. Then open the hood.

How to Handle Overheating

⚠WARNING

Steam and spray from an overheated engine can seriously scald you.


Do not open the hood if steam is coming out.

NOTICE

Continuing to drive with the high temperature indicator on may damage the engine.

Continued

■ Next thing to do



1. Check that the cooling fan is operating and turn the power system off once the high temperature indicator goes off.
   ▶ If the cooling fan is not operating, immediately turn the power system off.
2. Once the engine has cooled down, inspect the coolant level and check the cooling system components for leaks.
   ▶ If the coolant level in the reserve tank is low, add coolant until it reaches the **MAX** mark.
   ▶ If there is no coolant in the reserve tank, check that the radiator is cool. Cover the radiator cap with a heavy cloth and open the cap. If necessary, add coolant up to the base of the filler neck, and put the cap back on.

■ Last thing to do

Once the engine has cooled sufficiently, turn the power system on, and check the high temperature indicator.
If the high temperature indicator is off, resume driving. If it stay on, contact a dealer for repairs.

How to Handle Overheating

⚠WARNING

Removing the radiator cap while the engine is hot can cause the coolant to spray out, seriously scalding you.

Always let the engine and radiator cool down before removing the radiator cap.

If the coolant is leaking, contact a dealer for repairs.

Use water as an emergency/temporary measure only. Have a dealer flush the system with proper antifreeze as soon as possible.

Continuing to drive with the **Stop Driving When Safe. Engine Temperature Too Hot** message on the multi-information display may damage the engine.

If the Low Oil Pressure Indicator Comes On



■ **Reasons for the indicator to come on**

Comes on when the engine oil pressure is low.

■ **What to do as soon as the indicator comes on**

1. Immediately park the vehicle on level ground in a safe place.

2. If necessary, turn the hazard warning lights on.

■ **What to do after parking the vehicle**

1. Turn the power system off and let it sit for approximately three minutes.

2. Open the hood and check the oil level.

➡ **Oil Check** P. 573

3. Start the engine and check the low oil pressure indicator.

▶ The indicator goes off: Start driving again.

▶ The indicator does not go off within 10 seconds: Immediately turn the power system off and contact a dealer for repairs.

If the Low Oil Pressure Indicator Comes On

NOTICE

Running the engine with low oil pressure can cause serious mechanical damage almost immediately.

If the 12-Volt Battery Charging System Indicator Comes On



■ **Reasons for the indicator to come on**

Comes on when the 12-Volt battery is not being charged.

■ **What to do when the indicator comes on**

Turn off the climate control system, rear defogger, and other electrical systems, and immediately contact a dealer for repairs.

If the 12-Volt Battery Charging System Indicator Comes On

If you need to stop temporarily, do not turn off the power system. Restarting the power system may rapidly discharge the battery.

If the Malfunction Indicator Lamp Comes On or Blinks



■ **Reasons for the indicator lamp to come on or blink**

- Comes on when there is a problem with the engine emissions control system.
- Blinks when engine misfiring is detected.

■ **What to do when the indicator lamp comes on**

Avoid high speeds and immediately get your vehicle inspected at a dealer.

■ **What to do when the indicator lamp blinks**

Park the vehicle in a safe place with no flammable items and wait at least 10 minutes or more with the engine stopped until it cools.

If the Malfunction Indicator Lamp Comes On or Blinks

NOTICE

If you drive with the malfunction indicator lamp on, the emissions control system and the engine could be damaged.

If the malfunction indicator lamp blinks again when restarting the power system, drive to the nearest dealer at 31 mph (50 km/h) or less. Have your vehicle inspected.

If the Brake System Indicator (Red) Comes On

U.S.



Canada



■ **Reasons for the indicator to come on**

- The brake fluid is low.
- There is a malfunction in the brake system.

■ **What to do when the indicator comes on while driving**

Depress the brake pedal lightly to check pedal pressure.

- If normal, check the brake fluid level the next time you stop.
- If abnormal, take immediate action. If necessary, downshift the transmission to slow the vehicle using regenerative braking.

If the Speed-Sensitive Electric Power Steering (EPS) System Indicator Comes On



■ **Reasons for the indicator to come on**

- Comes on when there is a problem with the EPS system.
- If you depress the accelerator pedal repeatedly to increase the engine speed while the engine is idling, the indicator comes on, and sometimes the steering wheel becomes harder to operate.

■ **What to do when the indicator comes on**

Stop the vehicle in a safe place and restart the power system.
If the indicator comes on and stays on, immediately have your vehicle inspected by a dealer.

If the Brake System Indicator (Red) Comes On

Have your vehicle repaired immediately.
It is dangerous to drive with low brake fluid. If there is no resistance from the brake pedal, stop immediately in a safe place. If necessary downshift the gears.

If the brake system indicator and **ABS** indicator come on simultaneously, the electronic brake distribution system is not working. This can result in vehicle instability under sudden braking.
Have your vehicle inspected by a dealer immediately.

If both red and amber brake system indicators come on, stop the vehicle in a safe place and have it inspected by a dealer immediately.

If the Electric Parking Brake System Indicator Comes On



■ **Reasons for the indicator to come on**

Comes on when there is a problem with the electric parking brake system.

■ **What to do when the indicator comes on**

Avoid using the parking brake and immediately get your vehicle inspected at a dealer.

■ **What to do when the electric parking brake indicator comes on or blinks at the same time**

Release the parking brake.

➲ **Parking Brake** P. 517

- If the electric parking brake indicator remains on or blinks, even after releasing the parking brake, immediately stop the vehicle in a safe place, and call a dealer.

  ▶ Preventing the vehicle from moving, change the gear position to P.
- If only the electric parking brake indicator goes off, immediately get your vehicle inspected at a dealer.

If the Electric Parking Brake System Indicator Comes On

If you apply the parking brake, it may not release.

If the electric parking brake indicator also turns on, the parking brake is still applied.

When the electric parking brake indicator blinks at the same time as the electric parking brake system indicator, the system must be checked. The parking brake may not operate under these conditions.

If the Low Tire Pressure/TPMS Indicator Comes On or Blinks



■ **Reasons for the indicator to come on or blink**

A tire pressure is significantly low. If there is a problem with the TPMS with Tire Fill Assist or the compact spare tire* is installed, the indicator blinks for about one minute, and then stays on.

■ **What to do when the indicator comes on**

Drive carefully and avoid abrupt cornering and hard braking.

Stop your vehicle in a safe place. Check the tire pressure and adjust the pressure to the specified level. The specified tire pressure is on a label on the driver side doorjamb.

■ **What to do when the indicator blinks**

Have the tire inspected by a dealer as soon as possible. If the compact spare tire* causes the indicator to blink, change the tire to a full-size tire. The indicator goes off after driving for a few miles (kilometers).

If the Transmission System Indicator Blinks along with the Warning Message





■ **Reasons for the indicator to blink**

The transmission is malfunctioning.

■ **What to do when the indicator blinks**

- Immediately have your vehicle inspected by a dealer.

If the Low Tire Pressure/TPMS Indicator Comes On or Blinks

NOTICE

Driving on an extremely underinflated tire can cause it to overheat. An overheated tire can fail. Always inflate your tires to the prescribed level.

TPMS Fill Assist provides visual and audible assistance during tire pressure adjustment. With the power mode in ON, while you adjust tire pressure up or down, the system alerts you as follows:

Below recommended pressure: The beeper sounds and exterior lights flash once every five seconds.

At recommended pressure: The beeper sounds and the exterior lights flash rapidly for five seconds.

Above recommended pressure: The beeper sounds and lights flash twice every three seconds.

If the Transmission System Indicator Blinks along with the Warning Message

You may not be able to turn on the power system.

Make sure to set the parking brake when parking your vehicle.

Call a professional towing service if you need to tow your vehicle.

➡ **Emergency Towing** P. 656

* Not available on all models

If the Power System Indicator Comes On



■ **Reasons for the indicator to come on**

Comes on when there is a problem with the hybrid system.

■ **What to do when the indicator comes on**


Avoid high speeds and immediately have your vehicle inspected by a dealer.

Fuse Locations

If any electrical devices are not working, set the power mode to VEHICLE OFF and check to see if any applicable fuse is blown.

Engine Compartment Fuse Box Type A

Fuse locations are shown on the fuse box cover. Locate the fuse in question by the fuse number and box cover number. Located near the brake fluid reservoir. Push the tabs to open the box.



Circuit protected and fuse rating


	Circuit Protected	Amps
1	–	–
2	–	–
3	ACG FR	15 A
4	Washer	15 A
5	IG1 OP	(7.5 A)
6	ECU FR	7.5 A
7	VBSOL	(10 A)
8	FI Sub	15 A
9	DBW	15 A
10	FI Main	15 A
11	IG Coil	15 A
12	DRL R	10 A
13	DRL L	10 A
14	Injector	20 A
15	Radio	20 A
16	Back Up	10 A
17	MG Clutch	(7.5 A)
18	FR Fog*	(7.5 A)
19	–	–
20	H/L HI R	7.5 A
21	–	–
22	Small LT	10 A
23	–	–
24	H/L HI L	7.5 A
25	SBW	15 A
26	H/L LO R	10 A
27	H/L LO L	10 A
28	Oil LVL	7.5 A
29	Main Fan	30 A
30	Sub Fan	30 A
31	Wiper Main	30 A

* Not available on all models

Continued

Engine Compartment Fuse Box Type B

Fuse locations are shown on the fuse box cover. Locate the fuse in question by the fuse number and box cover number. Located near the battery. Push the tabs to open the box.




Circuit protected and fuse rating

	Circuit Protected	Amps
1	Main Fuse	200 A
2	AS F/B-1	50 A
	DR F/B-2	50 A
	DR F/B-1	50 A
	RR DEF	40 A
	RR F/B-2	60 A
	FR Blower	40 A
	H/L Washer*	(30 A)
	RR BLOWER & BMS	30 A
3	SUB F/B-1	60 A
	VSA MTR	40 A
	AS F/B-2	60 A
	R/B Main	60 A
	EPS	70 A
	SUB F/B-2	60 A
	VSA FSR	20 A
	ESB	40 A
4	Stop & Horn & Hazard	30 A
5	EOP RLY	30 A
6	RR F/B-1	40 A
7	FI Main	40 A
8	Stop & Horn	20 A
9	Hazard	10 A
10	BMS	7.5 A
11	–	–

* Not available on all models

■ Engine Compartment Fuse Box Type C

Located near the ⊕ terminal on the battery.



Pull up the cover.
Replacement of this fuse should be done by a dealer.


Fuse location is shown on the back of the positive battery terminal cover.

■ Circuit protected and fuse rating

	Circuit Protected	Amps
🕮	Fan Main	60 A

■ Driver's Side Interior Fuse Box Type A

Located under the dashboard.




Fuse locations are shown on the label on the outer side of the side panel cover. Locate the fuse in question by the fuse number and label number.

■ Circuit protected and fuse rating

	Circuit Protected	Amps
1	AS Door Lock	10 A
2	RR DR Door Lock	7.5 A
3	DR Door Lock	7.5 A
4	FR AS Door Unlock	10 A
5	RR DR Door Unlock	7.5 A
6	DR Door Unlock	(7.5 A)
7	D/L Main	20 A
8	–	–
9	ETS TELE	20 A
10	IG1 RR	15 A
11	Meter	7.5 A
12	IG1 FR	20 A
13	ACC	7.5 A
14	–	–
15	DR P/Seat (SLI)	20 A
16	S/R	20 A
17	RR DR P/W	20 A
18	Smart	10 A
19	FR DR P/W	20 A
20	–	–
21	Fuel Pump	20 A
22	IG1 AS	15 A
23	ABS/VSA	7.5 A
24	ACG AS	7.5 A
25	STRLD	7.5 A
26	IG2 HAC	7.5 A
27	DRL	7.5 A
28	ACC Key Lock	7.5 A
29	DR P/Seat (LUM)	7.5 A
30	INT Lights	7.5 A
31	ETS TILT	20 A
32	DR P/Seat (REC)	20 A
33	–	–
34	–	–

■ Driver's Side Interior Fuse Box Type B

Located under the type A driver's side interior fuse box. Take off the cover to open.



Fuse locations are shown on the label on the back side of the side panel cover. Locate the fuse in question by the fuse number and label number.


■ Circuit protected and fuse rating

	Circuit Protected	Amps
1	DCT	20 A
2	–	–
3	DCT	20 A
4	IG Main	30 A
5	Hybrid System	10 A
6	Hybrid System	15 A
7	Hybrid System	15 A
8	DCT	30 A

Continued

■ Driver's Side Interior Fuse Box Type C

Located under the type A driver's side interior fuse box. Take off the cover to open.




Fuse locations are shown on the label on the back side of the side panel cover. Locate the fuse in question by the fuse number and label number.

■ Circuit protected and fuse rating

	Circuit Protected	Amps
1	ADS	30 A
2	–	–
3	–	–
4	IG Main	30 A
5	Smart	10 A
6	A/C Water Pump	10 A
7	–	–
8	Starter Motor	30 A

Passenger's Side Interior Fuse Box

Located on the lower side panel. Take off the cover to open.



Fuse locations are shown on the cover.

Circuit protected and fuse rating

	Circuit Protected	Amps
1	–	–
2	RR AS P/W	20 A
3	ACM	20 A
4	FR DEF*	(15 A)
5	AVS Heated Seat	20 A
6	FR AS P/W	20 A
7	AS P/Seat (SLI)	20 A
8	AS P/Seat (REC)	20 A
9	AS P/Seat (LUM)	(7.5 A)
10	Spare	5 A
11	Heated Steering*	(10 A)
12	–	–
13	–	–
14	RR ACC Socket	20 A
15	FR ACC Socket	20 A
16	–	–
17	–	–
18	AMP	30 A
19	SRS	10 A
20	AS ECU	7.5 A
21	Option	7.5 A
22	–	–
23	–	–
24	OPDS	7.5 A
25	ILLUMI (INT)	5 A
26	–	–
27	CTR ACC Socket	20 A
28	AC INVTR*	(30 A)


* Not available on all models

Continued

■ Rear Fuse Box

Located on the left side of cargo area. Remove the cover by prying on the edge of the cover using a flat-tip screwdriver.

▶ Wrap the flat-tip screwdriver with a cloth to prevent scratches.




Fuse locations are shown on the cover. Locate the fuse in question by the fuse number and box cover number.


■ Circuit protected and fuse rating


	Circuit Protected	Amps
1	PTG Closer	20 A
2	–	–
3	USB CHARGE	15 A
4	Fuel Lid	7.5 A
5	Seat Slide	20 A
6	–	–
7	RR Heat Seat*	(20 A)
8	–	–
9	–	–
10	–	–
11	–	–
12	Rear Wiper	10 A
13	Rear ECU	7.5 A
14	SH-AWD	(20 A)
15	EPB-R	30 A
16	EPB-L	30 A
17	–	–
18	PTG MTR	40 A

* Not available on all models

Inspecting and Changing Fuses







1. Set the power mode to VEHICLE OFF. Turn headlights and all accessories off.
2. Remove the fuse box cover.
3. Check the large fuse in the engine compartment.
▶ If the fuse is blown, use a Phillips-head screwdriver to remove the screw and replace it with a new one.

4. Inspect the small fuses in the engine compartment and the vehicle interior.
▶ If there is a blown fuse, remove it with the fuse puller and replace it with a new one.

Inspecting and Changing Fuses

NOTICE
Replacing a fuse with one that has a higher rating greatly increases the chances of damaging the electrical system.

Replace fuse with a spare fuse of the same specified amperage.
Confirm the specified amperage using the charts on P. 647 to P. 654.

There is a fuse puller in the engine compartment fuse box.

Call a professional towing service if you need to tow your vehicle.

■ **Flat bed equipment**
The operator loads your vehicle on the back of a truck.
This is the only way you can safely transport your vehicle.
Any other towing method will damage the vehicle's drive system.

Emergency Towing


NOTICE
Trying to lift or tow your vehicle by the bumpers will cause serious damage. The bumpers are not designed to support the vehicle's weight.

NOTICE
Improper towing such as towing behind a motorhome or other motor vehicle can damage the transmission.

Never tow your vehicle with just a rope or chain.
It is very dangerous, since ropes or chains may shift from side to side or break.

What to Do When Unable to Unlock the Fuel Fill Door

If you cannot unlock the fuel fill door, use the following procedure.



1. Open the tailgate.
2. Lift the cargo floor lid by the handle in the center.
3. Remove the cargo floor box and set it aside.
4. Wrap a cloth around the flat-tip screwdriver. Put it into the cover slot (as shown in the image) and remove the cover.




5. Pull the release lever toward you.
▶ The release lever unlocks the fuel fill door when it is pulled.

What to Do When Unable to Unlock the Fuel Fill Door


After taking these steps, contact a dealer to have the vehicle checked.

What to Do When Unable to Open the Tailgate

If you cannot open the tailgate, use the following procedure.



1. Put screwdriver into the cover (as shown in the image) and remove the cover.
▶ Wrap a cloth around the flat-tip screwdriver.



2. To open the tailgate, push the tailgate while sliding the lever to the right.

What to Do When Unable to Open the Tailgate


Following up:
After taking these steps, contact a dealer to have the vehicle checked.

When you open the tailgate from inside, make sure there is enough space around the tailgate, and it does not hit anyone or any object.

Refueling From a Portable Fuel Container

If you have run out of fuel and need to refuel your vehicle from a portable fuel container, use the funnel provided with your vehicle.





1. Turn off the power system.
2. Press the fuel fill door release button.
   ▶ The fuel fill door opens.
3. Take the funnel out of its clip in the cargo area.
   Types of Tools P. 614
4. Place the end of the funnel on the lower part of filler opening, then insert it slowly and fully.
   ▶ Make sure that the end of the funnel goes down along with the filler pipe.
5. Fill the tank with fuel from the portable fuel container.
   ▶ Pour fuel carefully so you do not spill any.
6. Remove the funnel from the filler neck.
   ▶ Wipe up any fuel from the funnel before storing it.
7. Shut the fuel fill door by hand.

Refueling From a Portable Fuel Container

⚠WARNING

Gasoline is highly flammable and explosive. You can be burned or seriously injured when handling fuel.

- **Turn the power system off, and keep heat, sparks, and flame away.**
- **Handle fuel only outdoors.**
- **Wipe up spills immediately.**

NOTICE

Do not insert the nozzle of a portable fuel container or any funnel other than the one provided with your vehicle. Doing so can damage the fuel system.
Do not try to pry open or push open the sealed fuel tank with foreign objects. This can damage the fuel system and its seal.

Make sure the fuel in the portable fuel container is gasoline before you refuel.

This page intentionally left blank.

Information

This chapter includes your vehicle's specifications, locations of identification numbers, and other information required by regulation.



Specifications 662
Identification Numbers
Vehicle Identification Number (VIN), Engine Number, Motor Number, and Transmission Number 664
Devices that Emit Radio Waves 665
Reporting Safety Defects 666
Emissions Testing
Testing of Readiness Codes 667
Warranty Coverages 668
Authorized Manuals 670
Client Service Information 671

Vehicle Specifications

Model	MDX
No. of Passengers:	
Front	2
Rear (2nd)	2*1 3*2
Rear (3rd)	2
Total	6*1 7*2
Weights:	
Gross Vehicle Weight Rating	See the certification label on the driver's doorjamb
Gross Axle Weight Rating (Front)	See the certification label on the driver's doorjamb
Gross Axle Weight Rating (Rear)	See the certification label on the driver's doorjamb

*1: Models with second row captain seat
*2: Models with second row bench seat

Air Conditioning

Refrigerant Type	HFC-134a (R-134a)
Charge Quantity	23.8 – 25.6 oz (675 – 725 g)
Lubricant Type	ND-OIL11 (POE)
Quantity	8.54 – 9.46 cu-in (140 – 155 cm^3)

Engine Specifications

Displacement	182.8 cu-in (2,997 cm^3)	
Spark Plugs	NGK DENSO	ILZKR7B11 SXU22HCR11

Fuel

Type	Unleaded premium gasoline, Pump octane number of 91 or higher
Fuel Tank Capacity	19.4 US gal (73.3 L)

Washer Fluid

Tank Capacity	U.S.: 4 US qt (3.8 L) Canada: 5.6 US qt (5.3 L)

Light Bulbs

Headlights (High/Low Beam)	LED
Fog Lights*	LED
Front Turn Signal/Side Marker/ Parking Lights	LED
Daytime Running Lights	LED
Side Turn Signal Lights (on Door Mirrors)	LED
Brake Lights	21 W
Rear Side Marker Lights	LED
Taillights	LED
Back-Up Lights	21 W
Rear Turn Signal Lights	21 W
High-Mount Brake Light	LED
Rear License Plate Lights	LED
Puddle Lights	LED
Interior Lights	
Front, Second Row and Third Row Lights	LED
Front and Rear Ambient Lights	LED
Vanity Mirror Lights	1.4 W
Door Courtesy Lights	3.4 W
Door Inner Handle Lights	LED
Front and Rear* Console Compartment Lights	LED
Glove Box Light	1.4 W
Foot Lights	5 W
Cargo Area Lights	5 W

* Not available on all models

■ Brake Fluid

Specified	Acura Heavy Duty Brake Fluid DOT 3

■ Dual Clutch Transmission Fluid

Specified	Acura ATF DW-1 (automatic transmission fluid)	
Capacity	Change	3.7 US qt (3.5 L)

■ Twin Motor Unit Fluid

Specified	Acura ATF DW-1 (automatic transmission fluid)	
Capacity	Change	2.56 US qt (2.42 L)

■ Engine Oil

Recommended	·Genuine Acura Motor Oil 0W-20 ·API Premium-grade 0W-20 detergent oil	
Capacity	Change	4.2 US qt (4.0 L)
	Change including filter	4.5 US qt (4.3 L)

■ Engine Coolant

Specified	Acura Long Life Antifreeze/Coolant Type 2
Ratio	50/50 with distilled water
Capacity	2.03 US gal (7.68 L) (change including the remaining 0.22 US gal (0.82 L) in the reserve tank)

■ Inverter Coolant

Specified	Acura Long Life Antifreeze/Coolant Type 2
Ratio	50/50 with distilled water


■ Tire

Regular	Size	245/50R20 102H
	Pressure psi (kPa [kgf/cm²])	35 (240 [2.4])
Compact Spare*	Size	T165/80D17 104M
	Pressure psi (kPa [kgf/cm²])	60 (420 [4.2])
Wheel Size	Regular	20 x 8J
	Compact Spare*	17 x 4T

* Not available on all models


Vehicle Identification Number (VIN), Engine Number, Motor Number, and Transmission Number

Your vehicle has a 17-digit vehicle identification number (VIN) used to register your vehicle for warranty purposes, and for licensing and insuring your vehicle.
The locations of your vehicle's VIN, engine number, motor number, and transmission number are shown as follows.



Vehicle Identification Number (VIN), Engine Number, Motor Number, and Transmission Number

The interior vehicle identification number (VIN) is located under the cover.



Each radio frequency device installed in the vehicle conforms to the requirements and standards of the regulation listed below:

As required by the FCC:
This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

In the U.S.
If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying American Honda Motor Co., Inc.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or American Honda Motor Co., Inc.

To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at 1-888-327-4236 (TTY: 1-800-424-9153); go to *http://www.safercar.gov*; or write to: Administrator, NHTSA, 1200 New Jersey Avenue, SE., Washington, DC 20590. You can also obtain other information about motor vehicle safety from *http://www.safercar.gov*.

In Canada
If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform Honda Canada Inc. and you may also inform Transport Canada.

If Transport Canada receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may lead to a recall and remedy campaign. However, Transport Canada cannot become involved in individual problems between you, your dealer, or Honda Canada Inc.

To contact Transport Canada's Defect Investigations and Recalls Division, you may call 1-800-333-0510. For more information on reporting safety defects or about motor vehicle safety, go to *http://www.tc.gc.ca/roadsafety*.

Testing of Readiness Codes

Your vehicle has readiness code as part of the onboard self diagnostic system. Some states use these codes for testing to verify whether your vehicle's emissions components are working properly.
The codes may not be read properly if testing is performed just after the 12-volt battery has gone dead or been disconnected.

To check if they are set, set the power mode to ON, without turning the power system on. The malfunction indicator lamp will come on for several seconds. If it then goes off, the readiness codes are set. If it blinks five times, the readiness codes are not set.

If you are required to have your vehicle tested before the readiness codes are ready, prepare the vehicle for retesting by doing the following:

1. Fill the gas tank to approximately 3/4 full.
2. Park the vehicle and leave the power system off for 6 hours or more.
3. Make sure the ambient temperature is between 40°F and 95°F (4°C and 35°C).
4. Turn the power system on.
5. Select a nearby, lightly traveled major highway where you can maintain a speed of 50 mph (80 km/h) over for at least 20 minutes. Do not use cruise control and perform the following when traffic allows. When stopped before entering the highway, use paddle shifters. During acceleration up to speed, target 5,500 to 6,500 engine rpm continuously for at least 10 seconds. Then shift to D range and drive for 90 seconds without moving the accelerator pedal. (Vehicle speed may vary slightly; this is okay.) If you cannot do this for a continuous 90 seconds because of traffic conditions, drive for at least 30 seconds, then repeat it two more times (for a total of 90 seconds).
6. Drive in city or suburban traffic for at least 10 minutes. When traffic conditions allow, let the vehicle coast for several seconds without using the accelerator pedal or the brake pedal.
7. Park the vehicle and leave the power system off for 40 minutes.

Testing of Readiness Codes

The readiness codes are erased when the 12-volt battery is disconnected, and set again only after several days of driving under a variety of conditions.

If a testing facility determines that the readiness codes are not set, you may be requested to return at a later date to complete the test.

If the testing facility determines the readiness codes are still not set, see a dealer.

■ **U.S. Owners**
Your new vehicle is covered by these warranties:

New Vehicle Limited Warranty – covers your new vehicle, except for the emissions control systems and accessories, against defects in materials and workmanship.

Emissions Control Systems Defects Warranty and Emissions Performance Warranty – these two warranties cover your vehicle's emissions control systems. Time, mileage, and coverage are conditional. Please read your warranty booklet for exact information.

Seat Belt Limited Warranty – a seat belt that fails to function properly is covered by a limited warranty. Please read your warranty booklet for details.

Rust Perforation Limited Warranty – all exterior body panels are covered against rusting from the inside out for the specified time period, regardless of mileage.

Accessory Limited Warranty – Acura accessories are covered under this warranty. Time and mileage limits depend on the type of accessory and other factors. Please read your warranty booklet for details.

Replacement Parts Limited Warranty – covers all Acura replacement parts against defects in materials and workmanship.

Replacement 12-Volt Battery Limited Warranty – provides prorated coverage for a replacement battery purchased from your dealer.

Replacement Muffler Lifetime Limited Warranty – provides coverage for as long as the purchaser of the muffler owns the vehicle.

Restrictions and exclusions apply to all these warranties. Please read the Acura warranty information booklet that came with your vehicle for precise information on warranty coverages. Your vehicle's original tires are covered by their manufacturer. Tire warranty information is in a separate booklet.

■ Canadian Owners

Please refer to the warranty manual that came with your vehicle.

■ EPA Contact Information

An owner may obtain further information concerning emission warranties or report violations of the terms of the emission warranties by contacting:

U.S. Environmental Protection Agency
Office of Transportation and Air Quality
Compliance Division, Light-Duty Vehicle Group
Attn: Warranty Complaints
2000 Traverwood Drive
Ann Arbor, MI 48105
Email: complianceinfo@epa.gov

■ **Service Express**
For electronic copies of service publications, you can purchase a subscription to Service Express. Visit *www.techinfo.honda.com* for pricing and options.

■ **For U.S. Owners**
Manuals can be purchased from Helm Incorporated. You can order a manual by phone at 1 (800) 782-4356 (credit card orders only), or online at *www.helminc.com*.

■ **For Canadian Owners**
Please contact a dealer to order any manuals that you may require.

Acura dealership personnel are trained professionals who should be able to deal with any problems you may encounter with your vehicle. If, however, you are faced with a problem that they cannot resolve to your satisfaction, contact Acura Client Relations/Services.

U.S. Owners
American Honda Motor Co., Inc.
Acura Client Relations
Mail Stop 100-5E-8F
1919 Torrance Blvd.
Torrance, CA 90501-2746
Tel: 1 (800) 382-2238

Canadian Owners
Honda Canada Inc.
Acura Client Services
180 Honda Boulevard
Markham, ON
L6C 0H9
Tel: 1-888-9-ACURA-9
Fax: 1-877-939-0909
E-mail: acura_cr@ch.honda.com

In Puerto Rico and the U.S. Virgin Islands
Bella International
P.O. Box 190816
San Juan, PR 00919-0816
Tel: 1 (787) 620-7546

Client Service Information

When you call or write, please give us the following information:
- Vehicle Identification Number
  Vehicle Identification Number (VIN), Engine Number, Motor Number, and Transmission Number P. 664
- Date of purchase
- Odometer reading of your vehicle
- Your name, address, and telephone number
- A detailed description of the problem
- Name of the dealer who sold the vehicle to you

Continued

Gracenote Music Recognition Service (CDDB)



Music recognition technology and related data are provided by Gracenote®.
Gracenote is the industry standard in music recognition technology and related content delivery.
For more information, visit *www.gracenote.com.*
When music is recorded to the HDD from a CD, information such as the recording artist and track name are retrieved from the Gracenote Database and displayed (when available).
Gracenote may not contain information for all albums.
Gracenote is an internet-based music recognition service that allows artist, album, and track information from CDs to display on the HDD.
Gracenote users are allowed 4 free updates a year. More information about Gracenote, its features, and downloads are available at *www.acura.com* (in U.S.) or *www.acura.ca* (in Canada).
CD and music-related data from Gracenote, Inc., copyright © 2000 to present Gracenote. Gracenote Software, copyright © 2000 to present Gracenote.
One or more patents owned by Gracenote apply to this product and service. See the Gracenote website for a non-exhaustive list of applicable Gracenote patents.
Gracenote, CDDB, MusicID, MediaVOCS, the Gracenote logo and logotype, and the "Powered by Gracenote" logo are either registered trademarks or trademarks of Gracenote in the United States and/or other countries.

Gracenote® END USER LICENSE AGREEMENT

This application or device contains software from Gracenote, Inc. of Emeryville, California ("Gracenote"). The software from Gracenote (the "Gracenote Software") enables this application to perform disc and/or file identification and obtain music- related information, including name, artist, track, and title information ("Gracenote Data") from online servers or embedded databases (collectively, "Gracenote Servers") and to perform other functions. You may use Gracenote Data only by means of the intended End-User functions or this application or device.

You agree that you will use Gracenote Data, the Gracenote Software, and Gracenote Servers for your own personal non-commercial use only.

You agree not to assign, copy, transfer, or transmit the Gracenote Software or any Gracenote Data to any third party.

YOU AGREE NOT TO USE OR EXPLOIT GRACENOTE DATA, THE GRACENOTE SOFTWARE, OR GRACENOTE SERVERS, EXCEPT AS EXPRESSLY PERMITTED HEREIN.

You agree that your non-exclusive license to use the Gracenote Data, the Gracenote Software, and Gracenote Servers will terminate if you violate these restrictions. If your license terminates, you agree to cease any and all use of the Gracenote Data, the Gracenote Software, and Gracenote Servers.

Gracenote reserves all rights in Gracenote Data, the Gracenote Software, and the Gracenote Servers, including all ownership rights. Under no circumstances will Gracenote become liable for any payment to you for any information that you provide. You agree that Gracenote, Inc. may enforce its rights under this Agreement against you directly in its own name.

The Gracenote service uses a unique identifier to track queries for statistical purposes. The purpose of a randomly assigned numeric identifier is to allow the Gracenote service to count queries without knowing anything about who you are. For more information, see the web page for the Gracenote Privacy Policy for the Gracenote service.

The Gracenote Software and each item of Gracenote Data are licensed to you "AS IS."

Gracenote makes no representations or warranties, express or implied, regarding the accuracy of any Gracenote Data from in the Gracenote Servers. Gracenote reserves the right to delete data from the Gracenote Servers or to change data categories for any cause that Gracenote deems sufficient. No warranty is made that the Gracenote Software or Gracenote Servers are error-free or that functioning of Gracenote Software or Gracenote Servers will be uninterrupted.

Gracenote is not obligated to provide you with new enhanced or additional data types or categories that Gracenote may provide in the future and is free to discontinue its services at any time.

GRACENOTE DISCLAIMS ALL WARRANTIES EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, TITLE, AND NONINFRINGEMENT. GRACENOTE DOES NOT WARRANT THE RESULTS THAT WILL BE OBTAINED BY YOUR USE OF THE GRACENOTE SOFTWARE OR ANY GRACENOTE SERVER. IN NO CASE WILL GRACENOTE BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES OR FOR ANY LOST PROFITS OR LOST REVENUES.
© Gracenote 2009

Continued

■ Disclaimer of Pandora®*

Requirements to access Pandora®

- Latest version of the Pandora app installed on your Android, Blackberry, or iPhone.
- Registered Pandora account (you can create a free account at *www.pandora.com <http://www.pandora.com/>* or on your smartphone)
- Connection to the internet via Wi-Fi or cellular data network.

Limitations

- Access to Pandora requires an active internet connection
- Ability to access Pandora through this system is subject to change without notice
- Certain functionality of Pandora service is not available when accessing the service through this system including, but not limited to, creating new stations, deleting stations, emailing current stations, buying tracks, viewing additional text information, logging in to Pandora, and adjusting Cell Network Audio Quality. Pandora internet radio is a music service not affiliated with HONDA. More information is available at *http://www.pandora.com <http://www.pandora.com/>*. Pandora, the Pandora logo, and the Pandora trade dress are trademarks or registered trademarks of Pandora Media, Inc., used with permission.
- Mobile access requires a smartphone with an active data plan. Standard data rates may apply.
- Pandora is only available in the United States.

* Not available on all models

A

AAC 275, 300
ABS (Anti-lock Brake System) 523
AC Power Outlet 218
Accessories and Modifications 611
Accessory Power Sockets 217
Acoustic Vehicle Alerting System 473
AcuraLink 438
AcuraWatch™ 26
Adaptive Cruise Control (ACC) with Low Speed Follow (LSF) 477
  Indicator 100
Additives
  Coolant 577
  Engine Oil 572
  Washer 581
Additives, Engine Oil 572
Adjusting
  Armrest 208
  Front Seats 195
  Head Restraints 202, 204, 205
  Headlights 582
  Mirrors 192
  Rear Seats 207
  Steering Wheel 191
  Temperature 127
Agile Handling Assist 507
Air Conditioning System (Climate Control System) 223
  Changing the Mode 226
  Defrosting the Windshield and Windows 229
  Dust and Pollen Filter 604
  Rear Climate Control System 230
  Sensors 234
  Synchronized Mode 227
  Using Automatic Climate Control 223
Air Pressure 592, 663
Airbags 47
  Advanced Airbags 53
  After a Collision 51
  Airbag Care 61
  Driver's Knee Airbag 54
  Event Data Recorder 0
  Front Airbags (SRS) 50
  Indicator 59, 93
  Passenger Front Airbag Off Indicator 60
  Sensors 47
  Side Airbags 56
  Side Curtain Airbags 58
AM/FM Radio 261
Android Auto 310
Anti-lock Brake System (ABS) 523
  Indicator 93
Apple CarPlay 306
Armrest 208
Audio Remote Controls 241
Audio System 236
  Adjusting the Sound 256
  Auxiliary Input Jack 240
  Error Messages 315
  General Information 323
  HDD 278
  iPhone 298, 325
  iPod 291
  MP3/WMA/AAC 275, 300
  Pandora® 298
  Reactivating 240
  Recommended CDs 324
  Recommended Devices 325
  Remote Controls 241
  Security Code 240
  Theft Protection 240
  USB Flash Drives 300, 325
  USB Port 237
Authorized Manuals 670
Auto Door Locking/Unlocking 157
  Customize 137, 378
Auto Engine Stop/Start 13
Auto High-Beam 180
  Indicator 93
Automatic Brake Hold 521
  Indicator 521
Automatic Folding Door Mirror 194
Automatic Intermittent Wipers 184
Automatic Lighting 177
Auxiliary Console Panel 343
Auxiliary Input Jack 240
Average Fuel Economy 127
Average Speed 128

B

Back-Up Light 585
Battery 600
12-Volt 600
12-Volt Battery Charging System Indicator 88, 641
High Voltage 516
Jump Starting 637
Maintenance (Checking the 12-Volt Battery) 600
Maintenance (Replacing) 601
Battery Types 12
Belts (Seat) 39
Beverage Holders 215
Blind spot information System 509
Indicator 104
Bluetooth® Audio 303
Bluetooth® HandsFreeLink® 397
Booster Seats (For Children) 79
Brake System 517
Anti-lock Brake System (ABS) 523
Automatic Brake Hold 521
Brake Assist System 524
Brake System Indicator 85
Fluid 581
Foot Brake 520
Indicator 84, 85, 643
Parking Brake 517
Brake System (Amber)
Indicator 85
Brake System (Red)
Indicator 84, 643
Brightness Control (Instrument Panel) 187
Bulb Replacement 582
Back-Up Light 585
Brake Light and Rear Turn Signal Light 583
Fog Lights 582
Front Turn Signal/Parking, Daytime Running and Front Side Marker Lights 582
Headlights 582
High-Mount Brake Light 586
Puddle Lights 586
Rear License Plate Lights 586
Side Turn Signal/Emergency Indicator Lights 582
Taillights 585
Taillights/Rear Side Maker Lights 584
Bulb Specifications 662

C

CAMERA Button 547
Car Wash Mode 469
Carbon Monoxide Gas 80
Carrying Cargo 449, 451
CD Player 275
Center Pocket 214
Certification Label 664
Changing Bulbs 582
Charging System Indicator 88, 641
Child Safety 62
Childproof Door Locks 156
Child Seat 62
Booster Seats 79
Child Seat for Infants 64
Child Seat for Small Children 65
Installing a Child Seat with a Lap/Shoulder Seat Belt 72
Larger Children 78
Rear-facing Child Seat 64
Selecting a Child Seat 66
Childproof Door Locks 156
Cleaning the Exterior 607
Cleaning the Interior 605
Client Service Information 671
Climate Control System 223
Changing the Mode 226
Defrosting the Windshield and Windows 229
Dust and Pollen Filter 604
Rear Climate Control System 230
Sensors 234
Synchronized Mode 227
Using Automatic Climate Control 223
Clock 142
CMBS™ (Collision Mitigation Braking System™) 525
Coat Hook 219
Collision Mitigation Braking System™ (CMBS™) 525
Compact Spare Tire 615, 663

Console Compartment 213
Controls 141
Coolant (Engine) 577
Adding to the Radiator 578
Adding to the Reserve Tank 577
Overheating 639
Coolant (Inverter) 579
Creeping (Dual Clutch Transmission) 464
Cross Traffic Monitor 540
Cup Holders 215
Customized Features 131, 362

D

Daytime Running Lights 179
Dead Battery 637
Defrosting the Windshield and Windows 229
Detachable Anchor 44
Devices that Emit Radio Waves 665
Dimming
Headlights 176
Rearview Mirror 192
Dipstick (Engine Oil) 573
Directional Signals (Turn Signal) 175
Door Mirrors 193
Doors 143
Auto Door Locking 157
Auto Door Unlocking 157
Door Open Message 38
Keys 143
Locking/Unlocking the Doors from the Inside 18, 154
Locking/Unlocking the Doors from the Outside 145
Lockout Prevention System 152
DOT Tire Quality Grading 594
Driver's Knee Airbag 54
Driving 447
Braking 517
Dual Clutch Transmission 464
Off-Highway Driving Guidelines 455
Shifting Gear 465
Turning on the Power 457
Driving Position Memory System 189
Dual Clutch Transmission 464
Creeping 464
Fluid 580
Kickdown 464
Operating the Shift Button 23, 467
Shifting 465
Dust and Pollen Filter 604
Dynamic Mode button 474

E

Elapsed Time 128
Electric Parking Brake
Indicator 86
Switch 517
Electric Parking Brake System
Indicator 86
Electric Power Steering (EPS) System 95, 643
Electronic Stability Control (ESC) 505
Emergency 656
Emissions Testing (Readiness Codes) 667
Energy Efficiency 12
Engine 664
Coolant 577
Jump Starting 637
Oil 572
Remote Engine Start 459
Starting 457
Engine Compartment Cover 571
Engine Coolant 577
Adding to the Radiator 578
Adding to the Reserve Tank 577
Overheating 639
Engine Oil 572
Adding 574
Checking 573
Displaying Oil Life 565
Low Oil Pressure Indicator 88, 641
Recommended Engine Oil 572
EPS (Electric Power Steering) System 95, 643
Exhaust Gas Hazard (Carbon Monoxide) 80
Exterior Care (Cleaning) 607
Exterior Mirrors 193

F

Features 235
Filters
Dust and Pollen 604
Oil 575
Flat Tire 615, 622
Floor Mats 606
Fluids
Brake 581
Dual Clutch Transmission 580
Engine Coolant 577
Windshield Washer 581
Fog Lights 179
Folding Down the Second Row Seat 201
Folding Down the Third Row Seat 207
Foot Brake 520
Front Airbags (SRS) 50
Front Seats 195
Adjusting 195
Front Sensor Camera 475
Fuel 25, 556
Fuel Economy and CO_2 Emissions 559
Gauge 123
Instant Fuel Economy 128
Low Fuel Indicator 91
Range 128
Recommendation 556
Refueling 556
Fuel Economy and CO_2 Emissions 559
Fuel Fill Door 25, 557
Unable to Unlock 657
Fuses 647
Inspecting and Changing 655
Locations 647, 650, 653, 654

G

Gasoline (Fuel)
Economy 559
Gauge 123
Information 556
Low Fuel Indicator 91
Refueling 556
Gauges 123
Gear Position Indicator 89, 467
Gear Shift Positions
Dual Clutch Transmission 465
Glass (care) 608
Glove Box 212

H

Handling the Unexpected 613
HandsFreeLink® (HFL) 397
Auto Answer 413
Automatic Import of Cellular Phonebook and Call History 415
Automatic Transferring 413
Displaying Messages 433
HFL Buttons 397
HFL Menus 400
HFL Status Display 398
Limitations for Manual Operation 399
Making a Call 424
Options During a Call 430
Phone Setup 405
Phonebook Phonetic Modification 419
Receiving a Call 429
Receiving a Text/E-mail Message 431
Ring Tone 414
Roadside Assistance 437
Selecting a Mail Account 432
Speed Dial 416
To Create a Security PIN 411
To Set Up a Text/E-mail Message Option 410
Use Contact Photo 414
Hard Disk Drive (HDD) Audio 278
Hazard Warning Button 4
HDMI™ Port 344
Head Restraints 202, 204, 205
Headlight Washers 186
Headlights 176
Aiming 582
Auto High-Beam System 180
Automatic Operation 177
Dimming 176, 179
Operating 176
Heated Door Mirrors 188
Heated Steering Wheel 220
Heated Windshield 188
Heater (Steering Wheel) 220
Heaters (Seat) 221, 222

HFL (HandsFreeLink®) 397
High Beam Indicator 95
High Voltage Battery 516
Hill Start Assist System 462
HomeLink® Universal Transceiver 394
Honda App License Agreement 326
Hybrid Vehicle
SPORT HYBRID Super Handling-All Wheel Drive™ (SPORT HYBRID SH-AWD®) 9

I

Identification Numbers 664
Engine, Motor, and Transmission 664
Vehicle Identification 664
IDS (Integrated Dynamics System) 474
Illumination Control 187
Button 187
Immobilizer System 166
Indicator 96
Indicators 84
12-Volt Battery Charging System 88, 641
Adaptive Cruise Control (ACC) with Low Speed Follow (LSF) 100, 477
Anti-lock Brake System (ABS) 93
Auto High-Beam 93
Automatic Brake Hold 87, 521
Automatic Brake Hold System 87, 521
Blind spot information System 104
Brake System (Amber) 85
Brake System (Red) 84, 643
Collision Mitigation Braking System™ (CMBS™) 102, 103
Electric Parking Brake 86
Electric Parking Brake System 86, 644
Fog Lights 96
Gear Position 89
High Beam 95
High Temperature 92
Immobilizer System 96
Keyless Access System 97
Lane Keeping Assist System (LKAS) 98, 499
Lights On 96
Low Fuel 91
Low Oil Pressure 88, 641
Low Temperature 92
Low Tire Pressure/TPMS 95, 645
M (sequential mode) Indicator/Sequential Mode Gear Selection 89
Malfunction Indicator Lamp 88, 642
POWER SYSTEM Indicator 91, 646
READY 92
Road Departure Mitigation (RDM) 99
Seat Belt Reminder 40, 91
Security System Alarm 97
Speed-sensitive Electric Power Steering (EPS) System 95, 643
SPORT+ mode 92
Supplemental Restraint System 59, 93
System Message 97
Transmission System 90, 645
Turn Signal 95
Vehicle Stability Assist® (VSA®) System 94, 505
VSA® OFF 94, 506
Information 661
Information Screen 248
Instrument Panel 83
Brightness Control 187
Integrated Dynamics System (IDS) 474
Dynamic Mode button 474
Interface Dial 243
Interior Lights 210
Interior Rearview Mirror 192
iPhone 298, 325
iPod 291, 325

J

Jack (Wheel Nut Wrench) 619
Jump Starting 637

K

Key Number Tag 144
Keyless Access System 145
Keyless Lockout Prevention 152
Keys 143
Lockout Prevention 152
Number Tag 144
Rear Door Won't Open 156
Remote Transmitter 150
Types and Functions 143

Kickdown (Dual Clutch Transmission) 464

L

Lane Keeping Assist System (LKAS) 497
Indicator 98
Language (HFL) 398
LATCH (Child Seats) 67, 74
LED Puddle Light 149
Legal Information on Apple CarPlay/ Android Auto 338
License information 341
Lights 176, 582
Automatic 177
Bulb Replacement 582
Daytime Running Lights 179
High Beam Indicator 95
Interior 210
Light Switches 176
Lights On Indicator 96
Turn Signals 175
Load Limits 451
Locking/Unlocking 143
Auto Door Locking/Unlocking 157
Childproof Door Locks 156
From Inside 154
From Outside 145
Keys 143
Using a Key 151
Lockout Prevention System 152
Low Battery Charge 641
Low Fuel Indicator 91
Low Oil Pressure Indicator 88, 641
Lower Anchors 67, 74
Lubricant Specifications Chart 663
Luggage (Maximum Load Limit) 451
Lumbar Support 195

M

Maintenance 561
12-Volt Battery 600
Brake Fluid 581
Cleaning 605
Climate Control System 604
Coolant 577
Maintenance Minder™ 565
Oil 573
Precautions 562
Radiator 578
Remote Control 602
Remote Transmitter 601
Replacing Light Bulbs 582
Safety 563
Service Items 567
Tires 591
Transmission Fluid 580
Under the Hood 569
Wireless Headphone 603
Malfunction Indicator Lamp 88, 642
Map Lights 211
Maximum Load Limit 451
Meters, Gauges 123
MID (Multi-information Display) 125
Mirrors 192
Adjusting 192
Door 193
Exterior 193
Interior Rearview 192
Modifications (and Accessories) 611
Moonroof 171
MP3 ..... 275, 300
Multi-function Steering-wheel Controls 125
Multi-Information Display (MID) 125
Multi-View Rear Camera 544

N

Numbers (Identification) 664

O

Odometer 126
Off-Highway Driving Guidelines 455
Oil (Engine) 572
Adding 574
Checking 573
Displaying Oil Life 565
Low Oil Pressure Indicator 88, 641
Recommended Engine Oil 572
Viscosity 572
On Demand Multi-Use Display™ 244

Open Source Licenses 340
Opening/Closing
Hood 570
Moonroof 171
Power Windows 169
Tailgate 158
Operating the Switches Around the Steering Wheel 172
Outside Temperature Display 127
Overhead Screen 345
Overheating 639

P

Paddle Shifters (Sequential Mode) 472
Pandora® 298
Panic Mode 168
Parking 534
Parking Brake 517
Parking Brake and Brake System Indicator 84, 643
Parking Sensor System 536
Passenger Front Airbag Off Indicator 60
Passing Indicators 176
POWER Button 172
Power Tailgate 160
Power Windows 169
Precautions While Driving 463
Driving Guidelines for Your Utility Vehicle 463
Rain 463
Pregnant Women 45
Puncture (Tire) 615, 622

R

Radiator 578
Radio (AM/FM) 261
Radio (SiriusXM®) 264
Radio Data System (RDS) 262
Range 128
RDS (Radio Data System) 262
Readiness Codes (Emissions Testing) 667
Rear Climate Control System 230
From the Front Panel 230
From the Rear Panel 233
Rear Defogger/Heated Door Mirror Button 188
Rear Entertainment System (RES) 342
Auxiliary Console Panel 343
Front Control Panel Operation 356
HDMI™ Port 344
Operating the System 345
Overhead Screen 345
Playable Discs 361
Playing a DVD 346
Rear Control Panel Operation 346
Wireless Headphones 342
Rear Seats 207
Second Row Seat 200, 201
Third Row Seat 207
Rearview Mirror 192
Refueling 556
Fuel Gauge 123
Gasoline 556, 662
Low Fuel Indicator 91
Regenerative Energy and Regenerative Braking 12
Regulations 514, 594, 665
Remote Engine Start with Vehicle Feedback 459
Checking Door Lock Status 153
Remote Transmitter 150
Replacement
Battery 601, 602, 603
Bulbs 582
Front Wiper Blade Rubber 587
Fuses 647, 650, 653, 654
Rear Wiper Blade Rubber 589
Tires 597
Reporting Safety Defects 666
Resetting a Trip Meter 127
Reverse Tilt Door Mirror 193
Right Selector Wheel 125, 131
Road Departure Mitigation (RDM) 492
On and Off 494

S

Safe Driving 33
Safety Checklist 38
Safety Labels 81
Safety Message 1

Seat Belts 39
Adjusting the Shoulder Anchor 43
Automatic Seat Belt Tensioners 41
Checking 46
Detachable Anchor 44
Fastening 42
Installing a Child Seat with a Lap/Shoulder Seat Belt 72
Pregnant Women 45
Reminder 40
Warning Indicator 40, 91
Seat Heaters 221, 222
Seat Ventilation 221
Seats 195
Adjusting 195
Driver's Seat Lumbar Support 195
Front Seats 195
Rear Seats 207
Seat Heaters 221, 222
Seat Ventilation 221
Second Row Seat 200, 201
Third Row Seat 207
Second Row Outer Seats Heaters 222
Second Row Seat (Folding Down) 201
Security System 166
Immobilizer System Indicator 96
Security System Alarm Indicator 97
Selecting a Child Seat 66
Sequential Mode 471
Sequential Mode Operation 472
Setting the Clock 142
SH-AWD® Torque Distribution Monitor 129
Shift Button 23, 465
Operation 467
Shifting (Transmission) 23, 465
Shoulder Anchor 43
Side Airbags 56
Side Curtain Airbags 58
Siri Eyes Free 305
SiriusXM® Radio 264
Snow Tires 599
Sounds Unique to the SPORT HYBRID SH-AWD® System 13
Spare Tire 615, 663
Spark Plugs 662
Specifications 662
Specified Fuel 556, 662
Speedometer 123
Speed-sensitive Electric Power Steering (EPS) System
Indicator 95, 643
SPORT HYBRID Super Handling-All Wheel Drive™ (SPORT HYBRID SH-AWD®) 508
SRS Airbags (Airbags) 50
Steering Wheel 191
Adjusting 191
Heater 220
Stopping 534
Summer Tires 599
Sunglasses Holder 220
Supplemental Restraint System (SRS) 50
Surround View Camera System 546
Switches (Around the Steering Wheel) 4, 5, 172
Synchronized Mode 227
System Message Indicator 97

T

Tachometer 123
Tailgate 158
Unable to Open 658
Temperature
Outside Temperature Display 127
Temperature Sensor 127, 234
Temporary Tire Repair Kit 623
Text Message 431, 433
Third Row Seat (Folding Down) 207
Third Row Seat Access 200
Tie-down Anchors 219
Time (Setting) 142
Tire Fill Assist 512, 645
Tire Pressure Monitoring System (TPMS) with Tire Fill Assist 512
Indicator 95, 645
Tire Repair Kit 622
Tires 591
Air Pressure 592, 663
Checking and Maintaining 591
Inspection 591
Labeling 592
Puncture (Flat Tire) 615, 622
Regulations 594

Rotation ... 598
Spare Tire ... 615, 663
Summer ... 599
Temporary Tire Repair Kit ... 623
Tire Chains ... 599
Tire Repair Kit ... 622
Wear Indicators ... 596
Winter ... 599
Tools ... 614
Towing a Trailer ... 454
Towing Your Vehicle ... 454
Emergency ... 656
TPMS (Tire Pressure Monitoring System) with Tire Fill Assist ... 512
Indicator ... 95, 645
Transmission ... 23, 465
Dual Clutch ... 23, 464, 465
Fluid ... 580
Gear Position Indicator ... 89, 467
Number ... 664
Sequential Mode ... 471
TRIP Button ... 126
Trip Meter ... 127
Troubleshooting ... 613
Blown Fuse ... 647, 650, 653, 654
Brake Pedal Vibrates ... 29
Buzzer Sounds When Opening Door ... 29
Emergency Towing ... 656
Noise When Braking ... 31
Overheating ... 639
Power System Won't Start ... 634
Puncture/Flat Tire ... 615, 622
Rear Door Won't Open ... 29, 156
Warning Indicators ... 84
Turn Signals ... 175
Indicators (Instrument Panel) ... 95
Turn-by-Turn Directions ... 129
Turning on the Power ... 457
Does Not Activate ... 634
Jump Starting ... 637
Remote Engine Start ... 459

U

Under-floor Storage Area ... 214
Unlocking the Doors ... 145
Unlocking the Front Doors from the Inside ... 18, 154
USB Flash Drives ... 300, 325
USB Port ... 237

V

Vanity Mirrors ... 7
Vehicle Identification Number ... 664
Vehicle Stability Assist® (VSA®) ... 505
Off Button ... 506
Off Indicator ... 94
System Indicator ... 94, 505
Viscosity (Oil) ... 572, 663
Voice Control Operation ... 258
Voice Portal Screen ... 259
Voice Recognition ... 258
VSA® (Vehicle Stability Assist®) ... 505

W

Wallpaper ... 254
Warning and Information Messages ... 105
Warning Indicator On/Blinking ... 641
Warning Labels ... 81
Warranties (Warranty Manual provided separately) ... 668
Watts ... 662
Wear Indicators (Tire) ... 596
Wheel Nut Wrench (Jack Handle) ... 619
Window Washers ... 183
Adding/Refilling Fluid ... 581
Switch ... 183
Windows (Opening and Closing) ... 169
Windshield ... 183
Cleaning ... 608
Defrosting/Defogging ... 229
Washer Fluid ... 581
Wiper Blades ... 587
Wipers and Washers ... 183
Winter Tires ... 599
Snow Tires ... 599
Tire Chains ... 599

Wipers and Washers 183
Automatic Intermittent Wipers 184
Checking and Replacing Wiper Blades 587
Front 183
Rear 185
Wireless Headphones 342
WMA 275, 300
Worn Tires 591

ACURA

PRECISION CRAFTED PERFORMANCE

mygarage.acura.com (U.S.A.)
acura.ca (Canada)

31TRX621
OM-22021
00X31-TRX-6210

2019 Acura MDX Sport Hybrid Owner's Manual
© 2023 Honda Motor Co., Ltd. — All Rights Reserved

Printed in the U.S.A.