



Welcome to high performance, premium quality, innovation and strength. Welcome to Cub Cadet.

Parts/Warranty Supplement

Models

LX Series

Customer Support

Please do NOT return the machine to the retailer or dealer without first contacting the Customer Support Department.

If you have difficulty assembling this product, have questions regarding the controls, operation, or maintenance of this machine, want to order replacement parts/attachments/accessories, or want to view an online How-To video; you can seek help from the experts. Have your full model number and serial number ready. Choose from the options below:

◇ Web: www.cubcadet.com/equipment/cubcadet/service-and-parts

◇ Phone: (800) 965-4CUB

◇ Mail: Cub Cadet LLC • P.O. Box 361131 • Cleveland, OH • 44136-0019

Warranty

This document contains information for all listed models. Warranty information included in this document is specific to your purchased product.

Replacement Parts

Part Number	Description
954-05099	Deck Belt, 42" Deck
954-05087A	Deck Belt, 46" Deck
954-04077A	Deck Belt, 50" Deck
954-05027B	Drive Belt
942-04308A	Blades, 42" Decks
942-04308-X	XTREME™ Blades, 42" Deck
942-04244A	Blades, 46" Deck
942-04290-X	XTREME™ Blades, 46" Deck
942-05052A	Blades, 50" Deck
918-06976A	Deck Spindle, 42" Deck
918-06977A	Deck Spindle, 46" Deck
918-06981	Deck Spindle, 50" Deck
734-06305A	Front & Rear (If equipped) Deck Wheel

Part Number	Description
731-05679B	Nose Roller, 50" Deck
925-1707D	Lead-Acid Battery
725P17335	AGM Battery
751P15242A	Gas Cap
946-05235	Choke Control Cable, Kohler
946-05114A	Choke Control Cable, Kawasaki
946-05095A	Throttle Control Cable, Kawasaki
946-05357A	Throttle Control Cable, Cub Cadet
925-1745A	Ignition Key
631-04354C	Discharge Chute Assembly, 42" & 46" Deck
631-05116B	Discharge Chute Assembly, 50" Deck
634-05160	Rear Wheel Assembly
634-05159A	Front Wheel Assembly

Attachments & Accessories

Part Number	Description
19A30031100	Bagger, 42" & 46"
19A30030100	FastAttach™ Bagger, 42" & 46"
19A30018100	Bagger, 50"
19A70041100	Mulch Kit, 42"
19B30005100	Mulch Kit, 46"
19A30041100	Mulch Kit, 50"
19A30043100	Leaf Collection System
19B30029100	FastAttach™ Cargo Carrier
19A30035100	FastAttach™ Rear Sprayer
19A30028100	FastAttach™ Rear 100# Broadcast Spreader
19A300170EM	Snow Blade
19A30037100	FastAttach™ All Season Plow
19A40024100	Snow Blower
490-241-0023	Tire Chains

Part Number	Description
19C300260EM	Sun Shade/Snow Cab Combo Kit
19C300220EM	Snow Cab
490-900-0067	Universal Sun Shade
19C300210EM	Sun Shade (4-Post)
19B40026100	EZ-Stow Hauler
490-900-M060	Weight Kit
490-900-M059	Extra Weight
19A30020100	Bumper
19A30038100	FastAttach™ Brush Guard
757-05035A	Armrest Kit (If not included)
490-850-0008	Oil Siphon
490-850-0005	Blade Removal Tool
490-900-0045	Oil Filter Wrench

CUB CADET LLC, P.O. BOX 361131, CLEVELAND, OHIO 44136-0019



Form No. 769-26397
(November 15, 2021)



注意事项

请务必填写本产品质保卡，并发送给厂家登记备案用，以保证您依法享受保修期内免费更换配件的权力。
请留意：如果此文件缺失，则无法享受保修期内免费更换配件的权利。

质保卡

机器品牌		购买日期	年	月	日
机器型号		机器序列号			
客 户	公司名或用户名:				
	地址:				
	电话:		邮编:		
经 销 商 信 息	店名:				
	地址:				
	电话:		邮编:		

感谢购买 MTD 的产品，谨致深谢。本单由 MTD 领受后登录保管，并作为售后服务
的资料。敬请详细填写本单，以邮寄、传真、扫描、在线登记等方式发送给 MTD。

发送地址:

美特达机械（苏州）有限公司

地址：江苏省苏州市工业园区出口加工区 A 区 苏虹中路200号

电话：0512-62891900

邮编：215121

电子邮件：asia.service@mtdproducts.com

坐骑式草坪车质保条款

1. 质保期

产品的质保期为从产品购买日期起（以购机发票为准，若无购机发票，则以机器
出厂日期为准）
整机保修：12个月

2. 质保范围

在严格遵守使用说明书的正确操作和维护保养情况下，出现的零件与制造缺陷。

3. 非质保条款

- a. 没有遵守使用说明书的操作、维护保养所引起的机器故障。
- b. 使用非本公司原厂零件所引起的故障。
- c. 不正确的储存、随意更改出厂配置所引起的故障。
- d. 不可抗拒、异常外力所引起的故障与损伤。
- e. 机器的一般易损件及消耗件：
机油、空滤、油滤、火花塞、离合器、密封垫、刀片、皮带、刀座、轮胎、
启动马达等。
- f. 未按说明书使用正确的机油与燃油所引起的故障。
- g. 不能提供质保卡的。

草坪车操作说明书

启动步骤:

- 1) 使用前的检查
 - a) 所有的部件螺丝安装牢固;
 - b) 机油位在上下刻度线之间;
 - c) 半箱以上汽油;
 - d) 前后轮胎气压, 前轮:1.0 巴, 后轮:0.7 巴;
 - e) 底盘、发动机四周无碎草聚集;
 - f) 泄压阀处于接合状态, 泄压状态时机器无法前进和后退.
- 2) 坐入驾驶员座位;
- 3) 提起刀盘至最高割草位置;
- 4) 关闭刀盘: 按下 PTO 开关;
- 5) 方向盘款式草坪车, 左脚完全踩下刹车脚踏。如果是操纵杆款式草坪车, 两个杆子扳到刹车位置;
- 6) 将油门手柄移到中间的位置;
- 7) 冷机时发动引擎, 拉上阻风门至关闭;
- 8) 拧钥匙直至引擎发动 (如果马达运转 5 秒还没启动, 请停 10 秒后再尝试), 引擎发动后, 钥匙自动回位;
- 9) 将阻风门缓慢推回去;
- 10) 把油门加至最大;
- 11) 拔出 PTO 开关刀盘将旋转割草, 刀盘工作过程中始终将油门放在最大位置;
- 12) 右脚踩下前进脚踏可以前进割草, 若需要实现后退割草功能:
 - a) 把钥匙转至倒车割草档;
 - b) 按下右上角的三角形离合按钮, 此时红色的 LED 灯会点亮

停机步骤:

- 1) 让刀盘空运转半分钟左右;
- 2) 按下 PTO 开关, 关闭刀盘;
- 3) 把油门关小;
- 4) 将点火钥匙转到停止档;
- 5) 拔出点火钥匙;
- 6) 离开座位前, 开启驻车刹车;

注意事项:

- 1) 请使用原厂配件, 非原装配件将对机器和操作者造成伤害, 使用非原厂件引起的机器故障一律不在保修范围之内 (包括: 三滤, 皮带, 刀片等);
- 2) 机器割草过程中, 油门始终放在最大位置;
- 3) 启动刀片之前, 必须先把刀盘抬到最高;
- 4) 工作之前请先检查草地, 捡走碎石, 枯枝等一些杂物, 这样能避免这些碎物对您和您的机器造成伤害;
- 5) 在斜坡上驾驶机器是很危险的, 因为此时翻车和打滑的可能性都升高了, 请勿在超过 20 度的斜坡作业;
- 6) 若您需要对草坪车进行修理、检查等工作时, 请先确保以下几点:
 - a) 关掉引擎;
 - b) 拔出点火钥匙;
 - c) 拉上驻车刹车;
 - d) 等机器所有部位都已停转且引擎已经冷却;
 - e) 拔出火花塞, 避免意外启动.

保养:

- 1) 常规保养:
 - a) 新机使用的前 5 至 8 小时更换机油, 以后每 50 小时更换机油和机油滤芯, 机油要求 SJ 以上级别型号为 SAE10W-30 (推荐草坪车的原装机油);
 - b) 每 25 小时给黄油口加黄油;
 - c) 25 小时给前进, 后退, 刹车踏板和其他的连接旋转部位加些机油润滑;
 - d) 每 100 小时更换空气滤芯, 如果使用环境恶劣, 需要提前更换;
 - e) 每 100 小时更换燃油滤芯;
 - f) 每 100 小时确认火花塞间隙 0.76 毫米;
- 2) 长期储存:
 - a) 将汽油全部放掉, 启动引擎待自动停机;
 - b) 更换机油 SAE10W-30;
 - c) 拆出火花塞, 加 20 毫升机油进去. 装上火花塞, 但不用连火花塞冒, 让活塞运转 2-3 圈;
 - d) 清洁整机和刀盘, 给机身的金属部位抹点油, 防止生锈;
 - e) 给黄油口加些黄油;
 - f) 将电池拆卸下来, 充好电后放在一个干燥阴凉的地方。每 4~6 周充一次电, 再次使用前请先充电;
 - g) 将机器放在干燥地方储存;

故障排除:

- 1) 机器无法启动:
 - a) 确认 PTO 开关已关闭;
 - b) 脚刹已完全踩下;
 - c) 后排车, 检查后出草塑料筒螺丝已旋紧;
 - d) 钥匙拧到通电档, 显示屏电压大于 12 伏, 满电是 12.6 伏;
 - e) 有足够的新鲜汽油;
 - f) 保险丝完好;
 - g) 汽油滤芯没有被堵塞;
- 2) 机器工作时震动大:
 - a) 检查刀盘上的部件没有松动;
 - b) 刀片没有被损坏, 可以更换刀片确认;
- 3) 机器割不动草:
 - a) 确认油门已开到最大;
 - b) 确认刀片足够锋利;
 - c) 草的高度正常并干燥;
 - d) 确认皮带张力足够.

需要了解更多信息, 欢迎联系当地经销商或关注我们的微信公众号



NOTES