

PHILIPS AVENT

ENGLISH

Read all instructions carefully before use. Keep the user manual and product packaging for future reference.



Finding the right teat is important:

We all learn at our own pace. Suckling is a skill and some babies develop it quicker than others. That's why some babies might initially benefit from our "First Flow" teat (Teat 0) before progressing to the Natural Response teats. When should I switch the teats? Switch to "First Flow" teat when your baby takes longer than 20 minutes to drink 50 ml using the Natural Response teats. Try a Natural Response teat with a higher flow rate if your baby is playing with the teat instead of drinking or seems frustrated. If feeding difficulties persist, consult a healthcare professional.

For your child's safety and health

WARNING!

- Continuous and prolonged sucking of fluids will cause tooth decay.
- Always check food temperature before feeding.
- Throw away at the first signs of damage or weakness.
- Keep components not in use out of the reach of children.
- Never attach to cords, ribbons, laces or loose parts of clothing. The child can be strangled.
- Never use feeding teats as a soother.
- Always use this product with adult supervision.

Before first use, clean the product and then place in boiling water for 5 minutes. This is to ensure hygiene. After each use, wash in warm, soapy water, remove any food residues and rinse thoroughly. If you use a brush to clean the tip of the feeding teat, clean it as carefully as possible to avoid damage. Clean before each use to ensure hygiene. Do not allow children to play with small parts or walk/run while using bottles or cups. Do not place the product in a heated oven or microwave. Do not use aggressive cleaning agents. Do not place parts on surfaces cleaned with antibacterial cleaners. Inspect before each use and pull the feeding teat in all directions. Throw away at the first signs of damage or weakness. We recommend

replacing feeding teats every 3 months. Keep feeding teats in a dry, covered container. Do not leave a feeding teat in direct sunlight or heat, or leave in disinfectant (sterilizing solution) for longer than recommended, as this may weaken the teat. If you need information or support, please visit www.philips.com/support.

简体中文

使用前请仔细阅读所有说明。请保留用户手册和产品包装，以备日后参考。



找到合适的奶嘴很重要

每个人的学习节奏各不相同。吮吸是一项技能，有些宝宝掌握得更快。因此，有些宝宝在开始阶段使用“特小流量”奶嘴（0号奶嘴）会更适合，然后再逐步过渡到 Natural Response 奶嘴。什么时候需要更换奶嘴？如果宝宝使用 Natural Response 奶嘴喝完 50 毫升奶超过 20 分钟，可以尝试换成“特小流量”奶嘴。如果宝宝只是含着奶嘴玩，而不喝奶，或者显得有些烦躁，可以尝试流速更高的 Natural Response 奶嘴。如果喂养问题持续存在，请咨询医疗专业人士。

为了您孩子的安全与健康警告！

- 长期吸吮将会导致龅病。
- 喂食前应检查食物的温度。
- 若有明显破损或缺陷，请立即丢弃。
- 将不用的组件放置在儿童无法接触到的地方。
- 切勿系在绳索、丝带、蕾丝或衣服的松动部分，以免使孩子窒息。
- 请勿将奶嘴用作安抚奶嘴。
- 务必在成人的监督下使用本产品。
- 以免被儿童入口误吞或发生其他危险的意外，不应将奶瓶及奶瓶任何不见作为玩具使用。

首次使用之前，请清洁产品并将其置于沸水中浸泡 5 分钟。煮沸消毒时水量应足够，避免产品因长时间接触到温度较高的锅底或锅沿而导致变形。这样可以保证卫生。每次使用完后，在温热的肥皂水中进行清洗以除去任何食物残渣，并彻底冲洗。如果要使用刷子清洁奶嘴顶部，请尽量小心操作，避

免损坏奶嘴。请在每次使用前进行清洁或消毒，以保证卫生。切勿让儿童玩耍小零件，或让儿童在行走或奔跑时使用奶瓶或杯子。请勿将产品置于加热的烤箱或微波炉中。请勿使用腐蚀性清洁剂。请勿将部件放在使用抗菌清洁剂清洁过的表面上。每次使用前先检查、并向各方向拉伸奶嘴。一旦出现破损或缺陷应立即丢弃。不要将奶嘴置于阳光直射处、直接置于热源处或长期置于消毒剂中、这将导致奶嘴老化。如果您需要信息或支持，请访问

www.philips.com/support。
保留备用。



3000.147.3433.2
(2025-11-02)



www.philips.com/avent
Philips Consumer Lifestyle B.V.
Tussendiepen 4, 9206 AD Drachten, The Netherlands

Trademarks are the property of Koninklijke Philips N.V.
商标归 Koninklijke Philips N.V.
© 2025 Koninklijke Philips N.V.
All rights reserved.
保留所有权利。

使用前請先仔細閱讀所有說明。請保留使用手冊及產品包裝以供日後參考。



找到合適的奶嘴很重要：

每個寶寶的學習步調都不同。吮吸是一項技能，有些寶寶學得比其他寶寶快。因此，有些寶寶可能在使用 Natural Response 奶嘴前，需要先從我們的「初始流量」奶嘴 (0 號奶嘴) 開始。我應該什麼時候更換奶嘴？如果您的寶寶使用 Natural Response 奶嘴喝完 50 毫升的奶需要超過 20 分鐘，建議更換為「初始流量」奶嘴。若寶寶在餵奶時只是在玩弄奶嘴、不專心吮吸，或表現出焦躁情緒，您可以嘗試更換為流速更快的 Natural Response 奶嘴。若仍有餵哺上的困難，建議諮詢專業的醫療人員。

波爐中。請勿使用腐蝕性清潔劑。切勿將零件放在抗菌清潔劑清洗過的表面上。每次使用奶嘴前請先仔細檢查，並將奶嘴往各個方向輕拉，若有損壞或變質的現象，請立即丟棄。我們建議每 3 個月更換一次奶嘴。將奶嘴收納在乾燥的加蓋容器中。請勿將奶嘴直接曝曬在陽光下或高溫處，或置於消毒劑 (消毒溶液) 中超過建議時間，以避免奶嘴脆弱變質。如需相關資訊或支援，請瀏覽 www.philips.com/support。

為了孩童安全與健康

警告！

- 持續且長時間的吮吸液體會導致蛀牙。
- 餵哺之前，請務必檢查食物溫度。
- 若有損壞或變質的現象，請立即丟棄。
- 所有不用的組件應收放在孩童無法拿取的地方。
- 切勿加繫繩索、絲帶、鞋帶或衣物的寬鬆零件。否則可能造成兒童遭絞勒窒息。
- 請勿將餵哺奶嘴作為安撫奶嘴使用。
- 本產品必須在成人監督下使用。

第一次使用前先清洗產品，然後浸泡於滾水中 5 分鐘，以確保安全衛生。每次使用後，請使用溫肥皂水清洗；清除所有食物殘渣後，再徹底沖洗乾淨。如果使用刷子清潔奶嘴頭尖端，請盡可能小心清潔，避免造成損壞。使用前務必清潔產品，以確保衛生。請勿讓孩童把玩小型零件，或邊走/跑邊使用奶瓶或杯子。請勿將本產品放入熱焗爐或微