MAINTENANCE SCHEDULES

CONTENTS

■ Emission Control System Maintenance 332
■ Maintenance Schedules 332
□ Schedule “B” 335
□ Schedule “A” 344

EMISSION CONTROL SYSTEM MAINTENANCE

The "Scheduled" maintenance services, listed in **bold type** must be done at the times or mileages specified to assure the continued proper functioning of the emission control system. These, and all other maintenance services included in this manual, should be done to provide best vehicle performance and reliability. More frequent maintenance may be needed for vehicles in severe operating conditions such as dusty areas and very short trip driving.

Inspection and service also should be done any time a malfunction is suspected.

NOTE: Maintenance, replacement, or repair of the emission control devices and systems on your vehicle may be performed by any automotive repair establishment or individual using any automotive part, which has been certified pursuant to U.S. EPA or, in the State of California, California Air Resources Board regulations.

MAINTENANCE SCHEDULES

There are two maintenance schedules that show the **required** service for your vehicle.

First is Schedule **"B"**. It is for vehicles that are operated under the conditions that are listed below and at the beginning of the schedule.

- Day or night temperatures are below 32° F (0° C).
- Stop and go driving.
- Extensive engine idling.
- Driving in dusty conditions.
- Short trips of less than 10 miles (16 km).
- More than 50% of your driving is at sustained high speeds during hot weather, above 90° F (32° C).
- Trailer towing.
- Taxi, police, or delivery service (commercial service).
- Off-road or desert operation.
- Heavy Loading

NOTE: If **ANY** of these apply to you then change your engine oil every 3,000 miles (5 000 km) or 3 months, whichever comes first and follow schedule "B" of the "Maintenance Schedules" section of this manual.

NOTE: If **ANY** of these apply to you then change your coolant every 102,000 miles (170 000 km) or 60 months, whichever comes first and follow schedule "B" of the "Maintenance Schedules" section of this manual.

Second is Schedule **"A"**. It is for vehicles that are not operated under any of the conditions listed under Schedule "B."

Use the schedule that best describes your driving conditions. Where time and mileage are listed, follow the interval that occurs first.

NOTE: Under no circumstances should oil change intervals exceed 6000 miles (10 000 km) or 6 months whichever comes first.

CAUTION!

Failure to perform the required maintenance items may result in damage to the vehicle.

At Each Stop for Fuel

- Check the engine oil level about 5 minutes after a fully warmed engine is shut off. Checking the oil level while the vehicle is on level ground will improve the accuracy of the oil level reading. Add oil only when the level is at or below the ADD or MIN mark.
- Check the windshield washer solvent and add, if required.

Once a Month

- Check tire pressure and look for unusual wear or damage.
- Inspect the battery and clean and tighten the terminals as required.

- Check the fluid levels of coolant reservoir, brake/clutch master cylinder, and manual transaxle and add as needed.
- Check all lights and all other electrical items for correct operation.

At Each Oil Change

- Change the engine oil filter.
- Inspect the exhaust system.
- Inspect the brake hoses.
- Inspect the CV joints (if equipped) and front suspension components.
- Check the manual transmission fluid level (if equipped).
- Check the coolant level, hoses, and clamps.

CAUTION!

Do not check the automatic transaxle fluid. It must be check by a trained service technician every 15,000 miles and if required only the recommended fluid be added. Refer to the section "Fluids, Lubricants And Genuine Parts" for the proper fluid.

Schedule "B"

Follow schedule "B" if you usually operate your vehicle under one or more of the following conditions.

- Day or night temperatures are below 32° F (0° C).
- Stop and go driving.
- Extensive engine idling.
- Driving in dusty conditions.
- Short trips of less than 10 miles (16 km).
- More than 50% of your driving is at sustained high speeds during hot weather, above 90° F (32° C).
- Trailer towing.
- Taxi, police, or delivery service (commercial service).
- Off-road or desert operation.
- Heavy Loading

NOTE: If **ANY** of these apply to you then change your engine oil every 3,000 miles (5 000 km) or 3 months, whichever comes first and follow schedule "B" of the ″Maintenance Schedules″ section of this manual.

NOTE: If **ANY** of these apply to you then change your coolant every 102,000 miles (170 000 km) or 60 months, whichever comes first and follow schedule "B" of the ″Maintenance Schedules″ section of this manual.

Miles **(Kilometers)**	**3,000** **(5 000)**	**6,000** **(10 000)**	**9,000** **(15 000)**	**12,000** **(20 000)**	**15,000** **(25 000)**
Change engine oil and oil filter, or at 3 months, whichever comes first.	X	X	X	X	X
Inspect engine air cleaner filter, **replace if necessary.**					X
Rotate tires.		X		X	
Check spare tire for proper pressure and correct stowage.		X		X	

Miles **(Kilometers)**	**18,000** **(30 000)**	**21,000** **(35 000)**	**24,000** **(40 000)**	**27,000** **(45 000)**	**30,000** **(50 000)**
Change engine oil and oil filter, or at 3 months, whichever comes first.	X	X	X	X	X
Replace the air cleaner filter.					X
Rotate tires.	X		X		X
Check spare tire for proper pressure and correct stowage.	X		X		X
Inspect brake linings.	X				
Replace Spark Plugs: 2.4L Engine					X

Miles (Kilometers)	**33,000 (55 000)**	**36,000 (60 000)**	**39, 000 (65 000)**	**42,000 (70 000)**	**45,000 (75 000)**
Change engine oil and oil filter, or at 3 months, whichever comes first.	X	X	X	X	X
Inspect engine air cleaner filter, **replace if necessary.**					X
Rotate tires.		X		X	
Check spare tire for proper pressure and correct stowage.		X		X	
Inspect brake linings.		X			

Miles (Kilometers)	**48,000 (80 000)**	**51,000 (85 000)**	**54,000 (90 000)**	**57,000 (95 000)**	**60,000 (100 000)**
Change engine oil and oil filter, or at 3 months, whichever comes first.	X	X	X	X	X
Replace engine air cleaner filter.					X
Rotate tires.	X		X		X
Check spare tire for proper pressure and correct stowage.	X		X		X
Inspect brake linings.			X		
Change Automatic Transaxle Fluid and Filter.					X
Replace Spark Plugs: 2.4L Engine					X
Flush and replace engine coolant at 60 months, or 102,000 miles (170 000 km) whichever comes first.					X

Miles (Kilometers)	**63,000 (105 000)**	**66,000 (110 000)**	**69,000 (115 000)**	**72,000 (120 000)**	**75,000 (125 000)**
Change engine oil and oil filter, or at 3 months, whichever comes first.	X	X	X	X	X
Inspect engine air cleaner filter, **replace if necessary.**					X
Rotate tires.		X		X	
Check spare tire for proper pressure and correct stowage.		X		X	
Inspect brake linings.				X	

Miles (Kilometers)	**78,000 (130 000)**	**81,000 (135 000)**	**84,000 (140 000)**	**87,000 (145 000)**	**90,000 (150 000)**
Change engine oil and oil filter, or at 3 months, whichever comes first.	X	X	X	X	X
Replace engine air cleaner filter.					X
Rotate tires.	X		X		X
Check spare tire for proper pressure and correct stowage.	X		X		X
Inspect brake linings.					X
Replace Spark Plugs: 2.4L Engine					X

Miles (Kilometers)	**93,000 (155 000)**	**96,000 (160 000)**	**99,000 (165 000)**	**102,000 (170 000)**	**105,000 (175 000)**
Change engine oil and oil filter, or at 3 months, whichever comes first.	X	X	X	X	X
Replace engine air cleaner filter.					X
Rotate tires.		X		X	
Check spare tire for proper pressure and correct stowage.		X		X	
Replace Spark Plugs: 2.7L and 3.5L Engines				X	
Flush and replace engine coolant if not done at 60 months. (Flush and replace engine coolant at 60 months, or 102,000 miles (170 000 km) whichever comes first.				X	

Miles (Kilometers)	**108,000 (180 000)**	**111,000 (185 000)**	**114,000 (190 000)**	**117,000 (195 000)**	**120,000 (200 000)**
Change engine oil and oil filter, or at 3 months, whichever comes first.	X	X	X	X	X
Replace engine air cleaner filter.					X
Rotate tires.	X		X		X
Check spare tire for proper pressure and correct stowage.	X		X		X
Inspect brake linings.	X				
Change Automatic Transaxle Fluid and Filter.					X
Replace Spark Plugs: 2.4L Engine					X
Replace the accessory drive belt every 120,000 miles (200 000 km).					X

Schedule "A"

Miles **(Kilometers)** **[Months]**	**6,000** **(10 000)** **[6]**	**12,000** **(20 000)** **[12]**	**18,000** **(30 000)** **[18]**	**24,000** **(40 000)** **[24]**	**30,000** **(50 000)** **[30]**
Change engine oil and oil filter.	X	X	X	X	X
Replace engine air cleaner filter.					X
Rotate tires.	X	X	X	X	X
Check spare tire for proper pressure and correct stowage.	X	X	X	X	X
Inspect brake linings.			X		
Replace Spark Plugs: 2.4L Engine					X

Miles **(Kilometers)** **[Months]**	**36,000** **(60 000)** **[36]**	**42,000** **(70 000)** **[42]**	**48,000** **(80 000)** **[48]**	**54000** **(90 000)** **[54]**	**60,000** **(100 000)** **[60]**
Change engine oil and oil filter.	X	X	X	X	X
Replace engine air cleaner filter.					X
Rotate tires.	X	X	X	X	X
Check spare tire for proper pressure and correct stowage.	X	X	X	X	X
Inspect brake linings.	X			X	
Flush and replace engine coolant at 60 months, if not replaced at 102,000 miles (170 000 km).					X
Replace Spark Plugs: 2.4L Engine					X

Miles **(Kilometers)** **[Months]**	**66,000** **(110 000)** **[66]**	**72,000** **(120 000)** **[72]**	**78,000** **(130 000)** **[78]**	**84,000** **(140 000)** **[84]**	**90,000** **(150 000)** **[90]**
Change engine oil and oil filter.	X	X	X	X	X
Replace engine air cleaner filter.					X
Rotate tires.	X	X	X	X	X
Check spare tire for proper pressure and correct stowage.	X	X	X	X	X
Inspect brake linings.		X			X
Replace Spark Plugs: 2.4L Engine					X

Miles **(Kilometers)** **[Months]**	**96,000** **(160 000)** **[96]**	**102,000** **(170 000)** **[102]**	**108,000** **(180 000)** **[108]**	**114,000** **(190 000)** **[114]**	**120,000** **(200 000)** **[120]**
Change engine oil and oil filter.	X	X	X	X	X
Replace engine air cleaner filter.					X
Rotate tires.	X	X	X	X	X
Check spare tire for proper pressure and correct stowage.	X	X	X	X	X
Inspect brake linings.			X		
Change Automatic Transaxle Fluid and Filter.					X
Flush and replace engine coolant, 102,000 miles (170 000 km) if not done at 60,000 miles		X			
Replace Spark Plugs: 2.4L Engine					X
Replace Spark Plugs: 2.7L and 3.5L Engines		X			
Replace the accessory drive belt every 120,000 miles (200 000 km).					X

Inspection and service should also be performed anytime a malfunction is observed or suspected. Retain all receipts.

WARNING!

You can be badly injured working on or around a motor vehicle. Do only that service work for which you have the knowledge and the right equipment. If you have any doubt about your ability to perform a service job, take your vehicle to a competent mechanic.