MODELS – BJ9*** CALIBRE 6000 SERIES

Mvmt. Cal. No. B876

FEATURES

- ☐ Light Powered
- ☐ Time
- ☐ World Timer

BENEFITS

- ☐ Environmentally Clean Energy Source
- ☐ Displays 12 and 24 Hour System
- ☐ World Time for 23 Cities



TO SET THE TIME AND DATE

If your model features a screw down crown, unlock the crown by turning it counterclockwise.

NOTE: Your model may feature a single crown, rather than an upper and lower right crown.

☐ Pull the lower right or single crown out two 'clicks'.

☐ Rotate the lower right or single crown clockwise to set the 24-hour and minute hands to the correct time.

☐ Push the lower right or single crown in one 'click'.

☐ Turn the lower right or single crown clockwise to move the 12-hour hand clockwise until you see the date start to change. Use this time as a night time reference and continue to turn the crown clockwise until the current hour is set.

☐ Turn the lower right or single crown counterclockwise to set the current date.

☐ Push the lower right or single crown in one 'click' to the closed position next to the case. If your model features a screw down crown, lock the crown by turning it clockwise until it is seated next to the case.

TO SET THE DATE ONLY

For months shorter than 31 days, the date will need to be manually adjusted to the correct date.

If your model features a screw down crown, unlock the crown by turning it counterclockwise.

☐ Pull the lower right or single crown out one 'click'.

☐ Turn the lower right or single crown counterclockwise to advance the date.

☐ Push the lower right or single crown in one 'click' to the closed position next to the case. If your model features a screw down crown, lock the crown by turning it clockwise until it is seated next to the case.

TO SET A SECOND TIME ZONE

The hour hand can be set to indicate an alternate time zone in one hour increments.

If your model features a screw down crown, unlock the crown by turning it counterclockwise.

☐ Pull the lower right or single crown out one 'click'.

☐ Turn the lower right or single crown clockwise to move the 12-hour hand clockwise to the desired hour setting. You can only move the hour hand clockwise. NOTE: As the date mechanism is linked to the hour hand, it may be necessary to correct the date, depending on the time to which the hour hand was set.

☐ Push the lower right or single crown in one 'click' to the closed position next to the case. If your model features a screw down crown, lock the crown by turning it clockwise until it is seated next to the case.

TO DETERMINE WORLD TIME

Your model may feature a rotating world time dial ring or bezel. If your model features one of these, you can determine the time in other time zones.

NOTE: Your model may feature a single crown with rotating world time bezel, rather than an upper right crown with a rotating dial ring.

☐ Rotate the upper right crown or rotating bezel until the middle of the city name (time zone) is in alignment with the tip of the 24-hour hand.

In the example below, this city/time zone would be Los Angeles.

In this instance, the 24-hour hand indicates 10:00 hours or 10:00 a.m.

Referring to the 24-hour indicator track and the 'middle' of other city names, you can determine the corresponding hour of other time zones. Remember to read the time in hours past midnight (24-hour time). Minutes past the hour are determined by the minute hand.



In the above example:

Chicago = 12:09 hours or 12:09 p.m.

London = 18:09 hours or 6:00 p.m.

Hong Kong = 02:09 hours or 2:09 a.m. (tomorrow)

Tokyo = 03:09 hours or 3:09 a.m. (tomorrow)

NOTE: Remember that not all cities/time zones displayed observe daylight savings time. Take this into consideration when determining the time in other locales.