Citizen Movement/Cal. C460
Abbreviated Instructions

FEATURES

- ■30 Cities/ 22 Time Zones
- ■Analog and Digital Display
- ■Calendar
- ■2 Alarms
- ■24 Hour, 1/100 Second Chronograph
- ■99 Minute Countdown Timer
- ■Dual Time
- ■Electro-luminescence

BENEFITS

- ■Worldwide Time
- ■Time at a Glance
- ■Perpetual for 100 years
- ■Use Alarm 2 for Snooze
- ■Split-Second Precise Timing
- ■Sounds Signal When Time is Up
- ■See Two Time Zones
- ■Time Visible at Night



Click Here for Full Setting Instructions (176k pdf)

NOTE: After a battery change or an abnormal display or function is noticed, an ALL RESET is required. Be sure to set the time and date after performing the ALL RESET.

ALL RESET PROCEDURE

■Press and release the upper left button (M) to move mode indicator to TME (time) mode.

■Pull the crown out to setting position.

■Press the upper left (M), lower left(B) and lower right(A) buttons down simultaneously for 3 seconds, then release them. All digital segments in the displays will be highlighted (black).

■Press crown in. At this point, a beep is heard indicating that ALL RESET is complete. Set correct time and calendar and other modes as needed.

TO SET THE ANALOG TIME

■Pull crown out to hand setting position and turn crown.

TO SWITCH DIGITAL MODES

■Modes can be changed in the following sequence: **TME** (time), **CAL** (calendar), **AL-1** and **AL-2** (alarms), **CHR** (chronograph), **TMR** (timer), **SET** (zone setting) by pushing and releasing the Mode (M) button.

TO SET THE DIGITAL TIME

■Press the lower left button (B) to move the time zone city code into digital display II.

■If **TME** is not showing in digital mode display, press the upper left button (**M**) button to select **TME.**

■Press the lower left button (**B)** in and hold for 3 seconds to switch to digital time setting mode. **S**.**T**. (summer time) used for daylight saving time and "ON" or "OF" will begin flashing.

■Press lower right button (A) to select **S**.**T**. "ON" or "OF" (off).

■Press and release lower left button (B). Seconds figures will flash. Use lower right button (A) to reset seconds.

*Press and release the lower left button (B). Minutes will flash. Press the lower right button (A) to adjust minutes. Hold the lower right button (A) continuously for rapid change.

■Press and release the lower left button (B). Hours will flash.

■Press the lower right button (A) to set hours according to a.m. or p.m.

■Press the lower left button (B). 12H will flash. Press the lower right button (A) to select 24H (military time) if desired.

■Press the lower left button (B) or the upper left button (M) to return to normal time display.

TO SET THE CALENDAR

■Press and release the upper left button (M) to move mode indicator to CAL (calendar). Digital display I shows Month and Date. Digital display II shows City Code.

■Hold the lower left button (B) in for three seconds and then release. Month number starts flashing. Press the lower right button (A) to advance month number.

■Press and release lower left button (B). Date starts flashing. Press the lower right button (A) to advance date.

■Press and release the lower left button (B). Digital display I shows the year and year numbers will be flashing. Press the lower right button (A) to advance year.

■After the lower left button (B) or upper left button (M) is pressed, digital display I shows month (numeric) and date.

TO SET ALARMS (ALM 1 & 2)

■Pressing the upper left button (M), move the mode indicator to **ALM 1** (or **ALM 2**).

■Press and hold the lower left button (B) for 3 seconds then release it. The hours in digital display I will flash.

■Press the lower right button (A) to advance hours.

■Press and release the lower left button (B). Minutes in digital display I will flash. Press the lower right button (A) to set minutes. Setting **alarm** time sets **alarm** to on.

■Press the lower left button (B) to finalize setting.

■To switch **alarm** off or on while in **alarm** mode, press the lower right button (A). While in **alarm** mode, digital display II shows city code.

TO USE THE CHRONOGRAPH

■Press upper left button (M) to move to CHR mode. The chronograph can measure up to 23 hour, 59 minutes, 59 and 99/100 seconds.

■Press the lower right button (A) to start or stop chronograph. Digital display I shows minutes, seconds and 1/100 seconds. Digital display II shows measured time hours.

■If the lower left button (B) is pressed while chronograph is running, a split time is displayed for 10 seconds as chronograph continues counting elapsed time internally.

■If the lower left button (B) is pressed when counting is stopped, chronograph is reset to zero.

TO USE THE TIMER

■Press the upper left button (M) to move to TMR (Timer mode). Timer can be set to countdown from 99 minutes down to 1 minute in 1-minute intervals. Digital display II shows Timer set time in minutes and digital display I shows Timer minutes and seconds remaining.

■Press lower left button (B) to se**t** Timer minutes.

■Press lower right button (A) to start or stop Timer countdown.

■Pressing lower left button (B) after Timer is stopped resets it to original Timer set time.

■If the lower left button (B) is pressed while Timer is running, the time is reset to the original Timer set time and restarts the countdown automatically. When Timer counts down to zero, the time up signal sounds for 5 seconds and the display returns to the Timer set time and stops.

For additional features and instructions, please refer to the full instruction manual or our web site at ww.citizenwatch.com.