MODELS – BT00* CALIBRE 3100 TWIN DATE
CALIBRE 3150 TWIN DATE WORLD TIMER

Mvmt. Cal. No. E310

FEATURES

- ☐ Light Powered
- ☐ Perpetual Calendar
- ☐ Twin Date Display
- ☐ Time

BENEFITS

- ☐ Environmentally Clean Energy Source
- ☐ Accurate to the Year 2100
- ☐ Oversized Display Window
- ☐ Displays 12/24 Hour Systems



Please view our interactive setting instructions @ www.citizenwatch.com

IMPORTANT NOTES:

If a low/no charge state is reached, or another malfunction is experienced, an ALL RESET and 0-POSITIONING will be required.

A.M. or P.M. time is determined by referring to the 24-hour hand at the 9:00 position. When the hand indicates 24 to 12, the time is a.m. When the hand indicates 12 to 24, the time is p.m. It is important to pay particular attention to 24-hour hand when setting the time for proper function of the perpetual calendar.

This watch features two date 'discs', date disc 1 (left) and date disc 2 (right.) Each disc operates independently of the other. In addition to displaying the second digit of the date of the month, date disc 1 (left) has the following displays:

 Normal - shows date of month

 Indicates leap year is to be set

 Indicates months 1 to 9 are to be set

 Indicates months 10 to 12 are to be set

ALL RESET PROCEDURE AND 0-POSITIONING PROCEDURES

☐ Pull the crown out two 'clicks'.

☐ Press and hold the upper right button (A) and lower right button (B) simultaneously for 2 seconds and release. This completes the All Reset.

☐ Press and release the upper right button (A) to select a date disc.

☐ Press and release the lower right button (B) to change the date on the selected disc. Continue this until '0' is shown on the selected disc.

☐ Press and release the upper right button (A) to select the next date disc.

☐ Press and release the lower right button (B) to change the date on the selected disc. Continue this until '0' is shown on the selected disc.

☐ Push the crown in two 'clicks'. This completes the All Reset and 0-Positioning procedure. The time and calendar must now be set.

TO SET THE TIME

☐ Pull the crown out two 'clicks'.

☐ Rotate the crown clockwise or counterclockwise to set the current time, paying close attention to the 24-hour hand at the 9:00 position. Be sure to set the correct a.m. or p.m. time.

☐ Push the crown in two 'clicks' to the closed position next to the case. This completes setting the time.

TO SET THE LEAP YEAR, MONTH AND DATE

Before proceeding, be sure to determine if the current year is a leap year or how many years have elapsed since the last leap year.

☐ Pull the crown out one 'click'. The date disc 1 (left disc) and date disc 2 (right disc) will rotate to indicate the current month set in memory.

☐ Press and hold the upper right button (A) for two or more seconds then release. Date disc 1 (left disc) will display 'L.Y.', Date disc 2 (right disc) will show the current years past a leap year set in memory (0,1,2 or 3).

EX: the graphic below shows 1 year past a leap year



☐ Press and release the lower right button (B) until the correct leap year designation is shown on date disc 2 (right disc) EX: 0 = current year is leap year, 1 = 1 year past leap year, 2 = 2 years past a leap year, 3 = 3 years past a leap year.

☐ Press and release the upper right button (A). Both date discs will rotate to show the current month set in memory. Date disc 1 (left disc) will display 'MO' (for months 1 to 9) or 'M1' (for months 10 to 12) 'and date disc 2 (right disc) will show the single or first digit of current month set in memory. EX: In the picture below, the current month is November (11th month of the year.)



☐ Press and release the lower right button (B) to correct the current month second digit 'tens' indication ('MO' for months 1 to 9 or 'M1' for months 10 to 12.)

☐ Press and release the upper right button (A). Date disc 2 (right disc) will move from left to right slightly indicating date disc 2 (right disc) is now active for setting.

☐ Press and release the lower right button (B) to correct the current month first digit indication on date disc 2 (right disc) EX: Jan to September will be 1 to 9, while October = 0, November = 1, December = 2.

☐ Press and release the upper right button (A). Both date discs will rotate to show the current date set in memory. Date disc 1 (left disc) is now active for setting.

☐ Press and release the lower right button (B) to change the second digit 'tens' position of the date on date disc 1 (left disc) . EX: '0' for dates 1 to 9, '1' for dates 10 to 19, '2' for dates 20 to 29, '3' for dates 30 to 31.

☐ Press and release the upper right button (A). Date disc 2 (right disc) will move from left to right slightly indicating that date disc 2 (right disc) is now active for setting.

☐ Press and release the lower right button (B) to change the first digit 'ones' position of the date on date disc 2 (right disc). Example current date is 21:



☐ Push the crown to the closed position next to the case. This completes setting the leap year, month and date.

For additional features and instructions, please refer to the full instruction manual or our website at www.citizenwatch.com.