Dream Sight™ Camera Floor Stand User Guide

SKU: EWG6NNGLN

Dream Sight Camera Floor Stand Set Up

IFU-CamStand_EN: Rev 1



Setting Up your Dream Sight Camera Floor Stand This product is compatible with the Owlet Dream Sight™ camera. For detailed instructions on how to set up and use your Dream Sight camera, please refer to the Dream Sight User Guide.

Unbox the Floor Stand: Unbox your floor stand and make sure you have all the necessary parts laid out:

- Weighted base
- Pole segments (connected by the pre-threaded power cable)
- ASTM-certified cable management guards (1 corner piece and 4 straight pieces)
- Plastic slot-cover for corner cable management guard cover
- U-Clip wall mount bracket & screws (optional for extra stability)
- USB-C cable (pre-threaded through the pole segments)

Step 1: Assemble the Pole Segments

- Lay out the pre-threaded pole segments linearly on a flat surface or the floor
- Starting from the top pole segment, screw each pole segment together sequentially by hand
    - 💡 *Tip: If you encounter resistance from cable tension while connecting the pole segments, gently pull a bit of USB-C cable slack out through the bottom of the lowest pole segment to ease the twisting process*

Step 2: Secure the Pole Segments to the Weighted Base

- Lay the fully assembled pole segments down on the floor and tilt the base on its side to access the bottom
- Pull any remaining USB-C cable slack out through the center hole of the base to prepare the connection point
- Insert the bottom pole segment securely into the base reception hole
- Reach underneath the base to tighten the wing nut by hand
- Alignment Check: Before tightening the base completely, look at the orientation of the top hinge neck segment, rotate the entire pole system until the top neck is perfectly aligned in your desired position
- Once properly aligned, tighten the underside wing nut completely. Pull any remaining cable slack out through the bottom channel of the base

Step 3: Route the USB-C cable through the Corner Cable Guard and click into base

- Locate the corner cable guard. Identify the male end that will be inserted into the integrated plastic locking clip on the bottom of the base
- Take the USB connector and push it through the opening of the male end of the corner piece first, followed by the temperature sensor, and pull them out through the opening in the slot of the corner piece
- Once both USB connector and temperature sensors are through the slot opening, insert the USB connector back through the slot and push it through the other end of the elbow piece. Pull the remaining cable through
- Insert the plastic slot-cover to cover the opening of the corner cable guard
- With the assembled stand on its side, press the corner cable guard into your chosen side of the bottom of the base until it clicks, pulling excess cord through it as you go
    - 💡 *Tip: Place the corner cable guard so it curves toward the direction of your wall outlet*

Step 4: Install the ASTM-Certified Cable Management Guards

- Thread the cable through the provided ASTM-certified cable management guards and securely attach them together, and to the elbow piece.
- The stand body is now fully assembled!

Step 5: Attach the Wall Mount Bracket

A 2-piece quick-release U-clip wall mount bracket is included and is highly recommended when positioning the stand within 3 feet of a crib for added stability.

- Snap the wall mount piece around the midsection of the vertical pole
- Stand the pole upright against the wall where you intend to position it, use a pencil to mark the two screw hole locations on your wall, and then move your stand away
- If attaching to a wood surface, use a 1/8” drill bit to pre-drill your screw holes. If attaching to drywall, use the self-driving drywall anchors
- Drill your pilot holes (or screw in your self-driving drywall anchors). peel the adhesive backing off the bracket and and fix the bracket firmly to the wall, aligning the holes of the bracket to the mounting location. Secure using the provided screws
- Push the floor stand pole back into the bracket and secure it with the clip

Step 6: Install the Camera & Power On

- With the stand upright, take your Dream Sight camera (sold separately) and screw it into the thread of the ball joint at the top of the stand

- Plug the USB-C connector at the very top of the neck directly into the port on the back of the camera
- Plug the power adapter into the nearest wall outlet, and connect the USB cable
- Open the Owlet Dream app on your smartphone to complete the syncing process and adjust your viewing angle as needed
    - 💡 *Tip: For detailed instructions on how to set up and use your Dream Sight camera, please refer to the Dream Sight User Guide*

How to Adjust the Floor Stand Height

If the floor stand is too tall for your space, you can lower it to a two-segment configuration by completely removing the bottom pole segment

Step 1: Prepare for Disassembly

- Unplug the power adapter from the wall outlet and disconnect the camera from the top of the stand. (If you are using the quick release wall mount bracket, unclip the stand from the wall.)
- Remove the straight cable guards
- Carefully lay the entire stand flat on the floor to prevent it from falling.

Step 2: Disassemble the Base and Lower Pole Segment

- Loosen the lower pole segment from the base by unscrewing it directly, or by loosening the wing nut located on the underside of the base
- Once detached from the base, unscrew the bottom pole segment from the middle segment
    - **Note on Threaded Inserts:** If the silver threaded insert piece detaches or comes loose while unscrewing the lower pole, ensure it is re-inserted and screwed securely into the top of the lower pole for future use.

4. Step 3: Route the Cable and Remove the Pole

- Pull the entire power cable up and out through the corner piece and the bottom of the weighted base to create slack
    - 💡 *Tip: Remove the slot cover on the corner cable guard, and reverse the install steps to get the temperature sensor and the connector through the cable guard. You may need a small tool (like a flathead screwdriver) to remove the slot cover*

- Feed the cable through the detached base components to completely free them
- Slide the bottom pole segment off the cable entirely and set it aside
    - 💡 *Tip: Store the removed pole segment in your original box for safekeeping in case you want to raise the height later*

Step 4: Reassemble the Shorter Stand

- **Feed the Cable First**: Route the power cable connector back down through the center hole of the weighted base before trying to screw anything together
- **Pull the Slack**: Reach underneath the base and gently pull all the excess cable slack completely through the bottom
- **Screw the Pole to the Base**: Screw the remaining pole segments securely into the weighted base and tighten the wing nut underneath
- **Adjust the Top Pole Angle**: Double-check the rotation of the top pole so it points toward your crib or bassinet, then finish tightening
- **Route the Base Cable & Reinsert the Corner Cable Guard:** Wrap and press the power cable firmly into the routing channel on the underside of the base to manage excess slack in the cable. Route the cable through the corner cable guard. Re-insert the slot cover, and re-attach the corner cable guard to the base. Carefully lift the stand back into an upright position.
- **Snap Cable Management Guards Back On**: Re-attach the plastic cable management guards and ensure the cable is safety concealed

Power Up: Re-attach your camera, plug the adapter into the wall, and adjust the camera neck tilt as needed

Need help?

For contact information specific to your region, please visit:

https://support.owletcare.com



⚠WARNING:

Strangulation Hazard!

Children have STRANGLED in cords. Always use protective covering when used within 3 feet of the crib. Check before each use to ensure that the cord is not exposed to your child. Immediately discontinue use if protective covering is damaged or broken. When using without protective covering, keep this cord out of the reach of children (more than 3 ft (0.9m) away).

For indoor use only. To reduce the risk of fire or electrical shock, **DO NOT** expose this product to water or moisture. **DO NOT** use the monitor near water (such as bathtub, sink, etc.) or submerge in water.

If cleaning is required, disconnect the camera from power and use a dry microfiber cloth to gently wipe the lens and camera body. Do not use soap, water, or chemical cleaners.
The use of this monitor should not replace proper adult/parental supervision. You should check your child's activity at regular intervals, as this monitor will not alert parents to the silent activities of a child.

Adult assembly is required. Keep small parts away from children when assembling. Exercise care when unpacking the product. This product is not a toy. **DO NOT** allow children to play with it.

ADDITIONAL SAFETY INSTRUCTIONS

POWER CORD PROTECTION: The power supply cord should be routed so that it is not likely to be walked on or pinched by items placed upon or against it. Pay particular attention to the cord at the plug and at the point it exits from the monitor.

STORAGE TEMPERATURE

-25°C - + 60°C (-13°F to 140°F)

OPERATING TEMPERATURE

-10°C ~ + 40°C (14°F ~ 104°F)

LIMITED WARRANTY

Owlet proudly stands behind its products. Our warranties are found at: https://owletcare.com/pages/warranty

©2026 Owlet Baby Care, Inc. All rights reserved.

Owlet Baby Care, Inc.

2940 West Maple Loop Dr. Suite 203

Lehi, Utah 84048

USA