

CASSETTE AND FREEHUB

INSTALLATION INSTRUCTIONS



Insert 5mm Allen key turning counterclockwise to remove endcap. Set the end cap aside.



Slide the freehub off. Leave the spacer on the axle.



Slide freehub with cassette onto the axle. Thread the end cap back on the axle. Insert 5mm Allen key turning clockwise to tighten endcap.