

Instructions



1 Engage the brake pedal and unbutton the carriage fabric on the rear wall.



2 Place the Buddy Board on the lower frame tube.



3 Important: For Pro Series stroller wagons, attach the straps to the frame tube, not the sliding tabs.



4 Loop the strap behind and over the upper frame tube.



5 Slide the strap through the opening in the metal clip.



6 Completed attachment shown. Repeat steps 3-4 with the other strap.



7 Button the carriage fabric.



8 Completed installation shown.

Note: The Buddy Board should only be installed on the **rear** side of the wagon.
Do not exceed the weight limit of 44 lbs. (20 kg)



Follow Us!



WonderFold.com

Questions? Email Us: hello@wonderfold.com

How to Stow the Buddy Board



Lift the Buddy Board up towards the wagon.



Secure the magnetic lock on the left strap.



To release the lock, push the button at the top.



Completed Stow Away

How to Clean Your Buddy Board

1. Detach it from the stroller.
2. Wipe it down with a damp cloth and mild soap if needed.
3. Use a soft brush for tight spots.
4. Rinse, dry, and reattach.
5. Check for any loose parts such as the straps, metal clip, or magnetic clip.



Follow Us!



WonderFold.com

Questions? Email Us: hello@wonderfold.com