

Part 1


OPERATION OF INSTRUMENTS AND CONTROLS—


Chapter 1-1

Overview of instruments and controls

- Instrument panel overview
- Instrument cluster overview
- Indicator symbols on the instrument panel


Instrument panel overview





1. Instrument panel light control dial
2. Headlight and turn signal switch
3. Wiper and washer switches
4. Driving pattern selector button
5. Thermometer
6. Clock
7. Emergency flasher switch
8. Car audio
9. Miscellany box
10. Air conditioning controls
11. Ashtray and cigarette lighter
12. Rear window defogger switch
13. Ignition switch
14. Cruise control switch
15. Power rear view mirror control switch
16. Headlight cleaner switch

Instrument cluster overview



1. Fuel gauge

2. Engine coolant temperature gauge

3. Tachometer

4. Speedometer

5. Odometer

6. Trip meter

7. Trip meter reset knob

8. Service reminder indicators or
indicator lights

9. Theft deterrent system indicator light

Indicator symbols on the instrument panel

BRAKE (type A)  (type B)	Brake system warning light * ¹
	Seat belt reminder light* ¹
	Discharge warning light* ¹
	Low oil pressure warning light* ¹
	Malfunction indicator lamp* ¹
	Low fuel level warning light * ¹

ABS (type A)  (type B)	Anti-lock brake system warning light * ¹
	Open door warning light* ¹
	Rear light failure warning light* ¹
	SRS airbag warning light* ¹
	Turn signal indicator lights
	Headlight high beam indicator light

O/D OFF	Overdrive-off indicator light
ECT PWR	Driving pattern indicator light
CRUISE	Cruise control indicator light *2
P R N D 2 L	Automatic transmission indicator lights

*1: For details, see “Service reminder indicators and warning buzzers” in Chapter 1-5.

*2: If this light flashes, see “Cruise control” in Chapter 1-6.