

## Quick index

- If a service reminder indicator or warning buzzer comes on ..... 54
- If your vehicle will not start ..... 136
- If your engine stalls while driving ..... 139
- If your vehicle overheats ..... 139
- If you have a flat tire ..... 140
- If your vehicle needs to be towed ..... 146
- Tips for driving during break-in period ..... 114
- How to start the engine ..... 124
- General maintenance ..... 157
- Complete index ..... 197

## Gas station information

**Fuel type:** UNLEADED gasoline, Research Octane Number 91 (Octane Rating 87) or higher.

See page 126 for detailed information.

**Fuel tank capacity:** 70 L (18.5 gal., 15.4 Imp. gal.)

### Engine oil:

API SH, "Energy-Conserving II" multigrade engine oil or ILSAC multigrade engine oil is recommended.

See page 186 for detailed information.

### Automatic transmission fluid:

Automatic transmission fluid D-II or DEXRON<sup>®</sup> III (DEXRON<sup>®</sup> II)

**Tire information:** See pages 189 through 192.

**Tire pressure:** See page 207.

**Publication No. OM60708U**

**Part No. 01999-60708**

Printed in Japan 01-9608-00 [C]

ランドクルーザー(北米U)