

2009 Venza Navigation System Quick Reference Guide

V E N Z A

TABLE OF CONTENTS

LIMITATIONS OF THIS QUICK REFERENCE GUIDE	1
BASIC OPERATION	2
DESTINATION INPUT	3
<i>By Address</i>	3
<i>Note on Voice Recognition</i>	5
<i>Tips for Using Voice Recognition</i>	5
<i>By Address - Voice Recognition</i>	5
DESTINATION INPUT - POINT OF INTEREST (POI)	7
<i>Point of Interest by Name</i>	7
<i>Point of Interest by Category</i>	8
<i>Point of Interest by Category - Voice Recognition</i>	9
DESTINATION INPUT - TELEPHONE NUMBER	10
<i>Business or Registered Addresses</i>	10
SET HOME	11
CONNECT A BLUETOOTH PHONE	13
CALLING BY VOICE RECOGNITION	14
<i>Dial by Number</i>	14
ADDITIONAL NAVIGATION FEATURES	15
<i>Search Area</i>	15
<i>Route Preferences</i>	15
<i>3 Routes</i>	15
<i>Screen Preferences</i>	15
<i>Beep Setting</i>	16
<i>Voice Volume</i>	16
<i>Language</i>	16
<i>Clock Settings</i>	16
<i>Auto Screen Change</i>	16
<i>Voice Recognition Guidance</i>	16
<i>Estimated Distance and Time</i>	17
<i>Operation of Vehicle Emergency Screen</i>	17
VOICE COMMANDS	18
XM NAVTRAFFIC®	20
<i>XM NavTraffic® Preferences</i>	21

LIMITATIONS OF THIS QUICK REFERENCE GUIDE

This Quick Reference Guide is designed to provide information on the basic operation and key features of the navigation system. The Quick Reference Guide is not intended as a substitute for the Navigation Owner's Manual. We strongly encourage you to review the Navigation Owner's Manual so you will have a better understanding of the navigation system capabilities and limitations.



1 NORTH-UP OR COMPASS MODE Icon

Touch to change the map display between North-up or Head-up perspectives.

2 ZOOM IN/ZOOM OUT Icons

Touch to magnify or reduce the map scale.

3 DISPLAY Button

Adjust the contrast, brightness or turn off the screen.

4 SETUP Button

Adjust Preferences for: General Settings, Clock, Voice, Navigation, Phone, Audio, and Vehicle Maintenance.

5 MAP/VOICE Button

Repeat the last voice guidance prompt, cancel the map scrolling feature, or display the current position.

6 DESTINATION Button

Input the destination by one of several methods.

7 INFO/PHONE Button


Access Phone, Map Data, and Calendar.

8 CURRENT VEHICLE POSITION Mark

Indicates the current position of the vehicle and its directional heading.


DESTINATION INPUT

BY ADDRESS



step 1 Press the **DEST** panel button followed by .



step 2 Touch  and move to step 4. To change Search Area, touch  and move to step 3.




step 3 Select the desired Search Area and touch .



step 4 Input the city name and touch .



step 5 Touch the desired city name.




step 6 Input the street name and touch .


Quick Tip - Enter the street name without prefixes such as North or the letter N. The system will display the base street name without prefixes or suffixes on the next screen.

DESTINATION INPUT

BY ADDRESS



step 7 Touch the desired street name.




step 8 Input the house number and touch **OK**.



step 9 Touch **Go to**.



step 10 Select the desired Route Preferences by touching **Edit Route**, followed by **Preferences**. Touch **OK** to confirm selection.



step 11 Touch **OK** to start route guidance.

DESTINATION INPUT

NOTE ON VOICE RECOGNITION

The navigation system voice recognition feature will compare your spoken words with computer-generated word patterns preprogrammed in the system database. If the system does not provide your intended match, please try a different pronunciation. Voice-activation names are not available for every street and city.

TIPS FOR USING VOICE RECOGNITION

- tip 1

A large TALK icon  will appear on the NAV screen to signal when to speak your command.
- tip 2

Have the full and correct address in mind. The system will ask for the state, city, and street name followed by the house number as separate inputs.
- tip 3

Before using voice recognition, roll up all windows and set the climate control fan on low or off to reduce background noise in the cabin.
- tip 4

Speak at a normal volume and pace, and pronounce words clearly.
- tip 5

Numbered street names should be spoken as in these examples:
1st Street, say: *"First Street"*
15th Street, say: *"Fifteenth Street"*
190th Street, say: *"One Hundred Ninetieth Street"*
- tip 6

Say a street address number as single digits. Examples:
125, say: *"One two five"*
2000, say: *"Two zero zero zero"*
32307, say: *"Three two three zero seven"*

BY ADDRESS-VOICE RECOGNITION



- step 1

Press  on the steering wheel. After the beep say, "Destination."

Quick Tip - If you know your next command, you can press  at any time to interrupt the prompt. Speak your command after the beep.




- step 2


After the beep say, "Address."

DESTINATION INPUT


BY ADDRESS-VOICE RECOGNITION




step 3 After the beep say the city name or, "Change state" to search in another state.




step 4 After the beep say the street name.



step 5 After the beep say the house number.



step 6 After the beep say, "Enter" to confirm destination.



step 7 Touch **START** to start route guidance.

DESTINATION INPUT - POINT OF INTEREST (POI)

POINT OF INTEREST BY NAME



step 1 Press the **DEST** panel button followed by .



step 2 Touch .



step 3 Input the POI name and touch .



step 4 Use  or  to scroll up or down. Touch the desired destination.

Quick Tip - If the POI isn't listed in the database verify the spelling and Search Area for accuracy.



step 5 Touch .


Quick Tip - Touching  next to the POI name will display the address and telephone number.




step 6 See page 15 to select desired Route Preference. Touch  to start route guidance.

DESTINATION INPUT - POINT OF INTEREST (POI)


POINT OF INTEREST BY CATEGORY




step 1 Press the **DEST** panel button followed by .



step 2 Touch .



step 3 Touch the desired category location.



step 4 Touch the desired category icon followed by the desired sub-category.



step 5 Use  or  to scroll up or down. Touch the desired point of interest.



step 6 Touch . See page 15 to select desired Route Preference. Touch  to start route guidance.

DESTINATION INPUT - POINT OF INTEREST (POI)

POINT OF INTEREST BY CATEGORY - VOICE RECOGNITION



step 1 Press  on the steering wheel. After the beep say, "Destination."

Quick Tip - If you know your next command, you can press  at any time to interrupt the prompt. Speak your command after the beep.



step 2 After the beep say, "Point of Interest."



step 3 After the beep say, "Near Here."



step 4 After the beep say, "Hotels." See page 19 for the list of recognized POI categories in addition to those displayed on the screen.




step 5 After the beep say the number that corresponds to the desired destination.




step 6 After the beep say, "Enter" to confirm destination. Touch  to start route guidance.

DESTINATION INPUT - TELEPHONE NUMBER

BUSINESS OR REGISTERED ADDRESSES




step 1 Press the **DEST** panel button followed by **1**.



step 2 Touch **Phone #**. Input the area code and telephone number followed by **OK**. It is not necessary to dial "1."


Quick Tip - Personal telephone numbers cannot be used for Destination input unless previously added as a registered address.



step 3 Select the business or registered address from the screen.



step 4 Touch **Go to**.




step 5 See page 15 to select desired Route Preference. Touch **OK** to start route guidance.

SET HOME



step 1 Press the **SETUP** panel button followed by **Nav.**




step 2 Touch **Home**.




step 3 Touch **Set Home**.

Tip - For security reasons, use a point close to your home instead of your actual home address.



step 4 Touch **Address**.



step 5 Make sure you are in the desired Search Area. Touch **City**.



step 6 Input the city name and touch **OK**.




step 7 Touch the desired city name.




step 8 Input the street name and touch **OK**.


Quick Tip - Enter the street name without prefixes such as North or the letter N. The system will display the base street name without prefixes or suffixes on the next screen.



step 9 Touch the desired street name.



step 10 Input the house number and touch **OK**.




step 11 Touch **Edit** followed by **Edit** to change the home icon.




step 12 Touch the desired icon for your home. Touch **OK** at the bottom right of the Edit Home screen.

CONNECT A BLUETOOTH PHONE




step 1 Press the **INFO PHONE** panel button followed by .

Quick Tip - Verify the Bluetooth cell phone has been approved by visiting www.Toyota.Letstalk.com.



step 2 Touch . Verify that Bluetooth feature on the phone is ON and is in discoverable mode.




step 3 Input the passkey listed on the screen into the approved Bluetooth cell phone. Please refer to the cell phone manufacturer's user guide for pairing procedures.



step 4 Upon connection, the system will indicate that the pairing process was successful.

CALLING BY VOICE RECOGNITION

DIAL BY NUMBER




step 1 Press  on the steering wheel. After the beep say, "Phone."


Quick Tip - If you know your next command, you can press  at any time to interrupt the prompt. Speak your command after the beep.




step 2 After the beep say, "Dial by Number."



step 3 After the beep say the phone number digits individually (e.g. "Three, one, zero, four...").



step 4 After the beep, say "Dial."




step 5 Call is active when **Talking** is indicated. To end call, press  on the screen or  on the steering wheel.

   Some Bluetooth® equipped cell phones may or may not show battery or signal strength on the display.

Quick Tip - A noisy environment may prevent the voice recognition system from understanding your commands. It is recommended that you reduce background noise (including passenger conversation and wind noise) prior to using the Voice Recognition system.

ADDITIONAL NAVIGATION FEATURES

SEARCH AREA




Prior to inputting the desired address select the appropriate Search Area by pressing **Search Area**. If the incorrect Search Area is chosen, the system will either find an address that closely matches in that area or will indicate that the address cannot be found.



Select the desired Search Area and touch **OK**.

ROUTE PREFERENCES



Once the address has been inputted, select the desired route preference(s) for the trip. When the yellow bar appears, the preference has been selected. For example, if Allow Toll Roads is not selected, the system will route over non-toll roads which may take longer to reach the destination.

3 ROUTES



One of the three routes may be chosen for the trip. Quick offers the shortest route by time; Alt is the second fastest route; Short is the most direct based upon driven mileage. The system does not account for traffic signals or traffic flow.

SCREEN PREFERENCES




Touch **Show on Map** to select from seven different screen viewing options. Three screen preferences are available when the map is visible and four additional are available during route guidance only.

- | | | | |
|--|-------------|--|-------------------------|
| | Single Map | | * Arrow |
| | Dual Map | | * Freeway Information |
| | Compass | | * Intersection Guidance |
| | * Turn List | | |

* Selections available when in guidance mode.

ADDITIONAL NAVIGATION FEATURES

BEEP SETTING



PRESS **SETUP** **PANEL BUTTON** > 

Adjust the Beep sound On or Off.


VOICE VOLUME



PRESS **SETUP** **PANEL BUTTON** > 

Adjust the Voice Guidance volume level.


LANGUAGE



PRESS **SETUP** **PANEL BUTTON** > 

Select Language Preference: English, French or Spanish.


CLOCK SETTINGS



PRESS **SETUP** **PANEL BUTTON** > 

Adjust the Time Zone and Daylight Saving Time option.


AUTO SCREEN CHANGE



PRESS **SETUP** **PANEL BUTTON** > 

Once the screen transition is switched off, the audio screen will remain without reverting to the map display.

VOICE RECOGNITION GUIDANCE



PRESS **SETUP** **PANEL BUTTON** > 

Disables system guidance when responding to voice commands. Only on screen prompts will be available when switched off.

ADDITIONAL NAVIGATION FEATURES

ESTIMATED DISTANCE AND TIME†




PRESS **SETUP** **PANEL BUTTON** >
> **DETAILED NAVI SETTINGS** >
DRIVING SPEEDS

The system can be customized to match your driving habits. Adjust the speed settings for Residential, Main Streets and Freeways to match your normal driving speed. Adjusting these settings will affect the estimated time of arrival (ETA).

Please refer to the Navigation Owner's manual for a complete description of this feature.

† The system does not account for traffic signals or traffic flow.


OPERATION OF VEHICLE EMERGENCY SCREEN



Press the **DEST** panel button followed by  and then  to access four emergency destinations:

- Police Stn. • Hospital • Dealer • Fire Stn.

Touch the desired Emergency category. If the vehicle is in motion, only nearby police stations, dealers, hospitals or fire stations are shown.



Touch the desired destination.

VOICE COMMANDS

Press  on the steering wheel to activate the voice recognition feature. After the beep, say one of the voice commands listed. Please refer to the Navigation Owner's Manual for additional information.

AUDIO MODE

MODE

Radio
AM
FM
FM1
FM2
Satellite Radio*
Satellite Radio 1*
Satellite Radio 2*
Satellite Radio 3*
CD
CD Changer
Bluetooth Audio

FUNCTION

Audio On/Audio Off
Seek Up
Seek Down
Type Up
Type Down
Track Up
Track Down
Previous Track
Disc Up
Disc Down

TELEPHONE MODE

CALLING

Dial by Number
Dial by Name
Select Phone

NAVIGATION MODE

SCREEN PREFERENCES

Map
Dual Map
Single Map
Compass Mode
Arrow Mode
Turn List Mode
Freeway Mode
Intersection Mode

MAP OPERATION

Zoom In
Zoom Out
Right Map Zoom In
Right Map Zoom Out

MAP ORIENTATION

North Up
Heading Up
Map Direction
Right Map North Up
Right Map Heading Up
Right Map Direction

DESTINATION

Previous Start Point
Mark This Point
Delete Next Destination
Delete Final Destination
Delete All Destinations

CHANGE ROUTE

Quick Route
Short Route
Alternate Route
Detour
Detour Entire Route

GUIDANCE HELP

Route Overview
Next Destination Map
First Destination Map
Second Destination Map
Third Destination Map
Fourth Destination Map
Fifth Destination Map
Final Destination Map
Pause Guidance
Resume Guidance
Repeat Guidance

VOLUME

Louder
Softer

TRAFFIC

Traffic Information

* If equipped

VOICE COMMANDS

NAVIGATION MODE

POI (POI must be entered via the destination screen, see page 9.)

Attractions

Attractions
Bowling Centers
Entertainment
Golf Courses
Health & Fitness Clubs
Horse Racing
Parks & Beaches
Marinas
Motor Sports
Nightlife
Performing Arts
Ski Resorts
Sports Complexes
Sports & Fitness

Automotive

Automobile Clubs
Auto Service & Maint.
Car Rental Agencies
Car Washes
Dealerships
Gas
Lexus
Parking
Parts Stores
Roadside Assistance
Toyota
Other Automotive

Banks

ATMs
Full-Service Banks

City Centers

City Centers
Government
Libraries
Post Offices
Schools

Emergency/Medical

Fire Stations
Hospitals
Pharmacies
Police Stations
Other Med. Facilities

Food

Dining
American
Bakeries & Delis
Barbecue & Grill
Cajun/Caribbean
Chinese
Coffee Houses
Fast Food
French
Greek
Indian
Ice Cream & Candy
Italian
Japanese
Korean
Latin/S. American
Middle Eastern
Mexican
Pizza
Seafood
Spanish
Steak Houses
Thai
Vietnamese
Other Restaurants

Groceries

Convenience Stores
Groceries
Shopping Malls

Retail & Dept. Stores

Book Stores
Clothing & Shoes
Department Stores
Florists
Hobbies & Crafts
Jewelry
Retail & Dept. Stores
Sport Equipment
Other Retail Stores

Travel

Airports
Bus Stations
Hotels
Ports & Ferries
Recreational Vehicles
Rest Areas
Taxis & Shuttles
Tourist Information
Train Stations

Other

Dry Cleaners
Home Improvement
Personal Grooming
Shipping & Copies
Office & Electronics
Other Services
Clear All Icons




XM NavTraffic® integrates with your navigation system to display traffic information. Traffic events and flow data are updated 12 times each hour from a variety of sources. XM NavTraffic® service is available in 80 major metropolitan areas across the continental US with more to come.

New VENZA owners with factory-installed navigation receive a 90-day complimentary trial subscription from XM.

Traffic information provided by XM NavTraffic®:
<http://www.xmradio.com/navtraffic/index.xmc>



Route guidance with flow information and traffic events.



Traffic events - road construction.



Accidents and disabled vehicles.


XM NAVTRAFFIC®

XM NAVTRAFFIC® PREFERENCES

SHOW XM NAVTRAFFIC® INFORMATION




step 1 Touch **Show on Map**.




step 2 Touch **Traffic Information**. When the yellow bar appears, the preference has been selected. Touch **Route Trace**, traffic flow is displayed by color lines right along the side of the freeways:

- Free flow traffic
- Moderate traffic
- Heavy congestion

AUDIO AVOID TRAFFIC




step 1 Press **SETUP** followed by **Item**.




step 2 Touch **Detailed Navi. Settings**.




step 3 Select **On** from the Auto Avoid Traffic option. Touch **Save** followed by **Route**. The system will automatically select another route when moderate or heavy traffic is detected during route guidance.

TRAFFIC VOICE GUIDANCE


step 1 Press **SETUP** followed by **Voice**.



step 2 Touch **?** to display Traffic Voice Guidance option on page 2. Select **On** to receive voice notification of traffic events within 20 miles of the suggested route. Touch **Save** followed by **Back**.

SHOW FREE FLOWING TRAFFIC

step 1 Press **SETUP** followed by **Nav.**



step 2 Touch **Detailed Navi. Settings**.



step 3 Select **On** from the Show Free Flowing Traffic option. Touch **Save** followed by **Back**. Free flowing traffic is illustrated by green arrows on the map.



Customer Experience Center
1-800-331-4331