

Quick Reference Guide
for the vehicle

BMW 1 Series



The Ultimate
Driving Machine®



At a glance. The main functions of your BMW 1 Series.

Contents

Your BMW 1 Series in brief

Welcome on board

Your BMW 1 Series offers a wide range of equipment to make driving an enjoyable experience.

This Quick Reference Guide provides an initial overview. It contains information to enable you to become familiar with the basic functions of your BMW 1 Series.

For your safety and the safety of others, please read the detailed Owner's Manual.

You will find additional information in other brochures in the vehicle.

BMW hopes you get off to a good start and that you enjoy your BMW 1 Series.

Some illustrations show country-specific items or optional extras.

* Optional extras or country-specific items

4	Opening and closing
6	Seat and mirrors
9	Displays and controls
17	Safety
18	Driving
24	Radio/CD/Multimedia
26	iDrive
30	Navigation
32	Entertainment
34	Communication
36	Refueling
38	Service and Maintenance
40	24/7 Access
42	Trunk



4 Opening and closing Remote control



Open

Unlocks the entire vehicle.

Close


Locks the entire vehicle.

Open the trunk lid/tailgate

Press and hold (approx. 1 second) and then release.

Panic Mode*

Press for at least 3 seconds.
Press any button to cancel.



Convenient opening*

Press and hold the Open button to open the windows and glass sunroof* or top* after unlocking.

Convenient closing*

Convertible:

Using the remote control for Comfort Access*, press and hold the Close button to close the windows and top* after locking.

Opening and closing 5

Personal Profile and Comfort Access*

Personal Profile

Some of the vehicle's functions can be individually tailored and stored for several remote controls. Depending on the remote control that is detected when unlocking the vehicle, different settings are retrieved and implemented in the vehicle.

Keyless driving pleasure*


The Comfort Access system allows you to gain access to the vehicle and start the engine without holding the remote control. The remote control is automatically detected in the immediate vicinity of or inside the vehicle.

Open

Take a firm hold of the door handle.

Close

Touch the panel with your fingers for approx.
1 second.



6 Seat and mirrors


Mirrors

Mirror adjustment

Folding mirrors in and out*


Mirror left/right, Automatic Curb Monitor*

Select mirror: left/right.
Automatic Curb Monitor on: switch in driver's mirror position.



Seat and mirrors 7

Manual seat adjustment



8 Seat and mirrors

Electric* seat adjustment

MEMORY button*

Memory buttons*

Backrest angle

Forward/back*, height, seat tilt*

Lumbar support*


Backrest width*

Thigh support*

Seat and mirror memory*

You can store 2 different driver's seat and exterior mirror positions per remote control used.

1. Radio readiness or ignition on.
2. Adjust the seat and mirrors.
3. Press the MEMORY button; the LED lights up.
4. Press memory button 1 or 2.




Displays and controls 9

Around the steering wheel



Adjusting the steering wheel

1. Move the lever down.
2. Adjust the steering wheel to the seating position in longitudinal direction and height.
3. Move the lever back up.



10 Displays and controls

Around the steering wheel

Activating turn signals

Push the lever up or down past the pressure point.

Canceling turn signals

Push the lever as far as the pressure point.

Signaling briefly/one-touch signaling

Push the lever up or down to the pressure point.

High beams

Push the lever forward.


Onboard computer

Press the button on the lever.

Headlamp flasher


Pull the lever.

Horn



Displays and controls 11

Around the steering wheel



Switching on the wipers

Normal: push once.

Rapid: push twice.

Activating/deactivating intermittent operation or the rain sensor*

Press the button on the lever.

Interval or sensitivity of the rain sensor

Turn the thumbwheel.

Washing the windshield and headlamps*

Pull the lever.

Switching off the wipers

From normal speed: push once.

From rapid speed: push twice.

Brief wipe

Push once.

12 Displays and controls

Around the center console

Control Display

Dynamic Stability Control DSC
Dynamic Traction Control DTC

Hazard warning flashers


Central locking

Automatic climate control

Entertainment

Selector lever* or gearshift

Controller with buttons



Displays and controls 13

Buttons in the center console



Park Distance Control PDC*

Convertible: close top

Convertible: open top

Convertible: opening and closing the top

Prior to opening and closing, verify that no objects are located on or next to the trunk cover and that the trunk lid is closed.

14 Displays and controls

Automatic climate control

Open and close the air vents

AUTO intensity, air volume,
automatic climate control off

AUTO program


Air distribution, windshield and side win-
dows

Maximum cooling

Air distribution, upper body area


Seat heating*

Air distribution, foot area



Displays and controls 15

Automatic climate control




16 Displays and controls

Garage door opener*

Garage door opener

1. The ignition is on.
2. Press both outer buttons, 1 and 3, for approx. 20 seconds until the LED flashes.
3. Hold the hand-held transmitter a distance of approx. 4 to 10 in/12 to 30 cm away from the memory buttons.
4. Simultaneously press the transmit button of the hand-held transmitter and the memory button of the universal remote control.
5. Release both buttons when the LED flashes rapidly.



Refer to the following section in the Owner's Manual: integrated universal remote control.

Child restraint systems

Please observe the manufacturer's instructions for the child restraint systems concerning the selection, mounting and use of these systems; otherwise, the child's safety may be compromised.

LATCH* child restraint fixing system

Before mounting the LATCH child restraint fixing system, pull the belt away from the child seat fastening area.

The inserts for the lower LATCH mountings are located in the space between the seat and the backrest.

Make sure that both lower LATCH mountings are firmly snapped in and that the child restraint system is leaning against the backrest.

Pass the upper strap* between the holders of the head rests and attach it to the fastening point* with the hook. Tighten the upper safety belt and move the head restraint to its lowest position.

Refer to the following section in the Owner's Manual: Transporting children safely.

18 Driving

Start/Stop button



Switching the ignition on/off

Press the Start/Stop button without depressing the brake or the clutch.

Starting the engine

Press the Start/Stop button and depress the brake and, if necessary, the clutch.

Engine off/radio ready state

Press the Start/Stop button when the engine is running.

7-speed sport automatic transmission with double-clutch*/Parking brake

P button

Press the button to engage transmission position P.

Unlock button

To shift from P or to R:


1. Depress the brake while the engine is running.
2. Press the Unlock button.
3. Move the selector lever in the desired direction.

Release the parking brake

Pull the lever slightly upward, press the button and move the lever down.

Setting the parking brake

Pull up the lever.



Before driving into a car wash, so that the vehicle can roll:

1. Put the remote control into the ignition
2. Depress the brake pedal
3. Engage N
4. Release the parking brake
5. Turn off the engine
6. Release the brake pedal

The vehicle can roll for approx. 30 minutes, provided that the remote control remains in the ignition.

20 Driving

Automatic transmission*/Parking brake

Unlock button

To shift from P or to R:

1. Depress the brake while the engine is running.
2. Press the Unlock button.
3. Move the selector lever in the desired direction.

Transmission position M/S

Sport program:

Press the selector lever to the left.


Manual operation:

Press the selector lever to the left.

- + Shift up
- Shift down

Transmission position

- P Park
- R Reverse
- N Neutral
- D Drive



Before driving into a car wash, so that the vehicle can roll:

1. Put the remote control into the ignition
2. Depress the brake pedal
3. Engage N
4. Release the parking brake
5. Switch off the engine, leave the remote in the ignition.

Releasing the parking brake

Pull the lever slightly upward, press the button and move the lever down.

Setting the parking brake

Pull up the lever.


Manual transmission/Parking brake

Reverse

When pushing the gearshift to the left, overcome the resistance.

5th/6th gear

Press the gearshift to the right.



Releasing the parking brake

Pull the lever slightly upward, press the button and move the lever down.

Setting the parking brake

Pull up the lever.

22 Driving Lamps



Driving 23

Lamps


Fog lamps*

Parking lamps

Lamps off/daytime running lights

Automatic headlamp control*
Adaptive Light Control*
High-beam Assistant*
Welcome lights
Daytime running lights

Low beams
Welcome lights



24 Radio/CD/Multimedia Controls



CD/DVD* player

Eject CD/DVD*


On/off, volume control

Programmable memory keys

Change the radio station waveband


Change the audio and video sources

Change station/track



Radio/CD/Multimedia 25

Controls



Programmable memory keys

iDrive functions can be stored on the programmable memory keys and called up directly, for instance radio stations, navigation destinations, telephone numbers and jumps into the menu.

Storing functions

1. Select the function via iDrive.
2. Press the desired key for longer than two seconds.

Executing a function


Press the button.

The function is executed immediately. This means, for example, that the number is dialed when a phone number is selected.

26 iDrive Controller




Controller with buttons




iDrive 27 Controller

Highlighting the menu item




Turn the controller until the desired menu item is highlighted.

Opening the menu item





Press the controller.

Changing between panels




After selecting a menu item such as "Radio" a new panel will be displayed. Panels can overlap. Move the controller either to the left or the right. The panel changes.



28 iDrive


Buttons on the controller

Opening the menus



Press the button on the controller.


Accessing the "Options" menu



Press the OPTION button.

The OPTION menu consists of various sections: for instance screen settings, "Split screen"* and, if necessary, additional operating options for the selected menu such as "Radio".


Calling up the previous view



Press the BACK button.

Opens the display that was last shown on the Control Display.

Split screen*/Voice activation system*

**Split screen***


Additional information can be displayed on the right side of the split screen, information from the computer, for instance.

You can set which information is displayed.

Switching the split screen on/off*

1. Call up "Options".
2. "Split screen"

The split screen is activated and the information remains displayed even if another menu is selected.


**Voice activation system***

The voice activation system allows you to operate certain features via a spoken command.

Most text that is displayed on the Control Display may be voice-activated.

Example: calling up the FM waveband

1. Press the button on the steering wheel.
2. Say >Radio<.



3. Say >F M<.

The list of available radio stations is displayed.

Having the possible commands read aloud




1. Press the button on the steering wheel.
2. Say >Voice commands<.

Tip

You can also call up the functions directly via so-called short commands such as >Map perspective view<* and >Redial<. To give those commands, speak without hesitation, loudly and clearly. Avoid background noise, such as that caused by an open sunroof.

30 Navigation

Entering an address*



Entering a destination

1. "Navigation"
2. "Enter address"


3. Select "State/Province" or displayed state/province.
4. Select "Town/City/Postal Code" or displayed town/city/postal code.
5. Select the letters individually. The list gradually grows smaller each time you enter a new letter.

6. Move the controller to the right and select a town/city from the list.
7. Enter a street, as you did for the town/city.
8. If desired, select the building number or intersection.
9. "Accept destination"
10. "Start guidance"

Tip

You can also enter a destination using the voice activation system*. Town/city, street and building number can also be spoken in one command*.

Points of Interest/Map displays*



Points of Interest

Searching for specific destinations, for instance, points of interest, hotels, or gas stations:

1. "Navigation"
2. "Points of Interest"
3. Select search, for instance "A-Z search".
4. Specify "Category", "Town/City" and if necessary "Several category details" and "Keyword".
5. "Start search"

A list of points of interest is displayed.



Map displays*

Various map types can be displayed in the Professional navigation system, i.e., perspective view in 3D*.


1. "Navigation"
2. "Map"
3. Call up "Options".
4. "Settings"
5. "Perspective view in 3D"

Adjusting the map zoom

1. If necessary, turn the controller to the left to change the map display.
2.  Select the symbol.
3. Turn the controller.

32 Entertainment

Tone/Radio stations



Adjusting the tone

1. "Radio" or "Settings" or "CD/Multimedia"
2. "Tone"
3. Select the desired tone settings.
4. Adjust: turn the controller.
5. Confirm: press the controller.



Selecting a radio station

1. "Radio"
2. "FM"



3. Select the desired station.

Tip

You can store your favorite radio stations with the programmable memory keys 1 to 6. Use the iDrive to select the radio station and hold the desired memory key down for several seconds.

Entertainment 33

Storing music*



Storing music

CD and DVD* music tracks may be stored in the vehicle in a music collection.

1. Insert the CD/DVD* into the CD/DVD* player.
2. "CD/Multimedia"
3. "CD/DVD"
4.  Select the symbol for the CD/DVD* player.

5. "Store in vehicle"

The music collection is displayed. The tracks are stored and played in sequence from the music collection.

Observe the following during the storage process:

Do not switch back to the CD/DVD* player, and do not remove the CD/DVD* from the CD/DVD* player, as this will interrupt the storage process.

Tip



You can only store CDs/DVDs* from the CD/DVD* player.
Additional information about how to store compressed audio files from CDs/DVDs* or USB media can be found in the Owner's Manual.

Tip

You can switch to other audio sources except for the CD/DVD* player, without interrupting the storing process. Tracks from the current CD/DVD* that have already been stored can be called up.

34 Communication

Mobile phone pairing*



Pairing the mobile phone with the vehicle

1. Switch on the ignition.
2. Activate Bluetooth on the vehicle and the mobile phone.
3. If necessary, adjust the Bluetooth default settings on the mobile phone, i.e., connection invisible with the confirmation of the mobile phone.
4. Think of a 4 to 16-digit passkey in order to enter it later. The passkey is only required once for the pairing procedure.
5. "Telephone"
6. "Bluetooth (telephone)"

7. "Add new phone"
The Bluetooth name of the vehicle also appears on the Control Display.
8. Use the mobile phone to search for Bluetooth devices; check your mobile phone's operating instructions. The Bluetooth name of the vehicle also appears on the mobile phone display.
9. Select the Bluetooth name of the vehicle from the mobile phone.
The mobile phone's display or the iDrive will prompt you to enter the Bluetooth passkey.


10. Enter the passkey on the mobile phone and via the iDrive.

Tip

Please ask your BMW center which mobile phones with Bluetooth interface are supported by the mobile phone preparation package. You can obtain additional information on the Internet at: www.bmwusa.com/bluetooth.

Communication 35

Using the phone*



11. Select at least one function for which the mobile phone will be used.
12. "OK"

If pairing was successful, the mobile phone appears at the top of the list of mobile phones.




Dialing a number

1. "Telephone"
2. "Dial number"
3. Select the digits individually.
4.  Select the symbol to establish the call.

Accepting a call

-  Press the button on the steering wheel.



Selecting from the phone book


1. "Telephone"
2. "Phone book"
3. Select the desired entry.

Tip

Up to 3 mobile phones can be linked to the vehicle and used as a telephone, an additional telephone or an audio player. For more detailed information, consult the Owner's Manual.

36 Refueling

Refueling/Oil level



Refueling

To open the fuel filler flap:
Lightly press the rear edge.

Fuel quality

Gasoline:

BMW recommends using super premium
unleaded gasoline/AKI 91.

Minimum grade:

- 128i: AKI 87
- 135i: AKI 89

Electronic oil level check*

The oil level is monitored electronically and shown
on the Control Display.
For recommended oil grades, refer to the Owner's
Manual.

Operation via iDrive:

1. "Vehicle Info"
2. "Vehicle status"
3. "Engine oil level"

Refer to the information in the Owner's Manual.

Refueling 37

Tire pressure

FTM Flat Tire Monitor*

The system identifies a loss of pressure by comparing the speeds of rotation of the individual wheels as the car is traveling.

The system must be initialized with the correct tire pressures in order for it to respond reliably in detecting a flat tire.

Operation via iDrive:

1. "Vehicle Info"
2. "Vehicle status"
3. "Reset"
4. Start the engine; do not drive away.
5. "Reset"
6. Drive away.

FTM is no replacement for tire pressure checks.


TPM Tire Pressure Monitor*

Monitoring of the tire inflation pressure in the four mounted tires: the system reports when the tire inflation pressure has dropped considerably in one or more tires.

The system must have been reset when the inflation pressure was correct; otherwise, reliable signaling of a flat tire is not ensured.

Operation via iDrive:

1. "Vehicle Info"
2. "Vehicle status"
3. "Reset TPM"
4. Start the engine; do not drive away.
5. Start the initialization with "Reset TPM".
6. Drive away.



Tire pressure

Note the tire pressures in the Owner's Manual for speeds up to 100 mph or 160 km/h and maximum driving comfort and adjust, if necessary. These tire pressures may also be found on the door pillar when opening the driver's door.

Tip

Check the tire pressure twice a month and reinitialize the FTM/TPM after adjusting tire pressure and after changing a tire or wheel.

38 Service and Maintenance

BMW Ultimate Service™

BMW Ultimate Service™

Included at no charge with all new BMW vehicles for the first four years or 50,000 miles, whichever comes first.

It includes the New Vehicle Limited Warranty and the BMW Maintenance Program, which cover all factory-recommended maintenance services and specific items that require replacement due to normal wear and tear.

Also included are four years of unlimited mileage Roadside Assistance, and, if the vehicle is equipped with the BMW Assist™ and Bluetooth® system*, a four-year, unlimited mileage subscription to the BMW Assist Safety Plan.

See www.bmwassist.com to learn more.

* The BMW Assist™ and Bluetooth® system is part of the Premium Package or available as an option in the 1 Series.


Socket for Onboard Diagnostics OBD

On the driver's side is an OBD socket for testing components that are critical to exhaust composition.


Emission values

SERVICE
ENGINE
SOON

The warning lamp lights up.
The emission values are deteriorating. Have the vehicle checked as soon as possible.




Refer to the information in the Owner's Manual.



40 24/7 Access

BMW Assist™* and Bluetooth® System*




BMW Assist Safety Plan* **(included for four years)**

Combining GPS location technology with hands-free wireless communication, BMW Assist connects you with a trained response specialist 24/7 to help you with almost everything while on the road.

The BMW Assist Safety Plan provides:

- Automatic Collision Notification
- Emergency Request (SOS)
- Enhanced Roadside Assistance
- MyInfo
- Stolen Vehicle Recovery
- Door Unlock
- TeleService
- Customer Relations



Easy Access

To initiate the services, just go to "BMW Assist" in the main menu and select the desired service, or push the SOS button on the overhead console.

What you need to do

You must complete, sign and submit a subscriber agreement with your salesperson. To decline services, you must complete, sign and submit a "Waiver and Release" document.

If neither action is taken, your BMW Assist services will be remotely deactivated approximately 60 days after you take delivery of your new vehicle.

Bluetooth Hands-free Calling

The BMW Assist system includes Bluetooth hands-free calling capability with speech recognition. See page 34 or visit www.bmwusa.com/bluetooth for BMW approved handsets and pairing instructions.

Tip

You can even find destinations in the comfort of your home or office and send them via the Internet to your vehicle with the BMW Assist MyInfo service. Visit www.bmwassist.com/myinfo to learn more.

Tip

Upgrade to our optional Convenience Plan to receive directions, traffic and weather information, Critical Calling, Concierge services, online access to the Google Maps™ database, up-to-date fuel prices and stock indices in your BMW 1 Series with BMW Search. Push the SOS button, call toll-free 1-888-333-6118, or log on to www.bmwassist.com to learn more.

BMW Roadside Assistance

Can be contacted if assistance is needed in the event of a breakdown.

Telephone: (800) 332-BMW (4269)

For vehicles with the BMW Assist option:
Contacting Roadside Assistance through BMW Assist will also transmit vehicle and vehicle position data.

Towing

The only method approved for transporting your vehicle is to use a commercial flatbed carrier truck and to secure the vehicle to the flatbed truck with four nylon wheel straps.

When pulling the vehicle onto a flatbed carrier truck, only use the screw-in tow-eye found in the trunk tool kit.

Refer to the detailed towing instructions in the Owner's Manual.

BMW Financial Services**

Offers monthly payments.

UltimatePay: one-time electronic payment service.

EasyPay: have your monthly payment debited automatically every month from the bank account you designate. Of course, you can also pay by mail.

Simply go to the BMW Financial Services section of the Owner's Circle at bmwusa.com and look under "Account Services".

** Subject to credit approval

My Account

Enables BMW owners to enjoy high performance in their vehicles – and in the ownership experience itself.

This secure owner's site is filled with important, convenient and timely information. Here is where your vehicle information and BMW Financial Service account history are kept and updated. You can see your monthly statements online, and even pay for them quickly and easily with the click of your mouse.

There is also a wide variety of informative features on interesting topics.

For example, refer to the Owner's Manual section, which also contains video reference guides. Or watch a video to learn how to pair your Bluetooth phone.


Simply go to bmwusa.com and hover over "My Account" in the site's top navigation.

42 Trunk

Warning triangle*, first aid kit*, loading the Convertible


Warning triangle

The warning triangle is located in a holder in the trunk lid.




First aid kit

The first aid kit is located in a pocket on the right side of the trunk.



Expanding the trunk capacity

With the top closed:
Push the trunk partition up.



More about BMW

bmwusa.com
1-800-334-4BMW



**The Ultimate
Driving Machine®**

© 2010 Bayerische Motoren Werke
Aktiengesellschaft
Munich, Germany

Reprinting, including excerpts, only with the
written consent of BMW AG, Munich.

Order No. 01 40 2 605 275

US English VIII/10

Printed on environmentally friendly paper,
bleached without chlorine, suitable for recycling.

