



MY.SUBARU.COM

Your Subaru vehicle comes with a unique online resource that helps make your ownership experience more convenient and enjoyable. MySubaru.com is a personalized website that offers useful features and content that makes it easy for you to manage your vehicle that and enjoy all the benefits of Subaru ownership. Log on to MySubaru.com and access features such as: automated service history, e-mail maintenance reminders, online Owner's Manual, warranty information, maintenance schedules and much more... Access your site today @ MySubaru.com

For Roadside Assistance, please call our 24-hour toll-free number at 1-800-261-2155. Subaru of America, Inc.
Subaru Plaza
P.O. Box 6000
Cherry Hill, NJ 08034-6000

All information contained within this Legacy/Outback Monitor System Owner

Reference Guide was accurate at the time of publication. We reserve the right to change features, operation and/or functionality of any vehicle specification at any time. Your Subaru dealer is the best source for the most current information. For detailed operating and safety information, please consult your Owner's Manual.



MSA5B1012A
Printed in USA 04/09
Issued 04/09

2010 LEGACY/OUTBACK Monitor System Owner Reference Guide



MULTI-INFORMATION DISPLAY

DYNAMIC. PROGRESSIVE. REAL WORLD VERSATILITY.

Your Subaru vehicle represents state-of-the-art design and technology, providing you with a satisfying owner experience. Your Multi-Information Display offers essential information on your vehicle and driving operations. This Reference Guide is designed to provide a quick overview on the system and features of your Multi-Information Display. For a comprehensive description on operating this system, please read the Monitor System Owner's Manual.

Your control panel is your access to the Multi-Information Display. You must stop your vehicle in a safe place before operating the system. Some of the controls and functions cannot be used unless the vehicle is stationary.

1 INFO

Press this to display the Vehicle Information Screen.

2

Press this to adjust the brightness/contrast of the image and to display a calendar.




DISPLAYING VEHICLE INFORMATION SCREEN

FUEL CONSUMPTION


To check current fuel consumption rate, average fuel consumption rate and the range you can drive on the remaining fuel, press the **INFO** button, then select **INFO** and the information screen will be displayed.

FUEL CONS displays instantaneous fuel consumption. **AVG CONS-A** or **-B** displays average fuel consumption. **RANGE** displays the distance you can drive on the fuel in your tank.



DRIVING

To display the driving record data, press the **INFO** button, then select **INFO**. This screen displays your current driving information including distance, time, and average fuel consumption.



DISPLAYING VEHICLE INFORMATION SCREEN

THREE METERS

To display the three meters showing the average fuel consumption, current fuel consumption rate and throttle opening percentage (ACCEL), press the **INFO** button and select **222**. **AVG-A** tells you your average fuel consumption, **FUEL CONS** displays immediate fuel consumption, and **ACCEL** displays the accelerator's opening angle.



CALCULATOR

To use the calculator, press the **INFO** button, then select **444**. Now the screen can be used as a calculator by touching the screen.




DISPLAYING VEHICLE INFORMATION SCREEN

MAINTENANCE SCHEDULE INFORMATION

This function monitors maintenance, battery, tire pressure and timing belt. You can schedule checks by time and distance intervals. To access the maintenance schedule, press the **INFO** button. Then select **455**. Select which function you'd like to schedule.



Select **455** to enter your chosen maintenance schedule date. Select **SET**. **YES** will appear on the screen. Select it if the date is correct. Then press **NEXT** and press **455** to enter maintenance schedule distance. Select **SET**, and **YES** will appear; select it if the distance is correct. When the maintenance time comes, the monitor will remind you of the date by a message on the screen one month before, one week before or on the day maintenance is due.



OTHER SETTINGS

Selecting or deselecting **BEEP** turns the beep sound on or off.

You can program the monitor system for other display items and answer back beeps that let you know the door is locking. To use, press the **INFO** button and then select **SET**. The screen for mode of function will be displayed.

Selecting or deselecting **CLOCK** turns the time on or off the screen.

Selecting or deselecting **OUT TEMP** turns the outside temperature display on the screen on or off.



KEYLESS ENTRY

To program the **Keyless Entry** system, press the **INFO** button, then select **SET**.

LOCK SIGNAL

The **LOCK SIGNAL** notifies you that the door is locking or unlocking by flashing the hazard warning lights. Select or deselect the **BACK ANSWER** key to activate or deactivate this function.



OTHER SETTINGS

ROOMLAMP (INTERIOR LIGHT)

Roomlamp allows you to choose the delay time before the interior light turns off when the doors are unlocked using the keyless entry system transmitter, or when the doors are closed.

DEFOGGER

Defogger can be programmed for two operation modes: continuous and 15-minute. When the continuous operation mode is programmed, the rear window defogger will operate for 15 minutes, stop for 2 minutes, and operate again for 15 minutes, and so on. In the 15-minute mode, the defogger will automatically shut off after 15 minutes. You can shut it off before that time if you press the rear window defogger switch again.

DEICER

Deicer can be programmed for the same two operation modes: continuous and 15-minute. In continuous operation mode, when the windshield wiper deicer is pressed, the deicer will continue to function. In the 15-minute mode, the windshield wiper deicer will automatically shut off after about 15 minutes. Pressing the switch again will shut it off before that time.



TOUCH

To adjust the **TOUCH PANEL** sensing positions, press the **INFO** button, then select **RESET**, and the button. Then touch the center of the lower left crossmark.

