


2012
**Legacy/Outback
Navigation System**



Quick Reference Guide






Table of Contents

Safety	2
Navigation Introduction	3
Emergency Screen	4 - 5
Finding an Address	6 - 9
Finding a Point of Interest	10 - 11
Home Registration	12 - 13
Additional Quick Tips	14 - 15
Notes	16

Safety

Your Navigation System will assist you in reaching your destination and, if used properly, can do so with speed and ease. To use the system as safely as possible, follow all safety directions.

- **Before attempting to use this system while driving, learn how to use it.**
Make sure you read the **entire** Navigation System Owner's Manual Supplement. Do not allow others to use this system until they read the manual and understand the instructions.
- You can program your destination and select your route only when your vehicle is **not moving**. While driving, listen to the voice instructions as much as possible and only glance at the screen briefly and when it is safe to do so.
- The data in the system may occasionally be incomplete as road conditions and driving restrictions (no left turns, road closures, etc.) change. Before you follow system instructions, make sure to check whether you can comply with the instruction legally and safely. Do not be distracted by the navigation screen. Failure to keep your attention on the road could lead to an accident.
- The system cannot warn you of environmental or street hazards or the availability of emergency systems. If you are unsure about the safety of an area, don't drive into it.
- Use this system only where it is legal to do so. Some states/provinces may have laws prohibiting video screens within the driver's sight.

And remember, this system is never a substitute for the driver's personal judgment.

To start the Navigation System, start the engine. The opening screen will appear, followed by the CAUTION screen. Read the instructions on the screen and press **AGREE**. To select a language, press the **MENU** button, then select **NAVIGATION SET UP**, then select **LANGUAGE** and then select English, French or Spanish by touching the screen.



Navigation Introduction

Your Navigation System helps you find travel routes, create maps, store addresses, and more. Prior to using the system, be sure to read the full Navigation System Owner's Manual Supplement so you have a complete understanding of the system. For your convenience, this Quick Reference Guide offers a quick guide for regularly used features.

Your control panel is your access to the Navigation System. You must stop your vehicle in a safe place before operating the system. Some of the controls and functions cannot be used unless the vehicle is stationary.



1 Map

Press this to switch the screen to the Navigation System map screen from any other screen.

2 Dest

Press this to display the destination screen of your Navigation System.

3 Menu

Press this to display the menu screen of your Navigation System.

4 Info

Press this to display the vehicle information screen.

5 Navigation System Map Disc Location

The main unit is located below the CD slot behind a cover. To remove the cover, hold the upper side of the cover while pulling out the bottom of the cover using the notch located on the center underside. Load a map DVD-ROM disc into the system's main unit through the slot. Press the eject button to eject the disc. When finished, push the slot cover back in place.

Emergency Screen

To access the emergency screen, press the **DEST** button, then select **EMERGENCY**.



Select between **POLICE STATION** or **HOSPITAL**.



The screen now displays several options:

Use  to display the five previous suggestions.

Use  to display the previous suggestion.

Use  to display the next suggestion.

Use  to display up to five of the next suggestions.

DIST. SORT sorts the list by distance.

NAME SORT sorts the list alphabetically.

Then select  (destination) or  (waypoint).

The system will route you to the nearest location automatically.



Finding an Address

- 1 To find an address, press the **DEST** button. Make sure you are in the desired search area and touch **ADDRESS** to access the address input screen.




- 2 Enter a house number using the keypad on the house number input screen and then select **OK**.



- 3 Enter the street name and then select **LIST**.



- 4 Select the desired street from the list.



- 5 If the same street name exists in more than one city, a list of these towns will be shown. Select the correct town from the list.



- 6 Then select  (destination) or  (waypoint).
- Select destination to set the address entered in the above steps as the final destination. The system will calculate the route and display the entire route on the map.
 - Select waypoint if you want to set the address entered as a waypoint on your route. You can program up to five waypoints per trip.



Finding an Address

- 7 Select **START**; route guidance begins along the displayed route.




To cancel route guidance press the **MENU** button, then touch **ROUTE OPTIONS**, then touch **ROUTE PREF.**, and then touch **CANCEL GUIDANCE**.

NOTE

- If the system cannot find your desired route, select **CHG. ROUTE**. This will allow you to access the ROUTE OPTIONS screen from which you can prompt the system to calculate a new route.
- If the map disc does not contain the relevant house number data, an error message will be displayed and a street map will appear, allowing you to set the destination using the map disc.
- If the destination is not on a road, set a destination point on a main road nearest to the actual destination.

- Selecting **CITY** while inputting an address will display a screen that searches the destination on a city basis.



- ANY CITY** : Search the destination from all cities.
- 5 NEAREST CITIES** : Search the destination from the nearby five cities from your current position.
- INPUT CITY NAME** : Search the destination by inputting the city name.
- LAST 5 CITIES** : You can also search the destination from the five cities that you searched in the past.



Finding a Point of Interest

You can also find addresses by using the Point Of Interest (POI) function. You can use this in the event you do not have a specific address but can refer to a specific shopping mall, airport, museum, etc.

- 1 To find a Point Of Interest (POI) press the **DEST** button. Make sure you are in the desired geographical search area, and then touch **POINT OF INTEREST** to access the address input screen. **Note:** If you are not in the correct geographical area touch **CHANGE** to select the correct geographical area.



- 2 Enter the POI name by using the letter keys on the screen and then touch **LIST**.



- 3 Use the arrows on the screen to scroll up or down for the POI name. The screen will display suggested routes.



- 4 Select the route preference you want to take, and then touch  (destination) or  (waypoint).



- 5 The system searches the route and displays it on the screen. Once completed, touch **START** and begin driving.



Home Registration

If you have stored your home address in the system's memory, you can use it for your destination or a waypoint. Other locations stored in the memory can be used for quick setting of destinations and waypoints.

- 1 Press the **MENU** button and then touch **STORED LOCATIONS**



- 2 Next, touch **MEMORY POINTS**.



3 Then touch **ADD**.



4 Touch **ADDRESS** and then refer to steps 3-8 in the **FINDING AN ADDRESS** section earlier in this Quick Reference Guide.



Additional Quick Tips

Screen Preferences

From the map screen, touch . This expands the window to provide up to seven screen selections, including:



-  Single Map Mode
-  Dual Map Mode
-  Turn List Mode
-  Turn Arrow Guidance Mode
-  Intersection Guidance Mode
-  Freeway Info Mode
-  Compass Mode



1 Demonstration Mode (route preview)

To view the Demonstration mode after setting a destination, touch and hold **START** for at least 5 seconds. A beep indicates that the Demonstration mode has begun.



2 To end the Demonstration mode, press the **MAP** button.



1 Search Area

To change your search area, press the **DEST** button, then touch **CHANGE** on the screen.



2 Touch the desired search area and then touch **GO**.




Notes

[illegible]



About the Map Discs.

This navigation system includes three map discs (contained in 2 disc holders) covering different areas (West, Mid and East). Select the map disc containing the destination area you wish and insert it in the Navigation System. Make sure to reselect your destination when you change the map disc.

DISC HOLDER 1 CONTAINS:



DISC HOLDER 2 CONTAINS:



All information contained within this Legacy and Outback Navigation System Quick Reference Guide was accurate at the time of publication. We reserve the right to change features, operation and/or functionality of any vehicle specification at any time without incurring any obligation to make the same or similar changes to products previously sold. Your Subaru dealer is the best source for the most current information. For detailed operating and safety information, please consult your Owner's Manual.



MSA5B1207A
Issued May 2011
Printed in USA 10/11
2012A

