


2013 **VERSA** SEDAN

QUICK REFERENCE GUIDE





- 01** TWIN TRIP ODOMETER / TRIP COMPUTER
- 02** LOW TIRE PRESSURE WARNING LIGHT
- 03** INSTRUMENT BRIGHTNESS CONTROL*
- 04** HEADLIGHT AND TURN SIGNAL CONTROL

- 05** WINDSHIELD WIPER / WASHER SWITCH
- 06** OUTSIDE MIRROR CONTROL SWITCH
- 07** STEERING WHEEL SWITCHES FOR AUDIO CONTROL / BLUETOOTH*
- 08** CRUISE CONTROL

- 09** STEERING WHEEL TILT ADJUSTMENT*
- 10** VEHICLE DYNAMIC CONTROL (VDC) OFF SWITCH*
- 11** FUEL-FILLER DOOR RELEASE
- 12** HOOD RELEASE*

- 13** FRONT PASSENGER AIR BAG STATUS LIGHT*
- 14** AUDIO AND NAVIGATION SYSTEM
- 15** CLIMATE CONTROLS

*See your Owner's Manual for information.

NEW SYSTEM FEATURES

RearView Monitor (if so equipped)	2
Twin Trip Odometer/Trip Computer (if so equipped)	2
USB/iPod® Interface (if so equipped)	2

ESSENTIAL INFORMATION

Loose Fuel Cap	3
Tire Pressure Monitoring System (TPMS)	3

FIRST DRIVE FEATURES

NISSAN Intelligent Key® System (if so equipped)	4
Trunk Lid Release (if so equipped)	5
Seat Adjustments	5
Power Outside Mirror Control Switch (if so equipped)	5
Starting/Stopping the Engine	6
Headlight Control	7
Windshield Wiper/Washer Switch	7
Climate Controls	8
FM/AM/SiriusXM™ Satellite Radio with CD Player (if so equipped)	9
Cruise Control (if so equipped)	10
Fuel-Filler Door	10

SYSTEM GUIDE

Bluetooth® Hands-free Phone System (if so equipped)	11
Navigation System (if so equipped)	14



- A cellular telephone should not be used for any purpose while driving so full attention may be given to vehicle operation.
- Always wear your seat belt.
- Supplemental air bags do not replace proper seat belt usage.
- Children 12 and under should always ride in the rear seat properly secured in child restraints or seat belts according to their age and weight.
- Do not drink and drive.

For more information, refer to the **“Safety — Seats, seat belts and supplemental restraint system (section 1)”**, **“Display screen, heater, air conditioner, audio and phone systems (section 4)”** and **“Starting and driving (section 5)”** of your Owner’s Manual.



Additional information about your vehicle is also available in your Owner’s Manual, Navigation System Owner’s Manual and at www.nissanusa.com.

To view detailed instructional videos, go to www.nissanownersinfo.mobi/2013/versasedan or snap this barcode with an appropriate barcode reader.

new system features

REARVIEW MONITOR (if so equipped)


- When the shift lever is moved to the **R (REVERSE)** position, the front display shows the view to the rear of the vehicle.
- The colored lines on the display screen indicate approximate distances to objects.
 - Red 1.5 ft (0.5 m); Yellow 3 ft (1 m); Green 7 ft (2 m) and 10 ft (3 m).



For more information, refer to the “**Display screen, heater, air conditioner, audio and phone systems (section 4)**” of your Owner’s Manual.

TWIN TRIP ODOMETER/TRIP COMPUTER (if so equipped)

- With the ignition switch in the **ON** position, modes of the trip computer **01** can be selected by pushing the trip computer change button **02** on the instrument panel.
- The following modes can be selected in the display:
 - **ODO** - records the total distance the vehicle has been driven.
 - **Trip A** - measures the distance of one specific trip.
 - **Trip B** - measures the distance of a second specific trip.
 - **mpg** - displays the instant fuel consumption.
 - **mpg AVG** - displays the average fuel consumption since the last reset.
 - **mls** → - displays the estimated distance that can be driven before refueling.



For more information, refer to the “**Instruments and controls (section 2)**” of your Owner’s Manual.

USB/IPOD® INTERFACE (if so equipped)


- The USB/iPod® jack **01** is located on the center console.
- When a compatible USB memory device or iPod is plugged into the USB jack, compatible audio files stored on the device can be played through the vehicle’s audio system.



For more information, refer to the “**Display screen, heater, air conditioner, audio and phone systems (section 4)**” of your Owner’s Manual.

LOOSE FUEL CAP

- A **LOOSE FUEL CAP** warning message will display in the odometer **01** when the fuel-filler cap is not tightened correctly.
- To tighten, turn the cap clockwise until a single click is heard.
- The warning message will disappear when the vehicle detects the fuel-filler cap is properly tightened and the reset button **02** is pressed for more than 1 second.
- If the cap is not fully tightened, the Malfunction Indicator light  may also illuminate.



For more information, refer to the **"Instruments and controls (section 2)"** and the **"Pre-driving checks and adjustments (section 3)"** of your Owner's Manual.

TIRE PRESSURE MONITORING SYSTEM (TPMS)

- The TPMS monitors tire pressure. If the TPMS is not functioning properly, the low tire pressure warning light **01** will flash for approximately 1 minute and remain on. Have the system checked by a NISSAN dealer.
- If the low tire pressure warning light illuminates but does not flash, check the tire pressure in your tires. Adjust the tire pressure to the recommended COLD tire pressure shown on the Tire and Loading Information label.
 - The tires are considered cold after the vehicle has been parked for 3 hours or more or driven less than 1 mile (1.6km) at moderate speeds.
- After tire pressures are adjusted, the vehicle will need to be driven at speeds above 16MPH (25km/h) to activate the TPMS and turn off the low tire pressure warning light.
- Tire pressure rises and falls depending on the heat caused by the vehicle's operation and the outside temperature. Low outside temperature can lower the temperature of the air inside the tire, which can cause a lower tire inflation pressure. This may cause the low tire pressure warning light to illuminate. If the warning light illuminates in low ambient temperature, check the tire pressure in your tires.
 - Check the tire pressure (including the spare tire) often and always prior to long distance trips.
- The Tire and Loading Information label contains valuable information. Please refer to section 9, "Technical and consumer information", in your Owner's Manual for the location of the Tire and Loading Information label.



For more information, refer to the **"Instruments and controls (section 2)"**, **"Starting and driving (section 5)"** and the **"Maintenance and do-it-yourself (section 8)"** of your Owner's Manual.


first drive features

NISSAN INTELLIGENT KEY® SYSTEM (if so equipped)

- The NISSAN Intelligent Key® system allows you to lock or unlock your vehicle, open your trunk and start the engine.

NOTE: It is important to make sure the Intelligent Key is with you (that is, in your pocket or purse).

- The operating range of the Intelligent Key is within 31.5 in (80 cm) from each request switch.
- To lock the vehicle, push either door handle request switch **01** once or press the **i** button **02** on the keyfob.
- To unlock the vehicle, perform one of the following procedures:
 - Push either door handle request switch **01** once; the corresponding door will unlock. Push the door handle request switch **01** again within 5 seconds; all other doors will unlock, or
 - Press the **i** button **03** on the keyfob to unlock the driver's side door. Press the **i** button again; all other doors will unlock.
- To open the trunk, press the **HOLD** button **04** for more than 0.5 seconds.
- The Intelligent Key can also be used to activate the panic alarm by pressing and holding the **panic** button **05** for more than 1 second. Once activated, the panic alarm and headlights will stay on for 25 seconds.



INTELLIGENT KEY BATTERY DISCHARGE

- If the battery of the Intelligent Key is discharged, or environmental conditions interfere with the Intelligent Key operation, start the engine according to the following procedure:

1. Move the shift lever to the **P (PARK)** position.
2. Firmly apply the foot brake.
3. Touch the ignition switch with the Intelligent Key and a chime will sound.
4. Within 10 seconds after the chime sounds, push the ignition switch while depressing the brake pedal and the engine will start.




For more information, refer to the “**Pre-driving checks and adjustments (section 3)**”, “**Starting and driving (section 5)**” and the “**Maintenance and do-it yourself (section 8)**” of your Owner's Manual.

TRUNK LID RELEASE (if so equipped)

- Use one of the following methods to open the trunk:
 - Push the trunk opener request switch **01**, located on the far right under the trunk handle, for more than 1 second while carrying the NISSAN Intelligent Key® with you.
 - Press the trunk release button  **02** on the Intelligent Key for more than 0.5 seconds.

For more information, refer to the “**Pre-driving checks and adjustments (section 3)**” of your Owner’s Manual.




SEAT ADJUSTMENTS

- To slide the front seat forward or backward, pull up on the lever **01** under the front of the seat and slide forward or backward. Release the lever to lock the seat in position.
- To recline the seatback, pull up on the lever **02** and lean back. To bring the seatback forward, pull the lever up and lean your body forward. Release the lever to lock the seatback in position.

SEAT LIFTER (if so equipped for driver’s seat)


- To adjust the seat height, pull up or push down on the adjusting lever **03** repeatedly.

For more information, refer to the “**Safety – Seats, seat belts and supplemental restraint system (section 1)**” of your Owner’s Manual.



POWER OUTSIDE MIRROR CONTROL SWITCH (if so equipped)

- Move the switch **01** right or left to select the right or left mirror.
- Adjust each mirror to the desired position using the switch **02**.
- Move the switch **01** to the middle “neutral” position to prevent accidentally moving the mirror.



For more information, refer to the “**Pre-driving checks and adjustments (section 3)**” of your Owner’s Manual.

first drive features

STARTING/STOPPING THE ENGINE

STARTING THE ENGINE

CONTINUOUSLY VARIABLE TRANSMISSION (NISSAN Intelligent Key® models only - if so equipped)

- Depress the brake pedal.
 - If the brake pedal is not depressed, pushing the ignition switch once enters the ACC mode.
 - If the ignition is pushed a second time, the vehicle will enter the ON mode.
- Move the shift lever to **P (PARK)**.
- Push the ignition switch to start or stop the engine.



NOTE: It is important to make sure the Intelligent Key is with you (that is, in your pocket or purse).

MANUAL TRANSMISSION (if so equipped)

- Depress the brake pedal.
- Move the shift lever to **N (NEUTRAL)**.
- Depress the clutch pedal to the floor.
- Turn the ignition switch to **START**.



TURNING THE ENGINE OFF


- For a Continuously Variable Transmission (NISSAN Intelligent Key® models only - if so equipped), apply the brake pedal, move the shift lever to the **P (PARK)** position, apply the parking brake and push the ignition **START/STOP** switch to turn the engine off.
- For a manual transmission, apply the brake pedal, place the vehicle in 1st gear, apply the parking brake and turn the ignition switch to the **LOCK** position.

For more information, refer to the "**Starting and driving (section 5)**" of your Owner's Manual.

HEADLIGHT CONTROL


HEADLIGHT CONTROL SWITCH

- Turn the headlight control switch to the  position **01** to turn on the front parking, tail, license plate and instrument panel lights. Turn the switch to the  position **02** to turn on the headlights.



HIGH BEAM SELECT

- Push the headlight control switch forward **03** to select the high beam function. The blue indicator light  illuminates in the instrument panel. Pull the headlight switch back to the original position to select the low beam. The blue indicator light goes off.
- Pull and release the headlight control switch **04** to flash the headlight high beams on and off.




FOG LIGHT SWITCH (if so equipped)

NOTE: The headlights must be on and the low beams  selected for the fog lights to operate.

- Turn the switch (inside collar) to the  position **05** to turn the fog lights on.
- Turn the switch (inside collar) to the **OFF** position to turn the fog lights off.


For more information, refer to the “**Instruments and controls (section 2)**” of your Owner’s Manual.



WINDSHIELD WIPER/WASHER SWITCH

- Move the lever to the following positions to operate the windshield wipers:

- 01** Mist (**MIST**) - One sweep operation of the wipers.
- 02** Intermittent (**INT**) - Wipers operate intermittently. The intermittent operation speed can be adjusted by twisting the time control ring **03** (if so equipped).
- 04** Low (**LO**) - Wipers operate at a continuous low-speed.
- 05** High (**HI**) - Wipers operate at a continuous high-speed.
- 06** Washer  - Pull the lever toward you to activate the washer. The wipers will operate several times.



For more information, refer to the “**Instruments and controls (section 2)**” of your Owner’s Manual.

2013 Versa Sedan Delivery Checklist

BLUETOOTH® HANDS-FREE PHONE SYSTEM (if so equipped)

- 1. Connect the customer's phone
- 2. Explain voice tagging
- 3. Identify microphone location
- 4. Explain how to dial a number
- 5. Explain how to receive and end a call

Yes


☐

☐

☐

☐

☐



WINDSHIELD WIPER/WASHER SWITCH

Demonstrate

- 01 MIST (one sweep) function
- 02 Intermittent (INT) wiper function
- 03 Time delay adjustment ring (if so equipped)
- 04 Low (LO) speed wiper function
- 05 High (HI) speed wiper function
- 06 Front washer function

Yes

☐



☐

☐

☐

☐

☐



HEATING, VENTILATION AND AIR CONDITIONING

Demonstrate

- 1. Fan speed control
- 2. Air flow control
- 3. Temperature control
- 4. A/C function (if so equipped)
- 5. Defrost and Defog operation (include air intake lever)

Yes

☐

☐

☐

☐

☐



AUDIO SYSTEM

Demonstrate

- 1. How to turn the system on/off
- 2. How to tune the radio
- 3. How to operate SEEK/TRACK/CAT feature (if so equipped)
- 4. How to set a station preset into memory

Yes

☐

☐

☐

☐



2013 Versa Sedan Delivery Checklist

TIRE PRESSURE MONITORING SYSTEM (TPMS)

- Yes**
1. Identify TPMS icon in meter cluster ☐
 2. Demonstrate TPMS reset procedure ☐
 3. Explain effects of low ambient temperatures on tire pressure ☐



OUTSIDE MIRROR CONTROL SWITCH (if so equipped)

- Demonstrate**
- Yes**
1. Right and left outside mirror selection ☐
 2. Outside mirror adjustment switch location ☐
 3. Neutral switch position ☐



CLOCK SET/ADJUSTMENT

- Demonstrate**
- Yes**
1. How to set the clock in the Audio System or Navigation System (if so equipped). ☐

ELECTRONIC QUICK REFERENCE GUIDE (EQRG)

- Yes**
1. Explain that additional vehicle operation information can be viewed via the Nissan EQRG website at www.nissanownersinfo.mobi ☐
 2. Explain that EQRG information can be viewed via SmartPhone or personal computer ☐
 3. Identify where on the vehicle's Quick Reference Guide they can find the internet address (PC viewing) or Quick Response Code (SmartPhone viewing) to access the Nissan EQRG site ☐

Sales Consultant Signature

Date

Sales Manager Signature

Date

Customer Signature

Date

All information, specifications, photographs and illustrations are those in effect at the time of printing. NISSAN reserves the right to change specifications or design without notice and without obligation. For additional information, see your NISSAN dealer or contact NISSAN North America, Inc. See Owner's Manual for important warnings and details on vehicle operation and maintenance.



first drive features

CLIMATE CONTROLS


01 FAN SPEED CONTROL DIAL

- Turn the dial to the left to decrease fan speed or to the right to increase fan speed.

02 AIR FLOW CONTROL DIAL

- Turn the dial to select the following air flow outlets:

-  Air flows from the center and side vents.
-  Air flows from the center, side, and foot vents.
-  Air flows mainly from the foot vents.
-  Air flows from the defroster and foot vents.
-  Air flows mainly from the defroster vents.



03 TEMPERATURE CONTROL DIAL

- Turn the temperature control dial left for cooler air or right for warmer air.

04 DEFROSTING/DEFOGGING FRONT AND SIDE WINDOWS

- First, move the air intake lever  (05) to the left position to draw fresh air into the vehicle.
- Then turn the air flow control dial  (02) to the front window defroster mode.
- When the  or  position is selected, press the **A/C** button (if so equipped) to turn the air conditioner on for better performance. This will dehumidify the air and help defog the windows.

06 REAR WINDOW DEFROSTER SWITCH

- Push the rear window defroster switch  to turn the system on or off.

07 A/C BUTTON (if so equipped)

- Press the **A/C** button to turn the air conditioner on. This system helps cool and dehumidify the air inside the cabin and defog the windows.

For more information, refer to the **"Display screen, heater, air conditioner, audio and phone systems (section 4)"** of your Owner's Manual.



FM/AM/SiriusXM™* SATELLITE RADIO WITH CD PLAYER (if so equipped)

01 VOL/ON-OFF CONTROL KNOB

- Press the **VOL/ON-OFF** control knob to turn the system on or off.
- Turn the **VOL/ON-OFF** control knob to the right or left to increase or decrease the volume.

02 TUNE/SCROLL/AUDIO KNOB

- To manually tune the radio, turn the **TUNE/SCROLL/AUDIO** knob left or right.

03 SEEK/CATEGORY BUTTONS

- To scan through each broadcasting station, press the **SEEK/CATEGORY** buttons.
- To skip from one track to another on a CD, press the **SEEK/CATEGORY** buttons.
- When the **SEEK/CATEGORY** buttons are pressed and held while a CD is playing, the CD will rewind or fast forward. When the button is released, the CD will play at normal speed.

04 STATION SELECT BUTTONS

Twelve stations can be set for the FM band, six for the AM band and eighteen for SiriusXM™ satellite radio.

- To store a station in a preset you must first select a radio band by pressing the **FM•AM** 05 or **XM** button 06, then tune to the desired AM, FM or SiriusXM satellite radio station.
- Then press and hold the desired station select button (1-6) until the preset number is updated on the display and the sound is briefly muted. The channel indicator will then come on and the sound will resume. Programming is now complete.
- To retrieve a previously set station, select the radio band where the preset was stored then press the corresponding station select button (1-6).

*SiriusXM™ Satellite Radio is only available on vehicles equipped with optional SiriusXM™ satellite subscription service.


For more information, refer to the “**Display screen, heater, air conditioner, audio and phone systems (section 4)**” of your Owner’s Manual.

To view detailed instructional videos regarding these and other features, please go to www.nissanownersinfo.mobi

first drive features

CRUISE CONTROL (if so equipped)

- The cruise control system enables you to set a constant cruising speed once the vehicle has reached 25 mph.
- The system will automatically maintain the set speed until you tap the brake pedal, accelerate, cancel or turn the system off.
- To activate the cruise control, push the **CRUISE ON/OFF** switch **01**. The **CRUISE** indicator light in the instrument panel will illuminate.
- To set cruising speed, accelerate the vehicle to the desired speed, push the **COAST/SET** switch **02** and release. Take your foot off the accelerator pedal. Your vehicle will maintain the set speed.
- To reset at a faster cruising speed, push and hold the **ACCEL/RES** switch **03**. When the vehicle attains the desired speed, release the switch.
- To reset at a slower cruising speed, push and hold the **COAST/SET** switch **02**. Release the switch when the vehicle slows to the desired speed.
- To cancel the preset speed, push the **CANCEL** switch **04**.
- To turn off cruise control, push the **CRUISE ON/OFF** switch **01**. The **CRUISE** indicator light in the instrument panel will turn off.



For more information, refer to the “**Starting and driving (section 5)**” of your Owner’s Manual.

FUEL-FILLER DOOR

- The fuel-filler door release **01** is located to the left of the steering wheel and below the instrument panel.
- To open the fuel-filler door, pull the release. To lock, close the fuel-filler door securely.

For more information, refer to the “**Pre-driving checks and adjustments (section 3)**” of your Owner’s Manual.



BLUETOOTH® HANDS-FREE PHONE SYSTEM (if so equipped)

- With an overhead microphone and sound transmitted through the audio system speakers, the Bluetooth® Hands-free Phone System utilizes Bluetooth wireless technology and voice recognition to provide hands-free cellular phone communication.
- A cellular telephone should not be used while driving so full attention may be given to vehicle operation.*

SYSTEM OPERATING TIPS

- Close all windows. Surrounding noises may interfere with system operation and performance.
- Press the  button on the steering wheel to activate voice recognition.
- Wait for the tone before speaking.
- Begin speaking a command within 5 seconds of the tone.
- Speak in a clear and natural voice without pausing between words.
- Look straight ahead and avoid speaking too loudly or too softly.
- To go back to the previous command, say "Go back" or "Correction."
- To cancel a voice recognition session, simply wait 5 seconds, say "Cancel" or "Quit," or press the  button for 5 seconds.
- To interrupt the system voice and give a command quickly, press the  button.
- When speaking Phonebook names, please be aware some phones require the last name to be spoken before the first name. For example, "Michael Smith" may be spoken as "Smith Michael".
- To increase or decrease the volume of the voice prompts, push the volume control switches  or  on the steering wheel or turn the **VOL/ON-OFF** control knob on the audio system while the system is responding.
- Voice commands (if so equipped) can be used to operate various Bluetooth System features using the NISSAN Voice Recognition system. See your Owner's Manual for detailed information.
- If the Voice Recognition system does not recognize your voice commands, train the system using the Speaker Adaptation Mode.
- Some commands are not available while the vehicle is in motion.
- The "Help" command can be used to hear a list of available commands at any time.
- Please refer to the cellular phone manufacturer's Owner's Manual for detailed information regarding your Bluetooth phone.
- For recommended phones and detailed instructions, please visit www.nissanusa.com/bluetooth.



*Some jurisdictions prohibit the use of cellular telephones while driving.

CONNECTING PROCEDURE

NOTE: The vehicle must be stationary when connecting the phone.

1. Press the  button on the steering wheel. The system announces the available commands.
2. Say: "Connect phone". The system acknowledges the command and announces the next set of available commands.
3. Say: "Add phone". The system acknowledges the command and asks you to initiate connecting from the phone handset.
4. Initiate connecting from the phone:
 - The connecting procedure varies according to each cellular phone model. For detailed connecting instructions and compatible phones, please visit **www.nissanusa.com/bluetooth**.
 - When prompted for a Passkey code, enter "1234" from the handset. (The Passkey code is assigned by NISSAN and cannot be changed.)
5. Say a name for the phone when the system asks you to provide one. You can give the phone a name of your choice.

PHONEBOOK SETUP

- Depending on your cell phone, the system may automatically download your cell phone's entire phonebook to the vehicle's Bluetooth system.
- If the phonebook does not download automatically, 40 entries can be individually downloaded.
- To manually download entries:
 1. Push the  button on the steering wheel.
 2. After the tone, say "Phonebook".
 3. After the next tone, say "Transfer Entry". The system acknowledges the command and asks you to initiate the transfer from the phone handset. The new contact phone number will be transferred from the cellular phone to the vehicle.
- The transfer procedure varies according to each cellular phone. See your cellular phone's owner's manual for details. You can also visit **www.nissanusa.com/bluetooth** for instructions on transferring phone numbers from NISSAN recommended cellular phones.
- 4. The system repeats the number and prompts you for the next command. When you have finished entering numbers or transferring an entry, choose "Store".
- 5. The system confirms the name, location and number.

MAKING A CALL FROM THE PHONEBOOK

1. Press the  button.
2. After waiting for the tone, say "Call".
3. After the next tone, speak a name of a phonebook entry. For example, "Michael Smith".
4. Confirm the correct name is recognized by saying "Dial" after the tone.

NOTE: In some cases, names stored in all UPPERCASE letters may not be recognized by the voice recognition system.

MAKING A CALL BY PHONE NUMBER

1. Press the  button. A tone will sound.
2. Say: "Call". The system acknowledges the command and announces the next set of available commands.
3. Say: "Phone Number". The system acknowledges the command and announces the next set of available commands.
4. Say the number you wish to call starting with the area code in single digit format.
5. When you have finished speaking the phone number, the system repeats it back and announces the available commands.
6. Say: "Dial". The system acknowledges the command and makes the call.

RECEIVING/ENDING A CALL

- When you receive a phone call, a ring tone sounds through the audio system.
- To accept the call, press the  button. To reject the call, press the  button.
- To hang up the phone at the end of a call or to disconnect during call placement, press the  button.

For more information, refer to the **"Display screen, heater, air conditioner, audio and phone systems (section 4)"** of your Owner's Manual.



NAVIGATION SYSTEM (if so equipped)

- Your Navigation System can calculate a route from the current location to a preferred destination. The real-time map display and turn-by-turn voice guidance will lead you along the route.
- The Navigation System will continually update your vehicle's position. If you have deviated from the original route, it will recalculate the route from your current location.

- 01** button – Press to change the display brightness between day and night modes. While the mode is being displayed, the brightness can be adjusted using the **SCROLL** knob. Press and hold to turn the display off. Press again to turn the display on.
- 02** **NAV** button – Press to access the functions of the Navigation System.
- 03** **TRAF** button – Press to view traffic information on the route (if so equipped).
- 04** **Voice** key – Select to repeat the voice guidance while a route is active. Select and hold to switch the voice guidance on and off.
- 05** **MAP** button – Press to display the current location map screen.
- 06** **SETUP** button – Press to access the system settings.
- 07** key – Select to zoom the map in.
- 08** Touch screen display.
- 09** **BACK** button – Press to return to the previous screen.
- 10** key – Select to zoom the map out.
- 11** **VOL** knob – Turn right to increase the volume or left to decrease the volume.
- 12** **SCROLL** knob – Turn to scroll through the items in a list. Press to select a menu item.
- 13** **Menu** key – Select to access system menu options: “Store Current Position”, “Show Position/GPS Information”, “Show Destination Information” and “Map Setup”.
- 14** SD-card location – An SD-card with map data must be inserted here for map functions to operate.

For more information, refer to your Navigation System Owner's Manual.

This Quick Reference Guide is intended to provide an overview of some of the unique features of your new vehicle. See your Owner's Manual, which contains important safety warnings and information about the operation and maintenance of your vehicle, for complete details. Nissan North America, Inc. reserves the right to make changes, at anytime, without prior notice, in prices, colors, materials, equipment, specifications, and models and to discontinue models or equipment. Due to continuous product development and other pre- and post-production factors, actual vehicle, materials and specifications may vary. Some vehicles are shown with optional equipment. See the actual vehicle for complete accuracy. Specifications, options and accessories may differ in Hawaii, U.S. territories and other countries. For additional information on availability, options or accessories, see your NISSAN dealer or contact Nissan North America, Inc.



To view detailed instructional videos,
go to **www.nissanownersinfo.mobi/2013/versasedan**
or snap this barcode with an appropriate barcode reader.

