

2017

INFINITI QX50

QUICK REFERENCE GUIDE



To view detailed instructional videos, go to
www.infinitiownersinfo.mobi/2017/qx50
or snap this barcode with an
appropriate barcode reader.



Helpful Resources

BELOW IS A LIST OF HELPFUL RESOURCES THAT CAN BE USED TO LEARN MORE ABOUT THE VEHICLE'S SYSTEMS AND FEATURE OPERATIONS.

- **VEHICLE OWNER'S MANUAL**

- **INFINITI CLIENT SUPPORT 1-800-662-6200**

Support is always available if your Infiniti retailer cannot assist you or you would like to provide INFINITI directly with comments or questions.

- **INFINITI ROADSIDE ASSISTANCE 1-800-662-6200 (option 1)**

As part of the Infiniti Total Ownership Experience®, Roadside Assistance is available to you, 24 hours a day 365 days a year, for emergency roadside assistance.

- **INFINITI ELITE® EXTENDED PROTECTION PROGRAM 1-800-662-6200**

Infiniti Elite® Assurance Products provide you with quality long-term protection and enhanced peace of mind.

- **INFINITI FINANCIAL SERVICES CLIENT SUPPORT 1-800-627-4437**

For client support with your Infiniti Financial Services loan or lease.

- **INFINITI FINANCIAL SERVICES www.infinitifinance.com**

Use the IFS Online Account Manager to check your account status, schedule recurring payments and access important forms.

- **OWNER PORTAL 1-855-444-7244 www.owners.infinitiUSA.com/iowners**

Your Infiniti Owner Portal account contains your personal preferences, vehicle information and links to key vehicle features and services.

- **INFINITI INTOUCH™ 1-855-444-7244 usa.infinitiintouch.com**

The suite of services that is your direct link to personal security, convenience and confidence.

- **SiriusXM RADIO 1-877-447-0011**

For support with your SiriusXM subscription.

- **INFINITI USA.COM www.infinitiUSA.com/bluetooth**

Reference this site for a list of compatible cellular phones and instructions on how to pair your cellular phone to your vehicle.

- **INFINITI ELECTRONIC QUICK REFERENCE GUIDE**

(use the Quick Response (QR) code or URL on this page or on the back cover)

Table of Contents

Cockpit Overview	1	Opening the Liftgate	11
Instrument Panel.....	3	Sun Visors	11
Meters and Gauges.....	5	USB Connection Port.....	11
Connecting your Cellular Phone or Device via Bluetooth®	7	Exterior Light Operation	12
Bluetooth® Streaming Audio (if so equipped).....	7	Windows	12
Intelligent Cruise Control (ICC) (if so equipped).....	8	Clock Set/Adjustment.....	13
Navigation System (if so equipped)	9	Trip Computer.....	13
Infiniti Intelligent Key System.....	10	Wiper and Washer Switch	14
Seat Adjustments	10	Brightness Control Switches	14

Additional information about your vehicle is also available in your Owner's Manual, Navigation System Owner's Manual and at www.InfinitiUSA.com.

PLEASE SEE YOUR OWNER'S MANUAL FOR IMPORTANT SAFETY INFORMATION AND SYSTEM OPERATION LIMITATIONS.

- A cellular telephone should not be used for any purpose while driving so full attention may be given to vehicle operation.
- Always wear your seat belt.
- Supplemental air bags do not replace proper seat belt usage.
- Children 12 and under should always ride in the rear seat properly secured in child restraints or seat belts according to their age and weight.
- Do not drink and drive.



For more information, refer to the “Safety — Seats, seat belts and supplemental restraint system (section 1)”, the “Display screen, heater and air conditioner, and audio system (section 4)” and the “Starting and driving (section 5)” of your Owner's Manual.

Cockpit Overview




For more information, refer to your Owner's Manuals.

Cockpit Overview

- 1 Intelligent Cruise Control (ICC) switches (if so equipped)
- 2 Cruise control switches
- 3 Wiper and washer switch
- 4 Vehicle information display
- 5 Combined turn signal/Headlight control switch
- 6 Vehicle information display and audio control switches
- 7 Bluetooth® control switches

Instrument Panel



For more information, refer to your Owner's Manuals.

Instrument Panel

- ❶ Multi-function control touch-screen/ RearView Monitor display/
Around View® Monitor (AVM) display (if so equipped)
- ❷ Navigation control panel
- ❸ Push-button engine start
- ❹ Audio control panel
- ❺ Climate control panel
 - Heater and air conditioning (automatic)
 - Front/Rear window defroster
- ❻ Shift lever
- ❼ Parking brake
- ❽ Hood latch release
- ❾ Lower switch bank
 - Vehicle Dynamic Control (VDC) OFF switch
 - IBA OFF switch
 - Safety Shield OFF switch
 - Intelligent Key port

Meters and Gauges




Meters and Gauges

- 
- 1 Fuel gauge
 - 2 Speedometer
 - 3 Vehicle information display
 - 4 Shift lever indicator
 - 5 Tachometer
 - 6 Engine coolant temperature gauge

Connecting your Cellular Phone or Device via Bluetooth[®], 1, 2

The vehicle must be stationary when connecting the cellular phone.

1. Press the **SETTING** button on the control panel and touch the “Bluetooth” key on the display.
2. Touch the “Connect Bluetooth” key.
3. A pop-up box will appear on the screen, prompting you to confirm that the connection is for the hands-free phone system. Touch the “Yes” key.
4. Initiate connecting from the cellular phone.




For any Bluetooth[®] connectivity issues, reboot your cellular phone or device.

¹Availability of specific features is dependent upon the phone's Bluetooth[®] support. Please refer to your phone owner's manual for details. Bluetooth[®] word mark and logos are owned by Bluetooth SIG, Inc.

²Some jurisdictions prohibit the use of cellular telephones while driving. Compatible smartphone required. Text rates and/or data usage may apply

Bluetooth[®] Streaming Audio (if so equipped)

1. Press the **SETTING** button on the control panel and touch the “Bluetooth” key on the display.
2. Select “Connected Devices”.
3. Select “Audio Player”.
4. Select the name of the device that you are attempting to connect as an audio player.
5. Select “Select”.
6. Verify that the system confirms that the device has been selected as an audio player.




For any Bluetooth[®] connectivity issues, reboot your cellular phone or device.

Intelligent Cruise Control (ICC) (if so equipped)

The vehicle's cruise control maintains a constant set speed for you. The system is operational only at speeds above 20 mph (32 km/h).

- Press the **CRUISE ON/OFF** button ① to turn the system on and off. The indicator lights will illuminate ② in set mode and extinguish.
- Push the switch ③ down toward **COAST/SET** ④ and release it to set the desired speed.
- To set at a slower cruising speed, push down and hold the switch ③ toward **COAST/SET** ④ until the desired speed is reached.
- Press the vehicle-to-vehicle distance button ⑤ repeatedly to change the set distance.
- When a vehicle is not detected ahead, the set distance and set vehicle speed indicator lights will illuminate ⑥ in set mode.
- When a vehicle is detected ahead, the vehicle ahead detection, set distance and set vehicle speed indicator lights will illuminate ⑦ in set mode.
- Push up on the switch ③ toward **ACCEL/RES** ⑧ and release it to resume the set speed.



- To set a higher cruising speed, push up and hold the **CANCEL** switch ③ toward **ACCEL/RES** ⑧ until the desired speed is reached.
- Push the **CANCEL** switch ⑨ to cancel the set speed. The set vehicle speed indicator ⑥ will change to gray.

TO SET CONVENTIONAL (FIXED SPEED) CRUISE CONTROL MODE:

- While cruise control is off, press and hold the **CRUISE ON/OFF** button ① for more than 1.5 seconds. The **CRUISE** indicator light will illuminate.
- Accelerate to the desired speed.
- Push the switch ③ down toward **COAST/SET** ④ and release it. The **SET** indicator light will illuminate.

Navigation System (if so equipped)

- Your Navigation System can calculate a route from your current location to a preferred destination. The real-time map display and turn-by-turn voice guidance will lead you along the route.


SYSTEM OPERATION

- 1 Rotate to highlight an item on the screen.
- 2 Press the **ENTER** button to select the highlighted item, or touch the desired key on the touch-screen display.
- 3 Press the **BACK** button to return to the previous screen.
- 4 Press the **MAP** button to display the map on the display.
- 5 Push and hold to switch between the day screen (bright) and the night screen (dark).
- 6 Press the **INFO** button to display map info.
- 7 Press the **SETTING** button to access the navigation settings.



SETTING A ROUTE

1. Press the **ROUTE** button (8).
2. Touch the **DEST** button (9).
3. Enter the House Number and touch the "OK" key.
4. Enter the Street Name and touch the "List" key.
5. Select the preferred Street/City combination.
6. Touch the "Start" key.



CANCELING A ROUTE

1. Press the **ROUTE** button (8).
2. Select the "Cancel Route" key (10).

ZOOMING IN AND OUT

- On the map screen, turn the Infiniti controller (1) right or left to zoom in or out or press the **ZOOM OUT** button (11) to zoom out and the **ZOOM IN** button (12) to zoom in.

Infiniti Intelligent Key System

ROLL DOWN FEATURE

The windows can be opened remotely using your Infiniti Intelligent Key.

- Press and hold the unlock button ① to open the windows and moonroof (if so equipped) remotely.
- If the unlock button ① is released, the windows will stop. To resume the roll down feature, press and hold the unlock button ① again.



Seat Adjustments

POWER SEAT ADJUSTMENTS

- To slide the seat forward or backward, push the  switch ① forward or backward.
- To recline the seatback, push the  switch ② forward or backward.



SEAT LIFTER (driver's seat and if so equipped for passenger's seat)

- To adjust the angle of the front portion or height of the seat, push the front or rear end of the  switch ① up or down.

POWER LUMBAR SUPPORT (if so equipped for driver's seat)

- To adjust the seat lumbar support, push the front or back end of the  switch ③.

Opening the Liftgate


LIFTGATE RELEASE

- It is important to make sure the Intelligent Key is with you (that is, in your pocket or purse).
- Use one of the following methods to unlock the liftgate:
 - Press the  button ① on the Infiniti Intelligent Key twice.
 - Push the liftgate request switch ②.
- To open the liftgate, push the liftgate opener switch ③ located just above the license plate and pull the liftgate opener handle.



Sun Visors

- 1 Pull down the sun visor to block glare from the front.
- 2 Remove the sun visor from the center mount by lifting it slightly and swing it to the side to block glare from the side window.
- 3 Slide the sun visor out from the mount to further extend the visor location.




USB Connection Port

- The USB port ① is located in the center console under the armrest. Compatible audio and video files stored on a USB device can be played through the vehicle's audio system and front display.



Exterior Light Operation



- 1 Side lights, license plate lights and combination meter lighting ON position
- 2 Headlight ON position
- 3 Automatic **AUTO** headlight mode ON position (headlights switch on/off automatically depending on ambient light conditions/daytime light system)
- 4 **OFF** position
- 5 Front fog light switch
- 6 Push the headlight switch forward for the high beams.
- 7 Pull the headlight switch rearward to flash the high beams.

For normal headlight operation, leave the exterior light switch in the **AUTO** position.

Windows

All power windows can be operated through the main switch on the driver's door.

- 1 Power windows open/close.
- 2 Disable rear passenger window operation by rear passengers.



POWER WINDOW CONVENIENCE OPENING/CLOSING FEATURE

The vehicle can be locked/unlocked and the power windows can be closed/opened simultaneously from outside the vehicle using the Intelligent Key as follows:

To lock the vehicle and close the power windows simultaneously, touch the sensor surface ③ on the door handle until the windows are fully closed.



To unlock the vehicle and open the windows simultaneously, press and hold the 1 button on the Intelligent Key until the windows have reached the desired position.

Clock Set/Adjustment

DIGITAL CLOCK WITH NAVIGATION (if so equipped)


- To adjust the time and the appearance of the clock on the display:
 - Press the **SETTING** button on the control panel.
 - Select the “Others” key.
 - Select the “Clock” key.
- The following settings can be adjusted:
 - On-screen Clock:** The clock in the upper right corner of the display can be turned ON or OFF.
 - Clock Format (24h):** The clock can be set to 12 hours or 24 hours.
 - Offset (hour):** The time can be adjusted by increasing or decreasing per hour.
 - Offset (min):** The time can be adjusted by increasing or decreasing per minute.
 - Daylight Savings Time:** The application of Daylight Savings Time can be turned ON or OFF.
 - Time Zone:** Adjust the time zone. Choose a time zone from the available list.
- Press the **BACK** button to return to the previous screen.



ANALOG CLOCK

To set the clock forward, press the button ①.
To set the clock backward, press the button ②.

Trip Computer




- When the  button ① is pressed, the following modes will appear on the vehicle information display ②:
MPG, MPG/MPH, TIME/MILES, RANGE, OUTSIDE TEMP, SETTING, WARNING
- To reset the elapsed time/miles, press and hold the  button ③ for more than 1 second. Both elapsed time/miles will reset at the same time.

Wiper and Washer Switch


- Move the lever to one of the following positions to operate the windshield wipers:



- 1** Mist (**MIST**) – One sweep operation of the front wipers.
- 2** Intermittent (**INT**) – Turns on the speed-sensing front wipers intermittently.
- 3** The control ring adjusts the operation speed of the intermittent wipers to increase or decrease wiper speed.
- 4** Low (**LO**) – Operates at a continuous low-speed.
- 5** High (**HI**) – Operates at a continuous high-speed.
- 6** Front Washer  – Pull the lever toward you to activate the front washer. The front wipers will operate several times.




Brightness Control Switches



Use these buttons to adjust the brightness of the vehicle information display **1**.

- To increase the brightness, push the upper switch **2**.
- To decrease the brightness, push the lower switch **3**.

Memo



This Quick Reference Guide is intended to provide an overview of some of the unique features of your new vehicle. Please see your Owner's Manual for important safety information and system operation limitations. Features and equipment in your vehicle may vary depending on model, trim level, options selected, order, date of production, region or availability. Therefore, you may find information about features or equipment that are not included or installed on your vehicle.

All information, specifications and illustrations in this Quick Reference Guide are those in effect at the time of printing. INFINITI reserves the right to change specifications, performance, design or component suppliers without notice and without obligation. From time to time, INFINITI may update or revise this Quick Reference Guide to provide owners with the most accurate information currently available. Please carefully read and retain, with this Quick Reference Guide, all revision updates sent to you by INFINITI to ensure you have access to accurate and up-to-date information regarding your vehicle. Current versions of vehicle Quick Reference Guides, Owner's Manuals and any updates can also be found in the Owner section of the INFINITI website at <https://owners.infiniti-usa.com/iowners/navigation/manualsAndGuides>. If you have questions concerning any information in your Owner's Manual, contact INFINITI Client Support (see contact information listed above).



To view detailed instructional videos, go to www.infinitiownersinfo.mobi/2017/qx50 or snap this barcode with an appropriate barcode reader.



INSPIRED PERFORMANCE