

2017

INFINITI QX60

QUICK REFERENCE GUIDE



To view detailed instructional videos, go to
www.infinitiownersinfo.mobi/2017/qx60
or snap this barcode with an appropriate
barcode reader.



Helpful Resources

BELOW IS A LIST OF HELPFUL RESOURCES THAT CAN BE USED TO LEARN MORE ABOUT THE VEHICLE'S SYSTEMS AND FEATURE OPERATIONS.

- **VEHICLE OWNER'S MANUAL**

- **INFINITI CLIENT SUPPORT 1-800-662-6200**

Support is always available if your Infiniti retailer cannot assist you or you would like to provide INFINITI directly with comments or questions.

- **INFINITI ROADSIDE ASSISTANCE 1-800-662-6200 (option 1)**

As part of the Infiniti Total Ownership Experience®, Roadside Assistance is available to you, 24 hours a day 365 days a year, for emergency roadside assistance.

- **INFINITI ELITE® EXTENDED PROTECTION PROGRAM 1-800-662-6200**

Infiniti Elite® Assurance Products provide you with quality long-term protection and enhanced peace of mind.

- **INFINITI FINANCIAL SERVICES CLIENT SUPPORT 1-800-627-4437**

For client support with your Infiniti Financial Services loan or lease.

- **INFINITI FINANCIAL SERVICES www.infinitifinance.com**

Use the IFS Online Account Manager to check your account status, schedule recurring payments and access important forms.

- **OWNER PORTAL 1-855-444-7244 www.owners.infinitiUSA.com/iowners**

Your Infiniti Owner Portal account contains your personal preferences, vehicle information and links to key vehicle features and services.

- **INFINITI INTOUCH™ 1-855-444-7244 usa.infinitiintouch.com**

This suite of digital alerts and remote services is your direct link to personal security, convenience and confidence.

- **SiriusXM RADIO 1-877-447-0011**

For support with your SiriusXM subscription.

- **INFINITI USA.COM www.infinitiUSA.com/bluetooth**

Reference this site for a list of compatible cellular phones and instructions on how to pair your cellular phone to your vehicle.

- **INFINITI ELECTRONIC QUICK REFERENCE GUIDE**

(use the Quick Response (QR) code or URL on this page or on the back cover)

Table of Contents

Cockpit Overview	1
Instrument Panel	3
Meters and Gauges	5
Opening the Liftgate	7
Outside Mirrors	7
2 nd Row Seats	8
Wiper and Washer Switch	8
Dynamic Driver Assistance Switch (if so equipped)	9
USB Connection Ports	9
Remote Start (if so equipped)	10

Automatic Drive Positioner (if so equipped)	10
Heater and Air Conditioner (automatic)	11
Connecting your Cellular Phone or Device via Bluetooth®	12
Bluetooth® Streaming Audio	12
Voice Recognition	12
Center Display	13
Navigation System (if so equipped)	14
Clock Set/Adjustment	14
Infiniti InTouch™ Services (if so equipped)	15
Infiniti Mobile Entertainment System (MES) (if so equipped)	16


Additional information about your vehicle is also available in your Owner's Manual, Navigation System Owner's Manual and at www.InfinitiUSA.com.

PLEASE SEE YOUR OWNER'S MANUAL FOR IMPORTANT SAFETY INFORMATION AND SYSTEM OPERATION LIMITATIONS.

- A cellular telephone should not be used for any purpose while driving so full attention may be given to vehicle operation.
- Always wear your seat belt.
- Supplemental air bags do not replace proper seat belt usage.
- Children 12 and under should always ride in the rear seat properly secured in child restraints or seat belts according to their age and weight.
- Do not drink and drive.



For more information, refer to the “Safety — Seats, seat belts and supplemental restraint system (section 1)”, the “Monitor, climate, audio, phone and voice recognition systems (section 4)” and the “Starting and driving (section 5)” of your Owner's Manual.



Cockpit Overview



2

3

4

1

Cockpit Overview

- 1 Dynamic Driver Assistance switch
- 2 Vehicle information display and menu control switches
- 3 Bluetooth® control switches
- 4 Cruise control switches

Instrument Panel



For more information, refer to your Owner's Manuals.

Instrument Panel

- ❶ Multi-function control touch-screen/ RearView Monitor display/Around View® Monitor display (if so equipped)
- ❷ Climate control panel
 - Heater and air conditioning (automatic)
 - Front and rear window defroster
- ❸ Infiniti multi-function controller
- ❹ Audio system
- ❺ Shift lever
- ❻ Lower instrument panel switches
 - Vehicle Dynamic Control (VDC) OFF switch
 - Power liftgate switch
 - Power liftgate main switch
 - Heated steering wheel switch (if so equipped)
 - Warning systems switch
 - Power inverter switch (if so equipped)

Meters and Gauges



Meters and Gauges

- 
- 1 Tachometer
 - 2 Engine coolant temperature gauge
 - 3 Shift lever indicator
 - 4 Vehicle information display
 - 5 Speedometer
 - 6 Fuel gauge

Opening the Liftgate



To open the liftgate:

- Push the power liftgate switch ① on the instrument panel.
- Push the liftgate opener switch ②; the liftgate must be unlocked, or you must have the Intelligent Key with you (that is, in your pocket or purse).
- Press the  button ③ on the Infiniti Intelligent Key for longer than 1 second.
- The power liftgate operation can be turned on or off by the power liftgate main switch ④ on the instrument panel.



MOTION-ACTIVATED LIFTGATE

The liftgate can also be opened and closed using a foot kicking motion when it is locked or unlocked. The Intelligent Key must be present within 3 ft (1 m) of the liftgate.

To use this feature, make a single kicking motion under the center of the rear bumper ⑤. After the motion is complete, step back to allow the liftgate to open or close.



Outside Mirrors



Adjusting the outside mirrors:

- To adjust the outside mirrors, move the switch ① right or left to select the right or left mirror.
- Adjust the position of the mirror using the directional control switch ②.

Folding the outside mirrors:

To fold the mirrors closed, push the  switch ③. To open the mirrors, push the  switch ④.

REVERSE TILT-DOWN FEATURE (IF SO EQUIPPED)

When backing up the vehicle, the outside mirrors will turn downward automatically to provide better rear visibility. To enable the reverse tilt-down feature, move the switch ① to either the left or right position.

If the switch ① is set in the center (neutral) position, the mirror will not tilt down when reversing.

2nd Row Seats



Forward and backward adjustment:

Pull the center of the bar (1) up and hold it while you slide the seat forward or backward to the desired position until it latches.

Seat angle adjustment:

Pull up on the lever (2) and lean back until the seat latches. To bring the seatback forward, pull the lever up and lean your body forward until it latches.

MULTI-MODE/CHILD SEAT ACCESS FUNCTION

On the passenger's side of the vehicle, the 3rd row can be accessed without removing a child seat installed in the 2nd row.

- Lift up on the seatback release lever (3) and slide the entire seat forward.
- To return the seat to a locked position, push the upper seatback rearward until the seatback and track are locked.

Wiper and Washer Switch



Move the lever (1) up or down to one of the following positions to operate the windshield wipers:

- MIST** One sweep operation
- OFF** Wipers are OFF
- AUTO** Speed-sensing and rain-sensing (if so equipped) automatic wipe
- LO** Continuous wipe, slow
- HI** Continuous wipe, fast

To adjust the wiper sensitivity for the **AUTO** setting, twist the control ring (2). The rain-sensing function (if so equipped) can be disabled in the vehicle information display under “Vehicle Settings”.

Pull the lever (1) toward you operate the windshield washer.

REAR WIPER AND WASHER

Turn the rear wiper switch (3) to one of the following positions to operate the rear wiper:

- OFF** Wiper is OFF
- INT** Intermittent wiping
- ON** Continuous wipe, slow

Push the lever (1) forward to operate the rear windshield washer.


Dynamic Driver Assistance Switch (if so equipped)

The Dynamic Driver Assistance switch (1) can be used to temporarily turn on and off the following systems:

- Lane Departure Prevention (LDP): The LDP system helps warns the driver with a warning light and chime and helps assist the driver to return the vehicle to the center of the traveling lane.
- Distance Control Assist (DCA): The DCA system helps assist the driver to maintain a following distance from a vehicle ahead by activating the brakes and moving the accelerator pedal upward to decelerate smoothly.
- Blind Spot Intervention® (BSI): The BSI system helps alert the driver of other vehicles in adjacent lanes when changing lanes with a warning light and chime. It also helps assist the driver to return to the center of the current traveling lane when another vehicle is present in the adjacent lane.



USB Connection Ports



The USB ports (1) are located in the center console under the armrest.

- When a compatible USB memory device or iPod® is plugged into one of the USB ports, compatible audio files stored on the device can be played through the vehicle's audio system.
- These ports will also charge compatible devices.

USB/iPOD® CHARGING PORTS

- There is a USB port located in the 2nd row on the back of the center console (2) and two ports in the 3rd row located above the cup holders (3). These ports will charge compatible devices.

Remote Start (if so equipped)¹

To start your vehicle remotely, press the **LOCK** button ① on the Infiniti Intelligent Key, and within 5 seconds, press and hold the remote engine start **ENGINE START/STOP** button ② for at least 2 seconds.



- Automatic climate control will begin heating or cooling the vehicle based on the temperature inside and outside the vehicle.
- The engine will run for 10 minutes and then turn off. To extend the time for an additional 10-minute period, repeat the procedure.
- To start driving, depress the brake pedal and press the ignition switch **START/STOP** button.

Remote start can be enabled or disabled through the vehicle information display.

HEATED STEERING WHEEL (if so equipped)

The heated steering wheel may be activated during remote engine start when outside and cabin temperatures are low.

During remote start, the heated steering wheel switch will be inoperable until the ignition switch is turned on.

¹ For disclaimer, refer to page 17 of this guide.

Automatic Drive Positioner (if so equipped)



Two positions for the driver's seat, steering column and outside mirrors can be stored in the automatic drive positioner memory. To set a memory position:

1. Place the ignition switch in the ON or ACC position. (The vehicle should be stopped while setting the memory.)
2. Adjust the driver's seat, steering column and outside mirrors to the desired positions using the adjusting switches for each feature.
3. Push the **SET** switch ①, and within 5 seconds, push the memory switch (1 or 2) ②. The indicator light for the memory switch you select will illuminate for approximately 5 seconds and a chime will sound when the memory is stored.
4. Press the unlock button on the key fob to link the memorized position to your Infiniti Intelligent Key.

The driver's seat and steering column will automatically move when the shift lever is in the **P (PARK)** position to allow the driver to get in and out of the driver's seat more easily. "Exit Seat Slide" and "Exit Steering UP" can be disabled in the vehicle information display under "Vehicle Settings".

Heater and Air Conditioner (automatic)



- Press the **AUTO** button ① to turn the system on and automatically control the inside temperature.
- Press the **CLIMATE** button ② to adjust the automatic climate controls using the climate settings on the control panel display screen.
- Use the driver's side ③ or passenger's side ④ control buttons ▲ (warmer air) or ▼ (cooler air) to control the desired side's temperature.
- Press the air flow control button ⑤ to manually cycle through the available air flow modes.
- Press the **DUAL** button ⑥ to turn the system on and off.
- Press the fan speed control buttons ⑦ to increase or decrease the fan speed.
- Press the front defroster button ⑧ to turn the front defroster system on and off, and use the temperature control buttons ③ to change the temperature.
- To defrost the rear window and outside mirrors, push the rear defroster switch ⑨ to turn the system on and off.
- Press the intake air control button ⑩ to recirculate the air inside the vehicle.
- Press the **OFF** button ⑪ to turn the climate control system off.



REAR CONTROLS

- Press the **REAR ON-OFF** button ⑫ to turn the rear air conditioner on and off.
- Press the **OFF** button ⑬ to turn the system off.
- Adjust the fan speed up or down using the control buttons ⑭.
- Press the **AUTO** button ⑮ to turn on the automatic mode.
- Adjust the temperature up or down using the **TEMP** buttons ⑯.

Connecting your Cellular Phone or Device via Bluetooth[®],^{2,3}



Using Bluetooth[®] technology, you can connect (pair) your cellular phone with the in-vehicle system for hands-free use of your cellular phone⁴.

1. Press the **SETTING** button on the control panel.
2. Touch the “Phone/Mail” key.
3. Touch “Connect Device”.
4. Touch “Add New (X/5 Free)”.
5. When a PIN appears on the screen, operate the Bluetooth[®] device to enter/confirm the PIN.



For any Bluetooth[®] connectivity issues, reboot your cellular phone or device.

^{2,3,4} For disclaimer, refer to page 17 of this guide.

Bluetooth[®] Streaming Audio

If you have a compatible Bluetooth[®] device with streaming audio (A2DP and AVRCP profiles), you can set up a wireless connection between your Bluetooth[®] device and the in-vehicle audio system, enabling you to listen to the audio from your device through the vehicle's audio system.

After connecting your Bluetooth[®] device, press the **MEDIA** button on the control panel to switch to Bluetooth[®] Streaming Audio.

For any Bluetooth[®] connectivity issues, reboot your cellular phone or device.

For more information, refer to your Owner's Manuals.


Voice Recognition

SYSTEM OPERATING TIPS

- The interior of the vehicle should be as quiet as possible.
- Speak naturally. Speaking too fast, too slow, too soft, or too loud makes voice recognition more difficult.
- Confirm that the correct voice commands are being used. Glance at the screen to see the currently available commands.

USING THE VOICE RECOGNITION SYSTEM

- Press the  or  button ① on the steering wheel, and a list of commands will appear on the screen.
- After the tone sounds, speak the command.
- To skip the voice prompt and give the command immediately, press the  or  button ① on the steering wheel to interrupt the system. Speak the next command after the tone sounds.
- To cancel the command, press and hold the  or  button ① on the steering wheel.



Center Display

Infiniti InTouch® controls the audio, RearView/Around View® Monitor (if so equipped), Navigation System (if so equipped), InTouch Apps, Bluetooth® hands-free phone, and various settings using the touch-screen display, Infiniti controller, menu button and steering wheel switches.



TOUCH-SCREEN DISPLAY

- 1 ↶ – Return to the previous screen.
- 2 ◀ or ▶ – Touch the arrow keys to navigate between screens.
- 3 Touch any key to select that item.



INFINITI CONTROLLER AND MENU BUTTONS


- 4 **ENTER** – Select the highlighted item.
- 5 Center dial – Turn or slide to select an item or navigate through options.
- 6 ↶ **BACK** – Return to the previous screen.
- 7 **CAMERA** ☀/☾ – Press to view the Around View® Monitor (if so equipped). Press and hold to control the brightness.

STEERING WHEEL SWITCHES

- 8 ↶ – Return to the previous screen.
- 9 **ENTER** – Press to select the highlighted item.
- 10 ⬆ – Tilt the **ENTER** button up or down to navigate through options.



Navigation System (if so equipped)




Use the Infiniti controller ① and **ENTER** button ② to navigate through the center display screens.

- Press the **BACK** button ③ to return to the previous screen.
- Press the **MAP** button ④ to display the map.

SETTING A ROUTE

To set a route, first ensure that the correct region is selected on the touch-screen.

1. Press the **NAVI** button ⑤ on the control panel.
2. Touch the “Destination Menu” key ⑥ on the display.
3. Select the preferred destination setting method.
4. Enter the address number, street name, and city as prompted by the screen.




CANCELING A ROUTE

1. Press the **NAVI** button ⑤ on the control panel.
2. Touch the “Cancel Route” key ⑦.



Clock Set/Adjustment



To adjust the time and the appearance of the clock on the display:

1. Press the **SETTING** button ① on the Infiniti controller.
2. Locate and touch the “Clock” key to adjust “On-Screen Clock”, “Daylight Savings Time”, “Clock Format (24h)”, and “Time Zone”.
3. The time can be adjusted through “Offset Adjustment” ② by adjusting the minutes and/or hours forward or backward. The current clock time can be set up to a difference of 12 hours and 59 minutes.

Infiniti InTouch™ Services⁵ (if so equipped)

Infiniti InTouch™ Services combine personalized convenience settings and personal security features to compliment the Total Ownership Experience®. For more details on Infiniti InTouch Services or to enroll your vehicle, please visit usa.infinitiintouch.com or call 1-855-444-7244.



To access Infiniti InTouch Services:

Press the **SETTING** button (1) on the Infiniti controller. Select the “InTouch Services” key (2) on the display.

In case of an emergency, press and release the in-vehicle telematics **SOS** button (3), located above the rearview mirror.



INFINITI INTOUCH SERVICES ENROLLMENT

1. Create an Infiniti Owner Portal account.
(<https://owners.infiniti.com/iowners/>)
2. From your Infiniti Owner Portal account, enroll in Infiniti InTouch Services.
3. Download the Infiniti InTouch Services companion app from the App store and log in using your Infiniti Owner Portal ID and Password.

Available services include, but are not limited to:

- Automatic Collision Notification
- Alarm Notification
- Maintenance Alert
- Scheduled Maintenance Notification
- Report Stolen Vehicle
- Emergency Call
- Enhanced Roadside Assistance
- Remote Door Lock/Unlock
- Remote Engine Start/Stop
- Remote Horn/Lights
- My Schedule
- Destination Assistance
- Destination Send-to-Vehicle
- Connected Search
- Drive Zone
- Maximum Speed Alert
- Mobile Information Service
- Valet Alert

⁵ For disclaimer, refer to page 17 of this guide.

Infiniti Mobile Entertainment System (MES) (if so equipped)



With this entertainment system, you can play video files on both the front and rear display screens.

Watching a DVD:

- Insert a DVD into the DVD slot (1) and the DVD will play automatically. The front display will only work when the vehicle is in park and the parking brake is engaged.
- Press the **DISC** button (2) on the control panel to bring up the DVD menu and display settings. Use the touch-screen and the Infiniti controller to select the menu items.

Watching videos from a USB or HDMI device:

- Connect your compatible device to the USB or HDMI port located at the rear of the center console box.
- The source can be changed on the rear displays using the remote by pressing the **HOME** button.



REAR DISPLAYS

To turn the rear displays on and off from the front seats:

1. Press the **AUDIO** button (3) on the control panel.
2. Select the “Rear Display” key on the display.

- 4 **POWER** – Turn display screen on and off
- 5 **DISPLAY SELECT** – Change display controls between right and left screen
- 6 **HOME** – Change video source
- 7 **MENU** – Change menu display
- 8 **ENTER/Selection Buttons** – Control and select buttons
- 9 **BACK** – Previous menu button
- 10 **SETUP** – Bring up display menu
- 11 **Video Controls** – Play, stop, fast forward and rewind buttons
- 12 **Volume** – Control audio level

Disclaimers

¹ State laws may apply; review local laws before using.

² Availability of specific features is dependent upon the phone's Bluetooth® support. Please refer to your phone owner's manual for details. Bluetooth® word mark and logos are owned by Bluetooth SIG, Inc.

³ Some jurisdictions prohibit the use of cellular telephones while driving. Compatible smartphone required. Text rates and/or data usage may apply.

⁴ Laws in some jurisdictions may restrict the use of "Text-to-Speech". Some of the applications and features, such as social networking and texting, may also be restricted. Check local regulations for any requirements before using these features.

⁵ Driving is serious business. Only use Infiniti InTouch Services and Infiniti InTouch Services Premier when safe to do so. Never program while driving. GPS mapping may not be detailed in all areas or reflect current road status. Services, including automatic crash notification and SOS, require an active subscription, and are dependent upon the telematics device being in an operative condition, its ability to connect to a wireless network, compatible wireless network availability, navigation map data, and GPS satellite signal receptions, the absence of which can limit or prevent the ability to reach Infiniti InTouch Services Customer Care or receive support. Services require compatible 3G GSM/GPRS cellular network provided by AT&T. 3G cellular network not available in all areas and/or available at all times. Cellular technology is evolving, and changes to cellular networks provided by independent companies are not within Infiniti's or Sirius XM Connected Vehicle Service's Inc.'s control. Certain vehicle services, including Google® compatible services, provided by independent companies are not within Infiniti's or SiriusXM's control and are subject to change without notice or liability to Infiniti, its affiliates and agents or SiriusXM. Like other devices that rely on network coverage, once the network service is discontinued, Infiniti InTouch services will not function unless equipment replacements, upgrades, or alternative network coverage are available at that time, which neither Infiniti nor Sirius XM can guarantee. Infiniti and Sirius XM are not responsible for associated costs that may be required for continued operation due to cellular network shutdown or discontinuation (including equipment upgrades, if available, or roaming charges on alternative networks). 6 month trial subscription begins on your date of purchase or lease of your new Infiniti. Subsequently, your credit card (if on file) will be charged at the then current subscription rate and your service will renew automatically under the terms of your subscription. Standard text rates and/or data usage may apply. Terms and Conditions of Subscription Agreement apply. See www.infinitiusa.com/intouch for more information.

Memo



This Quick Reference Guide is intended to provide an overview of some of the unique features of your new vehicle. Please see your Owner's Manual for important safety information and system operation limitations. Features and equipment in your vehicle may vary depending on model, trim level, options selected, order, date of production, region or availability. Therefore, you may find information about features or equipment that are not included or installed on your vehicle.

All information, specifications and illustrations in this Quick Reference Guide are those in effect at the time of printing. INFINITI reserves the right to change specifications, performance, design or component suppliers without notice and without obligation. From time to time, INFINITI may update or revise this Quick Reference Guide to provide owners with the most accurate information currently available. Please carefully read and retain, with this Quick Reference Guide, all revision updates sent to you by INFINITI to ensure you have access to accurate and up-to-date information regarding your vehicle. Current versions of vehicle Quick Reference Guides, Owner's Manuals and any updates can also be found in the Owner section of the INFINITI website at <https://owners.infiniti-usa.com/iowners/navigation/manualsAndGuides>. If you have questions concerning any information in your Owner's Manual, contact INFINITI Client Support (see contact information listed above).



To view detailed instructional videos, go to www.infinitiownersinfo.mobi/2017/qx60 or snap this barcode with an appropriate barcode reader.



INSPIRED PERFORMANCE