

Contents

A-Z

Quick Reference
Card.



The Ultimate Driving
Machine®



THE BMW X1.

QUICK REFERENCE.

BMW EfficientDynamics
Less emissions. More driving pleasure.

© 2017 Bayerische Motoren Werke
Aktiengesellschaft
Munich, Germany
Reprinting, including excerpts, only with the written
consent of BMW AG, Munich.
US English V/2017,
Printed on environmentally friendly paper, bleached
without chlorine, suitable for recycling.

Contents

X1

6	Entering your vehicle
6	Remote Control
6	Central Locking
6	Comfort Access (if equipped)
7	Tailgate
8	Adjusting and controlling
8	Seats
9	Lights
10	Wipers
11	Heated Steering Wheel Button
11	Active Cruise Control (if equipped)
11	Bluetooth
12	Climate
13	Connectivity
13	iDrive
13	Programmable Memory Buttons
14	BMW Connected App
14	Apple CarPlay™*
15	Audio System
15	Navigation (if equipped)
16	Voice Control (if equipped)
17	Get going
17	Starting/Stopping the Engine
17	Auto Start/Stop
17	Shifting Gears and Driving Modes
18	Three-point Rear Center Seatbelt
19	Upholstery
19	Center Console Storage
20	Additional information
20	BMW Driver's Guide App
20	BMW Genius
20	Vehicle Equipment

Entering your vehicle

Remote Control

Control and convenience in the palm of your hand.

Operate windows, doors, tailgate, lights and alarm remotely – while storing your personalized profile.

Beyond simply locking and unlocking your vehicle, the remote control has several useful functions:



- 1 **Unlocking:** Press to unlock driver's door. Press again to unlock other doors (unless programmed to open all doors with one press).
- 2 **Locking:** Press to lock. Press twice (red indicator on interior mirror glows continuously) to deactivate interior motion detector (e.g., for elevator parking).
- 3 **Tailgate:** Hold one second to open.
- 4 **Panic Mode:** Press and hold three seconds to sound alarm.

Tip: Press and hold button 1 to open windows and moonroof from outside the vehicle.

 **Note:** Each remote also stores many preferred settings, such as seat/mirror position, climate, radio stations, etc., so be sure to use your personal remote. For proper operation, keep remote control and mobile phone apart. Do not lock vehicle using remote when people are inside. ◀

Central Locking

Quick security at your fingertips.

Lock and unlock all doors and the tailgate by using the buttons, conveniently located on the driver's and passenger's door by the armrest.




- ▷ **Locking:** Press the  button to lock all doors and tailgate.
- ▷ **Unlocking:** Press the  button to unlock all doors and tailgate.

 **Note:** When button is used to lock vehicle, fuel filler flap remains unlocked and the alarm system is not armed. When used to unlock doors, each door handle requires only one pull to open. ◀

Comfort Access (if equipped)

Making keys (almost) obsolete.

Unlock and lock the vehicle doors and tailgate without using the remote control – just keep it in your pocket or purse.



- 1 Unlocking: Grab the door handle and pull.
- 2 Locking: Touch the ridged area on the handle with your finger until the vehicle is locked.

Tip: Close your windows from the outside by keeping your finger on the ridged area until all windows and the moonroof are closed.

 Note: Remote control can still be used. For proper operation, keep remote control and mobile phone apart. ◀

Tailgate

A feature you'll get a kick out of.

There are many ways to open the tailgate, including hands-free – convenient if your arms are loaded with bags.

- ▷ Using the remote control to open: Hold  button for one second.



- ▷ On the tailgate: Press button (see arrow).
- ▷ To open from inside: Press the  button on the driver's door. If the vehicle is


locked, selector lever position P must be engaged.

To close:

- ▷ To close from inside: Pull and hold the  button on the driver's door until the tailgate closes. If you let go, the tailgate will stop.



- ▷ Press the  button on the inside of the tailgate. Pressing the button again stops the motion.
- ▷ Press the  button to close the tailgate and lock vehicle (if equipped).



Using Comfort Access:

- ▷ Have your key on you.
- ▷ Stand about an arm's length behind the car, in front of the license plate.
- ▷ Kick your foot forwards & backwards under the bumper in one quick movement.
- ▷ The taillights will flash and the trunk will either open or close.


 Note: Be careful to stand back when tailgate opens. Be sure to keep the remote control on you. For proper operation, keep remote control and mobile phone apart. ◀

Adjusting and controlling

Seats

Personalizing the seat of power.

Your power seats can easily be adjusted to provide comfortable support. Simply use the seat-shaped buttons along the outside edge of your seat bottom to achieve the perfect position – then use one of the seat and mirror memory buttons to lock in your settings.



- 1 Memory buttons: See later in this section.
- 2 Backrest width (available on sport seats): Press left/right side to adjust backrest wings in/out.
- 3 Lumbar support (available with Premium Package): Press left/right side to increase/decrease back support curve; press top/bottom to raise/lower the vertical position of the support curve.
- 4 Backrest tilt: Tilt top of the button left/right to tilt backrest forward/rearward.
- 5 Seat position: Keeping button horizontal to the ground, slide button left/right to move seat forward/rearward, and up/down to raise/lower seat. Move left side of button up/down to tilt seat front up/down.

Set it and forget it.



To store your preferred power seat position:

1. Turn on the ignition.
2. Set your preferred seating position and adjust mirrors accordingly.
3. Press SET button; the red glowing button indicates readiness.
4. Press memory button 1 or 2. A confirmation sound signals that storing is completed; the LED goes out as well.



Note: Memory buttons do not store lumbar support settings or backrest width (if equipped). ◀

Three routes to comfort.

Your preferred seating and mirror positions can be recalled three different ways.

One method uses your personal remote control:


- ▶ Each remote control stores the last driver's settings and automatically returns the seat and exterior mirrors to those positions when the key is detected near the vehicle. This function works best when only one key is in the car. To activate, you need to select the "Last seat position auto" via the iDrive under "Settings" and "Doors/Key". This is only necessary one time before the first use.

Two methods use your memory button:

- From outside the vehicle while ignition is still off, simply press the memory button with your stored settings and the seat and mirrors will adjust as stored.
- If you are already seated, press and hold the memory button until movement is completed. This safety feature ensures the seat will not move the occupant if a button is accidentally pressed. Releasing the button will stop movement.

Head restraint adjustment.

BMW head restraints are specially designed to help protect against whiplash in the event of an accident. They can be easily raised and lowered to the optimal height for your comfort.




- To lower: Press and hold the button (1) while pushing the head restraint down to your desired position.
- To raise: Pull the head restraint up to your desired position.
- To remove: Pull the head restraint up as far as possible. Then press and hold the button (1) while pulling the head restraint out completely.

▶ Note: Use pressure when raising or lowering the head restraint. When using the button (1), press it in horizontally and hold it firmly. Only remove head restraint when seat is not used. ◀

Folding rear seats.

- For flat cargo area: Grab the flaps inside the vehicle and pull to fold the seats. For maximum flexibility, every seat can be folded separately.
- For cargo position: Bring the folded seat in an upright position. This position allows you to carry large boxes in the trunk.




- Seating position: Grab and pull the flaps to unlock the seats; push seats from cargo into seating position.

▶ Note: Make sure the seat area is clear before folding. ◀

Lights

See and be seen.

Light switches include:



- 1 Front foglights. Press to switch on/off.*
- 2 Switch on Automatic headlight control. (Low beams automatically turn on/off.) A green headlight symbol appears in the instrument cluster if the lights are on (recommended setting).
- 3 Switch off lights. (Daytime running lights stay on.)

- 4 Switch on Parking lights.**
- 5 Switch on Low beams.
- 6 Dial to adjust instrument lighting. (Parking lights or Low beams must be on.)

* The main switch must not be in the “off” (3) position or Parking lights (4) position.

** Do not use for extended periods with the engine turned off, as this drains the battery.

 **Note:** To use the optional High Beam Assistant, use the lower button on the left stalk behind the steering wheel. The main switch must be either in position 1 or 4 to use the Assistant. ◀

Adaptive LED Headlights: Based on your steering input and other parameters, Adaptive Headlights automatically turn to follow road curves. Bright, daylight-like LED light illuminates your path for optimum visibility. In tight curves, the fog light on the side of the turn also switches on for added visibility.

 **Note:** Various lighting settings can be changed via iDrive. Select MENU > Settings > Lighting. ◀


Wipers

Make it a clean sweep.

The windshield wiper stalk is at the 3 o'clock position behind the steering wheel.

Windshield washing: Pull the stalk toward you and then release to activate washers.

Windshield wiping:




Press the lever up until the desired position is reached.


- ▷ Resting position of the wipers, position 0.
- ▷ Intermittent operation or rain sensor, position 1.
- ▷ Normal wiper speed, position 2.
- ▷ Fast wiper speed, position 3.

Interval mode or rain sensor:

1. Press the lever up once from its standard position. Wiping is started.
2. The LED in the wiper lever is illuminated.
3. Turn the thumbwheel to adjust the frequency or sensitivity of the rain sensor.



- ▷ Up: short interval or high sensitivity of the rain sensor.
- ▷ Down: long interval or low sensitivity of the rain sensor.



Rear window wiping:

Turn the outer switch upward.

- Resting position of the wiper, position 0.
- Intermittent mode, arrow 1.

Rear window washing:

- In resting position: turn the switch downward, arrow 3. The switch automatically returns to its resting position when released.
- In intermittent mode: turn the switch further, arrow 2. The switch automatically returns to its intermittent position when released.

 Note: In a car wash, be sure to deactivate the rain sensor to avoid wiper damage. ◀

Heated Steering Wheel Button

You won't need winter gloves (if equipped).



To warm the steering wheel, press the button on the left side of the steering wheel. When ac-

tivated, an LED lights up and a pop-up in the instrument cluster appears momentarily.

Active Cruise Control (if equipped)

Give your foot a rest.

Cruise control can increase your fuel efficiency and your comfort on long drives.

Buttons on the steering wheel:



Cruise control on/off.



Store/maintain speed.



Continue cruise control with the last setting.



Reduce distance.



Increase distance.



Rocker switch. Set speed.



Note: For detailed information about the Active Cruise Control system refer to the Owner's Manual. ◀

Bluetooth

Connect wirelessly to your world.

Pair your compatible mobile phone with your vehicle to enjoy the enhanced safety of hands-free calling.

To pair your mobile phone:

1. Put your phone in pairing mode by activating Bluetooth on your device.
2. Using the iDrive menu, select: Settings > Connections > Bluetooth® (phone) > Add new device.

3. Your vehicle's Bluetooth name will appear in the iDrive Control Display.
4. Use your phone to search for Bluetooth devices. Your vehicle's Bluetooth name should appear in your phone's display. Select it.
5. Both your phone and the iDrive display will display a passkey.
6. Confirm that the passkeys match, then select "OK" on the iDrive to confirm your phone.
7. Select at least one function you'll use on your phone. When done, select "OK". If you only select "Phone", you can only make calls with your connected device. Check "Media" to be able to play music from your device.
8. Confirm messages on your phone.
9. Your phone should appear at the top of the mobile phone list to confirm the pairing was a success.



Note: To make sure your phone is compatible, visit bmwusa.com/Bluetooth. Sometimes new phones require a software update of your iDrive. If you experience problems with your phone, check online for an update: BMW.com/update. Have your Vehicle Identification Number (short VIN) handy (can be found in registration papers). ◀

Climate

Automatic climate control – don't sweat the driving.

Automatically keep the cabin comfortable while you drive. When activated, the system quickly achieves the desired temperature by automatically controlling airflow, distribution and temperature.



- ▷ To activate: Press AUTO button; the LED in the button lights up. Select desired temperature by rotating the knobs. Press SYNC to align left and right side temperature simultaneously.
- ▷ To turn off: Press OFF.
- ▷ To cool vehicle quickly: Press MAX A/C button, which sets system to the lowest temperature, maximum air flow and recirculated air mode. Keep engine running.
- ▷ To defrost the windshields: Press to heat front windshield and to defrost rear window.
- ▷ To keep outside odors or pollutants from entering the car: Press to select between A (Automatic) and M (Manual) recirculation mode.
 - ▷ LEDs off: Outside air flows in.
 - ▷ Left LED on: Whenever a sensor detects pollutants, it automatically shuts off outside air. When pollutants are no longer detected, it flows in outside air again.
 - ▷ Right LED on: Outside air is permanently blocked from entering the vehicle.
 - ▷ At low temperatures: Recirculated air mode turns off after a period of time to keep windows from fogging.


Tip: Leave the A/C on even during cold weather conditions, as it helps to heat the cabin faster and prevents the windows from fogging.



Note: The side mirrors are heated automatically while the engine runs. There are separate temperature and air distribution controls for both left- and right-seat occupants. The settings are stored in the remote control. ◀

Connectivity

Wired or wireless – it's up to you.




The USB and AUX interface is located under the center armrest. Press the MEDIA/AUDIO button to select the connected media device.

iDrive

A new spin (and slide and push) on handling dozens of functions.

The iDrive controller replaces dashboard buttons for adjusting features and functions. Part of the iDrive system, it is used to select menu items. Its location on the center console allows intuitive operation without looking down while driving.



- 1 Control Display, positioned for easy readability, is used along with the iDrive controller.
- 2 iDrive controller can be rotated; slid left or right, and sometimes forward or backward; and pressed down to make a selection. If equipped with Technology Package, you can write Navigation system addresses directly on the iDrive touchpad controller.

The buttons next to the iDrive controller – each distinctively shaped for touch recognition – provide shortcuts to different menus, depending on equipped features:

- ▷ MENU – Main menu
- ▷ RADIO – Radio menu
- ▷ MEDIA – CD/Multimedia menu
- ▷ NAV – Navigation menu
- ▷ TEL – Telephone menu
- ▷ BACK – Previous panel
- ▷ OPTION – Options menu



Note: Available shortcuts and input options depend on the vehicle's equipped features. ◀

Programmable Memory Buttons

Your entertainment. Your information. Your way.

Use the eight programmable memory buttons to store favorite radio stations, iDrive menu

screens, phone numbers or navigation destinations.



- ▶ To store information:
 - ▶ Use iDrive to access and then highlight the function or information to be stored.
 - ▶ Press the desired memory button for about three seconds until you hear a confirmation sound.



- ▶ To access information: Press the memory button.

- ▶ To display button assignments and information:
 - ▶ Touch button to display the assigned function.
 - ▶ Touch button for a longer time to display the entire address.



Note: Each remote control holds its own personalized settings. ◀

BMW Connected App

Your Personal Mobility Companion.



The BMW Connected App offers a whole new way to interface with your new BMW, in and out of the car.

Download the "BMW Connected" App from the Apple App Store or from Google Play.

App Highlights include:

- ▶ Send destinations to the car from other apps, texts, and web.
- ▶ Book a service appointment from your smartphone.
- ▶ "Time-to-leave" notifications on your smartphone or Apple Watch to keep you on-time.
- ▶ Remotely lock/unlock the doors, flash the lights, sound the horn, and start ventilation.
- ▶ Keep family and friends informed of your arrival time when you're on the way.
- ▶ Simple access on a map to the last known position of your BMW.

Apple CarPlay™*

CarPlay™ your way.



1. Navigate through iDrive to: My vehicle > iDrive settings > Mobile devices > Connect new device.
2. Select "Apple CarPlay™" to initiate CarPlay™ compatible device.
3. Activate Bluetooth and WiFi on your CarPlay™ compatible device and search for your BMW. The name of your BMW is displayed in iDrive.
4. Select your BMW on your mobile phone to pair.
5. Both your phone and iDrive will display a passkey. Confirm that the passkeys match, then select "OK" on the iDrive to confirm your phone.
6. Your phone should appear at the top of the mobile device list to confirm the pairing was a success.

CarPlay™ is now accessible wirelessly through the iDrive headunit.

Tip: You can utilize both touchscreen and iDrive controller in order to intuitively navigate through the CarPlay™ Menu.

*Apple CarPlay™ is a trademark of Apple Inc.

Apple® is responsible for all content and functionality displayed in the vehicle via Apple CarPlay™.

For information including device and system compatibility, go to <https://www.apple.com/ios/carplay/>.

For information on privacy and the use of vehicle data, go to <http://apple.com/privacy/privacy-policy/> or <http://www.bmwusa.com/Standard/Content/PrivacyPolicy/>.

Audio System

Now is the time to play favorites.

- ▶ Press MEDIA button on iDrive controller twice to show a list of available entertainment sources.
- ▶ Starting from the Main menu select Media/Radio to see the full list of all possible entertainment sources.

The list shows items for:

- ▶ Presets (Favorites list of FM, AM and SAT radio (if equipped) stations).
- ▶ Currently and last connected devices via Bluetooth®, USB, etc.
- ▶ Music collection (Imported music from CDs and USB sticks on the 20GB internal hard drive).
- ▶ CD/DVD.
- ▶ Apps (if a supported device is connected, see Phone pairing for instructions).

Store your favorite FM, AM and Satellite channels (if equipped) in one Preset list for easy access.

To store a radio station:

- ▶ Select FM, AM or Satellite radio (if equipped) from the list of media devices.

- ▶ Select the station you would like to save.
- ▶ Press the iDrive controller or touch the ☆+ symbol.
- ▶ Select a position for the station via the controller or touch the desired position to store the radio station in the Presets list.

Tip: While in Presets mode you can scroll through your Presets list with the thumbwheel on the right side of the steering wheel. This will appear in either the Head-up Display (if equipped) or the instrument cluster. To select a station, press the thumbwheel.

Tip: Store your favorite station on a memory button by highlighting it and pressing the button until you hear a confirmation sound.



Note: Your Preset Buttons and radio stations are stored in your remote control. If you use a different remote control, different Preset stations will appear. ◀

Navigation (if equipped)

The world is at your fingertips.

To start navigation:

- ▶ Press the NAV button on the iDrive controller.
- ▶ Press the Voice Control  button (if equipped) and say "Navigation". (For details, see the "Voice Control" section.)

Multiple ways to enter addresses include:

- ▶ Choose "Enter address" and enter all necessary information.
- ▶ If you are looking for a specific store, monument or Points of Interest (POI), use either the online or integrated POI search. The online search works like Google Maps: simply type in what you are looking for and a list of locations is displayed on the right. Tilt the knob to the right to enter the list and choose your desired location.
- ▶ You can also navigate to locations in your address book or choose from your previ-

ous destinations. Then, select “Accept destination” and “Start guidance”.

To view the map, start from “Navigation”, then select “Map”. You will see traffic, routes, obstructions, and a function bar for personalizing how information is conveyed. Also, set the map mode, scale, split-screen (to display additional information) and other functions, such as traffic bulletins and Advanced Real Time Traffic Information (ARTTI) to help avoid traffic jams.

Tip: Store destinations on your memory buttons. Simply press the desired button for about three seconds before you press “Start guidance” in iDrive.



Note: For more information, refer to the “Navigation, Entertainment, Communication. Owner’s Manual”. ◀

Voice Control (if equipped)

Your word is BMW’s command.

The BMW Voice Control System understands your spoken commands. It’s the best way to control many non-driving functions, such as phone and navigation, while keeping your eyes on the road.

- ▶ To start: Press the  button on the steering wheel and you will hear an activation chime. Speak right after the chime at a constant pace. If further dialog steps are necessary, the system will ask for input. When the system displays  (with sound waves), it is ready for your input. When  is displayed, the system is processing and does not accept input.

Commonly used commands are displayed in a pop-up at the top of the center display.

Here are some tips for the most commonly used commands that are accessible from any menu:

- ▶ “Call John Smith”: Just say “Call” combined with a name from your contact book.

You will be asked for the type of number in the next dialog step, e.g., “mobile”.

- ▶ “Dial number”: Just say “Dial number”. After the system response, say the number in single digits
- ▶ “Go home”: After you have saved a home address in the system, this handy command will always lead you back home.



Note: To save a home address, please follow the steps in the iDrive menu: Menu > [Office] > [Contacts] > [Home] > [New Address] > (enter address) > choose [Home] or [Business] > [Store contact in vehicle]. ◀

- ▶ “Navigate to 300 Chestnut Ridge Road, Woodcliff Lake, New Jersey”: The address must be spoken in the specific order of building number, street, city and state, with a minimum of city and state.
- ▶ “Online Search”: This command will lead you to the online-based Points of Interest (POI) search dialogue.

You can say “Help”, which leads you to a general explanation of the voice control system.

The system works best in a closed environment, i.e., with windows and moonroof closed.

If you have an iPhone paired as your primary phone to the vehicle, pressing the  button for about one second will activate SIRI Eyes Free.

Get going

Starting/Stopping the Engine

The power of one touch.



- ▶ Turn on the electronics: Press the Start/Stop button once, with your foot off the brake pedal, to activate all electronics, including ventilation.
- ▶ Turn on the engine: Press the Start/Stop button once with your foot on the brake pedal.
- ▶ Turn off the engine: Press the Start/Stop button.
- ▶ Turn off the electronics: After turning off the engine, press the Start/Stop button again or lock the vehicle from the outside.

Auto Start/Stop

This vehicle stops for fuel efficiency.



To maximize fuel efficiency and minimize emissions, your BMW is equipped with the Auto Start/Stop function. Under certain conditions, this feature switches off the engine when you stop, and restarts it when you release the brake pedal. You can disable this feature by pressing the Auto Start/Stop button, located to the left of the Start/Stop button. An LED indicates when the system is disabled.




Note: When switched off, the vehicle retains the last Auto Start/Stop function setting. ◀

Shifting Gears and Driving Modes


Automatic transmission – directing the power.

Depending on the vehicle equipment, a transmission with either a latching selector lever or a tap-operated selector lever is installed.



Engaging selector lever positions with a latching selector lever:

- ▶ To release the selector lever lock: with the brake pedal depressed, press the button on the front of the selector lever.
- ▶ Move the selector lever into the desired position.



Engaging selector lever positions with a tap-operated selector lever:

- ▶ Press and hold the button to release the selector lever lock.

- ▶ With the driver's safety belt fastened, briefly push the selector lever in the desired direction, past a resistance point, if needed. The selector lever automatically returns to the center position when released.



To engage the parking position press button P on the selector lever.

▶ Note: In car washes, shift into Neutral or follow the posted instructions in the car wash. ◀

▶ Note: Make sure vehicle is in Park before exiting; otherwise, it may roll. Select Park only when vehicle is stopped; this blocks the drive wheels. See Owner's Manual for all instances when Park is engaged automatically. ◀

Personalize your BMW's driving character.

To switch between your new X1's different driving modes, use the button next to the gear-shift lever until SPORT Mode is displayed in the instrument cluster.

SPORT Mode

- ▶ Optimizes steering assistance based on driving speed.
- ▶ More direct throttle response.
- ▶ Deactivates Auto Start-Stop function.
- ▶ More aggressive shift logic.
- ▶ Increases fuel consumption.

Comfort Mode


- ▶ Well-balanced road feedback.
- ▶ Good fuel economy.

ECO PRO mode.


- ▶ Best fuel economy.
- ▶ Activates Auto Start-Stop function.
- ▶ More conservative shift logic, eases throttle response, adds coasting function.
- ▶ Regulates heating, cooling and ventilation to minimize power consumption.
- ▶ Tips for improved driving efficiency are shown in the iDrive Display; the instrument cluster shows the increased mileage per tank.

Three-point Rear Center Seatbelt

The rear middle seat features a threepoint belt for increased safety.



Buckle up: Sitting in the seat, grab and pull the belt with two buckle tongues from the roof. Insert the smaller tongue into the buckle on your left side (arrow 1). Then, pull the seatbelt across to your right side and insert the larger tongue into the buckle (arrow 2).



Unbuckling: First, release the buckle tongue by pressing the red button. Then, use that buckle tongue (arrow 1) to release the belt on your left side by inserting it into the red slot in the buckle (arrow 2).



Note: Be careful as the belt retracts to the roof. ◀

Upholstery

Long-lasting quality. Timeless beauty.

BMW selects the highest quality materials for both the upholstery and interior. Naturally, continued use will subject any interior surface to wear and dirt. To maintain your interior's beauty, we recommend you use BMW branded care and natural care items specially formulated for use on leather, fabrics, plastics and all synthetic surfaces.

Center Console Storage

A place for everything.

BMW has engineered intelligent storage into the center console. Additional storage space can be found in the glove box and large door pockets. There is also a storage compartment on the left side of the steering wheel plus increased storage versatility in the cargo area.

Additional information

BMW Driver's Guide App



The Owner's Manual is available as an app.

Additional information on the Internet:

www.bmw.com/bmw_drivers_guide

BMW Genius

BMW Genius Everywhere.

A holistic approach to understanding your BMW:

- ▷ Meet with a BMW Genius at one of our many BMW Centers.
- ▷ Contact the BMW Genius Hotline at +1-844-4GENIUS or at BMWGenius@BMWUSA.com.
- ▷ Install and use the BMW Genius App on your smartphone.
- ▷ Install and use the BMW Driver's Guide App for a virtual Owner's Manual.
- ▷ Go to YouTube.com/BMWUSA, scroll down and select "BMW Genius How to Videos and Owners Tips".

Vehicle Equipment

Standard, country-specific and optional equipment that is offered in the model series is described in this Quick Reference. Therefore, equipment is also described that is not available in a vehicle, e.g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

More about BMW



The Ultimate Driving
Machine®

bmwusa.com

01402982641 ue

