

Contents

A-Z

Quick Reference
Card.



The Ultimate Driving
Machine®



THE BMW X3. QUICK REFERENCE.

BMW EfficientDynamics
Less emissions. More driving pleasure.

© 2017 Bayerische Motoren Werke
Aktiengesellschaft
Munich, Germany
Reprinting, including excerpts, only with the written
consent of BMW AG, Munich.
US English VI/2017,
Printed on environmentally friendly paper, bleached
without chlorine, suitable for recycling.

Contents

X3


6	Entering your vehicle
6	Remote Control
6	Central Locking
6	Comfort Access
7	Trunk
9	Adjusting and controlling
9	Seats Controls with Touch Preview
10	Lights
10	Wipers
11	Steering Wheel Adjustment
11	Cruise Control
12	Phone Pairing
12	Climate Control
13	iDrive
14	Programmable Memory Buttons
14	Connectivity and Charging
15	Audio System
16	Apple CarPlay™*
16	BMW Connected App
17	Navigation (if equipped)
17	Voice Control
19	Get going
19	Engine and Driving Modes
21	Additional information
21	BMW Driver's Guide App
21	BMW Genius
21	Vehicle Equipment

Entering your vehicle

Remote Control

A world of control in the palm of your hand.

The remote control has several useful functions:



- 1 Unlocking: Press to unlock driver's door. Press again to unlock all doors.*
Also: Press and hold to open windows and moonroof.
- 2 Locking: Press to lock. Press twice in quick succession in order to deactivate interior motion detector, the red indicator on the interior mirror will become solid for several seconds.
- 3 Trunk: Hold one second to open.
- 4 Panic mode: Hold three seconds to sound.
* Unless programmed to open all doors with one press.

 Note: Each remote also stores many preferred settings, such as seat/mirror position, climate, radio stations, etc., so be sure to use your personal remote. For proper operation, keep remote control and mobile phone apart. Do not lock vehicle using remote when people are inside.◀

Central Locking

Lock/unlock the entire vehicle with one press.

Lock and unlock all doors and the trunk using these buttons, conveniently located on the front doors by the armrest.




- ▷ Locking: Press  to lock all doors and trunk.
- ▷ Unlocking: Press  to unlock all doors and trunk.

 Note: When button is used to lock vehicle, fuel filler flap remains unlocked and alarm system is not armed.◀

Comfort Access

Making keys (almost) obsolete.

Unlock and lock the vehicle doors and trunk without using the remote control – simply keep it inside a pocket or purse.



- 1 Unlocking: Grab the door handle and pull.
- 2 Locking: Touch the ridged area on the handle for one second.


Tip: You can close windows and moonroof by keeping your finger on the ridged area.

 Note: Remote control can still be used. For proper operation, keep remote control and mobile phone apart. ◀


Trunk

A helping hand when yours are full.

There are many ways to open the trunk, including hands-free – convenient if your arms are loaded with bags.




- ▶ Using Comfort Access (if equipped): Stand in the middle of the rear license plate and move your foot under the rear bumper in and out in one quick movement. The turn signals will flash and the trunk will open.
- ▶ Using the key fob to open: Press  until the trunk lid opens.



- ▶ On the trunk lid: Press button (see arrow).
- ▶ From inside: Press  in the driver's door pocket area.

To close (if equipped with power trunk-lid):

- ▶ Using comfort access: Repeat the kicking motion to close.



- ▶ Buttons in trunk:
 - 1: Closes trunk lid but does not lock vehicle.
 - 2: Closes trunk lid and locks entire vehicle.



From inside: Pull  lever in the driver's door pocket area toward you until trunk is closed completely. (For safety reasons, you have to hold button.)




Note: Be careful to stand back when trunk lid opens. Be sure to keep the key fob on you – not locked in your vehicle. For proper operation, keep key fob and mobile phone apart. ◀

Adjusting and controlling

Seats Controls with Touch Preview

World-class comfort (if equipped).

Your power seats can easily be adjusted to offer comfortable support. Simply use the controls along the outside edge of your seat bottom to achieve the perfect position – then use one of the seat memory buttons located on the door to store your settings.



- 1 Backrest width: Press forward/rearward to adjust backrest wings in/out.
- 2 Seat position: Keeping button horizontal to the ground, slide button forward/rearward to move seat accordingly, and up/down to raise/lower seat. Move forward side of button up/down to tilt seat front up/down.
- 3 Backrest adjustment: Tilt top of the button forward/rearward to tilt backrest accordingly.
- 4 Lumbar support: Press forward/rearward to increase/decrease back support curve; press top/bottom to raise/lower the vertical position of the support curve.

 **Note:** Touch the buttons gently to see available setting options on the iDrive display. The pop-up closes after five seconds. You can deactivate the preview display in the seat settings menu.◀

We'll save your seat.



Adjust the seat, steering wheel and the outside mirrors, then:

1. Press SET located on the door, which turns on the LED.
2. Press memory button 1 or 2. When the LED disappears and a confirmation signal sounds, your settings are stored on that button.



Note: Memory buttons do not store lumbar support settings.◀

Recalling saved seating position – three routes to comfort.

Your preferred seating, steering wheel position and mirror positions can be recalled three different ways.

By using your personal key fob:

- ▶ Each key fob stores the last driver's settings and automatically returns the seat and exterior mirrors to those positions. Before doing so, you need to select "Last seat position automatic" via the iDrive under "My Vehicle" > "Driver Profiles" then select the current or other driver.

By using your memory button (1 or 2, wherever your seat settings are stored):

- ▶ **While parked:** When the engine is not running, briefly press your memory button.

 **Note:** Using the memory function while driving can lead to unexpected seat or steering wheel movements. Vehicle control could be lost. There is a risk of an accident. Only retrieve the Controls Settings memory function when the vehicle is stationary. ◀



Right roadside parking light



Left roadside parking light

Lights

See and be seen.

The lights can be adjusted with the button panel to the left of the steering wheel.



Tip: Keep the switch in the “Auto” position for optimal lighting at all times.

Light switches include:



Front fog lights



Lights off
Daytime running lights



Parking lights



Automatic headlight control
Adaptive Light Control



Low beams




Instrument lighting

Wipers

Rain sensing ensures a clean sweep.

The windshield wiper stalk is at the three o'clock position behind the steering wheel.

- ▶ **Windshield washing:** Pull the stalk toward you to spray washer fluid, then release to let wipers clean the windshield.




Automatic mode:

- ▶ Move stalk up to position 1. A green LED on the stalk will indicate that the automatic mode is active. The wiper speed adjusts from off to maximum based on rain intensity.
- ▶ Use thumbwheel to adjust sensitivity.

Manual wiping:

- ▶ **Single wipe:** Press stalk down from position 0.
- ▶ **Normal speed:** Move stalk up to position 2, move down to position 0 to turn off.
- ▶ **High speed:** Move stalk up to position 3 to turn on; move down to position 2 to return to normal speed, or to position 0 to turn off.




Rear window washing:

- ▶ While the wipers are activated: Turn the switch past the resistance point (arrow 2).
- ▶ When wipers are not activated: Turn the switch as indicated (arrow 3).

 **Note:** The stalk always returns to the default position. In a car wash, be sure to deactivate the rain sensor to avoid wiper damage. ◀

Steering Wheel Adjustment

Adjust for total comfort.



1. Fold the lever down.
2. Move the steering wheel to the preferred height and angle to suit your seating position.
3. Fold the lever back up.

Cruise Control

Give your foot a rest.

Cruise control can increase your fuel efficiency and your comfort on long drives. The function buttons are located on the left side of the steering wheel.

Press  to activate cruise control. The current speed will be maintained. Press again to turn cruise control off.

Rocker switch increases/decreases set speed:

- ▶ By 1 mph: move up/down to the point of resistance.
- ▶ By 5 mph: move up/down past the point of resistance.

Press RES/CNCL to resume set speed or to interrupt.

Press SET to set cruise control to current vehicle speed when cruise control is in standby.

If equipped with Active Cruise Control with Stop & Go, it also uses radar to keep your pre-selected distance to the vehicle ahead and bring your vehicle to a complete stop, if needed — a useful feature in stop-and-go traffic. Also included is Collision Mitigation: if necessary, the brakes quickly engage.

 **Note:** If you came to a complete stop for more than five seconds, tip the throttle to resume forward motion. ◀

If your X3 is equipped with Active Lane Keeping Assistant:

- ▶ Press  to activate the assistant. This feature keeps the vehicle in the lane as long as you keep your hands on the steering wheel and exterior conditions are met.
- ▶ Press  to adjust distance to vehicle ahead. After smallest distance, the next button press will adjust to the longest distance.

 **Note:** Braking interrupts set speeds. ◀



Note: Without Active Lane Keeping Assistant equipped the buttons are slightly different. ◀

Phone Pairing

Connect wirelessly to your world.

To pair your mobile phone via Bluetooth®:

1. Press the  Connected Drive button to the right of the seven memory buttons > Select Manage Mobile devices > Connect new device.

Then select one function.

Tip: Select “Bluetooth® audio” to use phone as both media device and telephone.

2. Activate Bluetooth and search for your BMW on your phone. The name of your X3 is displayed in iDrive.
3. Select your BMW on your mobile phone to pair.
4. Both your phone and iDrive will display a passkey. Confirm that the passkeys match, then select “OK” on the iDrive to confirm your phone.
5. Your phone should appear at the top of the mobile phone list to confirm the pairing was a success.

Tip: Sometimes new phones require a software update of your iDrive. If you experience problems with your phone, check online for an update: BMW.com/update. Have your Vehicle Identification Number (VIN) handy (found in your registration papers).

Tip: If you want to keep a call when exiting your vehicle, click on the “Headset” option on your phone to deactivate the link to the car.

Tip: If you enter the vehicle, the call will automatically continue via the hands-free system.



Note: To make sure your phone is compatible, visit bmwusa.com/Bluetooth. For further details, refer to your mobile phone owner's manual. ◀

Climate Control

Inside it's all about comfort.

Keep the cabin a comfortable temperature automatically while you drive.



- ▷ To activate: Press the AUTO button and select desired temperature.
The system will quickly achieve it by automatically controlling air flow, distribution and temperature.
- ▷ To turn off: Press the “Lower fan speed” symbol button until it is turned off.
- ▷ To cool vehicle quickly: Press the MAX A/C button, which sets system to the lowest temperature, maximum airflow and recirculated air mode. Keep engine running.
- ▷ To defrost the windshield: Press the MAX  button. You can adjust airflow.
- ▷ To defrost rear window: Press the  button. The defroster will switch off automatically after a period of time.
- ▷ To keep outside odors or pollutants from entering the car: Press the  button to select mode.
 - ▷ LED off: Outside air flows in.*
 - ▷ LED on: Outside air is blocked from entering the vehicle.

- ▶ At low temperatures: Recirculated air mode turns off after a period of time to keep windows from fogging.

*Permanent Automatic recirculation mode can be activated in the iDrive menu. Select “Automatic air recirculation” under: My Vehicle > Vehicle settings > Climate functions > Air quality. Whenever a sensor detects pollutants, it automatically blocks outside air. When no longer detected, outside air flows in again.


Touch the SYNC button to keep the passenger-side temperature the same as the driver-side setting.

 Note: The side mirrors are always heated when the engine runs and the vehicle is not in ECO PRO. ◀

iDrive

The best of both worlds.

The iDrive system can now be controlled in two intuitive ways. You can use the familiar iDrive Controller on the center console to control many vehicle functions without having to look down while driving. Or use the touchscreen for intuitive operation – similar to using a tablet or smartphone. Everything you can select using the controller can be accessed by touch, and vice versa.



- 1 Touchscreen, positioned for easy use.
- 2 iDrive Controller can be rotated; slid left or right, forward or backward; and pressed down to make a selection. For address and

phone number input, you can use your fingertip to write letters or numbers directly on the iDrive touchpad controller.

 Note: You can switch between the iDrive Controller and touch commands any-time. The keyboard layout will automatically adjust to the preferred entry method as soon as you touch the screen or use the iDrive Controller. ◀

The buttons next to the iDrive Controller provide shortcuts to different menus:



- ▶ **MENU:** Press once for Main menu; press again to see a list of all menu items of the main menu.
- ▶ **MEDIA:** Press once for Multimedia menu; press again to see available media sources.
- ▶ **NAV:** Guides you directly to destination input menu.
- ▶ **COM:** Opens communication menu.
- ▶ **MAP:** Press once to open Navigation map; press again to hear voice guidance instructions.
- ▶ **BACK:** Press once for previous panel or deleting letter/number input; press and hold for menus used last.
- ▶ **OPTION:** Options menu.


To return to previous menus, choose one of the following:

- ▶ Tilt the knob to the left (pressing down on the middle of the virtual controller).
- ▶ Press BACK button.

Programmable Memory Buttons

Your entertainment. Your information. Your way.

Use the seven programmable memory buttons to store your favorite radio stations, iDrive menu screens, phone numbers or navigation destinations.



- ▶ To store information:
 - ▶ Use iDrive to access and then highlight the function or information to be stored.
 - ▶ Press one of the memory buttons for more than two seconds until you hear a confirmation signal.
- ▶ To access information: Press the memory button. (For example, this will dial a phone number.)
- ▶ To display button assignments and information: Touch button slightly with a bare finger; the button assignment will appear at the top edge of the iDrive screen.

1...7 The eighth button is a shortcut to ConnectedDrive features.

To replace an entry, simply assign a new shortcut to the key.

 Note: These settings are also stored in the key fob currently in use. ◀

Connectivity and Charging

Wired or wireless – it's up to you.

Your new X3 offers various possibilities to connect and charge your mobile device.



Via USB:

USB ports are conveniently located in the center armrest and in front of the cupholders. Both can be used to charge connected devices and play music through them. Additionally, you may play music stored on a USB thumb drive.

You can switch via iDrive through the connected media devices. Press the MEDIA button twice to see a list of accessible devices.

Qi Wireless Charging (if equipped):

To use this feature your mobile phone needs to fulfill the Qi standard for wireless inductive charging either integrated within the device or by an accessory case available via BMW Parts & Accessories.



The charging tray is located to the front of driver and passenger cupholders. To charge: Place your phone face up with its back to the charging surface.

Tip: You can set an alert when your mobile phone is still in the pocket and you are about to exit the vehicle. Go to **My Vehicle > iDrive settings > Wireless charging tray > Forgotten cell phone alert**.

Connect to the Wi-Fi hotspot:

When first used, make sure that the hotspot feature is activated: Press the **Connected Drive** button to the right of the seven memory buttons > **Select Manage Mobile devices > Connect new device > Settings > Internet hotspot** is checked. Connecting new devices is as easy as in your home's Wi-Fi network. To do so, proceed as follows:

- ▶ Press the **Connected Drive** button to the right of the seven memory buttons > **Select Manage Mobile devices > Connect new device > Internet hotspot**. The name and passkey of the network are shown.
- ▶ Activate Wi-Fi on your mobile phone and search for networks.
- ▶ Connect to your car's Wi-Fi by entering and confirming the passkey.



Note: With the first Internet usage via the WLAN hotspot, data must be purchased from a service provider. All devices connected via the WLAN hotspot use this data. ◀

Check the **Phone Pairing** section for pairing a mobile device via Bluetooth®.

Audio System

Now is the time to play favorites.

- ▶ Press **MEDIA** button on iDrive controller twice to show a list of available entertainment sources.
- ▶ Starting from the **Main** menu select **Media/Radio** to see the full list of all possible entertainment sources.

The list shows items for:

- ▶ **Presets** (Favorites list of FM, AM and SAT radio stations).
- ▶ **Currently and last connected devices** via Bluetooth®, USB, etc.
- ▶ **Music collection** (Imported music from CDs and USB sticks on the internal hard drive).
- ▶ **CD/DVD**.
- ▶ **Apps** (if a supported devices is connected, see **Phone pairing** for instructions).

Store your favorite FM, AM and Satellite channels in one **Preset** list for easy access.

To store a radio station:

- ▶ Select FM, AM or Satellite radio from the list of media devices.
- ▶ Select the station you would like to save.
- ▶ Press the iDrive controller or touch the save ★ symbol.
- ▶ Select a position for the station via the controller or touch the desired position to store the radio station in the **Presets** list.

Tip: While in **Presets** mode you can scroll through your **Presets** list with the thumbwheel on the right side of the steering wheel. This will appear in either the **Head-up Display** or the **instrument cluster**.

To select a station, press the thumbwheel.

Tip: Store your favorite station on a memory button by highlighting it and pressing the button until you hear a confirmation sound.



Note: Your Preset and Button radio stations are stored in your key fob. If you use a different key fob, different Preset stations will appear. ◀

Apple CarPlay™*

CarPlay™ your way.



1. Navigate through iDrive to: My vehicle > iDrive settings > Mobile devices > Connect new device.
2. Select "Apple CarPlay™" to initiate CarPlay™ compatible device.
3. Activate Bluetooth and WiFi on your CarPlay™ compatible device and search for your BMW. The name of your BMW is displayed in iDrive.
4. Select your BMW on your mobile phone to pair.
5. Both your phone and iDrive will display a passkey. Confirm that the passkeys match, then select "OK" on the iDrive to confirm your phone.
6. Your phone should appear at the top of the mobile device list to confirm the pairing was a success. CarPlay™ is now accessible wirelessly through the iDrive headunit.

Tip: You can utilize both touchscreen and iDrive controller in order to intuitively navigate through the CarPlay™ Menu.

*Apple CarPlay™ is a trademark of Apple Inc.

Apple® is responsible for all content and functionality displayed in the vehicle via Apple CarPlay™.

For information including device and system compatibility, go to <https://www.apple.com/ios/carplay/>.

For information on privacy and the use of vehicle data, go to <http://apple.com/privacy/>

[privacy-policy/](http://www.bmwusa.com/Standard/Content/PrivacyPolicy/) or <http://www.bmwusa.com/Standard/Content/PrivacyPolicy/>.

BMW Connected App

Your Personal Mobility Companion.



The BMW Connected App offers a whole new way to interface with your new BMW, in and out of the car.

Download the "BMW Connected" App from the Apple App Store or from Google Play. App Highlights include:

- ▶ Send destinations to the car from other apps, texts, and web.
- ▶ Book a service appointment from your smartphone.
- ▶ "Time-to-leave" notifications on your smartphone or Apple Watch to keep you on-time.
- ▶ Remotely lock/unlock the doors, flash the lights, sound the horn, and start ventilation.
- ▶ Keep family and friends informed of your arrival time when you're on the way.
- ▶ Simple access on a map to the last known position of your BMW.
- ▶ Use the navigation function to find nearby charging stations, and send their locations directly to your vehicle.
- ▶ Set preconditioning, which automatically cools the battery in warm weather and will always ensure a comfortable cabin temperature before your next journey begins.

Take advantage of charging station "Time of Use" rates with the Charge Control feature. (When available from your utility provider, these rates are typically lower than usual rates and often require charging between certain

hours. Check with your utility provider to see if these are available.)

Navigation (if equipped)

The world is at your fingertips.

To enter a new destination:

1. Press the NAV button on the iDrive controller and select an input method:
 - ▷ Select “Enter Address”. Enter the necessary information. As you enter more information, the list of possible entries narrows.
 - ▷ Select “Quick Search” or “Points of Interest” to find special destinations.
 - ▷ Select “Recent destinations” to find previously entered destinations.
2. Press the  button on your steering wheel and say “Enter destination”. You can even directly enter an address or point of interest through Voice Control. For details, check the Voice Control section.

To access the map directly, use the MAP button around the controller. You will see traffic routes, obstructions, and a function bar for personalizing how information is conveyed.

Also set the map view, scale, split screen (to display additional information) and other functions, such as traffic bulletins and Advanced Real Time Traffic Information (ARTTI) to help avoid traffic jams.

Tip: If the Learn route feature in Navigation > Settings > Route settings is activated, your X3 learns that you drive some routes differently than suggested by the Navigation system to adjust the calculated route.

 Note: For more information, refer to the “Navigation, Entertainment and Communication. Owner’s Manual”. ◀

Voice Control

Your word is BMW’s command.

The BMW Voice Control System understands your spoken commands. It’s the best way to control many functions, such as phone and navigation, while keeping your eyes on the road.

- ▷ To start: Press the  button on the steering wheel. After you hear the activation, speak at a constant pace. If further dialog steps are necessary, the system will ask for input. When the system displays the  symbol (with sound waves) in the instrument cluster or iDrive display, it is ready for your input.



 Note: When  is displayed, the system is processing and does not accept input. ◀

Commonly used commands are displayed in a pop-up at the top of the center display. Here are some tips for the common commands accessible from any menu:

- ▷ “Call John Smith on his mobile”.
- ▷ “Dial number”: After the system response, say the number in single digits.
- ▷ “Call my wife/husband”: When first used, the system will guide you through the setup. There are many more shortcuts possible, like mother, brother, boss, etc.
- ▷ “Drive me home”: After you have saved a home address in the system, this handy command will always lead you back home. When first used, the system will ask you for an address.
- ▷ “Navigate to 300 Chestnut Ridge Road, Woodcliff Lake, New Jersey”: The address must be spoken in the specific order: street number, street, city, state, with a minimum of city and state.
- ▷ “Find the next gas station”: This command searches online for the next gas station and provides a list of alternatives.* You can

use this command with various other searches.

▶ Note: You can say "Help", which leads you to a general explanation of the voice control system. ◀



The system works best with windows and moonroof closed.

For iPhone users, press and hold the voice control button for about one second to activate SIRI.

* This service requires an available internet connection.

Get going

Engine and Driving Modes

Effortless authority.

When you enter your vehicle nearly all systems are available. This is a result of new vehicle modes.

- **Awake:** Enter vehicle using the key fob. Engine is not running but electronics are on and nearly all functions are available.
- **Ready:** To start the engine, press the Start/Stop button while keeping your foot on the brake pedal. In this mode you are ready to go.
- **Asleep:** Activated when vehicle is locked from the outside with the engine turned off. Locking switches off all electronic devices.

 **Note:** Car will fall asleep when no action is performed for several minutes but vehicle is still unlocked. However, an active phone call prevents the system from shutting down. ◀



To engage gears:

- **Depress the brake pedal.**
- **D (Drive):** Press and hold the button on the left to release the selector lever lock and pull the lever toward you past the point of resistance.
- **R (Reverse):** Press and hold the button on the left to release the selector lever lock

and push lever forward past the point of resistance.

- **N (Neutral):** Depending on which gear you are currently in, push or pull until you reach the point of resistance, but not beyond.
- **P (Park):** Press the P button on the lever.

AUTO H (Hold) button: When activated, holds the vehicle in place once coming to a full stop, allowing you to remove your foot from the brake. This is beneficial in stop-and-go traffic. To drive off, use the throttle as usual. If activated, an LED lights up in the button.

 **Note:** Make sure vehicle is in Park before exiting; otherwise, it may roll. Select Park only when vehicle is stopped; this blocks the drive wheels. See Owner's Manual for all instances when Park is engaged automatically. ◀

These driving modes change the performing characteristics of your BMW:

- **SPORT:** Sporty response from the transmission, throttle, and steering wheel; stiffer suspension for better performance when cornering (if equipped); deactivates engine Auto Start/Stop.
- **COMFORT:** Balanced settings for suspension, transmission, throttle, and steering wheel; balanced fuel efficiency.
- **ECO PRO:** Maximum fuel efficiency; reduces energy consumption, e.g., regulates climate control and seat heating; activates Auto Start/Stop function; reduces energy consumption, shift patterns, throttle response and activates coasting.
- **ADAPTIVE (if equipped):** Comfort-oriented drive; tuning is automatically adjusted to driving style and situation. If Navigation system is activated, upcoming road conditions are also factored in.



Note: The last Auto Start/Stop function setting is stored and resumed at next start. If ECO PRO mode is selected, Auto Start/Stop will automatically engage. ◀

Additional information

BMW Driver's Guide App



The Owner's Manual is available as an app.

Additional information on the Internet:

www.bmw.com/bmw_drivers_guide

BMW Genius

BMW Genius Everywhere.

A holistic approach to understanding your BMW:

- Meet with a BMW Genius at one of our many BMW Centers.
- Contact the BMW Genius Hotline at +1-844-4GENIUS or at BMWGenius@BMWUSA.com.
- Install and use the BMW Genius App on your smartphone.
- Install and use the BMW Driver's Guide App for a virtual Owner's Manual.
- Go to [YouTube.com/BMWUSA](https://www.youtube.com/BMWUSA), scroll down and select "BMW Genius How to Videos and Owners Tips".

Vehicle Equipment

Standard, country-specific and optional equipment that is offered in the model series is described in this Quick Reference. Therefore, equipment is also described that is not available in a vehicle, e.g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

More about BMW



The Ultimate Driving
Machine®

bmwusa.com

01402982654 ue

