

Contents

Quick Reference
Card.



The Ultimate Driving
Machine®



THE BMW X6. QUICK REFERENCE.

BMW EfficientDynamics
Less emissions. More driving pleasure.

© 2017 Bayerische Motoren Werke
Aktiengesellschaft
Munich, Germany
Reprinting, including excerpts, only with the written
consent of BMW AG, Munich.
US English VI/2017,
Printed on environmentally friendly paper, bleached
without chlorine, suitable for recycling.

Contents

X6

6	Entering your vehicle
6	Remote Control
6	Central Locking
6	Comfort Access (if equipped)
7	Tailgate
8	Adjusting and controlling
8	Seats
9	Lights
10	Wipers
10	Steering Wheel
11	Cruise Control
11	Bluetooth
12	Climate
12	Connectivity
13	iDrive
14	Programmable Memory Buttons
14	BMW Connected App
15	Apple CarPlay™*
15	Audio System
16	Navigation (if equipped)
16	Voice Control
17	Time
18	Get going
18	Starting/Stopping the Engine
18	Auto Start/Stop
18	Brakes
18	Shifting Gears
19	Upholstery
19	Center Console Storage
20	Additional information
20	BMW Driver's Guide App
20	BMW Genius
20	Vehicle Equipment

Entering your vehicle

Remote Control

Holds the power over windows, doors, tailgate, lights, alarms – and remembers all your favorite settings.

Beyond simply locking and unlocking your vehicle, the remote control has several useful functions:



- 1 **Unlocking:** Press to unlock driver's door. Press again to unlock other doors.*
Also: hold to open the windows and sun-roof.
- 2 **Locking:** Press to lock. Press twice (the red indicator on the interior mirror glows for three seconds) in order to deactivate the interior motion detector (in case you leave an animal in the car when locked).
- 3 **Tailgate:** Hold one second to open.
- 4 **Panic mode:** Hold three seconds to sound.

* Unless programmed to open all doors with one press.

 **Note:** Preferred settings, such as seat/mirror position, climate, radio stations, etc., are stored with the remote. For proper operation, keep the remote control and mobile phone apart. Do not lock the vehicle using the remote when people are inside. ◀

Central Locking

Quick security at your fingertips.

Lock and unlock all doors and the tailgate by using these buttons, conveniently located on the driver's and passenger's doors by the arm-rest.




- ▷ **Locking:** Press the  button to lock all doors and tailgate.
- ▷ **Unlocking:** Press the  button to unlock all doors and tailgate.

 **Note:** When the button is used to lock the vehicle, the fuel filler flap remains unlocked and the vehicle is not secured against theft. When used to unlock the doors, each door handle requires only one pull to open. ◀

Comfort Access (if equipped)

Making keys (almost) obsolete.

This feature lets you unlock and lock the vehicle doors and tailgate without using the remote control, but simply by keeping it on you, in a pocket or purse.



- 1 Unlocking: Grab the door handle and pull.
- 2 Locking: Touch the ridged area on the handle for one second (without grasping the door handle). Also: hold the ridged area down to close windows and moonroof.

 Note: Remote control can still be used. For proper operation, keep remote control and mobile phone apart. ◀

Tailgate

There are many easy ways to open the tailgate.

- ▶ Using the remote control to open: Hold  button for one second.



- ▶ On the tailgate: Press button (see arrow).
- ▶ To open from inside: Press the  button on the driver's door. If the vehicle is locked, selector lever position P must be engaged.

To close:

- ▶ To close from inside: Pull and hold the  button on the driver's door until the

tailgate closes. If you let go, the tailgate will stop.

- ▶ Press the  button on the inside of the tailgate and lock the vehicle.
- ▶ Press the  button to close the tailgate and lock the vehicle.

Using Comfort Access (if equipped; operation only possible in combination with M Sport package):

- ▶ Have your key on you.
- ▶ Stand about an arm's length behind the car, in front of the license plate.
- ▶ Kick your foot forwards & backwards under the bumper in one quick movement.
- ▶ The taillights will flash and the trunk will either open or close.


 Note: Be careful to stand back when tailgate opens. Be sure to keep the remote control on you. For proper operation, keep remote control and mobile phone apart. ◀

Adjusting and controlling

Seats

Power seat adjustment – personalizing the seat of power.

Your power seats can easily be adjusted to offer comfortable support. Simply use the different-shaped controls along the outside edge of your seat bottom to achieve the perfect position – then use one of the seat and mirror memory buttons to lock in your settings.



- 1 Memory buttons: See below.
- 2 Shoulder support (multi-contour seats only): Press left/right to increase/decrease strain on the shoulder muscles.
- 3 Backrest width (multi-contour seats only): Press left/right side to adjust side bolsters.
- 4 Lumbar support: Press left/right side to increase/decrease back support curve; press top/bottom to raise/lower the support curve.
- 5 Backrest, head restraint: Move the button left/right to tilt the backrest. Adjust the height of the head restraint by moving the button up/down.
- 6 Seat position: Keeping button horizontal to the ground, slide button left/right to move seat forward/rearward, and up/down to

raise/lower seat. Move side of button up/down to tilt seat front up/down.

- 7 Thigh support (multi-contour seats only): Adjust the position by moving the button left or right.

Set it and forget it.



To store your preferred power seat position:

1. Turn on the ignition.
2. Set your preferred seating position.
3. Press the SET button, which turns on the red LED.
4. Select and press memory button 1 or 2. When the red LED goes out and there is an acoustic confirmation, your setting is stored in that button.

 **Note:** Memory buttons do not store lumbar support settings or, if so equipped, backrest width. ◀

Recalling saved seating position – three routes to comfort.

Your preferred seating, steering wheel position and mirror positions can be recalled three different ways.

By using your personal remote control:

- ▶ Each remote control stores the last driver's settings and automatically returns the seat and exterior mirrors to those positions. Be-

fore doing so, you need to select “Last seat position automatic” via the iDrive under “My Vehicle” > “Driver Profiles” then select the current or other driver.

By using your memory button (1 or 2, wherever your seat settings are stored):


- ▶ While parked: When the engine is not running, briefly press your memory button.

 **Note:** Using the memory function while driving can lead to unexpected seat or steering wheel movements. Vehicle control could be lost. There is a risk of an accident. Only retrieve the Controls Settings memory function when the vehicle is stationary. ◀

Head restraint adjustment.

BMW head restraints are specially designed to help protect against whiplash in the event of a sudden stop. They can also be easily raised and lowered electronically to the optimal height for comfort.

The height of the head restraint can be adjusted electrically by sliding the backrest adjustment button (5) up/down.




To adjust the distance to the back of the head press the button and push the head restraint toward the rear. Pull the head restraint for adjusting it forward.

Lights

See and be seen.

The signature corona headlight rings – “angel eyes” – are only one part of what your BMW offers for you to see and be seen while driving.

Light switches include:



- 1 Front foglights. Press to switch on/off.*
- 2 Switch on Automatic headlight control. (Low beams automatically turn on/off.) Includes Adaptive Light Control, Welcome lights and Daytime running lights.
- 3 Switch off lights. (Daytime running lights stay on.)
- 4 Switch on Parking lights.** (Daytime running lights stay on if activated in iDrive menu.)
- 5 Switch on Low beams.
- 6 Dial to adjust instrument lighting. (Parking lights or Low beams must be on.)

* The main switch must not be in the “off” position (3) or Parking lights (4) position.

** Do not use for extended periods with the engine turned off, as this drains the battery.

Adaptive Light Control available with Xenon or LED headlamps: Based on your steering input and other parameters, Adaptive headlights automatically turn to follow road curves. Bright, daylight-like Xenon or LED light illuminates your path for optimum visibility. In tight curves, the foglight on the side of the turn also switches on for added visibility.

 **Note:** To activate/deactivate various lighting functions and duration, select “Settings” in iDrive, then “Lighting”. ◀

Wipers


Make it a clean sweep.

The windshield wiper stalk is at the 3 o'clock position behind the steering wheel.

Windshield washing: Pull the stalk toward you to activate the washers and then release.


Windshield wiping:

- ▷ Single wipe: Press down on stalk.
- ▷ Normal speed: Move stalk up/down once to turn on/off.




- ▷ High speed: Move stalk up twice, or once past resistance point, to turn on; tap down once to return to normal speed, or twice to turn off.

Rain sensor:



- ▷ Press button on end of stalk to turn on/off. An LED lights up when active.




- ▷ Frequency setting: Turn thumbwheel on the stalk up/down to increase/decrease sensitivity to rain.

 **Note:** The stalk always returns to the default position. In a car wash, be sure to deactivate the rain sensor to avoid wiper damage. ◀

Steering Wheel

Tailor your steering wheel position for a perfect fit.



The steering wheel can be adjusted in four directions.

 **Note:** The remote control stores preferred settings. ◀

The touch of warmth when it's cold.



To warm the steering wheel, press the button on the left side of the steering column. An LED lights up when activated.


When activated/deactivated, the feedback "Steering wheel heating activated" or "Steering wheel heating deactivated" is displayed in the instrument cluster.

Cruise Control

Give your foot a rest.

Cruise control can increase your fuel efficiency and your comfort on long drives.

The function buttons are located on the left side of the steering wheel.



- 1 Press to start cruise control mode. Then get up to desired speed. Also: while in cruise control mode, press once to interrupt set speed; press twice to turn cruise control off.
- 2 Press to resume set speed.

- 3 Press to set cruise control at current vehicle speed.
- 4 Rocker switch increases/decreases the set speed.
 - ▶ By 1 mph: move up/down to the point of resistance.
 - ▶ By 5 mph: move up/down past the point of resistance.

 Note: Braking interrupts the system but does not turn it off. Vehicles equipped with Active Cruise Control will be slightly different. ◀

Bluetooth

Connect wirelessly to your world.

To pair your mobile phone via Bluetooth®:

1. Navigate through iDrive to: My vehicle > iDrive settings > Mobile devices > Connect new device. Then select one function.

Tip: Select "Bluetooth® audio" to use phone as both media device and telephone.
2. Activate Bluetooth and search for your BMW on your phone. Your vehicle's Bluetooth name is displayed in iDrive.
3. Select your BMW on your mobile phone to pair.
4. Both your phone and iDrive will display a passkey. Confirm that the passkeys match, then select "OK" on the iDrive to confirm your phone.
5. Your phone should appear at the top of the mobile phone list to confirm the pairing was a success.

Tip: Sometimes new phones require a software update of your iDrive. If you experience problems with your phone, check online for an update: BMW.com/update. Have your Vehicle

Identification Number (VIN) handy (found in your registration papers).

Tip: If you want to keep a call when exiting your vehicle, click on the “Headset” option on your phone to deactivate the link to the car.

Tip: If you enter the vehicle, the call will automatically continue via the hands-free system.

 **Note:** To make sure your phone is compatible, visit bmwusa.com/Bluetooth. For further details, refer to your mobile phone owner’s manual. ◀

Climate

Automatic climate control – don’t sweat the driving.

Keep the cabin a comfortable temperature automatically while you drive.



- ▶ To activate: Press AUTO button and select desired temperature. The system will quickly achieve it by automatically controlling air flow, distribution and temperature.
- ▶ To turn off: Lower the fan speed until it is turned off.
- ▶ To cool vehicle quickly: Press MAX A/C button, which sets system to the lowest temperature, maximum air flow and recirculated air mode. Keep engine running.
- ▶ To defrost the windshield: Press the  button. You can adjust air flow.
- ▶ To defrost rear window: Press the  button. The defroster will switch off automatically after a period of time.

- ▶ To keep outside odors or pollutants from entering the car: Press the  button to select mode.
 - ▶ LEDs off: Outside air flows in.
 - ▶ Left LED on: Whenever a sensor detects pollutants, it automatically shuts off outside air. When no longer detected, it flows in outside air again.
 - ▶ Right LED on: Outside air is permanently blocked from entering the vehicle.
 - ▶ At low temperatures: Recirculated air mode turns off after a period of time to keep windows from fogging.


 **Note:** There are separate temperature (if equipped) and air distribution controls for both left- and right-seat occupants. ◀

Connectivity

Wired or wireless – it’s up to you.

Your new X6 offers various possibilities to connect and charge your mobile device.

Via USB:



USB ports are conveniently located in the center armrest and in front of the cupholders (if equipped with Wireless Charging). Both can be used to charge connected devices and play music through them. Additionally, you may play music stored on a USB thumb drive.

You can switch via iDrive through the connected media devices. Press the MEDIA button twice to see a list of accessible devices.

Qi Wireless Charging (if equipped):

To use this feature your mobile phone needs to fulfill the Qi standard for wireless inductive charging either integrated within the device or by an accessory case available via BMW Parts & Accessories.

To charge: Place your phone with its back to the charging surface closest to the driver. The charging pocket is located inside the center console. An LED charging indicator lights up while charging.

Tip: You can set an alert when your mobile phone is still in the pocket and you are about to exit the vehicle. Go to My Vehicle > System settings > Wireless charging tray > Forgotten cell phone alert.

Connect to the Wi-Fi hotspot:

When first used, make sure that the hotspot feature is activated: My Vehicle > System settings > Mobile Devices > Settings > Internet hotspot is checked. Connecting new devices is as easy as in your home's Wi-Fi network. To do so, proceed as follows:

- ▶ MENU > My Vehicle > System Settings > Mobile devices > Internet hotspot. The name and passkey of the network are shown.
- ▶ Activate Wi-Fi on your mobile phone and search for networks.
- ▶ Connect to your car's Wi-Fi by entering and confirming the passkey.


 Note: With the first Internet usage via the WLAN hotspot, data must be purchased from a service provider. All devices connected via the WLAN hotspot use this data.◀

Check the Phone Pairing section for pairing a mobile device via Bluetooth®.

iDrive

The best of both worlds.

The iDrive system can now be controlled in two intuitive ways. You can use the familiar iDrive Controller on the center console to control many vehicle functions without having to look down while driving. Or use the new touchscreen for intuitive operation – similar to using a tablet or smartphone. Everything you can select using the controller can be accessed by touch, and vice versa.



- 1 Touchscreen, positioned for easy use.
- 2 iDrive Controller can be rotated; slid left or right, forward or backward; and pressed down to make a selection. You can write letters or numbers directly on the iDrive touchpad controller.

 Note: You can switch between the iDrive Controller and touch commands any-time. The keyboard layout will automatically adjust to the preferred entry method as soon as your finger is moving toward the screen or using the iDrive Controller.◀

The buttons next to the iDrive Controller – each distinctively shaped for tactile recognition – provide shortcuts to different menus:

- ▶ MENU: Press once for Main menu; press again to see a list of all menu items of the main menu.
- ▶ MEDIA: Press once for Multimedia menu; press again to see available media sources.

- ▷ NAV: Guides you directly to destination input menu.
- ▷ COM: Opens communication menu.
- ▷ MAP: Press once to open Navigation map; press again to hear voice guidance instructions.
- ▷ BACK: Previous panel or deleting letter/number input.
- ▷ OPTION: Options menu.

To return to previous menus, choose one of the following:

- ▷ Tilt the knob to the left (pressing down on the middle of the virtual controller).
- ▷ Press BACK button.

Programmable Memory Buttons

Your entertainment. Your information. Your way.

Use the eight programmable memory buttons to store your favorite radio stations, iDrive menu screens, phone numbers or navigation destinations.



- ▷ To store information:
 - ▷ Use iDrive to access and then highlight the function or information to be stored.
 - ▷ Press one of the memory buttons for more than two seconds until you hear a confirmation signal.



- ▷ To access information: Press the memory button. (For example, this will dial a phone number.)

- ▷ To display button assignments and information: Touch button slightly with a bare finger; the button assignment will appear at the top edge of the iDrive screen.

To replace an entry, simply assign a new shortcut to the key.



Note: These settings are also stored in the remote control currently in use. ◀

BMW Connected App

Your Personal Mobility Companion.



The BMW Connected App offers a whole new way to interface with your new BMW, in and out of the car.

Download the "BMW Connected" App from the Apple App Store or from Google Play.

App Highlights include:

- ▷ Send destinations to the car from other apps, texts, and web.
- ▷ Book a service appointment from your smartphone.
- ▷ "Time-to-leave" notifications on your smartphone or Apple Watch to keep you on-time.
- ▷ Remotely lock/unlock the doors, flash the lights, sound the horn, and start ventilation.
- ▷ Keep family and friends informed of your arrival time when you're on the way.
- ▷ Simple access on a map to the last known position of your BMW.

Apple CarPlay™*

CarPlay™ your way.



1. Navigate through iDrive to: My vehicle > iDrive settings > Mobile devices > Connect new device.
2. Select "Apple CarPlay™" to initiate CarPlay™ compatible device.
3. Activate Bluetooth and WiFi on your CarPlay™ compatible device and search for your BMW. The name of your BMW is displayed in iDrive.
4. Select your BMW on your mobile phone to pair.
5. Both your phone and iDrive will display a passkey. Confirm that the passkeys match, then select "OK" on the iDrive to confirm your phone.
6. Your phone should appear at the top of the mobile device list to confirm the pairing was a success.

CarPlay™ is now accessible wirelessly through the iDrive headunit.

Tip: You can utilize both touchscreen and iDrive controller in order to intuitively navigate through the CarPlay™ Menu.

*Apple CarPlay™ is a trademark of Apple Inc.

Apple® is responsible for all content and functionality displayed in the vehicle via Apple CarPlay™.

For information including device and system compatibility, go to <https://www.apple.com/ios/carplay/>.

For information on privacy and the use of vehicle data, go to <http://apple.com/privacy/privacy-policy/> or <http://www.bmwusa.com/Standard/Content/PrivacyPolicy/>.

Audio System

Now is the time to play favorites.

- ▶ Press MEDIA button on iDrive controller twice to show a list of available entertainment sources.
- ▶ Starting from the Main menu select Media/Radio to see the full list of all possible entertainment sources.

The list shows items for:

- ▶ Presets (Favorites list of FM, AM and SAT radio (if equipped) stations).
- ▶ Currently and last connected devices via Bluetooth®, USB, etc.
- ▶ Music collection (Imported music from CDs and USB sticks on the 20GB internal hard drive).
- ▶ CD/DVD.
- ▶ Apps (if a supported device is connected, see Phone pairing for instructions).

Store your favorite FM, AM and Satellite channels (if equipped) in one Preset list for easy access.

To store a radio station:

- ▶ Select FM, AM or Satellite radio (if equipped) from the list of media devices.
- ▶ Select the station you would like to save.
- ▶ Press the iDrive controller or touch the ☆+ symbol.
- ▶ Select a position for the station via the controller or touch the desired position to store the radio station in the Presets list.

Tip: While in Presets mode you can scroll through your Presets list with the thumbwheel on the right side of the steering wheel. This will appear in either the Head-up Display (if equipped) or the instrument cluster. To select a station, press the thumbwheel.

Tip: Store your favorite station on a memory button by highlighting it and pressing the button until you hear a confirmation sound.



Note: Your Preset Buttons and radio stations are stored in your remote control. If you use a different remote control, different Preset stations will appear. ◀

Navigation (if equipped)

The world is at your fingertips.

To enter a new destination:

1. Press the NAV button on the iDrive controller and select an input method:
 - ▶ Select “Enter Address”. Enter the necessary information. As you enter more information, the list of possible entries narrows.
 - ▶ Select “Quick Search” or “Points of Interest” to find special destinations.
 - ▶ Select “Recent destinations” to find previously entered destinations.
2. Press the  button on your steering wheel and say “Enter destination”. You can even directly enter an address or point of interest through Voice Control. For details, check the Voice Control section.

To access the map directly, use the MAP button around the controller. You will see traffic routes, obstructions, and a function bar for personalizing how information is conveyed. Also set the map view, scale, split screen (to display additional information) and other functions, such as traffic bulletins and Advanced Real Time Traffic Information (ARTTI) to help avoid traffic jams.

Tip: If the Learn route feature in Navigation > Settings > Route settings is activated, your vehicle will learn that you drive some routes differently than suggested by the Navigation system to adjust the calculated route.



Note: For more information, refer to the “Navigation, Entertainment and Communication. Owner’s Manual”. ◀

Voice Control

Your word is BMW’s command.

The BMW Voice Control System understands your spoken commands. It’s the best way to control many functions, such as phone and navigation, while keeping your eyes on the road.

- ▶ To start: Press the  button on the steering wheel. After you hear the activation, speak at a constant pace. If further dialog steps are necessary, the system will ask for input. When the system displays the  symbol (with sound waves) in the instrument cluster or iDrive display, it is ready for your input.



Note: When  is displayed, the system is processing and does not accept input. ◀



Commonly used commands are displayed in a pop-up at the top of the center display.

Here are some tips for the common commands accessible from any menu:

- ▶ “Call John Smith on his mobile”.
- ▶ “Dial number”: After the system response, say the number in single digits.
- ▶ “Call my wife/husband”: When first used, the system will guide you through the setup. There are many more shortcuts possible, like mother, brother, boss, etc.
- ▶ “Drive me home”: After you have saved a home address in the system, this handy command will always lead you back home. When first used, the system will ask you for an address.
- ▶ “Navigate to 300 Chestnut Ridge Road, Woodcliff Lake, New Jersey”: The address must be spoken in the specific order: street number, street, city, state, with a minimum of city and state.
- ▶ “Find the next gas station”: This command searches online for the next gas station and provides a list of alternatives.* You can

use this command with various other searches.

 Note: You can say “Help”, which leads you to a general explanation of the voice control system. ◀



The system works best with windows and moonroof closed.

If you have an iPhone paired as your primary phone to the vehicle, pressing the button for about one second will activate SIRI.

* This service requires an available internet connection.

 Note: Your vehicle will automatically adjust for Daylight Savings Time. Choose the correct time zone by selecting “Automatic Time Setting”. If you change time zones, please deselect and reselect “Automatic Time Setting”, and the system will automatically adjust the time zone. ◀

Time

How to set the time in no time.

To set the clock using the iDrive controller, first press the MENU button.

Then rotate the controller to:

1. My Vehicle. Press down.
2. iDrive Settings. Press down.
3. Time/Date. Press down.
4. Time. Press down.
5. Set the hour. Press down.
6. Set the minute. Press down.

Get going

Starting/Stopping the Engine

The power of one touch.



Turning the engine on:

- ▶ Press the brake pedal and the Start/Stop button together.

Turning the entire vehicle off:

- ▶ Press the Start/Stop button once to turn off the engine.
- ▶ Press the Start/Stop button a second time with your foot off the brake pedal to turn off the vehicle's electronics or lock the vehicle from outside.

Auto Start/Stop

This vehicle stops for fuel efficiency.



To maximize fuel efficiency and minimize emissions, your BMW is equipped with the Auto Start/Stop function. Under certain conditions, this feature switches off the engine when you stop, and restarts it when you release the brake. You can disable this feature by pressing the Auto Start/Stop button, located to the left of the Start/Stop button. An LED lights up when the system is disabled.



Note: When switched off, the vehicle retains the last Auto Start/Stop function setting. ◀

Brakes

The sign of high-performance stopping.

BMW vehicles are fitted with large, fade-resistant brakes, which are also an essential part of

their active safety. During heavy braking, friction on high-performance materials may create brake dust, a testament to their outstanding stopping power. Although brake dust cannot be avoided completely, it can be removed by washing.



Note: We suggest using BMW Wheel Cleaner Gel, formulated to easily and thoroughly clean all steel and light alloy wheel rims. ◀

Shifting Gears

Automatic transmission – directing the power.

The BMW gearshift lever was designed for added security before moving the vehicle.



Shifting out of Park: Press the brake pedal, then press and hold the “Unlock” button on the left side of the gearshift lever (arrow).



Then shift to:

- ▶ N (Neutral): Push forward or pull back to, but not beyond, the resistance point.

 Note: In car washes, shift into Neutral – because P (Park) is engaged automatically when ignition is switched off. ◀

- ▶ D (Drive): Pull back past the resistance point.

 Note: All forward gears can be engaged when in Drive. ◀

- ▶ R (Reverse): Push forward past the resistance point.

 Note: Select only when vehicle is stopped. ◀



Engaging Park: Press the button on top of the gearshift lever.

 Note: Make sure vehicle is in Park before exiting, otherwise vehicle may roll. Select Park only when vehicle is stopped; this blocks the drive wheels. See Owner's Manual for all instances when Park is engaged automatically. ◀

ECO PRO mode.

As part of EfficientDynamics, BMW created the ECO PRO mode. To engage the mode, press the “down” arrow of the Driving Dynamics Control (next to the gearshift lever). This adjusts engine response, climate control and seat heating for greater mileage. With the ECO PRO mode, the automated heating function of the exterior mirrors is turned off.

Additional driving tips:

- ▶ Avoid fast starts, use the accelerator pedal gently, and coast well in advance of situations that will require braking.
- ▶ Reduce vehicle speed to the ECO PRO-selected speed.
- ▶ Enable the Auto Start/Stop function (the function is automatically activated in ECO PRO mode).
- ▶ Avoid using the manual mode of the automatic transmission.

Upholstery

Long-lasting quality.

BMW selects the highest quality materials for upholstery and the interior. Naturally, continued use will subject any interior surface to wear and dirt. To keep your interior looking beautiful, we recommend you use BMW branded care and natural care items that are specially formulated for use on fabrics, plastics and all synthetic surfaces.

Center Console Storage

There's a place for that.

BMW has engineered intelligent storage into the center console. Additional storage space can also be found in driver- and passenger-side glove compartments, armrests and large door pockets.

Additional information

BMW Driver's Guide App



The Owner's Manual is available as an app.

Additional information on the Internet:

www.bmw.com/bmw_drivers_guide

BMW Genius

BMW Genius Everywhere.

A holistic approach to understanding your BMW:

- ▷ Meet with a BMW Genius at one of our many BMW Centers.
- ▷ Contact the BMW Genius Hotline at +1-844-4GENIUS or at BMWGenius@BMWUSA.com.
- ▷ Install and use the BMW Genius App on your smartphone.
- ▷ Install and use the BMW Driver's Guide App for a virtual Owner's Manual.
- ▷ Go to [YouTube.com/BMWUSA](https://www.youtube.com/BMWUSA), scroll down and select "BMW Genius How to Videos and Owners Tips".

Vehicle Equipment

Standard, country-specific and optional equipment that is offered in the model series is described in this Quick Reference. Therefore, equipment is also described that is not available in a vehicle, e.g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

More about BMW



The Ultimate Driving
Machine®

bmwusa.com

01402982629 ue

