

Getting Started Guide
BRZ
2026

Love. It's what makes Subaru, Subaru.®

SUBARU

© 2025 Subaru of America, Inc. Printed in USA. All rights reserved. Contents may not be reproduced in whole or in part without prior written permission of publisher. Specifications in this Guide are based on the latest product information available at the time of publication. Some images shown are for illustration purposes only. Some equipment shown in photography within this Guide is optional at extra cost. Specific options may be available only in combination with other options. Specific combinations of equipment or features may vary from time to time, and by geographic area. Subaru of America, Inc. reserves the right to change or discontinue at any time, without notice: Prices, colors, materials, equipment, accessories, specifications, models, and packages, without incurring any obligation to make the same or similar changes on vehicles previously sold. Colors shown may vary due to reproduction and printing processes. Subaru of America, Inc. is not responsible for typographical errors.

TABLE OF CONTENTS



PURPOSE OF THIS GUIDE
- WELCOME 4
- IMPORTANT SAFETY INFORMATION 4
- OWNER'S RESOURCES. 4
- IN CASE OF EMERGENCY 5
- TOWING YOUR SUBARU 6

ENTRY AND EXIT
- KEYLESS ENTRY 7
- KEYLESS ACCESS WITH PUSH BUTTON START 8

INSTRUMENT PANEL 10

GAUGES AND WARNING LIGHTS
- COMBINATION METER 12
- WARNING AND INDICATOR LIGHTS 14

CONTROLS
- INSTRUMENT PANEL SWITCHES (LOWER LEFT) 15
- AUDIO CONTROLS. 15
- ADAPTIVE CRUISE CONTROL . . 16
- COMBINATION METER DISPLAY CONTROLS 16
- LIGHT CONTROLS 17
- TURN SIGNALS 18
- WINDSHIELD WIPERS 18
- OVERHEAD CONSOLE. 19

GETTING COMFORTABLE
- SEATING 20
- TILT AND TELESCOPIC STEERING COLUMN 21
- POWER EXTERIOR MIRRORS . . 22
- REAR VIEW MIRROR 22
- POWER WINDOWS 23
- CLIMATE CONTROL 24
- ACCESSORY CONNECTIONS . . 27

OPERATING THE VEHICLE
- PUSH-BUTTON IGNITION SWITCH 28
- STARTING THE VEHICLE 28
- DRIVING THE VEHICLE 28
- DRIVING SYSTEMS/MODES . . . 30
- TURNING OFF THE VEHICLE. . . 31

REFUELING
- FUEL FILLER LID 32
- FUEL SPECIFICATIONS AND CAPACITY 32

PASSENGER/CARGO AREAS
- FOLDING THE REAR SEATBACK 33
- LATCH/ANCHOR. 34

TABLE OF CONTENTS

INTERNAL SAFETY TRUNK RELEASE WITH SELF-ILLUMINATING HANDLE 35
TRUNK LID OPENER 35
FLAT TIRE REPAIR KIT 36

ENGINE COMPARTMENT
HOOD PROP 37
2.4L ENGINE 38

ADDITIONAL SPECIFICATIONS
NEW VEHICLE BREAK-IN 40
ENGINE OIL SPECIFICATIONS & CAPACITIES 40
TRAILER TOWING CAPACITY . . 40
TIRE PRESSURE MONITORING SYSTEM (TPMS) 41

SUBARU MULTIMEDIA OVERVIEW
OVERVIEW OF YOUR MULTIMEDIA SYSTEM 43
BUTTONS 44
TOUCHSCREEN 45
STEERING WHEEL CONTROLS . . 46
VOICE RECOGNITION 47

HOME SCREEN
HOME SCREEN ICONS 49
REARRANGING ICONS 49
ADDING SHORTCUTS 50

DRIVER PROFILE
CREATING A DRIVER PROFILE . . 51

MULTIMEDIA
RADIO 54
MEDIA 55

PHONE
PAIRING A PHONE 56
MAKING A CALL 56
RECEIVING A CALL 57
TEXT MESSAGES 58

APPS
IN-VEHICLE APPS 59
MYSUBARU 60

CONNECTED SERVICES SUBSCRIPTIONS
MYSUBARU COMPANION AND MYSUBARU COMPANION+ OVERVIEW 62
ENROLLMENT 63
MYSUBARU INTEGRATION 63
AT&T WI-FI HOTSPOT 63

SETTINGS AND UPDATES
SETTINGS AND UPDATES OVERVIEW 64
SOUND 64
PHONE 66
CLOCK 66

EYESIGHT
EYESIGHT® OVERVIEW 67
OPERATION 67
FUNCTIONS 68
STEERING WHEEL CONTROLS . . 73
LANE DEPARTURE WARNING AND PRE-COLLISION BRAKING SYSTEM OFF 75

DRIVER ASSIST TECHNOLOGIES
REAR-VISION CAMERA 76
BLIND SPOT DETECTION (BSD) / REAR CROSS TRAFFIC ALERT (RCTA) 76
HIGH BEAM ASSIST (HBA) 78
STEERING RESPONSIVE HEADLIGHTS (SRH) 78
REVERSE AUTOMATIC BRAKING (RAB) 79

CARE AND LIMITATIONS
STEREO CAMERA PRECAUTIONS 80
WINDSHIELD GLASS AND DASHBOARD 80

FRONT VIEW
BRZ 81

EYESIGHT DISCLAIMER
EYESIGHT® DISCLAIMER 82

HOW TO APPENDIX
HOW TO OVERVIEW. 83
SETTING THE CLOCK 83
BLUETOOTH® PAIRING 86
ANDROID AUTO™ 92
APPLE CARPLAY® 94
WI-FI 96
INDEX 98

PURPOSE OF THIS GUIDE

WELCOME

Congratulations on choosing a Subaru BRZ and welcome to the Subaru family!

Subaru is More Than a Car Company®. We are committed to making the world a better place, and the Subaru Love Promise® is our vision to show love and respect to all people at every interaction with Subaru. We believe in building lifelong relationships with our customers, earning your trust and exceeding your expectations by providing customer service with integrity and compassion.

This Getting Started Guide will introduce you to your new Subaru BRZ by providing information on the basic operation and key features of your Subaru as well as the MySubaru Connected Services and EyeSight ® systems in your vehicle.

IMPORTANT SAFETY INFORMATION

The Getting Started Guide is not intended as a substitute for your Owner's Manuals. We strongly encourage you to review your Vehicle, MySubaru Connected Services and EyeSight® Owner's Manuals to ensure complete understanding.

OWNER'S RESOURCES

If you're having difficulty using any of the functions outlined in this guide, or want to learn more, you can get additional information from the following sources:

Your Subaru Owner's Manuals:
Located in the glovebox

Online Subaru Owner's Resources:
www.subaru.com/owners

Subaru Customer Support:
www.subaru.com/customer-support

1-800-782-2783 (1-800-SUBARU3)

Scan to learn more about **Owner's Resources**.

Scan to learn more about **Customer Support**.

My Subaru

Scan to get the **MySubaru** App.

IN CASE OF EMERGENCY

MySubaru Companion and Companion+ (subscription required)

SOS Emergency: Press the red "SOS" button on the overhead console in the event of an emergency to speak with a MySubaru Customer Care Agent.

Enhanced Roadside Assistance: Press the blue "i" button on the overhead console or select the "MySubaru" button and then choose "Roadside Assistance" on the multimedia system. The "i" button also connects to the MySubaru Personal Assistant service, if subscribed.



SOS and Roadside Assistance Buttons

For more information, please refer to "MySubaru Companion and Companion+ Overview" on page 62 in this Getting Started Guide or "Introduction" in your MySubaru Owner's Manual. Not available in all states. See Retailer for details.

Subaru Roadside Assistance

Subaru Roadside Assistance:
1-800-261-2155

Subaru Roadside Assistance is free and standard on your Subaru; there are no forms to complete. This service is available anytime during the 3-year/36,000-mile Subaru Limited Warranty, whichever comes first. See your Subaru Retailer for details and refer to the Roadside Assistance guide in the owner's information kit for the details on this coverage. A Subaru Roadside Assistance decal has been affixed to the driver's door window.

Roadside assistance helps with:

- Towing to the nearest authorized Subaru Retailer if you cannot safely drive your Subaru
- Jump-start if your battery is dead
- Gasoline delivery if you run out of gas
- Emergency lockout service
- National Subaru Retailer locator service, with phone numbers and location of the nearest Subaru Retailer anywhere in the U.S. or Canada

NOTE: Specifically excluded from Subaru Roadside Assistance coverage are service requests or claims resulting from: accidents, vandalism, acts of God, violation of any laws, or vehicle modifications not recommended by the manufacturer.

TOWING YOUR SUBARU

Improper towing may damage your BRZ. The best way to tow your BRZ is with a flatbed truck by your Subaru Retailer or a commercial towing service.

For more information, please refer to “In Case of Emergency” in your Owner’s Manual.

KEYLESS ENTRY



Access Key Fob

1 Lock/Arm

- Press the lock/arm button to lock the doors, trunk, and fuel filler lid and to activate the security alarm. A chirp sounds and the hazard warning lights flash once.
- If either of the doors are not fully closed, a chirp sounds for 5 seconds to alert you.
- Press the lock/arm button three times to activate the vehicle finder function. If you are within 30 feet of your Subaru, the horn sounds once, and the hazard warning lights flash three times.

2 Unlock/Disarm

- Press the unlock/disarm button once to unlock the driver's door. Two chirps sound and the hazard warning lights flash twice. To unlock both doors and the trunk, briefly press the button twice.
- The interior lights will illuminate when you press the unlock/disarm button if the interior light switch is set to the "DOOR" position on the overhead console.

3 Trunk

- Press and hold the trunk button to open the trunk. A chirp sounds once.

4 Panic Alarm

- Press the panic alarm button to sound the horn and flash the hazard warning lights.
- Press any button on the access key fob to deactivate the panic alarm.

The doors can also be locked and unlocked through the MySubaru app, if subscribed.

KEYLESS ACCESS WITH PUSH BUTTON START

The Keyless Access with Push-Button Start system features the following touch-activated door locking or unlocking functions without the key ever leaving your pocket or purse. You can customize the touch-activated door locking or unlocking settings using the Subaru Multimedia System by selecting “Settings”, and then selecting the “Car” menu.

Unlocking Using Door Handles

Grip the driver’s door handle to unlock the driver’s door. Grip the passenger’s door handle to unlock both doors and the trunk. Two chirps sound and the hazard warning lights flash twice.



Door Unlock Sensor

Locking Using Door Handles

Close both doors and touch the door lock sensor on either door handle. Both doors and the fuel filler lid lock. One chirp sounds and the hazard warning lights flash once.



Door Lock Sensor


Unlocking the Trunk

Press the trunk opener button to unlock and open the trunk.




Trunk Opener Button

INSTRUMENT PANEL




1. Power Window Switches (p. 23)
2. Power Exterior Mirror Switch (p. 22)
3. Instrument Panel Switches (p. 15)
4. Audio Controls (p. 15)
5. Combination Meter (p. 12)
6. Light Controls (p. 17)




7. Combination Meter Display Control Switches (p. 16)
8. Adaptive Cruise Control (p. 16)
9. Climate Control System (p. 24)
10. Windshield Wipers (p. 18)
11. Subaru Multimedia System (p. 43)
12. Shifter (MT) or Select Lever (AT) (p. 28)
13. Parking Brake

COMBINATION METER



Normal Mode

1. Trip meter and odometer
2. Combination Meter Display
3. Tachometer
4. Speedometer
5. Select lever/gear position indicator
6. Engine coolant temperature gauge
7. Fuel gauge



TRACK Mode

1. Trip meter and odometer
2. Combination Meter Display
3. Select lever/gear position indicator
4. Tachometer
5. Speedometer
6. TRACK Mode indicator light
7. Engine coolant temperature gauge
8. Fuel gauge

WARNING AND INDICATOR LIGHTS

Red lights indicate immediate attention is required. Some examples are:

		
Seatbelt warning	Door open indicator	Brake system warning

Yellow lights indicate caution. Some examples are:

		
Low fuel	Check engine warning light	Tire pressure warning

Green and **blue** lights are for information. Some examples are:

		
Headlight indicator	Cold coolant temperature	High beam indicator

INSTRUMENT PANEL SWITCHES (LOWER LEFT)

1. Illumination brightness (see p. 17)
2. Trunk Release (see p. 35)

For more information, please refer to “Instruments and Controls” and “Keys and Doors” in your Owner’s Manual.



AUDIO CONTROLS

1. Source
2. Volume Up/Volume Down
3. Presets/Skip
4. Call
5. End
6. Voice Recognition

For more information about your audio system and controls, please refer to page 46 in this Getting Started Guide or “Quick Guide” in your MySubaru Owner’s Manual.





ADAPTIVE CRUISE CONTROL

1. Adaptive Cruise Control On/Off
2. CANCEL
3. Following Distance
4. Resume (RES)/Increase Speed and Set (SET)/Decrease Speed

For more information on Adaptive Cruise Control, please refer to page 73 in this Getting Started Guide or “Adaptive Cruise Control” in your EyeSight® Owner’s Manual.





COMBINATION METER DISPLAY CONTROLS

1. Return
2. Scroll Up/Down
3. Scroll Left/Right
4. Enter

For more information, please refer to “Instruments and Controls” in your Owner’s Manual.



LIGHT CONTROLS



1. **AUTO:** Rotate the end of the lever to set your headlights to automatically turn on or off, depending on the level of light outside. When in the "AUTO" position, the headlights will automatically turn on when the windshield wipers operate several times.
   NOTE: The sensitivity of the automatic headlights can be adjusted through the Subaru Multimedia System.
2. **Parking Lights:** Rotate the end of the lever to turn on the instrument panel illumination, parking lights, side marker lights, tail lights, and license plate lights.
3. **Headlights:** Rotate the end of the lever to turn on the headlights, instrument panel illumination, parking lights, side marker lights, tail lights, and license plate lights. To flash the headlights, pull the lever toward you, and then release. The high beams will stay on as long as you hold the lever. The headlight flasher works even with the headlight control switch in the off position.
4. **High Beams:** Push the lever forward and release to change from low beam to high beam. Pull the lever rearward and release to return to low beam. When set to the "AUTO" position, pushing the lever forward also activates the High Beam Assist (HBA) system.

Illumination Brightness

When the light controls are on (in the " ", " ", or "AUTO" position), and ambient light is low, rotating the illumination brightness dial on the instrument panel upward will make the instrument panel illumination brighter. When the dial is fully rotated upward (dots aligned), the instrument panel illumination stays at full brightness. Rotating the dial downward dims the instrument panel illumination.



Illumination Brightness Dial

When the ambient light is bright, the illumination brightness is set to the maximum regardless of the position of the control dial.

For more information, please refer to "Instruments and Controls" in your Owner's Manual.

Daytime Running Lights


The daytime running lights automatically turn on when the engine is running, the parking brake is fully released, the select lever is out of the "P" position (AT models), and the light switch is set to Off, "AUTO", or " ". Always turn on the headlights when it's dark outside by rotating the dial to the " " or "AUTO" position.

TURN SIGNALS



Pushing the turn signal lever up/down and releasing it activates the turn signal. The lever then returns to its original position. To cancel the turn signal push and release the turn signal lever slightly in the opposite direction of the active turn signal. Your Subaru also has a one-touch lane changer feature: push slightly up and release to signal a right lane change or push slightly down and release to signal a left lane change.

WINDSHIELD WIPERS



1. **Intermittent:** Push the wiper control lever down one position for intermittent operation. When the lever is in the intermittent position, you can rotate the dial to adjust the operating interval of the wipers.
2. **Low Speed:** Push the wiper control lever down two positions for low speed wiper operation.
3. **High Speed:** Push the wiper control lever down three positions for high speed wiper operation.
4. **Mist:** Push the wiper up from the off position for a single wipe.
5. **Windshield Washer:** Pull the lever toward you to wash the windshield. The washer will spray and the wipers will operate while you pull the lever.

OVERHEAD CONSOLE



1. **SOS Emergency Assistance:** Press the red "SOS" button to connect with a MySubaru Customer Care Agent (Subscription required). Press and hold the button for about two seconds to cancel the call.

   For more information, please refer to page 62 in this Getting Started Guide or "Introduction" in your MySubaru Owner's Manual.

2. **Enhanced Roadside Assistance:** Press the blue "i" button to connect with a MySubaru Roadside Assistance Provider (Subscription required). Press and hold the button for about two seconds to cancel the call. The "i" button is also used for Concierge services, if subscribed.

   For more information, please refer to page 62 in this Getting Started Guide or "Introduction" in your MySubaru Owner's Manual.

3. **Automatic Illumination:** When the switch is in the "DOOR" position, the map lights will automatically turn on and off depending on the locking and unlocking of the doors, the opening and closing of the doors, as well as the position of the ignition switch.

4. **Map Lights:** Press a map light to turn it on or off.

SEATING

Manual Seats

1. **Forward/Backward:** Pull the lever below the seat up and slide the seat forward or backward. Release the lever and make sure the seat is locked into place.
2. **Seat Height (Driver's Seat):** Pulling up or pushing down on the lever will raise or lower the seat cushion.
3. **Recline Seatback:** Pull the lever up to adjust the seatback. Release the lever and make sure the seatback is locked into place.
4. **Seatback Fold Lever:** To get in and out of the back seats, pull the seatback fold lever to fold the desired seat. When finished, return the seatback to the upright position until it locks in place.




Manual Seat Levers



Seatback Fold Lever

Head Restraint Adjustment

Pull the head restraint up to raise it. To lower the head restraint, push it down while pressing the release button on the top of the seatback. Each head restraint should be adjusted so that the center of the head restraint is closest to the top of the occupant's ears.



TILT AND TELESCOPIC STEERING COLUMN

You can adjust both the height and lengthwise position of the steering wheel. Pull the lever on the steering column down firmly to unlock, and then adjust the position of the steering wheel. Push the lever firmly back up to lock the steering wheel in place.



Steering Column Unlock

POWER EXTERIOR MIRRORS

The power mirror knob works with the ignition in the “ON” or “ACC” position. Turn the knob to “L” (left side) or “R” (right side) to select a mirror. Push the knob in the direction you want to move the mirror. Turn the knob back to the center position when finished.



Power Mirror Knob

REAR VIEW MIRROR

Auto-dimming Mirror (if equipped)

The auto-dimming function senses distracting glare during nighttime driving and automatically dims to eliminate the glare and preserve your vision. Press the switch to turn auto-dimming on or off. A green LED indicator illuminates when the function is on.



HomeLink® 5 Accessory Mirror (if equipped)



The HomeLink® 5 accessory mirror provides three buttons to replace devices such as garage door openers, gate openers, entry door locks, security systems, and home lighting. The "Instruments and Controls" chapter in your Owner's Manual provides programming instructions, and **www.subaru.com/homelink** has a helpful "how to" video.

NOTE: HomeLink® 5 may not be compatible with some older door openers or additional equipment may be required.

Scan to learn more about **HomeLink®**.

POWER WINDOWS

To open or close a window, partially press down or pull up and hold the corresponding switch. The windows also have a one-touch auto up/down function. Fully press down or pull up and release to automatically open or close a window.



Power Window Switches

CLIMATE CONTROL

Dual-zone Automatic Climate Control



You can set separate temperatures for the driver and passenger seats. Set your desired temperature and let the system automatically make the adjustments for you. At any time, you can manually take control of the climate settings.

1. **ON/OFF Button:** Press this button to activate or deactivate the climate control system.

Operation in Automatic Mode

2. **Automatic Control Button:** This system automatically controls all of the climate systems except defogging. Press “AUTO” to activate.
3. **Temperature Control Dial:** Rotate the temperature control dial to set your preferred temperature. The temperature appears in the dial. You can adjust separate temperature settings for the driver’s side and passenger’s side.
4. **SYNC Button:** Press the button to synchronize the driver's and front passenger's temperatures to the driver’s temperature control dial. The SYNC button indicator illuminates. Press the SYNC button again or turn the passenger’s side temperature control dial to cancel SYNC mode and set separate driver and passenger side temperatures.

When using automatic mode, the fan speed, airflow distribution, air-inlet control and air conditioning are controlled automatically. To activate:

1. Press the “AUTO” button. The “FULL AUTO” indicator light illuminates on the indicator in the fan speed control dial.
2. Set the preferred temperature using the temperature control dial.

If you operate any of the buttons other than “ON/OFF”, rear window defogger, “SYNC” or the temperature control dial, the “FULL” indicator light will turn off. The “AUTO” light will remain illuminated. You can then manually control the system as desired. Press the “AUTO” button to change back to “FULL AUTO” mode.

Operation in Manual Mode

5 **Air Inlet Selection Button:** Select this button to activate recirculation mode and recirculate the interior air inside the vehicle. Recirculation mode is helpful when driving on a dusty road or when you want cooling performance to increase. Select the button again to return to outside air circulation mode and allow outside air to be drawn into your Subaru.
NOTE: To prevent windshield fogging, do not remain in the recirculated mode for an extended period of time.

6 **Fan Speed Control Dial:** Turn the fan speed control dial to increase or decrease fan speed.

7 **Airflow Mode Selection Button:** Press the button to select the desired airflow mode. The selected mode – ventilation, ventilation 2, bi-level, feet or feet-defrost – is shown by the indicator on the fan speed control dial.

ICON	MODE	FUNCTION
	**Ventilation**	Instrument panel outlets
	**Ventilation 2**	Instrument panel outlets and less foot outlets than bi-level
	**Bi-Level**	Instrument panel outlets and foot outlets
	**Feet**	Foot outlets, both side outlets of the instrument panel and some through windshield defroster outlets
	**Feet-Defrost**	Windshield defroster outlets, foot outlets and both side outlets of the instrument panel
	**Defrost**	Windshield defroster outlets and both side outlets of the instrument panel

NOTE: The defroster button is used to activate the defrost airflow mode.

8. **Air Conditioner Button:** Press this button to activate or deactivate the air conditioning.
9. **MAX A/C Button:** Press this button for quickest cooling.
10. **Defroster Button:** Press this button to defrost or dehumidify the windshield and door windows.
    NOTE: When defrost or feet-defrost is selected, the air conditioning operates automatically to defrost the windshield more quickly. However, the indicator on the air conditioner button may not illuminate.
11. **Rear Window Defogger Button:** Press this button to turn on the rear window defogger. It will automatically turn off after about 15 minutes. If the window clears before then, press the button again to turn it off. The outside mirror defogger will also activate. You can customize this function for continuous operation through the Subaru Multimedia System by selecting “Settings” and then “Car.”

Remote Engine Start with Climate Control (if equipped)

Scan to get the **MySubaru** App.

You can remotely start your Subaru and adjust the temperature using MySubaru Companion+ features through the **MySubaru** mobile app (subscription required). Please refer to “MySubaru Features” in your MySubaru Owner's Manual for a list of required vehicle conditions for this feature.

Heated Seats

The heated seat switches are located between the driver and passenger seats. There is a separate switch for the driver and passenger. Press the “HI” button for more rapid heating or press the “LO” button for normal heating. Return the switch to the center position to turn off the heated seat.



Heated Seat Switches

ACCESSORY CONNECTIONS



1 Auxiliary Input Jack:

The 3.5mm auxiliary input jack is located in the center console. You can connect a portable music player to the auxiliary jack and hear the music stored on it through your Subaru's speakers. Press the "Source" button located on the steering wheel or the "Media" button on the Subaru Multimedia System to select the auxiliary mode.

For more information, please refer to page 55 in this Getting Started Guide or "Audio" in your MySubaru Connected Services Owner's Manual.

2 Dual USB Ports:

The USB ports are located in the center console. You can connect a variety of USB-equipped devices, such as portable music players or smartphones, to enjoy your favorite music or connect to Apple CarPlay® or Android Auto™. These ports also provide charging (5V, 2.1A) to devices.

For more information on connecting to the USB ports, please refer to page 55 in this Getting Started Guide or "Audio" in your MySubaru Connected Services Owner's Manual.

For more information and set up instructions, please refer to page 92 for Android Auto™ and page 94 for Apple CarPlay® in the How To Appendix in this Getting Started Guide.

3 Power Outlets:

A power outlet (12V) is provided in the glove box. Electrical power is available for use with in-vehicle electrical appliances with a maximum power rating of 120W. This outlet cannot be used to connect to the Subaru Multimedia System.

For more information, please refer to "Interior Equipment" in your Owner's Manual.

PUSH-BUTTON IGNITION SWITCH



Each time you press the ignition switch without depressing the brake pedal (or clutch pedal for manual transmission vehicles), the ignition position will change as follows: ACC, ON, OFF.

ACC (Accessory): Provides power to the audio system and accessory power outlets.

ON: All electrical systems are available.

OFF: Power is switched off.

STARTING THE VEHICLE

With Push-button Ignition

To start the engine:

1. Sit in the driver's seat with the access key fob.
2. Make sure the select lever is in the "P" position or neutral for manual transmission vehicles.
3. Depress the brake pedal (and clutch pedal for manual transmission vehicles).
4. While depressing the brake pedal (and clutch pedal for manual transmission vehicles), briefly press and release the push-button ignition switch.

DRIVING THE VEHICLE

6-Speed Manual Transmission

This manual transmission is a fully synchronised 6-forward and 1-reverse speed transmission. To shift into the "R" position, raise and hold the slider ring, move the lever into the "R" position, then release the slider ring. Only pull the slider ring up when shifting into reverse gear.



Automatic Transmission Shift Mode (if equipped)



The transmission is electronically controlled and provides two different driving modes: normal and manual.

Normal Mode

When the select lever is in the “D” (Drive) position, the transmission is in normal shift mode. The select lever position indicator in the Combination Meter shows “D” and the transmission automatically shifts into a suitable forward gear.

Manual Mode

In manual mode, you select the desired gear position to obtain necessary acceleration and engine braking. Move the select lever left from the “D” position into the “M” position to select manual mode. The gear position indicator in the Combination Meter shows the currently selected gear from “M1” to “M6”. Arrow-shaped indicators show when upshifting or downshifting is available. To shift gears, use the paddle shift control switches behind the steering wheel or shift the select lever toward the “+” or “-” side.


Paddle Shift Control Switches (if equipped)



You can shift gears using the paddle shift control switches. To upshift to the next higher gear, pull the “+” paddle on the right toward you. To downshift to the next lower gear, pull the “–” paddle on the left toward you.

You can temporarily shift gears even when the select lever is in the “D” position by pulling either the “+” or “–” paddle toward you. In this case, “M” and the selected gear number will be displayed on the combination meter.

REV Alarm System



You can activate or deactivate the REV Alarm System and adjust the settings by navigating the Combination Meter Display to “Screen Settings”. The REV Alarm System has the following functions:

When the engine speed reaches a set speed, the select lever/gear position indicator will illuminate in orange and a buzzer will sound.

If the engine speed enters the red zone, the select lever/gear position indicator will illuminate in red.

For more information, please refer to “Instruments and Controls” in your Owner’s Manual.

DRIVING SYSTEMS/MODES

To help enhance driving safety and performance, you can operate the following systems in response to various driving situations or preferences:



1. **Vehicle Stability Control OFF:** Briefly press the Vehicle Stability Control (VSC) OFF switch to deactivate the TRAC system. Deactivating the TRAC system may help recover from the loss of traction in certain situations:
   - A standing start on a steeply sloping road with a snowy, gravel-covered, or otherwise slippery surface
   - Navigating a vehicle stuck in mud or deep snow

2. **TRACK Mode:** Your vehicle is equipped with two types of control modes to accommodate various driving preferences. The control modes can be selected with the TRACK button. Normal mode allows secure and smooth normal driving. When the TRACK button is pressed and held for one second or longer, TRACK mode is activated. Control characteristics such as the VSC system and traction control are adjusted to afford more maneuverability, while a sense of security is retained.

3 **Driving Mode Select Switch:** The following modes can be selected with the Driving Mode selection switch to suit driving usage and conditions:

- **Sport Mode:** Push the switch toward the “SPORT” mode for sporty driving or when driving in mountainous regions with lots of curves. For automatic transmission vehicles, if Sport mode is selected with the select lever in the “D” position, the selected gear, from “D1” to “D6” is displayed on the combination meter. For manual transmission vehicles, only select Sport mode when the vehicle is stationary or when the accelerator pedal is released. Changing to Sport mode while accelerating may cause the vehicle to vibrate. To cancel sport mode, push the switch toward “SPORT” mode again.
- **Snow Mode (automatic transmission vehicles only):** Push the switch toward the “SNOW” mode for accelerating and driving on slippery road surfaces, such as snow. To cancel snow mode, push the switch toward “SNOW” mode again.

For more information and cautions using these driving systems/modes, please refer to “Starting and Operating” in your Owner’s Manual.

TURNING OFF THE VEHICLE

With Push-button Ignition

To stop the engine:

1. Stop your Subaru completely.
2. Move the select lever to the “P” position or set the parking brake for manual transmission vehicles.
3. Press the ignition switch to stop the engine. For manual transmission vehicles, it is recommended to leave the vehicle in gear (1st gear for an upgrade and reverse for a downgrade).

NOTE: The windows will remain active for about 40 seconds or until a door is opened, whichever occurs first.

FUEL FILLER LID

The fuel filler lid is located toward the rear of the passenger side. To open the lid:

1. Make sure your Subaru is completely stopped and parked. Then, turn the ignition to the off position.
2. The fuel filler lid is unlocked by using the unlock switch in the door, access key fob, or door handles.
3. Push the rear side of the lid.
4. When the lid opens slightly, open it further by hand.



Fuel Filler Lid and Cap

While refueling, place the fuel filler cap on the cap holder inside the lid.

After refueling, put the cap back on and turn it clockwise until you hear a clicking noise. Be certain not to catch the tether under the cap while tightening.

To close the lid, press it until you hear it latch.

NOTE: The Check Engine warning light may illuminate if the fuel filler cap is not tightened properly.


FUEL SPECIFICATIONS AND CAPACITY

2.4L Engine Fuel Specifications and Capacity

Fuel Octane Rating	93 AKI or higher
Ethanol Content Limit	No more than 15%
Fuel Tank Capacity	13.2 US Gallons
Low Fuel Warning Light	1.8 US Gallons Appx.

FOLDING THE REAR SEATBACK

To fold the rear seatback, push the right and left seat release buttons on the seatback until the red marker is visible and fold down the seatback. To return the seatback to its original position, raise the seatback until it locks into place. You will no longer be able to see the red marker on the seat release buttons when the seat is locked.



Seat Release Button

To fold the rear seatback from the outside, open the trunk, pull both seat release straps, and push the seatback forward. The front seats may be need to be moved forward to clear the folding rear seatback.



Seat Release Straps

Passenger Occupant Detection and Seatbelt Reminders

To help keep your passengers safe, your Subaru has a passenger occupant detection and seatbelt reminder system for each seat, including the rear seats.

If passengers in the rear seats do not fasten their seatbelts while the ignition is in the "ON" position, the seatbelt warning lights illuminate or blink for the specific seat, and a warning chime may sound.


For more information, please refer to “Instruments and Controls” in your Owner’s Manual.



LATCH/ANCHOR

Your Subaru is equipped with Lower Anchors and Tethers for Children (LATCH). For maximum safety, first carefully read the LATCH system instructions from the device manufacturer, as well as the installation instructions in your Owner's Manual, to properly install the LATCH compatible restraint system. Use the appropriate seatbelts or anchorages provided in your Subaru. Children age 12 and under must properly occupy the rear seat at all times.

For more information, please refer to "Seat, Seatbelt and SRS Airbags" in your Owner's Manual.



INTERNAL SAFETY TRUNK RELEASE WITH SELF-ILLUMINATING HANDLE

In the event that children or adults become locked inside the trunk, this luminescent handle allows them to open the lid from inside the trunk. To open, simply pull the yellow handle as indicated by the arrow on the handle and then push up on the lid.



TRUNK LID OPENER

To open the trunk, press and hold the trunk lid opener switch in the lower left instrument panel.



FLAT TIRE REPAIR KIT

Your BRZ comes equipped with a flat tire repair kit and the following maintenance tools:

- Jack
- Jack handle
- Screwdriver
- Towing hook (eye bolt)
- Wheel nut wrench



For repair kit instructions and more information, please refer to “In Case of Emergency” in your Owner’s Manual.


HOOD PROP

The hood prop is located in the left front of the engine compartment. Unfold it and insert the end into the slot marked with an arrow.



ENGINE COMPARTMENT

2.4L ENGINE



1. Clutch Fluid Reservoir (MT models)
2. Brake Fluid Reservoir
3. Windshield Washer Tank
4. Engine Oil Filler Cap
5. Engine Oil Filter
6. Air Cleaner Element
7. Engine Oil Dipstick
8. Engine Coolant Reservoir
9. Radiator Cap
10. Fuse Box
11. Battery

The following table lists recommended first service items. Your maintenance needs may vary depending on your driving conditions. Please consult with your Retailer and refer to the Warranty and Maintenance Booklet for complete information and recommended replacement intervals.

Maintenance Item	Maintenance Interval	
	6 months or 6,000 Miles	12 months or 12,000 Miles
Replace Engine Oil and Filter	•	•
Rotate and Inspect Tires	•	•
Replace HVAC System A/C filter		•
Inspect Clutch Operation (Manual Transmission)		•
Inspect Rear Differential Gear Oil		•
Inspect Brake System, Steering System, and Suspension Components		•

ADDITIONAL SPECIFICATIONS

NEW VEHICLE BREAK-IN

The performance and long life of your Subaru are dependent on how you handle and care for your Subaru while it is new.

Follow these instructions during the first 1,000 miles:


- Do not race the engine.
- Do not allow the engine speed to exceed 4,000 rpm except in an emergency.
- Do not drive at one consistent engine or vehicle speed for a long time, either fast or slow.
- Avoid starting suddenly and rapid acceleration, except in an emergency.
- Avoid hard braking, except in an emergency.

ENGINE OIL SPECIFICATIONS & CAPACITIES

Use 0W-20 Synthetic Engine Oil.
5.3 US quarts (during oil and filter change).

When the level is at the "low" mark, add approximately 1.1 US quarts of engine oil in through the filler cap to bring the oil level to the “full” mark. For filler cap location see the engine compartment on page 38.

1. Full Level
2. Low Level



TRAILER TOWING CAPACITY

Your BRZ is neither designed nor intended to be used for trailer towing. Therefore, never tow a trailer with your vehicle.


For more information, please refer to “Driving Tips” in your Owner’s Manual.

TIRE PRESSURE MONITORING SYSTEM (TPMS)

Your Subaru has a Tire Pressure Monitoring System (TPMS) that tracks the pressure of each individual tire. You can learn more by scanning the QR code to see a video with tips and more information about your Subaru's TPMS.

Scan to learn more about the **Tire Pressure Monitoring System.**

The TPMS screen shows individual tire pressure in the Combination Meter Display. Use the Combination Meter Display controls to view the TPMS screen.



TPMS Screen

The TPMS set switch, located in the glove box, can be used to initialize the TPMS setting:

1. Adjust the tire inflation pressure to the specified cold tire inflation pressure level, listed on the tire inflation pressure label on the driver's side door pillar.
2. Press and hold the TPMS set switch with the ignition in the "ON" position until the tire pressure monitoring light blinks slowly 3 times in the Combination Meter.



TPMS Set Switch

NOTE: Initialization cannot be performed while the vehicle is moving.

ADDITIONAL SPECIFICATIONS

Tire pressure specification is listed on the tire inflation pressure label located on the driver's side door pillar and in the following table. For complete tire pressure specifications and information, please refer to the tire specifications in your Owner's Manual.



Tire Inflation Pressure Label

Tire Inflation Pressure	
Front Wheel	**Rear Wheel**
35 psi	35 psi

OVERVIEW OF YOUR MULTIMEDIA SYSTEM

Subaru Multimedia combines the radio along with the ability to connect your phone* through Bluetooth® for making calls, sending text messages and listening to your favorite songs on your phone.

* Compatible smartphone and application required. For applications to operate, latest version of each application required. Data provided by smartphone is displayed on the Touchscreen. Some state laws prohibit the operation of handheld electronic devices while operating a vehicle. Smartphone apps should only be launched when vehicle is safely parked. Your wireless carrier's rates may apply.

Various Systems

Depending on your model and trim level there are several types of Subaru Multimedia Systems. Some of the functions described in this guide will vary by system.

Screen Layout



1. **Car Settings:** Allows you to adjust a number of vehicle settings, even while driving.
2. **Status Bar:** The very top of the screen, which shows the outside temperature and clock. Tap on the clock display to adjust the time and other clock settings.
3. **Home Screen:** The main part of the display where media, phone features, apps, and car information is accessed.

BUTTONS

Radio Functions



1 Power/Volume Control

Press the power/volume control knob to mute or un-mute the audio. Rotate the knob left to decrease or right to increase the volume.

2 Tune

Rotate the knob to change the radio station or select the next or previous track/file. Press and hold the knob to display the sound customization screen.

3 Radio

Press the RADIO button to display the AM/FM/SXM screen. The different tuner modes can be selected by touching the source you want to hear.

4 Seek

Press the seek up or seek down button to seek the next or previous radio frequency. You can also use the seek up or down buttons to select different audio tracks from media sources. Press and hold to fast-forward or rewind.

Other Functions

5 Home

Displays the Home screen apps. The Home screen allows you to customize which apps appear and rearrange the icons in a personalized order.

6 Phone

Displays the phone screen, allowing you to place and receive calls and text messages.

7 Apps

Displays the installed apps that are available on your vehicle.

Controlling the Volume



Adjusting the Volume: Turn the “VOLUME” knob to adjust the volume. The volume stays at your set level even after an ignition cycle.

Muting the Volume: Press and release the knob once to turn on or mute the audio.

Turning the System Off: Press and hold the knob for about three seconds and select “OK” when the message appears to turn the system off. The system remains off after an ignition cycle. Press and hold the knob to turn it back on.

TOUCHSCREEN

Operations are performed by touching the screen directly with your finger.

MOTION	ACTION	USE
	**Touch** Quickly touch and release once.	Changing and selecting various settings
	**Drag*** Touch and drag your finger on the screen to move the screen to the desired position.	• Scrolling lists • Scrolling screens
	**Swipe*** Quickly move the screen by swiping with your finger.	• Scrolling lists • Scrolling screens

* The operations may not be performed on all screens.

STEERING WHEEL CONTROLS

1. **Source:** Press to turn on the audio system or change the audio source mode. Press and hold to turn off the audio system.
2. **Volume +/Volume –:** Push the "+" side of the switch to increase the volume or the "–" side to decrease the volume.
3. **Presets/Skip:** Press to toggle through your presets or change a track or media file. Press and hold to fast-forward or rewind.
4. **Call:** Press to receive a call without taking your hands off the steering wheel.
5. **End:** Press to end a call without taking your hands off the steering wheel.
6. **Voice Recognition:** Press to activate the built-in voice recognition function. Press and hold to activate the Apple CarPlay®/Android Auto™ voice recognition function.



MySubaru Audio Controls



MySubaru Audio Controls

VOICE RECOGNITION

With Subaru Multimedia, simple voice commands can control features like phone calls, entertainment, and applications.
A microphone is located in the overhead console; however, you do not need to speak directly into it to activate the voice command features. Press the Voice Recognition button on the steering wheel to start the voice recognition system. Press and hold the button to cancel the system.

For help with what features are available with voice recognition, press the "Help" button on the screen or press the voice recognition button and say "Help".

Scan to learn more about Subaru **Multimedia**.

Tips

The system may not recognize the voice command due to various types of interference. The following are some causes for voice command interference:

- The command is spoken too quickly or at a low or high volume.
- The command is incorrect or unclear.
- The window is open, the climate control system is set on high, or the ventilation is directed toward the microphone.
- Passengers are talking while the command is spoken.

NOTE: The system is designed to recognize a variety of commands, but certain words, accents or speech patterns may be difficult for the system to recognize.

Common Commands

Below are examples of common commands that can be used with the voice recognition system. Please refer to “Siri/Voice Recognition System” in your MySubaru Owner’s Manual for a complete list.

VOICE COMMAND	FUNCTION	EXAMPLE
Dial [Number]	Places a call to the phone number	Dial 555-123-4567
Call [Name] [Phone Type]	Places a call to the contact name and phone type of the contact from the phonebook	Call John Doe mobile
Tune to [Frequency] (AM / FM)	Switches to AM/FM and tunes to spoken frequency	Tune to 99.5 FM
Tune to Preset [Number]	Switches to the preset channel	Tune to Preset 3
Satellite Channel [Number]	Switches to satellite channel number	Satellite Channel 58
Launch [App Name]	Activates the spoken application	Launch MySubaru
Help	Changes to help screen	Help
Phone Help	Displays a list of voice commands related to controlling your phone	Phone Help
Music Help	Displays a list of commands related to media/music	Music Help
Apps Help	Displays a list of commands related to applications	Apps Help

HOME SCREEN ICONS

MySubaru – Whether you're on the road or planning adventures, the MySubaru app makes loving every part of owning your Subaru easy.

Apps – Entertainment and convenience applications to enhance your driving experience. The apps included are: MySubaru, Travel Link®, Android Auto™, and Apple CarPlay®.

Radio – Select a station to listen to as well as pause and playback live radio.



Home Screen Icons

Maintenance – Allows you to set maintenance reminders.

Media – Play USB/iPod music or Bluetooth® audio by connecting to the device.

Phone – Place and receive calls and text messages.

Settings – Change the settings to your personal choice for select systems inside the vehicle.

Scan to learn more about **MySubaru Connected Services.**

REARRANGING ICONS

You can rearrange the home screen icons when in Edit Mode (first make sure "Home Screen Shortcuts" is enabled in "Settings").

To rearrange icons:

1. Select and hold the shortcut icon you want to move until "Edit Mode" is displayed at the top of the screen.
2. Drag the icon to the desired position and release.
3. To delete an icon, drag the icon to the area at the bottom of the screen labeled "DRAG HERE TO DELETE" and release.
4. To exit "Edit Mode" push the "Home" button.



ADDING SHORTCUTS


You can add shortcut icons for various functions to the Home screen when the Home Screen Shortcut function is turned on. To turn on the Home Screen Shortcut function, go to “Settings”, and then the “General” menu.

To add icons, press the “Home” button.


1. Select “Add Shortcut”.



2. Select the desired function.



3. Select the desired shortcut function.



4. Check that the shortcut icon is displayed on the Home screen.




CREATING A DRIVER PROFILE

Creating a Driver Profile provides many benefits beyond just pairing a phone. The profile records and remembers station presets, sound preferences, phone favorites, screen icons and placement.

To create a driver profile:


1. On the Home screen, select “Settings”, then in the “General” menu, select “Driver Profiles”.



2. Select “Add”.



3. Select a language and then select “Next”.



4. Select “Driver’s Name”.



5 Type your name in using the keyboard screen, select “Next”.



6 Select “Next” on the following screen to go to phone pairing.



7 Select “Add Phone” to pair your phone to the system (see page 86 and 89 in the How To Appendix) or select your phone if it is already paired and select “Finish” when complete.




To edit a driver profile:

1. On the Home screen, select “Settings” and in the “General” menu, select “Driver Profiles”.
2. Select "Edit", then select a profile. You can then edit the profile according to same steps as creating a profile.

Retrieving a Driver Profile

There are two ways to retrieve a driver profile. The system may automatically retrieve the profile once you are in your Subaru with the multimedia system on and your phone's Bluetooth® active. You can also manually retrieve or change the profile by following these steps:

1. Select "Settings", then select "Driver Profiles".
2. Select the profile you want. You will receive a pop up screen asking " Are you sure you want to activate this profile?"
3. Select "OK".



RADIO

AM/FM Radio

Your Subaru is equipped standard with AM/FM radio, including HD Radio®. HD Radio® technology allows you to receive digital broadcasts (where available) in addition to analog broadcasts. Digital broadcasts provide free, crystal clear audio with no static or distortion.

Visit **www.hdradio.com** for more information and a guide to available radio stations and programming.



Scan to learn more about **HD Radio**.

Satellite Radio

A SiriusXM Satellite Radio is a tuner designed exclusively to receive broadcasts provided under a separate subscription. After a free trial period, a subscription is necessary to continue service.

For more information or to subscribe, visit **www.siriusxm.com**.



Scan to learn more about **SiriusXM Radio.**

Presets




You can preset 18 stations. Presets can be set for SiriusXM, FM, or AM stations, allowing you to switch among the three with the press of a single button. To preset a radio station:

1. Tune to the desired channel.
2. Press and hold the desired preset station button at the bottom of the screen.

MEDIA

Bluetooth®



Your Subaru has Bluetooth® hands-free technology to manage your phone and audio systems. Bluetooth®-enabled mobile phones link directly through your Touchscreen automatically, once connected. Receive and initiate calls or play music directly from your device while keeping it stowed for safety.

To pair a Bluetooth® device to the Touchscreen, see page 59 for Android devices or page 59 for Apple devices.

USB/iPod

You can plug in a USB memory storage device or iPod into the USB ports. This will bring up the media screen with controls. If using an iPod, make sure to use an Apple certified cable or MFi certified cable for proper operation.

AUX Input

The AUX jack is a port that allows input from an audio device such as MP3 players, portable music players, and iPods. To access the AUX menu, plug in the device to the AUX jack and the menu will appear, or select the AUX menu from the “Media” Screen.

PAIRING A PHONE

To begin using your Bluetooth® hands-free device you must first pair your phone with the system. Phone pairing provides access to the contact list on your phone and allows you to use the voice recognition system to make and receive calls. The system can also read incoming text messages, and allow you to send short messages to reply to texts. The system automatically reconnects to your Bluetooth® device and will remember your driver profile.

Scan to learn more about **Subaru Multimedia**.

MAKING A CALL

With a paired phone, you can make a call through voice recognition by touching the "Voice Recognition Switch" on the steering wheel to start the voice recognition system. After pressing the "Voice Recognition Switch", wait for the "Voice Guidance" screen to appear on the Touchscreen and say "Call [name and phone type]" or "Dial [number]".



To make a call from the Touchscreen, start by pushing the "Home" button and then select "Phone". After the phone screen displays, select the method you would like to use to make a call.



- Recents – Allows you to call someone that has recently called you or that you called.
- Favorites – Allows you to place a call to one of your registered favorites.
- Phonebook – Will display the phonebook that is on your phone.
- Messages – Allows you to call someone that recently sent you a text message.
- Keypad – Allow you to dial any number you would like.

RECEIVING A CALL

To receive a call, press the “Call” switch on the steering wheel or the “Accept” button on the Touchscreen.





To reject a call, press the “End” switch on the steering wheel or the “Decline” button on the Touchscreen.






TEXT MESSAGES

Received messages can be forwarded from the connected Bluetooth® phone, enabling playback and reply functions using the system. To use this function, it is necessary to set the phonebook download function to ON.

When a Short Message Service (SMS)/ Multimedia Messaging Service (MMS) is received, the incoming message screen pops up with sound and is ready to be retrieved using the Touchscreen. Select “Play” to listen to the message.

If there is more than one unread message, a screen will appear allowing you to either view your inbox or ignore the message.

Depending on the Bluetooth® phone type, messages may not be transferred to the inbox, the screen display may differ, and it may not be possible to use certain functions.





IN-VEHICLE APPS

MySubaru Connected Services offers advanced connectivity through Apple CarPlay® or Android Auto™ apps. Wireless pairing and hands-free smartphone operation allow for safe and easy connection to your favorite apps and content.

For a complete list of all the apps available, visit **www.subaru.com**

Scan to learn more about Subaru **Multimedia**.

Android Auto™

Android Auto can be used to view maps, play music, and place calls by connecting your Android device to the system. You can also run supported applications. To use the Android Auto application, connect your Android device to the USB port.

For details on services or operations, visit the Android Auto sites: **www.android.com/auto/** or **www.support.google.com/androidauto/**

For more information on connecting your phone, please refer to page 92 in this Getting Started Guide.

Scan to learn more about **Android Auto**.

Scan to learn more about **Android Auto Help**.

Apple CarPlay®


Apple CarPlay can be used to view maps, play music, and place calls by connecting your iPhone to the system. You can also run supported applications. To use the Apple CarPlay application, connect your iPhone to the USB port.

For more information on connecting your iPhone, please refer to page 95 in this Getting Started Guide.

For details on services or operations, check the Apple CarPlay site: **www.apple.com/ios/carplay/**

Scan to learn more about **Apple CarPlay**.

SiriusXM Travel Link®



SiriusXM U.S. satellite and data services are available in the 48 states of the contiguous USA and DC.

Data service information, comprising fuel prices, sports, stocks, weather, weather alerts, and parking, can be received via the SiriusXM Radio.

To receive the data service information in the vehicle, a subscription to the SiriusXM Satellite Radio Service is necessary following a free trial.

MYSUBARU

Whether you're on the road or planning adventures, the MySubaru app makes loving every part of owning your Subaru easy. Although the mobile app is great when you are on the go, you can also visit **www.MySubaru.com** from your computer to access similar functions and to aid in planning your trip before you leave.
You can download the MySubaru app from the Google Play Store or the Apple App Store on your phone by searching MySubaru.

Scan to get the **MySubaru** App.

By creating an account, you can:

- Schedule service with a preferred Subaru Retailer
- Get vehicle service reminders, recall alerts, and exclusive coupons
- Track and record your service history
- Access resources like your owner's manuals, how to videos and more
- Access MySubaru Companion and Companion+ features (must have an active MySubaru Connected Services subscription)
- Get help from 24-hour roadside assistance (24-hour roadside is included in standard 3-year warranty)

Service Appointment Scheduler



The MySubaru Service Appointment Scheduler can help you set an appointment from the MySubaru website, Mobile App or the vehicle's Touchscreen. Getting your Subaru vehicle to the Subaru professionals for service is easy, no matter where you are. If you are away from your preferred Subaru Retailer for service, you can always use Service Appointment Scheduler to locate any of our certified Subaru Retailers near your location.

MySubaru Service Appointment Scheduler on your Touchscreen is a convenient way to set a service appointment. Simply select the MySubaru icon on the home screen and choose "Make an Appointment" to get started.

An active MySubaru Connected Services subscription is required to use this in-vehicle feature.

MYSUBARU COMPANION AND MYSUBARU COMPANION+ OVERVIEW

MySubaru Companion and Companion+ features* are designed to help in your time of need. These include Advanced Automatic Collision Notification, SOS Emergency Assistance, Enhanced Roadside Assistance, Stolen Vehicle Recovery, the added convenience of Remote Engine Start with Climate Control, and so much more.

With the MySubaru Connected Services system integrated into your vehicle, advanced safety and security technology is just a button press away. The MySubaru Connected Services experience includes in-vehicle call center support, maintenance and diagnostic alerts as well as remote services that keep you connected to your Subaru vehicle.

Located in the overhead console of most Subaru vehicles are the red SOS SOS and blue i-button ((i)). Both buttons link you to MySubaru Customer Care that is there to support you 24 hours a day, 7 days a week.

The SOS button SOS is for SOS Emergency Assistance.

The i-button ((i)) is for Enhanced Roadside Assistance or Concierge (if subscribed).



- Press the SOS button SOS for SOS Emergency Assistance.*
- Press the i-button ((i)) for Enhanced Roadside Assistance* or Concierge* (if subscribed).*
- To cancel a SOS Emergency Assistance, Enhanced Roadside Assistance or a Concierge call, press and hold the same button for approximately two seconds or select the “End Call” button if displayed on the Touchscreen.

Head to **www.Subaru.com** to see all the MySubaru subscription services and packages.

* Access to MySubaru Companion and Companion+ services requires an active MySubaru Connected Services subscription. Not available in all States. See Retailer for details. Remote Engine Start available on keyless access with push-button start vehicles. Remote Engine Start with Climate Control is available on select models only. Not available on vehicles with manual transmission. See Retailer for details or visit the MySubaru page on Subaru.com to learn more.

Scan to learn more about **MySubaru Connected Services.**

ENROLLMENT

To enroll in MySubaru Connected Services subscription, a MySubaru account is required. You can set an account up with your retailer on-site or you can self-service at **www.mysubaru.com** You can also enroll by calling a MySubaru Customer Care Agent at 1-855-753-2495. Once your account is set up you can access all of the great MySubaru features in your MySubaru mobile app (Apple and Android compliant).

NOTE: Please have your Vehicle Identification Number (VIN) available, as you will need it to complete this step. After the enrollment process, you will learn more about the features in detail at MySubaru.com.

MYSUBARU INTEGRATION

The connection between you and your Subaru has never been simpler, and the MySubaru website (MySubaru.com) and MySubaru Mobile app are the best ways to stay in touch with your Subaru vehicle. From MySubaru, you can access the following information and MySubaru Connected Services*:

- Remote Services
- Vehicle Health
- Usage Reports
- Service Appointment Scheduler
- Vehicle Maintenance Schedules
- Service History
- Support Resources

* Activation with subscription required. Features and availability vary by vehicle and trim level. See your Retailer for details.

AT&T WI-FI HOTSPOT

In-vehicle AT&T Wi-Fi Hotspot* keeps you and your family connected using AT&T's 4G LTE nationwide cellular network. Whether watching movies, playing games or even listening to music, your family won't miss a beat with in-vehicle AT&T Wi-Fi Hotspot. Set up is quick and easy.

Scan to learn more about **AT&T Wi-Fi Hotspot**.

For more information on a subscription and step by step enrollment instructions, please refer to page 97 in this Getting Started Guide or visit:

https://myvehicle.att.com/#/subaru/learn?country=US&language=en

* Internet access is purchased separately through AT&T with monthly, per gigabyte, and unlimited data options available. Existing AT&T customers have the option to add an additional line to their AT&T Mobile Share plan. Available on select models.

SETTINGS AND UPDATES OVERVIEW

Many settings can be customized for different features in your Subaru. In this section you will find examples and instructions for some of the settings you can tailor to fit your preferences, as well as ways to keep your system updated.

Connect to Home Wi-Fi

Connecting to your Wi-Fi network can allow you to update the software. Wi-Fi can be found from the Home Screen by selecting “Settings”, then in the “General” menu, select “Wi-Fi”.



For step by step instructions on connecting to Wi-Fi, please refer to page 96 in this Getting Started Guide or “Settings” in your MySubaru Owner’s Manual.

SOUND

To change the sound settings, press the “Home” button and select “Settings”, then “Sound”. Choose the setting you want to change.

Settings may vary by Trim and Audio Grade. For more information, please refer to “Sound Settings” in your MySubaru Owner’s Manual.

SETTING	FUNCTION

Audio	In the audio settings, you may have the following setting capabilities:
	• **Sound Customization** — This function allows you to set the Equalizer, Balance/Fader and Vocal Image Control.
	  • **Equalizer** — How good an audio program sounds is largely determined by the mix of the treble, mid and bass levels. In fact, different kinds of music and vocal programs usually sound better with different mixes of treble, mid and bass.
	  • **Balance/Fader** — A good balance of the left and right stereo channels and of the front and rear sound levels is also important. Keep in mind that when listening to a stereo recording or broadcast, changing the right/left balance will increase the volume of 1 group of sounds while decreasing the volume of another.
	  • **Vocal Image Control** — Extracts only vocal sound from whole sound and adjusts volume balance off vocals only.
	• **Sound Restorer** — This function plays compressed audio with quality near original sound by adding the complement signal of high tone.
	• **Virtual Bass** — This function corrects the bass sound by adding harmonic sound.
	• **Dynamic Beat Enhancer** — This function expands the dynamic range lost in data compression and creates a sharp beat sound.
	• **Speed Volume Control** — The system adjusts to the optimum volume and tone quality according to vehicle speed to compensate for increased vehicle noise.
	• **AUX Volume Gain** — Sets the AUX volume gain.

Notification Volume	Sets the interrupt guidance volume.
Beep Sound Setting	Turns the tone sound on or off.
Beep Sound Volume	Sets the tone sound volume.
Phone Ringtone Volume	Sets the ringtone volume.
Incoming Call Volume	Sets the volume of the received call.
Call Volume	Sets the call volume.
SMS/MMS Ringtone Volume	Sets the SMS/MMS ringtone volume.
SMS/MMS Read Out Volume	Sets the SMS/MMS read out volume.
Voice Volume	Sets the voice recognition prompts volume.

PHONE

This system supports Bluetooth®, a wireless data system, allowing you to make and receive calls without taking your hands off the steering wheel.

In the settings menu, you will be able to manage devices, adjust phone book and message settings, and adjust other phone/Bluetooth® settings.

To access the phone settings screen, press the “Home” button, select “Settings”, then select the “Phone” menu.

CLOCK

Clock settings can be adjusted when the ignition is in the “ON” position. You can adjust the clock manually or set the clock to adjust automatically on the clock setting screen. To access the clock setting screen with a single step:




1. Select the clock on the status bar at the top of the Center Information Display.

For more information on clock settings and full step-by-step instructions on adjusting the clock both manually and automatically, please refer to page 83 in this Getting Started Guide.

EYESIGHT® OVERVIEW

Your Subaru features a variety of safety systems that are the culmination of everything Subaru Engineers know about safety. These systems are referred to as “Driver Assist Technologies” and add confidence to every trip you and your passengers take. Working together, these systems provide enhanced awareness, safety, and convenience in front, to the sides, and behind your Subaru. Subaru Driver Assist Technologies include:

- EyeSight® Driver Assist Technology
- Rear-Vision Camera
- Pre-Collision Braking
- Blind-Spot Detection (BSD)
- Rear Cross-Traffic Alert (RCTA)
- Reverse Automatic Braking (RAB) (Automatic Transmission Models Only)
- High Beam Assist (HBA)
- Steering Responsive Headlights (SRH)



OPERATION

EyeSight® is a driver assist technology that uses dual stereo cameras to serve as an extra pair of eyes on the road ahead to identify vehicles in front, pedestrians, traffic lanes, or other objects. If need be, the EyeSight® system can apply the brakes and/or reduce engine power to help avoid or reduce the severity of a collision. During these events, the system will provide audible and visual alerts to assist you in making decisions.

Since the characteristics and limitations of the EyeSight® cameras are similar to human eyes, it is important that the cameras, windshield, and area in front of the cameras are treated with special care. Please refer to “Care and Limitations” on page 80 in this Getting Started Guide for more details.



EyeSight® Cameras (inside)



EyeSight® Cameras (outside)


FUNCTIONS

The EyeSight® system features several distinct functions designed to provide extra awareness, improve safety, reduce fatigue, and add peace of mind every time you drive your Subaru. EyeSight® functions include:

- Pre-Collision Braking
- Pre-Collision Brake Assist
- Pre-Collision Throttle Management (Automatic Transmission Models Only)
- Lane Departure Warning
- Lane Sway Warning
- Adaptive Cruise Control
- Lead Vehicle Start Alert

Pre-Collision Braking

This function helps prevent or minimize a frontal collision with another vehicle, pedestrian, or other objects by providing visual and audible warnings. Warnings are displayed in the Combination Meter Display (CMD) with audible beeps. If you take no corrective action, the system automatically reduces engine power and applies the brakes with increasing force to help prevent or minimize the collision.



This system can be turned on or off in the Center Information Display (CID) (see page 75).

Automatic Transmission

Pre-Collision Braking can be activated when the select lever is in the “D” or “M” position. The lower limit for Pre-Collision Braking on automatic transmission vehicles is approximately 2 mph.

To override the system, press down on the accelerator pedal.

Manual Transmission

Pre-Collision Braking will activate regardless of whether the clutch pedal is engaged, or if the shift lever is in the “N” position or any forward gear.

The lower limit for Pre-Collision Braking on manual transmission vehicles is approximately 1 mph when in 1st - 6th gear. If the vehicle is in Neutral, or if the system is unable to detect what gear is engaged, Pre-Collision Braking will not activate at speeds lower than 5 mph.

Pre-Collision Braking will continue to control the vehicle until it stops, even if the engine stalls. The clutch pedal can be pressed to avoid stalling. Once the vehicle has stopped, the system will gradually release brake control, so be sure to apply the brakes if you want to keep the vehicle stopped.

To override the system, press down on the accelerator pedal while in any gear position.

Pre-Collision Braking is not a substitute for safe and attentive driving. You should always remain alert and keep your hands on the steering wheel at all times.

Pre-Collision Brake Assist

This function activates when the Pre-Collision Braking System is activated, the system determines that there is a high risk of collision with an obstacle in front, and you apply the brakes. The function assists by applying additional pressure to the braking system to decrease stopping distance.

This system can be turned on or off in the Center Information Display (CID) (see page 75).

Pre-Collision Throttle Management

This function is designed to help prevent you from unintentionally accelerating into a stopped vehicle or other obstacle by reducing engine power. Warnings are displayed in the Combination Meter Display (CMD) with audible beeps.

Pre-Collision Throttle Management is helpful when:

- You unintentionally place the select lever in the “D” position instead of the “R” position and start to accelerate toward a parked car, wall or parking structure.
- While you are at a stop, the vehicle ahead of you accelerates, but then suddenly slows down or stops as you begin to accelerate.


This system can be turned on or off in the Center Information Display (CID) (see page 75).

Pre-Collision Throttle Management is only available on vehicles with an automatic transmission.

Lane Departure Warning

This function provides audible and visual warnings if you are about to depart your lane of travel. Using the EyeSight® camera, the Lane Departure Warning function identifies lane markings when traveling at speeds of approximately 30 mph or greater. These warnings are displayed in the Combination Meter Display (CMD) with audible beeps. Lane Departure Warning does not provide any corrective actions.

You can turn this system on or off in the Center Information Display (CID) (see page 75).




Lane Sway Warning

This function detects repetitive or unusual side-to-side vehicle movement within a lane of travel that may indicate a drowsy or inattentive driver. Using the EyeSight® camera, the Lane Sway Warning function activates to identify lane markings when traveling at speeds of approximately 37 mph or greater and deactivates when vehicle speed falls below 25 mph. Warnings are displayed in the Combination Meter Display (CMD) with audible beeps. Lane Sway Warning does not provide any corrective actions.

You can turn this system on or off in the Center Information Display (CID) (see page 75).



Adaptive Cruise Control (ACC)



This system provides cruise control with the ability to keep a safe distance from the car in front of you. Using the EyeSight® camera, the Adaptive Cruise Control function identifies vehicles in front of you in the same lane, and your vehicle follows the vehicle in front (up to the maximum of your set speed). While following, your vehicle will automatically maintain a following distance that corresponds to the speed of the vehicle in front.

You can turn the Adaptive Cruise Control on or off using the Adaptive Cruise Control On/Off button on the side of the Adaptive Cruise Control lever (see page 73). Once the system is turned on, a white Adaptive Cruise Control icon will be displayed on the Combination Meter Display (CMD). When all the operational conditions are met, “READY” appears underneath the Adaptive Cruise Control icon.

To set Adaptive Cruise Control, push down Adaptive Cruise Control lever to the “– SET” side. The "READY" indicator turns off, the Adaptive Cruise Control icon turns green, and the CMD indicates the set vehicle speed. This speed can be adjusted up or down using the “+ RES” or “– SET ” sides of the lever (see page 73).

When a vehicle in front of you is identified, a Lead Vehicle indicator and icon will be displayed on the Combination Meter Display (CMD) . You can change the desired following distance from the lead vehicle by pressing the Following Distance Button (see page 73).

Automatic Transmission

On automatic transmission vehicles, Adaptive Cruise Control can be set at any speed above 0 mph.


Manual Transmission

On manual transmission vehicles, Adaptive Cruise Control can be set at speeds of 20 mph or higher, as long as the shift lever is in 2nd - 6th gear. You can switch gears freely while the system is operating.

Vehicle acceleration will be paused momentarily when the clutch pedal is depressed, but acceleration will resume when the clutch is engaged again. If the clutch pedal is pressed for more than 5 seconds, or if the select lever is placed in Neutral for more than 5 seconds, the Adaptive Cruise Control system will cancel. The system will also cancel if the engine RPM approaches the red line.

NOTE: If the vehicle speed falls below 16 mph, the Adaptive Cruise Control system will cancel and brake and/or clutch operation may be required.

Lead Vehicle Start Alert



This function will provide a visual and audible alert when a stopped vehicle in front of you begins to move, and your vehicle remains stationary. Warnings are displayed in the Combination Meter Display (CMD) with audible beeps. Lead Vehicle Start Alert is helpful in situations where you may become temporarily distracted at a traffic light, and the vehicle ahead begins to move.

Navigate the CID (select “Settings”, and then the “Car” menu) to access the EyeSight® settings menu to turn this function on or off.

Automatic Transmission

This function only activates when the select lever is in the “D”, “M”, or “N” position.

Manual Transmission

This function only activates when the brake pedal is depressed. The system will activate even if the engine stalls.

STEERING WHEEL CONTROLS

Adaptive Cruise Control





1. **Adaptive Cruise Control On/Off:** Press to turn Adaptive Cruise Control (ACC) on or off.
2. **CANCEL:** Pull the Adaptive Cruise Control lever toward you to cancel Adaptive Cruise Control.
3. **Following Distance:** Press to set the following distance in four stages while using Adaptive Cruise Control. Press and hold to change to Conventional Cruise Control.
4. **Resume (RES)/Increase Speed and Set (SET)/Decrease Speed:** Push the lever down to set an initial target speed. Once set, push up or down to adjust the target speed.
   - **Adjust by 1 mph:**
     - Briefly press the lever up to increase the target speed in 1 mph increments.
     - Briefly press the lever down to decrease the target speed in 1 mph increments.
   - **Adjust by 5 mph:**
     - Press and hold the lever up to increase the target speed in increments of 5 mph.
     - Press and hold the lever down to decrease the target speed in increments of 5 mph.

Customizing EyeSight® Settings

The EyeSight® system features customization of certain preferences and warnings. Select “Settings”, and then “Car” or select the “Car Settings” icon to adjust a number of EyeSight® Settings in the Center Information Display, such as:

- Pre-Collision Braking:
  - Setting ON
  - Setting OFF
- Lane Departure Warning On/Off
- Cruise Control Acceleration Characteristics:
  - Lv. 1 Eco
  - Lv. 2 Comfort
  - Lv. 3 Standard
  - Lv. 4 Dynamic
- Lead Vehicle Acquisition Sound On/Off
- Lead Vehicle Moving Monitor
- Select Drive on Left/Drive on Right:
  - Right Lane
  - Left Lane




Car Settings Icon

LANE DEPARTURE WARNING AND PRE-COLLISION BRAKING SYSTEM OFF

Lane Departure Warning OFF

Select the “Car Settings” icon, then in the “Driving Assistance” menu, select “Lane Departure Warning” to activate or deactivate the Lane Departure Warning and Lane Sway Warning functions.




When these functions are off, a yellow Lane Departure Warning OFF indicator illuminates in the Combination Meter. It may be helpful to turn these functions off when lane markings on the road are inconsistent.



Pre-Collision Braking System OFF

Select the “Car Settings” icon, then in the “Driving Assistance” menu, select “Pre-Collision Braking” to activate or deactivate the Pre-Collision Braking, Pre-Collision Brake Assist, and Pre-Collision Throttle Management functions.



When these functions are off, a yellow Pre-Collision Braking OFF indicator illuminates in the Combination Meter. It may be helpful to turn these functions off when using a drive-through carwash.



REAR-VISION CAMERA



This function provides a clear view of the area behind the vehicle to help avoid obstacles. Using a wide-angle camera mounted on the rear of the vehicle, an image is automatically displayed on the multimedia screen when you place the select lever/shift lever in the “R” position. The displayed image features a centerline indicator, colored distance markers, and dynamic guidelines that move as the steering wheel is turned.

BLIND SPOT DETECTION (BSD) / REAR CROSS TRAFFIC ALERT (RCTA)

This system uses radar sensors mounted behind the rear bumper on the left and right sides that warn you if another vehicle is sensed in your blind spots. These functions provide additional awareness when changing lanes or driving in reverse.

Blind Spot Detection (BSD)



Blind Spot Detection senses if a vehicle is traveling at the same relative speed in your blind spot and provides a visual warning. If the system detects a vehicle in your blind spot, the BSD/RCTA approach indicator light in the corresponding side mirror frame illuminates. If you operate the turn signal lever in the direction the BSD/RCTA approach indicator light is illuminated, the system provides an additional level of warning by rapidly flashing the BSD/RCTA approach indicator light.

Lane Change Assist (LCA)


Lane Change Assist (LCA) provides an additional level of protection by warning you of rapidly approaching vehicles in the neighboring lanes. If LCA detects a vehicle approaching at a high speed in the neighboring lanes, the BSD/RCTA approach indicator light in the corresponding side mirror frame illuminates. If you operate the turn signal lever in the direction the BSD/RCTA approach indicator light is illuminated, the system rapidly flashes the BSD/RCTA approach indicator light.

Rear Cross Traffic Alert (RCTA)



This function detects a vehicle approaching from either side as you reverse, helping you check the rear and side areas of the vehicle when moving backward. If RCTA detects a vehicle approaching from either side while moving backward, the system provides visual and audible warnings: The BSD/RCTA approach indicator light(s) on the side mirror(s) flash, the BSD/RCTA warning indicator appears in the upper corner of the Rear-Vision Camera display, and a warning buzzer sounds.

Blind Spot Detection / Rear Cross Traffic Alert OFF



BSD/RCTA can be turned on or off in the Center Information Display (CID):

1. Select the “Car Settings” Icon.
2. In the “Driving Assistance” menu, select “BSD/RCTA” to turn the function on or off.

When this function is off, a yellow BSD/RCTA OFF indicator will be displayed in Combination Meter.



HIGH BEAM ASSIST (HBA)



This function uses the EyeSight® cameras to automatically switch the headlights between high and low beam settings, enhancing safety for both you and other drivers on the road. To activate High Beam Assist, set the headlight control switch to the “AUTO” position and push the headlight lever forward to the high beam position and release. The green HBA indicator illuminates on the Combination Meter.

HBA automatically activates the high beams when the forward area is dark, there are no preceding/oncoming vehicles or sharp curves in the road, and your speed is approximately 20 mph or greater. When a preceding/oncoming vehicle is detected, the forward area is bright, your speed decreases to 10 mph or less, or the EyeSight® system is malfunctioning or is temporarily stopped, HBA automatically switches to low beams.

STEERING RESPONSIVE HEADLIGHTS (SRH)

The Steering Responsive Headlights (SRH) system aims the headlight beams in the direction you are steering, improving visibility at corners and intersections when driving at night. You can turn the SRH system on or off in the Center Information Display by selecting “Settings”, then selecting “Car”.

For more information, please refer to “Instruments and Controls” in your Owner’s Manual.

REVERSE AUTOMATIC BRAKING (RAB) (if equipped)



This system uses four rear bumper mounted sonar sensors to detect objects when moving between 1 and 9 mph in reverse. RAB uses the Rear-Vision Camera image to display colored proximity alerts when an object is detected. As an object becomes closer to the rear of your vehicle, audible beeps provide additional awareness in progressive levels. If RAB determines that a collision with an object is possible, the system can automatically apply the brakes to help prevent or minimize the impact.

NOTE: Turn off the RAB system while towing or using bike racks to avoid any unnecessary audio beeps or unexpected braking while in reverse.

RAB is only available on vehicles with an automatic transmission.

Reverse Automatic Braking (RAB) OFF

In some cases, it may be helpful to temporarily turn the system off. RAB can be turned off using the buttons on the Touchscreen when the select lever is in the “R” position.



Select and hold the “RAB ON” button until it changes to “RAB OFF” to disable the automatic braking functions of the RAB system.

Select and hold the “P))) ON” button in the lower part of the Touchscreen until it changes to “P))) OFF” to disable the sonar audible alarm function of the RAB system.

STEREO CAMERA PRECAUTIONS

Your EyeSight® stereo cameras are precision components that must be kept free from obstruction and contamination, such as fingerprints or cleaning solutions. When the system detects that the stereo camera lenses are impaired, a malfunction indicator will be displayed and EyeSight® functions will not be available.

When you are in the vicinity of the EyeSight® stereo cameras, always observe the following precautions:

- Do not touch or attempt to clean the EyeSight® camera lenses inside the vehicle. Extra caution should be used when cleaning the inside of the windshield. Over-spray from cleaning solutions may impair or even damage the camera lenses. Please inform others who may attempt to clean the windshield, such as car wash staff, of this precaution.
- Electronic Toll Collection devices, such as EZPass™, must be installed in an area that does not obstruct the stereo cameras' field of vision. See "Prohibited Area" on page 81 in this Getting Started Guide.
- Adjust the rearview mirror so it does not obstruct the stereo cameras' field of vision.
- Do not install any interior rearview mirror accessories, such as a wide-type mirror or hanging objects. Only approved Genuine SUBARU accessories may be installed.


For more detailed information, please refer to your EyeSight® Owner's Manual.

WINDSHIELD GLASS AND DASHBOARD

Since the characteristics and limitations of the EyeSight® stereo cameras are similar to human eyes, it is important that the area in front of the cameras be kept free from dirt, scratches, cracks, fogging, or accessories mounted to the windshield, hood or dashboard. Visual impairments or reflections can affect EyeSight® system performance. Extra caution should be taken when cleaning the windshield to prevent over-spray from cleaning solutions.

The image in the following section outlines those areas that must be kept clean and free from obstruction. Please refer to the Owner's Manual for a complete listing of limitations.

BRZ



Do not place stickers or objects in the prohibited area (in gray).

EYESIGHT® DISCLAIMER

EyeSight® is a driver assist technology which may not operate optimally under all driving conditions. The driver is always responsible for safe and attentive driving. System effectiveness depends on many factors such as vehicle maintenance, weather and road conditions. See Owner's Manual for complete details on system operations and limitations.

The Pre-Collision Braking system is designed to provide automatic braking that either prevents a collision or reduces the severity of a frontal impact.

The Pre-Collision Throttle Management system is designed to reduce acceleration and minimize the severity of certain frontal impacts.

Adaptive Cruise Control and Brake Light Recognition are designed to assist the driver and are not substitutes for safe and attentive driving.

Blind-Spot Detection, Lane Change Assist and Rear Cross Traffic Alert are systems designed to assist the driver by monitoring the rear and side areas of the vehicle during a lane change or reversing and are not a substitute for safe and attentive driving.

The Reverse Automatic Braking System is not a substitute for safe and attentive driving. System effectiveness depends on many factors, such as vehicle maintenance, weather and road conditions. Always exercise caution and use vehicle mirrors and the Rear-Vision Camera when backing up. See Owner's Manual for complete details on system operation and limitations.

HOW TO OVERVIEW

This “How To” appendix provides detailed, step-by-step instructions to easily connect with features of your BRZ.

If you need some help with these features or want to learn more, we are here to assist you:

Your Subaru Owner’s Manuals:
Located in the glovebox

Online Subaru Owner’s Resources:
www.subaru.com/owners

Subaru Customer Support:
www.subaru.com/customer-support

1-800-782-2783 (1-800-SUBARU3)

Scan to learn more about **Owner’s Resources**.

Scan to learn more about **Customer Support**.

SETTING THE CLOCK

Clock settings can be adjusted when the ignition is in the “ON” position. You can adjust the clock manually or set the clock to adjust automatically in the clock setting screen. To directly access the clock setting screen, you can select the clock on the status bar at the top of the Center Information Display. Full directions for accessing the clock settings and adjusting the clock manually or automatically are given in the following sections.

For more information, please refer to “Quick Guide” in your MySubaru Owner’s Manual.


Manually

To set the clock manually:


1. Select the Clock Display in the Status Bar.



2. Select “Time Setting”.



3. Select “Manual”.
4. Adjust the time and date using the “Arrow Up” and “Arrow Down” buttons.
5. Once you are finished, select “OK”.




Automatically

To set the clock automatically:

1. Select the Clock Display in the Status Bar.



2. Select “Time Setting”.



3. For vehicles with MySubaru Companion and Companion+, select “Auto”. For vehicles without MySubaru Companion and Companion+, select “Sync With Phone”.
4. Select “Back”.



The clock automatically adjusts as follows:

- Vehicles with MySubaru Companion and Companion+: Automatically adjusts the clock when a MySubaru Companion and Companion+ signal is available.
- Vehicles without MySubaru Companion and Companion+: Automatically adjusts the clock when a phone is paired and connected via Bluetooth®. “Phonebook Download” must be enabled in the Phone Settings.


BLUETOOTH® PAIRING

Pairing an Android Device


1. To pair an Android device, start by selcting the “Phone” button on the Home screen.




2. If there is no phone connected, “Do you want to add a device?” appears on the screen. Select “Yes”. If a device has already been paired, select “Manage Devices”, then select “Add ”.




3. The screen to the right will be displayed when pairing mode is in progress. The device name will most likely be Subaru BRZ, but be sure to make note of what name it is so you can find it on your phone.




4. On your Android device, go to “Settings” (it can be found under apps).




5 Next select “Connected Devices” or “Connections”. If needed, select “Bluetooth”.




6 Now select “Bluetooth”. This will show a screen to “Pair New Device” or it will be showing the nearby devices to add. Select “Subaru BRZ”, if shown on the list, or “Pair New Device”.







7 Now select “Pair” or “OK” to pair the devices. Make sure to allow access to your messages and call history in the “Allow Access to Messages” popup box.



8 Select “Yes” to transfer your contacts.



9 If you cannot access your phonebook or messages, go back to your phone’s Bluetooth® settings and select the gear icon next to your vehicle’s device name and ensure all settings are enabled.




Pairing an iOS/Apple Device


1. To pair an Apple device, start by touching the “Phone” button on the Home screen.




2. If there is no phone connected, it will ask you, “Do you want to add a device?”. Select “Yes”. If a device has already been paired, select “Manage Devices”, then select “Add”.




3. When this screen is displayed, it is in pairing mode. Note the “Device Name”; it will most likely be “Subaru BRZ”.




4. On your iOS/Apple device, select “Settings”. The location on the Home screen will vary.




5 Select “Bluetooth”.




6 Now select “Subaru BRZ”, or the device name from step 3, if not “Subaru BRZ”.




7 Verify your iOS/Apple device PIN is correct and select “Pair”. Then select “Allow” on the “Allow Contacts and Favorites Sync?” screen.






8 Select “Yes” to transfer contacts.



9 On your iOS/Apple device, Subaru BRZ should now be listed under “Bluetooth Settings”. Select the blue “i” next to the device name. Then ensure “Show Notifications” and “Sync Contacts” are enabled.

10 Your iOS/Apple device is now paired. It is recommended that you restart your Subaru to complete the process and ensure everything is fully synced.



ANDROID AUTO™

Cables

Always use a high-quality OEM USB cable.


Ensure the Android phone is fully up to date. Also verify that the Android Auto app, along with all other apps that work with Android Auto, are up to date. Android Auto might not function properly if one of them is outdated or having an issue. The apps can be downloaded from the Play Store.

For more information, visit: **www.android.com/auto/**

Scan to learn more about **Android Auto**

Connecting an Android Phone


1. To set up Android Auto™, first plug the Android phone into the USB port of the vehicle using a quality OEM cable. During initial setup, messages appear on your phone. Select “Next” or “Accept” as required for setup, following the prompts on your phone.




2. Once setup is complete, select the Android Auto™ icon on the vehicle screen if the app has not already launched.



3. You will then be taken to the Home screen of the Android Auto™ app.



4. If Android Auto won't launch, open the Android Auto app™ on the phone, then select the top left menu button. Select "Settings", then "Connected Cars", and finally select the top right menu icon and choose "Forget all cars". Then, try the process again. If this does not work, uninstall the Android Auto app from the phone and reinstall from the Play Store.



Compatible Models

Android Auto is available on Android phones. To see if your phone is compatible, please refer to the Android Auto website: **https://www.android.com/phones/**

Scan to see if your phone is compatible with **Android Auto**

APPLE CARPLAY®

Cables


Apple CarPlay requires compatible iPhones to be connected via your Subaru's USB port. Cables must be an 8-Pin Lightning MFi Certified cable (made for iPod/iPhone). Look for the Works with Apple CarPlay or Made for iPod, iPhone, iPad icons when selecting a cable.

For more information, visit: **www.apple.com/ios/carplay/**

Scan to learn more about **Apple CarPlay**

Connecting an iPhone

1. To set up Apple CarPlay, you will need to plug the iOS/Apple phone into the USB port of the vehicle. Make sure to use an MFi certified cable.
2. Select “Allow” on the iOS/Apple phone when prompted.



3. Select Apple CarPlay on the vehicle screen. This will bring you to the home screen of Apple CarPlay.

   Ensure the iOS/Apple phone is fully up to date. Also ensure all apps that work on Apple CarPlay are up to date. Apple CarPlay might not function correctly if one of the apps is outdated or having an issue. Apps can be updated in the App Store.



Compatible Models

For a list of all the Apple phones that are compatible with Apple CarPlay, visit: **www.apple.com/ios/carplay/**

Scan to learn more about **Apple CarPlay**

WI-FI

Connecting to a Wi-Fi Network


1. On the Home Screen, select “Settings”.



2. In the “General” settings menu, select “Wi-Fi Settings”.



3. Make sure that Wi-Fi is enabled, then select “Available Wi-Fi Networks”.



4. Select the desired network. When selecting a network with the lock icon, a screen will appear for you to enter the password, then select OK.



Wi-Fi Hotspot Subscription

Internet access is purchased separately through AT&T with monthly, per gigabyte, and unlimited data options available. Existing AT&T customers have the option to add an additional line to their AT&T Mobile Share plan. Available on select models.

Scan to learn more about **AT&T plans**.

Shortly after you take delivery of your new Subaru, you will receive an email from AT&T for a one month free trial and how to activate your free trial. To set up and enroll:

1. Select “Settings” on the Home screen.
2. Select “Wi-Fi Hotspot” to turn it on (if the Wi-Fi Hotpot is already on then proceed to the next step).
3. Select Wi-Fi Hotspot Settings to view or update the following settings:
   - Wi-Fi Network Name (SSID)
   - SSID Broadcast (Network ON / OFF)
   - Security Type (WPA / WPA2)
   - Password
   - Connected Devices (Maximum of 8 devices)
   - Broadcast Frequency

How to enroll:

1. Connect your tablet, smartphone or laptop to the MySubaru Wi-Fi Hotspot network listed in the settings menu and open your preferred web browser on the device connected.
2. Once the MySubaru Wi-Fi Hotspot homepage loads, follow the on-screen instructions to create a new account or to add your vehicle to an already existing AT&T Wireless account. You can also subscribe to the Wi-Fi Hotspot from the MySubaru website or Mobile App.

You can also visit an AT&T store or their website for more information at:
https://myvehicle.att.com/#/subaru/learn?country=US&language=en

INDEX

2.4L ENGINE 38

A

ACCESSORY CONNECTIONS 27
ADAPTIVE CRUISE CONTROL 16
ADDING SHORTCUTS 50
ANDROID AUTO™ 92
- Cables 92
- Compatible Models 94
- Connecting an Android Phone 92

APPLE CARPLAY® 94
- Cables 94
- Compatible Models 95
- Connecting an iPhone 95

AT&T WI-FI HOTSPOT 63
AUDIO CONTROLS 15

B

BLIND SPOT DETECTION (BSD) / REAR CROSS TRAFFIC ALERT (RCTA) . . . 76
- Blind Spot Detection (BSD) 76
- Blind Spot Detection / Rear Cross Traffic Alert OFF 77
- Lane Change Assist (LCA) 76
- Rear Cross Traffic Alert (RCTA) 77

BLUETOOTH® PAIRING 86
- Pairing an Android Device 86
- Pairing an iOS/Apple Device 89

BRZ 81
BUTTONS 44
- Controlling the Volume 45
- Other Functions 44
- Radio Functions 44

C

CLIMATE CONTROL 24
- Dual-zone Automatic Climate Control 24
- Heated Seats 26
- Remote Engine Start with Climate Control 26

CLOCK 66
COMBINATION METER 12
COMBINATION METER DISPLAY CONTROLS 16
CREATING A DRIVER PROFILE 51
- Retrieving a Driver Profile 53

D

DRIVING SYSTEMS/MODES 30
DRIVING THE VEHICLE 28
- 6-Speed Manual Transmission 28
- Automatic Transmission Shift Mode (if equipped) 29
- Paddle Shift Control Switches (if equipped) 29
- REV Alarm System 30

E

ENGINE OIL SPECIFICATIONS & CAPACITIES 40
ENROLLMENT 63
EYESIGHT® DISCLAIMER 82
EYESIGHT® OVERVIEW 67

F

FLAT TIRE REPAIR KIT 36
FOLDING THE REAR SEATBACK 33
- Passenger Occupant Detection and Seatbelt Reminders 33

FUEL FILLER LID 32
FUEL SPECIFICATIONS AND CAPACITY 32
FUNCTIONS 68
- Adaptive Cruise Control (ACC) 71
- Lane Departure Warning 70
- Lane Sway Warning 70
- Lead Vehicle Start Alert 72
- Pre-Collision Brake Assist 69

Pre-Collision Braking 68
Pre-Collision Throttle Management . . 69

H

HIGH BEAM ASSIST (HBA) 78
HOME SCREEN ICONS 49
HOOD PROP 37
HOW TO OVERVIEW 83

I

IMPORTANT SAFETY INFORMATION . . 4
IN CASE OF EMERGENCY 5
MySubaru Companion and Companion+ (subscription required) 5
Subaru Roadside Assistance 5
INSTRUMENT PANEL SWITCHES . . . 15
INTERNAL SAFETY TRUNK RELEASE WITH SELF-ILLUMINATING HANDLE 35
IN-VEHICLE APPS 59
Android Auto™ 59
Apple CarPlay® 59
SiriusXM Travel Link® 60

K

KEYLESS ACCESS WITH PUSH BUTTON START 8
Locking Using Door Handles 8
Unlocking the Trunk 9
Unlocking Using Door Handles 8
KEYLESS ENTRY 7

L

LANE DEPARTURE WARNING AND PRE-COLLISION BRAKING SYSTEM OFF 75
Lane Departure Warning OFF 75
Pre-Collision Braking System OFF . . 75
LATCH/ANCHOR 34
LIGHT CONTROLS 17
Daytime Running Lights 18
Illumination Brightness 17

M

MAKING A CALL 56
MEDIA 55
AUX Input 55
Bluetooth® 55
USB/iPod 55
MYSUBARU 60
Service Appointment Scheduler . . . 61
MYSUBARU COMPANION AND MYSUBARU COMPANION+ OVERVIEW 62
MYSUBARU INTEGRATION 63

N

NEW VEHICLE BREAK-IN 40

O

OPERATION 67
OVERHEAD CONSOLE 19
OVERVIEW OF YOUR MULTIMEDIA SYSTEM 43
Screen Layout 43
Various Systems 43
OWNER'S RESOURCES 4

P

PAIRING A PHONE 56
PHONE 66
POWER EXTERIOR MIRRORS 22
POWER WINDOWS 23
PUSH-BUTTON IGNITION SWITCH . . 28

INDEX

R

RADIO 54
AM/FM Radio 54
Presets 55
Satellite Radio 54
REARRANGING ICONS 49
REAR VIEW MIRROR 22
Auto-dimming Mirror 22
HomeLink® 5 Accessory Mirror . . . 23
REAR-VISION CAMERA 76
RECEIVING A CALL 57
REVERSE AUTOMATIC BRAKING (RAB) 79
Reverse Automatic Braking (RAB) OFF 79

S

SEATING 20
Head Restraint Adjustment 21
Manual Seats 20
SETTINGS AND UPDATES OVERVIEW . . 64
Connect to Home Wi-Fi 64
SETTING THE CLOCK 83
Automatically 85
Manually 84
SOUND 64
STARTING THE VEHICLE 28
With Push-button Ignition 28
STEERING RESPONSIVE HEADLIGHTS (SRH) 78
STEERING WHEEL CONTROLS 46
Adaptive Cruise Control 73
Customizing EyeSight® Settings . . . 74
STEREO CAMERA PRECAUTIONS . . . 80

T

TEXT MESSAGES 58
TILT AND TELESCOPIC STEERING COLUMN 21
TIRE PRESSURE MONITORING SYSTEM (TPMS) 41
TOUCHSCREEN 45
TOWING YOUR SUBARU 6
TRAILER TOWING CAPACITY 40
TRUNK LID OPENER 35
TURNING OFF THE VEHICLE 31
With Push-button Ignition 31
TURN SIGNALS 18

V

VOICE RECOGNITION 47
Common Commands 48
Tips 47

W

WARNING AND INDICATOR LIGHTS . . 14
WELCOME 4
WI-FI 96
Connecting to a Wi-Fi Network 96
Wi-Fi Hotspot Subscription 97
WINDSHIELD GLASS AND DASHBOARD 80
WINDSHIELD WIPERS 18

NOTES

NOTES

Subaru of America, Inc.
One Subaru Drive
Camden, NJ 08103-9800



MSA5B2606A
Issued August 2025
Printed in USA 08/25

