













Unpacking and Installation Guide



Scan this QR code with your smart phone to see helpful videos.



8

d-3

x 2

ARC

HDMI (eARC)

ANT

1

2

3

4

5

6

7

8

9

10

d-1

d-2

15 cm

6 inches

* When installing the TV as wallmount, You can place the One Connect Box as shown below.

⚠ When installing the TV as stand, Don't place the One Connect Box on back of the TV.

	A	B	C	D	E	F	G	H
83S95F	72.6 inches (1844.2 mm)	41.6 inches (1056.8 mm)	0.5 inches (12.6 mm)	44.2 inches (1123.4 mm)	12.0 inches (303.7 mm)	82.5 inches	85.1 lbs (38.6 kg)	114.4 lbs (51.9 kg)

	VESA A x B (mm)	C (mm)	D	E x 4	F (mm)	G (inches)	H (inches)	I (inches)
83S95F	400 x 400	5-6	C + ★	M8	1.25	8.7	28.4	17.0

★ : Wall-Mount Bracket