

City Sweep™

Manual Sweeper Series



Assembly:

Fit the threaded handle sections together and screw together tightly until secure. Screw the handle grip on the threaded end of the handle.

Emptying:

To empty the dirt pans, hold the sweeper over a trash bin and press the bottom of each dirt pan at the points indicated by the arrows.

Maintenance:

For best performance keep brushes and bearings clean of hair, threads and other debris.



©2017 BISSELL Homecare, Inc.
Grand Rapids, Michigan
All rights reserved. Printed in China
Part Number 161-2441 08/17
Visit our website at: www.BISSELL.com