

BOTE



HANGOUT™


WATER HAMMOCK 10

HANGOUT WATER HAMMOCK™ 10

The Hangout Water Hammock™ 10 by BOTE is part of our Hangout Suite of products and can function as a standalone item or alongside other Hangout Suite products like the Hangout Lounge™, Hangout Bar™, and more. Featuring comfortable, soft non-slip BVA deck pad foam, D-Rings for easily tying-off or anchoring and six MAGNEPOD™ attachment points to keep your BOTE drinkware at your fingertips. Use it as a swim platform, a place to lounge on the water, or pair it with other items in the Hangout suite to create the ultimate raft up party – the Hangout Water Hammock™ 10 is stable, versatile, durable, stylish, and sure to be a staple of all of your days on the water.


WELCOME TO BOTE.

FEATURES



INCLUDED ITEMS

Shown below are the basic components that are included with your Hangout Water Hammock™ 10.



**ONE (1)
HANGOUT WATER HAMMOCK™ 10**



**ONE (1)
ROLLING TRAVEL BAG**



**FOUR (4)
DOCKLINK CONNECTORS**




**ONE (1)
REPAIR KIT**



**ONE (1)
MANUAL HAND PUMP**

HOW TO

Inflating and deflating the Hangout Water Hammock™ 10 is simple. First remove the folded Hangout Water Hammock™ 10 from the bag, unroll, attach the pump hose to the inflation valve and fill 'er up. The Hangout Water Hammock™ 10 is to be filled until the pressure reaches 6-8 PSI. When you are ready to pack it up, do everything in reverse.



CARE & STORAGE

Always store your Hangout Water Hammock™ 10 in a cool, dry place or shady area out of reach of direct sunlight to avoid bursting or fading of colors. The sun both weakens the material and seams and increases the pressure beyond its design limits. If you must leave your Hangout Water Hammock™ 10 out of the water and in direct sunlight, reduce pressure until the Hangout Water Hammock™ 10 is compressible by hand.

The Hangout Water Hammock™ 10's recommended inflation is between 6-8 PSI.

HOW TO FOLD



1. When you are finished with your Hangout Water Hammock™ 10, make sure to clean off any dirt, sand or salt water with fresh water. Then allow the Hangout Water Hammock™ 10 to dry or dry with a towel.

2. Next, begin deflating by removing the inflate/deflate port cap and pressing the push pin down until you can turn it clockwise to lock it open.

Remove excess air with a pump in deflate mode.




3. Fold the Hangout Water Hammock™ 10 in half.



4. Fold in half again.

HOW TO FOLD



5. Begin rolling from one side to the other.



6. After rolling, lay the included strap under the rolled Water Hammock™ 10 with the clip facing down.



7. Finally, fold mesh up and secure with the strap by feeding the webbing through the clip and tightening.

WARRANTY

BOTE makes every effort to produce our Hangout Water Hammock™ 10 to the highest quality and standards in the industry. We do quality checks in our factories and warehouses in an effort to guarantee each Hangout Water Hammock™ 10's quality before shipping to Authorized BOTE Dealers or directly to the customer. We cannot warranty the performance of any Hangout Water Hammock™ 10 for individual users and varying skill levels and abilities. Furthermore, we cannot guarantee against damage or breakage and cannot protect or warranty against circumstances outside of our control.

WARRANTY REGISTRATION REQUIRED

The warranty registration form should be completed online within 30 days of original purchase to be activated. You should keep your sales receipt should it be required in the future for proof of purchase. The online Warranty Registration Form can be found at www.boteboard.com/support/warranty.

2 YEAR LIMITED WARRANTY

For the original retail purchaser ("Consumer"), BOTE provides a limited 2-year warranty from date of purchase against material or manufacturing defects in the hull and deck for a registered product.

LIMITATIONS AND EXCLUSIONS

This limited warranty does not apply to the following. Please visit www.boteboard.com/support/warranty for the complete list of limitations and exclusions.

- Normal wear and tear and aging of product.
- Hangout Water Hammock™ 10 damaged while in possession of a freight carrier, a dealer, Consumer, or any party other than BOTE.
- Hangout Water Hammock™ 10 sold as "demos" or in "as is" condition.
- Cosmetic flaws or colors may vary from those shown. Cosmetic flaws or variations in color are not covered by warranty.
- Does not cover any puncture, cut or abrasion sustained in normal use or damage from unreasonable uses or improper storage.

OBTAINING WARRANTY SERVICE

If you have a problem with your Hangout Water Hammock™ 10 and you suspect that it may be due to defective materials or workmanship, contact the dealer you purchased your BOTE from and arrange to have the problem inspected. Consumer is responsible for delivery to, and pickup from, the closest authorized dealer.

If you purchased the product directly from BOTE or a BOTE Retail Store, complete the online warranty claim form and await further instruction. Please visit www.boteboard.com/support/warranty to read the complete BOTE Warranty before using your new Hangout Water Hammock™ 10.



WARRANTY REGISTRATION
Scan the code for more information.

WE'RE HERE TO HELP



If you have any questions, please email us at
support@boteboard.com

WARNING

This is not a toy. Adult supervision is required.

- This is not a lifesaving device.
- Always wear a USCG approved Type III PFD when using this product.
- This product should never be towed.
- Never use this product in the surf zone or high rushing water.
- Do not swim under water hammock.
- Do not dive from water hammock.
- Failure to comply could lead to injury or death.



BOTEBOARD.COM

888.855.4450 | support@boteboard.com

12598 US Highway 98 W, Suite 200 | Miramar Beach, FL 32550 USA

PATENT PENDING