

SKU: R0206-00025-BK

Hitch Ski Rack

Notes Before Using

1. If this product is missing parts or defective, please reach out to us for free part replacements via service@bougeRV.com or +1 669 232 7427 (Sunday to Thursday 18:00PM-24:00PM PST) (Please attach your Amazon order ID in the email). If this product is found incompatible with your vehicle, you could contact us to see if we have other models for your vehicle. Anything you'd like to ask, feel free to contact us.
2. This ski rack holds up to 4 pairs of skis or 4 snowboards.
3. For your safety, check the mounting bolts before each use and drive at speeds under 120 km/h (75 mph).

Kit Contents

Ⓐ	Bottom Support Tube	*1
Ⓑ	Upper Support Tube	*1
Ⓒ	Bottom Main Rack	*1
Ⓓ	Upper Main Rack	*1
①	Open-end Wrench (S=17)	*1
②	Key	*1
③	Installation Instruction	*1
④	Pull Strap	*1
⑤	Anti-loose Nuts (M10*P1.5)	*4
⑥	M10 Washers	*4
⑦	Carriage Bolts (M10*P1.5*L65)	*2
⑧	Carriage Bolts (M10*P1.5*L75)	*2
⑨	D-shaped Pins	*2




Installation Tips

Mounting bracket [A]


Insert the bottom support tube into the hitch receiver. (Using Component Ⓐ)

Turn the red knob clockwise to extend the lock latch until it stops (Do not over-tighten). And then turn the key counterclockwise to lock the rack.

NOTE: Hold the red knob with your hand when you want to lock or unlock the key.






Lock latch protrudes from the tube





Mounting bracket [B]

Insert the upper support tube into the bottom support tube. By using 2 carriage Bolts and 2 washers and 2 nuts and tighten them.
(Using Component (B)/(5)/(6)/(7))



Mounting bracket [C] and [D]

"UPWARD" sign faces upward. By using 1 carriage bolt and 1 washer and 1 nut to connect them (Use the bolt hole according to your need and leave the last bolt hole for D-shape pin). And then insert the D-shape pin for folding limit position.
(Using Component (C)/(D)/(5)/(6)/(8)/(9))




Function display

Storage brackets [C] and [D]


Fold down the rack without ski boards. First, take out the D-shaped latch and fold down the main rack. Then insert the D-shaped pin once it's settled. Follow the same steps for the upper and bottom main racks.

NOTE: The order of this step is important. Bottom main rack needs to be folded up first, and then fold the upper main rack down.



Loading ski boards (Using Component 4)

- (1) Use the key to unlock
- (2) Open the outer cover.
- (3) Open the inner cover.
- (4) Load the ski boards.
- (5) Close the inner and outer cover.
- (6) Lock the outer cover. After loading the boards, use the strap to loop them with the rack.



Remove the ski boards (bring your own ski boards)


The steps to remove the snowboard are the opposite of the steps to install ski boards.

Tilt-Away Feature for Trunk Access

Warning

Hold the ski rack when placing down to prevent collisions.

Turn the red knob clockwise to lay the holding arm 40° down



Warranty

1. BougeRV roof racks carry a 12-month warranty. If there are any problems with the product, please contact us via service@bougeRV.com or **+1 669 232 7427**.
2. This warranty doesn't cover other products sold by other channels except for the BougeRV Amazon store.
3. This warranty does not warrant any conditions that are beyond BougeRV's control which include but are not limited to the following: excessive loading, improper assembly, theft, day-to-day wear and tear, damage due to unauthorized repairs or any use not consistent with the user guide.

VIP Service & Extra 12-month Warranty

1. Search "BougeRV Cargo Club" on your FB or scan the QR code beside.
2. Join "BougeRV Cargo Club".
3. Become a VIP and get a 24-month warranty and the privilege to test BougeRV cargo-related new arrivals.

