




Parts Manual

Mfg. No: 122432-0127-B8



Model Components	Page
Air Cleaner, Exhaust System.	4
Blower Housing, Electric Starter, Flywheel, Gear Reduction, Rewind Starter.	8
Camshaft, Crankcase Cover, Crankshaft, Cylinder, Lubrication, Piston Group.	12
Carburetor.	18
Controls, Governor Spring, Ignition.	22
Cylinder Head.	26
Fuel Supply.	30
Replacement Engine - US & Canada.	34

Not For
Reproduction



Air Cleaner, Exhaust System

REF NO	PART NO	QTY	DESCRIPTION
11	812208		TUBE, Breather -(Flat Panel Air Cleaner)
11C	793418		TUBE, Breather -(Oil Bath Air Cleaner)
50	793419		MANIFOLD, Intake
161	699207		BASE-AIR CLEANER -(Metal) (Flat Panel Air Cleaner)
163B	696024		GASKET, Air Cleaner -(Flat Panel Air Cleaner)
163D	793412		GASKET, Air Cleaner -(Oil Bath Air Cleaner)
176	793441		SEAL, O-Ring -(Air Cleaner Base)
300A	699231		MUFFLER
300E	791595		MUFFLER
346	690661		SCREW -(Spark Arrestor) (SAE)
346	699203		SCREW -(Spark Arrestor) (Metric)
412	793443		NUT -(Air Cleaner Cover)
425	699208		SCREW -(Air Cleaner Cover)
436	793706		MANIFOLD, Exhaust
437	791972		SCREW -(Exhaust Manifold)
445	491588S		FILTER, A/C Cartridge -(Flat Panel)
535	696263		FILTER, Air Cleaner Foam
535A	792472		FILTER, Air Cleaner Foam
549	793434		WASHER -(Air Cleaner)
601	791850		CLAMP, Hose
613	699209		SCREW -(Muffler)
613A	699481		SCREW -(Muffler)
613B	697812		SCREW -(Muffler) (SAE)
613B	799081		SCREW -(Muffler) (Metric)
617	793440		SEAL, O-Ring -(Intake Manifold)
643	696264		RETAINER, Air Filter
643A	793424		RETAINER, Air Filter
676	393760		DEFLECTOR, Muffler
676A	697816		DEFLECTOR, Muffler
677	690661		SCREW -(Muffler Deflector) (SAE)
677	699203		SCREW -(Muffler Deflector) (Metric)
677A	699776		SCREW -(Muffler Deflector)
819	699233		SCREW -(Muffler Bracket)
823	699209		SCREW -(Muffler Adapter)
832A	697818		GUARD, Muffler




Air Cleaner, Exhaust System

REF NO	PART NO	QTY	DESCRIPTION
832D	796240		GUARD, Muffler -Used After Code Date 08062400
832D	791600		GUARD, Muffler -Used Before Code Date 08062500
836B	699209		SCREW -(Muffler Guard)
836E	699755		SCREW -(Muffler Guard)
836C	699234		SCREW -(Muffler Guard)
863	699229		BRACKET, Muffler
864	699232		ADAPTER, Muffler
875B	793423		BASE, Air Cleaner -(Plastic) (Oil Bath Air Cleaner)
883	691893		GASKET-EXHAUST
883A	692237		GASKET-EXHAUST
967	493537S		FILTER, Air Cleaner Foam -(Flat Panel)
968	692584		COVER, Air Cleaner -(Flat Panel)
968C	793425		COVER, Air Cleaner -(Oil Bath Air Cleaner)
971	690370		SCREW -(Air Cleaner Base to Carburetor) (SAE)
971	798649		SCREW -(Air Cleaner Base to Carburetor) (Metric)
994D	793985		ARRESTOR, Spark
1130	793438		STUD -(Intake Manifold)

Blower Housing, Electric Starter, Flywheel, Gear Reduction, Rewind Starter

Mfg. No: 122432-0127-B8




Blower Housing, Electric Starter, Flywheel, Gear Reduction, Rewind Starter

REF NO	PART NO	QTY	DESCRIPTION
3	299819S		SEAL, Oil -(Magneto Side)
15C	792750		PLUG, Oil Drain
17	692517		BEARING, Ball -(PTO Side)
17B	99158		BEARING-BALL
20	692550		SEAL-OIL -(PTO Side)
23	699488		FLYWHEEL
37	699661		GUARD, Flywheel
55	691422		HOUSING, Rewind Starter -(Rewind Starter Parts Used With 3MM Diameter Starter Rope)
55	791848		HOUSING, Rewind Starter -(Rewind Starter Parts Used With 5MM Diameter Starter Rope)
58	66574		ROPE, Starter -(Rewind Starter Parts Used With 5MM Diameter Starter Rope)
58	693389		ROPE, Starter -(Cut To Required Length) (Rewind Starter Parts Used With 3MM Diameter Starter Rope)
60	490652		GRIP-STARTER ROPE
65	699228		SCREW -(Rewind Starter) (SAE)
65	699851		SCREW -(Rewind Starter) (Metric)
78	699205		SCREW -(Flywheel Guard)
79A	792746		CASE, Gear Reduction
80	792755		GASKET, Gear Case
82	807421		SCREW -(Gear Reduction Case)
82B	792753		SCREW -(Gear Reduction Case)
83A	792756		SHAFT, Auxiliary Drive
84A	792759		PLUG, Breather
85A	690711		SCREW -(Gear Cover)
86	790332		COVER, Gear
86A	795647		COVER, Gear
87A	792752		SEAL, Gear Reduction
88	790333		GASKET, Gear Cover/Housing
88A	792760		GASKET, Gear Cover/Housing
146A	790943		KEY, Woodruff
304	699598		HOUSING, Blower
305	699481		SCREW -(Blower Housing)
309	694504		MOTOR, Starter
310	690323		SCREW -(Starter Motor)
311	497608		SET, Brush
332	792723		NUT -(Flywheel)
363	19203		PULLER, Flywheel
415A	792749		PLUG
455	591302		CUP, Flywheel -Used After Code Date 11123100
455	692591		CUP, Flywheel -Used Before Code Date 12010100

Blower Housing, Electric Starter, Flywheel, Gear Reduction, Rewind Starter

Mfg. No: 122432-0127-B8



Blower Housing, Electric Starter, Flywheel, Gear Reduction, Rewind Starter

REF NO	PART NO	QTY	DESCRIPTION
456	692299		PLATE-PAWL FRICTION
459	281505S		PAWL-RATCHET
510	499308		DRIVE-STARTER
513	692024		CLUTCH, Drive
544	692966		ARMATURE, Starter
597	691696		SCREW -(Pawl Friction Plate)
608	693394		STARTER, Rewind -(Rewind Starter Parts Used With 3MM Diameter Starter Rope) -Used Before Code Date 12010100
608	791670		STARTER, Rewind -(Rewind Starter Parts Used With 5MM Diameter Starter Rope) -Used Before Code Date 12010100
608C	591301		STARTER, Rewind -Used After Code Date 11123100
675	691261		WASHER -(Brush Retainer)
689	691855		SPRING-FRICTION
697	793567		KIT-SCREW/WASHER -(Drive Cap)
725	792874		SHIELD, Heat
727	698039		COVER-STARTER DRIVE
728	699632		SCREW -(Heat Shield)
732	699200		SCREW -(Starter Drive Cover)
783	692353		GEAR-PINION
797	691029		NUT -(Brush Retainer)
801	694482		CAP-DRIVE
802	691286		CAP, End
803	693757		HOUSING, Starter -(3 5/8 Housing)
1005	692592		FAN, Flywheel
1005A	794273		FAN, Flywheel
1036	-----		Label-Emissions -(Available From A Briggs & Stratton Authorized Dealer)
1051	691265		RING, Retaining
1070	699201		SCREW -(Flywheel Fan)
1090	691293		RETAINER, Brush
1210	791849		PULLEY/SPRING ASSEMBLY -(Pulley) (Rewind Starter Parts Used With 5MM Diameter Starter Rope)
1210	498144		PULLEY/SPRING ASSY -(Pulley) (Rewind Starter Parts Used With 3MM Diameter Starter Rope)
1211	498144		PULLEY/SPRING ASSY -(Spring) (Rewind Starter Parts Used With 3MM Diameter Starter Rope)
1211	791849		PULLEY/SPRING ASSEMBLY -(Spring) (Rewind Starter Parts Used With 5MM Diameter Starter Rope)
1363	790334		SPROCKET, Gear Reduction
1364	790335		CHAIN, Gear Reduction
1365	790336		SHAFT, Output Gear Reduction
1367	690936		SCREW -(Gear Reduction Sprocket)
1368	690301		WASHER -(Gear Reduction Sprocket)

1319 WARNING LABEL

WARNING

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

25

26

27

28

29

30

31

32

33

34

35

36

37

38

39

40

41

42

43

44

45

46

47

48

49

50

51

52

53

54

55

56

57

58

59

60

61

62

63

64

65

66

67

68

69

70

71

72

73

74

75

76

77

78

79

80

81

82

83

84

85

86

87

88

89

90

91

92

93

94

95

96

97

98

99

100

101

102

103

104

105

106

107

108

109

110

111

112

113

114

115

116

117

118

119

120

121

122

123

124

125

126

127

128

129

130

131

132

133

134

135

136

137

138

139

140

141

142

143

144

145

146

147

148

149

150

151

152

153

154

155

156

157

158

159

160

161

162

163

164

165

166

167

168

169

170

171

172

173

174

175

176

177

178

179

180

181

182

183

184

185

186

187

188

189

190

191

192

193

194

195

196

197

198

199

200

201

202

203

204

205

206

207

208

209

210

211

212

213

214

215

216

217

218

219

220

221

222

223

224

225

226

227

228

229

230

231

232

233

234

235

236

237

238

239

240

241

242

243

244

245

246

247

248

249

250

251

252

253

254

255

256

257

258

259

260

261

262

263

264

265

266

267

268

269

270

271

272

273

274

275

276

277

278

279

280

281

282

283

284

285

286

287

288

289

290

291

292

293

294

295

296

297

298

299

300

301

302

303

304

305

306

307

308

309

310

311

312

313

314

315

316

317

318

319

320

321

322

323

324

325

326

327

328

329

330

331

332

333

334

335

336

337

338

339

340

341

342

343

344

345

346

347

348

349

350

351

352

353

354

355

356

357

358

359

360

361

362

363

364

365

366

367

368

369

370

371

372

373

374

375

376

377

378

379

380

381

382

383

384

385

386

387

388

389

390

391

392

393

394

395

396

397

398

399

400

401

402

403

404

405

406

407

408

409

410

411

412

413

414

415

416

417

418

419

420

421

422

423

424

425

426

427

428

429

430

431

432

433

434

435

436

437

438

439

440

441

442

443

444

445

446

447

448

449

450

451

452

453

454

455

456

457

458

459

460

461

462

463

464

465

466

467

468

469

470

471

472

473

474

475

476

477

478

479

480

481

482

483

484

485

486

487

488

489

490

491

492

493

494

495

496

497

498

499

500

501

502

503

504

505

506

507

508

509

510

511

512

513

514

515

516

517

518

519

520

521

522

523

524

525

526

527

528

529

530

531

532

533

534

535

536

537

538

539

540

541

542

543

544

545

546

547

548

549

550

551

552

553

554

555

556

557

558

559

560

561

562

563

564

565

566

567

568

569

570

571

572

573

574

575

576

577

578

579

580

581

582

583

584

585

586

587

588

589

590

591

592

593

594

595

596

597

598

599

600

601

602

603

604

605

606

607

608

609

610

611

612

613

614

615

616

617

618

619

620

621

622

623

624

625

626

627

628

629

630

631

632

633

634

635

636

637

638

639

640

641

642

643

644

645

646

647

648

649

650

651

652

653

654

655

656

657

658

659

660

661

662

663

664

665

666

667

668

669

670

671

672

673

674

675

676

677

678

679

680

681

682

683

684

685

686

687

688

689

690

691

692

693

694

695

696

697

698

699

700

701

702

703

704

705

706

707

708

709

710

711

712

713

714

715

716

717

718

719

720

721

722

723

724

725

726

727

728

729

730

731

732

733

734

735

736

737

738

739

740

741

742

743

744

745

746

747

748

749

750

751

752

753

754

755

756

757

758

759

760

761

762

763

764

765

766

767

768

769

770

771

772

773

774

775

776

777

778

779

780

781

782

783

784

785

786

787

788

789

790

791

792

793

794

795

796

797

798

799

800

801

802

803

804

805

806

807

808

809

810

811

812

813

814

815

816

817

818

819

820

821

822

823

824

825

826

827

828

829

830

831

832

833

834

835

836

837

838

839

840

841

842

843

844

845

846

847

848

849

850

851

852

853

854

855

856

857

858

859

860

861

862

863

864

865

866

867

868

869

870

871

872

873

874

875

876

877

878

879

880

881

882

883

884

885

886

887

888

889

890

891

892

893

894

895

896

897

898

899

900

901

902

903

904

905

906

907

908

909

910

911

912

913

914

915

916

917

918

919

920

921

922

923

924

925

926

927

928

929

930

931

932

933

934

935

936

937

938

939

940

941

942

943

944

945

946

947

948

949

950

951

952

953

954

955

956

957

958

959

960

961

962

963

964

965

966

967

968

969

970

971

972

973

974

975

976

977

978

979

980

981

982

983

984

985

986

987

988

989

990

991

992

993

994

995

996

997

998

999

1000

1001

1002

REQUIRED when replacing parts with warning labels affixed.

1058 OPERATOR'S MANUAL

1330 REPAIR MANUAL

Copyright © Briggs & Stratton. All Rights reserved

12

22-Jun-2026

Camshaft, Crankcase Cover, Crankshaft, Cylinder, Lubrication, Piston Group

REF NO	PART NO	QTY	DESCRIPTION
1	699490		CYLINDER ASSEMBLY
3	299819S		SEAL, Oil -(Magneto Side)
7	698210		GASKET, Cylinder Head
12	699485		GASKET, Crankcase
15	691686		PLUG-OIL DRAIN -(Square Head)
15A	691682		PLUG-OIL DRAIN -(Flush)
16	698879		CRANKSHAFT
17	692517		BEARING, Ball -(PTO Side)
17A	690824		BEARING-BALL
18A	790337		COVER, Crankcase
20	692550		SEAL-OIL -(PTO Side)
21	281658S		CAP, Oil Fill
22	699478		SCREW -(Crankcase Cover/Sump)
24	796335		KEY, Flywheel
25	791325		PISTON ASSEMBLY -(.020 Oversize)
25	792004		PISTON ASSEMBLY -(Standard)
25	797820		PISTON ASSEMBLY -(.010 Oversize)
26	692786		SET, Ring -(.020 Oversize) -Used Before Code Date 05100100
26	797821		SET, Ring -(.010 Oversize)
26	499631		SET, Ring -(Standard) -Used Before Code Date 05100100
26	791969		SET, Ring -(Standard) -Used After Code Date 05093000
26	791324		SET, Ring -(.020 Oversize) -Used After Code Date 05093000
27	691866		LOCK-PISTON PIN
28	499423		PIN-PISTON/STD -(Standard)
29	690124		ROD, Connecting -Used Before Code Date 07081600
29	792247		ROD, Connecting -(.020 Undersize)
29B	797436		ROD, Connecting -(Metric) -Used After Code Date 09053100
29B	795636		ROD, Connecting -(SAE) -Used After Code Date 07081500 -Used Before Code Date 09060100
30	791584		DIPPER-CONN ROD
32	691664		SCREW -(Connecting Rod)
32A	695759		SCREW -(Connecting Rod)

1319 WARNING LABEL

WARNING

1. Read the tool & operating instructions before using engine.

2. Assemble & operate. Make engine to run at least 5 minutes before starting.

3. Engines that cannot be started.

4. DO NOT run with exhaust open.












5. Never use compressed air to clean.

6. 150°F. Do not touch hot parts.

REQUIRED when replacing parts with warning labels affixed.

1058 OPERATOR'S MANUAL

1330 REPAIR MANUAL



Camshaft, Crankcase Cover, Crankshaft, Cylinder, Lubrication, Piston Group

REF NO	PART NO	QTY	DESCRIPTION
32B	791784		SCREW -(Connecting Rod) (SAE) -Used Before Code Date 09060100
32B	797437		SCREW -(Connecting Rod) (Metric) -Used After Code Date 09053100
46A	696813		CAMSHAFT
51	692555		GASKET, Intake -(2 Required)
88	790333		GASKET, Gear Cover/Housing
146	690979		KEY, Woodruff
163B	696024		GASKET, Air Cleaner -(Flat Panel Air Cleaner)
170	699818		STUD -(Crankcase Cover/Sump)
219	693578		GEAR, Governor
220	691724		WASHER -(Governor Gear)
286	794185		MODULE, Oil Sensor
287	699629		SCREW -(Dipstick Tube)
306	693610		SHIELD, Cylinder
307	699483		SCREW -(Cylinder Shield)
332	792723		NUT -(Flywheel)
357	692191		KEY, Drive Pulley -(SAE)
357	798869		KEY, Drive Pulley -(Metric)
358	791797		GASKET SET, Engine
364	695693		TERMINAL, Oil Plug
415	693463		PLUG
522	697689		PLUG, Dipstick/Fill
523	693618		DIPSTICK
524	281370S		SEAL, Dipstick Tube -(Dipstick Tube)
552	692346		BUSHING, Governor Crank
615	692576		RETAINER, Governor Shaft
616	692547		CRANK, Governor
718	690959		PIN, Locating
741	695087		GEAR, Timing
742	692564		RETAINER, E Ring
746	790278		GEAR-IDLER
799	699202		SCREW -(Oil Sensor)
842	691031		SEAL, O-Ring -(Dipstick Tube)
847	693617		DIPSTICK/TUBE ASSEMBLY
868	692044		SEAL, Valve
883	691893		GASKET-EXHAUST
883A	692237		GASKET-EXHAUST
993	694088		GASKET, Cylinder Head Plate
1022	691890		GASKET-ROCKER COVER
1052	790141		SENSOR, Oil
1058	276339		MANUAL, Operator's -(Oil Bath Air Cleaner)

1319 WARNING LABEL

WARNING

Read the tool & equipment instructions before using engine.

Assemble & operate. Make engine to operate at rated speed. Never exceed rated speed.

Engine and operator must be protected.












DO NOT run with exhaust open.

Exhaust temperature may exceed 500°F. Do not touch hot parts.

REQUIRED when replacing parts with warning labels affixed.

1058 OPERATOR'S MANUAL









1330 REPAIR MANUAL



Camshaft, Crankcase Cover, Crankshaft, Cylinder, Lubrication, Piston Group









REF NO	PART NO	QTY	DESCRIPTION
1058	277040		MANUAL, Operator's
1305	699691		SCREW -(Oil Sensor Module)
1319	794467		LABEL, Warning
1330	272147		MANUAL, Repair

Not For Reproduction




Carburetor

REF NO	PART NO	QTY	DESCRIPTION
38	698557		SCREW -(Shut Off Valve)
38A	797150		SCREW -(Shut Off Valve)
51	692555		GASKET, Intake -(2 Required)
53	793414		STUD -(Carburetor)
95	691636		SCREW -(Throttle Valve)
95A	698544		SCREW -(Throttle Valve)
95B	797161		SCREW -(Throttle Valve)
97A	698542		SHAFT, Throttle
97C	797628		SHAFT, Throttle
97B	797153		SHAFT, Throttle
98B	698551		KIT, Idle Speed -(Carburetor)
98C	797156		KIT, Idle Speed
104A	698536		PIN, Float Hinge
104B	797138		PIN, Float Hinge
104C	797622		PIN, Float Hinge
105	698537		VALVE, Float Needle
105A	797139		VALVE, Float Needle
108	692567		VALVE-CHOKE
108C	698546		VALVE, Choke
108D	797159		VALVE, Choke
109C	790624		SHAFT, Choke
117A	698666		JET, Main -(Standard)
117D	797574		JET, Main -(Standard)
117B	793708		JET, Main -(Standard)
117C	797140		JET, Main -(Standard)
118A	698552		JET, Main -(High Altitude)
118C	797141		JET, Main -(High Altitude)
118D	797575		JET, Main -(High Altitude)
118B	793709		JET, Main -(High Altitude)
122	795643		SPACER, Carburetor
125A	698558		CARBURETOR -Used Before Code Date 09030100
125C	796447		CARBURETOR -Used After Code Date 09022800
127C	690727		PLUG, Welch
127D	797135		PLUG, Welch
127E	797633		PLUG, Welch
130B	698543		VALVE, Throttle
130C	797154		VALVE, Throttle
130D	797630		VALVE, Throttle




Carburetor

REF NO	PART NO	QTY	DESCRIPTION
133A	698539		FLOAT, Carburetor
133B	797136		FLOAT, Carburetor
133C	797626		FLOAT, Carburetor
137A	698538		GASKET, Float Bowl
137B	797137		GASKET, Float Bowl
137C	797625		GASKET, Float Bowl
141	698545		KIT, Choke Shaft
141A	797158		KIT, Choke Shaft
142	797151		NOZZLE, Carburetor -(Standard)
163B	696024		GASKET, Air Cleaner -(Flat Panel Air Cleaner)
163D	793412		GASKET, Air Cleaner -(Oil Bath Air Cleaner)
231	690718		SCREW -(Choke Valve)
231A	797160		SCREW -(Choke Valve)
254	797145		DRAIN, Carburetor Bowl
276A	698540		WASHER, Sealing
276C	797632		WASHER, Sealing
276B	797147		WASHER, Sealing
365	699484		SCREW -(Carburetor)
464	698550		SEAL, O-Ring -(Fuel Shut-off Valve)
464A	797148		SEAL, O-Ring -(Fuel Shut-off Valve)
464B	797155		SEAL, O-Ring -(Fuel Shut-off Valve)
633	693867		SEAL, Choke/Throttle Shaft
633B	690998		SEAL, Choke/Throttle Shaft
633C	797157		SEAL, Choke/Throttle Shaft
692	690572		SPRING, Detent -(Choke)
692A	797134		SPRING, Detent
692B	797624		SPRING, Detent -(Choke)
951A	797592		LEVER, Choke
958A	698549		VALVE, Fuel Shut Off -(Plastic)
958B	797149		VALVE, Fuel Shut Off -(Plastic)
975A	698541		BOWL, Float
975B	797142		BOWL, Float
975C	797631		BOWL, Float
987	698556		SEAL, Choke/Throttle Shaft
987A	797152		SEAL, Choke/Throttle Shaft
987B	797629		SEAL, Choke/Throttle Shaft
1127	797146		SCREW -(Float Bowl to Carburetor Body)
1174	692055		NUT -(Intake Manifold)
1244	797143		SEAL, O-Ring -(Carburetor Bowl Drain)




Controls, Governor Spring, Ignition

REF NO	PART NO	QTY	DESCRIPTION
188	699479		SCREW -(Control Bracket)
190	699220		SCREW -(Fuel Tank)
209	692571		SPRING, Governor
209A	691278		SPRING, Governor
211	692069		SPRING, Governed Idle
222	699589		BRACKET, Control -Used Before Code Date 07030100
222C	699493		BRACKET, Control -Used Before Code Date 07030100
222D	795669		BRACKET, Control -(Used With Metal Fuel Tanks) -Used After Code Date 08051100
222F	795668		BRACKET, Control -(Used With Metal Fuel Tanks) -Used After Code Date 08051100
222F	793100		BRACKET, Control -(Used With Plastic Fuel Tanks) -Used After Code Date 07022800
222F	793100		BRACKET, Control -(Used With Metal Fuel Tanks) -Used After Code Date 07022800 -Used Before Code Date 08051200
222D	793107		BRACKET, Control -(Used With Plastic Fuel Tanks) -Used After Code Date 07022800
222D	793107		BRACKET, Control -(Used With Metal Fuel Tanks) -Used After Code Date 07022800 -Used Before Code Date 08051200
227	692573		LEVER, Governor Control
265	691024		CLAMP, Casing
267	699492		SCREW -(Casing Clamp)
268	691025		CASING, Control Wire -(Cut To Required Length)
269	691026		WIRE, Control -(Cut To Required Length)
270	691027		NUT -(Control Wire Casing)
271	691028		LEVER, Control
271A	694256		LEVER, Control
281	790261		PANEL, Control -Used Before Code Date 07030100
281	793133		PANEL, Control -Used After Code Date 07022800
318B	793567		KIT-SCREW/WASHER -(Mounting Bracket)
333	695711		ARMATURE, Magneto
334	699477		SCREW -(Magneto Armature)
347	698338		SWITCH, Rocker
356	693651		WIRE, Stop
356A	692390		WIRE, Stop
356K	791765		WIRE, Stop
356M	792609		WIRE, Stop
356B	692602		WIRE-STOP
356C	695630		WIRE, Stop




Controls, Governor Spring, Ignition

REF NO	PART NO	QTY	DESCRIPTION
356F	697397		WIRE, Stop
427	694255		NUT -(Control Bracket) (SAE)
427	798458		NUT -(Control Bracket) (Metric)
474	695730		ALTERNATOR
474A	698314		ALTERNATOR
493	691177		BRACKET, Mounting
493C	699048		BRACKET, Mounting
497	691693		SCREW -(Stopswitch Bracket)
500A	792613		WASHER -(Key Switch)
501	698315		REGULATOR
503	691532		STRAP, Starter
504	694254		SET, Friction Washer
505	691251		NUT -(Governor Control Lever)
526	690297		SCREW -(Regulator)
526A	690326		SCREW -(Regulator)
562	691119		BOLT -(Governor Control Lever)
564	699491		SCREW -(Control Cover)
564A	699206		SCREW -(Control Cover)
577	690795		CABLE, Starter
578B	790948		WIRE ASSEMBLY
579	691029		NUT -(Starter Cable)
604	697326		COVER-CONTROL
621	692310		SWITCH, Stop
627	792608		BRACKET, Stopswitch
632	693408		SPRING/LINK, Mechanical Governor
652	699755		SCREW -(Support Bracket)
652A	699481		SCREW -(Support Bracket)
663	699206		SCREW -(Control Panel)
668	694257		SPACER
773	694258		RETAINER -(Control Bracket)
813	690635		CLAMP
843A	695588		SLEEVE, Lever
851	493880S		TERMINAL, Spark Plug
890	790203		BRACKET, Support
892	791944		SWITCH, Key
920	691656		SOLENOID, Starter
990	695756		SET, Key
1054	280275		TIE, Cable
1119	699772		SCREW -(Alternator)



Cylinder Head

REF NO	PART NO	QTY	DESCRIPTION
5	797439		HEAD, Cylinder -(Metric) -Used After Code Date 09061700
5	699486		HEAD, Cylinder -(SAE) -Used Before Code Date 09061800
7	698210		GASKET, Cylinder Head
13	699482		SCREW -(Cylinder Head)
33	499642		VALVE, Exhaust
34	499641		VALVE, Intake
35	691304		SPRING, Valve -(Intake)
36	691304		SPRING, Valve -(Exhaust)
40	692194		RETAINER, Valve
45	690977		TAPPET, Valve
51	692555		GASKET, Intake -(2 Required)
122	795643		SPACER, Carburetor
155	797442		PLATE, Cylinder Head -(Metric) -Used After Code Date 09061700
155	698214		PLATE, Cylinder Head -(SAE) -Used Before Code Date 09061800
192	694543		ADJUSTER-ROCKER ARM -(SAE) -Used Before Code Date 09061800
192	797440		ADJUSTER, Rocker Arm -(Metric) -Used After Code Date 09061700
238	691300		CAP, Valve
337	691043		PLUG, Spark -(EMS)
337	491055S		PLUG, Spark -(Resistor)
337	84007216	1	PLUG, SPARK -(China Only)
383	19374S		WRENCH, Spark Plug
619	699481		SCREW -(Cylinder Head Plate)
635	692076		BOOT, Spark Plug
635A	692927		BOOT, Spark Plug
830	797441		STUD, Rocker Arm -(Rocker Arm) (Metric) -Used After Code Date 09061700
830	694544		STUD-ROCKER ARM -(Rocker Arm) (SAE) -Used Before Code Date 09061800
868	692044		SEAL, Valve
914	699481		SCREW -(Rocker Cover) (Bottom)
914A	692557		SCREW -(Rocker Cover) (Top) -Used Before Code Date 09061800
914A	797444		SCREW -(Rocker Cover) (Top) -Used After Code Date 09061700
914B	697551		SCREW -(Rocker Cover) (Center) -Used Before Code Date 09061800












Cylinder Head

REF NO	PART NO	QTY	DESCRIPTION
914B	797444S		SCREW -(Rocker Cover) (Center) -Used After Code Date 09061700
993	694088		GASKET, Cylinder Head Plate
1022	691890		GASKET-ROCKER COVER
1023	791585		COVER, Rocker
1026	790287		ROD, Push
1029	691230		ARM, Rocker -(SAE) -Used Before Code Date 09061800
1029	797443		ARM, Rocker -(Metric) -Used After Code Date 09061700
1034	691343		GUIDE, Push Rod
1095	791798		GASKET SET, Valve

121D CARBURETOR OVERHAUL KIT									
	127C		137A		633		464		
	127D				633B		464A		
	127E		137B		633C		464B		
	104A								
104B			137C		987		987A		
104C		163B		276A		276B		276C	
							987B		

977D CARBURETOR GASKET SET				
	137A		464	
			464A	
	137B		464B	
	137C			
163B				
	276A		276B	
		276C		












Fuel Supply

REF NO	PART NO	QTY	DESCRIPTION
51	692555		GASKET, Intake -(2 Required)
104A	698536		PIN, Float Hinge
104B	797138		PIN, Float Hinge
104C	797622		PIN, Float Hinge
121D	797634		KIT, Carburetor Overhaul
127C	690727		PLUG, Welch
127D	797135		PLUG, Welch
127E	797633		PLUG, Welch
137A	698538		GASKET, Float Bowl
137C	797625		GASKET, Float Bowl
137B	797137		GASKET, Float Bowl
163B	696024		GASKET, Air Cleaner -(Flat Panel Air Cleaner)
180	791598		TANK, Fuel -(Metal) -Used Before Code Date 07050900
180	794640		TANK, Fuel -(Metal) -Used After Code Date 07050800 -Used Before Code Date 08051200
180	795832		TANK, Fuel -(Metal) -Used After Code Date 08051100
181	699840		CAP, Fuel Tank -(Metal) -Used Before Code Date 07050900
181	794641		CAP, Fuel Tank -(Metal) -Used After Code Date 07050800
187	791745		LINE, Fuel -(Cut To Required Length)
187B	791874		LINE, Fuel -(Molded)
187C	797184		LINE, Fuel -(Molded)
187D	795046		LINE, Fuel -(Molded)
187E	797183		LINE, Fuel -(Molded)
190	699220		SCREW -(Fuel Tank)
190B	699839		SCREW -(Fuel Tank) -Used Before Code Date 08051200
190B	795047		SCREW -(Fuel Tank) -Used After Code Date 08051100
240	298090S		FILTER, Fuel
276A	698540		WASHER, Sealing
276B	797147		WASHER, Sealing
276C	797632		WASHER, Sealing
464	698550		SEAL, O-Ring -(Fuel Shut-off Valve)
464A	797148		SEAL, O-Ring -(Fuel Shut-off Valve)
464B	797155		SEAL, O-Ring -(Fuel Shut-off Valve)
601	791850		CLAMP, Hose

121D CARBURETOR OVERHAUL KIT									
	127C		137A		633		464		
	127D				633B		464A		
	127E		137B		633C		464B		
	104A								
104B			137C		987		987A		
104C		163B		276A		276B		276C	
							987B		

977D CARBURETOR GASKET SET				
	137A		464	
			464A	
	137B		464B	
	137C			
163B				
	276A		276B	
			276C	



Fuel Supply

REF NO	PART NO	QTY	DESCRIPTION
633	693867		SEAL, Choke/Throttle Shaft
633B	690998		SEAL, Choke/Throttle Shaft
633C	797157		SEAL, Choke/Throttle Shaft
957	792647		CAP, Fuel Tank -(Plastic) (Fresh Start)
957	795027		CAP, Fuel Tank -(Plastic) (Text Free)
957A	799719		CAP, Fuel Tank -(Plastic) (Carbon In Cap)
957B	698109		CAP, Fuel Tank -(Plastic)
958	698180		VALVE, Fuel Shutoff -(Plastic)
972	694260		TANK, Fuel -(Plastic)
977D	797635		SET, Carburetor Gasket
987	698556		SEAL, Choke/Throttle Shaft
987A	797152		SEAL, Choke/Throttle Shaft
987B	797629		SEAL, Choke/Throttle Shaft
1345	699887		FILTER, Filler Neck
1345A	792917		FILTER, Filler Neck

Replacement Engine - US & Canada

REF NO	PART NO	QTY	DESCRIPTION
--------	---------	-----	-------------

Not For Reproduction

