




Parts Manual

Mfg. No: 15B194-0018-E1


Model Components	Page
Blower Housing/Shrouds, Exhaust System, Flywheel.	4
Camshaft, Crankcase Cover, Crankshaft, Cylinder, Lubrication, Piston Group.	8
Carburetor, Fuel Supply.	12
Controls, Electric Starter, Governor Spring, Ignition, Rewind Starter.	16
Cylinder Head.	20
Replacement Engine - US & Canada.	24

Not For
Reproduction



Blower Housing/Shrouds, Exhaust System, Flywheel

REF NO	PART NO	QTY	DESCRIPTION
11B	695745		TUBE, Breather
23	699516		FLYWHEEL
37	699661		GUARD, Flywheel
65	699228		SCREW -(Rewind Starter)
78	699205		SCREW -(Flywheel Guard)
281A	793131		PANEL, Control -Used After Code Date 06051400
281A	697550		PANEL, Control -Used Before Code Date 06051500
300	699512		MUFFLER
304	699598		HOUSING, Blower
305	699481		SCREW -(Blower Housing)
318	690370		SCREW -(Mounting Bracket) (SAE)
318	798649		SCREW -(Mounting Bracket) (Metric)
332A	792723		NUT -(Flywheel)
363	19203		PULLER, Flywheel
455	797431		CUP, Flywheel -Used After Code Date 10071900
455	692591		CUP, Flywheel -Used Before Code Date 10072000
472	696691		KNOB, Choke Shaft
472B	791958		KNOB, Choke Shaft
493A	695744		BRACKET, Mounting
528	793006		HOSE, Primer
564	699854		SCREW -(Control Cover)
604A	793134		COVER, Control
604B	790473		COVER, Control
613	799081		SCREW -(Muffler) (Metric)
613	697812		SCREW -(Muffler) (SAE)
613A	699481		SCREW -(Muffler)
663	699854		SCREW -(Control Panel)
676D	794213		DEFLECTOR, Muffler
677A	699776		SCREW -(Muffler Deflector)
731	794590		HOOD, Snow
819	699233		SCREW -(Muffler Bracket)
823	699209		SCREW -(Muffler Adapter)
824	696017		GASKET, Heat Shield
832A	699313		MUFFLER
836B	699209		SCREW -(Muffler Guard)
836C	699234		SCREW -(Muffler Guard)
863	699849		BRACKET, Muffler



Blower Housing/Shrouds, Exhaust System, Flywheel

REF NO	PART NO	QTY	DESCRIPTION
864	699232		ADAPTER, Muffler
883	692237		GASKET-EXHAUST
883A	691893		GASKET-EXHAUST
976	790221		PRIMER, Carburetor
996	794687		SHIELD, Carburetor
1005	692592		FAN, Flywheel
1005A	794273		FAN, Flywheel
1011	794544		TUBE, Vent
1036	-----		Label-Emissions -(Available From A Briggs & Stratton Authorized Dealer)
1070	699201		SCREW -(Flywheel Fan)
1196	696692		SCREW -(Snow Hood)
1196A	699854		SCREW -(Snow Hood)
1251	696699		SHIELD, Snow
1252	699629		SCREW -(Snow Shield)














1319 WARNING LABEL

REQUIRED when replacing parts with warning labels affixed.

1058 OPERATOR'S MANUAL

1330 REPAIR MANUAL

1019 LABEL KIT



Camshaft, Crankcase Cover, Crankshaft, Cylinder, Lubrication, Piston Group

REF NO	PART NO	QTY	DESCRIPTION
1	794188		CYLINDER ASSEMBLY
2	399269		KIT, Bushing/Seal -(Magneto Side)
3	299819S		SEAL, Oil -(Magneto Side)
7B	791716		GASKET, Cylinder Head
12	699485		GASKET, Crankcase
15	691686		PLUG-OIL DRAIN
15B	695757		PLUG, Oil Drain
16	792208		CRANKSHAFT
18	699804		COVER, Crankcase
18B	699677		COVER, Crankcase
20	692550		SEAL-OIL -(PTO Side)
20A	691952		SEAL, Oil -(PTO Side) (Auxiliary Drive)
21	281658S		CAP, Oil Fill
22	699478		SCREW -(Crankcase Cover/Sump)
24	796335		KEY, Flywheel
25	791791		PISTON ASSEMBLY -(.020 Oversize)
25	791786		PISTON ASSEMBLY -(Standard)
26	791787		SET, Ring -(Standard)
26	791792		SET, Ring -(.020 Oversize)
27	690975		LOCK, Piston Pin
28	690229		PIN, Piston -(Standard)
29B	791783		ROD, Connecting
32	791784		SCREW -(Connecting Rod)
46	693404		CAMSHAFT
46A	695285		CAMSHAFT
51	791718		GASKET, Intake
146	690979		KEY, Woodruff
219	693578		GEAR, Governor
220	691724		WASHER -(Governor Gear)
287	699629		SCREW -(Dipstick Tube)
306A	695710		SHIELD, Cylinder
307	699483		SCREW -(Cylinder Shield)
307A	699234		SCREW -(Cylinder Shield)
307B	790557		SCREW -(Cylinder Shield)
358B	791797		GASKET SET, Engine
523	693618		DIPSTICK
524	281370S		SEAL, Dipstick Tube -(Dipstick Tube)
552	692346		BUSHING, Governor Crank
584	791759		COVER, Breather Passage















1319 WARNING LABEL

REQUIRED when replacing parts with warning labels affixed.

1058 OPERATOR'S MANUAL











1330 REPAIR MANUAL

1019 LABEL KIT













Camshaft, Crankcase Cover, Crankshaft, Cylinder, Lubrication, Piston Group

REF NO	PART NO	QTY	DESCRIPTION
585	791760		GASKET, Breather Passage
598	220624		SHIM, End Play -(Crankshaft or Camshaft Bearing)
615	692576		RETAINER, Governor Shaft
616	692547		CRANK, Governor
684	791761		SCREW -(Breather Passage Cover)
718	690959		PIN, Locating
741	695087		GEAR, Timing
742	692564		RETAINER, E Ring
746	790278		GEAR-IDLER
842	691031		SEAL, O-Ring -(Dipstick Tube)
847	693617		DIPSTICK/TUBE ASSEMBLY
868	692044		SEAL, Valve
883	692237		GASKET-EXHAUST
883A	691893		GASKET-EXHAUST
993	694088		GASKET, Cylinder Head Plate
998	696683		PIPE, Oil -(4)
998	792928		PIPE, Oil -(2 1/2)
1019	792211		KIT, Label
1022	691890		GASKET-ROCKER COVER
1058	279128TRI		MANUAL, Operator's
1319	794467		LABEL, Warning
1330	272147		MANUAL, Repair






















Carburetor, Fuel Supply

REF NO	PART NO	QTY	DESCRIPTION
51	791718		GASKET, Intake
95	691636		SCREW -(Throttle Valve)
97	690024		SHAFT, Throttle
97C	797628		SHAFT, Throttle
98	398185		KIT-IDLE SPEED -(Idle Speed) (Lmt 26, 27, 28, 31)
98C	797156		KIT, Idle Speed
104	691242		PIN, Float Hinge
104C	797622		PIN, Float Hinge
105A	797139		VALVE, Float Needle
108	695807		VALVE, Choke
109B	695729		SHAFT, Choke
109C	791957		SHAFT, Choke
117	694176		JET, Main -(Standard)
117E	798930		JET, Main -(Standard) -Used Before Code Date 11080800
117E	590906		JET, Main -(Standard) -Used After Code Date 11080700
118	695042		JET, Main -(High Altitude)
118E	798661		JET, Main -(High Altitude) -Used Before Code Date 11080800
118E	590440		JET, Main -(High Altitude) -Used After Code Date 11080700
121	792006		KIT, Carburetor Overhaul
121D	797634		KIT, Carburetor Overhaul
122	791717		SPACER, Carburetor
125A	794588		CARBURETOR -Used Before Code Date 10071000
125E	590907		CARBURETOR -Used After Code Date 11080700
125E	798918		CARBURETOR -Used After Code Date 10070900 -Used Before Code Date 11080800
127	694468		PLUG, Welch -(Bowl Vent)
127A	691739		PLUG-WELCH
127E	797633		PLUG, Welch
130	691181		VALVE-THROTTLE
130D	797630		VALVE, Throttle
133	398187		FLOAT-CARBURETOR
133B	797136		FLOAT, Carburetor
134	398188		KIT-NEEDLE/SEAT
137	693981		GASKET-FLOAT BOWL
137D	798932		GASKET, Float Bowl
186	692317		CONNECTOR-HOSE
187	791766		LINE, Fuel -(Cut To Required Length)
187A	798908		LINE, Fuel -(Molded) -Used After Code Date 10070900




















Carburetor, Fuel Supply

REF NO	PART NO	QTY	DESCRIPTION
187A	791867		LINE, Fuel -(Molded) -Used Before Code Date 10071000
187B	791874		LINE, Fuel -(Molded) -Used Before Code Date 10071000
187B	798907		LINE, Fuel -(Molded) -Used After Code Date 10070900
190	699220		SCREW -(Fuel Tank)
276	271716		WASHER-SEALING
276C	797632		WASHER, Sealing
365	699484		SCREW -(Carburetor)
601	791850		CLAMP, Hose
692	690572		SPRING, Detent
692B	797624		SPRING, Detent
957	792647		CAP, Fuel Tank -(Plastic) (Fresh Start)
957	795027		CAP, Fuel Tank -(Plastic) (Text Free)
957A	799719		CAP, Fuel Tank -(Plastic) (Carbon In Cap)
957B	698109		CAP, Fuel Tank -(Plastic)
958	698180		VALVE, Fuel Shutoff -(Plastic)
972	694260		TANK, Fuel -(Plastic)
975	493640		BOWL, Float
975D	798931		BOWL, Float







Controls, Electric Starter, Governor Spring, Ignition, Rewind Starter

REF NO	PART NO	QTY	DESCRIPTION
55A	696710		HOUSING, Rewind Starter
58	693389		ROPE, Starter -(Cut To Required Length)
60B	699334		GRIP, Starter Rope
65A	699851		SCREW -(Rewind Starter)
188	699479		SCREW -(Control Bracket)
190	699220		SCREW -(Fuel Tank)
209	692571		SPRING, Governor
209A	691278		SPRING, Governor
222	699592		BRACKET, Control -Used Before Code Date 06051500
222D	790549		BRACKET, Control -Used Before Code Date 06051500
222F	793100		BRACKET, Control -Used After Code Date 06051400
222G	793109		BRACKET, Control -Used After Code Date 06051400
227	692573		LEVER, Governor Control
268	691025		CASING, Control Wire -(Cut To Required Length)
269	691026		WIRE, Control -(Cut To Required Length)
270	691027		NUT -(Control Wire Casing) (Control Wire Casing)
271	691028		LEVER, Control
271A	698038		LEVER, Control
309A	793667		MOTOR, Starter
318A	790537		SCREW -(Mounting Bracket)
333	695711		ARMATURE, Magneto
334	699477		SCREW -(Magneto Armature)
347	698338		SWITCH, Rocker
356C	695630		WIRE, Stop
356K	695731		WIRE, Stop
356L	790552		WIRE, Stop
427	694255		NUT -(Control Bracket) (SAE)
427	798458		NUT -(Control Bracket) (Metric)
456	692299		PLATE-PAWL FRICTION
459	281505S		PAWL-RATCHET
474	698314		ALTERNATOR
474A	791743		ALTERNATOR
485	695755		KNOB, Control
493B	691177		BRACKET, Mounting
493C	699048		BRACKET, Mounting
501	698315		REGULATOR
504	694254		SET, Friction Washer
505	691251		NUT -(Governor Control Lever)
526	690297		SCREW -(Regulator)







Controls, Electric Starter, Governor Spring, Ignition, Rewind Starter

REF NO	PART NO	QTY	DESCRIPTION
562	691119		BOLT -(Governor Control Lever)
578A	790481		WIRE ASSEMBLY
597	691696		SCREW -(Pawl Friction Plate)
608A	699335		STARTER-REWIND -Used Before Code Date 10072000
608B	797430		STARTER, Rewind -Used After Code Date 10071900
621	692310		SWITCH, Stop
632	692653		SPRING/LINK, Mechanical Governor
668	694257		SPACER
689	691855		SPRING-FRICTION
773	694258		RETAINER
851	493880S		TERMINAL, Spark Plug
892	791944		SWITCH, Key
892A	798182		SWITCH, Key
930	696709		GUARD, Rewind
990	695756		SET, Key
990A	798177		SET, Key
1054	280275		TIE, Cable
1119	699772		SCREW -(Alternator)
1210	498144		PULLEY/SPRING ASSY -(Pulley)
1211	498144		PULLEY/SPRING ASSY -(Spring)
1230	699847		STUD -(Control Bracket)
1403	699481		SCREW -(Wire Assembly)



Cylinder Head

REF NO	PART NO	QTY	DESCRIPTION
5	791720		HEAD, Cylinder
7B	791716		GASKET, Cylinder Head
13	699482		SCREW -(Cylinder Head)
33	499642		VALVE, Exhaust
34	499641		VALVE, Intake
35	691304		SPRING, Valve -(Intake)
36	691304		SPRING, Valve -(Exhaust)
40	692194		RETAINER, Valve
45	690977		TAPPET, Valve
51	791718		GASKET, Intake
122	791717		SPACER, Carburetor
155	698214		PLATE, Cylinder Head -(SAE) -Used Before Code Date 09061800
155	797442		PLATE, Cylinder Head -(Metric) -Used After Code Date 09061700
192	797440		ADJUSTER, Rocker Arm -(Metric) -Used After Code Date 09061700
192	694543		ADJUSTER-ROCKER ARM -(SAE) -Used Before Code Date 09061800
238	691300		CAP, Valve
337	691043		PLUG, Spark -(EMS)
337	491055S		PLUG, Spark -(Resistor)
337	84007216		PLUG, SPARK -(China Only)
383	19374S		WRENCH, Spark Plug
619	699481		SCREW -(Cylinder Head Plate)
635A	692927		BOOT, Spark Plug
830	797441		STUD, Rocker Arm -(Rocker Arm) (Metric) -Used After Code Date 09061700
830	694544		STUD-ROCKER ARM -(Rocker Arm) (SAE) -Used Before Code Date 09061800
868	692044		SEAL, Valve
914	699481		SCREW -(Rocker Cover) (Bottom)
914A	692557		SCREW -(Rocker Cover) (Top) -Used Before Code Date 09061800
914A	797444		SCREW -(Rocker Cover) (Top) -Used After Code Date 09061700
914B	697551		SCREW -(Rocker Cover) (Center) -Used Before Code Date 09061800
914B	797444S		SCREW -(Rocker Cover) (Center) -Used After Code Date 09061700
993	694088		GASKET, Cylinder Head Plate



Cylinder Head

REF NO	PART NO	QTY	DESCRIPTION
1022	691890		GASKET-ROCKER COVER
1023	499924		COVER, Rocker
1026	790287		ROD, Push
1029	691230		ARM, Rocker -(SAE) -Used Before Code Date 09061800
1029	797443		ARM, Rocker -(Metric) -Used After Code Date 09061700
1034	691343		GUIDE, Push Rod
1095A	791798		GASKET SET, Valve

Replacement Engine - US & Canada

REF NO	PART NO	QTY	DESCRIPTION
	15C1943018	1	Replacement Engine
	795434	1	Replacement Short Block
	-----		Top No-Load Speed: 3600 -Trim: ALL
	-----		Service Note: For all Go-Karts use only a Model 136200 series engine as a replacement, regardless of the original Model.

Not For Reproduction

