



Parts Manual

Mfg. No: 18055x89
Walk-Behind Mower (1996)


Model Components	Page
General Assembly.....	4
Torque Specification Chart.....	8

Not For
Reproduction

General Assembly

Note: Unless noted otherwise, use the standard torque specifications

Mfg. No: 18055x89



General Assembly

REF NO	PART NO	QTY	DESCRIPTION
1	-----		Key Assembly *
2	776065		Discharge Chute
3	-----		Battery Pack Assembly -(To order part call Briggs & Stratton)
4	-----		Interlock Switch Assembly *
5	776066MA		Magnet
6	776067		Screw
7	776068		Cord Clip
8	-----		Circuit Board Wire Assembly -(To order part call Briggs & Stratton)
9	-----		Harness - Wiring
10	776069		Mower Cover *
11	-----		Solenoid *
12	776070		Knob
13	-----		Motor *
14	776071		Height Adjustor Handle
15	776072		Mulching Cover
16	776073		Chute Stud
17	776074		Interlock Retainer
18	776075		Mower Deck
19	776076		Height Adjustor, Front
20	776077		Bolt, Motor
21	776078		Blade Adaptor
22	776079		Blade
23	776080		Axle Retainer
24	776081		Screw
25	776082		Front Wheel
26	776083		Hubcap
27	776084		Wheel Retainer
28	776085		Height Adjustor Link
29	776086		Blade Mounting Bolt
30	776087		Washer, Split Ring
31	776088		Trailing Shield
32	776089		Lower Handle Bar Bolt
33	PER - 776090		Rear Wheel
34	776091		Height Adjustor, Rear
35	776092		Link Retainer
36	776093		Bolt Retainer
37	-----		Charger -(To order part call Briggs & Stratton)
38	776094		Handlebar Knob
39	776096		Wire Clamp
40	-----		Harness, Battery Charger * -(Optional)
41	776097		Lower Handlebar
42	776094		Handlebar Knob
43	776095		Handlebar Bolt
44	-----		Circuit Breaker Label/Boot -(To order part call Briggs & Stratton)
45	776098		Handlebar Screw


Footnotes:

Note* To order part call Briggs & Stratton

General Assembly

Note: Unless noted otherwise, use the standard torque specifications

Mfg. No: 18055x89



General Assembly




REF NO	PART NO	QTY	DESCRIPTION
46	776099		Upper Handlebar
47	-----		Motor Control *
48	776100		Foam Grip
49	-----		Blade Control Assembly -(To order part call Briggs & Stratton)

Not For
Reproduction

Hardware Identification & Torque Specifications

Torque Specification Chart								
FOR STANDARD METRIC MACHINE HARDWARE (Tolerance ± 20%)								
Property Class	 Class 5.6		 Class 8.8		 Class 10.9		 Class 12.9	
Size Of Hardware	in/lbs ft/lbs	Nm.	in/lbs ft/lbs	Nm.	in/lbs ft/lbs	Nm.	in/lbs ft/lbs	Nm.
M3	5.88	.56	13.44	1.28	19.2	1.80	22.92	2.15
M4	13.44	1.28	30.72	2.90	43.44	4.10	52.56	4.95
M5	26.4	2.50	60.96	5.75	5.97	8.10	7.15	9.7
M6	44.64	4.3	7.3	9.9	10.3	14	12.1	16.5
M7	5.2	7.1	12.1	16.5	16.9	23	19.9	27
M8	7.7	10.5	17.7	24	25	34	29	40
M10	15	21	35	48	50	67	59	81
M12	26	36	61	83	86.2	117	103	140
M14	42	58	101	132	136	185	162	220
M16	64	88	147	200	210	285	250	340
M18	89	121	202	275	287	390	346	470
M20	126	171	290	390	405	550	486	660
M22	169	230	390	530	559	745	656	890
M24	217	295	497	375	708	960	840	1140
M27	320	435	733	995	1032	1400	1239	1680
M30	435	590	995	1350	1401	1900	1681	2280
M33	590	800	1349	1830	1902	2580	2278	3090
M36	759	1030	1740	2360	2441	3310	2935	3980
M39	988	1340	2249	3050	3163	4290	3798	5150

The guides and ruler furnished below are designed to help you select the appropriate hardware.



Standard Hardware Sizing

When a washer or nut is identified as 1/2" (M8), this is the *Nominal size*, meaning the *inside diameter* is 1/2 inch (8mm metric thread diameter); if a second number is present it represents the *threads per inch* (distance between threads).


When bolt or capscrew is identified as 1/2 - 16 x 2" (M8 - 1.25 x 50), this means the *Nominal size*, or body diameter is 1/2 inch (8mm metric thread diameter), the second number, 16, represents the *threads per inch*, (*distance between threads*). The final number is the body length of the bolt or screw, 2 inches (50mm).

Torque Specification Chart						
FOR STANDARD MACHINE HARDWARE (Tolerance ± 20%)						
Hardware Grade	 SAE Grade 2		 SAE Grade 5		 SAE Grade 8	
Size Of Hardware	in/lbs ft/lbs	Nm.	in/lbs ft/lbs	Nm.	in/lbs ft/lbs	Nm.
8-32	19	2.1	30	3.4	41	4.6
8-36	20	2.3	31	3.5	43	4.9
10-24	27	3.1	43	4.9	60	6.8
10-32	31	3.5	49	5.5	68	7.7
1/4-20	66	7.6	8	10.9	12	16.3
1/4-28	76	8.6	10	13.6	14	19.0
5/16-18	11	15.0	17	23.1	25	34.0
5/16-24	12	16.3	19	25.8	29	34.0
3/8-16	20	27.2	30	40.8	45	61.2
3/8-24	23	31.3	35	47.6	50	68.0
7/16-14	30	40.8	50	68.0	70	95.2
7/16-20	35	47.6	55	74.8	80	108.8
1/2-13	50	68.0	75	102.0	110	149.6
1/2-20	55	74.8	90	122.4	120	163.2
9/16-12	65	88.4	110	149.6	150	204.0
9/16-18	75	102.0	120	163.2	170	231.2
5/8-11	90	122.4	150	204.0	220	299.2
5/8-18	100	136	180	244.8	240	326.4
3/4-10	160	217.6	260	353.6	386	525.0
3/4-16	180	244.8	300	408.0	420	571.2
7/8-9	140	190.4	400	544.0	600	816.0
7/8-14	155	210.8	440	598.4	660	897.6
1-8	220	299.2	580	788.8	900	1,244.0
1-12	240	326.4	640	870.4	1,000	1,360.0

NOTES

- These torque values are to be used for all hardware excluding: locknuts, self-tapping screws, thread forming screws, sheet metal screws and socket head setscrews.
- Recommended seating torque values for locknuts:
 - for prevailing torque locknuts - use 65% of grade 5 torques.
 - for flange whizlock nuts and screws - use 135% of grade 5 torques.
- Unless otherwise noted on assembly drawings, all torque values must meet this specification.

Common Hardware Types



Wrench & Fastener Size Guide

 1/4" Bolt or Nut Wrench—7/16"	 5/16" Bolt or Nut Wrench—1/2"	 3/8" Bolt or Nut Wrench—9/16"	 7/16" Bolt or Nut Wrench (Bolt)—5/8" Wrench (Nut)—11/16"	 1/2" Bolt or Nut Wrench—3/4"
M6 Bolt or Nut Wrench—10mm	M8 Bolt or Nut Wrench—13mm	M10 Bolt or Nut Wrench—17mm	M12 Bolt or Nut Wrench—19mm	M14 Bolt or Nut Wrench—22mm

