




Parts Manual

Mfg. No: 19L237-0056-F1


Model Components	Page
Air Cleaner Group.	4
Alternator Group.	6
Blower Housing Group.	8
Carburetor Group.	10
Controls Group.	16
Crankcase Cover/Sump and Lubrication Group.	18
Crankshaft Group.	20
Cylinder Group.	22
Cylinder Head Group.	24
Exhaust Group.	26
Flywheel, Ignition, and Starter Group.	28
Fuel Supply Group.	30
Service Parts and Tools Group.	32

Not For
Reproduction




Air Cleaner Group


REF NO	PART NO	QTY	DESCRIPTION
11	798964	1	TUBE, Breather
53	-----	2	STUD -(Part information located in Carburetor Group.)
176	798965	1	SEAL, O-Ring -(Air Cleaner Base)
185	794838	2	NUT -(Air Cleaner Base)
276	798505	1	WASHER, Sealing
412	793443	2	NUT -(Air Cleaner Cover)
445	797032	1	FILTER, A/C Cartridge
467	691985	1	KNOB, Air Cleaner Cover
717	798989	1	BRACKET, Air Cleaner
875	798966	1	BASE, Air Cleaner
961	699691	1	SCREW -(Air Cleaner Bracket)
967	798795	1	FILTER, Pre Cleaner
968	798963	1	COVER, Air Cleaner




1119




526



501




493



Alternator Group


REF NO	PART NO	QTY	DESCRIPTION
474	695466	1	ALTERNATOR
493	691177	1	BRACKET, Mounting
501	845907	1	REGULATOR
526	699772	2	SCREW -(Regulator)
1119	699772	4	SCREW -(Alternator)

Not For Reproduction




Blower Housing Group

REF NO	PART NO	QTY	DESCRIPTION
304A	594749	1	HOUSING-BLOWER
305	699481	3	SCREW -(Blower Housing)
727A	-----	1	COVER, Starter Drive -(Part information located in Flywheel/Ignition/Starter Group.)
732	-----	2	SCREW -(Part information located in Flywheel/Ignition/Starter Group.)
1036	-----	1	LABEL, Emissions -(Available From A Briggs & Stratton Authorized Service Dealer)
1319	794467	1	LABEL, Warning -(Required When Replacing Parts With Warning Labels Affixed)
1319A	797669	1	LABEL, Warning -(Required When Replacing Parts With Warning Labels Affixed)




Carburetor Group

REF NO	PART NO	QTY	DESCRIPTION
38	698557	2	SCREW -(Fuel Shut Off Valve) -Used Before Code Date 18112600
38A	595328	2	SCREW -(Fuel Shut Off Valve) -Used After Code Date 18112500
51	-----	1	GASKET, Intake -(Part information located in Cylinder Head Group.)
53	798988	2	STUD -(Carburetor)
95	690718	2	SCREW -(Throttle Valve) -Used Before Code Date 18112600
95A	797161	2	SCREW -(Throttle Valve) -Used After Code Date 18112500
98	695408	1	KIT, Idle Speed -Used Before Code Date 18112600
98A	847139	1	KIT, Idle Speed -Used After Code Date 18112500
104	694918	1	PIN, Float Hinge -Used Before Code Date 18112600
104A	597533	1	PIN, Float Hinge -Used After Code Date 18112500
105	696136	1	VALVE, Float Needle -Used Before Code Date 18112600
105A	84004840	1	VALVE, Float Needle -Used After Code Date 18112500
117	698788	1	JET, Main -(Standard) -Used Before Code Date 18112600
117A	84004489	1	JET, Main -(Standard) -Used After Code Date 18112500
118	799134	1	JET, Main -(High Altitude) -Used Before Code Date 18112600
118A	84004744	1	JET, Main -(High Altitude) -Used After Code Date 18112500
121	799722	1	KIT, Carburetor Overhaul -(Service Kits may include extra parts not specific to this engine.) -Used Before Code Date 18112600
121A	84004975	1	KIT, Carburetor Overhaul -(Service Kits may include extra parts not specific to this engine.) -Used After Code Date 18112500
122	799766	1	SPACER, Carburetor -Used Before Code Date 18112600
122A	84004776	1	SPACER, Carburetor -Used After Code Date 17112000
125	799060	1	CARBURETOR -Used Before Code Date 18112600
125A	84003204	1	CARBURETOR -Used After Code Date 18112500
127	690727	1	PLUG, Welch -Used Before Code Date 18112600
127A	84004841	1	PLUG, Welch -Used After Code Date 18112500
130	696139	1	VALVE, Throttle -Used Before Code Date 18112600
130A	84004397	1	VALVE, Throttle -Used After Code Date 18112500



Carburetor Group


REF NO	PART NO	QTY	DESCRIPTION
133	694914	1	FLOAT, Carburetor -Used Before Code Date 18112600
133A	84004490	1	FLOAT, Carburetor -Used After Code Date 18112500
137	799991	1	GASKET, Float Bowl -Used Before Code Date 18112600
137A	84004205	1	GASKET, Float Bowl -Used After Code Date 18112500
147	594872	1	JET, Pilot -Used After Code Date 18112500
163	798962	1	GASKET, Air Cleaner
185	-----	2	NUT -(Part information located in Air Cleaner Group.)
240	597039	1	FILTER, Fuel -Used After Code Date 18112500
246	595153	1	BOWL-FUEL VALVE-STRAINER -Used Before Code Date 18112600
246A	597043	1	BOWL, Fuel Filter -Used After Code Date 18112500
254	595322	1	DRAIN, Carburetor Bowl -Used After Code Date 18112500
276	84004488	1	WASHER, Sealing -Used After Code Date 18112500
315	799035	1	SEAL, O-Ring -(Fuel Filter Bowl) -Used Before Code Date 18112600
315A	597735	1	GASKET, Fuel Bowl -(Fuel Filter Bowl) -Used After Code Date 18112500
464	698550	1	SEAL, O-Ring -(Fuel Shut-off Valve) -Used Before Code Date 18112600
464A	595320	1	SEAL, O-Ring -(Fuel Shut-off Valve) -Used After Code Date 18112500
623	799051	1	SEAL, O-Ring -(Carburetor Spacer) -Used Before Code Date 18112600
632	-----	1	SPRING/LINK, Mechanical Governor -(Part information located in Controls Group.)
633	690722	1	SEAL, Choke/Throttle Shaft -Used Before Code Date 18112600
633A	84004398	1	SEAL, Choke/Throttle Shaft -Used After Code Date 18112500
717	798989	1	BRACKET, Air Cleaner -Used Before Code Date 18112600
717	84004868	1	BRACKET, Air Cleaner -Used After Code Date 18112500
787	798635	1	ARM, Lever -Used Before Code Date 18112600
951	798528	1	LEVER, Choke
955	595329	1	PLUG, Carburetor -Used After Code Date 18112500
958	799073	1	VALVE, Fuel Shut Off -Used Before Code Date 18112600
958A	84004839	1	VALVE, Fuel Shut Off -Used After Code Date 18112500
961	699691	1	SCREW -(Air Cleaner Bracket)
975	84004204	1	BOWL, Float -Used After Code Date 18112500



Carburetor Group


REF NO	PART NO	QTY	DESCRIPTION
1127	695407	2	SCREW -(Float Bowl to Carburetor Body) -Used Before Code Date 18112600
1297	798637	2	SCREW -Used Before Code Date 18112600
1570	84005011	1	GASKET, Spacer -Used After Code Date 17112000

Not For Reproduction




Controls Group

REF NO	PART NO	QTY	DESCRIPTION
188	699479		SCREW -(Control Bracket)
209	799058		SPRING, Governor
211	798960		SPRING, Governed Idle
222	798478		BRACKET, Control
227	799049		LEVER, Governor Control
278	798196		WASHER -(Governor Control Lever)
281	798961		PANEL, Control
286	594800		MODULE, Oil Sensor
318	691693		SCREW -(Mounting Bracket)
427	798458		NUT -(Control Bracket)
493A	798803		BRACKET, Mounting
500	691086		WASHER -(Key Switch)
505	793515		NUT -(Governor Control Lever)
562	798197		BOLT -(Governor Control Lever)
578	798802		WIRE ASSEMBLY
578A	596032		WIRE ASSEMBLY
632	799083		SPRING/LINK, Mechanical Governor
663	699492		SCREW -(Control Panel)
664	691087		NUT -(Key Switch)
843	695588		SLEEVE, Lever
892	690646		SWITCH, Key
990	691959		SET, Key




Crankcase Cover/Sump and Lubrication Group

REF NO	PART NO	QTY	DESCRIPTION
12	798807		GASKET, Crankcase
18	791412		COVER-CRANKCASE
20	798991		SEAL, Oil -(PTO Side)
22	798955		SCREW -(Crankcase Cover/Sump)
219	693578		GEAR, Governor
220	693578		GEAR, Governor -(Governor Gear)
364	699947		TERMINAL, Oil Plug
522	798503		PLUG, Dipstick/Fill
742	692564		RETAINER, E Ring
746	694679		GEAR, Idler
799	695446		SCREW -(Oil Sensor)
1052	597141		SENSOR, Oil
1548	798995		BEARING, Ball







Crankshaft Group

REF NO	PART NO	QTY	DESCRIPTION
16	590368		CRANKSHAFT
24	222698S		KEY, Flywheel
25	594750		PISTON ASSEMBLY
26	792026		SET, Ring
27	690975		LOCK, Piston Pin
28	594734		PIN, Piston
29	694691		ROD, Connecting
30	694692		DIPPER, Connecting Rod
32	690976		SCREW -(Connecting Rod)
46	795697		CAMSHAFT
377	690979		KEY, Woodruff
741	691288		GEAR, Timing






Cylinder Group

REF NO	PART NO	QTY	DESCRIPTION
1	799046		CYLINDER ASSEMBLY
3	798991		SEAL, Oil -(Magneto Side)
15	691686		PLUG-OIL DRAIN
17	798993		BEARING, Ball
306	798992		SHIELD, Cylinder
307	794822		SCREW -(Cylinder Shield)
404	795759		WASHER -(Governor Crank)
529	791822		GROMMET
552	694674		BUSHING, Governor Crank
614	691620		PIN, Cotter
616	795758		CRANK, Governor
718	592860		PIN, Locating
718A	695178		PIN, Locating
725	590347		SHIELD, Heat
728	699481		SCREW -(Heat Shield)




Cylinder Head Group

REF NO	PART NO	QTY	DESCRIPTION
3	-----	1	SEAL, Oil -(Part information located in Cylinder Group.)
5	799858	1	HEAD, Cylinder
7	694872	1	GASKET, Cylinder Head
12	-----	1	GASKET, Crankcase -(Part information located in Crankcase Cover/Sump Group.)
13	794829	5	SCREW -(Cylinder Head)
20	-----	1	SEAL, Oil -(Part information located in Crankcase Cover/Sump Group.)
33	697576	1	VALVE, Exhaust
34	792200	1	VALVE, Intake
35	694865	1	SPRING, Valve -(Intake)
36	694865	1	SPRING, Valve -(Exhaust)
42	499586	2	KEEPER, Valve
45	690977	2	TAPPET, Valve
51	590396	1	GASKET, Intake
163	-----	1	GASKET, Air Cleaner -(Part information located in Carburetor Group.)
176	-----	1	GASKET, Air Cleaner -(Part information located in Air Cleaner Group.)
192	690083	2	ADJUSTER, Rocker Arm
337	555737	1	PLUG, Spark
358	-----	1	GASKET SET, Engine -(Part information located in Cylinder Group.)
623	799051	1	SEAL, O-Ring -(Carburetor Spacer)
635	691909	1	BOOT, Spark Plug
798	697890	2	SCREW -(Rocker Arm)
868	690968	1	SEAL, Valve
883	-----	1	GASKET, Exhaust -(Part information located in Exhaust Group.)
914	794827	4	SCREW -(Rocker Cover)
1022	690971	1	GASKET, Rocker Cover
1023	697691	1	COVER, Rocker
1026	592673	2	ROD, Push
1029	690972	2	ARM, Rocker
1095	798801	1	GASKET SET, Valve -(Service Kits can include parts not for this engine.)
1100	791959	2	PIVOT, Rocker Arm








Exhaust Group

REF NO	PART NO	QTY	DESCRIPTION
300	593836		MUFFLER
346	794845		SCREW -(Spark Arrestor)
613	594653		SCREW -(Muffler)
613B	794844		SCREW -(Muffler)
832	593835		GUARD, Muffler
836	593834		SCREW -(Muffler Guard)
883	695398		GASKET, Exhaust
994	796399		ARRESTOR, Spark








Flywheel, Ignition, and Starter Group

REF NO	PART NO	QTY	DESCRIPTION
23	794812		FLYWHEEL
58	693389		ROPE, Starter -(Cut to Required Length)
60	490652		GRIP-STARTER ROPE
65	699228		SCREW -(Rewind Starter)
309	695479		MOTOR, Starter
310	690323		SCREW -(Starter Motor)
332	794824		NUT -(Flywheel)
333	591459		ARMATURE-MAGNETO
334	699477		SCREW -(Magneto Armature)
356	695630		WIRE, Stop
356A	799721		WIRE, Stop
363	19203		PULLER, Flywheel
455	794867		CUP, Flywheel
462	691261		WASHER -(Starter Cable)
503	691532		STRAP, Starter
510	693699		DRIVE, Starter
513	692024		CLUTCH, Drive
577	690795		CABLE, Starter
579	691029		NUT -(Starter Cable)
608	594738		STARTER, Rewind
727A	697465		COVER, Starter Drive
729	799133		CLIP, Wire
732	699200		SCREW -(Starter Drive Cover)
783	593935		GEAR, Pinion
801	694482		CAP-DRIVE
802	691286		CAP, End
813	690635		CLAMP
851	493880S		TERMINAL, Spark Plug
920	846820		SOLENOID, Starter
1005	794815		FAN, Flywheel
1051	691265		RING, Retaining
1070	794821		SCREW -(Flywheel Fan)
1090	691293		RETAINER, Brush



Fuel Supply Group

REF NO	PART NO	QTY	DESCRIPTION
182	595316		BRACKET, Fuel Tank
187	594748		LINE, Fuel
187B	791766		LINE, Fuel
190	798496		SCREW -(Fuel Tank)
190A	799725		SCREW -(Used with Oil Sensor Module)
240	394358S		FILTER, Fuel
601	791850		CLAMP, Hose
705	690941		NUT -(Fuel Tank)
705A	794838		NUT -(Fuel Tank)
957	799324		CAP, Fuel Tank
972	596357		TANK, Fuel



Service Parts and Tools Group

REF NO	PART NO	QTY	DESCRIPTION
121	799722		KIT, Carburetor Overhaul -(Service Kits may include extra parts not specific to this engine.)
358	798800		GASKET SET, Engine -(Service Kits may include extra parts not specific to this engine.)
363	19203		PULLER, Flywheel
383	19576S		WRENCH, Spark Plug
1095	798801		GASKET SET, Valve -(Service Kits may include extra parts not specific to this engine.)

