




Parts Manual

Mfg. No: 206457-0118-E9

Model Components	Page
Air Cleaner, Exhaust System.	4
Alternator, Ignition.	6
Blower Housing/Shrouds, Flywheel, Rewind Starter.	8
Camshaft, Crankcase Cover, Crankshaft, Cylinder, Lubrication, Operator's Manual, Piston/Rings/Connecting	10
Carburetor, Kit - Carburetor Overhaul.	14
Controls, Governor Spring.	18
Cylinder Head, Gasket Set - Engine, Gasket Set - Valve, Valves.	20
Electric Starter, Gear Reduction.	22
Fuel Supply.	24
Replacement Engine - US & Canada.	26

Not For
Reproduction



Air Cleaner, Exhaust System

REF NO	PART NO	QTY	DESCRIPTION
11A	695305		TUBE, Breather
53A	695433		STUD -(Carburetor)
81	695400		LOCK, Muffler Screw
163	693458		GASKET, Air Cleaner -(Air Cleaner)
176	691917		SEAL, O-Ring -(Air Cleaner Base)
185	690958		NUT -(Air Cleaner Base)
300	697252		MUFFLER
300C	793701		MUFFLER
355	691075		WASHER -(Muffler Bracket)
436C	792374		MANIFOLD, Exhaust
437	696705		SCREW -(Exhaust Manifold)
445A	695302		FILTER, A/C Cartridge
467	691668		KNOB, Air Cleaner Cover
613	695312		SCREW -(Muffler)
613A	695399		SCREW -(Muffler)
676	393761		DEFLECTOR, Muffler -(Side Outlet)
677	690367		SCREW -(Muffler Deflector)
740	710090		LOCKNUT -(Muffler Bracket)
740A	793859		NUT -(Muffler Bracket)
819	690352		SCREW -(Muffler Bracket)
832	795035		GUARD, Muffler
832C	792380		MUFFLER
836	690367		SCREW -(Muffler Guard) -Used Before Code Date 01061100
836	695312		SCREW -(Muffler Guard) -Used After Code Date 01061000
836C	710023		SCREW -(Muffler Guard)
863C	793700		BRACKET, Muffler
875	695304		BASE, Air Cleaner -(Plastic)
883	695398		GASKET, Exhaust
883A	697255		GASKET, Exhaust
883C	710250		GASKET, Exhaust
967A	695303		FILTER, Pre Cleaner
968B	695301		COVER, Air Cleaner
971	695181		SCREW -(Air Cleaner Base) (Remote Choke)
1177	710090		LOCKNUT -(Muffler)

503

813

579

920

577A

578A

627A

347B

361A

990A

892A

500A

10 - 16 AMP
474D
578
NOTE: All stators use a No. 1119 mounting screw. NOTE: The proper flywheel part number and/or the alternator magnet size will determine the alternator type or output. See repair instruction manual for additional information. 526 501

892

664

990

577

641A

636

641

575

627

361

500

663A

1046

347A

334

333

851

493A

286

286B

286C

356

356B

356C

356D

356E


356H

356J

356L

Alternator, Ignition


REF NO	PART NO	QTY	DESCRIPTION
286B	696058		MODULE, Oil Sensor -Used Before Code Date 03010600
286C	699951		MODULE, Oil Sensor -Used After Code Date 03010500
333	492341		ARMATURE, Magneto
334	691061		SCREW -(Magneto Armature)
347B	790949		SWITCH, Rocker
356E	696328		WIRE, Stop
361	691681		SCREW -(Starting Switch)
361A	690297		SCREW -(Starting Switch)
474D	695466		ALTERNATOR -(10 Amp Regulated)
493A	691177		BRACKET, Mounting
500	691086		WASHER -(Key Switch)
501	691185		REGULATOR -(16 Amp Regulated)
503	691532		STRAP, Starter
526	690297		SCREW -(Regulator)
575	692303		SWITCH-STARTING
577	690630		CABLE, Starter
578	692306		WIRE ASSEMBLY
578A	790948		WIRE ASSEMBLY
579	691029		NUT -(Starter Cable)
627	696064		BRACKET, Stopswitch
627A	792608		BRACKET, Stopswitch
636	696198		NUT -(Starting Switch)
641	691075		WASHER -(Starting Switch)
641A	690282		WASHER -(Starting Switch)
663A	690372		SCREW -(Control Panel)
664	691087		NUT -(Key Switch)
813	690635		CLAMP
851	692424		TERMINAL, Spark Plug
892	392833		SWITCH, Key
920	691656		SOLENOID, Starter
990	691959		SET, Key
990A	695756		SET, Key
1046	691337		PLUG, Blower Housing
1119	691183		SCREW -(Alternator)



Blower Housing/Shrouds, Flywheel, Rewind Starter

REF NO	PART NO	QTY	DESCRIPTION
23	695485		FLYWHEEL
55	695288		HOUSING-REWIND STR
58	693389		ROPE, Starter -(Cut To Required Length)
59	805957		INSERT, Grip
60	490652		GRIP-STARTER ROPE
65	690759		SCREW -(Rewind Starter)
304	791478		HOUSING, Blower
305	691108		SCREW -(Blower Housing)
332	694685		NUT -(Flywheel)
363	19203		PULLER, Flywheel
455	694683		CUP, Flywheel
456	692299		PLATE-PAWL FRICTION
459	281505S		PAWL-RATCHET
563	695449		SCREW -(Debris Screen Guard)
592	690800		NUT -(Rewind Starter)
597	691696		SCREW -(Pawl Friction Plate)
608	695287		STARTER-REWIND
689	691855		SPRING-FRICTION
695	698807		SCREW -(Ring Gear)
727A	697465		COVER, Starter Drive
732	691097		SCREW -(Starter Drive Cover)
949	790495		GUARD, Debris Screen
1005	694684		FAN, Flywheel
1036	-----		Label-Emissions -(Available From A Briggs & Stratton Authorized Dealer)
1070	691058		SCREW -(Flywheel Fan)
1210	498144		PULLEY/SPRING ASSY -(Pulley)
1211	498144		PULLEY/SPRING ASSY -(Spring)

1058 OPERATOR'S MANUAL



1319 WARNING LABEL

WARNING





Read and follow Operating Instructions before running engine.

Gasoline is flammable. Allow engine to cool at least 2 minutes before refueling.









Engines emit carbon monoxide, DO NOT run in enclosed area.

Muffler area temperature may exceed 150°F. Do not touch hot parts.

REQUIRED when replacing parts with warning labels affixed.













718A





Camshaft, Crankcase Cover, Crankshaft, Cylinder, Lubrication, Operator's Manual, Piston/

REF NO	PART NO	QTY	DESCRIPTION
1	793117		CYLINDER ASSEMBLY
2	698340		KIT, Bushing/Seal -(Magneto Side)
3	391086S		SEAL, Oil -(Magneto Side)
12	694953		GASKET, Crankcase
15	691686		PLUG-OIL DRAIN
16	695817		CRANKSHAFT
17	695434		BEARING, Ball
18	792139		COVER, Crankcase -Used After Code Date 06082000
18	695816		COVER, Crankcase -Used Before Code Date 06082100
19	698340		KIT, Bushing/Seal -(PTO Side)
20	391086S		SEAL, Oil -(PTO Side)
21	281658S		CAP, Oil Fill
22	695174		SCREW -(Crankcase Cover/Sump)
24	222698S		KEY, Flywheel
25	792144		PISTON ASSEMBLY -(.020 Oversize)
25	792117		PISTON ASSEMBLY -(Standard)
26	792026		SET, Ring -(Standard) -Used After Code Date 05081000
26	792073		SET, Ring -(.020 Oversize) -Used After Code Date 05081000
26	694004		SET, Ring -(Standard) -Used Before Code Date 05081100
26	694008		SET, Ring -(.020 Oversize) -Used Before Code Date 05081100
27	690975		LOCK, Piston Pin
28	696581		PIN, Piston -(Standard)
29	694691		ROD, Connecting
30	694692		DIPPER, Connecting Rod
32	690976		SCREW -(Connecting Rod)
46	790958		CAMSHAFT
146	690979		KEY, Woodruff
170	695296		STUD -(Crankcase Cover/Sump)
219	693578		GEAR, Governor
220	691724		WASHER -(Governor Gear)
287	691693		SCREW -(Dipstick Tube)
306	697240		SHIELD, Cylinder -Used After Code Date 01102800
306	694677		SHIELD, Cylinder -Used Before Code Date 01102900
307	691660		SCREW -(Cylinder Shield)





718A



Camshaft, Crankcase Cover, Crankshaft, Cylinder, Lubrication, Operator's Manual, Piston/


REF NO	PART NO	QTY	DESCRIPTION
357	691483		KEY, Drive Pulley
415	691363		PLUG
522	697689		PLUG, Dipstick/Fill
523	695344		DIPSTICK
524	691876		SEAL, O-Ring
525	695343		TUBE, Dipstick
529	791822		GROMMET
552	694674		BUSHING, Governor Crank
718	690959		PIN, Locating
718A	695178		PIN, Locating -(Head)
741	691288		GEAR, Timing
742	692564		RETAINER, E Ring
746	694679		GEAR, Idler
842	691031		SEAL, O-Ring -(Dipstick Tube)
847	695342		DIPSTICK/TUBE ASSEMBLY
1058	277040		MANUAL, Operator's
1194	691876		SEAL, O-Ring -(Plug)
1319	794467		LABEL, Warning

GHOSTED PARTS ARE NOT SERVICEABLE
AND ARE SHOWN FOR REFERENCE ONLY.




WALBRO CARBURETOR

977 CARBURETOR GASKET SET





121 CARBURETOR OVERHAUL KIT



NIKKI CARBURETOR



121A CARBURETOR OVERHAUL KIT



Carburetor, Kit - Carburetor Overhaul


REF NO	PART NO	QTY	DESCRIPTION
51	694874		GASKET, Intake
51A	694875		GASKET, Intake
93	690602		BUSHING, Throttle Shaft
95	691636		SCREW -(Throttle Valve)
95A	690718		SCREW -(Throttle Valve)
97	695325		SHAFT, Throttle
97A	696387		SHAFT, Throttle
98	495800		KIT, Idle Speed -(Idle Speed) (Lmt 54, 55, 91)
98A	695408		KIT, Idle Speed
104	690525		PIN, Float Hinge
104A	694918		PIN, Float Hinge
105	691782		VALVE, Float Needle
105A	696136		VALVE, Float Needle
106	690577		SEAT, Inlet
108	691227		VALVE, Choke
108A	696143		VALVE, Choke
109B	695329		SHAFT, Choke
109C	790148		SHAFT, Choke
117	696134		JET, Main -(Standard)
118	696135		JET, Main -(High Altitude)
121	695441		KIT, Carburetor Overhaul -(Use With Walbro Carburetor)
121A	696146		KIT, Carburetor Overhaul -(Nikki Carburetor)
122	694876		SPACER, Carburetor
125	-----		Carburetor -(To Service Complete Carburetor, See Reference Number 125A)
125A	695920		CARBURETOR -(Nikki Carburetor)
127	694524		PLUG, Welch
127A	690727		PLUG, Welch
130	690468		VALVE, Throttle
130A	696139		VALVE, Throttle
133	494381		FLOAT, Carburetor
133A	694914		FLOAT, Carburetor
135	696142		TUBE, Fuel Transfer
137	281165S		GASKET, Float Bowl
137A	695426		GASKET, Float Bowl
141B	696144		KIT, Choke Shaft
142	695528		NOZZLE, Carburetor -(Standard)
143	695529		NOZZLE, Carburetor -(High Altitude)
163	693458		GASKET, Air Cleaner -(Air Cleaner)
176	691917		SEAL, O-Ring -(Air Cleaner Base)
186	692317		CONNECTOR-HOSE -(90 Degree)
186B	691764		CONNECTOR-HOSE -(Straight)

GHOSTED PARTS ARE NOT SERVICEABLE
AND ARE SHOWN FOR REFERENCE ONLY.




WALBRO CARBURETOR

977 CARBURETOR GASKET SET





121 CARBURETOR OVERHAUL KIT









NIKKI CARBURETOR

121A CARBURETOR OVERHAUL KIT






Carburetor, Kit - Carburetor Overhaul

REF NO	PART NO	QTY	DESCRIPTION
231	691636		SCREW -(Choke Valve)
276	692255		WASHER, Sealing
369	695422		SPRING, Float Bowl
632	694868		SPRING/LINK, Mechanical Governor -(Used With Walbro Carburetors)
632	695917		SPRING/LINK, Mechanical Governor -(Use With Nikki Carburetor)
633	690597		SEAL, Choke/Throttle Shaft
633A	691326		SEAL, Choke/Throttle Shaft
633B	690998		SEAL, Choke/Throttle Shaft
692	691301		SPRING, Detent
950	695407		SCREW -(Float Bowl)
955	695659		PLUG, Carburetor
975	495933		BOWL, Float -(Float Bowl)
975A	696138		BOWL, Float
977	695439		SET, Carburetor Gasket -(Use With Walbro Carburetor)
1127A	695407		SCREW -(Float Bowl) (Float Bowl to Carburetor Body)




Controls, Governor Spring

REF NO	PART NO	QTY	DESCRIPTION
188	690877		SCREW -(Control Bracket)
209	694867		SPRING, Governor
211	695307		SPRING, Governed Idle
222	695380		BRACKET, Control
227	694864		LEVER, Governor Control
265	691024		CLAMP, Casing
267	692577		SCREW -(Casing Clamp)
268	691025		CASING, Control Wire -(Cut To Required Length)
269	691026		WIRE, Control -(Cut To Required Length)
270	691027		NUT -(Control Wire Casing)
271	691028		LEVER, Control
271A	695381		LEVER, Control
278	792008		WASHER -(Governor Lever)
281	697268		PANEL, Control -Used After Code Date 01102800
281	695294		PANEL, Control -Used Before Code Date 01102900
410	695382		LINK, Control
504	695383		SET, Friction Washer
505	691251		NUT -(Governor Control Lever)
562	793216		BOLT -(Governor Lever)
564	692198		SCREW -(Control Cover)
604	699066		COVER, Control
615	694676		RETAINER, Governor Shaft
616	694675		CRANK, Governor
621	692310		SWITCH, Stop
632	694868		SPRING/LINK, Mechanical Governor -(Used With Walbro Carburetors)
632	695917		SPRING/LINK, Mechanical Governor -(Use With Nikki Carburetor)
668	694257		SPACER -(Control Bracket)
773	694258		RETAINER
843	695588		SLEEVE, Lever
1138	694255		NUT -(Control Bracket)




Cylinder Head, Gasket Set - Engine, Gasket Set - Valve, Valves

REF NO	PART NO	QTY	DESCRIPTION
3	391086S		SEAL, Oil -(Magneto Side)
5	793009		HEAD, Cylinder
7	694872		GASKET, Cylinder Head
12	694953		GASKET, Crankcase
13	690360		SCREW -(Cylinder Head)
20	391086S		SEAL, Oil -(PTO Side)
33	499596		VALVE, Exhaust
34	792200		VALVE, Intake
35	694865		SPRING, Valve -(Intake)
36	694865		SPRING, Valve -(Exhaust)
42	499586		KEEPER, Valve
45	690977		TAPPET, Valve
51	694874		GASKET, Intake
51A	694875		GASKET, Intake
163	693458		GASKET, Air Cleaner -(Air Cleaner)
176	691917		SEAL, O-Ring -(Air Cleaner Base)
192	690083		ADJUSTER, Rocker Arm
337	491055S		PLUG, Spark
337	84007216	1	PLUG, SPARK -(China Only)
358	695438		GASKET SET, Engine
383	19374S		WRENCH, Spark Plug
635	691909		BOOT, Spark Plug
798	697890		SCREW -(Rocker Arm)
868	690968		SEAL, Valve
883	695398		GASKET, Exhaust
914	693732		SCREW -(Rocker Cover)
1022	690971		GASKET, Rocker Cover
1023	697691		COVER, Rocker
1026	695177		ROD, Push
1029	690972		ARM, Rocker
1095	695440		GASKET SET, Valve
1100	791959		PIVOT, Rocker Arm



Electric Starter, Gear Reduction

REF NO	PART NO	QTY	DESCRIPTION
15A	691682		PLUG-OIL DRAIN
79	690614		CASE, Gear Reduction -Used Before Code Date 07021600
79A	793590		CASE, Gear Reduction -Used After Code Date 07021500
80	691603		GASKET, Gear Case -Used Before Code Date 07021600
80A	793588		GASKET, Gear Case -Used After Code Date 07021500
82	690287		SCREW -(Gear Reduction Case) -Used Before Code Date 07021600
82A	792753		SCREW -(Gear Reduction Case) -Used After Code Date 07021500
83	690387		SHAFT, Auxiliary Drive
84	691121		PLUG-BREATHER
85	691076		SCREW -(Gear Cover to Gear Reduction Case)
86	690613		COVER, Gear -Used Before Code Date 07021600
86A	793591		COVER, Gear -Used After Code Date 07021500
87	391086S		SEAL, Oil
88	691601		GASKET, Gear Cover/Housing -Used Before Code Date 07021600
88A	793589		GASKET, Gear Cover/Housing -Used After Code Date 07021500
272	691168		LOCK, Screw Head
277	691075		WASHER -(Gear Case To Gear Reduction)
309	695479		MOTOR, Starter
310	690323		SCREW -(Starter Motor)
415B	690283		PLUG, Oil -(1/8 Standard)
503	691532		STRAP, Starter
510	693699		DRIVE, Starter
513	692024		CLUTCH, Drive
544	692034		ARMATURE, Starter -(3 5/8 Housing)
579	691029		NUT -(Starter Cable)
783	693713		GEAR, Pinion
801	694482		CAP-DRIVE
802	691286		CAP, End
803	-----		Housing-Starter -(Not Serviced Separately, Order Starter Motor 695479)
1051	691265		RING, Retaining
1090	691293		RETAINER, Brush



Fuel Supply

REF NO	PART NO	QTY	DESCRIPTION
187	791766		LINE, Fuel -(15" Long)(Cut to Required Length)
187A	791869		LINE, Fuel -Used After Code Date 05063000
187A	695429		LINE, Fuel -Used Before Code Date 05070100
187B	695482		LINE, Fuel -Used Before Code Date 05070100
187C	695483		LINE, Fuel -Used Before Code Date 05070100
187B	791834		LINE, Fuel -Used After Code Date 05063000
187C	791871		LINE, Fuel -Used After Code Date 05063000
190	692127		SCREW -(Fuel Tank)
240A	694485		FILTER, Fuel
364A	699947		TERMINAL, Oil Plug
387	808656		PUMP, Fuel
601	791850		CLAMP, Hose
628	690297		SCREW -(Fuel Pump Bracket)
774	695447		SCREW -(Stop Wire)
799	695446		SCREW -(Oil Sensor)
799A	690297		SCREW -(Oil Sensor)
813	690635		CLAMP
918	393815		HOSE, Vacuum -(Cylinder To Impulse Pump)(Cut To Required Length)
957	792647		CAP, Fuel Tank -(Plastic)
958	698180		VALVE, Fuel Shutoff -(Plastic)
972A	694260		TANK, Fuel -(Plastic)
1052A	791159		SENSOR, Oil

Replacement Engine - US & Canada

REF NO	PART NO	QTY	DESCRIPTION
	20S2520049	1	Replacement Engine
	794908	1	Replacement Short Block
	-----		Top No-Load Speed: 3600 -Trim: ALL
	-----		Service Note: Gear Red. @ 3 o'clock.
	-----		Service Note: Transfer Flywheel, Blower Housing , Alternator and/or Gear Drive Electric Starter and Panel Assembly to replacement engine.
	-----		Service Note: For all Go-Karts use only a Model 136200 series engine as a replacement, regardless of the original Model.

